

Set up the parameters of the servo amplifier (hereinafter called amplifier) to perform the Modbus communications.

(1) Protocol selection

No.	Parameter name	Setting range	Default value	Change
PA2_97	Communication protocol selection	0: PC Loader protocol 1: Modbus RTU	0	Power



Set to 1 (Modbus RTU).

Since this parameter is set to 0 (PC Loader protocol) at factory shipment, be sure to change it to 1.


(2) Station number/communication baud rate

No.	Parameter name	Setting range	Default value	Change
PA2_72	Station number	1 to 31	1	Power
PA2_73	Communication baud rate	0··· 38400 [bps] 1··· 19200 [bps] 2··· 9600 [bps] 3··· 115200 [bps]	0	Power


Set an amplifier's station number (slave's station number) and a communication baud rate.

(3) Character configuration

No.	Parameter name	Setting range	Default value	Change
PA2_93	Selection of parity/stop bit	0: Even parity with 1 stop bit 1: Odd parity with 1 stop bit 2: No parity with 1 stop bit 3: Even parity with 2 stop bits 4: Odd parity with 2 stop bits 5: No parity with 2 stop bits	0	Power



In case of using Fuji's MONITOUCH



- Connect between Smart and Smart with a commercial LAN cable (straight).