

## PG Interface Card "OPC-PG3ID"


Thank you for purchasing this PG interface card "OPC-PG3ID." Installing this card to your FRENIC-series enables to provide motor control according to feedback signal from encoder (12V/15V/24V complementary or open-collector type).

**Note** • Connect this PG interface card to the C-port on control board of FRENIC-series. Do not connect it to any other port.

### 1. Acceptance inspection

- (1) A PG interface card and two screws (M3 × 8) are contained in the package.
- (2) The PG interface card is not damaged during transportation--no defective devices, dents or warps.
- (3) The model name "OPC-PG3ID" is printed on the front of the PG interface card as shown in Figure 1.1. (The "PG" on the front is a short name, as shown in Figure 1.1.)

If you suspect the product is not working properly or if you have any questions about your product, contact the shop where you bought the product or your local Fuji branch office.



### 2. Installation Procedure

#### ⚠ WARNING

Before starting installation and wiring, turn OFF the power and wait at least five minutes for inverters with a capacity of 22 kW or below, or at least ten minutes for inverters with a capacity of 30 kW or above. Make sure that the LED monitor and charging lamp are turned OFF. Further, make sure, using a multimeter or a similar instrument, that the DC link bus voltage between the terminals P(+) and N(-) has dropped to the safe level (+25 VDC or below).

**Otherwise, electric shock could occur.**

- (1) Perform wiring on the PG interface card.

Refer to Section 4. "Wiring"


TERM1 is the removable terminal. Use it with below precautions.

#### ⚠ CAUTION

- Remove and connect the removable terminal after PG interface card is removed from inverter.
- Remove the removable terminal from the PG interface card by the tool (e.g. the straight slot screw

**Otherwise, injuries could occur.**

**Failure may occur the PG interface card**



- (2) Remove the front cover from the inverter and expose the control printed circuit board (control PCB). The PG interface card can be connected to the C-port only.
  - To remove the front cover, refer to the FRENIC-series Instruction Manual. For inverters with a capacity of 30 kW or above, open also the keypad enclosure.
- (3) Insert connector CN1 on the back of the PG interface card into the C-port on the inverter's control PCB. Then tighten the two screws that come with the card.
  - Note** Check that the positioning cutout is fitted on the tab and connector CN1 is fully inserted. Do not connect the PG interface card to the ports other than C-port. Doing so may damage the card.
- (4) If necessary, Please set change of the divided output with disconnection detection.
  - Refer to Section 8 "Setting."
- (5) Put the front cover back into place.
  - To put back the front cover, refer to the FRENIC-series Instruction Manual. For inverters with a capacity of 30 kW or above, close also the keypad enclosure.

### 3. Product Guarantee

The product guarantee term is one year after installation or two years after manufacturing on the nameplate, whichever expires first. However, the guarantee will not apply in the following cases, even if the guarantee term has not expired.

- (1) The cause includes incorrect usage or inappropriate repair or modification.
- (2) The product is used outside the standard specified range.
- (3) The failure is caused by dropping, damage or breakage during transportation after the purchase.
- (4) The cause is earthquake, fire, storm or flood, lightning, excessive voltage, or other types of disaster or secondary disasters.

### 4. Wiring

<b>⚠ WARNING</b>
In general, the covers of the control signal wires are not specifically designed to withstand a high voltage (i.e., reinforced insulation is not applied). Therefore, if a control signal wire comes into direct contact with a live conductor of the main circuit, the insulation of the cover might break down, which would expose the signal wire to a high voltage of the main circuit. Make sure that the control signal wires will not come into contact with live conductors of the main circuit. <b>Failure to observe this precaution could cause electric shock or an accident.</b>

<b>⚠ CAUTION</b>
Noise may be emitted from the inverter, motor and wires. Take appropriate measures to prevent the nearby sensors and devices from malfunctioning due to such noise. <b>An accident could occur.</b>

Perform wiring properly, referring to Figure 4.1 and Table 4.1 shown below.

FA	CM	FB	CM	PO	CM	PO	CM	PA	PB	PZ
----	----	----	----	----	----	----	----	----	----	----

Figure 4.1 Terminal Allocations and Symbol Diagram of OPC-PG3ID

Table 4.1 Terminal Specifications

Terminal Size	M2
Tightening Torque	0.22 to 0.25 N·m
Recommended Wire Gauge*	AWG16 to 26
Wire strip length	5 mm

\* Insulated wires with allowable temperature of 105°C (UL-listed) are recommended.

## 5. Specifications of applicable encoder and PG interface card

Specifications of applicable encoder and PG interface card are shown in Table 5.1.

Table 5.1 Specifications of applicable encoder and PG interface card

Item	Specifications
Encoder output pulse frequency	30 kHz max. (Open-collector) *1 100 kHz max. (Complementary)
Encoder pulse resolution	20 to 60000 P/R, A, B and Z phase (incremental)
Input pulse threshold	High level : 8V or more Low level : 3V or less
Pulse input current	12mA <sub>dc</sub> max(Power supply: 24V) 8mA <sub>dc</sub> max(Power supply: 15V) 6mA <sub>dc</sub> max(Power supply: 12V)
Encoder power supply	+12V <sub>dc</sub> ±10% / 210mA or less +15V <sub>dc</sub> ±10% / 168mA or less +24V <sub>dc</sub> ±10% / 100mA or less
Pulse output circuit	Open-collector: max 27V <sub>dc</sub> , 50mA(Sink) Maximum cable length: 20 m Maximum output frequency: 30kHz with complementary encoder 15kHz with open-collector encoder

\*1 External pull-up resistors may be necessary depending on Max pulse frequency and encoder wiring length when open-collector type encoder is applied. Refer to chapter 9.2. for details.

## 6. Storage Environment

### 6.1. Temporary Storage

Store the option card in an environment that satisfies the requirements listed in Table 6.1.

Table 6.1 Environmental Requirements for Storage and Transportation

Item	Requirements
Storage Temperature * 1	-25 to 70°C
Relative humidity	5 to 95% * 2
Atmosphere	The inverter must not be exposed to dust, direct sunlight, corrosive or flammable gases, oil mist, vapor, water drops or vibration. The atmosphere must contain only a low level of salt. (0.01 mg/cm <sup>2</sup> or less per year)
Atmospheric pressure	86 to 106 kPa (in storage) 70 to 106 kPa (during transportation)

\* 1 Assuming a comparatively short storage period (e.g., during transportation or the like)

\* 2 Even if the humidity is within the specified requirements, avoid such places where the option card will be subjected to sudden changes in temperature that will cause condensation to form.

### Precautions for temporary storage

- (1) Do not leave the inverter directly on the floor.
- (2) If the environment does not satisfy the specified requirements, wrap the option card in an airtight vinyl sheet or the like for storage.
- (3) If the option card is to be stored in an environment with a high level of humidity, put a drying agent (such as silica gel) in the airtight package described in item (2).

### 6.2. Long-term Storage

The long-term storage methods for the inverter vary largely according to the environment of the storage site. General storage methods are described below.

- (1) The storage site must satisfy the requirements specified for temporary storage.
- (2) The inverter must be stored in a package that is airtight to protect it from moisture. Include a drying agent inside the package to maintain the relative humidity inside the package to within 70%.
- (3) If the option card has been installed in the equipment or control board at a construction site where it may be subjected to humidity, dust or dirt, then remove the option card and store it in a suitable environment specified in Table 6.1.

## 7. Terminal Functions

Table 7.17.1 lists terminal specifications.

Table 7.1 Terminal Specifications

Terminal symbol	Name	Functions
[PO]	Power supply for encoder *1	12Vdc±10%, max.210mAdc (Factory default setting ) 15Vdc±10%, max.168mAdc 24Vdc±10%, max.100mAdc
[CM]	Common terminal of power supply	0Vdc (GND for power supply)
[PA]	Pulse input terminal A	Input frequency max.30kHz (Open-collector)
[PB]	Pulse input terminal B	Input frequency max.100kHz (Complementary)
[PZ]	Pulse input terminal Z	Complementary or open-collector
[FA]	Pulse output terminal FA	Open-collector Ratio of dividing frequency setting 1/1, 1/2, 1/4, 1/8, 1/16, 1/32, 1/64, 1/128
[FB]	Pulse output terminal FB	Wavy accuracy : refer to Figure 7.1 Maximum output frequency: 30kHz with complementary encoder 15kHz with open-collector encoder

\*1 Turn the internal switch (SW2) to the proper position according to the encoder power requirement. The factory default position is "12V."

\*2 External pull-up resistors may be necessary depending on maximum pulse frequency and encoder wiring length when open-collector type encoder is applied.




Figure 7.1 Accuracy of line driver output.

## 8. Setting

### 8.1. Setting up the switch For OPC-PG3ID





Figure 8.1 Location of the Switch on OPC-PG3ID

Figure 8.2 Switching example and factory default



Change the switch position using a tool with pointed end (end of tweezers, etc.) while taking care to avoid touching other electrical parts and so on.  
If the slider is in the center, this means that it is open. Push the slider in fully.

### 8.2. Switching between power supplies for the encoder

Before powering on the inverter, switch power supplies for the encoder using jumper SW2 referring to Figure 8.3.




Figure 8.3 Configuration of Jumper SW2



When changing the output setting, set inverter output to OFF.

### 8.3. Output signals of dividing frequency

The input pulse from encoder is divided, and it is possible to output. The division ratio 「n」 is set with dip switch SW1 on the option card. Figure 8.4 shows externals of the ratio of dividing frequency set switch of the pulse output. Table 8.18.1 shows the method of setting SW1.




Figure 8.4 Ratio of dividing frequency set switch

Table 8.1 Division ratio setting

SW1 setting	n : Division ratio
0,8	1 (Factory default setting)
1,9	2
2	4
3	8
4	16
5	32
6	64
7	128

## ⚠ CAUTION

When changing the dividing frequency output setting, turn the power OFF.  
 If settings are changed with the power ON, pulses will be output from the line driver output even if the inverter is stopped.  
**There is a possibility that the system will malfunction.**

### 8.4. Enabling/disabling the wire break detection function with DIP SW3

The PG interface card has a wire break detection function that detects wire breaks in the encoder wiring. It is possible to enable/disable this detection function in each of the PA, PB, and PZ phases. Please refer to Table 8.2 when enabling/disabling the detection function for each phase with the DIP SW3.

Table 8.2 Enabling/Disabling the Wire Break Detection Function

Selector DIP SW3	Wire Break Detection Function		
	XA phase	XB phase	XZ phase
ON	EN	EN	EN
OFF	DIS	DIS	DIS
Z-OFF	EN	EN	DIS



When using an open-collector encoder, a disconnection will be mistakenly detected, and therefore DIP SW3 must be turned to OFF.  
 If using a complimentary encoder without Z phase or if Z phase is not connected to this option card, turn DIP SW3 to Z-OFF.

### 8.5. Encoder installation and signal

The encoder shall rotate in the direction of Figure 8.5 when terminal FWD is ON. Encoder output pulse is shown the Figure 8.6. Connect the encoder directly to the motor using a coupling. If encoder rotation is different from Figure 8.5, change the parameter of H190. The rotational direction of IEC standard motors is opposite to Figure 8.5.




Figure 8.5 Motor and encoder rotational direction when terminal FWD is ON




Figure 8.6 Encoder signals

## 9. Drive Control

For details of PG interface functions available, refer to the FRENIC-series Instruction Manual, "Details of Function Codes" or the FRENIC-series User's Manual.

### 9.1. Speed control (Vector control with speed sensor)

The inverter detects the motor's rotational speed from PG feedback signals, decomposes the motor drive current into the exciting and torque current components, and controls each of components in vector. The vector control enables speed control with high accuracy and high response.

For settings and adjustments of the vector control, refer to FRENIC-series Instruction Manual and FRENIC-series User's Manual.

### 9.2. Connection diagram examples

Figure 9.1 B shows the connection diagram example for speed control.




Figure 9.1 Basic Wiring Diagram.

- \*1 Use shielding wire for wiring. It is recommended that the shield for FA, FB and CM wiring is grounded and the shield for encoder wiring is connected to CM terminal.  
However, an effect may not be acquired by the ground grounding environment to device.  
In this case, it may improve by connecting the shield for FA, FB and CM wiring to CM terminal or the shield for encoder wiring to ground terminal. Take the shield connection that best fits your system.
- \*2 To prevent malfunction resulting from noise, try as best as possible to keep the PG interface card wiring separate from the main circuit wiring. Employ such measures as bundling wires together inside the inverter to ensure that the PG interface card wiring does not come into direct contact with live parts of the main circuit (e.g., main circuit terminal block). If the wiring between the encoder and inverter is long, signal output from the encoder may malfunction as a result of A phase and B phase interference, possibly resulting in abnormal noise or torque pulsation. In a case such as this, improvements may be seen by significantly shortening the wiring length (review of wiring route) or using cables with low stray capacitance may be made. Review the shielding wire if the influence of noise remains significant even after taking the above measures.
- \*3 External pull-up resistors may be necessary between PO and PA, PB, PZ depending on maximum pulse frequency and encoder wiring length when open-collector type encoder is applied. If PO current exceed its maximum values due to the pull-up resistors, the external power supply for the encoder may be necessary. Refer to Figure 9.2, Figure 9.3, Table 9.1, Table 9.2 Table 9.3. The stray capacitance of encoder wiring is 0.3nF/m or less per phase for guide line of the installation.




Figure 9.2 Application of Pull-up resistors




Figure 9.3 Application of Pull-up resistors and External power supply

Table 9.1 Encoder wiring length vs Maximum allowable pulse frequency

Encoder Wiring length [m]	Maximum allowable pulse frequency [kHz]		
	Encoder Power supply 12V	Encoder Power supply 15V	Encoder Power supply 24V
5	8.1	18.0	30.0
10	4.9	11.3	22.1
15	3.4	8.2	16.5
20	2.6	6.4	13.2

Table 9.2 Encoder Power supply vs Maximum allowable encoder wiring length (Pulse freq.30kHz)

Encoder Power supply	Maximum allowable encoder wiring length [m]
12V	N/A
15V	1.5
24V	6.1

Table 9.3 Encoder Wiring length vs External pull-up resistors  
(Pulse freq.30kHz, Encoder wiring length 20m)

Encoder Wiring length [m]	External pull-up resistors		
	Encoder Power supply 12V	Encoder Power supply 15V	Encoder Power supply 24V
5	1.3kΩ	3.3kΩ	N/A
10	680Ω	1.2Ω	5.1kΩ
15	430Ω	750Ω	2.2kΩ
20	330Ω	560Ω	1.5kΩ

## Fuji Electric Co., Ltd.

Gate City Ohsaki, East Tower, 11-2, Osaki 1-chome, Shinagawa-ku, Tokyo, 141-0032, Japan

Phone: +81 3 5435 7058 Fax: +81 3 5435 7420

URL <http://www.fujielectric.com/>