

User's Manual

USER'S MANUAL

FRENIC-VG Series

Unit Type / Function Codes Edition

High Performance, Vector Control Inverter
FRENIC-VG

User's Manual
(Unit Type / Function Codes Edition)

| Revision History | Index | Date of Revision | Revision Contents |
|------------------|-------|------------------|--------------------|
| 1st Edition | — | 2013-03 | First Edition |
| 2nd Edition | a | 2019-02 | Content is updated |
| 3rd Edition | b | 2019-07 | Content is updated |

Copyright © 2012-2019 Fuji Electric Co., Ltd.

All rights reserved.

No part of this publication may be reproduced or copied without prior written permission from Fuji Electric Co., Ltd.

All products and company names mentioned in this manual are trademarks or registered trademarks of their respective holders.

The information contained herein is subject to change without prior notice for improvement.

Preface

This manual provides the following information on the FRENIC-VG series of inverters.

- Function codes available in the FRENIC-VG series (Unit type/Stack type) and keypad operation
- Unit type inverter specifications, installation, and selection of peripheral equipment

Carefully read this manual for proper use. Incorrect handling of the inverter may prevent the inverter or related equipment from operating correctly, shorten their lives, or cause problems.

The table below lists the materials related to the use of the FRENIC-VG. Read them in conjunction with this manual as necessary.

| Name | | Manual No. | Description |
|---|---|----------------------------------|--|
| Catalog | | 24A1-□-0002* (Old No. MH659) | Product scope, features, specifications, external drawings, and options of the product |
| User's Manuals | Unit Type / Function Codes Edition (this manual) | 24A7-□-0019* (Old No. MHT286) | 1) Function codes, keypad operation, etc. for the FRENIC-VG series (Unit type/Stack type) 2) Outline, features, specifications, replacement data, etc. of the FRENIC-VG Unit type |
| | Option Edition | 24A7-□-0045* (Old No. MHT286) | Functions of various option cards, RS-485 interface, etc. available for the FRENIC-VG series * For the optional functional safety card (OPC-VG1-SAFE), refer to the option card instruction manual. Other options are described in this manual. |
| | Stack Type Edition | 24A7-□-0018* | Features, specifications, cabinet design materials, etc. of the FRENIC-VG Stack type and the converter |
| | UPAC Option Edition | 24A7-□-0044* | UPAC option card specifications, INV↔UPAC interface, application package software (orientation and dancer type of winders), etc. |
| Instruction Manual (FRENIC-VG Unit Type) | | INR-SI47-1580*-□ | Acceptance inspection, mounting & wiring of the inverter, operation using the keypad, troubleshooting, and maintenance and inspection, specifications, etc. |
| FRENIC-VG Loader Instruction Manual | WPS-VG1-STR | INR-SI47-1617*-□ | Instructions for inverter support software FRENIC-VG Loader (free version) |
| | WPS-VG1-PCL | INR-SI47-1589*-□ | Instructions for FRENIC-VG Loader (paid-for version) including the tracing function not supported by the WPS-VG1-STR (free version) |

Note 1: A box (□) in the above table replaces an alphabet letter: J (Japanese), E (English), or C (Chinese).
An asterisk (*) replaces a revision code (a, b, c,...).

Note 2: The materials are subject to change without notice. Be sure to obtain the latest editions for use.

Guideline for Suppressing Harmonics in Home Electric and General-purpose Appliances

Our three-phase, 200 V class series inverters of 3.7 kW or less (FRENIC-VG series) were the products of which were restricted by the "Guideline for Suppressing Harmonics in Home Electric and General-purpose Appliances" (established in September 1994 and revised in October 1999) issued by the Ministry of Economy, Trade and Industry.

The above restriction, however, was lifted when the Guideline was revised in January 2004. Since then, the inverter makers have individually imposed voluntary restrictions on the harmonics of their products.

We, as before, recommend that you connect a reactor (for suppressing harmonics) to your inverter. As a reactor, select a "DC REACTOR" introduced in this manual. For use of the other reactor, please inquire of us about detailed specifications.

Japanese Guideline for Suppressing Harmonics by Customers Receiving High Voltage or Special High Voltage

Refer to Appendix B in this manual for details on this guideline.

How this manual is organized

This manual contains Chapters 1 through 13 and Appendices.

Chapter 1 OVERVIEW

This chapter describes the overview, features and the control system of the FRENIC-VG series and the recommended configuration for the inverter and peripheral equipment.

Chapter 2 SPECIFICATIONS

This chapter describes specifications of the output ratings, control system, dedicated motor specifications, and terminal functions for the FRENIC-VG series of inverters. It also provides descriptions of the external dimensions, examples of basic connection diagrams, and details of the protective functions.

Chapter 3 PREPARATION AND TEST RUN

This chapter describes the operating and storage environments, installation and wiring, typical connection diagram, names and functions of keypad components, keypad operation, and test run procedure.

Chapter 4 CONTROL AND OPERATION

This chapter provides the main block diagrams for the control logic of the FRENIC-VG series of inverters. It also contains overview tables of function codes and details of function codes.

Chapter 5 USING STANDARD RS-485 ... See the Option Edition (24A7-E-0045) separately issued.

This chapter describes the use of standard RS-485 communications ports and provides an overview of the FRENIC-VG Loader.

Chapter 6 CONTROL OPTIONS ... See the Option Edition (24A7-E-0045) separately issued.

This chapter describes the FRENIC-VG's control options.

Chapter 7 APPLICATION EXAMPLES

This chapter gives application examples of the FRENIC-VG series of inverters.

Chapter 8 SELECTING PERIPHERAL EQUIPMENT

This chapter describes how to use a range of peripheral equipment and options, FRENIC-VG's configuration with them, and requirements and precautions for selecting wires and crimp terminals.

Chapter 9 SELECTING OPTIMAL MOTOR AND INVERTER CAPACITIES

This chapter provides you with information about the inverter output torque characteristics, selection procedure, and equations for calculating capacities to help you select optimal motor and inverter models. It also helps you select braking resistors and inverter mode (HD, MD, or LD).

Chapter 10 ABOUT MOTORS

This chapter details vector motors that can be connected to the FRENIC-VG series of inverters.

Chapter 11 OPERATION DATA

This chapter provides the characteristics data of the FRENIC-VG series of inverters running.

Chapter 12 REPLACEMENT DATA

When replacing the former inverters (VG, VG3, VG5) with FRENIC-VG, refer to this section.

Chapter 13 TROUBLESHOOTING

This chapter describes troubleshooting procedures to be followed when the inverter malfunctions or detects an alarm or a light alarm condition. In this chapter, first check whether any alarm code or the "light alarm" indication ($\text{L} - \text{AL}$) is displayed or not, and then proceed to the troubleshooting items.

Appendices

CONTENTS

Chapter 1 OVERVIEW

| | | |
|---------|--|------|
| 1.1 | Overview | 1-1 |
| 1.1.1 | Industry-best control performance | 1-1 |
| 1.1.2 | System support | 1-1 |
| 1.1.3 | Extensive built-in functionality | 1-1 |
| 1.1.4 | Broad capacity and application ranges | 1-2 |
| 1.1.5 | Global support | 1-2 |
| 1.2 | Features | 1-3 |
| 1.2.1 | Best-in-industry control performance | 1-3 |
| 1.2.2 | Support for various control systems (multi-drive function) | 1-4 |
| 1.2.3 | Broad capacity range/flexible application range | 1-4 |
| 1.2.4 | User program functionality (UPAC option) | 1-4 |
| 1.2.5 | Extensive network support | 1-5 |
| 1.2.6 | Inverter support software "FRENIC-VG Loader" | 1-5 |
| 1.2.7 | Extensive built-in functionality | 1-6 |
| 1.2.8 | Extensive maintenance and protective functionality | 1-7 |
| 1.2.9 | Environmental considerations | 1-8 |
| 1.2.10 | Simple, interactive keypad | 1-10 |
| 1.2.11 | Compliance with overseas standards | 1-11 |
| 1.2.12 | Compliance with functional safety standards | 1-11 |
| 1.2.13 | Compatibility with legacy models | 1-11 |
| 1.3 | Control Systems | 1-12 |
| 1.3.1 | Control system features and applications | 1-12 |
| 1.3.1.1 | Open-loop speed control | 1-12 |
| 1.3.1.2 | Closed-loop speed control | 1-14 |

Chapter 2 SPECIFICATIONS

| | | |
|---------|---|------|
| 2.1 | Standard Model 1 (Basic Type) | 2-1 |
| 2.1.1 | HD (High Duty)-mode inverters for heavy load | 2-1 |
| 2.1.2 | MD (Medium Duty)-mode inverters for medium load | 2-3 |
| 2.1.3 | LD (Low Duty)-mode inverters for light load | 2-4 |
| 2.1.4 | Rated current derating | 2-6 |
| 2.2 | Common Specifications | 2-10 |
| 2.3 | External Dimensions | 2-16 |
| 2.3.1 | Standard models | 2-16 |
| 2.3.2 | Keypad | 2-27 |
| 2.4 | Dedicated Motor Specifications | 2-28 |
| 2.4.1 | Induction motor (IM) with speed sensor | 2-28 |
| 2.4.2 | Permanent magnet synchronous motor (PMSM) with speed sensor | 2-32 |
| 2.5 | Protective Functions | 2-38 |
| 2.6 | Connection Diagrams and Terminal Functions | 2-42 |
| 2.6.1 | Connection diagrams | 2-42 |
| 2.6.1.1 | Running the MVK type of an induction motor (dedicated motor) | 2-42 |
| 2.6.1.2 | Running the GNF2 type of a permanent magnet synchronous motor (dedicated motor) | 2-44 |
| 2.6.2 | List of terminal functions | 2-46 |

Chapter 3 PREPARATION AND TEST RUN

| | | |
|-------|---|-----|
| 3.1 | Before Use | 3-1 |
| 3.1.1 | Acceptance inspection (Nameplates and type of inverter) | 3-1 |
| 3.1.2 | External view and terminal blocks | 3-3 |
| 3.2 | Precautions for Using Inverters | 3-5 |
| 3.2.1 | Installation environment | 3-5 |
| 3.2.2 | Storage environment | 3-6 |

| | | |
|----------|---|-------|
| 3.2.3 | Wiring precautions | 3-7 |
| 3.2.4 | Precautions for connection of peripheral equipment | 3-8 |
| 3.2.5 | Noise reduction | 3-12 |
| 3.2.6 | Leakage current | 3-12 |
| 3.2.7 | Precautions in driving a permanent magnet synchronous motor (PMSM) | 3-12 |
| 3.3 | Mounting and Wiring the Inverter | 3-13 |
| 3.3.1 | Operating environment | 3-13 |
| 3.3.2 | Installing the Inverter | 3-14 |
| 3.3.3 | Wiring | 3-16 |
| 3.3.3.1 | Removing and mounting the front cover and the wiring guide | 3-16 |
| 3.3.3.2 | Screw specifications and recommended wire sizes | 3-17 |
| 3.3.3.3 | Arrangement of terminals | 3-19 |
| 3.3.3.4 | Wiring precautions | 3-22 |
| 3.3.3.5 | Connection diagram | 3-25 |
| 3.3.3.6 | Detailed functions of main circuit terminals and grounding terminals | 3-27 |
| 3.3.3.7 | Switching connectors | 3-31 |
| 3.3.3.8 | Detailed functions of control circuit terminals | 3-33 |
| 3.3.3.9 | Setting up the slide switches | 3-42 |
| 3.3.4 | Mounting and connecting a keypad | 3-44 |
| 3.3.4.1 | Parts required for connection | 3-44 |
| 3.3.4.2 | Mounting procedure | 3-44 |
| 3.3.5 | USB connectivity | 3-48 |
| 3.4 | Operation Using the Keypad | 3-49 |
| 3.4.1 | Names and functions of keypad components | 3-49 |
| 3.4.2 | Overview of operation modes | 3-52 |
| 3.4.3 | Running mode | 3-53 |
| 3.4.3.1 | Configuring the speed command | 3-53 |
| 3.4.3.2 | Running or stopping the motor | 3-54 |
| 3.4.3.3 | Monitoring the running status on the LED monitor | 3-56 |
| 3.4.3.4 | Jogging (inching) the motor | 3-57 |
| 3.4.3.5 | Monitoring light alarms | 3-58 |
| 3.4.4 | Programming mode | 3-60 |
| 3.4.4.1 | Selecting language -- Menu #0 "LANGUAGE" | 3-66 |
| 3.4.4.2 | Configuring function codes -- Menu #1 "DATA SET" | 3-67 |
| 3.4.4.3 | Checking function code data -- Menu #2 "DATA CHECK" | 3-69 |
| 3.4.4.4 | Monitoring the running status -- Menu #3 "OPR MNTR" | 3-71 |
| 3.4.4.5 | Checking I/O signal status -- Menu #4 "I/O CHECK" | 3-74 |
| 3.4.4.6 | Reading maintenance information -- Menu #5 "MAINTENANCE" | 3-77 |
| 3.4.4.7 | Measuring load factor -- Menu #6 "LOAD FCTR" | 3-79 |
| 3.4.4.8 | Reading alarm information -- Menu #7 "ALM INF" | 3-80 |
| 3.4.4.9 | Viewing causes of alarm -- Menu #8 "ALM CAUSE" | 3-83 |
| 3.4.4.10 | Copying data -- Menu #10 "DATA COPY" | 3-84 |
| 3.4.4.11 | Checking changed function codes -- Menu #11 "CHANGES" | 3-88 |
| 3.4.4.12 | Setting the calendar clock -- Menu #12 "DATE/TIME" | 3-89 |
| 3.4.4.13 | Limiting function codes to be displayed -- Menu #14 "LIMITED FC" | 3-91 |
| 3.5 | Test Run Procedure | 3-92 |
| 3.5.1 | Checking prior to powering On | 3-93 |
| 3.5.2 | Powering ON and checking | 3-94 |
| 3.5.2.1 | Checking the input state of PG (pulse generator) signals | 3-94 |
| 3.5.2.2 | Mounting direction of a PG (pulse generator) and PG signals | 3-95 |
| 3.5.3 | Selecting a desired motor drive control | 3-96 |
| 3.5.3.1 | Vector control for IM with speed sensor | 3-96 |
| 3.5.3.2 | Vector control for IM without speed sensor | 3-98 |
| 3.5.3.3 | Vector control for PMSM with speed sensor and magnetic pole position sensor | 3-100 |
| 3.5.3.4 | V/f control for IM | 3-103 |
| 3.5.4 | Running the inverter for operation check | 3-105 |
| 3.5.4.1 | Test run procedure for induction motor (IM) | 3-105 |
| 3.5.4.2 | Test run procedure for permanent magnet synchronous motor (PMSM) | 3-106 |

| | | |
|---------|---|-------|
| 3.5.5 | Selecting a speed command source | 3-113 |
| 3.5.5.1 | Setting up a speed command from the keypad | 3-113 |
| 3.5.5.2 | Setting up a speed command with an external potentiometer | 3-113 |
| 3.5.5.3 | Setting up a speed command with multistep speed selection | 3-114 |
| 3.5.6 | Selecting a run command source | 3-115 |
| 3.5.6.1 | Setting up a run command from the keypad | 3-115 |
| 3.5.6.2 | Setting up a run command with digital input signals (terminals [FWD] and [REV]) | 3-115 |

Chapter 4 CONTROL AND OPERATION

| | | |
|---------|---|-------|
| 4.1 | Block Diagrams for Control Logic | 4-1 |
| 4.1.1 | Operation Command | 4-1 |
| 4.1.2 | Speed Command Selection Section | 4-2 |
| 4.1.3 | Acceleration/deceleration Calculation, Speed Limiting, and Position Control Input Section | 4-3 |
| 4.1.4 | Motor Speed/Line Speed Detection | 4-4 |
| 4.1.5 | Pulse Train Command Input Section and Position Detection Section | 4-5 |
| 4.1.6 | Speed Control (ASR) and Torque Command Section | 4-6 |
| 4.1.7 | Torque Limit, Torque Current Command, and Magnetic-flux Command Section | 4-7 |
| 4.1.8 | Current Control and Vector Control Section | 4-8 |
| 4.1.9 | PID Calculation Section | 4-9 |
| 4.1.10 | Load Adaptive Control Section | 4-10 |
| 4.1.11 | Motor Temperature Detection Section | 4-11 |
| 4.1.12 | Function Selection Digital Input | 4-12 |
| 4.1.13 | Function Selection Digital Output/Fault Output | 4-13 |
| 4.1.14 | Function Selection Analog Input/Output | 4-14 |
| 4.1.15 | Link Command Function Selection | 4-15 |
| 4.1.16 | Enabling to Write to/Recording Function Codes | 4-16 |
| 4.2 | Function Code Tables | 4-17 |
| 4.2.1 | Function Code Groups and Function Codes | 4-17 |
| 4.2.2 | About the Contents of Column Headers in Function Code Tables | 4-18 |
| 4.2.3 | Function Code Tables | 4-19 |
| 4.2.4 | Data Format List | 4-59 |
| 4.2.4.1 | Data Type 0 to 13 | 4-59 |
| 4.2.4.2 | Data Type 12 to 145 | 4-59 |
| 4.3 | Details of Function Codes | 4-76 |
| 4.3.1 | F codes (Fundamental Functions) | 4-76 |
| 4.3.2 | E codes (Extension Terminal Functions) | 4-118 |
| 4.3.3 | C codes (Control Functions) | 4-190 |
| 4.3.4 | P codes (Motor Parameter Functions) | 4-196 |
| 4.3.5 | H codes (High Performance Functions) | 4-211 |
| 4.3.6 | A codes (Alternative Motor Functions) | 4-264 |
| 4.3.7 | o codes (Option Functions) | 4-267 |
| 4.3.8 | L codes (Lift Functions) | 4-275 |

Chapter 7 APPLICATION EXAMPLES

| | | |
|-----|--|-----|
| 7.1 | Large Crane and Overhead Crane | 7-1 |
| 7.2 | Application to Plants | 7-1 |
| 7.3 | Servo Press: Large Size for Automobiles, Small Size for Machines such as Crimping Terminal Processing Machines | 7-2 |
| 7.4 | Winding Equipment (Paper and Metal) | 7-2 |
| 7.5 | Feeding Part of Semiconductor Manufacturing Device, Wire Saw | 7-3 |
| 7.6 | Test Equipment for Automobiles | 7-3 |
| 7.7 | Shipboard Winch | 7-4 |
| 7.8 | Flying Shear | 7-4 |

Chapter 8 SELECTING PERIPHERAL EQUIPMENT

| | | |
|---------|---|------|
| 8.1 | Configuring the FRENIC-VG | 8-1 |
| 8.2 | Selecting Wires and Crimp Terminals | 8-2 |
| 8.3 | Recommended Wires | 8-6 |
| 8.4 | Peripheral Equipment | 8-20 |
| 8.4.1 | Molded case circuit breaker or residual-current-operated protective device/earth leakage circuit breaker/magnetic contactor | 8-20 |
| 8.4.1.1 | Functional overview | 8-20 |
| 8.4.1.2 | Connection example and criteria for selection of circuit breakers | 8-22 |
| 8.4.2 | Surge killer for L-load | 8-26 |
| 8.4.3 | Arrester | 8-27 |
| 8.4.4 | Surge absorber | 8-28 |
| 8.4.5 | Filter capacitor for radio noise reduction | 8-29 |
| 8.5 | Peripheral Equipment Options | 8-30 |
| 8.5.1 | Braking resistors (DBRs) and braking units | 8-30 |
| 8.5.1.1 | Braking resistors (DBRs) | 8-30 |
| 8.5.1.2 | Braking units | 8-30 |
| 8.5.1.3 | Specifications and connection example | 8-31 |
| 8.5.1.4 | External dimensions | 8-42 |
| 8.5.2 | Power regenerative PWM converters (RHC series) | 8-45 |
| 8.5.2.1 | Features | 8-45 |
| 8.5.2.2 | Specifications | 8-46 |
| 8.5.2.3 | Function specifications | 8-48 |
| 8.5.2.4 | Converter configuration | 8-52 |
| 8.5.2.5 | Basic connection diagrams | 8-54 |
| 8.5.2.6 | External dimensions | 8-56 |
| 8.5.2.7 | Generated loss | 8-64 |
| 8.5.3 | DC reactor (DCR) | 8-66 |
| 8.5.4 | AC reactor (ACR) | 8-71 |
| 8.5.5 | Surge suppression unit (SSU) | 8-76 |
| 8.5.6 | Output circuit filter (OFL) | 8-77 |
| 8.5.7 | Radio noise reducing zero phase reactor (ACL) | 8-81 |
| 8.5.8 | External cooling attachment | 8-82 |
| 8.6 | Battery | 8-84 |
| 8.6.1 | Overview of battery | 8-84 |
| 8.6.2 | Installing battery | 8-85 |
| 8.6.2.1 | Installing battery (for 22 kW or lower) | 8-85 |
| 8.6.2.2 | Installing battery (for 30 kW or higher) | 8-86 |
| 8.6.3 | Replacing battery | 8-87 |
| 8.6.4 | About marine or air transport of a lithium-metal battery | 8-87 |
| 8.7 | PG Amplifier (Isolated Signal Conditioner) | 8-88 |
| 8.7.1 | Recommended Pulse Amplifier Models | 8-88 |
| 8.7.2 | Specifications and description of terminals | 8-88 |
| 8.7.3 | Notes for connection and use | 8-89 |
| 8.7.3.1 | Connection diagram | 8-89 |
| 8.7.3.2 | Notes for use | 8-89 |
| 8.7.4 | External dimensions | 8-89 |

Chapter 9 SELECTING OPTIMAL MOTOR AND INVERTER CAPACITIES

| | | |
|---------|--|------|
| 9.1 | Selecting Motor and Inverter Capacities | 9-1 |
| 9.1.1 | Motor output torque characteristics | 9-1 |
| 9.1.2 | Selection procedure | 9-3 |
| 9.1.3 | Equations for selections | 9-7 |
| 9.1.3.1 | Load torque during constant speed running | 9-7 |
| 9.1.3.2 | Acceleration and deceleration time calculation | 9-9 |
| 9.1.3.3 | Heat energy calculation of braking resistor | 9-14 |
| 9.1.3.4 | Calculating the RMS rating of the motor | 9-15 |

| | | |
|-------|---|------|
| 9.2 | Selecting a Braking Resistor | 9-16 |
| 9.2.1 | Selection procedure | 9-16 |
| 9.2.2 | Notes on selection | 9-16 |
| 9.3 | Selecting an Inverter Drive Mode (HD/MD/LD)..... | 9-17 |
| 9.3.1 | Precaution in making the selection | 9-17 |
| 9.3.2 | Guideline for selecting inverter drive mode and capacity..... | 9-18 |

Chapter 10 ABOUT MOTORS

| | | |
|--------|--|------|
| 10.1 | Vibration and Noise | 10-1 |
| 10.2 | Acceleration Vibration Value | 10-2 |
| 10.3 | Allowable Radial Load at Motor Shaft Extension | 10-3 |
| 10.4 | Allowable Thrust Load | 10-5 |
| 10.5 | List of Special Combinations..... | 10-6 |
| 10.5.1 | Combination list of 380V series..... | 10-6 |
| 10.5.2 | Combination list of low base speed series | 10-7 |

Chapter 11 OPERATION DATA

| | | |
|------|--|------|
| 11.1 | Frequency Response Characteristics..... | 11-1 |
| 11.2 | Rotational Fluctuation Measurement Sample | 11-1 |
| 11.3 | Current Distortion Characteristics | 11-2 |
| 11.4 | Torque Ripple | 11-2 |
| 11.5 | Impact Load Characteristics | 11-3 |
| 11.6 | Speed-torque Characteristics (Vector control with speed sensor)..... | 11-3 |
| 11.7 | Torque Control Accuracy (Vector control with speed sensor) | 11-4 |
| 11.8 | Deceleration/Acceleration via Zero Speed (Vector control with speed sensor)..... | 11-4 |

Chapter 12 REPLACEMENT DATA

| | | |
|--------|--------------------------------------|-------|
| 12.1 | Classification of Replacement | 12-1 |
| 12.2 | External Dimensions Comparison | 12-2 |
| 12.2.1 | Replacing VG7S | 12-2 |
| 12.2.2 | Replacing VG5S | 12-4 |
| 12.2.3 | Replacing VG3..... | 12-5 |
| 12.3 | Terminal Size | 12-6 |
| 12.3.1 | Replacing VG7S | 12-6 |
| 12.3.2 | Replacing VG5S | 12-8 |
| 12.3.3 | Replacing VG3..... | 12-10 |
| 12.4 | Terminal Symbols | 12-12 |
| 12.4.1 | Replacing VG7S | 12-12 |
| 12.4.2 | Replacing VG5S | 12-13 |
| 12.4.3 | Replacing VG3..... | 12-16 |
| 12.5 | Function Codes | 12-19 |
| 12.5.1 | Replacing VG7S | 12-19 |
| 12.5.2 | Replacing VG5S | 12-22 |
| 12.5.3 | Replacing VG3..... | 12-27 |
| 12.6 | Motor Parameters..... | 12-32 |
| 12.6.1 | Replacing VG7S | 12-32 |
| 12.6.2 | Replacing VG5S | 12-35 |
| 12.6.3 | Replacing VG3..... | 12-37 |
| 12.7 | Protective Functions | 12-39 |
| 12.7.1 | Replacing VG7S | 12-39 |
| 12.7.2 | Replacing VG5S | 12-40 |
| 12.7.3 | Replacing VG3..... | 12-41 |
| 12.8 | Options..... | 12-42 |
| 12.8.1 | Replacing VG7S | 12-42 |
| 12.8.2 | Replacing VG5S | 12-43 |

| | |
|---------------------------|-------|
| 12.8.3 Replacing VG3..... | 12-44 |
|---------------------------|-------|

Chapter 13 TROUBLESHOOTING

| | |
|---|-------|
| 13.1 Protective Functions | 13-1 |
| 13.2 Before Proceeding with Troubleshooting | 13-2 |
| 13.3 If an alarm code appears on the LED monitor | 13-3 |
| 13.3.1 List of alarm codes..... | 13-3 |
| 13.3.2 Possible causes of alarms, checks and measures..... | 13-5 |
| 13.4 If the "Light Alarm" Indication ($\overset{L}{\sim}$ - $\overset{FL}{\sim}$) Appears on the LED Monitor..... | 13-27 |
| 13.5 If Neither an Alarm Code Nor "Light Alarm" Indication ($\overset{L}{\sim}$ - $\overset{FL}{\sim}$) Appears on the LED Monitor..... | 13-28 |
| 13.5.1 Abnormal motor operation..... | 13-28 |
| 13.5.2 Problems with inverter settings..... | 13-40 |



Appendices

| | |
|---|------|
| App. A Advantageous Use of Inverters (Notes on electrical noise)..... | A-1 |
| A.1 Effect of inverters on other devices | A-1 |
| A.2 Noise..... | A-2 |
| A.3 Noise prevention..... | A-4 |
| App. B Japanese Guideline for Suppressing Harmonics by Customers Receiving High Voltage or Special High Voltage | A-12 |
| B.1 Application to general-purpose inverters..... | A-12 |
| B.2 Compliance to the harmonic suppression for customers receiving high voltage or special high voltage | A-13 |
| App. C Effect on Insulation of General-purpose Motors Driven with 400 V Class Inverters | A-18 |
| C.1 Generating mechanism of surge voltages | A-18 |
| C.2 Effect of surge voltages | A-19 |
| C.3 Countermeasures against surge voltages | A-19 |
| C.4 Regarding existing equipment..... | A-20 |
| App. D Inverter Generating Loss | A-21 |
| App. E Conversion from SI Units..... | A-23 |
| App. F Allowable Current of Insulated Wires | A-25 |

Safety precautions


Read this manual thoroughly before proceeding with installation, connections (wiring), operation, or maintenance and inspection. Ensure you have sound knowledge of the device and familiarize yourself with all safety information and precautions before proceeding to operate the inverter.

Safety precautions are classified into the following two categories in this manual.


| | |
|--|---|
|  WARNING | Failure to heed the information indicated by this symbol may lead to dangerous conditions, possibly resulting in death or serious bodily injuries. |
|  CAUTION | Failure to heed the information indicated by this symbol may lead to dangerous conditions, possibly resulting in minor or light bodily injuries and/or substantial property damage. |


Failure to heed the information contained under the CAUTION title can also result in serious consequences. These safety precautions are of utmost importance and must be observed at all times.

Application

| | |
|---|--|
|  WARNING | |
| <ul style="list-style-type: none">• The FRENIC-VG is designed to drive a three-phase induction motor. Do not use it for single-phase motors or for other purposes. Fire or an accident could occur. | |
| <ul style="list-style-type: none">• The FRENIC-VG may not be used for a life-support system or other purposes directly related to the human safety.• Though the FRENIC-VG is manufactured under strict quality control, install safety devices for applications where serious accidents or property damages are foreseen in relation to the failure of it. An accident could occur. | |

Installation

| | |
|---|--|
|  WARNING | |
| <ul style="list-style-type: none">• Install the inverter on a base made of metal or other non-flammable material. Otherwise, a fire could occur. | |
| <ul style="list-style-type: none">• Do not place flammable object nearby. Doing so could cause fire. | |
| <ul style="list-style-type: none">• Inverters with a capacity of 30 kW or above, whose protective structure is IP00, involve a possibility that a human body may touch the live conductors of the main circuit terminal block. Inverters to which an optional DC reactor is connected also involve the same. Install such inverters in an inaccessible place. Otherwise, electric shock or injuries could occur. | |

| | |
|--|--|
|  CAUTION | |
| <ul style="list-style-type: none">• Do not support the inverter by its front cover during transportation. Doing so could cause a drop of the inverter and injuries. | |
| <ul style="list-style-type: none">• Prevent lint, paper fibers, sawdust, dust, metallic chips, or other foreign materials from getting into the inverter or from accumulating on the heat sink.• When changing the positions of the top and bottom mounting bases, use only the specified screws. Otherwise, a fire or an accident might result. | |
| <ul style="list-style-type: none">• Do not install or operate an inverter that is damaged or lacking parts. Doing so could cause fire, an accident or injuries. | |

Wiring

WARNING

- If no zero-phase current (earth leakage current) detective device such as a ground-fault relay is installed in the upstream power supply line in order to avoid the entire power supply system's shutdown undesirable to factory operation, install a residual-current-operated protective device (RCD)/earth leakage circuit breaker (ELCB) individually to inverters to break the individual inverter power supply lines only.

Otherwise, a fire could occur.

- When wiring the inverter to the power source, insert a recommended molded case circuit breaker (MCCB) or residual-current-operated protective device (RCD)/earth leakage circuit breaker (ELCB) (with overcurrent protection) in the path of each pair of power lines to inverters. Use the recommended devices within the recommended current capacity.
- Use wires in the specified size.
- Tighten terminals with specified torque.


Otherwise, a fire could occur.

- When there is more than one combination of an inverter and motor, do not use a multicore cable for the purpose of handling their wirings together.
- Do not connect a surge killer to the inverter's output (secondary) circuit.

Doing so could cause a fire.

- Be sure to connect an optional DC reactor (DCR) when the capacity of the power supply transformer exceeds 500 kVA and is 10 times or more the inverter rated capacity.

Otherwise, a fire could occur.

- Ground the inverter in compliance with the national or local electric code.
- Be sure to ground the inverter's grounding terminals G.

Otherwise, an electric shock or a fire could occur.

- Qualified electricians should carry out wiring.
- Be sure to perform wiring after turning the power OFF.

Otherwise, an electric shock could occur.

- Be sure to perform wiring after installing the inverter unit.

Otherwise, an electric shock or injuries could occur.

- Ensure that the number of input phases and the rated voltage of the product match the number of phases and the voltage of the AC power supply to which the product is to be connected.

Otherwise, a fire or an accident could occur.

- Do not connect the power supply wires to output terminals (U, V, and W).
- When connecting a DC braking resistor (DBR), never connect it to terminals other than terminals P(+) and DB.

Doing so could cause fire or an accident.

- In general, sheaths of the control signal wires are not specifically designed to withstand a high voltage (i.e., reinforced insulation is not applied). Therefore, if a control signal wire comes into direct contact with a live conductor of the main circuit, the insulation of the sheath might break down, which would expose the signal wire to a high voltage of the main circuit. Make sure that the control signal wires will not come into contact with live conductors of the main circuit.

Doing so could cause an accident or an electric shock.

WARNING

- Before changing the switches or touching the control circuit terminal symbol plate, **turn OFF the power and wait at least five minutes for inverters with a capacity of 22 kW or below, or at least ten minutes for inverters with a capacity of 30 kW or above.** Make sure that the LED monitor and charging lamp are turned OFF. Further, make sure, using a multimeter or a similar instrument, that the DC link bus voltage between the terminals P(+) and N(-) has dropped to the safe level (+25 VDC or below).

Otherwise, an electric shock could occur.




CAUTION

- The inverter, motor and wiring generate electric noise. Be careful about malfunction of the nearby sensors and devices. To prevent them from malfunctioning, implement noise control measures.

Otherwise an accident could occur.

Operation

WARNING

- Be sure to mount the front cover before turning the power ON. Do not remove the cover when the inverter power is ON.
Otherwise, an electric shock could occur.
- Do not operate switches with wet hands.
Doing so could cause electric shock.
- If the auto-reset function has been selected, the inverter may automatically restart and drive the motor depending on the cause of tripping. Design the machinery or equipment so that human safety is ensured at the time of restarting.
Otherwise, an accident could occur.
- If the stall prevention function (torque limiter) has been selected, the inverter may operate with acceleration/deceleration or speed different from the commanded ones. Design the machine so that safety is ensured even in such cases.
- The  key on the keypad is effective only when the keypad operation is enabled with function code F02 (= 0, 2 or 3). When the keypad operation is disabled, prepare an emergency stop switch separately for safe operations. Switching the run command source from keypad (local) to external equipment (remote) by turning ON the "Enable communications link" command **LE** disables the  key.
To enable the  key for an emergency stop, select the STOP key priority with function code H96 (= 1 or 3).
- If any of the protective functions have been activated, first remove the cause. Then, after checking that the all run commands are set to OFF, release the alarm. If the alarm is released while any run commands are set to ON, the inverter may supply the power to the motor, running the motor.
Otherwise, an accident could occur.
- If you enable the "Restart mode after momentary power failure" (Function code F14 = 3 to 5), then the inverter automatically restarts running the motor when the power is recovered.
Design the machinery or equipment so that human safety is ensured after restarting.
- If the user configures the function codes wrongly without completely understanding this Instruction Manual and the FRENIC-VG User's Manual, the motor may rotate with a torque or at a speed not permitted for the machine.
An accident or injuries could occur.
- Even if the inverter has interrupted power to the motor, if the voltage is applied to the main circuit input terminals L1/R, L2/S and L3/T, voltage may be output to inverter output terminals U, V, and W.
- Even if the run command is set to OFF, voltage is output to inverter output terminals U, V, and W if the servo-lock command is ON.
- Even if the motor is stopped due to DC braking or preliminary excitation, voltage is output to inverter output terminals U, V, and W.
An electric shock may occur.
- The inverter can easily accept high-speed operation. When changing the speed setting, carefully check the specifications of motors or equipment beforehand.
Otherwise, injuries could occur.

CAUTION

- Do not touch the heat sink and braking resistor because they become very hot.
Doing so could cause burns.
- The DC brake function of the inverter does not provide any holding mechanism.
Injuries could occur.
- Ensure safety before modifying the function code settings.
Run commands (e.g., "Run forward" **FWD**), stop commands (e.g., "Coast to a stop" **BX**), and speed change commands can be assigned to digital input terminals. Depending upon the assignment states of those terminals, modifying the function code setting may cause a sudden motor start or an abrupt change in speed.
- When the inverter is controlled with the digital input signals, switching run or speed command sources with the related terminal commands (e.g., **SS1**, **SS2**, **SS4**, **SS8**, **N2/NI**, **KP/PID**, **IVS**, and **LE**) may cause a sudden motor start or an abrupt change in speed.
An accident or injuries could occur.

Maintenance and inspection, and parts replacement

WARNING

- Before proceeding to the maintenance/inspection jobs, **turn OFF the power and wait at least five minutes for inverters with a capacity of 22 kW or below, or at least ten minutes for inverters with a capacity of 30 kW or above.** Make sure that the LED monitor and charging lamp are turned OFF. Further, make sure, using a multimeter or a similar instrument, that the DC link bus voltage between the terminals P(+) and N(-) has dropped to the safe level (+25 VDC or below).

Otherwise, an electric shock could occur.

- Maintenance, inspection, and parts replacement should be made only by qualified persons.
- Take off the watch, rings and other metallic objects before starting work.
- Use insulated tools.

Otherwise, an electric shock or injuries could occur.

- Never modify the inverter.

Doing so could cause an electric shock or injuries.

Disposal

CAUTION

- Treat the inverter as an industrial waste when disposing of it.

Otherwise injuries could occur.

Speed control mode

CAUTION

- If the control parameters of the automatic speed regulator (ASR) are not appropriately configured under speed control, even turning the run command OFF may not decelerate the motor due to hunting caused by high gain setting. Accordingly, the inverter may not reach the stop conditions so that it may continue running.

Even if the inverter starts deceleration, the detected speed deviates from the zero speed area before the zero speed control duration (F39) elapses due to hunting caused by high response in low speed operation. Accordingly, the inverter will not reach the stop conditions so that it enters the deceleration mode again and continues running.

If any of the above problems occurs, adjust the ASR control parameters to appropriate values and use the speed mismatch alarm function in order to alarm-trip the inverter, switch the control parameters by speed, or judge the detection of a stop speed by commanded values when the actual speed deviates from the commanded one.

An accident or injuries could occur.

Torque control mode

CAUTION

- When the motor is rotated by load-side torque exceeding the torque command under torque control, turning the run command OFF may not bring the stop conditions so that the inverter may continue running.

To shut down the inverter output, switch from torque control to speed control and apply a decelerate-to-stop or coast-to-stop command.

An accident or injuries could occur.

GENERAL PRECAUTIONS

Drawings in this manual may be illustrated without covers or safety shields for explanation of detail parts. Restore the covers and shields in the original state and observe the description in the manual before starting operation.

Icons

The following icons are used throughout this manual.



This icon indicates information which, if not heeded, can result in the inverter not operating to full efficiency, as well as information concerning incorrect operations and settings which can result in accidents.



This icon indicates information that can prove handy when performing certain settings or operations.



This icon indicates a reference to more detailed information.

FRENIC-VG 1

Chapter 1 OVERVIEW

This chapter describes the overview, features and the control system of the FRENIC-VG series and the recommended configuration for the inverter and peripheral equipment.

Contents

| | | |
|---------|--|------|
| 1.1 | Overview | 1-1 |
| 1.1.1 | Industry-best control performance | 1-1 |
| 1.1.2 | System support | 1-1 |
| 1.1.3 | Extensive built-in functionality | 1-1 |
| 1.1.4 | Broad capacity and application ranges | 1-2 |
| 1.1.5 | Global support | 1-2 |
| 1.2 | Features | 1-3 |
| 1.2.1 | Best-in-industry control performance | 1-3 |
| 1.2.2 | Support for various control systems (multi-drive function) | 1-4 |
| 1.2.3 | Broad capacity range/flexible application range | 1-4 |
| 1.2.4 | User program functionality (UPAC option) | 1-4 |
| 1.2.5 | Extensive network support | 1-5 |
| 1.2.6 | Inverter support software "FRENIC-VG Loader" | 1-5 |
| 1.2.7 | Extensive built-in functionality | 1-6 |
| 1.2.8 | Extensive maintenance and protective functionality | 1-7 |
| 1.2.9 | Environmental considerations | 1-8 |
| 1.2.10 | Simple, interactive keypad | 1-10 |
| 1.2.11 | Compliance with overseas standards | 1-11 |
| 1.2.12 | Compliance with functional safety standards | 1-11 |
| 1.2.13 | Compatibility with legacy models | 1-11 |
| 1.3 | Control Systems | 1-12 |
| 1.3.1 | Control system features and applications | 1-12 |
| 1.3.1.1 | Open-loop speed control | 1-12 |
| 1.3.1.2 | Closed-loop speed control | 1-14 |

1.1 Overview

1.1.1 Industry-best control performance

- The FRENIC-VG implements vector control with a speed sensor (induction and synchronous motors), vector control without a speed sensor (induction motors), V/f control (induction motors), and multi-drive functionality.
- Vector control with a speed sensor (for FRENIC-VG induction motors) delivers best-in-industry performance with a speed response of 600 Hz, current response of 2,000 Hz, speed control accuracy of $\pm 0.005\%$, and torque control accuracy of $\pm 3\%$.

1.1.2 System support

- The FRENIC-VG has the RS-485 communications function as standard and supports various networks (T-Link, SX bus, and CC-Link, and PROFIBUS) as an option.
- The optional UPAC card with user program functionality allows users to configure and develop proprietary systems, and dedicated package software is also available.
- The direct parallel connection control system is adopted so that two or more inverters can be connected in parallel to drive a single motor (single winding). If some inverters go wrong, therefore, the remaining normal inverters can continue to drive the motor (reduced-inverters operation).

1.1.3 Extensive built-in functionality

- Extensive auto-tuning function for optimal control of all types of motors
- Built-in load oscillation suppression observer function and load compensation control function
- Extensive position control functionality, including zero-speed lock control
- Optional position synchronization control using pulse train input
- Optional orientation control
- Inverter support loader software FRENIC-VG Loader that enables you to read and write the function code data from/to the inverter on the computer. In addition, the multifunction FRENIC-Loader provides the trace function (traceback, real-time trace, and historical trace) for management of inverter function code configuration, the logger tool for setting-up the machinery, and the failure analysis.

FRENIC-VG Loader runs on Windows XP, Vista, Windows 7 (32/64bit), Windows 8.1 (32/64bit) and Windows 10 (32/64bit).

1.1.4 Broad capacity and application ranges

- A single set of specifications supports a broad range of capacities—from 0.75 kW to 90 kW for 200 V circuits and 3.7 kW to 630 kW for 400 V circuits—simplifying the system development process.
- Three sets of ratings are supported by HD mode (constant-torque), which offers an overload rating of 150% for 1 min. and 200% for 3 sec.; LD mode (square deceleration torque), which supports motors with rated currents one step larger than the inverter and offers an overload rating of 120% for 1 min.; and MD mode, which supports motors with rated currents one step larger than the inverter while limiting the inverter's internal switching frequency and offers an overload rating of 150% for 1 min.

1.1.5 Global support

- The standard model complies with UL/cUL standards, CE Mark requirements, the RoHS Directive, and Radio Waves Act (South Korea, KC certification), making it possible to standardize equipment and machinery specifications both inside and outside Japan.
- The FRENIC-VG has the safety function STO (Safe Torque Off) complying with the IEC/EN61800-5-2 functional safety standard, as standard. Mounting the functional safety option OPC-VG1-SAFE on the FRENIC-VG adds the safety functions SS1 (Safe Stop 1), SLS (Safely Limited Speed), and SBC (Safe Brake Control) to the FRENIC-VG.
- The keypad displays English, Japanese, Chinese, and Korean (Hangul).
- Optional support is available for open networks (e.g. PROFIBUS-DP and DeviceNet).


1.2 Features

The FRENIC-VG is a high-performance vector control inverter that provides a high degree of freedom in adjusting speed and torque.


1.2.1 Best-in-industry control performance

- Speed response of 600 Hz (6× Fuji’s previous VG7 model when using vector control with a speed sensor)
- Current response of 2,000 Hz (2× Fuji’s previous VG7 model when using vector control with a speed sensor)
- Torque control accuracy (linear) of $\pm 3\%$ and speed control accuracy of $\pm 0.005\%$


Speed response of 600 Hz




Tracking characteristics with impact load



Reduction of rotational unevenness to 1/3



Speed and torque characteristics



1.2.2 Support for various control systems (multi-drive function)

- Supports vector control with/without a speed sensor and V/f control for induction motors.
- Supports vector control with a speed sensor (requires optional card) for synchronous motors.
- Capable of driving megawatt motors by adopting multi-winding drive or direct parallel connection. This requires the optional high-speed serial communication terminal block.

1.2.3 Broad capacity range/flexible application range

- A single model supports a broad range of capacities from 0.75 kW to 630 kW, simplifying the system development process.
- The standard model supports three modes.

The operating mode is switched based on the motor's load conditions. In medium-duty (MD) and low-duty (LD) applications, the FRENIC-VG can drive motors one to two steps larger than the inverter.

| Mode | Applied load | Characteristics | Applied overload rating |
|------|----------------------|--|---|
| HD | High duty (standard) | Powerful, low noise | Current 150% for 1 min. / 200% for 3 sec. |
| MD | Medium duty | Can drive a motor one step larger than the inverter*1. | Current 150% for 1 min., carrier 2 to 4 kHz*2 |
| LD | Low duty | Can drive a motor 1 to 2 steps larger than the inverter*1. | Current 120% for 1 min. |

*1 Varies with motor specifications and supply voltage.


*2 Produces a higher level of noise. Verify suitability of environment in which motor will be installed.

1.2.4 User program functionality (UPAC option)

- The UPAC (User Programmable Application Card) option OPC-VG1-UPAC, which provides user program functionality, allows certain aspects of inverter control and terminal functionality to be changed, making it possible for users to configure and develop proprietary systems.
- Dedicated package software is also available for functionality such as orientation control, dancer control, and tension control.
- The OPC-VG1-UPAC application software is compatible with the FRENIC5000VG7-UPAC one.

Note: To download the FRENIC5000VG7-UPAC application software to the OPC-VG1-UPAC, the version of the SX-Programmer Expert (D300win) and its UPAC support functions should be V3.6.1.3 or later.

UPAC system



Outline of UPAC Optical Link System Configuration


- The UPAC option is mounted on the FRENIC-VG master.
- The TBSI(Optical link option card) OPC-VG1-TBSI is mounted on each inverter. (Connected with an optical cable that comes with the TBSI.)
- Restrictions on the number of inverters in a UPAC optical link system
 - i) 6-inverter system : 2 to 6 inverters
 - ii) 12-inverter system : 2 to 12 inverters
 - iii) Broadcast : 2 to 156 inverters (1 ms cycle)
 The number of I/O words differs for each inverter.

UPAC: OPC-VG1-UPAC (User programmable application card option)

TBSI: OPC-VG1-TBSI (Optical link option card)

1.2.5 Extensive network support

- The RS-485 communications function is provided as standard. Optional support is available for various networks.
 - i) RS-485 communications system : A standard RS-485 terminal is provided as a control circuit terminal, making it easy to implement multi-drop connections.
 - ii) Fuji private link : T-Link, SX-bus, and E-SX bus
 - iii) CC-Link : CC-Link Ver. 1.10/Ver. 2.00
- It also supports various open buses--PROFIBUS-DP, DeviceNet, and PROFINET-IRT (*1).
 - *1 PROFINET-IRT is only supported by special product.





Note: The FRENIC-VG is network-compatible with the FRENIC5000VG7 to facilitate updating.

1.2.6 Inverter support software "FRENIC-VG Loader"

The CD-ROM that comes with the FRENIC-VG contains the inverter support software "FRENIC-VG Loader" (WPS-VG1-STR). Installing FRENIC-VG Loader to a computer enables the following.

- i) Reading and writing function code data from/to the inverter. Saving function code data and conversion to a CSV file, making management of function codes easy.
- ii) Traceback in the trace function, facilitating failure analysis.
- Commercially available USB cables can be used.
- Supports for Windows XP, Vista, Windows 7 (32-/64-bit version), Windows 8.1 (32-/64-bit version), Windows 10 (32-/64-bit version).



1.2.7 Extensive built-in functionality

- Auto-tuning functionality
 - i) Possible to tune motor parameters while the motor is in the stopped state.
 - ii) Online tuning function that allows motor parameters to be revised while the motor is running.
- Built-in observer function for suppressing load oscillation
- Load compensation control function
 - Enables continuous speed control during low-duty operation.
- Extensive position control functionality
 - i) Zero-speed lock control
 - ii) Optional position synchronization control using pulse train input
 - iii) Optional orientation control
- Braking resistor drive circuit incorporated as standard
 - The FRENIC-VG of 55 kW or less (for 200 V class series) or 160 kW or less (for 400 V class series) incorporates a braking resistor drive circuit, allowing a braking resistor to be connected directly to the FRENIC-VG unit. This feature helps make devices using the inverter more compact.

For the FRENIC-VG not incorporating it as standard, a braking unit (BU-C series) can be used.

- Total of 23 I/O contacts

| | Input | Output |
|---------|-------------|------------|
| Analog | 3 contacts | 3 contacts |
| Digital | 11 contacts | 6 contacts |

- PG feedback interfaces
 - i) Standard built-in complementary PG interface (12 V, 15 V)
 - ii) Optional interfaces for line driver PG and open collector PG
 - iii) For a permanent magnet synchronous motor (PMSM), optional dedicated interface for line driver PG and open collector PG
 - (Magnetic pole position signals support 4-bit or 3-bit gray code.)
 - iv) Optional interface for Tamagawa Seiki serial PG (17-bit absolute encoder)


Optional interfaces given in iv) above are available for controlling both IM (induction motor) and PMSM.

1.2.8 Extensive maintenance and protective functionality

- The calendar & clock function records and displays the date and time at which a trip occurred, making it easier to search for the causes of trips by checking them against the operating state of the machine.
- The traceback function automatically records running state data (traceback data) including the speed, torque, current, and voltage being applied immediately preceding a trip stop, in the inverter. The traceback data can be displayed in a chart.
- The optional paid-for version (WPS-VG1-PCL) of FRENIC-VG Loader has additional running monitor, real-time trace and historical trace functions that are not available in the free version (WPS-VG1-STR).

Data logger function

- Running monitor
 - Real-time trace
 - Historical trace
- Note: These functions above are supported by the optional version (WPS-VG1-PCL).
- Traceback



Note: The calendar & clock function and traceback function require a built-in battery (included as standard for inverters of 30 kW or above).

- The inverter’s operating state at the time of the most recent and three previous trip stops is stored and can be monitored on the keypad.
- Specific alarms can be registered as a light alarm object to make it possible to keep running the inverter without causing a trip. If a light alarm occurs, the inverter merely displays $\angle -F\angle$ on the LED monitor and outputs **Do** (optional).
- A mock alarm can be triggered by either keypad operation or FRENIC-VG Loader. This capability can be used to check the trip stop sequence.
- I/O terminal check function
- Main circuit capacitor service life detection
- Inverter load rate measurement
- Recording and display of cumulative run time
- Display of operating state data such as output voltage, cooler temperature, and torque command value
- Configuration of the electronic thermal time constant, allowing the inverter to support a variety of motors
- The design life of various consumable parts inside the inverter has been extended to 10 years, which has allowed equipment maintenance cycles to be extended.

| Consumable part | Design life |
|-------------------------------|-------------|
| Cooling fan | 10 years |
| Main circuit capacitor | 10 years |
| Electrolytic capacitor on PCB | 10 years |
| Fuse (90 kW or above) | 10 years |
| Calendar/clock backup battery | 5 years |

Service life figures are based on the following conditions:

- Ambient temperature: 40°C
- Load factor: 100% (HD mode), 80% (MD/LD mode)

*Design life figures are calculated values and are not intended to serve as a guarantee of hardware performance.

● Extensive service life warnings

The inverter provides functionality designed to facilitate machinery maintenance.

| Item | Purpose |
|---|---|
| Cumulative run time (unit: 1 hour) | Displays the total run time for the inverter. The amount of time during which the main power supply is supplied is indicated as a whole number of hours. |
| Cumulative motor run time (unit: 10 hours) | Displays the total run time for the motor. This figure is used to determine the service life of the machinery (load). |
| Cumulative startup count | Displays the number of motor startups. This figure can be used as a guide for timing the replacement of machinery parts (such as timing belts) that are placed under load during normal operation. |
| Equipment maintenance warning Cumulative motor run time (unit: 10 hours) Cumulative startup count | The inverter can output a warning signal when the set value is reached. This functionality makes it possible to manage the motor's cumulative run time and number of startups, which are useful in planning maintenance. |
| Display of inverter service life alarm | Displays the following: <ul style="list-style-type: none"> • Current capacitance of DC link bus capacitor • Total run time of the cooling fan (with on/off compensation) • Total run time of the electrolytic capacitor on the PCB |

1.2.9 Environmental considerations

● Enhanced environmental resistance

The inverter offers improved resistance to harsh operating environments compared to conventional inverter models.

- (1) Enhanced environmental resistance of the cooling fan
- (2) Adoption of nickel and tin plating for copper bars

While the FRENIC-VG offers improved resistance to harsh operating environments compared to conventional models, special consideration concerning the operating environment is necessary in the following cases:

- a. Environments where sulfide gas is present (some applications in tire manufacturing, paper manufacturing, sewage treatment, and fiber manufacturing)
- b. Environments where conductive dust or foreign matter is present (metalworking, extruding machine or printing press operation, waste disposal, etc.)
- c. Other: Where the inverter would be used in an environment that differs from the standard specifications

If you are considering using the inverter under any of the above conditions, please contact Fuji in advance.

- Protection against micro-surges (optional)


- SSU surge suppression units (optional)

If the motor drive cable is too long, a very low surge voltage (micro-surge) may be generated at the motor connection ends. This surge voltage can cause deterioration of the motor, dielectric breakdown, and increased noise. A surge suppression unit can be used to suppress this surge voltage.

- (1) Simply connecting a surge suppression unit to the motor dramatically reduces the surge voltage.
- (2) Since no additional work is required, the units can be easily installed on existing equipment.
- (3) The units can be used with motors with a capacity of 75 kW or less.
- (4) The units require no power source or maintenance.
- (5) Two types are available: one for 50 m motor cable and the other for 100 m motor cable.
- (6) The units comply with environmental and safety standards (including the RoHS Directive).



- Surge suppression mechanism



- Compliance with the RoHS Directive

The FRENIC-VG complies with the Restriction of Hazardous Substances (RoHS) Directive in its standard configuration. It is an environmentally friendly inverter as use of the following six hazardous substances has been restricted.

- Six hazardous substances

Lead, mercury, cadmium, hexavalent chromium, polybrominated biphenyls (PBBs), and polybrominated diphenyl ether (PBDE)

*Except certain parts on some models.

- About the RoHS Directive

Directive 2002/96/EC, promulgated by the European Parliament and European Council, limits the use of specific hazardous substances in electrical and electronic devices.

1.2.10 Simple, interactive keypad

- A large, easy-to-read LED consisting of five 7-segment digits allows users to visually check monitor values with ease.
- A backlit dot matrix LCD allows users to set function codes and monitor multiple data points at the same time while displaying guidance.
- Standard copy function
Function code data can be easily copied to another FRENIC-VG unit.
- Out-of-the-box remote operation
Simply connect the inverter and keypad with a 10Base-T LAN cable to enable remote operation (at distances of up to 20 m).
- Standard support for eight languages (Japanese, English, Chinese and Korean).
- JOG (jogging) operation is possible with keypad key or terminal block input.
- A help key displays guidance on device operation.
- The calendar & clock function can display the time and date.




1.2.11 Compliance with overseas standards

- The FRENIC-VG complies with the following overseas standards in its standard configuration, allowing standardization of device and machinery specifications in Japan and overseas:

EC directives: Low Voltage Directive, RoHS Directive, Machinery Directive, UL Standards, cUL Standards, KC Certification

- The FRENIC-VG also complies with the EMC Directive when the standard model is combined with an option (EMC filter).



1.2.12 Compliance with functional safety standards

- The FRENIC-VG supports the safety function STO (Safe Torque Off) complying with the IEC/EN61800-5-2 Functional Safety Standard, as standard.
- Mounting the functional safety option OPC-VG1-SAFE on the FRENIC-VG adds the safety functions SS1 (Safe Stop 1), SLS (Safely Limited Speed), and SBC (Safe Brake Control) complying with the IEC/EN61800-5-2, to the FRENIC-VG.

Safe Torque Off (STO): This immediately shuts down the inverter output to the motor (motor torque off).

Safe Stop 1 (SS1): This decelerates the motor speed and shuts down the inverter output to the motor (motor torque off) by using the STO function immediately when the motor speed decelerates to the specified speed or the specified time has elapsed.

Safely Limited Speed (SLS): This prevents the motor from exceeding the specified speed.

Safe Brake Control (SBC): This outputs motor brake control signals.

1.2.13 Compatibility with legacy models

The FRENIC-VG is compatible with previous Fuji vector control inverters, making it easy to update to the FRENIC-VG.

- Compatibility with the FRENIC5000VG7S

Since the FRENIC-VG's function codes are compatible with the VG7's function codes, the FRENIC-VG can be configured with VG7 function codes without modification. (For details, refer to Chapter 12, Section 12.5.1 "Replacing VG7S.") Additionally, function codes can be captured from a VG7 unit with FRENIC-VG Loader and copied to the FRENIC-VG without modification.

1.3 Control Systems

1.3.1 Control system features and applications

Inverter-based devices for varying AC motor speed are most commonly used to control the rotational speed of a load. This section describes the basic architecture of various speed control systems, their characteristics, and important information to consider when using them in various applications.

Speaking broadly, speed control systems can be classified as either open-loop or closed-loop control systems (see Figure 1.3.1).




Figure 1.3.1 Classification of Speed Control Systems

1.3.1.1 Open-loop speed control




Figure 1.3.2 Open-loop Speed Control: Basic Architecture

As is illustrated in Figure 1.3.2, “Open-loop Speed Control: Basic Architecture,” this approach attempts to control the load’s rotational speed by means of the frequency of inverter output, without generating feedback in the form of speed information for the control target. As shown in Figure 1.3.3, induction motors’ speed versus torque characteristics are characterized by a slight slope across frequencies f_1 to f_6 . If the frequency of the voltage supplied to the motor remains constant, then there is little variation in rotational speed in response to variations in load; for example, slip at the rated torque is on the order of several percent. In other words, when controlling the motor’s speed by changing the inverter’s output frequency, V/f control, which controls the ratio between the motor’s terminal voltage and the applied frequency, is generally used.




Figure 1.3.3 Speed vs. Torque Characteristics

Since open-loop control does not require a speed sensor, it is primarily used by general-purpose inverters in applications where fast response is not particularly important, for example to enable variable-speed operation of existing motors or with squared-deceleration torque loads such as fans or pumps.




Figure 1.3.4 Speed Control Using the Slip Compensation Systems

Factors determining the accuracy of the rotational speed in open-loop speed control include load torque fluctuations, accuracy of the output frequency, and supply voltage fluctuations. The slip compensation control system addresses load torque fluctuations by calculating the output torque from the motor’s terminal voltage and primary current and compensating the inverter’s output frequency accordingly in an attempt to maintain a constant rotational speed, as illustrated in Figure 1.3.4.

1.3.1.2 Closed-loop speed control

Closed-loop speed control compensates for speed fluctuations by generating feedback in the form of speed information.

Since highly accurate speed control is possible by generating feedback in the form of the control target's rotational speed, closed-loop speed control can be used in applications such as paper machines and machine tools.




Figure 1.3.5 Closed-loop Speed Control: Basic Architecture

Figure 1.3.5 illustrates the basic architecture of the closed-loop speed control system. Speed information from a speed detection sensor such as a pulse generator (PG) is fed back to the system and compared to the speed command, and the inverter's output frequency is controlled so that the speed command and the detected speed value match.

Speed control systems include slip frequency control, vector control with a speed sensor, and vector control without a speed sensor. An overview of each of these control systems follows.

The FRENIC-VG series of high-performance vector control inverters uses closed-loop vector control to implement speed control.

(a) Slip frequency control




Figure 1.3.6 Slip Frequency Control Architecture

Figure 1.3.6 illustrates the architecture of the slip frequency control system. Output from the speed controller becomes the slip frequency based on the torque, and the inverter compensates for speed fluctuations by adding the slip frequency to the actual speed. Because this system is comparatively simple, it is used in applications such as speed control in general-purpose inverters. However, since basic control is performed using V/f control, this system is used in applications that do not require fast response.

(b) Vector control with a speed sensor

Vector control is used to implement fast response for AC motors. By controlling an AC motor's primary current, magnetic flux current, and torque current separately, vector control attempts to achieve a similar level of control performance as that for DC motors.

Vector control achieves performance that differs from the V/f control system in the following ways, making it well suited for use in applications that require fast response and high accuracy:

- (1) Good acceleration and deceleration characteristics
- (2) Broad speed control range
- (3) Torque control capability
- (4) Fast control response




Figure 1.3.7 Example Vector Control Architecture

Figure 1.3.7 illustrates a vector control architecture example. Since the vector calculation unit uses the motor constant, performance varies greatly with the accuracy with which that constant is understood. Performance is also significantly affected by changes to the constant caused by temperature conditions. Since the control system is complex, this system is primarily used with combinations of dedicated inverters and dedicated motors.

(c) Vector control without a speed sensor

Vector control with a speed sensor offers exceptional performance in terms of fast response and high accuracy but suffers from issues such as the need to install a speed sensor and route wiring from the sensor to the inverter. By contrast, vector control without a speed sensor estimates the rotational speed based on the motor's terminal voltage and primary current without relying on sensor input and uses the estimated value as the speed feedback signal. Vector control without a speed sensor delivers performance that is slightly inferior to vector control with a speed sensor.

Figure 1.3.8 illustrates architecture for vector control without a speed sensor.




Figure 1.3.8 Example Architecture for Vector Control without a Speed Sensor

The FRENIC-VG can use this type of control when utilized in combination with a general-purpose motor. However, control performance and other specifications are slightly inferior to those of applications where the inverter is used in combination with a dedicated motor.

Chapter 2

SPECIFICATIONS

This chapter describes specifications of the output ratings, control system, dedicated motor specifications, and terminal functions for the FRENIC-VG series of inverters. It also provides descriptions of the external dimensions, examples of basic connection diagrams, and details of the protective functions.

Contents

| | | |
|---------|---|------|
| 2.1 | Standard Model 1 (Basic Type)..... | 2-1 |
| 2.1.1 | HD (High Duty)-mode inverters for heavy load | 2-1 |
| 2.1.2 | MD (Medium Duty)-mode inverters for medium load..... | 2-3 |
| 2.1.3 | LD (Low Duty)-mode inverters for light load..... | 2-4 |
| 2.1.4 | Rated current derating | 2-6 |
| 2.2 | Common Specifications | 2-10 |
| 2.3 | External Dimensions | 2-16 |
| 2.3.1 | Standard models | 2-16 |
| 2.3.2 | Keypad | 2-27 |
| 2.4 | Dedicated Motor Specifications | 2-28 |
| 2.4.1 | Induction motor (IM) with speed sensor | 2-28 |
| 2.4.2 | Permanent magnet synchronous motor (PMSM) with speed sensor | 2-32 |
| 2.5 | Protective Functions..... | 2-38 |
| 2.6 | Connection Diagrams and Terminal Functions | 2-42 |
| 2.6.1 | Connection diagrams..... | 2-42 |
| 2.6.1.1 | Running the MVK type of an induction motor (dedicated motor) | 2-42 |
| 2.6.1.2 | Running the GNF2 type of a permanent magnet synchronous motor (dedicated motor) | 2-44 |
| 2.6.2 | List of terminal functions | 2-46 |

2.1 Standard Model 1 (Basic Type)

2.1.1 HD (High Duty)-mode inverters for heavy load

Three-phase 200 V class series

| Type (FRN___VG1S-2□) | 0.75 | 1.5 | 2.2 | 3.7 | 5.5 | 7.5 | 11 | 15 | 18.5 | 22 | 30 | 37 | 45 | 55 | 75 | 90 | |
|-----------------------------------|---|--|-----|------|------|------|------|------|------|------|---|--|-----|-----|---------|-----|-----|
| Nominal applied motor (kW) | 0.75 | 1.5 | 2.2 | 3.7 | 5.5 | 7.5 | 11 | 15 | 18.5 | 22 | 30 | 37 | 45 | 55 | 75 | 90 | |
| Rated capacity (kVA) *1 | 1.9 | 3.0 | 4.1 | 6.8 | 10 | 14 | 18 | 24 | 28 | 34 | 45 | 55 | 68 | 81 | 107 | 131 | |
| Rated current (A) | 5 | 8 | 11 | 18 | 27 | 37 | 49 | 63 | 76 | 90 | 119 | 146 | 180 | 215 | 283 | 346 | |
| Overload capability | 150% of the rated current -1 min. *2 200% of the rated current -3 s. *3 | | | | | | | | | | | | | | | | |
| Input power | Main power input: Phase, voltage, frequency | Three-phase, 200 to 230 V, 50/60 Hz | | | | | | | | | | Three-phase, 200 to 220 V/50 Hz, 200 to 230 V/60 Hz *4 | | | | | |
| | Auxiliary control power input: Phase, voltage, frequency | Single-phase, 200 to 230V, 50/60 Hz | | | | | | | | | | | | | | | |
| | Auxiliary fan power input: Phase, voltage, frequency *5 | - | | | | | | | | | | Single-phase 200 to 220 V/50 Hz, 200 to 230 V/60 Hz *4 | | | | | |
| | Allowable voltage/frequency | Voltage: +10 to -15% (Interphase voltage unbalance: 2% or less *6), Frequency: +5 to -5% | | | | | | | | | | | | | | | |
| | Rated current (A) *7 (with DCR) (without DCR) | 3.2 | 6.1 | 8.9 | 15.0 | 21.1 | 28.8 | 42.2 | 57.6 | 71.0 | 84.4 | 114 | 138 | 167 | 203 | 282 | 334 |
| | | 5.3 | 9.5 | 13.2 | 22.2 | 31.5 | 42.7 | 60.7 | 80.1 | 97.0 | 112 | 151 | 185 | 225 | 270 | — | — |
| Required capacity (kVA) *8 | 1.2 | 2.2 | 3.1 | 5.2 | 7.4 | 10 | 15 | 20 | 25 | 30 | 40 | 48 | 58 | 71 | 98 | 116 | |
| Braking method, Braking torque | Braking resistor discharge control: 150% braking torque, Separately installed resistor (option), Separately installed braking unit (option for FRN75VG1S-2□ or higher type) | | | | | | | | | | | | | | | | |
| Carrier frequency (kHz) *9 | 2 to 15 | | | | | | | | | | | | | | 2 to 10 | | |
| Approx. mass (kg) | 6.2 | 6.2 | 6.2 | 6.2 | 6.2 | 6.2 | 11 | 11 | 11 | 12 | 25 | 32 | 42 | 43 | 62 | 105 | |
| Enclosure | IP20, UL open type | | | | | | | | | | IP00, UL open type (IP20 is optionally available.) | | | | | | |

Note: A box (□) replaces an alphabetic letter depending on the shipping destination.

Note: The above specifications apply when Function code F80 = 0 (HD mode).

A DC reactor (DCR) is provided as standard for HD-mode inverters of 75 kW or above.

*1 This specification applies when the rated output voltage is 220 V.

*2 When the inverter output frequency converted is less than 10 Hz, the inverter may trip earlier due to overload depending on the ambient temperature and other conditions.

*3 When the inverter output frequency converted is less than 5 Hz, the inverter may trip earlier due to overload depending on the surrounding temperature and other conditions.

*4 Inverters of 200 to 230 V/50 Hz are available on request.

*5 Use this input as an AC fan power in a power system using a power regenerative PWM converter. (Usually, there is no need to use this input.)

*6
$$\text{Voltage unbalance}(\%) = \frac{\text{Max. voltage(V)} - \text{Min. voltage(V)}}{\text{Three-phase average voltage(V)}} \times 67$$

If this value exceeds 2%, use an AC reactor (ACR).

*7 This specification is an estimate to be applied when the power supply capacity is 500 kVA (Inverter capacity x 10 when the capacity exceeds 50 kVA) and the power supply with %X = 5% is connected.

*8 This specification applies when a DC reactor (DCR) is used. (A DCR is optionally available for inverters of 55 kW or below.)

If the power source uses an electrical generator, it may burn due to the inverter harmonic current. To avoid such an accident, about three or four times the required capacity should be ensured. (About four times when no DCR is connected; about three times when a DCR is connected.)

*9 The inverter may automatically reduce the carrier frequency in accordance with the surrounding temperature or output current in order to protect itself.

Canceling the automatic lowering of the carrier frequency (HI04, hundreds digit) lowers the inverter's continuous rated current according to the carrier frequency setting. (For the details about the rated current lowering characteristics, refer to Chapter 2, Section 2.1.4.)

Three-phase 400 V class series

| Type (FRN___VG1S-4□) | 3.7 | 5.5 | 7.5 | 11 | 15 | 18.5 | 22 | 30 | 37 | 45 | 55 | 75 | 90 | 110 | 132 | 160 | 200 | 220 | 280 | 315 | 355 | 400 | 500 | 630 | |
|------------------------------------|--|--|------|------|------|------|------|------|------|------|------|-----|--|---|-----|-----|-----|-----|-----|-----|-----|-----|--------|------|------|
| Nominal applied motor (kW) | 3.7 | 5.5 | 7.5 | 11 | 15 | 18.5 | 22 | 30 | 37 | 45 | 55 | 75 | 90 | 110 | 132 | 160 | 200 | 220 | 280 | 315 | 355 | 400 | 500 | 630 | |
| Rated capacity (kVA) *1 | 6.8 | 10 | 14 | 18 | 24 | 29 | 34 | 45 | 57 | 69 | 85 | 114 | 134 | 160 | 192 | 231 | 287 | 316 | 396 | 445 | 495 | 563 | 731 | 891 | |
| Rated current (A) | 9.0 | 13.5 | 18.5 | 24.5 | 32.0 | 39.0 | 45.0 | 60.0 | 75.0 | 91.0 | 112 | 150 | 176 | 210 | 253 | 304 | 377 | 415 | 520 | 585 | 650 | 740 | 960 | 1170 | |
| Overload capability | 150% of the rated current -1 min. *2 200% of the rated current -3 s. *3 | | | | | | | | | | | | | | | | | | | | | | | | |
| Input power | Main power input: Phase, voltage, frequency | Three-phase, 380 to 480 V, 50/60 Hz | | | | | | | | | | | | Three-phase, 380 to 440 V/50 Hz, 380 to 480 V/60 Hz *4 | | | | | | | | | | | |
| | Auxiliary control power input: Phase, voltage, frequency | Single-phase, 380 to 480 V, 50/60 Hz | | | | | | | | | | | | | | | | | | | | | | | |
| | Auxiliary fan power input: Phase, voltage, frequency *5 | - | | | | | | | | | | | | Single-phase, 380 to 440 V/50 Hz, 380 to 480 V/60 Hz *4 | | | | | | | | | | | |
| | Allowable voltage/frequency | Voltage: +10 to -15% (Interphase voltage unbalance: 2% or less *6), Frequency: +5 to -5% | | | | | | | | | | | | | | | | | | | | | | | |
| | Rated current (A) *7 (with DCR) (without DCR) | 7.5 | 10.6 | 14.4 | 21.1 | 28.8 | 35.5 | 42.2 | 57.0 | 68.5 | 83.2 | 102 | 138 | 164 | 210 | 238 | 286 | 357 | 390 | 500 | 559 | 628 | 705 | 881 | 1115 |
| Required capacity (kVA) *8 | 5.2 | 7.4 | 10 | 15 | 20 | 25 | 30 | 40 | 48 | 58 | 71 | 96 | 114 | 140 | 165 | 199 | 248 | 271 | 347 | 388 | 436 | 489 | 610 | 773 | |
| Braking method , Braking torque | Braking resistor discharge control: 150% braking torque, Separately installed braking resistor (option), Separately installed braking unit (option for FRN200VG1S-4□ or higher type) | | | | | | | | | | | | | | | | | | | | | | | | |
| Carrier frequency (kHz) *9 | 2 to 15 | | | | | | | | | | | | 2 to 10 | | | | | | | | | | 2 to 5 | | |
| Approx. mass (kg) | 6.2 | 6.2 | 6.2 | 11 | 11 | 11 | 11 | 25 | 26 | 31 | 33 | 42 | 62 | 64 | 94 | 98 | 130 | 140 | 245 | 245 | 330 | 330 | 555 | 555 | |
| Enclosure | IP20, UL open type | | | | | | | | | | | | IP00, UL open type (IP20 is optionally available.) | | | | | | | | | | | | |

Note: A box (□) replaces an alphabetic letter depending on the shipping destination.

Note: The above specifications apply when Function code F80 = 0 (HD mode).

A DC reactor (DCR) is provided as standard for HD-mode inverters of 75 kW or above.

*1 This specification applies when the rated output voltage is 440 V.

*2 When the inverter output frequency converted is less than 10 Hz, the inverter may trip earlier due to overload depending on the ambient temperature and other conditions.

*3 When the inverter output frequency converted is less than 5 Hz, the inverter may trip earlier due to overload depending on the ambient temperature and other conditions.

*4 For 380 to 398 V/50 Hz or 380 to 430 V/60 Hz, connector switching is required inside the inverter.
If the input voltage is 380 V, the output may be reduced. For details, refer to Chapter 10, Section 10.5.1 "Combination list of 380V series."

*5 Use this input as an AC fan power in a power system using a power regenerative PWM converter. (Usually, there is no need to use this input.)

*6 Voltage unbalance(%) = $\frac{\text{Max. voltage(V)} - \text{Min. voltage(V)}}{\text{Three-phase average voltage(V)}} \times 67$

If this value exceeds 2%, use an AC reactor (ACR).

*7 This specification is an estimate to be applied when the power supply capacity is 500 kVA (Inverter capacity x 10 when the capacity exceeds 50 kVA) and the power supply with %X = 5% is connected.

*8 This specification applies when a DC reactor (DCR) is used. (A DCR is optionally available for inverters of 55 kW or below.)

If the power source uses an electrical generator, it may burn due to the inverter harmonic current. To avoid such an accident, about three or four times the required capacity should be ensured. (About four times when no DCR is connected; about three times when a DCR is connected.)

*9 The inverter may automatically reduce the carrier frequency in accordance with the surrounding temperature or output current in order to protect itself.

Canceling the automatic lowering of the carrier frequency (H104, hundreds digit) lowers the inverter's continuous rated current according to the carrier frequency setting. (For the details about the rated current lowering characteristics, refer to Chapter 2, Section 2.1.4.)

2.1.2 MD (Medium Duty)-mode inverters for medium load

Three-phase 400 V class series

| | | | | | | | | | | | |
|-----------------------------------|--|--|-----|-----|-----|-----|-----|-----|-----|-----|-----|
| Type (FRN ___VG1S-4□) | 90 | 110 | 132 | 160 | 200 | 220 | 280 | 315 | 355 | 400 | |
| Nominal applied motor (kW) *8 | 110 | 132 | 160 | 200 | 220 | 250 | 315 | 355 | 400 | 450 | |
| Rated capacity (kVA) *1 | 160 | 192 | 231 | 287 | 316 | 356 | 445 | 495 | 563 | 640 | |
| Rated current (A) | 210 | 253 | 304 | 377 | 415 | 468 | 585 | 650 | 740 | 840 | |
| Overload capability | 150% of the rated current -1 min. *2 | | | | | | | | | | |
| Input power | Main power input: Phase, voltage, frequency | Three-phase, 380 to 440 V/50 Hz, 380 to 480 V/60 Hz *3 | | | | | | | | | |
| | Auxiliary control power input: Phase, voltage, frequency | Single-phase, 380 to 480 V, 50/60 Hz | | | | | | | | | |
| | Auxiliary fan power input: Phase, voltage, frequency *4 | Single-phase, 380 to 440 V/50 Hz, 380 to 480 V/60 Hz *3 | | | | | | | | | |
| | Allowable voltage/frequency | Voltage: +10 to -15% (Interphase voltage unbalance: 2% or less *5), Frequency: +5 to -5% | | | | | | | | | |
| | Rated current (A) *6 (with DCR) (without DCR) | 210 | 238 | 286 | 357 | 390 | 443 | 559 | 628 | 705 | 789 |
| | Required capacity (kVA) *7 | 140 | 165 | 199 | 248 | 271 | 312 | 388 | 436 | 489 | 547 |
| Braking method, Braking torque | Braking resistor discharge control: 150% braking torque, Separately installed braking resistor (option), Separately installed braking unit (option for FRN200VG1S-4□ or higher type) | | | | | | | | | | |
| Carrier frequency (kHz) *9 | 2 to 4 | | | | | | | | | | |
| Approx. mass (kg) | 62 | 64 | 94 | 98 | 130 | 140 | 245 | 245 | 330 | 330 | |
| Enclosure | IP00, UL open type (IP20 is optionally available.) | | | | | | | | | | |

Note: A box (□) replaces an alphabetic letter depending on the shipping destination.

Note: The above specifications apply when Function code F80 = 3 (MD mode).

To use the inverter in the MD mode, inform your Fuji Electric representative of the MD-mode use when placing an order. The inverter comes with a DC reactor (DCR) suitable for the nominal applied motor as standard.

*1 This specification applies when the rated output voltage is 440 V.

*2 When the inverter output frequency converted is less than 1 Hz, the inverter may trip earlier due to overload depending on the ambient temperature and other conditions.

*3 For 380 to 398 V/50 Hz or 380 to 430 V/60 Hz, connector switching is required inside the inverter.
If the input voltage is 380 V, the output may be reduced. For details, refer to Chapter 10, Section 10.5.1 "Combination list of 380V series."

*4 Use this input as an AC fan power in a power system using a power regenerative PWM converter. (Usually, there is no need to use this input.)

*5
$$\text{Voltage unbalance}(\%) = \frac{\text{Max. voltage(V)} - \text{Min. voltage(V)}}{\text{Three-phase average voltage(V)}} \times 67$$

If this value exceeds 2%, use an AC reactor (ACR).

*6 This specification is an estimate to be applied when the power supply capacity is equal to "Inverter capacity x 10" and the power supply with %X = 5% is connected.

*7 This specification applies when a DC reactor (DCR) is used.

If the power source uses an electrical generator, it may burn due to the inverter harmonic current. To avoid such an accident, about three or four times the required capacity should be ensured. (About four times when no DCR is connected; about three times when a DCR is connected.)

*8 Depending on the load conditions, motor heating may increase due to the low carrier frequency. When placing an order for motors, therefore, specify the MD-mode use.

*9 Running the PMSM at low carrier frequency may overheat the permanent magnet due to the output current harmonics, resulting in demagnetization. The carrier frequency specification of the inverter is low (2 to 4 kHz), so be sure to check the allowable carrier frequency of the motor. If the MD-mode inverter is not applicable due to the low carrier frequency (2 to 4 kHz), consider the HD mode (F80 = 0).

2.1.3 LD (Low Duty)-mode inverters for light load

Three-phase 200 V class series

| | | | | | | | |
|-----------------------------------|---|--|---|-----|--------|-----|-----|
| Type (FRN___VG1S-2□) | 30 | 37 | 45 | 55 | 75 | 90 | |
| Nominal applied motor (kW) | 37 | 45 | 55 | 75 | 90 | 110 | |
| Rated capacity (kVA) *1 | 55 | 68 | 81 | 107 | 131 | 158 | |
| Rated current (A) | 146 | 180 | 215 | 283 | 346 | 415 | |
| Overload capability | 120% of the rated current -1 min. *2 | | | | | | |
| Input power | Main power input: Phase, voltage, frequency | Three-phase, 200 to 220 V/50 Hz, 200 to 230 V/60 Hz *2 | | | | | |
| | Auxiliary control power input: Phase, voltage, frequency | Single-phase, 200 to 230 V, 50/60 Hz | | | | | |
| | Auxiliary fan power input: Phase, voltage, frequency *4 | - | Single-phase, 200 to 220 V/50 Hz, 200 to 230 V/60 Hz *3 | | | | |
| | Allowable voltage/frequency | Voltage: +10 to -15% (Interphase voltage unbalance: 2% or less *5), Frequency: +5 to -5% | | | | | |
| | Rated current (A) *6 (with DCR) | 138 | 167 | 203 | 282 | 334 | 410 |
| | (without DCR) | 185 | 225 | 270 | - | — | — |
| Required capacity (kVA) *7 | 48 | 58 | 71 | 98 | 116 | 143 | |
| Braking method, Braking torque | Braking resistor discharge control: 110% braking torque, Separately installed braking resistor (option), Separately installed braking unit (option for FRN75VG1S-2□ or higher type) | | | | | | |
| Carrier frequency (kHz) *8 | 2 to 10 | | | | 2 to 5 | | |
| Approx. mass (kg) | 25 | 32 | 42 | 43 | 62 | 105 | |
| Enclosure | IP00, UL open type (IP20 is optionally available.) | | | | | | |

Note: A box (□) replaces an alphabetic letter depending on the shipping destination.

Note: The above specifications apply when Function code F80 = 1 (LD mode).

To use the inverter of 55 kW or above in the LD mode, inform your Fuji Electric representative of the LD-mode use when placing an order. The inverter comes with a DC reactor (DCR) suitable for the nominal applied motor as standard.

*1 This specification applies when the rated output voltage is 220 V.

*2 When the inverter output frequency converted is less than 10 Hz, the inverter may trip earlier due to overload depending on the ambient temperature and other conditions.

*3 Inverters of 200 to 230 V/50 Hz are available on request.

*4 Use this input as an AC fan power in a power system using a power regenerative PWM converter. (Usually, there is no need to use this input.)

*5
$$\text{Voltage unbalance}(\%) = \frac{\text{Max. voltage(V)} - \text{Min. voltage(V)}}{\text{Three-phase average voltage(V)}} \times 67$$

If this value exceeds 2%, use an AC reactor (ACR).

*6 This specification is an estimate to be applied when the power supply capacity is 500 kVA (Inverter capacity x 10 when the capacity exceeds 50 kVA) and the power supply with %X = 5% is connected.

*7 This specification applies when a DC reactor (DCR) is used. (A DCR is optionally available for the FRN45VG1S-2□ or lower type.)

If the power source uses an electrical generator, it may burn due to the inverter harmonic current. To avoid such an accident, about three or four times the required capacity should be ensured. (About four times when no DCR is connected; about three times when a DCR is connected.)

*8 The inverter may automatically reduce the carrier frequency in accordance with the surrounding temperature or output current in order to protect itself.

Canceling the automatic lowering of the carrier frequency (H104, hundreds digit) lowers the inverter's continuous rated current according to the carrier frequency setting. (For the details about the rated current lowering characteristics, refer to Chapter 2, Section 2.1.4.)

Three-phase 400 V class series

| Type (FRN___VG1S-4□) | 30 | 37 | 45 | 55 | 75 | 90 | 110 | 132 | 160 | 200 | 220 | 280 | 315 | 355 | 400 | 500 | 630 | |
|-----------------------------------|--|--|-------------|------------|----------|----------|----------|---|----------|----------|----------|----------|----------|----------|----------|----------|-----------|-----------|
| Nominal applied motor (kW) | 37 | 45 | 55 | 75 | 90 | 110 | 132 | 160 | 200 | 220 | 280 | 355 | 400 | 450 | 500 | 630 | 710 | |
| Rated capacity (kVA) *1 | 57 | 69 | 85 | 114 | 134 | 160 | 192 | 231 | 287 | 316 | 396 | 495 | 563 | 640 | 731 | 891 | 1044 | |
| Rated current (A) | 75 | 91 | 112 | 150 | 176 | 210 | 253 | 304 | 377 | 415 | 520 | 650 | 740 | 840 | 960 | 1170 | 1370 | |
| Overload capability | 120% of the rated current -1 min. *2 | | | | | | | | | | | | | | | | | |
| Input power | Main power input: Phase, voltage, frequency | Three-phase, 380 to 480 V, 50/60 Hz | | | | | | Three-phase, 380 to 440 V/50 Hz, 380 to 480 V/60 Hz *3 | | | | | | | | | | |
| | Auxiliary control power input: Phase, voltage, frequency | Single-phase, 380 to 480 V, 50/60 Hz | | | | | | | | | | | | | | | | |
| | Auxiliary fan power input: Phase, voltage, frequency *4 | - | | | | | | Single-phase, 380 to 440 V/50 Hz, 380 to 480 V/60 Hz *3 | | | | | | | | | | |
| | Allowable voltage/frequency | Voltage: +10 to -15% (Interphase voltage unbalance: 2% or less *5), Frequency: +5 to -5% | | | | | | | | | | | | | | | | |
| | Rated current (A) *6 (with DCR) (without DCR) | 68.5 94.3 | 83.2 114 | 102 140 | 138 - | 164 - | 210 - | 238 - | 286 - | 357 - | 390 - | 500 - | 628 - | 705 - | 789 - | 881 - | 1115 - | 1256 - |
| Required capacity (kVA) *7 | 48 | 58 | 71 | 96 | 114 | 140 | 165 | 199 | 248 | 271 | 347 | 436 | 489 | 547 | 611 | 773 | 871 | |
| Braking method, Braking torque | Braking resistor discharge control: 110% braking torque, Separately installed braking resistor (option), Separately installed braking unit (option for FRN200VG1S-4□ or higher type) | | | | | | | | | | | | | | | | | |
| Carrier frequency (kHz) *8 | 2 to 10 | | | | | | 2 to 5 | | | | | | | | | | 2 | |
| Approx. mass (kg) | 25 | 26 | 31 | 33 | 42 | 62 | 64 | 94 | 98 | 130 | 140 | 245 | 245 | 330 | 330 | 555 | 555 | |
| Enclosure | IP00, UL open type (IP20 is optionally available.) | | | | | | | | | | | | | | | | | |

Note: A box (□) replaces an alphabetic letter depending on the shipping destination.

Note: The above specifications apply when Function code F80 = 1 (LD mode).

To use the inverter of 55 kW or above in the LD mode, inform your Fuji Electric representative of the LD-mode use when placing an order. The inverter comes with a DC reactor (DCR) suitable for the nominal applied motor as standard.

*1 This specification applies when the rated output voltage is 440 V.

*2 When the inverter output frequency converted is less than 10 Hz, the inverter may trip earlier due to overload depending on the ambient temperature and other conditions.

*3 For 380 to 398 V/50 Hz or 380 to 430 V/60 Hz, connector switching is required inside the inverter.
If the input voltage is 380 V, the output may be reduced. For details, refer to Chapter 10, Section 10.5.1 "Combination list of 380V series."

*4 Use this input as an AC fan power in a power system using a power regenerative PWM converter. (Usually, there is no need to use this input.)

*5
$$\text{Voltage unbalance}(\%) = \frac{\text{Max. voltage(V)} - \text{Min. voltage(V)}}{\text{Three-phase average voltage(V)}} \times 67$$

If this value exceeds 2%, use an AC reactor (ACR).

*6 This specification is an estimate to be applied when the power supply capacity is 500 kVA (Inverter capacity x 10 when the capacity exceeds 50 kVA) and the power supply with %X = 5% is connected.

*7 This specification applies when a DC reactor (DCR) is used. (A DCR is optionally available for the FRN45VG1S-4□ or lower type.)

If the power source uses an electrical generator, it may burn due to the inverter harmonic current. To avoid such an accident, about three or four times the required capacity should be ensured. (About four times when no DCR is connected; about three times when a DCR is connected.)

*8 The inverter may automatically reduce the carrier frequency in accordance with the surrounding temperature or output current in order to protect itself.

Canceling the automatic lowering of the carrier frequency (H104, hundreds digit) lowers the inverter's continuous rated current according to the carrier frequency setting. (For the details about the rated current lowering characteristics, refer to Chapter 2, Section 2.1.4.)

2.1.4 Rated current derating

Canceling the automatic lowering of the carrier frequency (H104, Hundreds digit) when the inverter drives a permanent magnet synchronous motor (PMSM) derates the continuous rated current of the inverter according to the carrier frequency setting (F26). Select the inverter capacity and the carrier frequency (F26) which match the motor specifications, referring to the tables given below.

HD (High Duty)-mode inverters for heavy load

Three-phase 200 V class series

| Nominal applied motor (kW) | Inverter type | Rated current (A) | Derated current (A) (Derating rate (%)) | | | | | | | | | | | | |
|----------------------------|----------------|-------------------|---|--------------|---------------|---------------|----------------|---------------|-----------------|---------------|----|----|----|----|----|
| | | | Carrier frequency setting made with F26 (kHz) | | | | | | | | | | | | |
| | | | 2 | 3 | 4 | 5 | 6 | 7 | 8 | 9 | 10 | 11 | 12 | 13 | 14 |
| 0.75 | FRN0.75VG1S-2□ | 5 | 5.00 (100%) | | 4.50 (90%) | 3.80 (76%) | 5.00 (100%) | 4.55 (91%) | 4.15 (83%) | 3.50 (70%) | | | | | |
| 1.5 | FRN1.5VG1S-2□ | 8 | 8.00 (100%) | | 7.20 (90%) | 6.08 (76%) | 8.00 (100%) | 7.28 (91%) | 6.64 (83%) | 5.60 (70%) | | | | | |
| 2.2 | FRN2.2VG1S-2□ | 11 | 11.0 (100%) | | 9.90 (90%) | 8.36 (76%) | 11.0 (100%) | 10.0 (91%) | 9.13 (83%) | 7.70 (70%) | | | | | |
| 3.7 | FRN3.7VG1S-2□ | 18 | 18.0 (100%) | | 16.2 (90%) | 13.6 (76%) | 18.0 (100%) | 16.3 (91%) | 14.9 (83%) | 12.6 (70%) | | | | | |
| 5.5 | FRN5.5VG1S-2□ | 27 | 27.0 (100%) | | 24.3 (90%) | 20.5 (76%) | 27.0 (100%) | 24.5 (91%) | 22.4 (83%) | 18.9 (70%) | | | | | |
| 7.5 | FRN7.5VG1S-2□ | 37 | 37.0 (100%) | | 33.3 (90%) | 28.1 (76%) | 37.0 (100%) | 33.6 (91%) | 30.7 (83%) | 25.9 (70%) | | | | | |
| 11 | FRN11VG1S-2□ | 49 | 49.0 (100%) | | 44.1 (90%) | 37.2 (76%) | 49.0 (100%) | 44.5 (91%) | 40.6 (83%) | 34.3 (70%) | | | | | |
| 15 | FRN15VG1S-2□ | 63 | 63.0 (100%) | | 56.7 (90%) | 47.8 (76%) | 63.0 (100%) | 57.3 (91%) | 52.2 (83%) | 44.1 (70%) | | | | | |
| 18.5 | FRN18.5VG1S-2□ | 76 | 76.0 (100%) | | 72.2 (95%) | 66.8 (88%) | 76.0 (100%) | | 69.9 (92%) | 60 (79%) | | | | | |
| 22 | FRN22VG1S-2□ | 90 | 90.0 (100%) | | 85.5 (95%) | 79.2 (88%) | 90.0 (100%) | | 82.8 (92%) | 71.1 (79%) | | | | | |
| 30 | FRN30VG1S-2□ | 119 | 119 (100%) | | 117 (99%) | 109 (92%) | 119 (100%) | | 113 (95%) | 103 (87%) | | | | | |
| 37 | FRN37VG1S-2□ | 146 | 146 (100%) | | 144 (99%) | 134 (92%) | 146 (100%) | | 138 (95%) | 127 (87%) | | | | | |
| 45 | FRN45VG1S-2□ | 180 | 180 (100%) | | 178 (99%) | 165 (92%) | 180 (100%) | | 171 (95%) | 156 (87%) | | | | | |
| 55 | FRN55VG1S-2□ | 215 | 215 (100%) | | 212 (99%) | 197 (92%) | 215 (100%) | | 204 (95%) | 187 (87%) | | | | | |
| 75 | FRN75VG1S-2□ | 283 | 283 (100%) | 274 (97%) | 263 (93%) | 283 (100%) | 271 (96%) | 268 (95%) | 254 *1 (90%) | | | | | | |
| 90 | FRN90VG1S-2□ | 346 | 346 (100%) | 335 (97%) | 321 (93%) | 346 (100%) | 332 (96%) | 328 (95%) | 311 *1 (90%) | | | | | | |

Note: A box (□) replaces an alphabetic letter depending on the shipping destination.

*1 The internal carrier frequency is 10 kHz independent of the F26 setting.

Three-phase 400 V class series

| Nominal applied motor (kW) | Inverter type | Rated current (A) | Derated current (A) (Derating rate (%)) | | | | | | | | | | | | |
|----------------------------|----------------|-------------------|---|--------------|--------------|-------------------|---------------|----------------|-----------------|---------------|---------------|---------------|---------------|---------------|----|
| | | | Carrier frequency setting made with F26 (kHz) | | | | | | | | | | | | |
| | | | 2 | 3 | 4 | 5 | 6 | 7 | 8 | 9 | 10 | 11 | 12 | 13 | 14 |
| 3.7 | FRN3.7VG1S-4□ | 9 | 9.00 (100%) | | | 8.55 (95%) | 7.65 (85%) | 9.00 (100%) | | | 8.10 (90%) | | 6.84 (76%) | | |
| 5.5 | FRN5.5VG1S-4□ | 13.5 | 13.5 (100%) | | | 12.8 (95%) | 11.4 (85%) | 13.5 (100%) | | | 12.1 (90%) | | 10.2 (76%) | | |
| 7.5 | FRN7.5VG1S-4□ | 18.5 | 18.5 (100%) | | | 17.5 (95%) | 15.7 (85%) | 18.5 (100%) | | | 16.6 (90%) | | 14.0 (76%) | | |
| 11 | FRN11VG1S-4□ | 24.5 | 24.5 (100%) | | | 21.8 (89%) | 17.6 (72%) | 24.5 (100%) | 22.2 (91%) | | 19.8 (81%) | | 16.4 (67%) | | |
| 15 | FRN15VG1S-4□ | 32 | 32.0 (100%) | | | 28.4 (89%) | 23.0 (72%) | 32.0 (100%) | | 29.1 (91%) | | 25.9 (81%) | | 21.4 (67%) | |
| 18.5 | FRN18.5VG1S-4□ | 39 | 39.0 (100%) | | | 36.2 (93%) | 32.3 (83%) | 39.0 (100%) | | | 34.7 (89%) | | 28.4 (73%) | | |
| 22 | FRN22VG1S-4□ | 45 | 45.0 (100%) | | | 41.8 (93%) | 37.3 (83%) | 45.0 (100%) | | | 40.0 (89%) | | 32.8 (73%) | | |
| 30 | FRN30VG1S-4□ | 60 | 60.0 (100%) | | | 54.0 (90%) | 45.0 (75%) | 60.0 (100%) | | | 51.0 (85%) | | 41.4 (69%) | | |
| 37 | FRN37VG1S-4□ | 75 | 75.0 (100%) | | | 67.5 (90%) | 56.2 (75%) | 75.0 (100%) | | | 63.7 (85%) | | 51.7 (69%) | | |
| 45 | FRN45VG1S-4□ | 91 | 91.0 (100%) | | | 81.9 (90%) | 68.2 (75%) | 91.0 (100%) | | | 77.3 (85%) | | 62.7 (69%) | | |
| 55 | FRN55VG1S-4□ | 112 | 112 (100%) | | | 100 (90%) | 84.0 (75%) | 112 (100%) | | | 95.0 (85%) | | 77.2 (69%) | | |
| 75 | FRN75VG1S-4□ | 150 | 150 (100%) | 141 (94%) | 115 (77%) | 150 (100%) | 130 (87%) | 126 (84%) | 111 *1 (74%) | | | | | | |
| 90 | FRN90VG1S-4□ | 176 | 176 (100%) | 165 (94%) | 135 (77%) | 176 (100%) | 153 (87%) | 147 (84%) | 130 *1 (74%) | | | | | | |
| 110 | FRN110VG1S-4□ | 210 | 210 (100%) | 197 (94%) | 161 (77%) | 210 (100%) | 182 (87%) | 176 (84%) | 155 *1 (74%) | | | | | | |
| 132 | FRN132VG1S-4□ | 253 | 253 (100%) | 237 (94%) | 194 (77%) | 253 (100%) | 220 (87%) | 212 (84%) | 187 *1 (74%) | | | | | | |
| 160 | FRN160VG1S-4□ | 304 | 304 (100%) | 285 (94%) | 234 (77%) | 304 (100%) | 264 (87%) | 255 (84%) | 224 *1 (74%) | | | | | | |
| 200 | FRN200VG1S-4□ | 377 | 377 (100%) | 354 (94%) | 290 (77%) | 377 (100%) | 327 (87%) | 316 (84%) | 278 *1 (74%) | | | | | | |
| 220 | FRN220VG1S-4□ | 415 | 415 (100%) | 390 (94%) | 319 (77%) | 415 (100%) | 361 (87%) | 348 (84%) | 307 *1 (74%) | | | | | | |
| 280 | FRN280VG1S-4□ | 520 | 520 (100%) | 488 (94%) | 400 (77%) | 520 (100%) | 452 (87%) | 436 (84%) | 384 *1 (74%) | | | | | | |
| 315 | FRN315VG1S-4□ | 585 | 585 (100%) | 549 (94%) | 450 (77%) | 585 (100%) | 509 (87%) | 491 (84%) | 432 *1 (74%) | | | | | | |
| 355 | FRN355VG1S-4□ | 650 | 650 (100%) | 611 (94%) | 500 (77%) | 650 (100%) | 565 (87%) | 546 (84%) | 481 *1 (74%) | | | | | | |
| 400 | FRN400VG1S-4□ | 740 | 740 (100%) | 695 (94%) | 569 (77%) | 740 (100%) | 643 (87%) | 621 (84%) | 547 *1 (74%) | | | | | | |
| 500 | FRN500VG1S-4□ | 960 | 960 (100%) | | | 960 *2 (100%) | | | | | | | | | |
| 630 | FRN630VG1S-4□ | 1170 | 1170 (100%) | | | 1170 *2 (100%) | | | | | | | | | |

Note: A box (□) replaces an alphabetic letter depending on the shipping destination.

*1 The internal carrier frequency is 10 kHz independent of the F26 setting.

*2 The internal carrier frequency is 5 kHz independent of the F26 setting.

MD (Medium Duty)-mode inverters for medium load

Three-phase 400 V class series

| Nominal applied motor (kW) | Inverter type | Rated current (A) | Derated current (A) (Derating rate (%)) | | | | | | | | | | | | |
|----------------------------|---------------|-------------------|---|---|---|---|---|---|---|---|----|----|----|--------------------|----|
| | | | Carrier frequency setting made with F26 (kHz) | | | | | | | | | | | | |
| | | | 2 | 3 | 4 | 5 | 6 | 7 | 8 | 9 | 10 | 11 | 12 | 13 | 14 |
| 110 | FRN90VG1S-4□ | 210 | 210 (100%) | | | | | | | | | | | 210 *1 (100%) | |
| 132 | FRN110VG1S-4□ | 253 | 253 (100%) | | | | | | | | | | | 253 *1 (100%) | |
| 160 | FRN132VG1S-4□ | 304 | 304 (100%) | | | | | | | | | | | 304 *1 (100%) | |
| 200 | FRN160VG1S-4□ | 377 | 377 (100%) | | | | | | | | | | | 377 *1 (100%) | |
| 220 | FRN200VG1S-4□ | 415 | 415 (100%) | | | | | | | | | | | 415 *1 (100%) | |
| 280 | FRN220VG1S-4□ | 468 | 468 (100%) | | | | | | | | | | | 468 *1 (100%) | |
| 315 | FRN280VG1S-4□ | 585 | 585.0 (100%) | | | | | | | | | | | 585.0 *1 (100%) | |
| 355 | FRN315VG1S-4□ | 650 | 650 (100%) | | | | | | | | | | | 650 *1 (100%) | |
| 400 | FRN355VG1S-4□ | 740 | 740 (100%) | | | | | | | | | | | 740 *1 (100%) | |
| 450 | FRN400VG1S-4□ | 840 | 840 (100%) | | | | | | | | | | | 840 *1 (100%) | |

Note: A box (□) replaces an alphabetic letter depending on the shipping destination.

*1 The internal carrier frequency is 4 kHz independent of the F26 setting.

LD (Low Duty)-mode inverters for light load**Three-phase 200 V class series**

| Nominal applied motor (kW) | Inverter type | Rated current (A) | Derated current (A) (Derating rate (%)) | | | | | | | | | | | | | | |
|----------------------------|---------------|-------------------|---|--------------|---------------|-----------------|--------------|-----------------|---|---|----|----|----|----|----|----|--|
| | | | Carrier frequency setting made with F26 (kHz) | | | | | | | | | | | | | | |
| | | | 2 | 3 | 4 | 5 | 6 | 7 | 8 | 9 | 10 | 11 | 12 | 13 | 14 | 15 | |
| 37 | FRN30VG1S-2□ | 146 | 146 (100%) | | | 140 (96%) | 138 (95%) | 131 *1 (90%) | | | | | | | | | |
| 45 | FRN37VG1S-2□ | 180 | 180 (100%) | | | 172 (96%) | 171 (95%) | 162 *1 (90%) | | | | | | | | | |
| 55 | FRN45VG1S-2□ | 215 | 215 (100%) | | | 206 (96%) | 204 (95%) | 193 *1 (90%) | | | | | | | | | |
| 75 | FRN55VG1S-2□ | 283 | 283 (100%) | | | 271 (96%) | 268 (95%) | 254 *1 (90%) | | | | | | | | | |
| 90 | FRN75VG1S-2□ | 346 | 342 (99%) | 335 (97%) | 346 (100%) | 335 *2 (97%) | | | | | | | | | | | |
| 110 | FRN90VG1S-2□ | 415 | 410 (99%) | 402 (97%) | 415 (100%) | 402 *2 (97%) | | | | | | | | | | | |

Note: A box (□) replaces an alphabetic letter depending on the shipping destination.

*1 The internal carrier frequency is 10 kHz independent of the F26 setting.

*2 The internal carrier frequency is 5 kHz independent of the F26 setting.

Three-phase 400 V class series

| Nominal applied motor (kW) | Inverter type | Rated current (A) | Derated current (A) (Derating rate (%)) | | | | | | | | | | | | | | |
|----------------------------|---------------|-------------------|---|---------------|----------------|------------------|---------------|------------------|---|---|----|----|----|----|----|----|--|
| | | | Carrier frequency setting made with F26 (kHz) | | | | | | | | | | | | | | |
| | | | 2 | 3 | 4 | 5 | 6 | 7 | 8 | 9 | 10 | 11 | 12 | 13 | 14 | 15 | |
| 37 | FRN30VG1S-4□ | 75 | 75.0 (100%) | | | 66.0 (88%) | 63.0 (84%) | 54.0 *1 (72%) | | | | | | | | | |
| 45 | FRN37VG1S-4□ | 91 | 91.0 (100%) | | | 80.0 (88%) | 76.4 (84%) | 65.5 *1 (72%) | | | | | | | | | |
| 55 | FRN45VG1S-4□ | 112 | 112 (100%) | | | 99.0 (88%) | 94.0 (84%) | 80.6 *1 (72%) | | | | | | | | | |
| 75 | FRN55VG1S-4□ | 150 | 150 (100%) | | | 132 (88%) | 126 (84%) | 108 *1 (72%) | | | | | | | | | |
| 90 | FRN75VG1S-4□ | 176 | 161 (92%) | 151 (86%) | 176 (100%) | 153 *2 (87%) | | | | | | | | | | | |
| 110 | FRN90VG1S-4□ | 210 | 193 (92%) | 180 (86%) | 210 (100%) | 182 *2 (87%) | | | | | | | | | | | |
| 132 | FRN110VG1S-4□ | 253 | 232 (92%) | 217 (86%) | 253 (100%) | 220 *2 (87%) | | | | | | | | | | | |
| 160 | FRN132VG1S-4□ | 304 | 279 (92%) | 261 (86%) | 304 (100%) | 264 *2 (87%) | | | | | | | | | | | |
| 200 | FRN160VG1S-4□ | 377 | 346 (92%) | 324 (86%) | 377 (100%) | 327 *2 (87%) | | | | | | | | | | | |
| 220 | FRN200VG1S-4□ | 415 | 481 (92%) | 356 (86%) | 415 (100%) | 361 *2 (87%) | | | | | | | | | | | |
| 280 | FRN220VG1S-4□ | 520 | 478 (92%) | 447 (86%) | 520 (100%) | 452 *2 (87%) | | | | | | | | | | | |
| 355 | FRN280VG1S-4□ | 650 | 598 (92%) | 559 (86%) | 650 (100%) | 565 *2 (87%) | | | | | | | | | | | |
| 400 | FRN315VG1S-4□ | 740 | 680 (92%) | 636 (86%) | 740 (100%) | 643 *2 (87%) | | | | | | | | | | | |
| 450 | FRN355VG1S-4□ | 840 | 772 (92%) | 722 (86%) | 840 (100%) | 730 *2 (87%) | | | | | | | | | | | |
| 500 | FRN400VG1S-4□ | 960 | 883 (92%) | 825 (86%) | 960 (100%) | 835 *2 (87%) | | | | | | | | | | | |
| 630 | FRN500VG1S-4□ | 1170 | 1076 (92%) | 1006 (86%) | 1170 (100%) | 1017 *2 (87%) | | | | | | | | | | | |
| 710 | FRN630VG1S-4□ | 1370 | 1287 (94%) | 1219 (89%) | 1370 (100%) | 1287 *2 (94%) | | | | | | | | | | | |

Note: A box (□) replaces an alphabetic letter depending on the shipping destination.

*1 The internal carrier frequency is 10 kHz independent of the F26 setting.

*2 The internal carrier frequency is 5 kHz independent of the F26 setting.

2.2 Common Specifications

| Item | | Explanation | | |
|------------|---|--|--|--|
| Control | Control method | | | |
| | For induction motor (IM) | <ul style="list-style-type: none"> • Vector control with speed sensor • Vector control without speed sensor • V/f control | | |
| | For permanent magnet synchronous motor (PMSM) | Vector control with speed sensor & magnetic pole position sensor | | |
| | Test mode | Simulation mode | | |
| Driving IM | Vector control with speed sensor | Setting resolution | Speed command Analog setting: 0.005% of maximum speed Digital setting: 0.005% of maximum speed | |
| | | | Torque command, Torque current command 0.01% of the rated torque | |
| | | Control accuracy | Speed | Analog setting: $\pm 0.1\%$ of maximum speed (at $25 \pm 10^\circ\text{C}$) Digital setting: $\pm 0.005\%$ of maximum speed (at -10 to $+50^\circ\text{C}$) |
| | | | Torque | $\pm 3\%$ of the rated torque (when a dedicated motor is in use) |
| | | Control response | Speed | 600 Hz *1 |
| | | Maximum speed | 500 Hz (when converted to the inverter output frequency) *1 *2 | |
| | | Speed control range | 1 : 1500 When the base speed is 1500 r/min: 1 to 1500 r/min to maximum speed (in the case of the PG pulse resolution 1024 P/R) 1 : 6 (Constant torque range : Constant output range) | |
| | Vector control without speed sensor | Setting resolution | Speed command Analog setting: 0.005% of maximum speed Digital setting: 0.005% of maximum speed | |
| | | | Torque command, Torque current command 0.01% of the rated torque | |
| | | Control accuracy | Speed | Analog setting: $\pm 0.1\%$ of maximum speed (at $25 \pm 10^\circ\text{C}$) Digital setting: $\pm 0.1\%$ of maximum speed (at -10 to $+50^\circ\text{C}$) |
| | | | Torque | $\pm 5\%$ of the rated torque |
| | | Control response | Speed | 40 Hz *1 |
| | | Maximum speed | 500 Hz (when converted to the inverter output frequency) *1 *3 | |
| | | Speed control range | 1 : 250 When the base speed is 1500 r/min: 6 to 1500 r/min to maximum speed 1 : 4 (Constant torque range : Constant output range) | |
| | V/f control | Setting resolution | Analog setting: 0.005% of maximum frequency Digital setting: 0.005% of maximum frequency | |
| | | Output frequency control accuracy | Analog setting: $\pm 0.2\%$ of maximum frequency (at $25 \pm 10^\circ\text{C}$) Digital setting: $\pm 0.01\%$ of maximum frequency (at -10 to $+50^\circ\text{C}$) | |
| | | Maximum frequency | 500 Hz | |
| | | Control range | 0.2 to 500 Hz 1 : 4 (Constant torque range : Constant output range) | |

*1 The specified value denotes the maximum value. It may not be reached depending on the carrier frequency setting and other conditions.

*2 Under vector control with speed sensor: 400 Hz when the carrier frequency is 5 kHz, 150 Hz when it is 2 kHz.

*3 Under vector control without speed sensor: 250 Hz when the carrier frequency is 5 kHz, 120 Hz when it is 2 kHz.

| Item | | Explanation | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
|-----------------------|----------------------------------|---|---|---|--|----------------|------------------------------|----|--------------------------|------------------|---------|-------------|-------------------|------------|----------------|---------|------|--------------|---|---------|---------------|--|--------------|--|-------------------------------------|-------|------------|--|----------|--------|
| Driving PMSM | Vector control with speed sensor | Setting resolution | Speed command | Analog setting: 0.005% of maximum speed Digital setting: 0.005% of maximum speed | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | | | Torque command, Torque current command | 0.01% of the rated torque | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | | Control accuracy | Speed | Analog setting: ±0.1% of maximum speed (at 25 ±10°C) Digital setting: ±0.005% of maximum speed (at -10 to +50°C) | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | | | Torque | ±3% of the rated torque (when a dedicated motor is in use) | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | | Control response | Speed | 600 Hz *1 | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | | Maximum speed | 500 Hz (when converted to the inverter output frequency) *1 *2 | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | | Speed control range | 1 : 1500 When the base speed is 1500 r/min: 1 to 1500 r/min to maximum speed (in the case of the PG pulse resolution 1024 P/R) | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| Control functions | Start/stop operation | | Keypad: and keys (for forward/reverse rotation), key (for stop) Digital input signals: "Switch normal/inverse operation," "Coast to a stop," "Reset alarm," "Select multistep speed," etc. | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | Speed setting | | Keypad: and keys External potentiometer: Three-terminal variable resistor (1 to 5kΩ) Analog input signals: 0 to ±10 V, 4-20 mA UP/DOWN control: When the digital input signal UP or DOWN is ON, the speed increases or decreases, respectively. Multistep speed: The combination of the four digital input signals SS1 , SS2 , SS4 and SS8 enables 15 different speeds to be selected. Digital signal: Using an option card enables speed setting with "16-bit parallel signals." Serial link operation: RS-485 (provided as standard). Various communication options are available. Jogging operation: and keys or digital input on [FWD] and [REV] terminals in jogging mode. | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | Speed detection | | The receivable frequency differs depending upon the speed detector used. <table border="1" style="width: 100%; border-collapse: collapse;"> <thead> <tr> <th colspan="2">PG interface</th> <th>Speed detector</th> <th>Maximum frequency receivable</th> </tr> </thead> <tbody> <tr> <td rowspan="3">IM</td> <td>PG interface on inverter</td> <td>Complementary PG</td> <td rowspan="2">100 kHz</td> </tr> <tr> <td>OPC-VG1-PGo</td> <td>Open-collector PG</td> </tr> <tr> <td>OPC-VG1-PG</td> <td>Line driver PG</td> <td>500 kHz</td> </tr> <tr> <td rowspan="2">PMSM</td> <td>OPC-VG1-PMPG</td> <td>Line driver PG (with magnetic pole position function)</td> <td rowspan="2">100 kHz</td> </tr> <tr> <td>OPC-VG1-PMPGo</td> <td>Open-collector PG (with magnetic pole position function)</td> </tr> <tr> <td colspan="2">OPC-VG1-SPGT</td> <td>Serial PG (17-bit absolute encoder)</td> <td>1 MHz</td> </tr> <tr> <td colspan="2">OPC-VG1-RD</td> <td>Resolver</td> <td>10 kHz</td> </tr> </tbody> </table> <p>Some PG interface options require a dedicated cable.</p> | PG interface | | Speed detector | Maximum frequency receivable | IM | PG interface on inverter | Complementary PG | 100 kHz | OPC-VG1-PGo | Open-collector PG | OPC-VG1-PG | Line driver PG | 500 kHz | PMSM | OPC-VG1-PMPG | Line driver PG (with magnetic pole position function) | 100 kHz | OPC-VG1-PMPGo | Open-collector PG (with magnetic pole position function) | OPC-VG1-SPGT | | Serial PG (17-bit absolute encoder) | 1 MHz | OPC-VG1-RD | | Resolver | 10 kHz |
| | PG interface | | Speed detector | Maximum frequency receivable | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | IM | PG interface on inverter | Complementary PG | 100 kHz | | | | | | | | | | | | | | | | | | | | | | | | | | |
| OPC-VG1-PGo | | Open-collector PG | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| OPC-VG1-PG | | Line driver PG | 500 kHz | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| PMSM | OPC-VG1-PMPG | Line driver PG (with magnetic pole position function) | 100 kHz | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | OPC-VG1-PMPGo | Open-collector PG (with magnetic pole position function) | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| OPC-VG1-SPGT | | Serial PG (17-bit absolute encoder) | 1 MHz | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| OPC-VG1-RD | | Resolver | 10 kHz | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| Speed control | | PI calculation with feed-forward terms. Control parameters switchable by external signals. | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| Running status signal | | Transistor output signals: "Inverter running," "Speed arrival," "Speed detected," "Inverter overload early warning," "Torque limiting," etc. Analog output signals: "Motor speed," "Output voltage," "Torque," "Load factor," etc. | | | | | | | | | | | | | | | | | | | | | | | | | | | | |

*1 The specified value denotes the maximum value. It may not be reached depending on the carrier frequency setting and other conditions.

*2 Under vector control with speed sensor: 400 Hz when the carrier frequency is 5 kHz, 150 Hz when it is 2 kHz.

| Item | | Explanation | |
|-------------------|--|--|---|
| Control functions | Acceleration/ deceleration time | 0.01 to 3600 s (Four independent settings can be made for each of acceleration and deceleration. They are selectable with external signals.) (S-curve acceleration/deceleration in addition to linear acceleration/deceleration) | |
| | Speed setting gain | Proportional relationship between analog speed setting and motor speed can be specified in the range of 0 to 200%. | |
| | Jump speed | Jump speed (3 points) and jump hysteresis width (1 point) can be specified. | |
| | Auto search for idling motor speed | Automatically searches for the idling motor speed to be harmonized and starts to drive it without stopping it. (Available under vector control with/without speed sensor) | |
| | Auto-restart after momentary power failure | Possible to restart the inverter after a momentary power failure without stopping the motor depending on the restart mode setting. | |
| | Slip compensation | Compensates for decrease in speed according to the load for stabilized operation. (Available for IM under V/f control.) | |
| | Droop control | The motor speed droops in proportion to output torque. (Not available under V/f control.) | |
| | Torque limit | Limits the torque to the predetermined values (selectable from "common to 4 quadrants", "independent driving and braking", etc.) Analog and external signal (2 steps) settings are available. | |
| | Torque control | Analog setting: 0 to $\pm 10V/0$ to $\pm 150\%$ (Up to 300% by gain adjustment) Digital setting: Using an option card enables torque control with "16-bit parallel signals." | |
| | PID control | PID control with analog input Possible to select whether to use the PID output as speed setting or auxiliary setting to be added or subtracted to/from the main setting. | |
| | Cooling fan ON/OFF control | Stops cooling fans when the motor is stopped and the temperature is low for lifetime extension and noise reduction of the cooling fans. | |
| | Toggle monitor control | Monitors communication between the host equipment (PLC) and the inverter to see whether the communication is normal. | |
| | Torque bias | The combination of the fixed value (one step, with the polarity switching function by the motor rotation direction) and digital input signals TBI and TB2 provides three steps of torque bias internal setting. Analog setting (with Hold function) is available. | |
| | Motor selection | Selectable from the three types of motors, by Function code F79. Switchable between the three types of motors by the combination of digital input signals. | |
| | Temperature detection | NTC thermistor (Equivalent to Fuji Electric specifications) PTC thermistor exclusively used for protection from motor overheat (The trip level is specified by parameters.) | |
| | Self-diagnostic function for PG detection circuit | Self-diagnoses the detection circuit of pulse generator input signals (PA and PB). | |
| | Load adaptive control | Calculates the maximum allowable elevating speed (e.g., vertical carrier machine) according to the load to improve the operation efficiency of the equipment. | |
| | Multiplex system | Multiwinding motor drive | Option: OPC-VG1-TBSI is required. Maximum number of multiplexes: 6 units Control specifications: Available only under vector control with speed sensor |
| | | Direct parallel connection *1 | Option: OPC-VG1-TBSI is required. Maximum number of multiplexes: 3 units The carrier frequency is fixed at 2 kHz. Restrictions on the output wiring length and other operating conditions |
| | UP/DOWN control | Speed setting by the combination of digital input signals UP , DOWN , and CLR ("Clear ACC/DEC to zero") | |
| Stop function | Three types of the stop functions by digital input signals STOP1 , STOP2 , and STOP3 . | | |
| PG pulse output | Outputs pulse generator signals (input pulses) with fixed frequency dividing or arbitrary frequency dividing. Switchable between open collector and complementary (equivalent to the voltage on the [PGP] terminal) transistor outputs, by the slide switch in the inverter unit. | | |

*1 Available in the ROM version H1/2 0020 or later.

| Item | | Explanation | |
|---|------------------|--|--|
| Control functions | Observer | Suppresses load disturbances and vibrations. | |
| | Offline tuning | Tunes the motor parameters while the motor is stopped or running. | |
| | Online tuning | Tunes the motor parameters to compensate for the temperature change. | |
| | Position control | Standard function: Position control by servo-lock and integrated oscillation circuit | |
| | Option | OPC-VG1-PG (PR): For pulse command input of line driver type OPC-VG1-PGo (PR): For pulse command input of open collector type OPC-VG7-SPGT: 17-bit high resolution ABS encoder | |
| Pulse train, synchronous operation (Option) | | OPC-VG1-PG (PR): For pulse command input of line driver type OPC-VG1-PGo (PR): For pulse command input of open collector type | |
| Indication/Setting | Keypad | Display | 7-segment LED monitor and backlit LCD |
| | | Multilingual display | Four languages: Japanese, English, Chinese, and Korean |
| | | When the inverter is running or stopped | <ul style="list-style-type: none"> • Detected speed • Output frequency • Torque command value • Power consumption (Motor output) • Output voltage • Magnetic-flux command value • Load shaft speed • PID feedback value • Ai adjusted value (I2) • Ai adjusted value (Ai2) • Presence of digital input/output signal • Heat sink temperature • Input power • Operation time • Cumulative run time of the motor/Number of startups (for each motor), etc. <ul style="list-style-type: none"> • Speed command • Reference torque current value • Torque calculation value • Output current • DC link circuit voltage • Magnetic-flux calculation value • PID command value • PID output value • Ai adjusted value (Ai1) • Optional monitor 1 to 6 • Motor temperature • Load factor • Input watt-hour |
| | | When function codes are configured | Function code names and data are displayed. |
| | | When an alarm occurs | Alarm factors that appear: <ul style="list-style-type: none"> • dbrH (Braking resistor overheated) • EF (Ground fault) • Er2 (Keypad communications error) • Er4 (Communications error) • Er5 (Operation error) • Er8 (A/D converter error) • L ir (Input phase loss) • rrb (NTC wire break error) • H i (Heat sink overheat) • H3 (Inverter internal overheat) • OL 1 (Overload of motor 1) • OL 3 (Overload of motor 3) • OS (Overspeed) • PG (PG wire break) • dbrA (Braking transistor broken) • OPL (Output phase loss) • ErH (Hardware error) • ErA (UPAC error) *1 • Erb (Inter-inverter communications link error) • ECC (Functional safety circuit error) *1 • dI (Excessive positioning deviation) • L dC (Start delay) • FrF (Toggle error detection alarm) • S iF (Functional safety card error) *1 <ul style="list-style-type: none"> • dLF (DC fuse blown) • Er i (Memory error) • Er3 (CPU error) • Er5 (RS-485 communications error) • Er7 (Output wire fault) • Er9 (Speed mismatch) • LL (Undervoltage) • OL (Overcurrent) • H2 (External alarm) • H4 (Motor protection) • OL 2 (Overload of motor 2) • OL L (Inverter overload) • OL (Overvoltage) • PbF (Charger circuit fault) • Err (Mock alarm) • dFF (DC fan locked) • EL (Encoder communications error) • Et i (Encoder error) • FrE (E-SX error) • SrF (Functional safety card error) *1 |

*1 Available in the ROM version H1/2 0020 or later.

| Item | | Explanation | |
|--------------------|--|---|---|
| Indication/Setting | Keypad | When a light alarm occurs | The light-alarm display $\angle -\overline{L}$ appears. The inverter retains the cause of the light alarm to display it. |
| | | When the inverter is running or an alarm occurs | The inverter retains the latest and the last 10 alarm codes and the latest and the last three pieces of alarm information to display them. The calendar clock function retains the date and time*2 when an alarm occurred to display them. (Precision: ± 27 seconds/month ($T_a = 25^\circ\text{C}$)) Data retention period *2: At least 5 years (at the surrounding temperature 25°C) |
| | FRENIC-VG Loader | Historical trace *1 | Reads out the sampling data held in the inverter and shows it graphically. Sampling interval: 50 μs to 1 s |
| | | Real-time trace *1 | Reads out the current data of the running inverter and shows it graphically in real-time. Sampling interval: 1 ms to 1 s |
| | | Traceback | Reads out the sampling data held in the inverter and shows it graphically when an alarm has occurred. Sampling interval: 50 μs to 1s (400 μs for sampling data except current) The sampling data is retained in the memory by the backup battery. *2 Data retention period: At least 5 years (at the surrounding temperature 25°C) |
| | | Operation monitor *1 | I/O monitor, system monitor, alarm history monitor, etc. |
| | Configuration of function code | Shows the configuration of the function codes, as well as enabling editing, transmitting, comparing, and initialization. | |
| Charge lamp | Lights when power is applied to the inverter unit. (Lights when power is applied to the control circuit only.) | | |
| Maintenance | Main circuit capacitor life | Life judgment function installed | |
| | Common functions | <ul style="list-style-type: none"> Retains and displays the cumulative run time of the main circuit capacitor and the cumulative run time of cooling fans. Retains and displays the inverter operation time. Retains and displays the maximum output current and the maximum internal temperature for the past one hour. | |
| Communications | RS-485 | I/O terminals to connect the inverter with a computer or programmable logic controller (PLC) for RS-485 communication. | |
| | USB | USB connector (mini B) to connect the inverter with a computer. This enables you to use the inverter support loader running on the computer for editing, transferring and verifying the inverter function codes, making a test run of the inverter, and monitoring various inverter statuses. | |
| Compatibility | VG7 | Function code data | Compatible with the VG7 function codes, except function codes for the 3rd motor. (Using the VG7 function codes as is produces the same operation on the FRENIC-VG.) Possible to read out VG7 function code data using FRENIC-VG Loader and write it as is into the FRENIC-VG. (Except special inverter versions) |
| | | Various communications tools | Fully compatible with T-Link, SX-bus, and CC-Link. (Software in the host equipment PLC is available as is. Except special software.) |
| | Mounting adapter | Mounting adapters are provided for matching the FRENIC-VG with conventional models in mounting dimensions. | |

*1 Available in the paid-for version of FRENIC-VG Loader (WPS-VG1-PCL).

*2 Backup battery: Included as standard for inverters of 30 kW or above
Option (OPK-BP) for inverters of 22 kW or below

| Item | | Explanation | | |
|--------------------------|--|---|---|---|
| Product standards | UL Standards and Canadian Standards *1 | UL, cUL (UL508C, C22.2 No.14) *2 | | |
| | European Standards (CE marking) *1 | Machinery Directive | EN ISO13849-1: PL-d category: 3 IEC/EN 60204-1: Stop category 0 | |
| | | Low Voltage Directive | IEC/EN 61800-5-1 (Overvoltage category: 3) | |
| | | EMC Standards | IEC/EN 61800-3, IEC/EN 61326-3-1 Emission (EMC-filter: option) 220 kW or below: Category C2 280 kW or above: Category C3 Immunity 2nd Env. | |
| | Functional Safety (European Standards) | IEC/EN 61800-5-2: SIL2 IEC/EN 62061: SIL2 | | |
| | | Safe Torque Off (STO) | Turning off external digital input signals on terminals [EN1] and [EN2] activates the STO function that shuts down the inverter output transistor by hardware to coast the motor to a stop. | |
| | | The optional functional safety card OPC-VG1-SAFE has the following functions. ☐ Refer to the Functional Safety Card instruction manual (INR-SI47-1541). | | |
| | | Safe Torque Off (STO) (standard function) | Turning off external digital input signals on terminals [EN1] and [EN2] activates the STO function that shuts down the inverter output transistor by hardware to coast the motor to a stop. | |
| | | Safe Stop 1 (SS1) | This SS1 function decelerates the motor speed and shuts down the inverter output to the motor (torque off) by using the STO function immediately when the motor speed decelerates to the specified speed or the specified time has elapsed. | |
| | | Safely Limited Speed (SLS) | The SLS function prevents the motor from exceeding the specified speed. | |
| Safe Brake Control (SBC) | The SBC function outputs motor brake control signals. | | | |
| Environment | Installation location | Shall be free from corrosive gases, flammable gases, oil mist, dusts, and direct sunlight. (Pollution degree 2 (IEC60664-1)). Indoor use only. | | |
| | Surrounding temperature | -10 to +50°C (-10 to +40°C when installed side-by-side without clearance (22 kW or below)) | | |
| | Relative humidity | 5 to 95% RH (without condensation) | | |
| | Altitude | Lower than 3,000 m If the altitude is 1,001 to 3,000 m, output current derating is required. If it is 2,001 to 3,000 m, the insulation level of the control circuits lowers from the reinforced insulation to the basic insulation. Refer to Chapter 3, Section 3.3 "Mounting and Wiring." | | |
| | Vibration | <table border="1" style="width: 100%; border-collapse: collapse;"> <tr> <td style="width: 50%; vertical-align: top;"> 200 V 55 kW, 400 V 75 kW or below 3 mm: 2 to less than 9 Hz, 9.8m/s²: 9 to less than 20 Hz 2 m/ s²: 20 to less than 55 Hz 1 m/ s²: 55 to less than 200 Hz </td> <td style="width: 50%; vertical-align: top;"> 200V 75 kW, 400 V 90 kW or above 3 mm: 2 to less than 9 Hz 2 m/s²: 9 to less than 55 Hz 1 m/s²: 55 to less than 200 Hz </td> </tr> </table> | 200 V 55 kW, 400 V 75 kW or below 3 mm: 2 to less than 9 Hz, 9.8m/s ² : 9 to less than 20 Hz 2 m/ s ² : 20 to less than 55 Hz 1 m/ s ² : 55 to less than 200 Hz | 200V 75 kW, 400 V 90 kW or above 3 mm: 2 to less than 9 Hz 2 m/s ² : 9 to less than 55 Hz 1 m/s ² : 55 to less than 200 Hz |
| | 200 V 55 kW, 400 V 75 kW or below 3 mm: 2 to less than 9 Hz, 9.8m/s ² : 9 to less than 20 Hz 2 m/ s ² : 20 to less than 55 Hz 1 m/ s ² : 55 to less than 200 Hz | 200V 75 kW, 400 V 90 kW or above 3 mm: 2 to less than 9 Hz 2 m/s ² : 9 to less than 55 Hz 1 m/s ² : 55 to less than 200 Hz | | |
| | Storage temperature | -25 to +70°C | | |
| Storage humidity | 5 to 95% RH (without condensation) | | | |

*1 Available in the ROM version H1/2 0020 or later.

*2 The FRN45/55VG1S-2☐ and FRN75/160/200/220/355/400VG1S-4☐ do not conform to C22.2 No. 14. If necessary, contact your Fuji Electric representative.

2.3 External Dimensions

2.3.1 Standard models


The diagrams below show external dimensions of the FRENIC-VG series of inverters according to the inverter capacity. (Three-phase 200 V/400 V class series)

A figure given in the lower right-hand corner of each set of drawings shows the dimension of panel cutting required for external cooling. To employ external cooling for inverters of 22 kW or below, the optional mounting adapter for external cooling is necessary. For the external dimensions of the mounting adapter, refer to Chapter 8, Section 8.5.8 "Mounting adapter for external cooling."

(Unit: mm)


■ FRN0.75 to 7.5VG1S-2□

■ FRN3.7 to 7.5VG1S-4□



■ FRN11 to 22VG1S-2□

■ FRN11 to 22VG1S-4□




Note: A box (□) replaces an alphabetic letter depending on the shipping destination.


A figure given in the lower right-hand corner of each set of drawings shows the dimension of panel cutting required for employing external cooling. To employ external cooling for inverters of 30 kW or above, change the positions of the mounting bases. For details, refer to Chapter 3, Section 3.3.2 "Installing the Inverter, ■ When employing external cooling."

(Unit: mm)

- FRN30VG1S-2□
- FRN30/37VG1S-4□




- FRN37VG1S-2□
- FRN45VG1S-4□




Note: A box (□) replaces an alphabetic letter depending on the shipping destination.

(Unit: mm)

■ FRN45VG1S-2□



■ FRN55VG1S-2□



| | Reactor | Figure | W | W1 | D | D1 | D2 | G | H | H1 | J | Approx. mass (kg) |
|---------|-------------|--------|-----|-----|-----|----|-----|-----------|-----|-----|-----|-------------------|
| HD mode | DCR2-55B *1 | D | 190 | 160 | 131 | 90 | 100 | M6 (φ8) | 210 | 250 | M12 | 16 |
| | DCR2-55C *1 | C | 255 | 225 | 96 | 76 | 140 | M6 (7*13) | 145 | - | M12 | 11 |
| LD mode | DCR2-75C | C | 255 | 225 | 106 | 86 | 145 | M6 (7*13) | 145 | - | M12 | 12 |

*1 The DCR2-55B and DCR2-55C are optionally available.

Note: A box (□) replaces an alphabetic letter depending on the shipping destination.

(Unit: mm)

■ FRN75VG1S-2□





Figure C

| | Reactor | Figure | W | W1 | D | D1 | D2 | G | H | H1 | J | Approx. mass (kg) |
|---------|----------|--------|-----|-----|-----|----|-----|-----------|-----|----|-----|-------------------|
| HD mode | DCR2-75C | C | 255 | 225 | 106 | 86 | 145 | M6 (7*13) | 145 | - | M12 | 12 |
| LD mode | DCR2-90C | | 255 | 225 | 116 | 96 | 155 | M6 (7*13) | 145 | - | M12 | 14 |

■ FRN90VG1S-2□






Figure C

| | Reactor | Figure | W | W1 | D | D1 | D2 | G | H | H1 | J | Approx. mass (kg) |
|---------|-----------|--------|-----|-----|-----|----|-----|------------|-----|----|-----|-------------------|
| HD mode | DCR2-90C | C | 255 | 225 | 116 | 96 | 155 | M6 (7*13) | 145 | - | M12 | 14 |
| LD mode | DCR2-110C | | 300 | 265 | 116 | 90 | 185 | M8 (10*18) | 160 | - | M12 | 17 |

Note: A box (□) replaces an alphabetic letter depending on the shipping destination.

(Unit: mm)


■ FRN55VG1S-4□



| | Reactor | Figure | W | W1 | D | D1 | D2 | G | H | H1 | J | Approx. mass (kg) |
|---------|-------------|--------|-----|-----|-----|-----|-----|-----------|-----|-----|-----|-------------------|
| HD mode | DCR4-55B *1 | B | 171 | 110 | 170 | 130 | 110 | M6 (φ8) | 150 | 210 | M8 | 20 |
| | DCR4-55C *1 | C | 255 | 225 | 96 | 76 | 120 | M6 (7*13) | 145 | - | M10 | 11 |
| LD mode | DCR4-75C | C | 255 | 225 | 106 | 86 | 125 | M6 (7*13) | 145 | - | M10 | 13 |

*1 The DCR4-55B and DCR4-55C are optionally available.

■ FRN75VG1S-4□



| | Reactor | Figure | W | W1 | D | D1 | D2 | G | H | H1 | J | Approx. mass (kg) |
|---------|----------|--------|-----|-----|-----|----|-----|-----------|-----|----|-----|-------------------|
| HD mode | DCR4-75C | C | 255 | 225 | 106 | 86 | 125 | M6 (7*13) | 145 | - | M10 | 13 |
| LD mode | DCR4-90C | | 255 | 225 | 116 | 96 | 140 | M6 (7*13) | 145 | - | M12 | 15 |

Note: A box (□) replaces an alphabetic letter depending on the shipping destination.

(Unit: mm)

■ FRN90VG1S-4□





Figure C

| | Reactor | Figure | W | W1 | D | D1 | D2 | G | H | H1 | J | Approx. mass (kg) |
|---------|-----------|--------|-----|-----|-----|----|-----|------------|-----|----|-----|-------------------|
| HD mode | DCR4-90C | C | 255 | 225 | 116 | 96 | 140 | M6 (7*13) | 145 | - | M12 | 15 |
| MD mode | DCR4-110C | | 300 | 265 | 116 | 90 | 175 | M8 (10*18) | 155 | - | M12 | 19 |
| LD mode | | | | | | | | | | | | |

■ FRN110VG1S-4□





Figure C

| | Reactor | Figure | W | W1 | D | D1 | D2 | G | H | H1 | J | Approx. mass (kg) | | | | | | | | | | |
|---------|-----------|--------|-----|-----|-----|----|-----|------------|-----|----|-----|-------------------|-----|-----|-----|-----|-----|------------|-----|---|-----|----|
| HD mode | DCR4-110C | C | 300 | 265 | 116 | 90 | 175 | M8 (10*18) | 155 | - | M12 | 19 | | | | | | | | | | |
| MD mode | DCR4-132C | | | | | | | | | | | | 300 | 265 | 126 | 100 | 180 | M8 (10*18) | 160 | - | M12 | 22 |
| LD mode | | | | | | | | | | | | | | | | | | | | | | |

Note: A box (□) replaces an alphabetic letter depending on the shipping destination.

(Unit: mm)

■ FRN132VG1S-4□




Figure C

| | Reactor | Figure | W | W1 | D | D1 | D2 | G | H | H1 | J | Approx. mass (kg) |
|---------|-----------|--------|-----|-----|-----|-----|-----|-------------|-----|----|-----|-------------------|
| HD mode | DCR4-132C | C | 300 | 265 | 126 | 100 | 180 | M8 (10*18) | 160 | - | M12 | 22 |
| MD mode | DCR4-160C | | 350 | 310 | 131 | 103 | 180 | M10 (12*22) | 190 | - | M12 | 26 |
| LD mode | | | | | | | | | | | | |

■ FRN160VG1S-4□




Figure C

| | Reactor | Figure | W | W1 | D | D1 | D2 | G | H | H1 | J | Approx. mass (kg) |
|---------|-----------|--------|-----|-----|-----|-----|-----|-------------|-----|----|-----|-------------------|
| HD mode | DCR4-160C | C | 350 | 310 | 131 | 103 | 180 | M10 (12*22) | 190 | - | M12 | 26 |
| MD mode | DCR4-200C | | 350 | 310 | 141 | 113 | 185 | M10 (12*22) | 190 | - | M12 | 30 |
| LD mode | | | | | | | | | | | | |

Note: A box (□) replaces an alphabetic letter depending on the shipping destination.

(Unit: mm)

■ FRN200VG1S-4□





Figure C

| | Reactor | Figure | W | W1 | D | D1 | D2 | G | H | H1 | J | Approx. mass (kg) |
|---------|-----------|--------|-----|-----|-----|-----|-----|-------------|-----|----|-----|-------------------|
| HD mode | DCR4-200C | C | 350 | 310 | 141 | 113 | 185 | M10 (12*22) | 190 | - | M12 | 30 |
| MD mode | DCR4-220C | | 350 | 310 | 146 | 118 | 200 | M10 (12*22) | 190 | - | M12 | 33 |
| LD mode | | | | | | | | | | | | |

■ FRN220VG1S-4□





Figure C

| | Reactor | Figure | W | W1 | D | D1 | D2 | G | H | H1 | J | Approx. mass (kg) |
|---------|-----------|--------|-----|-----|-----|-----|-----|-------------|-----|----|-----|-------------------|
| HD mode | DCR4-220C | C | 350 | 310 | 146 | 118 | 200 | M10 (12*22) | 190 | - | M12 | 33 |
| MD mode | DCR4-250C | | 350 | 310 | 161 | 133 | 210 | M10 (12*22) | 190 | - | M12 | 35 |
| LD mode | DCR4-280C | | 350 | 310 | 161 | 133 | 210 | M10 (12*22) | 190 | - | M16 | 37 |

Note: A box (□) replaces an alphabetic letter depending on the shipping destination.

(Unit: mm)

■ FRN280VG1S-4□





Figure C




Figure E

| | Reactor | Figure | W | W1 | D | D1 | D2 | G | H | H1 | J | Approx. mass (kg) |
|---------|-----------|--------|-----|-----|-----|-----|-----|-------------|-----|----|-------|-------------------|
| HD mode | DCR4-280C | C | 350 | 310 | 161 | 133 | 210 | M10 (12*22) | 190 | - | M16 | 37 |
| MD mode | DCR4-315C | | 400 | 345 | 146 | 118 | 200 | M10 (12*22) | 225 | - | M16 | 40 |
| LD mode | DCR4-355C | E | 400 | 345 | 156 | 128 | 200 | M10 (12*22) | 225 | - | 4*M12 | 49 |

■ FRN315VG1S-4□





Figure C




Figure E

| | Reactor | Figure | W | W1 | D | D1 | D2 | G | H | H1 | J | Approx. mass (kg) |
|---------|-----------|--------|-----|-----|-----|-----|-----|-------------|-----|----|-------|-------------------|
| HD mode | DCR4-315C | C | 400 | 345 | 146 | 118 | 200 | M10 (12*22) | 225 | - | M16 | 40 |
| MD mode | DCR4-355C | E | 400 | 345 | 156 | 128 | 200 | M10 (12*22) | 225 | - | 4*M12 | 49 |
| LD mode | DCR4-400C | | 445 | 385 | 145 | 117 | 213 | M10 (12*22) | 245 | - | 4*M12 | 52 |

Note: A box (□) replaces an alphabetic letter depending on the shipping destination.

(Unit: mm)

■ FRN355VG1S-4□





Figure E

| | Reactor | Figure | W | W1 | D | D1 | D2 | G | H | H1 | J | Approx. mass (kg) |
|---------|-----------|--------|-----|-----|-----|-----|-----|------------|-----|----|-------|-------------------|
| HD mode | DCR4-355C | E | 400 | 345 | 156 | 128 | 200 | M10(12*22) | 225 | - | 4*M12 | 49 |
| MD mode | DCR4-400C | | 445 | 385 | 145 | 117 | 213 | M10(12*22) | 245 | - | 4*M12 | 52 |
| LD mode | DCR4-450C | | 440 | 385 | 150 | 122 | 215 | M10(12*22) | 245 | - | 4*M12 | 62 |

■ FRN400VG1S-4□





Figure E

| | Reactor | Figure | W | W1 | D | D1 | D2 | G | H | H1 | J | Approx. mass (kg) |
|---------|-----------|--------|-----|-----|-----|-----|-----|------------|-----|----|-------|-------------------|
| HD mode | DCR4-400C | E | 445 | 385 | 145 | 117 | 213 | M10(12*22) | 245 | - | 4*M12 | 52 |
| MD mode | DCR4-450C | | 440 | 385 | 150 | 122 | 215 | M10(12*22) | 245 | - | 4*M12 | 62 |
| LD mode | DCR4-500C | | 445 | 390 | 165 | 137 | 220 | M10(12*22) | 245 | - | 4*M12 | 72 |

Note: A box (□) replaces an alphabetic letter depending on the shipping destination.

(Unit: mm)

■ FRN500VG1S-4□





Figure E




Figure F

| | Reactor | Figure | W | W1 | D | D1 | D2 | G | H | H1 | J | Approx. mass (kg) |
|---------|-----------|--------|-----|-----|-----|-----|-----|------------|-----|----|-------|-------------------|
| HD mode | DCR4-500C | E | 445 | 390 | 165 | 137 | 220 | M10(12*22) | 245 | - | 4*M12 | 72 |
| LD mode | DCR4-630C | F | 285 | 145 | 203 | 170 | 195 | M12(14*20) | 480 | - | 2*M12 | 75 |

■ FRN630VG1S-4□







Figure F

| | Reactor | Figure | W | W1 | D | D1 | D2 | G | H | H1 | J | Approx. mass (kg) |
|---------|-----------|--------|-----|-----|-----|-----|-----|------------|-----|----|-------|-------------------|
| HD mode | DCR4-630C | F | 285 | 145 | 203 | 170 | 195 | M12(14*20) | 480 | - | 2*M12 | 75 |
| LD mode | DCR4-710C | | 340 | 160 | 295 | 255 | 225 | M12(φ15) | 480 | - | 4*M12 | 95 |


Note: A box (□) replaces an alphabetic letter depending on the shipping destination.

2.3.2 Keypad

(Unit: mm)



* If the thickness of the panel is outside the range specified here, use screws of an appropriate length.



Dimensions of panel cutting (viewed from A)

2.4 Dedicated Motor Specifications

2.4.1 Induction motor (IM) with speed sensor

• Standard specifications for three-phase 200 V series

| Item | Specifications | | | | | | | | | | | | | | | | |
|---|------------------------|--|-------------------|-------|-------|-------|-----------|-------------------|-------|------------------|-------|-------|-------------|-----------------------------|--------------|-------|--|
| Dedicated motor rated output (kW) | 0.75 | 1.5 | 2.2 | 3.7 | 5.5 | 7.5 | 11 | 15 | 18.5 | 22 | 30 | 37 | 45 | 55 | 75 | 90 | |
| Applicable motor type (MVK ₁) | 8095A | 8097A | 8107A | 8115A | 8133A | 8135A | 8165A | 8167A | 8184A | 8185A | 8187A | 8207A | 8208A | 9224A | 9254A | 9256A | |
| Moment of inertia of rotor (kg•m ²) | 0.009 | 0.009 | 0.009 | 0.016 | 0.030 | 0.037 | 0.085 | 0.11 | 0.21 | 0.23 | 0.34 | 0.41 | 0.47 | 0.53 | 0.88 | 1.03 | |
| Rotor GD ² (kg•m ²) | 0.036 | 0.036 | 0.036 | 0.065 | 0.12 | 0.15 | 0.34 | 0.47 | 0.83 | 0.92 | 1.34 | 1.65 | 1.87 | 2.12 | 3.52 | 4.12 | |
| Rated speed/ Max. speed (r/min) | 1500/3600 | | | | | | 1500/3000 | | | | | | 1500/2400 | | 1500/2000 | | |
| Vibration | V10 or less | | | | | | | | | | | | V15 or less | | | | |
| Cooling fan | Voltage (V) | 200 to 210 V/50 Hz, 200 to 230 V/60 Hz | | | | | | | | | | | | 200/50 Hz, 200, 220 V/60 Hz | | | |
| | Number of phases/poles | - | Single-phase, 4P | | | | | Three-phase, 4P | | | | | | | | | |
| | Input power (W) | - | 40/50 | | | | | 90/120 | | 150/210 | | | | 80/120 | 270/390 | | |
| | Current (A) | - | 0.29/0.27 to 0.31 | | | | | 0.49/0.44 to 0.48 | | 0.75/0.77 to 0.8 | | | | 0.76/0.8, 0.8 | 1.9/2.0, 2.0 | | |
| Approx. mass (kg) | 28 | 29 | 32 | 46 | 63 | 73 | 111 | 133 | 190 | 197 | 235 | 280 | 296 | 380 | 510 | 570 | |

• Standard specifications for three-phase 400 V series

| Item | Specifications | | | | | | | | | | | | | | | | | | |
|---|------------------------|--|-------|-------|--|-------|-----------|------------------|-------|-------------|-------------------------------|-------|--------------|-------|---|--------------|-------|--------------|--|
| Dedicated motor rated output (kW) | 3.7 | 5.5 | 7.5 | 11 | 15 | 18.5 | 22 | 30 | 37 | 45 | 55 | 75 | 90 | 110 | 132 | 160 | 200 | 220 | |
| Applicable motor type (MVK_) | 8115A | 8133A | 8135A | 8165A | 8167A | 8184A | 8185A | 8187A | 8207A | 8208A | 9224A | 9254A | 9256A | 9284A | 9286A | 528KA | 528LA | 531FA | |
| Moment of inertia of rotor (kg•m ²) | 0.016 | 0.030 | 0.037 | 0.085 | 0.11 | 0.21 | 0.23 | 0.34 | 0.41 | 0.47 | 0.53 | 0.88 | 1.03 | 1.54 | 1.77 | 1.72 | 1.83 | 2.33 | |
| Rotor GD ² (kg•m ²) | 0.065 | 0.12 | 0.15 | 0.34 | 0.47 | 0.83 | 0.92 | 1.34 | 1.65 | 1.87 | 2.12 | 3.52 | 4.12 | 6.16 | 7.08 | 6.88 | 7.32 | 9.32 | |
| Rated speed / Max. speed (r/min) | 1500/3600 | | | | | | 1500/3000 | | | 1500/2400 | | | 1500/2000 | | | | | | |
| Vibration | V10 or less | | | | | | | | | V15 or less | | | | | | | | | |
| Cooling fan | Voltage (V) | 200 to 210 V/50 Hz, 200 to 230 V/60 Hz | | | 400 to 420 V/50 Hz, 400 to 440 V/60 Hz | | | | | | 400 V/50 Hz, 400, 440 V/60 Hz | | | | 380, 400, 415 V/50 Hz, 400, 440 V/60 Hz | | | | |
| | Number of phases/poles | Single-phase, 4P | | | Three-phase, 4P | | | | | | | | | | | | | | |
| | Input power (W) | 40/50 | | | 90/120 | | | 150/210 | | | 80/120 | | 270/390 | | | 2200 | | 3700 | |
| | Current (A) | 0.29/0.27 to 0.31 | | | 0.27/0.24 to 0.25 | | | 0.38/0.39 to 0.4 | | | 0.39/0.4, 0.4 | | 1.0/1.0, 1.0 | | | 4.6/4.3, 4.1 | | 7.8/7.1, 7.6 | |
| Approx. mass (kg) | 46 | 63 | 73 | 111 | 133 | 190 | 197 | 235 | 280 | 296 | 380 | 510 | 570 | 710 | 760 | 1270 | 1310 | 1630 | |

| Item | Specifications | | | | | |
|---|------------------------|-------------------------------|-------|-------|-------|-------|
| Dedicated motor rated output (kW) | 250 | 280 | 300 | 315 | 355 | 400 |
| Applicable motor type (MVK_) | 531GA | 531HA | 535GA | 535GA | 535HA | 535JA |
| Moment of inertia of rotor (kg•m ²) | 2.52 | 2.76 | 5.99 | 5.99 | 6.53 | 7.18 |
| Rotor GD ² (kg•m ²) | 10.08 | 12.34 | 23.96 | 23.96 | 26.12 | 28.72 |
| Rated speed / Max. speed (r/min) | 1500/2000 | | | | | |
| Vibration | V15 or less | | | | | |
| Cooling fan | Voltage (V) | 400 V/50 Hz, 400, 440 V/60 Hz | | | | |
| | Number of phases/poles | Three-phase, 4P | | | | |
| | Input power (W) | 3700 | | | | |
| | Current (A) | 7.8/7.1, 7.6 | | | | |
| Approx. mass (kg) | 1685 | 1745 | 2230 | 2230 | 2310 | 2420 |

● **Common specifications**


| Item | Specifications |
|---|---|
| Insulation class, Number of poles | Class F, 4P |
| Terminal structure | Main terminal box (lug type): Three or six main circuit terminals, Two NTC thermistor terminals (MVK8 series), Three NTC thermistor terminals (MVK9 or MVK5 series. One terminal is reserved.) Auxiliary terminal box (terminal block): Pulse generator (PGP, PGM, PA, PB, SS), cooling fan (FU, FV or FU, FV, FW) |
| Mounting method | Foot mounted with bracket (IMB3), Note: Contact your Fuji Electric representative for other mounting. |
| Degree of protection, Cooling method | IP44, Totally enclosed forced-ventilation system with cooling fan motor. A cooling fan blows air over the motor toward the drive-end. *Only MVK8095A (0.75 kW): Self-cooling |
| Installation location | Indoors, 1000 m or less in altitude. |
| Ambient temperature, humidity | -10 to +40°C, 90% RH or less (no condensation) |
| Finishing color | Munsell N5 |
| Standard conformity | MVK8 series: JEM1466 or JEC-2137-2000 MVK9 or MVK5 series: JEC-2137-2000 |
| Standard accessories | Pulse generator (1024 P/R, +15V, complementary output), NTC thermistor(s) (1 or 2), and cooling fan (except MVK8095A) |

Note 1: For applicable motors of 55 kW or above, the torque accuracy is $\pm 5\%$. When higher accuracy is required, contact your Fuji Electric representative.


Note 2: For dedicated motors other than 4-pole ones with the base speed of 1500 r/min, contact your Fuji Electric representative.

• External dimensions of dedicated motors


• Figure A




• Figure B




Shaft extension




• Figure C



• Figure D



• Figure E



• Dimensions common to 200V and 400V series

| Motor rated output (kW) | Motor type | Fig. | Dimensions (mm) | | | | | | | | | | | | | | | | | Shaft extension (mm) | | | | | | Approx. mass (kg) | | | | | | | | | | | | | | | | | | | | | | | | | | | |
|-------------------------|------------|------|-----------------|-------|-----|-----|-------|-------|------|------|------|-----|----|-------|------|-------|------|-------|-------|----------------------|------|-------|------|------|------|-------------------|------|------|-----|----|-------|----|------|-----|-----|-------|-----|-------|-------|-----|--|--|-----|------|---|-----|----|-----|-----|--|--|--|------|
| | | | A | C | D | E | F | G | I | J | K | K1 | K2 | KD | KL | L | M | N | R | XB | Z | Q | QR | S | T | | U | W | | | | | | | | | | | | | | | | | | | | | | | | | |
| 0.75 | MVK8095A | A | 201.5 | 90 | 204 | 70 | 62.5 | 10 | 195 | 35.5 | 35.5 | | | 27 | 189 | 370 | 170 | 150 | 168.5 | 56 | 10 | 50 | 0.5 | 24j6 | 7 | 4 | 8 | 28 | | | | | | | | | | | | | | | | | | | | | | | | | |
| 1.5 | MVK8097A | | 277.5 | | | | | | | | | | | | 27 | 189 | 446 | | | | | | | | | | | | | | | | | 29 | | | | | | | | | | | | | | | | | | | |
| 2.2 | MVK8107A | | 292 | 100 | 203 | 80 | | 12.5 | 238 | | 40 | 40 | | | 190 | 485 | 195 | 170 | 193 | 63 | | 60 | 12 | 28j6 | | | | 32 | | | | | | | | | | | | | | | | | | | | | | | | | |
| 3.7 | MVK8115A | | 299 | 112 | 236 | 95 | 70 | | 14 | 270 | | | | | 205 | 499 | 224 | 175 | 200 | 70 | | 80 | | | | | | | | | | | | 46 | | | | | | | | | | | | | | | | | | | |
| 5.5 | MVK8133A | B | 309 | 132 | 273 | 108 | 89 | 17 | 311 | 45 | 50 | | | 34 | 223 | 548 | 250 | 180 | 239 | 89 | 12 | 80 | | | | | | | 63 | | | | | | | | | | | | | | | | | | | | | | | | |
| 7.5 | MVK8135A | | 328 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 11 | MVK8165A | A | 400 | 160 | 321 | 127 | 105 | 18 | 376 | 50 | 63 | | | 48 | 272 | 723 | 300 | 250 | 323 | 108 | 14.5 | 110 | 1 | 42k6 | 8 | 5 | | 111 | | | | | | | | | | | | | | | | | | | | | | | | | |
| 15 | MVK8167A | | 422 | | | | | | | | | | | | | | | 127 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | 133 | | | | |
| 18.5 | MVK8184A | | 435 | | | | 180 | | | | | | | | | 376 | | 139.5 | 120.5 | | | | | | | | | 20 | 428 | 75 | 75 | | | 60 | 305 | 786.5 | 350 | 292 | 351.5 | 121 | | | 1.5 | 48k6 | 9 | 5.5 | 14 | 190 | | | | | |
| 22 | MVK8185A | | 454 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | 139.5 | | | | | | | | | | | | | | | |
| 30 | MVK8187A | | | | | | | | | | | | | | | 824.5 | 330 | 370.5 | | | | | | | | | | 235 | | | | | | | | | | | | | | | | | | | | | | | | | |
| 37 | MVK8207A | C | 490 | 200 | 411 | 159 | 152.5 | 25 | 466 | 80 | 85 | | | 80 | 364 | 915.5 | 390 | 360 | 425.5 | 133 | 18.5 | 140 | | 60m6 | 11 | 7 | 18 | 280 | | | | | | | | | | | | | | | | | | | | | | | | | |
| 45 | MVK8208A | | 55 | 723 | 225 | 445 | 178 | | | | | | | | 143 | 515 | 95 | | | | | | | | | | | | | | | | | | | | | | | | | | 296 | | | | | | | | | | |
| 75 | MVK9224A | | 75 | 693.5 | 250 | 545 | 203 | 155.5 | 30 | 743 | 100 | 120 | | | | 106 | 1157 | 506 | 411 | 463.5 | 168 | | | 2 | 75m6 | 12 | 7.5 | 20 | 380 | | | | | | | | | | | | | | | | | | | | | | | | |
| 90 | MVK9256A | | 90 | 711.5 | | | | | | | | | | | | | | | 174.5 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | 510 | | | | |
| 110 | MVK9284A | 110 | 764 | | | | | | | | | | | 184 | | | 35 | 798 | | | | | | 203 | 1308 | 557 | 468 | 544 | 190 | | | | | | | | | 570 | | | | | | | | | | | | | | | |
| 132 | MVK9286A | 132 | 789.5 | | | | | | | | | | | 209.5 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 160 | MVK528JA | E | 1015.5 | 315 | 689 | 254 | 254 | 36 | 1425 | 150 | | | | 102 | 1604 | 560 | 557 | 588.5 | 216 | 28 | 210 | 1 | 85m6 | 14 | 9 | | 760 | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 200 | MVK528LA | | | | | | | | | | | | | | | | | | | | | | | | | | 200 | | | | 228.5 | 30 | 1234 | 125 | | | | | | | | | | | | | | | | | | | 1230 |
| 220 | MVK531FA | | | | | | | | | | | | | | | | | | | | | | | | | | 220 | | | | | | | | | | | | | | | | | | | | | | | | | | 1350 |
| 250 | MVK531GA | | | | | | | | | | | | | | | | | | | | | | | | | | 250 | | | | | | | | | | | | | | | | | | | | | | | | | | 1690 |
| 280 | MVK531HA | 280 | 1073 | 315 | 689 | 254 | 254 | | 1425 | 150 | | | | | 1713 | 630 | 648 | 640 | 216 | | | | | | | | | 1750 | | | | | | | | | | | | | | | | | | | | | | | | | |
| 300 | MVK535GA | 300 | 1111 | 355 | 778 | 305 | 355 | | 1510 | 160 | | | | | | | | | | | 2 | 100m6 | 16 | 10 | 28 | | 1820 | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 315 | | | | | | | | | | | | | | | | | | | | | | | | | | | 2230 | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 355 | MVK535HA | 355 | | | | | | | | | | | | | | | | | | | | | | | | | 2310 | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 400 | MVK535JA | 400 | | | | | | | | | | | | | | | | | | | | | | | | | 2420 | | | | | | | | | | | | | | | | | | | | | | | | | | |

Note 1: The MVK8095A (0.75 kW) has a shaft-driven fan (Cooling system: IC410).

Note 2: The MVK8095A (0.75 kW) has a single cable lead-in hole of φ22.

Note 3: The MVK9224A (55 kW) has an auxiliary terminal box for fan, in addition to the configuration shown in Figure C.

Note 4: Dimensional tolerance of rotary shaft height C

C ≤ 250 mm: 0 to -0.5 mm, C > 250 mm: 0 to 1.0 mm

2.4.2 Permanent magnet synchronous motor (PMSM) with speed sensor

• Standard specifications for three-phase 200 V series

| Item | | Specifications | | | | | | | | | | | |
|---|-----------------------------|---------------------------|-------|-------|-------|---------------------------|-------|------------------------------|---------|-----------------------|---------|------------------|---------|
| Dedicated motor rated output (kW) | | 5.5 | 7.5 | 11 | 15 | 18.5 | 22 | 30 | 37 | 45 | 55 | 75 | 90 |
| Dedicated motor type (GNF_) | | 2114A | 2115A | 2117A | 2118A | 2136A | 2137A | 2139A | 2165A | 2167A | 2185A | 2187A | 2207A |
| Moment of inertia of rotor (kg•m ²) | | 0.018 | 0.021 | 0.027 | 0.036 | 0.065 | 0.070 | 0.090 | 0.153 | 0.191 | 0.350 | 0.467 | 0.805 |
| Rotor GD ² (kg•m ²) | | 0.072 | 0.084 | 0.107 | 0.143 | 0.259 | 0.281 | 0.360 | 0.610 | 0.763 | 1.401 | 1.868 | 3.220 |
| Base speed/Max. speed (r/min) | | 1500/2000 | | | | | | | | | | | |
| Rated current (A) | | 20/20 | 29/29 | 42/42 | 57/57 | 71/70 | 82/81 | 113/108 | 144/144 | 165/165 | 200/200 | 270/270 | 316/316 |
| Vibration | | V10 or less | | | | | | | | | | | |
| Cooling fan | Voltage (V), Frequency (Hz) | 200 to 240, 50/60 | | | | | | 200 to 210/50, 200 to 230/60 | | | | | |
| | Number of phases/poles | Three-phase, 2P | | | | | | Three-phase, 4P | | | | | |
| | Input power (W) | 38 to 44/56 to 58 | | | | 54 to 58/70 to 78 | | | | 90/120 | | 150/210 | |
| | Current (A) | 0.13 to 0.16/0.18 to 0.16 | | | | 0.18 to 0.18/0.22 to 0.21 | | | | 0.49/ 0.44 to 0.48 | | 0.75/0.77 to 0.8 | |
| Approx. mass (kg) | | 51 | 55 | 69 | 78 | 100 | 106 | 127 | 170 | 192 | 247 | 325 | 420 |

• Standard specifications for three-phase 400 V series

| Item | | Specifications | | | | | | | | | | | |
|---|-----------------------------|---------------------------|-------|-------|-------|---------------------------|-------|------------------------------|-------|-----------------------|---------|------------------|---------|
| Dedicated motor rated output (kW) | | 5.5 | 7.5 | 11 | 15 | 18.5 | 22 | 30 | 37 | 45 | 55 | 75 | 90 |
| Dedicated motor type (GNF_) | | 2114A | 2115A | 2117A | 2118A | 2136A | 2137A | 2139A | 2165A | 2167A | 2185A | 2187A | 2207A |
| Moment of inertia of rotor (kg•m ²) | | 0.018 | 0.021 | 0.027 | 0.036 | 0.065 | 0.070 | 0.090 | 0.153 | 0.191 | 0.350 | 0.467 | 0.805 |
| Rotor GD ² (kg•m ²) | | 0.072 | 0.084 | 0.107 | 0.143 | 0.259 | 0.281 | 0.360 | 0.610 | 0.763 | 1.401 | 1.868 | 3.220 |
| Base speed/Max. speed (r/min) | | 1500/2000 | | | | | | | | | | | |
| Rated current (A) | | 10/10 | 15/15 | 21/21 | 29/29 | 36/35 | 41/41 | 57/54 | 72/72 | 83/83 | 100/100 | 135/135 | 158/158 |
| Vibration | | V10 or less | | | | | | | | | | | |
| Cooling fan | Voltage (V), Frequency (Hz) | 200 to 240, 50/60 | | | | | | 400 to 420/50, 400 to 440/60 | | | | | |
| | Number of phases/poles | Three-phase, 2P | | | | | | Three-phase, 4P | | | | | |
| | Input power (W) | 38 to 44/56 to 58 | | | | 54 to 58/70 to 78 | | | | 90/120 | | 150/210 | |
| | Current (A) | 0.13 to 0.16/0.18 to 0.16 | | | | 0.18 to 0.18/0.22 to 0.21 | | | | 0.27/ 0.24 to 0.25 | | 0.38/0.39 to 0.4 | |
| Approx. mass (kg) | | 51 | 55 | 69 | 78 | 100 | 106 | 127 | 170 | 192 | 247 | 325 | 420 |


| Item | | Specifications | | | | | | | |
|---|------------------------|-------------------------------------|-------|--------------------------|-------|-------|-----|-------|-----|
| Dedicated motor rated output (kW) | | 110 | 132 | 160 | 200 | 220 | 250 | 280 | 300 |
| Dedicated motor type (GNF_) | | 2224B | 2226B | 2254B | 2256B | 2284B | | 2286B | |
| Moment of inertia of rotor (kg•m ²) | | 0.882 | 0.994 | 1.96 | 2.22 | 2.89 | | 3.24 | |
| Rotor GD ² (kg•m ²) | | 3.53 | 3.98 | 7.84 | 8.88 | 11.6 | | 13.0 | |
| Base speed/Max. speed (r/min) | | 1500/2000 | | | | | | | |
| Rated current (A) | | 198 | 232 | 273 | 340 | 369 | 420 | 480 | 520 |
| Vibration | | V10 or less | | | | | | | |
| Cooling fan | Voltage (V) | 380, 400, 415/400, 415, 440, 460 | | | | | | | |
| | Number of phases/poles | Three-phase, 4P | | | | | | | |
| | Power frequency (Hz) | 50/60 | | | | | | | |
| | Input power (W) | 80/120 | | 270/390 | | | | | |
| | Current (A) | 0.36, 0.38, 0.41/0.4, 0.4, 0.4, 0.4 | | 0.95, 0.95, 1/1, 1, 1, 1 | | | | | |
| Approx. mass (kg) | | 520 | 580 | 760 | 810 | 1020 | | 1080 | |

• Common specifications


| Item | Specifications |
|---|--|
| Insulation class, Number of poles | Class F, 6P |
| Terminal structure | Main terminal box (lug type): Three or six main circuit terminals, Two NTC thermistor terminals (Three for 110 kW or above. One terminal is reserved.) |
| | Auxiliary terminal box (terminal block): Cooling fan (FU, FV, FW) |
| Rotation direction | CCW when viewed from the drive side |
| Mounting method | Legs mounted (IMB3) Note: Contact your Fuji Electric representative for other mounting. |
| Overload resistance | 150% for 1 minute |
| Time rating | S1 |
| Degree of protection, Cooling method | IP44, Totally enclosed forced-ventilation system with cooling fan motor. A cooling fan blows air over the motor toward the drive-end. |
| Installation location | Indoors, 1000 m or less in altitude. |
| Ambient temperature, humidity | -10 to +40°C, 90% RH or less (no condensation) |
| Noise | 5.5 to 90 kW: 80 dB (A) or less at 1 m, 110 to 300 kW: 90 dB(A) or less at 1 m |
| Vibration resistance | 6.86 m/s ² (0.7 G) |
| Finishing color | Munsell N1.2 |
| Standard conformity | JEM1487: 2005 |
| Standard built-in parts | Pulse generator (1024 P/R, +5VDC, A, B, Z, U, V, W line driver output), One NTC thermistor (Two for 110 kW or above) and Cooling fan |

● External dimensions of dedicated motors


Shaft extension




● Figure A




● Figure B




● Figure C




● Figure D



● Figure E



● Figure F



● Dimensions common to 200V and 400V series


| Motor rated output (kW) | Motor type | Flame no. | Fig. | Dimensions (mm) | | | | | | | | | | | | | | | | Shaft extension (mm) | | | | | | Approx. mass (kg) | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
|-------------------------|------------|-----------|------|-----------------|-----|------------|-------|-------|----|-----|-----|-----|-----|--------|--------|-------|-------|-------|-----|----------------------|----|------|------|------|-----|-------------------|----|---|--|--|-----|------|-----|--|--|--|--|--|--|--|--|--|--|--|--|--|--|--|--|--|--|--|--|--|--|--|--|--|--|--|------|
| | | | | A | C | D | E | F | G | I | J | K | KD | KL | L | M | N | R | XB | Z | Q | QR | S | T | U | | W | Y | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 5.5 | GNF2114A | 112Mh | A | 335.5 | | | | 70 | 14 | | 40 | | 34 | 200 | 555.5 | 224 | 175 | 220 | 70 | 12 | 80 | 0.5 | 38k6 | | | | | | | | 51 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 7.5 | GNF2115A | | | 112 | 235 | 95 | | | | | 270 | | | | | | | | | | | | | | | | | | | | | 55 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 11 | GNF2117A | 112Jh | | 380.5 | | | | 100 | 18 | | | 55 | | 235 | 698.5 | 228 | | | 318 | | | | 1 | 42k6 | | 8 | 5 | | | | | 69 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 15 | GNF2118A | | | | | | | | | | | | 50 | 48 | | | | | | | | | | | | | | | | | | 78 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 18.5 | GNF2136A | 132Lh | A | 386 | | | 101.5 | | | 311 | 45 | | 247 | 705.5 | 250 | | | 319.5 | | | | 1.5 | 48k6 | 9 | 5.5 | 14 | | | | | 100 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 22 | GNF2137A | | | 424.5 | 132 | 272 | 108 | 140 | 20 | | | | 60 | 782.5 | | 313 | 358 | | | | | | | 55m6 | 10 | 6 | 16 | | | | 106 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 30 | GNF2139A | 132Hh | B | 470.5 | | | 127 | | | 376 | 75 | 75 | 320 | 845.5 | 350 | 300 | 375 | | | | | | | | | | | | | | | 170 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 45 | GNF2167A | 160Jg | | 501 | 160 | 319 | 139.5 | 157.5 | | | | | | 906.5 | 370 | 405.5 | | | | | | 18.5 | | 60m6 | 11 | 7 | 18 | | | | 192 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 55 | GNF2185A | 180Lg | C | 510 | | | 139.5 | | | 428 | 80 | 85 | 356 | 910.5 | 390 | 330 | 400.5 | 121 | | | | 2 | 65m6 | | | | | | | | | 247 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 75 | GNF2187A | 180Jg | | 576 | 180 | 375 | 159 | 177.5 | 25 | | | | | 1061.5 | 420 | 450 | 485.5 | | | | | | | | | | | | | | | 325 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 90 | GNF2207A | 200Jg | D | 618.5 | 200 | 410 | 178 | | | 549 | | | 80 | 107 | 1126.5 | 450 | 479 | 508 | | | | | | | | | | | | | | 420 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 110 | GNF2224B | 225Kg | | 711 | 225 | 446 | 203 | 200 | 28 | 628 | 100 | | | 142 | 1249 | 506 | 526 | 538 | | | | | | | | | | | | | | | 520 | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 132 | GNF2226B | 225Hg | | 761 | | | 250 | | | | | | | 1349 | | 626 | 588 | | | | | | | 85m6 | | | | | | | | 580 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 160 | GNF2254B | 250Hg | E | 829 | 250 | 508 505 | 228.5 | | 32 | 763 | | 120 | 203 | 1469 | 557 | 677 | | | | | | | | | | | | | | | | 760 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 200 | GNF2256B | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | 810 |
| 220 | GNF2284B | 280Jf | F | 881 | 280 | 570 | 254 | 280 | 35 | 878 | 120 | | 102 | 303 | 1521 | 628 | 680 | 640 | 190 | | | | | 95m6 | | | | | | | | 1020 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 250 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | 1020 |
| 280 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 300 | GNF2286B | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | 1080 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |

Note 1: Models of 110 kW output or above are exclusive to direct connection. For indirect connection, contact your Fuji Electric representative.

Note 2: Dimensional tolerance of rotary shaft height C
 C ≤ 250 mm: 0 to -0.5 mm, C > 250 mm: 0 to 1.0 mm





• Cables exclusive to inverter connection

| Name | | Specifications | | |
|---|--------------------------------|----------------------------------|----------------------------|---|
| Cable type | Wiring length (L dimension) | Plug shape at the motor side | | Remarks |
| | | Straight plug | Right angle plug | |
| | 5 m | CB-VG1-PMPG-05S | CB-VG1-PMPG-05A | |
| | 15 m | CB-VG1-PMPG-15S | CB-VG1-PMPG-15A | |
| | 30 m | CB-VG1-PMPG-30S | CB-VG1-PMPG-30A | |
| | 50 m | CB-VG1-PMPG-50S | CB-VG1-PMPG-50A | |
| Cable structure | <p><u>Straight plug</u></p> | | | |
| | <p><u>Right angle plug</u></p> | | | |
| Wiring table and pin assignment | • Wiring | | | • Pin assignment |
| | Connector # at the motor side | Connector # at the inverter side | Function | At the motor side |
| | 1 | 9 or 20 | Power +5V | <p>Viewed from P in the above figure</p> |
| | 2 | 10 or 19 | 0V common | |
| | 3 | 3 | A phase | |
| | 4 | 2 | A phase reversed | |
| | 5 | 5 | B phase | |
| | 6 | 4 | B phase reversed | |
| | 7 | - | Z phase (*1) | |
| | 8 | - | Z phase reversed (*1) | |
| | 9 | 8 | Magnetic pole position F0 | <p>OPC-VG1-PMPG connector</p> <p>Inside the connector</p> |
| | 10 | 7 | Magnetic pole position *F0 | |
| | 11 | 13 | Magnetic pole position F1 | |
| | 12 | 12 | Magnetic pole position *F1 | |
| | 13 | 15 | Magnetic pole position F2 | |
| 14 | 14 | Magnetic pole position *F2 | | |
| 15 | - | Shield layer | | |
| (*1) For the PG card (OPC-VG1-PMPG), no Z phase or Z phase reversed are required. | | | | |



● Reference: Connectors and contact terminals recommended

The following specifications are recommended for customers who produce inverter connection cables.

| | |
|--|--|
| <p>At the inverter side: Connector (10320-52F0-008) Sumitomo 3M Co., Ltd.</p> | <p>At the motor side: Connector contact terminal (JN1-22-22F-PKG100) Japan Aviation Electronics Industry, Limited</p> |
|  |  <p>Max. applicable wire size: AWG20 (Outer dia. of coated cable: φ1.5 mm or less)</p> |
| <p>At the motor side: Straight plug connector (JN2DW15SL) Japan Aviation Electronics Industry, Limited</p> | <p>At the motor side: Angle plug connector (JN2FW15SL1) Japan Aviation Electronics Industry, Limited</p> |
|  |  |

Note 1: The following specifications are recommended for PG shield layers.

| | |
|----------------------------|---|
| Type | Braided, shielded wires (Twisted-pair cable (Outer dia.: Approx. φ10)) |
| Number of cores | 14 or more |
| Dia. of lead | 0.2 to 0.3 mm ² |
| Outer dia. of coated cable | Max. φ1.5 mm |

Note 2: The PKG in contact terminal models denotes that 100 terminals are packed in bulk.


Note 3: Joint with contact terminals should be presoldered.

2.5 Protective Functions

The table below lists the name of the protective functions, description, alarm codes on the LED monitor, and presence of alarm output at terminals [30A/B/C]. If an alarm code appears on the LED monitor, remove the cause of activation of the alarm function referring to Chapter 13 "TROUBLESHOOTING."


| Name | Description | LED monitor displays | Related function code |
|--------------------------------------|--|----------------------|---|
| Braking transistor broken | If a breakdown of the braking transistor is detected, this protective function stops the inverter output. (For models of 55 kW or below in 200 V class series and 160 kW or below in 400 V class series) If this alarm is detected, be sure to shut down the power on the primary side of the inverter. | <i>oB A</i> | H103 |
| Braking resistor overheated | This function estimates the temperature of the braking resistor and stops the inverter output if the temperature exceeds the allowable value. It is necessary to configure Function codes E35 to E37 depending on the resistor (integrated or externally mounted). | <i>oB H</i> | E35 to E37 |
| DC fuse blown | If a fuse in the main DC circuit blows due to a short circuit in the IGBT circuit, this protective function displays the error to prevent the secondary damage. The inverter could be broken, so immediately contact your Fuji Electric representative. (For models of 75 kW or above in 200 V class series and 90 kW or above in 400 V class series) | <i>oC F</i> | |
| Excessive positioning deviation | This function is activated when the positioning deviation between the command and the detected values exceeds "Setting of function code o18 (Excessive deviation value) x 10" in synchronous operation. | <i>oD</i> | o18 |
| PG communications error | This function is activated if a PG communication error occurs when the 17-bit high resolution ABS interface (OPC-VG1-SPGT) is used. | <i>EE</i> | |
| Functional safety circuit failure *1 | This function is activated when the input to either one of EN1 and EN2 is OFF for the duration exceeding 50 ms (which is regarded as a mismatch). The alarm state can be reset only by restarting the inverter. | <i>EEF</i> | |
| Ground fault | This function is activated when a ground fault is detected in the inverter output circuit. If the ground-fault current is large, the overcurrent protection may be activated. This protective function is to protect the inverter. For the sake of prevention of accidents such as human damage and fire, connect a separate earth-leakage protective relay or an earth-leakage circuit breaker (ELCB). | <i>EF</i> | H103 |
| Memory error | This function is activated when a memory error such as a data write error occurs. Note: The inverter memory has a limited number of rewritable times (100,000 to 1,000,000 times). Saving data with the Save All function into the memory so many times will no longer allow the memory to save data, causing a memory error. | <i>Er-1</i> | |
| Keypad communications error | This function is activated if a communications error occurs between the keypad and the inverter control circuit when the start/stop command given from the keypad is valid (Function code F02=0). Note: Even if a keypad communications error occurs when the inverter is being driven via the control circuit terminals or the communications link, the inverter continues running without displaying any alarm or issuing an alarm output (for any alarm). | <i>Er-2</i> | F02 |
| CPU error | This function is activated if a CPU error occurs. | <i>Er-3</i> | |
| Network error | This function is activated: - if a communications error occurs due to noise when the inverter is being driven via the T-Link, SX-bus, E-SX bus, CC-Link or Field bus. | <i>Er-4</i> | o30, o31, H107 E01 to E14 E15 to E28 |

*1 Available in the ROM version H1/2 0020 or later.



| Name | Description | LED monitor displays | Related function code |
|--|---|----------------------|-----------------------------|
| RS-485 communications error | This function is activated if an RS-485 communications error occurs and is kept for the duration (0.1 to 60.0 sec.) specified by H38 when the inverter is being driven via the RS-485 interface and Function code H32 is set to any of "0" through "2." | <i>Er-5</i> | H32, H33, H38 H107 |
| Operation error | This function is activated if: 1) Two or more network options are mounted, 2) The SW configuration is the same on two or more PG options (More than one PG option can be mounted.), 3) Auto tuning (Function code H01) is attempted when any of the digital input signals BX , STOP1 , STOP2 and STOP3 is ON, or 4) Auto tuning is selected with Function code H01 but the  key on the keypad is not pressed within 20 seconds. | <i>Er-6</i> | H01 |
| Output wiring fault | This function is activated if the wires in the inverter output circuit are not connected during auto-tuning. | <i>Er-7</i> | H01 |
| A/D converter error | This function is activated if an error occurs in the A/D converter circuit. | <i>Er-8</i> | |
| Speed not agreed | This function is activated if the deviation between the speed command (reference speed) and the motor speed (detected or estimated speed) becomes excessive. The detection level and detection time can be specified with function codes. | <i>Er-9</i> | E43, E44, E45 H108, H149 |
| UPAC error *1 | This function is activated if the UPAC option causes a hardware failure or a communications error in communication with the inverter controller, or the backup battery runs out. | <i>Er-A</i> | |
| Inter-inverter communications link error | This function is activated if a communications error occurs in the inverter-to-inverter communications link using a high-speed serial communication terminal block (option). | <i>Er-b</i> | |
| Hardware error | This function is activated upon detection of an LSI failure on the printed circuit board. | <i>Er-H</i> | |
| Mock alarm | This can be caused with an external signal input (FTB), keypad operation or FRENIC-VG Loader. | <i>Er-r</i> | E01 to E14 H108, H142 |
| PG failure | This function is activated if a PG data error or PG failure is detected when the 17-bit serial PG (OPC-VG1-SPGT) is used. | <i>Et-1</i> | |
| Input phase loss | This function protects the inverter when an input phase loss is detected. If the connected load is light or a DC reactor is connected to the inverter, this function may not detect input phase loss if any. | <i>L 17</i> | E45 |
| Start delay | This function is activated when the reference torque current exceeds the start delay detection level (H140) and the detected or estimated speed drops below the stop speed (F37) and then the low-speed state is kept for the specified duration (H141). The detection level and detection timer can be specified with function codes. | <i>LdL</i> | H108, H140, H141 |
| Undervoltage | This function is activated when the DC link bus voltage drops below the undervoltage detection level (180 VDC for 200 V series, 360 VDC for 400 V series). Note that, if the restart mode after momentary power failure is selected (F14 = 3, 4 or 5), no alarm is output even if the DC link bus voltage drops. | <i>LL</i> | F14 |
| NTC wire break error | This function is activated if the thermistor wire breaks when the NTC thermistor is selected with Function code P30/A31/A131 for motor M1/M2/M3. This function works even at extremely low temperatures (approx. -30°C or below). | <i>nr-b</i> | P30, A31, A131 H106 |
| Overcurrent | This function stops the inverter output if the output current to the motor exceeds the overcurrent level of the inverter. When the inverter is driving a PMSM, this function is activated if the output current to the motor exceeds the overcurrent protection level (P44, A64, A164). | <i>OL</i> | P44, A64, A164 |

*1 Available in the ROM version H1/2 0020 or later.

| Name | Description | LED monitor displays | Related function code |
|----------------------------|---|----------------------|------------------------|
| Heat sink overheat | This function is activated if the temperature surrounding the heat sink (that cools down the rectifier diodes and the IGBTs) increases due to stopped cooling fans. | <i>OH1</i> | |
| External alarm | Assigning THR ("Enable external alarm trip") to a digital input terminal and operating the contact stops the inverter as an alarm. Connecting an alarm signal of external equipment such as a braking unit or braking resistor to the input terminal (to which the THR is assigned) operates the inverter according to the contact signal status. | <i>OH2</i> | E01 to E14, H106 |
| Inverter internal overheat | This function is activated if the temperature surrounding the control printed circuit board increases due to poor ventilation inside the inverter. | <i>OH3</i> | |
| Motor overheat | This function is activated if the temperature detected by the NTC thermistor of a dedicated motor exceeds the motor overheat protection level (E30). | <i>OH4</i> | E30, H106 |
| Motor 1 overload | This function is activated by the electronic thermal overload protection if the motor 1 current (inverter output current) exceeds the operation level specified by Function code F11. | <i>OL1</i> | F11, H106 |
| Motor 2 overload | This function is activated by the electronic thermal overload protection if the motor 2 current (inverter output current) exceeds the operation level specified by Function code A33. | <i>OL2</i> | A33, H106 |
| Motor 3 overload | This function is activated by the electronic thermal overload protection if the motor 3 current (inverter output current) exceeds the operation level specified by Function code A133. | <i>OL3</i> | A133, H106 |
| Inverter overload | This function is activated if the output current exceeds the overload characteristic of the inverse time characteristic. It stops the inverter output depending upon the heat sink temperature and switching element temperature calculated from the output current. | <i>OLU</i> | F80 |
| Output phase loss | This function detects a break in inverter output wiring during running and stops the inverter output. (Available under vector control for IM with speed sensor.) | <i>OPL</i> | H103, P01 A01, A101 |
| Overspeed | This function stops the inverter output if the detected speed is 120% or over of the maximum frequency. This function is activated if the motor speed (detected or estimated speed) exceeds 120% (adjustable with Function code H90) of the maximum speed (F03, A06, A106). | <i>OS</i> | H90 |
| Overvoltage | This function is activated if the DC link bus voltage exceeds the overvoltage detection level (405 VDC for 200 V series, 820 VDC for 400 V series) due to an increase of supply voltage or regenerative braking current from the motor. Note that this function cannot protect the inverter if an excessive power (high voltage, for example) is connected mistakenly. | <i>OU</i> | |
| PG wire break | This function is activated if a wire breaks in the PA/PB signal lines or PGP/PGM power lines on the PG interface. It does not work under vector control without speed sensor or under V/f control. When the PG interface card (OPC-VG1-PG, OPC-VG1-PMPG) is used, this function is activated by a wire break in PG signal lines or wrong wiring. | <i>PG</i> | H104 |
| Charger circuit fault | This function is activated if the bypass circuit of the DC link bus is not configured (that is, the magnetic contactor for bypass of the charging circuit is not closed) even after the main power is applied. (For models of 37 kW or above in 200 V class series and 75 kW or above in 400 V class series) | <i>PLF</i> | |
| DC fan locked | This function is activated if the DC fan is stopped. (For models of 45 kW or above in 200 V class series and 75 kW or above in 400 V class series) | <i>DFL</i> | H108 |

| Name | Description | LED monitor displays | Related function code |
|-------------------------------------|---|--|-----------------------|
| E-SX bus tact synchronization error | This error occurs when the E-SX tact and inverter control cycle are out of synchronization with each other. | $\overline{Pr-E}$ | H108 |
| Toggle abnormality error | The inverter monitors 2-bit signals of toggle signal 1 TGL1 and toggle signal 2 TGL2 which are sent from the PLC. When the inverter receives no prescribed change pattern within the time specified by H144, this error occurs. | $\overline{Pr-F}$ | H107 |
| Functional safety card error *1 | Protective function for the functional safety card.  For details, refer to the Functional Safety Card instruction manual (INR-SI47-1541). | $\overline{S_i-F}$ $\overline{S_r-F}$ | |
| Light alarm (warning) | If an alarm or warning preset as a light alarm occurs, this function displays $\overline{L-FL}$ on the LED monitor. It also outputs the L-ALM signal onto the Y terminal (transistor output) if the signal is assigned to the terminal beforehand. Note that this function does not issue an alarm relay output ([30A], [30B], [30C]), so the inverter continues to run. <u>Light alarm objects (selectable)</u> Motor overheat (\overline{OH}), Motor overload (\overline{OL} to $\overline{OL3}$), NTC wire break error ($\overline{rr-b}$), External failure ($\overline{H-L}$), RS-485 communications error ($\overline{Er-5}$), Network error ($\overline{Er-4}$), Toggle abnormality error ($\overline{Pr-F}$), Mock alarm ($\overline{Er-r}$), DC fan locked (\overline{dFF}), Speed mismatch ($\overline{Er-9}$), E-SX bus tact synchronization error ($\overline{Pr-E}$), Motor overheat early warning (\overline{rLOH}), Motor overload early warning (\overline{rLOL}), Lifetime alarm ($\overline{L-iF}$), Heat sink overheat early warning (\overline{LOH}), Inverter overload early warning (\overline{LOL}), Battery life expired (\overline{bF}), Start delay ($\overline{L-dL}$) | $\overline{L-FL}$ | H106 to H111 |
| Surge protection | This function protects the inverter against surge voltages which might appear between one of the power lines, using surge absorbers connected to the main circuit power terminals (L1/R, L2/S, L3/T) and control power terminals (R0, T0). | - | |
| Main power shut down | This function monitors the AC input power to the inverter and judges whether the AC input power (main power) is established. When the main power is not established, whether to run the inverter or not can be selected. (When the power is supplied via a PWM converter or the DC link bus, there is no AC input. In this case, do not change the data of Function code H76 from the default (H76 = 0). | - | H76 |


*1 Available in the ROM version H1/2 0020 or later.

-  **Note**
- All protective functions are automatically reset if the control power voltage decreases until the inverter control circuit no longer operates.
 - The inverter retains the latest and the last 10 alarm codes and the latest and the last three pieces of alarm information..
 - Stoppage due to a protective function can be reset by the  key on the keypad or turning OFF and then ON between the X terminal (to which **RST** is assigned) and the CM. This action is invalid if the cause of an alarm is not removed.
 - The inverter cannot reset until the causes of all alarms are removed. (The causes of alarms not removed can be checked on the keypad.).

2.6 Connection Diagrams and Terminal Functions


2.6.1 Connection diagrams

2.6.1.1 Running the MVK type of an induction motor (dedicated motor)



- (Note 1) Install a recommended molded case circuit breaker (MCCB) or residual-current-operated protective device (RCD)/earth leakage circuit breaker (ELCB) (with overcurrent protection function) in the primary circuit of the inverter to protect wiring. Ensure that the circuit breaker capacity is equivalent to or lower than the recommended capacity.
- (Note 2) Install a magnetic contactor (MC) for each inverter to separate the inverter from the power supply, apart from the MCCB or RCD/ELCB, when necessary.
Connect a surge absorber in parallel when installing a coil such as the MC or solenoid near the inverter.
- (Note 3) To retain an alarm output signal **ALM** issued on inverter's programmable output terminals by the protective function or to keep the keypad alive even if the main power has shut down, connect these terminals to the power supply lines. Without power supply to these terminals, the inverter can run.
- (Note 4) Normally no need to be connected. Use these terminals when the inverter is equipped with a high power-factor, regenerative PWM converter (RHC series).
- (Note 5) When connecting an optional DC reactor (DCR), remove the jumper bar from the main circuit terminals P1 and P(+). Inverters of 75 kW or above and LD-mode inverters of 55 kW come with a DCR as standard. Be sure to connect the DCR.
Use a DCR when the capacity of the power supply transformer exceeds 500 kVA and is 10 times or more the inverter rated capacity, or when there are thyristor-driven loads in the same power supply line.
- (Note 6) Inverters of 55 kW or below (200 V class series) and those of 160 kW or below (400 V class series) have a built-in braking transistor, allowing a braking resistor (DBR) to be directly connected between terminals P(+) and DB.
- (Note 7) When connecting an optional braking resistor (DBR) to inverters of 75 kW or above (200 V class series) or those of 200 kW or above (400 V class series), be sure to use an optional braking unit (BU) together.
Connect the BU between terminals P(+) and N(-). Auxiliary terminals [1] and [2] have polarity, so make connection as shown in the connection diagram.
- (Note 8) A grounding terminal for a motor. It is recommended that the motor be grounded via this terminal for suppressing inverter noise.
- (Note 9) For wiring enclosed with $\frac{\square}{\square}$, use twisted or shielded wires.
In principle, the shielded sheath of wires should be connected to ground. If the inverter is significantly affected by external induction noise, however, connection to $\textcircled{0V}$ ([M], [11], [THC]) or $\textcircled{0V}$ ([CM], (PGM)) may be effective to suppress the influence of noise.
Keep the control circuit wiring away from the main circuit wiring as far as possible (recommended: 10 cm or more). Never install them in the same wire duct. When crossing the control circuit wiring with the main circuit wiring, set them at right angles.
- (Note 10) The connection diagram shows factory default functions assigned to digital input terminals [X1] to [X9], transistor output terminals [Y1] to [Y4], and relay contact output terminals [Y5A/C].
- (Note 11) Switching connectors in the main circuits. For details, refer to Chapter 3, Section 3.3.3.7 "Switching connectors."
- (Note 12) Slide switches on the control printed circuit board (control PCB). Use these switches to customize the inverter operations. For details, refer to Chapter 3, Section 3.3.3.9 "Setting up the slide switches."
- (Note 13) The cooling fan power supply for motors of 7.5 kW or less is single-phase. Connect terminals [FU] and [FV].
For motors of 7.5 kW or less (400 V class series), the power voltage/frequency rating of the cooling fan is 200 V/50 Hz or 200-230 V/60 Hz. For motors of 11 kW or above (400 V class series), it is 400-420 V/50 Hz or 400-440 V/60 Hz. To use the fan with power voltage other than the above specifications, a transformer is necessary.
- (Note 14) $\textcircled{0V}$ ([M], [11], [THC]) and $\textcircled{0V}$ ([CM], (PGM)) are insulated inside the inverter unit.
- (Note 15) Use the auxiliary contact (manual reset) of the thermal relay to trip the MCCB or MC.
- (Note 16) Jumper bars are mounted between safety terminals [EN1]/[EN2] and [PS] by factory default. To use the safety function, remove the jumper bars before connection of safety devices.


2.6.1.2 Running the GNF2 type of a permanent magnet synchronous motor (dedicated motor)



- (Note 1) Install a recommended molded case circuit breaker (MCCB) or residual-current-operated protective device (RCD)/earth leakage circuit breaker (ELCB) (with overcurrent protection function) in the primary circuit of the inverter to protect wiring. Ensure that the circuit breaker capacity is equivalent to or lower than the recommended capacity.
- (Note 2) Install a magnetic contactor (MC) for each inverter to separate the inverter from the power supply, apart from the MCCB or RCD/ELCB, when necessary.
Connect a surge absorber in parallel when installing a coil such as the MC or solenoid near the inverter.
- (Note 3) To retain an alarm output signal **ALM** issued on inverter's programmable output terminals by the protective function or to keep the keypad alive even if the main power has shut down, connect these terminals to the power supply lines. Without power supply to these terminals, the inverter can run.
- (Note 4) Normally no need to be connected. Use these terminals when the inverter is equipped with a high power-factor, regenerative PWM converter (RHC series).
- (Note 5) When connecting an optional DC reactor (DCR), remove the jumper bar from the main circuit terminals P1 and P(+). Inverters of 75 kW or above and LD-mode inverters of 55 kW come with a DCR as standard. Be sure to connect the DCR.
Use a DCR when the capacity of the power supply transformer exceeds 500 kVA and is 10 times or more the inverter rated capacity, or when there are thyristor-driven loads in the same power supply line.
- (Note 6) Inverters of 55 kW or below (200 V class series) and those of 160 kW or below (400 V class series) have a built-in braking transistor, allowing a braking resistor (DBR) to be directly connected between terminals P(+) and DB.
- (Note 7) When connecting an optional braking resistor (DBR) to inverters of 75 kW or above (200 V class series) or those of 200 kW or above (400 V class series), be sure to use an optional braking unit (BU) together.
Connect the BU between terminals P(+) and N(-). Auxiliary terminals [1] and [2] have polarity, so make connection as shown in the connection diagram.
- (Note 8) A grounding terminal for a motor. It is recommended that the motor be grounded via this terminal for suppressing inverter noise.
- (Note 9) For wiring enclosed with $\frac{1}{2}$ " $\frac{3}{4}$ ", use twisted or shielded wires.
In principle, the shielded sheath of wires should be connected to ground. If the inverter is significantly affected by external induction noise, however, connection to $\text{\textcircled{0V}}$ ([M], [11], [THC]) or $\text{\textcircled{0V}}$ ([CM], (PGM)) may be effective to suppress the influence of noise.
Keep the control circuit wiring away from the main circuit wiring as far as possible (recommended: 10 cm or more). Never install them in the same wire duct. When crossing the control circuit wiring with the main circuit wiring, set them at right angles.
- (Note 10) The connection diagram shows factory default functions assigned to digital input terminals [X1] to [X9], transistor output terminals [Y1] to [Y4], and relay contact output terminals [Y5A/C].
- (Note 11) Switching connectors in the main circuits. For details, refer to Chapter 3, Section 3.3.3.7 "Switching connectors."
- (Note 12) Slide switches on the control printed circuit board (control PCB). Use these switches to customize the inverter operations. For details, refer to Chapter 3, Section 3.3.3.9 "Setting up the slide switches."
- (Note 13) The cooling fan power supply for motors of 7.5 kW or less is single-phase. Connect terminals [FU] and [FV].
For motors of 7.5 kW or less (400 V class series), the power voltage/frequency rating of the cooling fan is 200 V/50 Hz or 200-230 V/60 Hz. For motors of 11 kW or above (400 V class series), it is 400-420 V/50 Hz or 400-440 V/60 Hz. To use the fan with power voltage other than the above specifications, a transformer is necessary.
- (Note 14) $\text{\textcircled{0V}}$ ([M], [11], [THC]) and $\text{\textcircled{0V}}$ ([CM], (PGM)) are insulated inside the inverter unit.
- (Note 15) Use the auxiliary contact (manual reset) of the thermal relay to trip the MCCB or MC.
- (Note 16) Jumper bars are mounted between safety terminals [EN1]/[EN2] and [PS] by factory default. To use the safety function, remove the jumper bars before connection of safety devices.
- (Note 17) If the activation of the inverter protective function may result in a high-speed motor rotation due to the load, be sure to insert an MC.
- (Note 18) A single inverter cannot drive two or more PMSMs.
- (Note 19) A PMSM (GNF2 type) cannot be driven by commercial power. Driving the PMSM may result in a motor burnout.
- (Note 20) Driving a PMSM requires setting the inverter carrier frequency high in order to prevent permanent magnet overheat and demagnetization due to the output current harmonics (except Fuji GNF2 type). Be sure to check the allowable carrier frequency of the motor and determine the settings of the carrier frequency (F26) and automatic lowering of the carrier frequency (H104, Hundreds digit).
When canceling the automatic lowering of the carrier frequency, take care since it derates the continuous rated current of the inverter according to the carrier frequency setting (F26). (For the rated current derating, refer to Section 2.1.4.)

2.6.2 List of terminal functions

Main Circuit Terminals and Analog Input Terminals

| Classification | Symbol | Name | Functions |
|----------------|---|---|---|
| Main circuit | L1/R, L2/S, L3/T | Main circuit power inputs | Connect the three-phase input power lines. |
| | U, V, W | Inverter outputs | Connect a three-phase motor. |
| | P (+), P1 | DC reactor connection | Connect a DC reactor (DCR) for correcting power factor. HD- and MD-mode inverters: A DCR is provided as an option for inverters of 55 kW or below, and as standard for those of 75 kW or above. LD-mode inverters: A DCR is provided as an option for inverters of 45 kW or below, and as standard for those of 55 kW or above. |
| | P (+), N (-) | Braking unit connection | Connect a braking resistor (DBR) via a braking unit. For connection to the DC link bus. |
| | P (+), DB | External braking resistor connection | Connect an optional external braking resistor. |
| |  G | Grounding for inverter | Grounding terminals of the inverter. |
| | R0, T0 | Auxiliary power input for the control circuit | For a backup of the control circuit power supply, connect AC power lines same as that of the main power input. |
| | R1, T1 | Auxiliary power input for the fans | For use in combination with a power regenerative PWM converter (RHC series), use these terminals for an auxiliary power input of the AC fans inside the inverter. (For 200 V class series of inverters with 37 kW or above and 400 V class series with 75 kW or above) Normally, no need to use these terminals. |
| Speed setting | [13] | Power supply for the potentiometer | Power supply (+10 VDC, 10 mA max.) for a speed command potentiometer (Variable resistor: 1 to 5kΩ). |
| | [12] | Setting voltage input | The speed is commanded according to the external analog voltage input. Reversed operation with ± signals: 0 to ±10V DC/0 to maximum speed |
| | [11] | Analog input common | Common for analog input signals. |
| Analog input | [Ai1] | Analog input 1 | Selectable from the following functions to assign. Possible to make setting according to analog input voltage specified from the external equipment. 0: Input signal off (OFF) 1: Auxiliary speed setting 1 (AUX-N1) 2: Auxiliary speed setting 2 (AUX-N2) 3: Torque limiter (level 1) (TL-REF1) 4: Torque limiter (level 2) (TL-REF2) 5: Torque bias command (TB-REF) 6: Torque command (T-REF) 7: Torque current command (IT-REF) 8: Creep speed 1 under UP/DOWN control (CRP-N1) 9: Creep speed 2 under UP/DOWN control (CRP-N2) 10: Magnetic-flux reference (MF-REF) 11: Line speed detected (LINE-N) 12: Motor temperature (M-TMP) 13: Speed override (N-OR) 14: Universal Ai (U-AI) 15: PID feedback value 1 (PID-FB1) 16: PID command (PID-REF) 17: PID correction gain (PID-G) 18-24: Custom Ai 1 to 7 (C-AI 1 to 7) 25: Main speed reference (N-REFV) 26: Current input speed reference (N-REFC) 27: PID feedback value 2 (PID-FB2) * Ai2 is switchable between voltage input and current input by using the internal switch. Note that current input supports "speed setting" only. |
| | [Ai2] | Analog input 2 | |
| | [M] | Analog input common | Common for analog input signals. |

Digital Input Terminals

| Classification | Symbol | Name | Functions | |
|--|--------|-------------------------------------|--|---|
| Digital input (Sink/source switchable) | [FWD] | Run forward command Stop command | FWD-CM: ON Run the motor in the forward direction. FWD-CM: OFF Decelerate the motor to stop. | |
| | [REV] | Run reverse command Stop command | REV-CM: ON Run the motor in the reverse direction. REV-CM: OFF Decelerate the motor to stop. | |
| | [X1] | Digital input 1 | 00, 01, 02, 03: Select multistep speed (1 to 15 steps) (00: <i>SSI</i> , 01: <i>SS2</i> , 02: <i>SS4</i> , 03: <i>SS8</i>) 04, 05: Select ASR and ACC/DEC time (4 steps) (04: <i>RT1</i> , 05: <i>RT2</i>) 06: Enable 3-wire operation (<i>HLD</i>) 07: Coast to a stop (<i>BX</i>) 08: Reset alarm (<i>RST</i>) 09: Enable external alarm trip (<i>THR</i>) 10: Ready for jogging (<i>JOG</i>) 11: Select speed command N2/N1 (<i>N2/N1</i>) 12: Select motor 2 (<i>M-CH2</i>) 13: Select motor 3 (<i>M-CH3</i>) 14: Enable DC braking (<i>DCBRK</i>) 15: Clear ACC/DEC to zero (<i>CLR</i>) 16: Switch creep speed under UP/DOWN control (<i>CRP-N2/N1</i>) 17: UP (Increase speed under UP/DOWN control) (<i>UP</i>) 18: DOWN (Decrease speed under UP/DOWN control) (<i>DOWN</i>) 19: Enable data change with keypad (<i>WE-KP</i>) 20: Cancel PID control (<i>KP/PID</i>) 21: Switch normal/inverse operation (<i>IVS</i>) 22: Interlock (52-2) (<i>IL</i>) 23: Enable data change via communications link (<i>WE-LK</i>) 24: Enable communications link (<i>LE</i>) 25: Universal DI (<i>U-DI</i>) 26: Enable auto search for idling motor speed at starting (<i>STM</i>) 27: Synchronous operation command (<i>SYC</i>) 28: Lock at zero speed (<i>LOCK</i>) 29: Pre-excitation (<i>EXITE</i>) 30: Cancel speed limiter (<i>N-LIM</i>) 31: Cancel H41 (Torque command) (<i>H41-CCL</i>) 32: Cancel H42 (Torque current command) (<i>H42-CCL</i>) 33: Cancel H43 (Magnetic flux command) (<i>H43-CCL</i>) 34: Cancel F40 (Torque limiter mode 1) (<i>F40-CCL</i>) 35: Select torque limiter level 2/1 (<i>TL2/TL1</i>) 36: Bypass ACC/DEC processor (<i>BPS</i>) 37, 38: Select torque bias command 1/2 (37: <i>TBI</i> , 38: <i>TB2</i>) 39: Select droop control (<i>DROOP</i>) 40: Zero-hold Ai1 (<i>ZH-AI1</i>) 41: Zero-hold Ai2 (<i>ZH-AI2</i>) 42: Zero-hold Ai3 (<i>ZH-AI3</i>) 43: Zero-hold Ai4 (<i>ZH-AI4</i>) 44: Reverse Ai1 polarity (<i>REV-AI1</i>) 45: Reverse Ai2 polarity (<i>REV-AI2</i>) 46: Reverse Ai3 polarity (<i>REV-AI3</i>) 47: Reverse Ai4 polarity (<i>REV-AI4</i>) 48: Inverse PID output (<i>PID-INV</i>) 49: Cancel PG alarm (<i>PG-CCL</i>) 50: Cancel undervoltage alarm (<i>LU-CCL</i>) 51: Hold Ai torque bias (<i>H-TB</i>) 52: STOP1 (Decelerate to stop with normal deceleration time) (<i>STOP1</i>) 53: STOP2 (Decelerate to stop with deceleration time 4) (<i>STOP2</i>) 54: STOP3 (Decelerate to stop with max. braking torque) (<i>STOP3</i>) 55: Latch DIA data (<i>DIA</i>) 56: Latch DIB data (<i>DIB</i>) 57: Cancel multiplex system (<i>MT-CCL</i>) 58-67: Custom Di1-Di10 (<i>C-DI1</i> to <i>C-DI10</i>) 68: Select load adaptive parameters 2/1 (<i>AN-P1/2</i>) *1 69: Cancel PID components (<i>PID-CCL</i>) 70: Enable PID FF component (<i>PID-FF</i>) 71: Reset completion of speed limit calculation (<i>NL-RST</i>) *1 72: Toggle signal 1 (<i>TGL1</i>) 73: Toggle signal 2 (<i>TGL2</i>) 74: Cause external mock alarm (<i>FTB</i>) 75: Cancel NTC thermistor alarm (<i>NTC-CCL</i>) 76: Cancel lifetime alarm signal (<i>LF-CCL</i>) 78: Switch PID feedback signals (<i>PID-1/2</i>) 79: Select PID torque bias (<i>TB-PID</i>) | |
| | [X2] | Digital input 2 | | |
| | [X3] | Digital input 3 | | |
| | [X4] | Digital input 4 | | |
| | [X5] | Digital input 5 | | |
| | [X6] | Digital input 6 | | |
| | [X7] | Digital input 7 | | |
| | [X8] | Digital input 8 | | |
| | [X9] | Digital input 9 | | |
| | [PLC] | PLC signal power | | Connect the PLC output signal power supply. This terminal also supplies power to the load connected to the transistor output terminals. +24 V (22 to 27 V), 100 mA max. |
| | [CM] | Digital input common | | Common terminal for digital input signals. |

*1 Available soon

| Classification | Symbol | Name | Functions |
|-----------------------|---------------------|--------------------------------------|--|
| Transistor output | [Y4] | Transistor output 4 | 61: Speed agreement 2 (<i>N-AG2</i>) 62: Speed agreement 3 (<i>N-AG3</i>) 63: Axial fan stopped (<i>MFAN</i>) 64: Answerback to toggle signal 1 (<i>TGL1-AB</i>) 65: Answerback to toggle signal 2 (<i>TGL2-AB</i>) 66: Answerback to droop control enabled (<i>DSAB</i>) 67: Answerback to cancellation of torque command/torque current command (<i>TCL-C</i>) 68: Answerback to cancellation of torque limiter mode 1 (<i>F40-AB</i>) 71: 73 ON command (<i>PRT-73</i>) 72: Turn ON Y-terminal test output (<i>Y-ON</i>) 73: Turn OFF Y-terminal test output (<i>Y-OFF</i>) 75: System clock battery lifetime expired (<i>BATT</i>) 77: SPGT battery warning (<i>SPGT-B</i>) (Available soon) 80: EN terminal detection circuit failure (<i>DECF</i>) *1 81: EN terminal OFF (<i>ENOFF</i>) *1 82: Safety function in progress (<i>SF-RUN</i>) *1 84: STO under testing by safety function (<i>SF-TST</i>) *1 |
| | [CMY] | Transistor output common | Common terminal for transistor output signals. |
| Relay output | [Y5A], [Y5C] | Relay output | Same signals as listed in [Y1] to [Y4] are selectable. |
| | [30A], [30B], [30C] | Alarm relay output | Outputs a no-voltage contact signal (1C) when the protective function has been activated to stop the motor. Switchable whether excitation or non-excitation outputs an alarm. |
| Communication | [DX+], [DX-] | RS-485 communication input/output | Input/output terminals for RS-485 communication. Multi-drop connection enables up to 31 inverters to connect to one host equipment. Half-duplex mode. |
| | USB connector | USB port | Accessible from the front of the inverter. USB connector: mini B, USB 2.0 Full Speed |
| Speed detection | [PA], [PB] | Pulse generator 2-phase signal input | Connection of 2-phase signals sent from a pulse generator. |
| | [PGP], [PGM] | Pulse generator power supply | Power supply (+15 VDC, switchable to +12 VDC) to a PG. |
| | [FA], [FB] | Pulse generator output | Outputs frequency-divided (programmable with Function code E29) pulse generator signals. Switchable between open collector and complementary (equivalent to the voltage on the [PGP] terminal) transistor outputs. |
| | [CM] | Pulse generator output common | A common terminal for [FA] and [FB]. |
| Temperature detection | [TH1], [THC] | NTC/PTC thermistor connection | Monitor of the motor temperature with NTC or PTC thermistor. For a PTC thermistor, the motor overheat protection level can be specified with Function code E32. |

*1 Available in the ROM version H1/2 0020 or later.

Chapter 3

PREPARATION AND TEST RUN

This chapter describes the operating and storage environments, installation and wiring, typical connection diagram, names and functions of keypad components, keypad operation, and test run procedure.

Contents

| | | |
|---------|--|------|
| 3.1 | Before Use | 3-1 |
| 3.1.1 | Acceptance inspection (Nameplates and type of inverter) | 3-1 |
| 3.1.2 | External view and terminal blocks | 3-3 |
| 3.2 | Precautions for Using Inverters..... | 3-5 |
| 3.2.1 | Installation environment..... | 3-5 |
| 3.2.2 | Storage environment | 3-6 |
| 3.2.3 | Wiring precautions | 3-7 |
| 3.2.4 | Precautions for connection of peripheral equipment | 3-8 |
| 3.2.5 | Noise reduction | 3-12 |
| 3.2.6 | Leakage current..... | 3-12 |
| 3.2.7 | Precautions in driving a permanent magnet synchronous motor (PMSM)..... | 3-12 |
| 3.3 | Mounting and Wiring the Inverter..... | 3-13 |
| 3.3.1 | Operating environment..... | 3-13 |
| 3.3.2 | Installing the Inverter | 3-14 |
| 3.3.3 | Wiring | 3-16 |
| 3.3.3.1 | Removing and mounting the front cover and the wiring guide | 3-16 |
| 3.3.3.2 | Screw specifications and recommended wire sizes | 3-17 |
| 3.3.3.3 | Arrangement of terminals..... | 3-19 |
| 3.3.3.4 | Wiring precautions | 3-22 |
| 3.3.3.5 | Connection diagram | 3-25 |
| 3.3.3.6 | Detailed functions of main circuit terminals and grounding terminals | 3-27 |
| 3.3.3.7 | Switching connectors | 3-31 |
| 3.3.3.8 | Detailed functions of control circuit terminals | 3-33 |
| 3.3.3.9 | Setting up the slide switches | 3-42 |
| 3.3.4 | Mounting and connecting a keypad | 3-44 |
| 3.3.4.1 | Parts required for connection | 3-44 |
| 3.3.4.2 | Mounting procedure | 3-44 |
| 3.3.5 | USB connectivity | 3-48 |
| 3.4 | Operation Using the Keypad..... | 3-49 |
| 3.4.1 | Names and functions of keypad components | 3-49 |
| 3.4.2 | Overview of operation modes | 3-52 |
| 3.4.3 | Running mode..... | 3-53 |
| 3.4.3.1 | Configuring the speed command..... | 3-53 |


| | | |
|----------|---|-------|
| 3.4.3.2 | Running or stopping the motor..... | 3-54 |
| 3.4.3.3 | Monitoring the running status on the LED monitor | 3-56 |
| 3.4.3.4 | Jogging (inching) the motor | 3-57 |
| 3.4.3.5 | Monitoring light alarms..... | 3-58 |
| 3.4.4 | Programming mode..... | 3-60 |
| 3.4.4.1 | Selecting language -- Menu #0 "LANGUAGE" | 3-66 |
| 3.4.4.2 | Configuring function codes -- Menu #1 "DATA SET" | 3-67 |
| 3.4.4.3 | Checking function code data -- Menu #2 "DATA CHECK"..... | 3-69 |
| 3.4.4.4 | Monitoring the running status -- Menu #3 "OPR MNTR" | 3-71 |
| 3.4.4.5 | Checking I/O signal status -- Menu #4 "I/O CHECK" | 3-74 |
| 3.4.4.6 | Reading maintenance information -- Menu #5 "MAINTENANCE" | 3-77 |
| 3.4.4.7 | Measuring load factor -- Menu #6 "LOAD FCTR"..... | 3-79 |
| 3.4.4.8 | Reading alarm information -- Menu #7 "ALM INF" | 3-80 |
| 3.4.4.9 | Viewing causes of alarm -- Menu #8 "ALM CAUSE"..... | 3-83 |
| 3.4.4.10 | Copying data -- Menu #10 "DATA COPY"..... | 3-84 |
| 3.4.4.11 | Checking changed function codes -- Menu #11 "CHANGES" | 3-88 |
| 3.4.4.12 | Setting the calendar clock -- Menu #12 "DATE/TIME"..... | 3-89 |
| 3.4.4.13 | Limiting function codes to be displayed -- Menu #14 "LIMITED FC" | 3-91 |
| 3.5 | Test Run Procedure | 3-92 |
| 3.5.1 | Checking prior to powering On..... | 3-93 |
| 3.5.2 | Powering ON and checking..... | 3-94 |
| 3.5.2.1 | Checking the input state of PG (pulse generator) signals..... | 3-94 |
| 3.5.2.2 | Mounting direction of a PG (pulse generator) and PG signals | 3-95 |
| 3.5.3 | Selecting a desired motor drive control..... | 3-96 |
| 3.5.3.1 | Vector control for IM with speed sensor | 3-96 |
| 3.5.3.2 | Vector control for IM without speed sensor | 3-98 |
| 3.5.3.3 | Vector control for PMSM with speed sensor and magnetic pole position sensor | 3-100 |
| 3.5.3.4 | V/f control for IM..... | 3-103 |
| 3.5.4 | Running the inverter for operation check..... | 3-105 |
| 3.5.4.1 | Test run procedure for induction motor (IM) | 3-105 |
| 3.5.4.2 | Test run procedure for permanent magnet synchronous motor (PMSM) | 3-106 |
| 3.5.5 | Selecting a speed command source | 3-113 |
| 3.5.5.1 | Setting up a speed command from the keypad | 3-113 |
| 3.5.5.2 | Setting up a speed command with an external potentiometer | 3-113 |
| 3.5.5.3 | Setting up a speed command with multistep speed selection | 3-114 |
| 3.5.6 | Selecting a run command source..... | 3-115 |
| 3.5.6.1 | Setting up a run command from the keypad..... | 3-115 |
| 3.5.6.2 | Setting up a run command with digital input signals (terminals [FWD] and [REV]) | 3-115 |

3.1 Before Use

3.1.1 Acceptance inspection (Nameplates and type of inverter)

Unpack the package and check the following:

- (1) An inverter and the following accessories are contained.
 - Accessories - DC reactor (DCR)
(for inverters of 75 kW or above and LD-mode inverters of 55 kW)
 - Instruction manual
 - CD-ROM (containing the FRENIC-VG User's Manual, FRENIC-VG Loader software (free version), and FRENIC-VG Loader Instruction Manual)
- (2) The inverter has not been damaged during transportation—there should be no dents or parts missing.
- (3) The inverter is the type you ordered. You can check the type and specifications on the main and sub nameplates. (The main and sub nameplates are attached to the inverter as shown in Figure 3.1-2.) For inverters of 30 kW or above, the mass is printed on the main nameplate.




(a) Main Nameplate

(b) Sub Nameplate

Figure 3.1-1 Nameplates

TYPE: Type of inverter








Note In this manual, inverter types are denoted as "FRN_ _ _ VG1□-2□/4□."


The FRENIC-VG is available in two or three drive modes depending upon the inverter capacity: High Duty (HD) and Low Duty (LD) modes or High Duty (HD), Medium Duty (MD) and Low Duty (LD) modes. One of these modes should be selected to match the load property of your system. Specifications in each mode are printed on the main nameplate.

- High Duty: HD mode designed for heavy duty load applications.
Overload capability: 150% for 1 min, 200% for 3 s. Continuous ratings = Inverter ratings
- Medium Duty: MD mode designed for medium duty load applications.
Overload capability: 150% for 1 min. Continuous ratings = One rank higher capacity of inverters
- Low Duty: LD mode designed for light duty load applications.
Overload capability: 120% for 1 min. Continuous ratings = One rank or two ranks higher capacity of inverters
- SOURCE: Number of input phases (three-phase: 3PH), input voltage, input frequency, input current
- OUTPUT: Number of output phases, rated output voltage, output frequency range, rated output capacity, rated output current, and overload capability
- SCCR: Short-circuit capacity
- MASS: Mass of the inverter in kilogram (for 30 kW or above)
- SER. No.: Product number

6 8 A 1 2 3 A 0 5 8 9 BB 6 0 1



-  : Mark of conformity with European standards
-  : Mark of conformity with UL Standards and CSA Standards (cUL-listed for Canada)
-  : Mark of conformity with the Radio Waves Act (South Korea)
-  : Mark of conformity with WEEE Directive

 For details about conformity with standards, refer to the FRENIC-VG Instruction Manual (INR-SI47-1580*-E).

* Only product version other than "AA" and "AB" support functional safety standards.

If you suspect the product is not working properly or if you have any questions about your product, contact your Fuji Electric representative.

3.1.2 External view and terminal blocks

(1) Outside and inside views





Figure 3.1-2 Outside and Inside Views of Inverters

(2) Warning plates and label

FRENIC-VG

| |
|--|
| ⚠ WARNING ⚠ |
| <p>■ RISK OF INJURY OR ELECTRIC SHOCK</p> <ul style="list-style-type: none"> Refer to the instruction manual before installation and operation. Do not remove any cover while applying power and at least 5min. after disconnecting power. More than one live circuit. See instruction manual. Securely ground (earth) the equipment. High touch current. |
| ⚠ 警告 ⚠ |
| <p>■ 有可能引起受伤、触电</p> <ul style="list-style-type: none"> 安装运行之前请务必阅读操作说明书并遵照其指示 通电时及切断电源5分钟之内请不要打开前面板 请正确接地 |
| ⚠ 警告 ⚠ |
| <p>■ けが、感電のおそれあり</p> <ul style="list-style-type: none"> 据え付け運転時の前に、必ず取扱説明書を読んでその指示に従うこと。 運転中および電源しゃ断後5分以内は表面カバーを開けないこと。 確実に接地をおこなうこと。 |
| <p>Only type B of RCD is allowed. See manual for details.</p> |

FO

(a) FRN7.5VG1□-2□

| |
|--|
| ⚠ WARNING ⚠ |
| <p>■ RISK OF INJURY OR ELECTRIC SHOCK</p> <ul style="list-style-type: none"> Refer to the instruction manual before installation and operation. Do not remove this cover while applying power. This cover can be removed after at least 10 min of power off and after the "CHARGE" lamp turns off. More than one live circuit. See instruction manual. Do not insert fingers or anything else into the inverter. Securely ground (earth) the equipment. High touch current. |
| ⚠ 警告 ⚠ |
| <p>■ 有可能引起受伤、触电</p> <ul style="list-style-type: none"> 安装运行之前请务必阅读操作说明书并遵照其指示 通电中不要打开表面盖板 断电10分钟以上、充电指示灯熄灭后才可打开表面盖板 打开表盖时，要确认控制电路辅助电源(R0-T0、R1-T1端子)也被切断后再进行 即便在安装了表面盖板时，也不要从缝隙间插入手指或其他异物 请正确接地 |
| ⚠ 警告 ⚠ |
| <p>■ けが、感電のおそれあり</p> <ul style="list-style-type: none"> 据え付け運転時の前に、必ず取扱説明書を読んでその指示に従うこと。 運転中は、表面カバーを開けないこと。 表面カバーを開ける場合は、電流しゃ断後10分以上経過後チャージランプが消灯したのを確認してから行うこと。 表面カバーを開ける場合は、各補助電源(R0-T0、R1-T1端子)もしゃ断していることを確認してから行うこと。 表面カバー取付状態であっても、開口部より装置内部に指・異物等挿入しないこと。 確実に接地をおこなうこと。 |
| <p>Only type B of RCD is allowed. See manual for details.</p> |

FO

(b) FRN220VG1□-4□

| |
|----------------------------|
| ⚠ WARNING ⚠ |
| ⚠ RISK OF ELECTRIC SHOCK ⚠ |
| ⚠ 警告 ⚠ |
| ⚠ 有可能引起触电 ⚠ |
| ⚠ 警告 ⚠ |
| ⚠ 感電のおそれあり ⚠ |

Figure 3.1-3 Warning Plates and Label

3.2 Precautions for Using Inverters

This section provides precautions in introducing inverters, e.g. precautions for installation environment, power supply lines, wiring, and connection to peripheral equipment. Be sure to observe those precautions.

3.2.1 Installation environment

Install the inverter in an environment that satisfies the requirements listed in Chapter 2, Section 2.2 "Common Specifications."

Fuji Electric strongly recommends installing inverters in a panel for safety reasons, in particular, when installing the ones whose enclosure rating is IP00.

When installing the inverter in a place out of the specified environmental requirements, it is necessary to derate the inverter or consider the panel engineering design suitable for the special environment or the panel installation location. For details, refer to the Fuji Electric technical information "Engineering Design of Panels" or consult your Fuji Electric representative.

The special environments listed below require using the specially designed panel or considering the panel installation location.

| Environments | Possible problems | Sample measures | Applications |
|---|---|---|--|
| Highly concentrated sulfidizing gas or other corrosive gases | Corrosive gases cause parts inside the inverter to corrode, resulting in an inverter malfunction. | Any of the following measures may be necessary. <ul style="list-style-type: none"> - Mount the inverter in a sealed panel with IP6X or air-purge mechanism. - Place the panel in a room free from influence of the gases. | Paper manufacturing, sewage disposal, sludge treatment, tire manufacturing, gypsum manufacturing, metal processing, and a particular process in textile factories. |
| A lot of conductive dust or foreign material (e.g., metal powders or shavings, carbon fibers, or carbon dust) | Entry of conductive dust into the inverter causes a short circuit. | Any of the following measures may be necessary. <ul style="list-style-type: none"> - Mount the inverter in a sealed panel. - Place the panel in a room free from influence of the conductive dust. | Wiredrawing machines, metal processing, extruding machines, printing presses, combustors, and industrial waste treatment. |
| A lot of fibrous or paper dust | Fibrous or paper dust accumulated on the heat sink lowers the cooling effect. Entry of dust into the inverter causes the electronic circuitry to malfunction. | Any of the following measures may be necessary. <ul style="list-style-type: none"> - Mount the inverter in a sealed panel that shuts out dust. - Ensure a maintenance space for periodical cleaning of the heat sink in panel engineering design. - Employ external cooling when mounting the inverter in a panel for easy maintenance and perform periodical maintenance. | Textile manufacturing and paper manufacturing. |
| High humidity or dew condensation | In an environment where a humidifier is used or where the air conditioner is not equipped with a dehumidifier, high humidity or dew condensation results, which causes a short-circuiting or malfunction of electronic circuitry inside the inverter. | <ul style="list-style-type: none"> - Put a heating module such as a space heater in the panel. | Outdoor installation. Film manufacturing line, pumps and food processing. |
| Vibration or shock exceeding the specified level | If a large vibration or shock exceeding the specified level is applied to the inverter, for example, due to a carrier running on seam joints of rails or blasting at a construction site, the inverter structure gets damaged. | <ul style="list-style-type: none"> - Insert shock-absorbing materials between the mounting base of the inverter and the panel for safe mounting. | Installation of an inverter panel on a carrier or self-propelled machine. Ventilating fan at a construction site or a press machine. |
| Fumigation for export packaging | Halogen compounds such as methyl bromide used in fumigation corrodes some parts inside the inverter. | <ul style="list-style-type: none"> - When exporting an inverter built in a panel or equipment, pack them in a previously fumigated wooden crate. - When packing an inverter alone for export, use a laminated veneer lumber (LVL). | Exporting. |

3.2.2 Storage environment

The storage environment in which the inverter should be stored after purchase differs from the installation environment. Store the inverter in an environment that satisfies the requirements listed below.

[1] Temporary storage

Table 3.2-1 Storage and Transport Environments

| Item | Specifications | |
|------------------------|--|--|
| Storage temperature *1 | -25 to +70°C | Places not subjected to abrupt temperature changes or condensation or freezing |
| Relative humidity | 5 to 95% *2 | |
| Atmosphere | The inverter must not be exposed to dust, direct sunlight, corrosive or flammable gases, oil mist, vapor, water drops or vibration. The atmosphere must contain only a low level of salt. (0.01 mg/cm ² or less per year) | |
| Atmospheric pressure | 86 to 106 kPa (during storage) | |
| | 70 to 106 kPa (during transportation) | |

*1 Assuming comparatively short time storage, e.g., during transportation or the like.

*2 Even if the humidity is within the specified requirements, avoid such places where the inverter will be subjected to sudden changes in temperature that will cause condensation to form.

Precautions for temporary storage

- (1) Do not leave the inverter directly on the floor.
- (2) If the environment does not satisfy the specified requirements listed in Table 3.2-1, wrap the inverter in an airtight vinyl sheet or the like for storage.
- (3) If the inverter is to be stored in a high-humidity environment, put a drying agent (such as silica gel) in the airtight package described in (2) above.

[2] Long-term storage

The long-term storage method of the inverter varies largely according to the environment of the storage site. General storage methods are described below.

- (1) The storage site must satisfy the requirements specified for temporary storage.
However, for storage exceeding three months, the surrounding temperature range should be within the range from -10 to 30°C. This is to prevent electrolytic capacitors in the inverter from deterioration.
- (2) The package must be airtight to protect the inverter from moisture. Add a drying agent inside the package to maintain the relative humidity inside the package within 70%.
- (3) If the inverter has been installed to the equipment or panel at construction sites where it may be subjected to humidity, dust or dirt, then temporarily remove the inverter and store it in the environment specified in Table 3.2-1.

Precautions for storage over 1 year

If the inverter has not been powered on for a long time, the property of the electrolytic capacitors may deteriorate. Power the inverters on once a year and keep the inverters powering on for 30 to 60 minutes. Do not connect the inverters to the load circuit (secondary side) or run the inverter.

3.2.3 Wiring precautions


- (1) Route the wiring of the control circuit terminals as far from the wiring of the main circuit as possible. Otherwise electric noise may cause malfunctions.
- (2) Fix the control circuit wires inside the inverter to keep them away from the live parts of the main circuit (such as the terminal block of the main circuit).
- (3) If more than one motor is to be connected to a single inverter, the wiring length should be the sum of the length of the wires to the motors.
- (4) Precautions for high frequency leakage currents

If the wiring distance between an inverter and a motor is long, high frequency currents flowing through stray capacitance across wires of phases may cause an inverter overheat, overcurrent trip, increase of leakage current, or it may not assure the accuracy in measuring leakage current. Depending on the operating condition, an excessive leakage current may damage the inverter.

To avoid the above problems when directly connecting an inverter to a motor, keep the wiring distance 50 m or less for inverters with a capacity of 3.7 kW or below, and 100 m or less for inverters with a higher capacity.

If the wiring distance longer than the specified above is required, lower the carrier frequency or insert an output circuit filter (OFL-□□□-□A) as shown below.

When a single inverter drives two or more motors connected in parallel (group drive), in particular, using shielded wires, the stray capacitance to the earth is large, so lower the carrier frequency or insert an output circuit filter (OFL-□□□-□A).



- Note**
- If the drive motor is equipped with a pulse generator (PG) and the wiring distance exceeds 100 m, inserting an isolated signal conditioner in the PG wiring or any other measure is required. (For recommended isolated signal conditioners and the connection method, refer to Chapter 8, Section 8.7 "PG Amplifier (Isolated signal conditioner).")
 - If further longer secondary wiring is required, consult your Fuji Electric representative.

- (5) Precautions for surge voltage in driving a motor by an inverter (especially for 400 V class motors)

If the motor is driven by a PWM-type inverter, surge voltage generated by switching the inverter component may be superimposed on the output voltage and may be applied to the motor terminals. Particularly if the wiring length is long, the surge voltage may deteriorate the insulation resistance of the motor. Implement any of the following measures.

- Use a motor with insulation that withstands the surge voltage. (All Fuji standard motors feature reinforced insulation.)
 - Connect a surge suppressor unit (SSU50/100TA-NS) at the motor terminal.
 - Connect an output circuit filter (OFL-□□□-□A) to the output terminals (secondary circuits) of the inverter.
 - Minimize the wiring length between the inverter and motor (10 to 20 m or less).
- (6) When an output circuit filter is inserted in the secondary circuit or the wiring between the inverter and the motor is long, a voltage loss occurs due to reactance of the filter or wiring so that the insufficient voltage may cause output current oscillation or a lack of motor output torque.

3.2.4 Precautions for connection of peripheral equipment

(1) Phase-advancing capacitors for power factor correction

Do not mount a phase-advancing capacitor for power factor correction in the inverter's input (primary) or output (secondary) circuit. Mounting it in the input (primary) circuit takes no effect. To correct the inverter power factor, use an optional DC reactor (DCR). Mounting it in the output (secondary) circuit causes an overcurrent trip, disabling operation.

An overvoltage trip that occurs when the inverter is stopped or running with a light load is assumed to be due to surge current generated by open/close of phase-advancing capacitors in the power system. An optional DC/AC reactor (DCR/ACR) is recommended as a measure to be taken at the inverter side.

Input current to an inverter contains a harmonic component that may affect other motors and phase-advancing capacitors on the same power supply line. If the harmonic component causes any problems, connect an optional DCR/ACR to the inverter. In some cases, it is necessary to insert a reactor in series with the phase-advancing capacitors.

(2) Power supply lines (Application of a DC/AC reactor)

Use an optional DC reactor (DCR) when the capacity of the power supply transformer is 500 kVA or more and is 10 times or more the inverter rated capacity or when there are thyristor-driven loads. If no DCR is used, the percentage-reactance of the power supply decreases, and harmonic components and their peak levels increase. These factors may break rectifiers or capacitors in the converter section of the inverter, or decrease the capacitance of the capacitors.

If the input voltage unbalance rate is 2% to 3%, use an optional DCR/ACR.

$$\text{Voltage unbalance (\%)} = \frac{\text{Max voltage (V)} - \text{Min voltage (V)}}{\text{Three-phase average voltage (V)}} \times 67 \text{ (IEC 61800 - 3)}$$

(3) Optional DCR for correcting the inverter input power factor (for suppressing harmonics)

To correct the inverter input power factor (to suppress harmonics), use an optional DCR. Using a DCR increases the reactance of inverter's power source so as to decrease harmonic components on the power source lines and correct the power factor of the inverter.

| DCR models | Input power factor | Remarks |
|-------------------|--------------------|---|
| DCR2/4-□□/□□A/□□B | Approx. 90% to 95% | The last letter identifies the capacitance. These DCR models comply with "Standard Specifications for Public Building Construction" (Electric Equipment, 2010 version) supervised by the Ministry of Land, Infrastructure, Transport and Tourism. (The input power factor is 94% or above when the power factor of the fundamental harmonic is assumed as "1" according to the 2010 version.) |
| DCR2/4-□□C | Approx. 86% to 90% | Exclusively designed for nominal applied motor of 37 kW or above. |

- Note**
- Select a DCR matching not the inverter capacity but the nominal applied motor capacity. Applicable reactor models differ depending upon the selected HD, MD, or LD mode even on the same type of inverters.
 - Inverters of 75 kW or above and LD-mode inverters of 55 kW are provided together with a DCR as standard. Be sure to connect the DCR to the inverter.

(4) PWM converter for correcting the inverter input power factor

Using a PWM converter (High power-factor, regenerative PWM converter, RHC series) corrects the inverter power factor up to nearly "1." When combining an inverter with a PWM converter, disable the main power down detection by setting the function code H76 to "0" (default). If the main power down detection is enabled (H76 = 1), the inverter interprets the main power as being shut down, ignoring an entry of a run command.

- (5) Molded case circuit breaker (MCCB) or residual-current-operated protective device (RCD)/earth leakage circuit breaker (ELCB)

Install a recommended MCCB or RCD/ELCB (with overcurrent protection) in the primary circuit of the inverter to protect the wiring. Since using an MCCB or RCD/ELCB with a larger capacity than recommended ones breaks the protective coordination of the power supply system, be sure to select recommended ones. Also select ones with short-circuit breaking capacity suitable for the power source impedance.

Molded Case Circuit Breaker (MCCB) and Residual-Current-Operated Protective Device (RCD)/Earth Leakage Circuit Breaker (ELCB)

| Power supply voltage | Nominal applied motor (kW) | Inverter type | HD/MD/LD mode | Rated current of MCCB and RCD/ELCB (A) | |
|----------------------|----------------------------|----------------|---------------|--|---------|
| | | | | w/ DCR | w/o DCR |
| Three-phase 200 V | 0.75 | FRN0.75VG1□-2□ | HD | 5 | 10 |
| | 1.5 | FRN1.5VG1□-2□ | HD | 10 | 15 |
| | 2.2 | FRN2.2VG1□-2□ | HD | | 20 |
| | 3.7 | FRN3.7VG1□-2□ | HD | 20 | 30 |
| | 5.5 | FRN5.5VG1□-2□ | HD | 30 | 50 |
| | 7.5 | FRN7.5VG1□-2□ | HD | 40 | 75 |
| | 11 | FRN11VG1□-2□ | HD | 50 | 100 |
| | 15 | FRN15VG1□-2□ | HD | 75 | 125 |
| | 18.5 | FRN18.5VG1□-2□ | HD | 100 | 150 |
| | 22 | FRN22VG1□-2□ | HD | | 175 |
| | 30 | FRN30VG1□-2□ | HD | 150 | 200 |
| | 37 | | LD | 175 | 250 |
| | 45 | FRN37VG1□-2□ | HD | | |
| | | LD | | | |
| | 55 | FRN45VG1□-2□ | HD | 250 | 350 |
| | | LD | | | |
| | 75 | FRN55VG1□-2□ | HD | 350 | - |
| | | LD | | | |
| 90 | FRN75VG1□-2□ | HD | 400 | | |
| | LD | | | | |
| 110 | FRN90VG1□-2□ | HD | 350 | | |
| | LD | | | | |

Molded Case Circuit Breaker (MCCB) and
Residual-Current-Operated Protective Device (RCD)/Earth Leakage Circuit Breaker (ELCB) (continued)




| Power supply voltage | Nominal applied motor (kW) | Inverter type | HD/MD/LD mode | Rated current of MCCB and RCD/ELCB (A) | |
|----------------------|----------------------------|----------------|---------------|--|---------|
| | | | | w/ DCR | w/o DCR |
| Three-phase 400 V | 3.7 | FRN3.7VG1□-4□ | HD | 10 | 20 |
| | 5.5 | FRN5.5VG1□-4□ | HD | 15 | 30 |
| | 7.5 | FRN7.5VG1□-4□ | HD | 20 | 40 |
| | 11 | FRN11VG1□-4□ | HD | 30 | 50 |
| | 15 | FRN15VG1□-4□ | HD | 40 | 60 |
| | 18.5 | FRN18.5VG1□-4□ | HD | | 75 |
| | 22 | FRN22VG1□-4□ | HD | 50 | 100 |
| | 30 | FRN30VG1□-4□ | HD | 75 | 125 |
| | 37 | | LD | | |
| | 45 | FRN37VG1□-4□ | HD | 100 | 150 |
| | | FRN45VG1□-4□ | LD | | |
| | 55 | FRN55VG1□-4□ | HD | 125 | 200 |
| | | | LD | | |
| | 75 | FRN75VG1□-4□ | HD | 175 | |
| | | | LD | | |
| | 90 | FRN90VG1□-4□ | HD | 200 | |
| | | | MD/LD | | |
| | 110 | FRN110VG1□-4□ | HD | 250 | |
| | | | MD/LD | | |
| | 132 | FRN132VG1□-4□ | HD | 300 | |
| | | | MD/LD | | |
| | 160 | FRN160VG1□-4□ | HD | 350 | |
| | | | MD/LD | | |
| | 200 | FRN200VG1□-4□ | HD | 500 | |
| | | | MD/LD | | |
| | 220 | FRN220VG1□-4□ | HD | 600 | |
| | | | MD | | |
| | 280 | FRN280VG1□-4□ | LD | 800 | |
| | | | HD | | |
| | 315 | FRN315VG1□-4□ | MD | 1200 | |
| | | | HD | | |
| | 355 | FRN280VG1□-4□ | LD | 1400 | |
| MD | | | | | |
| 400 | FRN315VG1□-4□ | HD | 1600 | | |
| | | LD | | | |
| 450 | FRN355VG1□-4□ | MD | 1400 | | |
| | | LD | | | |
| 500 | FRN400VG1□-4□ | MD | 1600 | | |
| | | LD | | | |
| 630 | FRN500VG1□-4□ | HD | 1400 | | |
| | | LD | | | |
| 710 | FRN630VG1□-4□ | LD | 1600 | | |

⚠ WARNING


If no zero-phase current (earth leakage current) detective device such as a ground-fault relay is installed in the upstream power supply line in order to avoid the entire power supply system's shutdown undesirable to factory operation, install a residual-current-operated protective device (RCD)/earth leakage circuit breaker (ELCB) individually to inverters to break the individual inverter power supply lines only.

Otherwise, a fire could occur.

(6) Magnetic contactor (MC) in the inverter input (primary) circuit

Avoid frequent ON/OFF operation of the magnetic contactor (MC) in the input circuit; otherwise, the inverter failure may result. If frequent start/stop of the motor is required, use **FWD/REV** terminal signals or the  /  /  keys on the inverter's keypad.

The frequency of the MC's ON/OFF should not be more than once per 30 minutes. To assure 10-year or longer service life of the inverter, it should not be more than once per hour.

-  • From the system's safety point of view, it is recommended to employ such a sequence that shuts down the magnetic contactor (MC) in the inverter input circuit with an alarm output signal **30X** issued on inverter's programmable output terminals. The sequence minimizes the secondary damage even if the inverter breaks.

When the sequence is employed, connecting the MC's primary power line to the inverter's auxiliary control power input makes it possible to monitor the inverter's alarm status on the keypad.

- The breakdown of a braking unit or misconnection of an external braking resistor may trigger that of the inverter's internal parts (e.g., charging resistor). To avoid such a breakdown linkage, introduce an MC and configure a sequence that shuts down the MC if a DC link voltage establishment signal is not issued within three seconds after the MC is switched on.

For the braking transistor built-in type of inverters, assign a transistor error output signal **DBAL** on inverter's programmable output terminals to switch off the MC in the input circuit.

(7) Magnetic contactor (MC) in the inverter output (secondary) circuit

If a magnetic contactor (MC) is inserted in the inverter's output (secondary) circuit for switching the motor to a commercial power or for any other purposes, it should be switched on and off when both the inverter and motor are completely stopped. This prevents the contact point from getting rough due to a switching arc of the MC. The MC should not be equipped with any main circuit surge killer.

Applying a commercial power to the inverter's output circuit breaks the inverter. To avoid it, interlock the MC on the motor's commercial power line with the one in the inverter output circuit so that they are not switched ON at the same time.

(8) Surge absorber/surge killer

Do not install any surge absorber or surge killer in the inverter's output (secondary) lines.

3.2.5 Noise reduction

If noise generated from the inverter affects other devices, or that generated from peripheral equipment causes the inverter to malfunction, follow the basic measures outlined below.

- (1) If noise generated from the inverter affects the other devices through power wires or grounding wires:
 - Isolate the grounding terminals of the inverter from those of the other devices.
 - Connect a noise filter to the inverter power wires.
 - Isolate the power system of the other devices from that of the inverter with an insulated transformer.
 - Decrease the inverter's carrier frequency (F26). (See **Note** below.)
- (2) If induction or radio noise generated from the inverter affects other devices:
 - Isolate the main circuit wires from the control circuit wires and other device wires.
 - Put the main circuit wires through a metal conduit pipe, and connect the pipe to the ground near the inverter.
 - Install the inverter into the metal panel and connect the whole panel to the ground.
 - Connect a noise filter to the inverter's power wires.
 - Decrease the inverter's carrier frequency (F26). (See **Note** below.)
- (3) When implementing measures against noise generated from peripheral equipment:
 - For inverter's control signal wires, use twisted or shielded-twisted wires. When using shielded-twisted wires, connect the shield of the shielded wires to the common terminals of the control circuit.
 - Connect a surge absorber in parallel with magnetic contactor's coils or other solenoids (if any).

Note Running a permanent magnet synchronous motor (PMSM) at a low carrier frequency may heat the permanent magnet due to the output current harmonics, resulting in demagnetization. When decreasing the carrier frequency setting, be sure to check the allowable carrier frequency of the motor.

3.2.6 Leakage current

A high frequency current component generated by insulated gate bipolar transistors (IGBTs) switching on/off inside the inverter becomes leakage current through stray capacitance of inverter input and output wires or a motor. If any of the problems listed below occurs, take an appropriate measure against them.

| Problem | Measures |
|--|--|
| An earth leakage circuit breaker* that is connected to the input (primary) side has tripped. *With overcurrent protection | <ol style="list-style-type: none"> 1) Decrease the carrier frequency. (See Note given in Section 3.2.5 above.) 2) Make the wires between the inverter and motor shorter. 3) Use an earth leakage circuit breaker with lower sensitivity than the one currently used. 4) Use an earth leakage circuit breaker that features measures against the high frequency current component (Fuji SG and EG series). |
| An external thermal relay was falsely activated. | <ol style="list-style-type: none"> 1) Decrease the carrier frequency. (See Note given in Section 3.2.5 above.) 2) Increase the current setting of the thermal relay. 3) Use the electronic thermal overload protection built in the inverter, instead of the external thermal relay. |

3.2.7 Precautions in driving a permanent magnet synchronous motor (PMSM)

When using a PMSM, note the following.

- When using a PMSM other than the Fuji standard synchronous motor (GNF2), consult your Fuji Electric representative.
- A single inverter cannot drive two or more PMSMs.
- A PMSM cannot be driven by commercial power.

3.3 Mounting and Wiring the Inverter

3.3.1 Operating environment

Install the inverter in an environment that satisfies the requirements listed in Table 3.3-1.

Table 3.3-1 Environmental Requirements

| Item | Specifications | |
|---|---|---|
| Site location | Indoors | |
| Surrounding temperature | -10 to +50°C (Note 1) | |
| Relative humidity | 5 to 95% (No condensation) | |
| Atmosphere | <p>The inverter must not be exposed to dust, direct sunlight, corrosive gases, flammable gases, oil mist, vapor or water drops.</p> <p>Pollution degree 2 (IEC60664-1) (Note 2)</p> <p>The atmosphere can contain a small amount of salt. (0.01 mg/cm² or less per year)</p> <p>The inverter must not be subjected to sudden changes in temperature that will cause condensation to form.</p> | |
| Altitude | <p>3,000 m max.</p> <ul style="list-style-type: none"> • 1,001 to 3,000 m: Output current derating is required. (Note 3) • 2,001 to 3,000 m: The insulation level of the control circuits lowers from the reinforced insulation to the basic one. (Note 4) | |
| Atmospheric pressure | 86 to 106 kPa | |
| Vibration | 55 kW or below (200 V class series) | 75 kW or above (200 V class series) |
| | 75 kW or below (400 V class series) | 90 kW or above (400 V class series) |
| | 3 mm (Max. amplitude) 2 to less than 9 Hz | 3 mm (Max. amplitude) 2 to less than 9 Hz |
| | 9.8 m/s ² 9 to less than 20 Hz | 2 m/s ² 9 to less than 55 Hz |
| 2 m/s ² 20 to less than 55 Hz | 1 m/s ² 55 to less than 200 Hz | |
| 1 m/s ² 55 to less than 200 Hz | | |

- (Note 1)** When inverters are mounted side-by-side without any clearance between them (22 kW or below), the surrounding temperature should be within the range from -10 to +40°C.
- (Note 2)** Do not install the inverter in an environment where it may be exposed to lint, cotton waste or moist dust or dirt which will clog the heat sink of the inverter. If the inverter is to be used in such an environment, install it in a dustproof panel of your system.
- (Note 3)** When installing the inverter in an altitude above 1,000 m, apply an output current derating factor as listed in Table 3.3-2.
- (Note 4)** The FRENIC-VG inverter unit is compliant with the Low Voltage Directive IEC/EN61800-5-1 (Overvoltage category: 3). If it is installed in an altitude above 2,000 m, however, the insulation level lowers from the reinforced insulation to the basic one. To keep compliance with the Low Voltage Directive in the altitude, take necessary measure to keep the reinforced insulation at the equipment side to which the inverter is installed.

Table 3.3-2 Output Current Derating Factor in Relation to Altitude

| Altitude | Output current derating factor |
|-----------------|--------------------------------|
| 1000 m or lower | 1.00 |
| 1000 to 1500 m | 0.97 |
| 1500 to 2000 m | 0.95 |
| 2000 to 2500 m | 0.91 |
| 2500 to 3000 m | 0.88 |

3.3.2 Installing the Inverter

(1) Mounting base

Install the inverter on a base made of metal or other non-flammable material. Do not mount the inverter upside down or horizontally.

| |
|--|
| ⚠ WARNING |
| Install the inverter on a base made of metal or other non-flammable material. Otherwise, a fire could occur. |

(2) Clearances

Ensure that the minimum clearances indicated in Figure 3.3-1 and Table 3.3-3 are maintained at all times. When mounting the inverter in the panel of your system, take extra care with ventilation inside the panel as the surrounding temperature easily rises. Do not mount the inverter in a small panel with poor ventilation.

■ When mounting two or more inverters

When mounting two or more inverters in the same unit or panel, basically lay them out side by side. When mounting them necessarily one above the other, be sure to separate them with a partition plate or the like so that any heat radiating from an inverter will not affect the one/s above.

As long as the surrounding temperature is 40°C or lower, inverters with a capacity of 22 kW or below can be mounted side by side without any clearance between them.



Figure 3.3-1 Mounting Direction and Required Clearances

Table 3.3-3 Clearances (mm)

| Inverter capacity | A | B | C |
|-------------------|----|-----|-----|
| 0.75 to 22 kW | 20 | 100 | 0 |
| 30 to 220 kW | 50 | | 100 |
| 280 to 630 kW | | 150 | 150 |

C: Space required in front of the inverter unit

■ When employing external cooling

In external cooling, the heat sink, which dissipates about 70% of the total heat (total loss) generated into air, is situated outside the equipment or the panel. The external cooling, therefore, significantly reduces heat radiating inside the equipment or panel.

To employ external cooling for inverters with a capacity of 22 kW or below, use the mounting adapter for external cooling (option); for those with a capacity of 30 kW or above, simply change the positions of the mounting bases.

For the dimensional outline drawing of the mounting adapter (option), refer to Chapter 8, Section 8.5.8.




Figure 3.3-2 External Cooling

| |
|--|
| ⚠ CAUTION |
| Prevent lint, paper fibers, sawdust, dust, metallic chips, or other foreign materials from getting into the inverter or from accumulating on the heat sink. Otherwise, a fire or accident could occur. |

To utilize external cooling for inverters with a capacity of 30 kW or above, change the positions of the top and bottom mounting bases from the edge to the center of the inverter as shown below (Figure 3.3-3).

Screws differ in size and count for each inverter. Refer to the table below.

For the panel cutting size, refer to Chapter 2, Section 2.3 "External Dimensions."

Table 3.3-4 Screw Size, Count and Tightening Torque

| Inverter type | Base fixing screw (Screw size and q'ty) | Case fixing screw (Screw size and q'ty) | Tightening torque (N·m) |
|--|--|--|-------------------------------|
| FRN30VG1□-2□/FRN37VG1□-2□ FRN30VG1□-4□ to FRN55VG1□-4□ | M6 × 20 5 pcs for upper side, 3 pcs for lower side | M6 × 20 2 pcs for upper side | 5.8 |
| FRN45VG1□-2□/FRN55VG1□-2□ FRN75VG1□-4□ | M6 × 20 3 pcs each for upper and lower sides | M6 × 12 3 pcs for upper side | 5.8 |
| FRN75VG1□-2□ FRN90VG1□-4□/FRN110VG1□-4□ | M5 × 12 7 pcs each for upper and lower sides | M5 × 12 7 pcs for upper side | 3.5 |
| FRN132VG1□-4□/FRN160VG1□-4□ | M5 × 16 7 pcs each for upper and lower sides | M5 × 16 7 pcs for upper side | 3.5 |
| FRN90VG1□-2□ FRN200VG1□-4□/FRN220VG1□-4□ | M5 × 16 8 pcs each for upper and lower sides | M5 × 16 8 pcs for upper side | 3.5 |
| FRN280VG1□-4□/FRN315VG1□-4□ FRN355VG1□-4□/FRN400VG1□-4□ | M5 × 16 2 pcs each for upper and lower sides M6 × 20 6 pcs each for upper and lower sides | M5 × 16 2 pcs each for upper and lower sides M6 × 20 6 pcs each for upper and lower sides | 3.5 5.8 |
| FRN500VG1□-4□/FRN630VG1□-4□ | M8 × 20 8 pcs each for upper and lower sides | M8 × 20 8 pcs each for upper and lower sides | 13.5 |

- 1) Remove all of the base fixing screws and the case fixing screws from the top of the inverter.
- 2) Move the top mounting base to the center of the inverter and secure it to the case fixing screw holes with the base fixing screws. (After changing the position of the top mounting base, some screws may be left unused.)
- 3) Remove the base fixing screws from the bottom of the inverter, move the bottom mounting base to the center of the inverter, and secure it with the base fixing screws, just as in step 2). (Inverters with a capacity of 220 kW or below have no case fixing screws on the bottom.)




Figure 3.3-3 Changing the Positions of the Top and Bottom Mounting Bases

CAUTION

When changing the positions of the top and bottom mounting bases, use only the specified screws.
Otherwise, a fire or accident could occur.

3.3.3 Wiring

Follow the procedure below. (In the following description, the inverter has already been installed.)

Note In tables given in this manual, inverter types are denoted as "FRN__VG1□-2□/4□.

3.3.3.1 Removing and mounting the front cover and the wiring guide

⚠ CAUTION

Be sure to disconnect the USB cable from the USB connector before removing the front cover.

Otherwise, a fire or accident could occur.

(1) For inverters with a capacity of 22 kW or below

- ① First loosen the front cover fixing screw, hold the cover with both hands, slide it downward, tilt it toward you, and then pull it upward, as shown below.
- ② While pressing the wiring guide upward, pull it out toward you.
- ③ After carrying out wiring, put the wiring guide and the front cover back into place in the reverse order of removal.




Figure 3.3-4 Removing the Front Cover and the Wiring Guide (FRN11VG1□-2□)

(2) For inverters with a capacity of 30 to 630 kW

- ① Loosen the four front cover fixing screws, hold the cover with both hands, slide it upward slightly, and pull it toward you, as shown below.
- ② After carrying out wiring, align the screw holes provided in the front cover with the screws on the inverter case, then put the front cover back into place in the reverse order of removal.

Tip To expose the control printed circuit board (control PCB), open the keypad enclosure.




Figure 3.3-5 Removing the Front Cover (FRN30VG1□-2□)

3.3.3.2 Screw specifications and recommended wire sizes

(1) Main circuit terminals

The tables and figures given below show the screw specifications and wire sizes. Note that the terminal arrangements differ depending on the inverter types. In each of the figures, two grounding terminals (⊕G) are not exclusive to the power supply wiring (primary circuit) or motor wiring (secondary circuit).

Use crimp terminals covered with an insulation sheath or with an insulation tube. The recommended wire sizes for the main circuits are examples of using a single HIV wire (for 75°C) at a surrounding temperature of 50°C.

Table 3.3-5 Screw Specifications

| Inverter type | | Refer to Section 3.3.3.3. | Screw specifications | | | | | | | |
|-------------------|-------------------|---------------------------|--------------------------------|-------------------------|--------------------------------|-------------------------|--|-------------------------|--|-------------------------|
| Three-phase 200 V | Three-phase 400 V | | Main circuit terminals | | Grounding terminals | | Auxiliary control power input terminals [R0, T0] | | Auxiliary fan power input terminals [R1, T1] | |
| | | | Screw size (Screw-driver size) | Tightening torque (N·m) | Screw size (Screw-driver size) | Tightening torque (N·m) | Screw size | Tightening torque (N·m) | Screw size | Tightening torque (N·m) |
| FRN0.75VG1□-2□ | FRN0.75VG1□-4□ | Figure A | M5 (No. 2) | 3.5 | M5 (No. 2) | 3.5 | | | | |
| FRN1.5VG1□-2□ | FRN1.5VG1□-4□ | | | | | | | | | |
| FRN2.2VG1□-2□ | FRN2.2VG1□-4□ | | | | | | | | | |
| FRN3.7VG1□-2□ | FRN3.7VG1□-4□ | | | | | | | | | |
| FRN5.5VG1□-2□ | FRN5.5VG1□-4□ | | | | | | | | | |
| FRN7.5G1□-2□ | FRN7.5VG1□-4□ | | | | | | | | | |
| FRN11VG1□-2□ | FRN11VG1□-4□ | Figure B | M6 (No. 3) | 5.8 | M6 (No. 3) | 5.8 | | | -- | -- |
| FRN15VG1□-2□ | FRN15VG1□-4□ | | | | | | | | | |
| FRN18.5VG1□-2□ | FRN18.5VG1□-4□ | | | | | | | | | |
| FRN22VG1□-2□ | FRN22VG1□-4□ | Figure C | M8 | 13.5 | | | | | | |
| FRN30VG1□-2□ | FRN30VG1□-4□ | | | | | | | | | |
| FRN37VG1□-2□ | FRN37VG1□-4□ | | | | | | | | | |
| FRN45VG1□-2□ | FRN45VG1□-4□ | | | | | | | | | |
| FRN55VG1□-2□ | FRN55VG1□-4□ | Figure D | M10 | 27 | M8 | 13.5 | M3.5 | 1.2 | | |
| FRN75VG1□-2□ | FRN75VG1□-4□ | | | | | | | | | |
| -- | FRN90VG1□-4□ | Figure E | | | | | | | | |
| -- | FRN110VG1□-4□ | Figure F | | | | | | | | |
| FRN75VG1□-2□ | -- | Figure G | | | | | | | | |
| -- | FRN132VG1□-4□ | | | | | | | | | |
| -- | FRN160VG1□-4□ | Figure H | | | | | | | | |
| FRN90VG1□-2□ | FRN200VG1□-4□ | Figure I | M12 | 48 | M10 | 27 | | | | |
| -- | FRN220VG1□-4□ | | | | | | | | | |
| -- | FRN280VG1□-4□ | Figure J | | | | | | | | |
| -- | FRN315VG1□-4□ | | | | | | | | | |
| -- | FRN355VG1□-4□ | Figure K | | | | | | | | |
| -- | FRN400VG1□-4□ | | | | | | | | | |
| -- | FRN500VG1□-4□ | | | | | | | | | |
| -- | FRN630VG1□-4□ | | | | | | | | | |

⚠ WARNING ⚠

When the inverter power is ON, a high voltage is applied to the following terminals.

Main circuit terminals: L1/R, L2/S, L3/T, P1, P(+), N(-), DB, U, V, W, R0, T0, R1, T1, AUX-contact (30A, 30B, 30C, Y5A, Y5C)

Insulation level

Main circuit — Enclosure : Basic insulation (Overvoltage category III, Pollution degree 2)

Main circuit — Control circuit : Reinforced insulation (Overvoltage category III, Pollution degree 2)

Relay output — Control circuit : Reinforced insulation (Overvoltage category II, Pollution degree 2)

An electric shock may occur.

Table 3.3-6 Recommended Wire Sizes

| Power supply voltage | Nominal applied motor (kW) | Inverter type | | | Recommended wire size (mm ²) | | | | |
|----------------------|----------------------------|----------------|---------------|---------------|---|---------|----------------|---------------------------|----------------|
| | | | | | Main circuit power input (L1/R, L2/S, L3/T) | | Grounding [EG] | Inverter output [U, V, W] | DCR [P1, P(+)] |
| | | HD mode | LD mode | MD mode | w/ DCR | w/o DCR | | | |
| Three-phase 200 V | 0.75 | FRN0.75VG1□-2□ | -- | -- | 2.0 | 2.0 | 2.0 | 2.0 | 2.0 |
| | 1.5 | FRN1.5VG1□-2□ | -- | -- | | | | | |
| | 2.2 | FRN2.2VG1□-2□ | -- | -- | | | | | |
| | 3.7 | FRN3.7VG1□-2□ | -- | -- | | | | | |
| | 5.5 | FRN5.5VG1□-2□ | -- | -- | | | | | |
| | 7.5 | FRN7.5VG1□-2□ | -- | -- | 3.5 | 5.5 | 5.5 | 5.5 | 5.5 |
| | 11 | FRN11VG1□-2□ | -- | -- | 5.5 | 14 | | 8.0 | 8.0 |
| | 15 | FRN15VG1□-2□ | -- | -- | 14 | 22 | 14 | 14 | 14 |
| | 18.5 | FRN18.5VG1□-2□ | -- | -- | | | | | |
| | 22 | FRN22VG1□-2□ | -- | -- | 22 | 38 *1 | 14 | 22 | 22 |
| | 30 | FRN30VG1□-2□ | -- | -- | 38 | 60 | | 38 | 38 |
| | 37 | FRN37VG1□-2□ | FRN30VG1□-2□ | -- | | | 60 | 100 | 22 |
| | 45 | FRN45VG1□-2□ | FRN37VG1□-2□ | -- | 100 | 100 | | | |
| | 55 | FRN55VG1□-2□ | FRN45VG1□-2□ | -- | 150 *2 | -- | 22 | 150 *2 | 150 |
| | 75 | FRN75VG1□-2□ | FRN55VG1□-2□ | -- | | | | | |
| 90 | FRN90VG1□-2□ | FRN75VG1□-2□ | -- | 150 | -- | 38 | 150 | 200 | |
| 110 | -- | FRN90VG1□-2□ | -- | 200 | -- | | 200 | 200 | 250 |
| Three-phase 400 V | 3.7 | FRN3.7VG1□-4□ | -- | -- | 2.0 | 2.0 | 2.0 | 2.0 | 2.0 |
| | 5.5 | FRN5.5VG1□-4□ | -- | -- | | | | | |
| | 7.5 | FRN7.5VG1□-4□ | -- | -- | | | | | |
| | 11 | FRN11VG1□-4□ | -- | -- | | | | | |
| | 15 | FRN15VG1□-4□ | -- | -- | | | | | |
| | 18.5 | FRN18.5VG1□-4□ | -- | -- | 3.5 | 5.5 | 5.5 | 3.5 | 5.5 |
| | 22 | FRN22VG1□-4□ | -- | -- | 5.5 | 8.0 *3 | | 5.5 | 8.0 *3 |
| | 30 | FRN30VG1□-4□ | -- | -- | 14 | 22 | 8.0 | 14 | 14 |
| | 37 | FRN37VG1□-4□ | FRN30VG1□-4□ | -- | | | | | |
| | 45 | FRN45VG1□-4□ | FRN37VG1□-4□ | -- | 22 | 38 | 14 | 22 | 22 |
| | 55 | FRN55VG1□-4□ | FRN45VG1□-4□ | -- | | | | | |
| | 75 | FRN75VG1□-4□ | FRN55VG1□-4□ | -- | 38 | -- | 14 | 38 | 38 |
| | 90 | FRN90VG1□-4□ | FRN75VG1□-4□ | -- | 60 | -- | | 60 | 60 |
| | 110 | FRN110VG1□-4□ | FRN90VG1□-4□ | FRN90VG1□-4□ | | | 100 | -- | 22 |
| | 132 | FRN132VG1□-4□ | FRN110VG1□-4□ | FRN110VG1□-4□ | | | | | |
| | 160 | FRN160VG1□-4□ | FRN132VG1□-4□ | FRN132VG1□-4□ | 150 | -- | 38 | 150 | 150 |
| | 200 | FRN200VG1□-4□ | FRN160VG1□-4□ | FRN160VG1□-4□ | | | | | |
| | 220 | FRN220VG1□-4□ | FRN200VG1□-4□ | FRN200VG1□-4□ | 200 | -- | 38 | 200 | 250 |
| | 250 | -- | -- | FRN220VG1□-4□ | 250 | -- | | 250 | 250 |
| | 280 | -- | FRN220VG1□-4□ | -- | | | | | |
| | 315 | FRN315VG1□-4□ | -- | FRN280VG1□-4□ | 150x2 | -- | 60 | 150x2 | 200x2 |
| | 355 | FRN355VG1□-4□ | FRN280VG1□-4□ | FRN315VG1□-4□ | 200x2 | -- | | 200x2 | 200x2 |
| | 400 | FRN400VG1□-4□ | FRN355VG1□-4□ | FRN355VG1□-4□ | | | | | |
| | 450 | -- | FRN355VG1□-4□ | FRN400VG1□-4□ | 250x2 | -- | 100 | 250x2 | 325x2 |
| | 500 | FRN500VG1□-4□ | FRN400VG1□-4□ | -- | 325x2 | -- | | 325x2 | 325x3 |
| 630 | FRN630VG1□-4□ | FRN500VG1□-4□ | -- | 325x3 | -- | 100 | 325x3 | 325x4 | |
| 710 | -- | FRN630VG1□-4□ | -- | 250x4 | -- | | 325x4 | 325x4 | 325x4 |

*1 Use the crimp terminal model No. 38-6 manufactured by JST Mfg. Co., Ltd., or equivalent.

*2 When using 150 mm² wires for main circuit terminals of FRN55VG1□-2□ (LD mode), use CB150-10 crimp terminals designed for low voltage appliances in JEM1399.

*3 Use the crimp terminal model No. 8-L6 manufactured by JST Mfg. Co., Ltd., or equivalent.

| Terminals common to all inverters | Recommended wire size (mm ²) | Remarks |
|---|--|---|
| Auxiliary control power input terminals R0 and T0 | 2.0 | -- |
| Auxiliary fan power input terminals R1 and T1 | 2.0 | 200 V class series with 37 kW or above and 400 V class series with 75 kW or above |

(2) Control circuit terminals (common to all inverter types)

Table 3.3-7 lists the screw specifications and recommended wire size for wiring of the control circuit terminals. The control circuit terminals are common to all inverter types regardless of their capacities.


Table 3.3-7 Screw Specifications and Recommended Wire Size

| Terminals common to all inverter types | Screw specifications | | Recommended wire size (mm ²) |
|--|----------------------|-------------------------|--|
| | Screw size | Tightening torque (N·m) | |
| Control circuit terminals | M3 | 0.7 | 1.25 * |

* Using wires exceeding the recommended sizes may lift the front cover depending upon the number of wires used, impeding keypad's normal operation.

3.3.3.3 Arrangement of terminals

(1) Control circuit terminals (common to all inverter types)



(2) Main circuit terminals

Figure A




Figure B




Figure C




Figure D / Figure E




Figure F




Figure G




Figure H





Figure I  Charging lamp





Figure J  Charging lamp






Figure K  Charging lamp



3.3.3.4 Wiring precautions


Follow the rules below when performing wiring for the inverter.

- (1) Make sure that the source voltage is within the rated voltage range specified on the nameplate.
- (2) Be sure to connect the three-phase power wires to the main circuit power input terminals L1/R, L2/S and L3/T of the inverter. If the power wires are connected to other terminals, the inverter will be damaged when the power is turned ON.
- (3) Always connect the grounding terminal to prevent electric shock, fire or other disasters and to reduce electric noise.
- (4) Use crimp terminals covered with insulated sleeves for the main circuit terminal wiring to ensure a reliable connection.
- (5) Keep the power supply wiring (primary circuit) and motor wiring (secondary circuit) of the main circuit, and control circuit wiring as far away as possible from each other.
- (6) After removing a screw from the main circuit terminal block, be sure to restore the screw even if no wire is connected.
- (7) Use the wiring guide to separate wiring. For inverters with a capacity of 7.5 kW or below, the wiring guide separates the main circuit wires and the control circuit wires. For inverters with a capacity of 11 to 22 kW, it separates the upper and lower main circuit wires, and control circuit wires. Be careful about the wiring order.




■ Preparing for the wiring guide

Inverters with a capacity of 22 kW or below are sometimes lacking in wiring space for main circuit wires depending upon the wire materials used. To assure a sufficient wiring space, remove the clip-off sections (see below) as required with a nipper. Note that the enclosure rating of IP20 is not ensured when the wiring guide itself is removed to secure a space for thick main circuit wiring.



Wiring Guide (FRN7.5VG1□-2□)




Clip-off sections


If the inverter output wire size is 22 mm², remove clip-off section ①; if it is 38 mm², remove clip-off section ② before wiring.

Wiring Guide (FRN22VG1□-2□)


- (8) In some types of inverters, the wires from the main circuit terminal block cannot be straight routed. Route such wires as shown below so that the front cover is set into place.




- (9) For inverters with a capacity of 500 kW or 630 kW, two L2/S input terminals are arranged vertically to the terminal block. When connecting wires to these terminals, use the bolts, washers and nuts that come with the inverter, as shown below.



⚠ WARNING

- When wiring the inverter to the power source, insert a recommended molded case circuit breaker (MCCB) or residual-current-operated protective device (RCD)/earth leakage circuit breaker (ELCB) (with overcurrent protection) in the path of each pair of power lines to inverters. Use the recommended devices within the recommended current capacity.
- Be sure to use wires in the specified size.
- Tighten terminals with specified torque.
Otherwise, a fire could occur.
- When there is more than one combination of an inverter and motor, do not use a multicore cable for the purpose of handling their wirings together.
- Do not connect a surge killer to the inverter's output (secondary) circuit.
Doing so could cause a fire.
- Ground the inverter in compliance with the national or local electric code.
- Be sure to ground the inverter's grounding terminals G.
Otherwise, an electric shock or fire could occur.
- Qualified electricians should carry out wiring.
- Be sure to perform wiring after shutting down the power.
Otherwise, electric shock could occur.
- Be sure to perform wiring after installing the inverter unit.
Otherwise, electric shock or injuries could occur.
- Ensure that the number of input phases and the rated voltage of the product match the number of phases and the voltage of the AC power supply to which the product is to be connected.
Otherwise, a fire or an accident could occur.
- Do not connect the power source wires to inverter output terminals (U, V, and W).
Doing so could cause fire or an accident.

3.3.3.5 Connection diagram



-
- (Note 1) Install a recommended molded case circuit breaker (MCCB) or residual-current-operated protective device (RCD)/earth leakage circuit breaker (ELCB) (with overcurrent protection function) in the primary circuit of the inverter to protect wiring. Ensure that the circuit breaker capacity is equivalent to or lower than the recommended capacity.
- (Note 2) Install a magnetic contactor (MC) for each inverter to separate the inverter from the power supply, apart from the MCCB or RCD/ELCB, when necessary.
Connect a surge absorber in parallel when installing a coil such as the MC or solenoid near the inverter.
- (Note 3) To retain an alarm output signal **ALM** issued on inverter's programmable output terminals by the protective function or to keep the keypad alive even if the main power has shut down, connect these terminals to the power supply lines. Without power supply to these terminals, the inverter can run.
- (Note 4) Normally no need to be connected. Use these terminals when the inverter is equipped with a high power-factor, regenerative PWM converter (RHC series).
- (Note 5) When connecting an optional DC reactor (DCR), remove the jumper bar from the main circuit terminals P1 and P(+). Inverters of 75 kW or above and LD-mode inverters of 55 kW come with a DCR as standard. Be sure to connect the DCR.
Use a DCR when the capacity of the power supply transformer exceeds 500 kVA and is 10 times or more the inverter rated capacity, or when there are thyristor-driven loads in the same power supply line.
- (Note 6) Inverters of 55 kW or below (200 V class series) and those of 160 kW or below (400 V class series) have a built-in braking transistor, allowing a braking resistor (DBR) to be directly connected between terminals P(+) and DB.
- (Note 7) When connecting an optional braking resistor (DBR) to inverters of 75 kW or above (200 V class series) or those of 200 kW or above (400 V class series), be sure to use an optional braking unit (BU) together.
Connect the BU between terminals P(+) and N(-). Auxiliary terminals [1] and [2] have polarity, so make connection as shown in the connection diagram.
- (Note 8) A grounding terminal for a motor. It is recommended that the motor be grounded via this terminal for suppressing inverter noise.
- (Note 9) For wiring enclosed with $\frac{\pi}{4}$ or $\frac{3}{4}$, use twisted or shielded wires.
In principle, the shielded sheath of wires should be connected to ground. If the inverter is significantly affected by external induction noise, however, connection to 0V ([M], [11], [THC]) or 0V ([CM], (PGM)) may be effective to suppress the influence of noise.
Keep the control circuit wiring away from the main circuit wiring as far as possible (recommended: 10 cm or more). Never install them in the same wire duct. When crossing the control circuit wiring with the main circuit wiring, set them at right angles.
- (Note 10) The connection diagram shows factory default functions assigned to digital input terminals [X1] to [X9], transistor output terminals [Y1] to [Y4], and relay contact output terminals [Y5A/C].
- (Note 11) Switching connectors in the main circuits. For details, refer to Section 3.3.3.7 "Switching connectors."
- (Note 12) Slide switches on the control printed circuit board (control PCB). Use these switches to customize the inverter operations. For details, refer to Section 3.3.3.9 "Setting up the slide switches."
- (Note 13) The cooling fan power supply for motors of 7.5 kW or less is single-phase. Connect terminals [FU] and [FV].
For motors of 7.5 kW or less (400 V class series), the power voltage/frequency rating of the cooling fan is 200 V/50 Hz or 200-230 V/60 Hz. For motors of 11 kW or above (400 V class series), it is 400-420 V/50 Hz or 400-440 V/60 Hz. To use the fan with power voltage other than the above specifications, a transformer is necessary.
- (Note 14) 0V ([M], [11], [THC]) and 0V ([CM], (PGM)) are insulated inside the inverter unit.
- (Note 15) Use the auxiliary contact (manual reset) of the thermal relay to trip the MCCB or MC.
- (Note 16) Jumper bars are mounted between safety terminals [EN1]/[EN2] and [PS] by factory default. To use the safety function, remove the jumper bars before connection of safety devices.

3.3.3.6 Detailed functions of main circuit terminals and grounding terminals

① Primary grounding terminal (⚡G) for inverter enclosure

Two grounding terminals (⚡G) are not exclusive to the power supply wiring (primary circuit) or motor wiring (secondary circuit). Be sure to ground either of the two grounding terminals for safety and noise reduction. The inverter is designed for use with safety grounding to avoid electric shock, fire and other disasters.

The grounding terminal for inverter enclosure should be grounded as follows:


- 1) Ground the inverter in compliance with the national or local electric code.
- 2) Use a thick grounding wire with a large surface area and keep the wiring length as short as possible.

② Inverter output terminals U, V, and W and secondary grounding terminals (⚡G) for motor

Inverter's output terminals should be connected as follows:

- 1) Connect the three wires of the 3-phase motor to terminals U, V, and W, aligning the phases each other.
- 2) Connect the secondary grounding wire to the grounding terminal (⚡G).

Note When there is more than one combination of an inverter and motor, do not use a multicore cable for the purpose of handling their wirings together.



③ DC reactor terminals P1 and P(+)

Connect a DC reactor (DCR) to these terminals for power factor correction.

- 1) Remove the jumper bar from terminals P1 and P(+).
(Inverters of 75 kW or above and LD-mode inverters of 55 kW are not equipped with a jumper bar.)
- 2) Connect an optional DCR to those terminals.

Note

- The wiring length should be 10 m or below.
- Do not remove the jumper bar when a DCR is not used.
- For inverters of 75 kW or above and LD-mode inverters of 55 kW, a DCR is provided as standard. Be sure to connect the DCR to the inverter.
- When a PWM converter is connected to the inverter, no DCR is required.

⚠ WARNING

Be sure to connect an optional DC reactor (DCR) when the capacity of the power supply transformer exceeds 500 kVA and is 10 times or more the inverter rated capacity.

Otherwise, a fire could occur.

④ **DC braking resistor terminals P(+) and DB (Inverters of 55 kW or below for 200 V class series and those of 160 kW or below for 400 V class series)**

- 1) Connect an optional DBR to terminals P(+) and DB.
- 2) Arrange the DBR and inverter so that the wiring length comes to 5 m or less and twist the two DBR wires or route them together in parallel.

| |
|--|
| ⚠ WARNING |
| When connecting a DC braking resistor (DBR), never connect it to terminals other than terminals P(+) and DB. |
| Otherwise, a fire could occur. |

⑤ **DC link bus terminals P(+) and N(-)**

| Capacity (kW) | Braking transistor | Built-in DC braking resistor (DBR) | Optional devices | Devices and terminals |
|--|--------------------|------------------------------------|---|--------------------------------------|
| 75 to 90 (200 V) 200 to 630 (400 V) | None | None | Braking unit DC braking resistor (DBR) | Inverter–Braking unit: P(+) and N(-) |


1) **Connecting an optional braking unit or DC braking resistor (DBR)**

Inverters of 75 kW or above (200 V class series) and those of 200 kW or above (400 V class series) require both a braking unit and DBR.

Connect the terminals P(+) and N(-) of a braking unit to those on the inverter. Arrange the inverter and the braking unit so that the wiring length comes to 5 m or less and twist the two wires or route them together in parallel.

Next, connect the terminals P(+) and DB of a DBR to those on the braking unit. Arrange the braking unit and DBR so that the wiring length comes to 10 m or less and twist the two wires or route them together in parallel.

For details about the wiring, refer to the Braking Unit Instruction Manual.



2) **Connecting other external devices**

A DC link bus of other inverter(s) or a PWM converter is connectable to these terminals.

For connection examples at the PWM converter side, refer to Chapter 8, Section 8.5.2 "Power regenerative PWM converters, RHC series."

⑥ Main circuit power input terminals L1/R, L2/S, and L3/T (three-phase input)

The three-phase input power lines are connected to these terminals.

- 1) For safety, make sure that the molded case circuit breaker (MCCB) or magnetic contactor (MC) is turned OFF before wiring the main circuit power input terminals.
- 2) Connect the main circuit power supply wires (L1/R, L2/S and L3/T) to the input terminals of the inverter via an MCCB or residual-current-operated protective device (RCD)/earth leakage circuit breaker (ELCB)*, and an MC if necessary.

It is not necessary to align phases of the power supply wires and the input terminals of the inverter with each other.

* With overcurrent protection

Tip It is recommended to insert a manually operable magnetic contactor (MC) that allows you to disconnect the inverter from the power supply in an emergency (e.g., when the protective function is activated), preventing a failure or accident from causing secondary disasters.

⑦ Auxiliary control power input terminals R0 and T0

In general, the inverter runs normally without power supplied to the auxiliary control power input terminals R0 and T0. If the inverter main power is shut down, however, no power is supplied to the control circuit so that the inverter cannot issue a variety of output signals or display on the keypad.

To retain an alarm output signal *ALM* issued on inverter's programmable output terminals by the protective function or to keep the keypad alive even if the main power has shut down, connect the auxiliary control power input terminals R0 and T0 to the power supply lines. If a magnetic contactor (MC) is installed in the inverter's primary circuit, connect the primary circuit of the MC to these terminals R0 and T0.

Terminal rating:

200 to 240 VAC, 50/60 Hz, Maximum current 1.0 A (200 V class series with 22 kW or below)

200 to 230 VAC, 50/60 Hz, Maximum current 1.0 A (200 V class series with 30 kW or above)

380 to 480 VAC, 50/60 Hz, Maximum current 0.5 A (400 V class series)

Note When introducing a residual-current-operated protective device (RCD)/earth leakage circuit breaker (ELCB), connect its output (secondary) side to terminals R0 and T0. Connecting its input (primary) side to those terminals causes the RCD/ELCB to malfunction since the input power voltage to the inverter is three-phase but the one to terminals R0 and T0 is single-phase. To avoid such problems, be sure to insert an insulation transformer or auxiliary B contacts of a magnetic contactor in the location shown below.




Figure 3.3-6 Connection Example of Residual-current-operated Protective Device (RCD)/Earth Leakage Circuit Breaker (ELCB)



When connecting a PWM converter with an inverter, do not connect the power supply line directly to terminals R0 and T0. If a PWM is to be connected, insert an insulation transformer or auxiliary B contacts of a magnetic contactor at the power supply side.

For connection examples at the PWM converter side, refer to Chapter 8, Section 8.5.2 "Power regenerative PWM converters, RHC series."

⑧ Auxiliary fan power input terminals R1 and T1

The 200 V class series with 37 kW or above and 400 V class series with 75 kW or above are equipped with terminals R1 and T1. Only if the inverter works with the DC-linked power input whose source is a PWM converter, these terminals are used to feed AC power to the fans, while they are not used in any power system of ordinary configuration.

In this case, set up the fan power supply switching connectors (CN R and CN W).

Terminal rating:

(200 V class series with 37 kW or above)

200-220 VAC/50 Hz, 200-230 VAC/60 Hz, Maximum current 1.0 A

(400 V class series with 75 kW to 400 kW)

380-440 VAC/50 Hz, 380-480 VAC/60 Hz, Maximum current 1.0 A

(400 V class series with 500 kW and 630 kW)

380-440 VAC/50 Hz, 380-480 VAC/60 Hz, Maximum current 2.0 A



3.3.3.7 Switching connectors

■ **Power switching connectors (CN UX), for inverters of 75 kW or above (400 V class series)**



Inverters of 75 kW or above (400 V class series) are equipped with a set of switching connectors (male) which should be configured according to the power source voltage and frequency. By factory default, a jumper (female connector) is set to U1. If the power supply to the main power inputs (L1/R, L2/S, L3/T) or the auxiliary fan power input terminals (R1, T1) matches the conditions listed below, change the jumper to U2.

For the switching instructions, see Figures 3.3-7 and 3.3-8.

(a) **FRN75VG1S-4□ to FRN110VG1S-4□**

| | | |
|-------------------------|---|---|
| Connector configuration |  |  |
| Power source voltage | 398 to 440 V/50 Hz, 430 to 480 V/60 Hz (Factory default) | 380 to 398 V/50 Hz 380 to 430 V/60 Hz |

(b) **FRN132VG1S-4□ to FRN630VG1S-4□**

| | | |
|-------------------------|--|---|
| Connector configuration |  |  |
| Power source voltage | 398 to 440 V/50 Hz, 430 to 480 V/60 Hz (Factory default) | 380 to 398 V/50 Hz, 380 to 430 V/60 Hz |


- Note**
- The allowable power input voltage fluctuation is within -15% to +10% of the power source voltage.
 - A box (□) replaces an alphabetic letter depending on the shipping destination.

■ **Fan power supply switching connectors (CN R and CN W), for inverters of 37 kW or above (200 V class series) and those of 75 kW or above (400 V class series)**


The standard FRENIC-VG series accepts DC-linked power input in combination with a PWM converter. The 200 V class series with 37 kW or above and 400 V class series with 75 kW or above, however, contain AC-driven components such as AC fans. To supply AC power to those components, exchange the CN R and CN W connectors as shown below and connect the AC power line to the auxiliary fan power input terminals (R1, T1).

For the switching instructions, see Figures 3.3-7 and 3.3-8.

(a) FRN37VG1S-2□ to FRN75VG1S-2□, FRN75VG1S-4□ to FRN110VG1S-4□

| | |
|-------------------------|--|
| Connector configuration |  |
| Use conditions | <p>When not using terminal R1 or T1 (Factory default)</p> <p>When using terminals R1 and T1</p> <ul style="list-style-type: none"> • Feeding the DC-linked power • Combined with a PWM converter |

(b) FRN90VG1S-2□, FRN132VG1S-4□ to FRN630VG1S-4□

| | |
|-------------------------|--|
| Connector configuration |  |
| Use conditions | <p>When not using terminal R1 or T1 (Factory default)</p> <p>When using terminals R1 and T1</p> <ul style="list-style-type: none"> • Feeding the DC-linked power • Combined with a PWM converter |

- Note**
- By factory default, the fan power supply switching connectors CN R and CN W are set on the **FAN** and **NC** positions, respectively. Do not exchange them unless you drive the inverter with a DC-linked power supply.
 - Wrong configuration of these switching connectors cannot drive the cooling fans, causing a heat sink overheat alarm $\overline{H}/$ or a charger circuit alarm \overline{PbF} .
 - A box (□) replaces an alphabetic letter depending on the shipping destination.

■ Location of the switching connectors

The switching connectors are located on the power printed circuit board (power PCB) as shown below.





Figure 3.3-7 Location of Switching Connectors and Auxiliary Power Input Terminals



Note To remove each of the jumpers, pinch its upper side between your fingers, unlock its fastener, and pull it up.
When mounting it, fit the jumper over the connector until it snaps into place.

Figure 3.3-8 Inserting/Removing the Jumpers

3.3.3.8 Detailed functions of control circuit terminals

⚠ WARNING

In general, the covers of the control signal wires are not specifically designed to withstand a high voltage (i.e., reinforced insulation is not applied). Therefore, if a control signal wire comes into direct contact with a live conductor of the main circuit, the insulation of the cover might break down, which would expose the signal wire to a high voltage of the main circuit. Make sure that the control signal wires will not come into contact with live conductors of the main circuit.

Failure to observe these precautions could cause electric shock or an accident.

⚠ CAUTION

Noise may be emitted from the inverter, motor and wires. Take appropriate measures to prevent the nearby sensors and devices from malfunctioning due to such noise.

It takes a maximum of 5 seconds to establish the input/output of the control circuit after the main power is turned ON. Take appropriate measures, such as external timers.

An accident could occur.

Table 3.3-8 lists the symbols, names and functions of the control circuit terminals. The wiring to the control circuit terminals differs depending upon the setting of the function codes, which reflects the use of the inverter. Route wires properly to reduce the influence of noise.

Table 3.3-8 Symbols, Names and Functions of the Control Circuit Terminals




| Classification | Symbol | Name | Functions |
|----------------|----------------|--|---|
| Analog input | [13] | Power supply for potentiometer | Power supply (+10 VDC) for an external speed command potentiometer. (Variable resistor: 1 to 5kΩ) The potentiometer of 1/2 W rating or more should be connected. <u>Specifications:</u> 10 VDC/10 mA max. |
| | [12] | Analog setting voltage input | The speed is commanded according to the external voltage input. <u>Specifications:</u> • 0 to ±10 VDC/0 to maximum speed Maximum input voltage: ±15 VDC Note that the input voltage out of the range of ±10 VDC is regarded as ±10 VDC. • Input impedance: 10kΩ |
| | [Ai1] [Ai2] | Analog input 1 Analog input 2 | (1) Analog input voltage from external equipment. Possible to assign various signal functions (Input signal off, Auxiliary speed setting 1, Torque limiter (level 1, etc.), selected with Function codes E49 and E50 to these terminals. For details, refer to Chapter 4, Section 4.2 "Function Codes." (2) Only for terminal [Ai2], the input is switchable between voltage and current with the SW3 configuration. (For details about slide switches, refer to Section 3.3.3.9.) (3) To use terminal [Ai2] for current input speed setting (<i>N-REFC</i>), turn SW3 to the I position, set F01 or C25 to "9" and set E50 to "26." After that, check that the current input is normal on the I/O check screen (given in Section 3.4.4.5). <u>Specifications:</u> • Voltage input: 0 to ±10 VDC, Input impedance: 10kΩ Maximum input voltage: ±15 VDC Note that the input voltage out of the range of ±10 VDC is regarded as ±10 VDC. • Current input (only on terminal [Ai2]): Input impedance: 250Ω Maximum input current: 30 mADC Note that the input current exceeding 20 mADC is regarded as 20 mADC. |
| | [11] [M] | Analog input common | Common for analog input signals ([12], [Ai1] and [Ai2]). Isolated from terminals [CM], [CMY] and [PGM]. |
| | |  Note | <ul style="list-style-type: none"> - Since low level analog signals are handled, these signals are especially susceptible to the external noise effects. Route the wiring as short as possible (within 20 m) and use shielded wires. In principle, ground the shielded sheath of wires; if effects of external inductive noises are considerable, connection to terminal [11] may be effective. As shown in Figures 3.3-9 and 3.3-10, be sure to ground the single end of the shield to enhance the shield effect. - Use a twin-contact relay for low level signals if the relay is used in the control circuit. Do not connect the relay's contact to terminal [11] or [M]. - When the inverter is connected to an external device outputting the analog signal, the external device may malfunction due to electric noise generated by the inverter. If this happens, according to the circumstances, connect a ferrite core (a toroidal core or equivalent) to the device outputting the analog signal or connect a capacitor having the good cut-off characteristics for high frequency between control signal wires as shown in Figures 3.3-9 and 3.3-10. - Do not apply a voltage of +7.5 VDC or higher to terminal [C1]. Doing so could damage the internal control circuit. |
| | |  |  |
| | | Figure 3.3-9 Connection of Shielded Wire | Figure 3.3-10 Example of Electric Noise Reduction |

Table 3.3-8 Symbols, Names and Functions of the Control Circuit Terminals (Continued)


| Classification | Symbol | Name | Functions | | | | | | | | | | | | | | | | | | | | | | | | | |
|---|--|---|---|------|--|------|------|--------------------------|----------|-----|-----|-----------|------|------|----------------------------|----------|------|------|-----------|-----|-----|---|--|---|--------|----------------------------------|--|---|
| Digital input | [FWD] | Run forward command | <p>(1) In SINK mode: When terminals [FWD] and [CM] are closed, the motor runs in the forward direction; when they are opened, the motor decelerates to a stop.</p> <p>In SOURCE mode: When terminals [FWD] and [PLC] are closed, the motor runs in the forward direction; when they are opened, the motor decelerates to a stop.</p> <p>(2) Input mode, i.e. SINK/SOURCE, is changeable by using the slide switch SW1.</p> <p>Factory default: SINK (Refer to Section 3.3.3.9 "Setting up the slide switches.")</p> | | | | | | | | | | | | | | | | | | | | | | | | | |
| | [REV] | Run reverse command | <p>(1) In SINK mode: When terminals [REV] and [CM] are closed, the motor runs in the reverse direction; when they are opened, the motor decelerates to a stop.</p> <p>In SOURCE mode: When terminals [REV] and [PLC] are closed, the motor runs in the reverse direction; when they are opened, the motor decelerates to a stop. (SOURCE)</p> <p>(2) Input mode, i.e. SINK/SOURCE, is changeable by using the slide switch SW1.</p> <p>Factory default: SINK (Refer to Section 3.3.3.9 "Setting up the slide switches.")</p> | | | | | | | | | | | | | | | | | | | | | | | | | |
| | [X1] [X2] [X3] [X4] [X5] [X6] [X7] [X8] [X9] | Digital input 1 Digital input 2 Digital input 3 Digital input 4 Digital input 5 Digital input 6 Digital input 7 Digital input 8 Digital input 9 | <p>(1) Various signals such as "Coast to a stop," "Enable external alarm trip," and "Select multistep speed" can be assigned to these terminals by setting Function codes E01 to E09. For details, refer to Chapter 4, Section 4.2 "Function Codes."</p> <p>(2) Input mode, i.e. SINK/SOURCE, is changeable by using the slide switch SW1. Factory default: SINK (Refer to Section 3.3.3.9 "Setting up the slide switches.")</p> <p>(3) Function code E14 switches the logic value (1/0) for ON/OFF of the terminals [X1] to [X9]. If the logic value for ON of the terminal [X1] is "1" in the normal logic system, for example, OFF is "1" in the negative logic system and vice versa.</p> <p>(Digital input circuit specifications)</p>  <table border="1" data-bbox="925 1131 1380 1400"> <thead> <tr> <th>Item</th> <th></th> <th>Min.</th> <th>Max.</th> </tr> </thead> <tbody> <tr> <td rowspan="2">Operating voltage (SINK)</td> <td>ON level</td> <td>0 V</td> <td>2 V</td> </tr> <tr> <td>OFF level</td> <td>22 V</td> <td>27 V</td> </tr> <tr> <td rowspan="2">Operating voltage (SOURCE)</td> <td>ON level</td> <td>22 V</td> <td>27 V</td> </tr> <tr> <td>OFF level</td> <td>0 V</td> <td>2 V</td> </tr> <tr> <td colspan="2">Operating current at ON (Input voltage is at 0 V)</td> <td>-</td> <td>4.5 mA</td> </tr> <tr> <td colspan="2">Allowable leakage current at OFF</td> <td>-</td> <td>0.5 mA</td> </tr> </tbody> </table> <p>Figure 3.3-11 Digital Input Circuit</p> | Item | | Min. | Max. | Operating voltage (SINK) | ON level | 0 V | 2 V | OFF level | 22 V | 27 V | Operating voltage (SOURCE) | ON level | 22 V | 27 V | OFF level | 0 V | 2 V | Operating current at ON (Input voltage is at 0 V) | | - | 4.5 mA | Allowable leakage current at OFF | | - |
| Item | | Min. | Max. | | | | | | | | | | | | | | | | | | | | | | | | | |
| Operating voltage (SINK) | ON level | 0 V | 2 V | | | | | | | | | | | | | | | | | | | | | | | | | |
| | OFF level | 22 V | 27 V | | | | | | | | | | | | | | | | | | | | | | | | | |
| Operating voltage (SOURCE) | ON level | 22 V | 27 V | | | | | | | | | | | | | | | | | | | | | | | | | |
| | OFF level | 0 V | 2 V | | | | | | | | | | | | | | | | | | | | | | | | | |
| Operating current at ON (Input voltage is at 0 V) | | - | 4.5 mA | | | | | | | | | | | | | | | | | | | | | | | | | |
| Allowable leakage current at OFF | | - | 0.5 mA | | | | | | | | | | | | | | | | | | | | | | | | | |

Table 3.3-8 Symbols, Names and Functions of the Control Circuit Terminals (Continued)



| Classification | Symbol | Name | Functions | | | | | | | | | | | | | | | | | | | |
|----------------------------------|---|---|--|--------|--|------|------|----------------------------|----------|------|------|-----------|-----|-----|---|--|---|--------|----------------------------------|--|---|--------|
| Digital input | [EN1] [EN2] | Enable input | <p>(1) When [EN1]-[PS] or [EN2]-[PS] is opened (OFF), the inverter output transistor stops its operation. (Safe Torque Off, STO)</p> <p>To enable the STO function, remove the jumper bars.</p> <p>(2) The input mode of terminals [EN1] and [EN2] is fixed at SOURCE. It cannot be switched to SINK.</p> <p>(3) When not using the Enable input function, short the circuit between [EN1]-[PS] and [EN2]-[PS] with jumper bars (that is, keep the short bars connected).</p> <p>(Terminal EN circuit specification)</p>  <table border="1" data-bbox="911 600 1366 797"> <thead> <tr> <th colspan="2">Item</th> <th>Min.</th> <th>Max.</th> </tr> </thead> <tbody> <tr> <td rowspan="2">Operating voltage (SOURCE)</td> <td>ON level</td> <td>22 V</td> <td>27 V</td> </tr> <tr> <td>OFF level</td> <td>0 V</td> <td>2 V</td> </tr> <tr> <td colspan="2">Operating current at ON (Input voltage is at 0 V)</td> <td>-</td> <td>4.5 mA</td> </tr> <tr> <td colspan="2">Allowable leakage current at OFF</td> <td>-</td> <td>0.5 mA</td> </tr> </tbody> </table> | Item | | Min. | Max. | Operating voltage (SOURCE) | ON level | 22 V | 27 V | OFF level | 0 V | 2 V | Operating current at ON (Input voltage is at 0 V) | | - | 4.5 mA | Allowable leakage current at OFF | | - | 0.5 mA |
| | Item | | Min. | Max. | | | | | | | | | | | | | | | | | | |
| | Operating voltage (SOURCE) | ON level | 22 V | 27 V | | | | | | | | | | | | | | | | | | |
| | | OFF level | 0 V | 2 V | | | | | | | | | | | | | | | | | | |
| | Operating current at ON (Input voltage is at 0 V) | | - | 4.5 mA | | | | | | | | | | | | | | | | | | |
| Allowable leakage current at OFF | | - | 0.5 mA | | | | | | | | | | | | | | | | | | | |
| [PS] | [EN] terminal power | Power terminal for terminals [EN1] and [EN2]. This terminal outputs +24 VDC (Reference for terminal [CM]). | | | | | | | | | | | | | | | | | | | | |
| [PLC] | PLC signal power | <p>(1) Connects to PLC output signal power supply. Rated voltage: +24 VDC (Allowable range: +22 to +27 VDC), Maximum 100 mA DC</p> <p>(2) This terminal also supplies a power to the load connected to the transistor output terminals. Refer to "Transistor output" described later in this table for more.</p> | | | | | | | | | | | | | | | | | | | | |
| [CM] | Digital input common | Two common terminals for digital input signals Electrically isolated from terminals [11], [M], and [CMY]. | | | | | | | | | | | | | | | | | | | | |
| | Tip | <p>■ Using a relay contact to turn [FWD], [REV], or [X1] to [X9] ON or OFF</p> <p>Figure 3.3-12 shows two examples of a circuit configuration that uses a relay contact to turn control signal input [X1] to [X9], [FWD], or [REV] ON or OFF. In circuit (a), the slide switch is turned to SINK, whereas in circuit (b) it is turned to SOURCE.</p> <p>Note: To configure this kind of circuit, use a highly reliable relay. (Recommended product: Fuji control relay Model HH54PW.)</p>  <p>(a) With the switch turned to SINK</p> <p>(b) With the switch turned to SOURCE</p> | | | | | | | | | | | | | | | | | | | | |

Figure 3.3-12 Circuit Configuration Using a Relay Contact

Table 3.3-8 Symbols, Names and Functions of the Control Circuit Terminals (Continued)


| Classification | Symbol | Name | Functions |
|----------------|--|--|---|
| Digital input | <p>Tip ■ Using a programmable logic controller (PLC) to turn [FWD], [REV], or [X1] to [X9] ON or OFF</p> <p>Figure 3.3-13 shows two examples of a circuit configuration that uses a programmable logic controller (PLC) to turn control signal input [X1] to [X9], [FWD], or [REV] ON or OFF. In circuit (a), the slide switch is turned to SINK (factory default), whereas in circuit (b) it is turned to SOURCE.</p> <p>In circuit (a) below, short-circuiting or opening the transistor's open collector circuit in the PLC using an external power supply turns ON or OFF control signal [FWD], [REV], or [X1] to [X9]. When using this type of circuit, observe the following:</p> <ul style="list-style-type: none"> - Connect the + node of the external power supply (which should be isolated from the PLC's power) to terminal [PLC] of the inverter. - Do not connect terminal [CM] of the inverter to the common terminal of the PLC.  <p>(a) With the switch turned to SINK (factory default) (b) With the switch turned to SOURCE</p> | <p>Figure 3.3-13 Circuit Configuration Using a PLC</p> <p>For details about the slide switch setting, refer to Section 3.3.3.9 "Setting up the slide switches."</p> | |
| | Analog output | <p>[Ao1] Analog output 1</p> <p>[Ao2] Analog output 2</p> <p>[Ao3] Analog output 3</p> | |
| [M] | | Analog common | <p>Common for analog output signals ([Ao1], [Ao2] and [Ao3]). Electrically isolated from terminals [CM], [CMY] and [PGM].</p> |

Table 3.3-8 Symbols, Names and Functions of the Control Circuit Terminals (Continued)





| Classification | Symbol | Name | Functions | | | | | | | | | | | | | | |
|------------------------|------------------------------|--|---|------|--|------|-------------------|----------|-----|-----------|------|-----------------------|--|-------|------------------------|--|--------|
| Transistor output | [Y1] [Y2] [Y3] [Y4] | Transistor output 1 Transistor output 2 Transistor output 3 Transistor output 4 | <p>(1) Various signals such as "Inverter running," "Speed valid," and "Speed agreement" can be assigned to these terminals by setting Function codes E15 to E18. For details, refer to Chapter 4, Section 4.2 "Function Codes."</p> <p>(2) Function code E28 switches the logic value (1/0) for ON/OFF of the terminals between [Y1] to [Y4], and [CMY]. If the logic value for ON between [Y1] to [Y4] and [CMY] is 1 in the normal logic system, for example, OFF is 1 in the negative logic system and vice versa.</p> <p>(Transistor output circuit specification)</p>  <table border="1" data-bbox="991 593 1374 768"> <thead> <tr> <th colspan="2">Item</th> <th>Max.</th> </tr> </thead> <tbody> <tr> <td rowspan="2">Operation voltage</td> <td>ON level</td> <td>2 V</td> </tr> <tr> <td>OFF level</td> <td>27 V</td> </tr> <tr> <td colspan="2">Maximum current at ON</td> <td>50 mA</td> </tr> <tr> <td colspan="2">Leakage current at OFF</td> <td>0.1 mA</td> </tr> </tbody> </table> <p>Figure 3.3-14 Transistor Output Circuit</p> <p>Note - When a transistor output drives a control relay, connect a surge-absorbing diode across relay's coil terminals.</p> <p>- When any equipment or device connected to the transistor output needs to be supplied with DC power, feed the power (+24 VDC: allowable range: +22 to +27 VDC, 100 mA max.) through the [PLC] terminal. Short-circuit between the terminals [CMY] and [CM] in this case.</p> | Item | | Max. | Operation voltage | ON level | 2 V | OFF level | 27 V | Maximum current at ON | | 50 mA | Leakage current at OFF | | 0.1 mA |
| | Item | | Max. | | | | | | | | | | | | | | |
| Operation voltage | ON level | 2 V | | | | | | | | | | | | | | | |
| | OFF level | 27 V | | | | | | | | | | | | | | | |
| Maximum current at ON | | 50 mA | | | | | | | | | | | | | | | |
| Leakage current at OFF | | 0.1 mA | | | | | | | | | | | | | | | |
| | [CMY] | Transistor output common | <p>Common terminal for transistor output signals</p> <p>Electrically isolated from terminals [CM], [11], [M], and [PGM].</p> | | | | | | | | | | | | | | |
| | Tip | <p>■ Connecting programmable logic controller (PLC) to terminal [Y1], [Y2], [Y3] or [Y4]</p> <p>Figure 3.3-15 shows two examples of circuit connection between the transistor output of the inverter's control circuit and a PLC. In example (a), the input circuit of the PLC serves as a SINK for the control circuit output, whereas in example (b), it serves as a SOURCE for the output.</p> |  <p>(a) PLC serving as SINK</p> <p>(b) PLC serving as SOURCE</p> <p>Figure 3.3-15 Connecting PLC to Control Circuit</p> | | | | | | | | | | | | | | |

Table 3.3-8 Symbols, Names and Functions of the Control Circuit Terminals (Continued)

| Classification | Symbol | Name | Functions |
|-----------------|-----------------|---|--|
| Relay output | [Y5A/C] | General-purpose relay output | (1) Function code E19 selects a general-purpose relay contact output signal usable as well as the function of the transistor output terminal [Y1], [Y2], [Y3] or [Y4]. Contact rating: $250 \text{ VAC } 0.3 \text{ A, } \cos \phi = 0.3$, $48 \text{ VDC, } 0.5 \text{ A}$ (2) Function code E28 switches the normal/negative logic output applicable to the following two contact output modes: "Active ON" (Terminals [Y5A] and [Y5C] are closed (excited) if the signal is active.) and "Active OFF" (Terminals [Y5A] and [Y5C] are opened (non-excited) if the signal is active.) |
| | [30A/B/C] | Alarm relay output (for any error) | (1) Outputs a contact signal (SPDT) when a protective function has been activated to stop the motor. Contact rating: $250 \text{ VAC, } 0.3 \text{ A, } \cos \phi = 0.3$, $48 \text{ VDC, } 0.5 \text{ A}$ (2) Function code F36 switches the normal/negative logic output applicable to the following two contact output modes: "Active ON" (Terminals [30A] and [30C] are closed (excited) if the signal is active.) and "Active OFF" (Terminals [30A] and [30C] are opened (non-excited) if the signal is active.) |
| Communication | [DX+]/ [DX-] | RS-485 communications port (Terminals on control PCB) | Input/output terminals to transmit data through the RS-485 multipoint protocol between the inverter and a computer or other equipment such as a PLC. (For setting of the terminating resistor, refer to Section 3.3.3.9 "Setting up the slide switches.") |
| | USB connector | USB port (On the keypad) | A USB port connector (mini B) that connects an inverter to a computer. FRENIC-VG Loader (inverter support software*) running on the computer supports editing the function codes, transferring them to the inverter, verifying them, test-running an inverter and monitoring the inverter running status. * FRENIC-VG Loader (free version) is available as an install from the CD-ROM (that comes with the inverter as an accessory) or as a free download from our website at: http://www.fujielectric.com/products/inverter/download/ The free version supports editing, transferring and verifying of function codes and the traceback function. |
| Speed detection | [PA] [PB] | Pulse generator 2-phase signal input | The PG interface uses a complementary output mode. [PA]: Input terminal for A phase of the pulse generator [PB]: Input terminal B phase of the pulse generator When 12V power supply is in use: H level $\geq 9\text{V}$, L level $\leq 1.5\text{V}$ When 15V power supply is in use: H level $\geq 12\text{V}$, L level $\leq 1.5\text{V}$ Input pulse frequency: 100 kHz or below, Duty: 50 \pm 10% Wiring length (as a guide): 100 m or less (Note) False detection may occur due to noise. Make the wiring length as short as possible and take sufficient noise control measures. |
| | [PGP] | Pulse generator power supply | Power supply terminal for a pulse generator. The output voltage is switchable between 15V (factory default) and 12V with the output voltage switch SW6 on the control circuit PCB. Output: +15 VDC \pm 10% or +12 VDC \pm 10% Maximum current: 270 mA (For output voltage switch SW6, refer to Section 3.3.3.9 "Setting up the slide switches.") |
| | [PGM] | Common terminal | Common terminal for pulse generator power/signal. Electrically isolated from terminals [11], [M] and [CMY]. Not electrically isolated from terminal [CM], but not equivalent voltage. |

Table 3.3-8 Symbols, Names and Functions of the Control Circuit Terminals (Continued)

| Classification | Symbol | Name | Functions | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
|----------------------------------|--------------|---|--|-------|--|------|-------------------|----------|-----|-----------|---|------------------------------|--|-------|---------------|--|------|-------|--|------|------|-------------------|------------|--------|---|-----------|---|-----|-------------------------|--|---|-------|----------------------------------|--|---|--------|
| Speed detection | [FA] [FB] | Pulse generator output | <p>(1) This outputs pulse generator signals with frequency divided to 1/n (where, n is programmable with Function code E29).</p> <p>(2) Switchable between open collector and complementary (equivalent to the voltage on the [PGP] terminal) transistor outputs. Factory default: Open collector (For switching, refer to Section 3.3.3.9 "Setting up the slide switches.")</p> <p>Open collector</p>  <table border="1" data-bbox="989 560 1388 750"> <thead> <tr> <th colspan="2">Items</th> <th>Max.</th> </tr> </thead> <tbody> <tr> <td rowspan="2">Operating voltage</td> <td>ON level</td> <td>2 V</td> </tr> <tr> <td>OFF level</td> <td>Indefinite (depends on the receiver side)</td> </tr> <tr> <td colspan="2">Operating load current at ON</td> <td>15 mA</td> </tr> <tr> <td colspan="2">Rated voltage</td> <td>15 V</td> </tr> </tbody> </table> <p>Complementary</p>  <table border="1" data-bbox="989 862 1388 1041"> <thead> <tr> <th colspan="2">Items</th> <th>Min.</th> <th>Max.</th> </tr> </thead> <tbody> <tr> <td rowspan="2">Operating voltage</td> <td>High level</td> <td>PGP-3V</td> <td>-</td> </tr> <tr> <td>Low level</td> <td>-</td> <td>2 V</td> </tr> <tr> <td colspan="2">Operating current at ON</td> <td>-</td> <td>20 mA</td> </tr> <tr> <td colspan="2">Allowable leakage current at OFF</td> <td>-</td> <td>0.5 mA</td> </tr> </tbody> </table> <p style="text-align: center;">Figure 3.3-16 Pulse Output Circuit</p> | Items | | Max. | Operating voltage | ON level | 2 V | OFF level | Indefinite (depends on the receiver side) | Operating load current at ON | | 15 mA | Rated voltage | | 15 V | Items | | Min. | Max. | Operating voltage | High level | PGP-3V | - | Low level | - | 2 V | Operating current at ON | | - | 20 mA | Allowable leakage current at OFF | | - | 0.5 mA |
| | Items | | Max. | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| Operating voltage | ON level | 2 V | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | OFF level | Indefinite (depends on the receiver side) | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| Operating load current at ON | | 15 mA | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| Rated voltage | | 15 V | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| Items | | Min. | Max. | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| Operating voltage | High level | PGP-3V | - | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | Low level | - | 2 V | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| Operating current at ON | | - | 20 mA | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| Allowable leakage current at OFF | | - | 0.5 mA | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | [CM] | Pulse generator output common | Common terminal for pulse generator output [FA] and [FB]. | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| Temperature detection | [TH1] | NTC/PTC thermistor connection | Monitors the motor temperature with NTC or PTC thermistor. For a PTC thermistor, the motor overheat protection level can be specified with Function code E32. | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | [THC] | Common | Common terminal for NTC and PTC thermistors. Electrically isolated from terminals [CM], [PGM], and [CMY] | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |

■ Wiring for control circuit terminals

For FRN75VG1□-2□, FRN90VG1□-2□ and FRN132VG1□-4□ to FRN630VG1□-4□

- (1) As shown in Figure 3.3-17, route the control circuit wires along the left side panel to the outside of the inverter.
- (2) Secure those wires to the wiring support, using a cable tie (e.g., Insulok) with 3.8 mm or less in width and 1.5 mm or less in thickness.




Figure 3.3-17 Wiring Route and Fixing Position for the Control Circuit Wires



- Route the wiring of the control circuit terminals as far from the wiring of the main circuit as possible. Otherwise electric noise may cause malfunctions.
- Fix the control circuit wires with a cable tie inside the inverter to keep them away from the live parts of the main circuit (such as the terminal block of the main circuit).

3.3.3.9 Setting up the slide switches

| |
|--|
| WARNING |
| <p>Before changing the switches or touching the control circuit terminal symbol plate, turn OFF the power and wait at least five minutes for inverters of 22 kW or below, or at least ten minutes for those of 30 kW or above. Make sure that the LED monitor and charging lamp are turned OFF. Further, make sure, using a multimeter or a similar instrument, that the DC link bus voltage between the terminals P(+) and N(-) has dropped to the safe level (+25 VDC or below).</p> <p>An electric shock may result if this warning is not heeded as there may be some residual electric charge in the DC bus capacitor even after the power has been turned OFF.</p> |

Switching the slide switches located on the control PCB allows you to customize the operation mode of the analog output terminals, digital I/O terminals, and communications ports. The locations of those switches are shown in Figure 3.3-18 "Location of the Slide Switches on the Control PCB."

To access the slide switches, remove the front cover so that you can see the control PCB. For inverters with a capacity of 30 kW or above, open also the keypad enclosure.

For details on how to remove the front cover and how to open and close the keypad enclosure, refer to Section 3.3.3.1 "Removing and mounting the front cover and the wiring guide."

Table 3.3-9 lists function of each slide switch.

Table 3.3-9 Function of Each Slide Switch

| Switch | Function | | | | | | | | | |
|---|---|------------------------|------------------------|---------------------------------|---|------------------------|------------|----------------------|---|---|
| SW1 | Switches the service mode of the digital input terminals between SINK and SOURCE. <ul style="list-style-type: none"> ▪ This switches the input mode of digital input terminals [X1] to [X9], [FWD] and [REV] to be used as the SINK or SOURCE mode. ▪ Factory default: SINK | | | | | | | | | |
| SW2 | Reserved for particular manufacturers. | | | | | | | | | |
| SW3 | Switches the input mode of the analog input terminal [Ai2] between voltage and current. <table border="1" style="width: 100%; border-collapse: collapse; margin-top: 5px;"> <tr> <td style="width: 60%;">Input form</td> <td style="width: 40%;">SW3</td> </tr> <tr> <td>Voltage input (Factory default)</td> <td>V position</td> </tr> <tr> <td>Current input</td> <td>I position</td> </tr> </table> | Input form | SW3 | Voltage input (Factory default) | V position | Current input | I position | | | |
| Input form | SW3 | | | | | | | | | |
| Voltage input (Factory default) | V position | | | | | | | | | |
| Current input | I position | | | | | | | | | |
| SW4 | Switches the terminating resistor of RS-485 communications port 2 on the terminal block ON and OFF. <ul style="list-style-type: none"> ▪ If the inverter is connected to the RS-485 communications network as a terminating device, turn SW4 to ON. | | | | | | | | | |
| SW5 | Reserved for particular manufacturers. | | | | | | | | | |
| SW6 | Switches the output voltage of terminal [PGP] between 12 V and 15 V. Select the voltage level that matches the power voltage of the pulse generator to be connected. <table border="1" style="width: 100%; border-collapse: collapse; margin-top: 5px;"> <tr> <td style="width: 60%;">Output voltage</td> <td style="width: 40%;">SW6</td> </tr> <tr> <td>12 V</td> <td>12 V</td> </tr> <tr> <td>15 V (Factory default)</td> <td>15 V</td> </tr> </table> | Output voltage | SW6 | 12 V | 12 V | 15 V (Factory default) | 15 V | | | |
| Output voltage | SW6 | | | | | | | | | |
| 12 V | 12 V | | | | | | | | | |
| 15 V (Factory default) | 15 V | | | | | | | | | |
| SW7 SW8 | Switch the output mode of terminals [FA] and [FB] between open collector output and complementary output. <table border="1" style="width: 100%; border-collapse: collapse; margin-top: 5px;"> <tr> <td style="width: 50%;">Output form</td> <td style="width: 25%;">SW7 (Terminal [FA])</td> <td style="width: 25%;">SW8 (Terminal [FB])</td> </tr> <tr> <td>Open collector output (Factory default)</td> <td>1</td> <td>1</td> </tr> <tr> <td>Complementary output</td> <td>2</td> <td>2</td> </tr> </table> | Output form | SW7 (Terminal [FA]) | SW8 (Terminal [FB]) | Open collector output (Factory default) | 1 | 1 | Complementary output | 2 | 2 |
| Output form | SW7 (Terminal [FA]) | SW8 (Terminal [FB]) | | | | | | | | |
| Open collector output (Factory default) | 1 | 1 | | | | | | | | |
| Complementary output | 2 | 2 | | | | | | | | |

Figure 3.3-18 shows the location of slide switches on the control PCB for the input/output terminal configuration.




Figure 3.3-18 Location of the Slide Switches on the Control PCB

Switch Configuration and Factory Defaults

| | SW1 | SW2 | SW3 | SW4 | SW5 | SW6 | SW7 SW8 |
|-----------------|--------------|-----|---------|-----------|-------|-----|------------|
| Factory default | SINK ← | | V ← | OFF ← | ← | 15V | 1 |
| --- | → SOURCE | | → I | → ON | | 12V | 2 |

Note To move a switch slider, use a tool with a narrow tip (e.g., a tip of tweezers). Be careful not to touch other electronic parts, etc. If the slider is in an ambiguous position, the circuit is unclear whether it is turned ON or OFF and the digital input remains in an undefined state. Be sure to place the slider so that it contacts either side of the switch.

SW2 and SW5 are reserved for particular manufacturers. Do not access them.

3.3.4 Mounting and connecting a keypad

3.3.4.1 Parts required for connection

To mount a keypad on a place other than an inverter, the parts listed below are needed.

| Parts name | Model | Remarks |
|--------------------------|------------------------|---|
| Extension cable (Note 1) | CB-5S, CB-3S and CB-1S | 3 types available in length of 5 m, 3 m, and 1 m. |
| Fixing screw | M3 × □ (Note 2) | Two screws needed. (To be provided by the customer) |

(Note 1) When using an off-the-shelf LAN cable, use a 10BASE-T/100BASE-TX straight type cable compliant with US ANSI/TIA/EIA-568A Category 5. (20 m or less)

Recommended LAN cable

Manufacturer: Sanwa Supply Inc.

Model: KB-10T5-01K (1 m)

KB-STP-01K: (1 m) (Shielded LAN cable to make the inverter compliant with the EMC Directive)

(Note 2) When mounting on a panel wall, use the screws with a length suitable for the wall thickness.

3.3.4.2 Mounting procedure

You can install and/or use the keypad in one of the following three ways:

- Mounting it directly on the inverter (See Figure 3.3-19 (a), (b).)
- Mounting it on the panel (See Figure 3.3-20.)
- Using it remotely in your hand (See Figure 3.3-21.)




Figure 3.3-19 Mounting the Keypad Directly on the Inverter




Figure 3.3-20 Mounting the Keypad on the Panel




Figure 3.3-21 Using the Keypad Remotely in Your Hand

After completion of wiring, mount the keypad using the following procedure. Make sure that the inverter power is shut down beforehand.

■ **Removing and mounting the keypad from/onto the inverter**

- (1) Remove the keypad by pulling it toward you with the hook held down as directed by the arrows in Figure 3.3-22.




Figure 3.3-22 Removing a Keypad

- (2) Put the keypad in the original slot while engaging its bottom latches with the holes (as shown below), and push it onto the case of the inverter (arrow ②) while holding it downward (against the terminal block cover) (arrow ①).




Figure 3.3-23 Mounting the Keypad

■ Mounting the keypad on the panel

- (1) Cut the panel out for a single square area and perforate two screw holes on the panel wall as shown in Figure 3.3-24.




Figure 3.3-24 Location of Screw Holes and Dimension of Panel Cutout

- (2) Mount the keypad on the panel wall with 2 screws as shown below. (Recommended tightening torque: 0.7 N•m)




Figure 3.3-25 Mounting the Keypad

- (3) Using a remote operation extension cable or a LAN cable, interconnect the keypad and the inverter (insert one end of the cable into the RS-485 port with RJ-45 connector on the keypad and the other end into that on the inverter) (See Figure 3.3-26).




Figure 3.3-26 Connecting the Keypad to the Inverter with Remote Operation Extension Cable or an Off-the-shelf LAN Cable

CAUTION

- The RJ-45 connector on the inverter is exclusive to communication via a touch panel. With the RJ-45 connector, neither RS-485 communication nor connection with FRENIC-VG Loader is possible.
- Do not connect the inverter to a LAN port of a computer, Ethernet hub, or telephone line. Doing so may damage the inverter or devices connected.

A fire or accident could occur.

■ Using the keypad remotely in hand

Follow step (3) of "Mounting the keypad on the panel" above.

3.3.5 USB connectivity

At the right side of the keypad mounting place, a USB port (mini B connector) is provided. To connect a USB cable, open the USB port cover as shown below.




Figure 3.3-27 Connecting a USB Cable

Connecting the inverter to a PC with a USB cable enables remote control from FRENIC-VG Loader. On the PC running FRENIC-VG Loader, it is possible to edit, check and manage the inverter's function code data and monitor the real-time data and the running/alarm status of the inverter.

⚠ CAUTION

Connector located beneath the USB connector is provided for particular manufacturers. Do not access it.

Otherwise, a fire or accident could occur.

3.4 Operation Using the Keypad

3.4.1 Names and functions of keypad components

The keypad allows you to start and stop the motor, view various data including maintenance information and alarm information, configure function codes, monitor I/O signal status, copy data, and calculate the load factor.




















Table 3.4-1 Overview of Keypad Functions

| Item | Monitors and Keys | Functions |
|------------------|---|--|
| Monitors |  | <p>Five-digit, 7-segment LED monitor which displays the following according to the operation modes:</p> <ul style="list-style-type: none"> ■ In Running mode: Running status information (e.g., detected speed, speed command, and torque command) ■ In Programming mode: Same as above. ■ In Alarm mode: Alarm code, which identifies the cause of alarm when the protective function is activated. |
| |  | <p>LCD monitor which displays the following according to the operation modes:</p> <ul style="list-style-type: none"> ■ In Running mode: Running status information ■ In Programming mode: Menus, function codes and their data ■ In Alarm mode: Alarm information, which identifies the cause of an alarm when the protective function is activated. |
| | Indicator indexes | <p>In Running mode, these indexes show the unit of the number displayed on the 7-segment LED monitor and the running status information on the LCD monitor. For details, see the next page.</p> |
| Programming keys |  | Switches the operation modes of the inverter. |
| |  | Shifts the cursor to the right for entry of a numerical value. |
| |  | <p>Pressing this key after removing the cause of an alarm switches the inverter to Running mode.</p> <p>This key is used to reset settings or screen transition.</p> |
| |  | UP and DOWN keys, which are used to select the setting items or change function code data. |
| |  | <p>Function/Data key, which switches the operation mode as follows:</p> <ul style="list-style-type: none"> ■ In Running mode: Pressing this key switches the information to be displayed concerning the status of the inverter (detected speed, speed command, torque command, etc.). ■ In Programming mode: Pressing this key displays the function code and establishes the newly entered data. ■ In Alarm mode: Pressing this key displays the details of the problem indicated by the alarm code that has come up on the LED monitor. |
| |  | <p>This simultaneous keying toggles between the ordinary running mode and jogging mode.</p> <p>The current mode appears on the corresponding indicator.</p> |
| |  | <p>This simultaneous keying toggles between the remote and local modes.</p> <p>The current mode appears on the corresponding indicator.</p> |
| |  | <p>This simultaneous keying jumps the cursor to the preceding/following function code group (F to M) in selecting a function code.</p> <p>On the function code data modification screens: This simultaneous keying displays the initial data value.</p> <p>On the running status monitor, I/O checking, and maintenance info. screens: This simultaneous keying holds the displayed data.</p> |
| Operation keys |  | Starts running the motor in the forward rotation. |
| |  | Starts running the motor in the reverse rotation. |
| |  | Stops the motor. |
| |  | Switches the screen to the operation guide display prepared for each operation mode or to the menu function guide display. |
| LED lamp |  | Lights when the inverter is running. |

Details of Indicator Indexes



| Type | Item | Description (information, condition, status) |
|-------------------------------|-------|---|
| Unit of number on LED monitor | Hz | Output frequency |
| | A | Output current |
| | V | Output voltage |
| | % | Torque command, calculated torque, and load factor |
| | kW | Input power and motor output |
| | r/min | Preset and actual (detected) motor speeds |
| | m/min | Preset and actual line speeds |
| | X10 | Data exceeding 99,999 |
| | min | Not used. |
| | sec | Not used. |
| | VG5 | Not used. |
| Running status | FWD | Running in forward rotation |
| | REV | Running in reverse rotation |
| | STOP | No output frequency |
| Run command source | REM | Remote mode (Run command and speed command sources selected by F02 and F01) (In the remote mode, a run command entered via the communications link takes effect. This indicator goes off when H30 = 2 or 3.) |
| | LOC | Local mode (Run command and speed command sources from the keypad, independent of the setting of F02 and F01.) |
| | COMM | Via communications link |
| | JOG | Jogging mode |
| | HAND | Via keypad This indicator lights also: - in local mode or - in remote mode and when H30 = 0 and F02 = 0 |

3.4.2 Overview of operation modes

The FRENIC-VG features the following three operation modes.

Table 3.4-2 Operation Modes

| Mode | Description |
|------------------|--|
| Running Mode | This mode allows you to specify run/stop commands in regular operation. It is also possible to monitor the running status in real time. If a light alarm occurs, the $\text{L} - \text{AL}$ * appears on the LED monitor. |
| Programming Mode | This mode allows you to configure function code data and check a variety of information relating to the inverter status and maintenance. |
| Alarm Mode | If an alarm condition arises, the inverter automatically enters the Alarm mode in which you can view the corresponding alarm code* and its related information on the LED and LCD monitors. |

* Alarm code that represents the cause(s) of the alarm(s) that has been triggered by the protective function. For details, refer to Chapter 2, Section 2.5 "Protective Functions."

Figure 3.4-1 shows the status transition of the inverter between these three operation modes.




Figure 3.4-1 Status Transition between Operation Modes

3.4.3 Running mode

When the inverter is turned ON, it automatically enters Running mode in which you can:

- [1] Configure speed commands,
- [2] Run or stop the motor,
- [3] Monitor the running status,
- [4] Jog (inch) the motor, and
- [5] Monitor light alarms.

3.4.3.1 Configuring the speed command

Using \odot and \ominus keys (F01 = 0 (factory default))

- (1) Set function code F01 at "0". This cannot be done when the keypad is in Programming mode or Alarm mode. To enable speed setting using the \odot and \ominus keys, first switch the keypad to Running mode.
- (2) Press the \odot or \ominus key. The lowest digit on the LED monitor blinks. The 7-segment LED monitor displays the speed command and the LCD monitor displays the related information including the operation guide, as shown below.
- (3) Press the \odot or \ominus key again to change the frequency command. The new setting can be saved into the inverter's internal memory.

When the speed command source is other than digital setting, the LCD monitor displays the following.




Table 3.4-3 lists the available command sources and their symbols.

Table 3.4-3 Available Command Sources

| Symbol | Command source | Symbol | Command source | Symbol | Command source |
|--------|---|--------|---|----------|--|
| HAND | Keypad | DIB | DIB card | PID-HAND | PID keypad command |
| 12 ± | Voltage input on terminal [12] (with polarity) | MULTI | Terminal command SS8, SS4, SS2, SSI ("Select multistep speed") | JOG | Jogging speed |
| 12 | Voltage input on terminal [12] (without polarity) | LINK | Terminal command LE ("Enable communications link") H30: Communications Link Function (Link operation) | LOADER | Inverter support software "FRENIC-VG Loader" |
| U/D1 | UP/DOWN control (Default = 0) | UPAC | UPAC SW1 (Speed command 1): Enable | AI-V | Voltage input on analog input terminal N-REFV |
| U/D2 | UP/DOWN control (Default = Previous value) | PTI | Terminal command SYN ("Synchronous operation command (pulse train)": Enable | LOCAL | Keypad in local mode |
| U/D3 | UP/DOWN control (Default = CRP1, 2) | LOCK | Terminal command LOCK ("Servo-lock command") | AI-C | Current input on analog input terminal N-REFC |
| DIA | DIA card | PID-AI | PID analog input command Ai | | |

3.4.3.2 Running or stopping the motor

By factory default, pressing the **FWD** key starts running the motor in the forward direction and pressing the **REV** key, in the reverse direction. Pressing the **STOP** key decelerates the motor to stop. The keypad operation is possible only in Running and Programming modes.




Figure 3.4-2 Rotation Direction of Motor

Note) The rotation direction of IEC-compliant motors is opposite to the one shown above.

■ Displaying the running status on the LCD monitor

(1) When function code F57 (LCD monitor, Item selection) = 0

The LCD monitor displays the current running status, the run command, and the date & time (calendar clock)*. (The upper indicators show the unit of values shown on the LED monitor, and the lower indicators, the running status and run command source.)

* If no backup battery is loaded (option for inverters of 22 kW or below), turning the power OFF resets the calendar clock.




Figure 3.4-3 Display of Running Status


The running status and the run command are displayed as listed below.

Table 3.4-4 Running Status and Run Commands

| Running mode display items | Meaning |
|----------------------------|--|
| Running status | RUN: The inverter is running. STOP: No run command is given and the inverter is stopped. JOG: The inverter is jogging. |
| Run commands | FWD: Run forward command entered. REV: Run reverse command entered. Blank: The inverter is stopped. |

- (2) When function code F57 (LCD monitor, Item selection) = 1

The LCD monitor displays the motor speed, output current, and torque command in a bar chart. (The upper indicators show the unit of the value shown on the LED monitor, and the lower indicators, the running status and run command source.)



The full scale (maximum value) for each parameter is as follows:

- Motor speed: Maximum frequency
- Output current: 200% of motor rating
- Torque command: 200% of motor rating

Figure 3.4-4 Bar Chart

3.4.3.3 Monitoring the running status on the LED monitor

The items listed below can be monitored on the 7-segment LED monitor. Immediately after the power is turned ON, the monitor item specified by function code F55 is displayed.


Pressing the  key in Running mode switches between monitor items in the sequence shown in Table 3.4-5.

Table 3.4-5 Monitor Items

| Page # | LED monitor | | Digital setting mode | | Unit | Resolution |
|--------|--|----------------------|--------------------------------|------------------------------|------------------------------|---------------------------------|
| | Running | Stopped (F56 = 0) *8 | Digital speed setting | PID command | | |
| 0 | MOTOR SPEED 1 *1 | REFERENCE SPEED *1*9 | Speed command from keypad | PID command from keypad | r/min | 0 to 9999: resolution 1 |
| 1 | REFERENCE SPEED 4 *1 | | | | r/min | 10000 to 30000: 10 |
| 2 | OUTPUT FREQUENCY | | | | Hz | 0.1 to 400.0: resolution 0.1 |
| 3 | REFERENCE TORQUE CURRENT | | | | % | 1% |
| 4 | REFERENCE MOTOR TORQUE | | | | % | 1% |
| 5 | CAL MOTOR TORQUE *2 | | | | % | 1% |
| 6 | MOTOR OUTPUT POWER (kW) | | | | F60 = 0 (kW) F60 = 1 (HP) | 0.01 to 99.99: 0.01 |
| 7 | OUTPUT CURRENT | | | | A | 100.0 to 999.9: 0.1 |
| 8 | OUTPUT VOLTAGE | | | | V | 1000 or above : 1 |
| 9 | DC LINK VOLTAGE | | | | V | 1 V |
| 10 | REFERENCE MAGNETIC FLUX | | | | % | 1% |
| 11 | CAL MAGNETIC FLUX | | | | % | 1% |
| 12 | MOTOR TEMPERATURE *3 | | - | 1 | | |
| 13 | LOAD SHAFT SPEED *4 | LOAD SHAFT SPEED *4 | Load speed command from keypad | PID command from keypad | r/min | 1 |
| 14 | LINE SPEED *4 | LINE SPEED *4 | | | m/min | 1 |
| 15 | Ai (I2) ADJUSTMENT | | | | % | 0.1% |
| 16 | Ai (Ai1) ADJUSTMENT | | | | % | 0.1% |
| 17 | Ai (Ai2) ADJUSTMENT | | | | % | 0.1% |
| 18 | Ai (Ai3) ADJUSTMENT *5 | | | | % | 0.1% |
| 19 | Ai (Ai4) ADJUSTMENT *5 | | | | % | 0.1% |
| 20 | PID REFERENCE *6 | | | | | 0.00 to ±9.99: 0.01 |
| 21 | PID FEEDBACK *6 | | | | | 10.0 to ±99.9: 0.1 |
| 22 | PID OUTPUT *6 | | | | | 100 to ±999: 1 |
| 23 | OPTION MONITOR 1 (hex.) *7 | | Speed command from keypad | | in hexadecimal | 1 |
| 24 | OPTION MONITOR 2 (hex.) *7 | | | | in hexadecimal | 1 |
| 25 | OPTION MONITOR 3 (dec.) *7 | | | in decimal | 1, x 10 | |
| 26 | OPTION MONITOR 4 (dec.) *7 | | | in decimal | 1, x 10 | |
| 27 | OPTION MONITOR 5 (dec.) *7 | | | in decimal | 1, x 10 | |
| 28 | OPTION MONITOR 6 (dec.) *7 | | | in decimal | 1, x 10 | |
| 29 | - | | | - | - | |
| 30 | LOAD FACTOR *1 | | | % | 1% | |
| 31 | INPUT POWER | | | F60 = 0 (kW) F60 = 1 (HP) | 0.01 to 99.99: 0.01 | |
| 32 | WATT-HOUR (Display value = Input watt-hour (kWh)/100) | | | kWh | 100.0 to 999.9: 0.1 | |
| | | | | | 1000 or above : 1 | |
| | | | | | 0.1 | |

*1 Shown as an absolute value.

*2 Under vector control, the inverter outputs the torque value to which the compensation for motor loss (iron loss) is added.

*3 "---" appears when no NTC thermistor is used.

*4 Limited to a maximum of 60,000 in display.


*5 Not shown when no AIO option is mounted.

*6 Not shown when the PID control is disabled.

*7 Shown or not shown, depending upon application. Option monitors 5 and 6 have a sign; option monitors 3 and 4 have not.

*8 For switching the display when the inverter is stopped, refer to the description of function code F56.

*9 For the reference speed monitor to be shown when the inverter is stopped, refer to the block diagram given in Chapter 4, Section 4.1.2 "Speed Command Selection Section."

The LCD monitor (given below) shows information related to the item shown on the LED monitor. The monitor item on the LED monitor can be switched by pressing the  key.










Figure 3.4-5 LCD Monitor Sample Detailed for the LED Monitor Item

3.4.3.4 Jogging (inching) the motor

To start jogging operation, perform the following procedure.

- (1) Make the inverter ready to jog with the steps below.
 - 1) Switch the inverter to Running mode.
 - 2) Press the " +  keys" simultaneously. The lower indicator above the "JOG" index comes ON.
- (2) Jog the motor.
While the  or  key is held down, the motor continues jogging. Releasing the key decelerates the motor to stop.
- (3) Make the inverter exit from the ready-to-jog state and return to the normal operation state.
Press the " +  keys" simultaneously. The lower indicator above the "JOG" index goes OFF.




Figure 3.4-6 Display of Jogging Mode

3.4.3.5 Monitoring light alarms

The inverter identifies abnormal states in two categories--Heavy alarm and Light alarm. If the former occurs, the inverter immediately trips; if the latter occurs, the inverter shows the $\angle -\overline{FL}$ on the LED monitor and blinks the "L-ALARM" indication in the operation guide area on the LCD monitor but it continues to run without tripping.

Which abnormal states are categorized as a light alarm ("Light alarm" object) should be defined with function codes H106 to H111 beforehand.

Assigning the *L-ALM* signal to any one of the general-purpose, digital output terminals with any of function codes E15 to E27 (data = 57) enables the inverter to output the *L-ALM* signal on that terminal upon occurrence of a light alarm.




Figure 3.4-7 Display of Light Alarm


For details of the light alarm factors, refer to Chapter 13 "TROUBLESHOOTING."

How to check a light alarm factor


If a light alarm occurs, $\angle -\overline{FL}$ appears on the LED monitor. To check the current light alarm factor, switch to Programming mode by pressing the (PRG) key and select LALM1 on Menu #5 "Maintenance Information." For details of the menu transition of the maintenance information, refer to Section 3.4.4.6 "Reading maintenance information."

It is also possible to check the factors of the last three light alarms by selecting LALM2 (last) to LALM4 (3rd last).

■ How to remove the current light alarm

After checking the current light alarm, to switch the LED monitor from the $L-FIL$ indication back to the running status display, press the  key in Running mode. To reset a light alarm via the communications link, use an alarm reset signal.

If the light alarm factor has been removed, the "L-ALARM" disappears and the *L-ALM* output signal turns OFF. If not (e.g. DC fan lock), the $L-FIL$ on the LED monitor disappears so that normal monitoring becomes available, but the "L-ALARM" remains displayed on the LCD monitor (as shown below) and the *L-ALM* output signal remains ON.



3.4.4 Programming mode


Programming mode allows you to set and check function code data and monitor maintenance information and input/output (I/O) signal status. The functions can be easily selected with a menu-driven system. Table 3.4-6 lists menus available in Programming mode.

Table 3.4-6 Menus Available in Programming Mode

| Menu # | Menu | Used to: | Refer to Section: |
|--------|--|---|-------------------|
| 0 | Selecting language (LANGUAGE) | Change the display language on the LCD monitor. | 3.4.4.1 |
| 1 | Configuring function codes (DATA SET) | Display and change the data of the function code selected. | 3.4.4.2 |
| 2 | Checking function code data (DATA CHECK) | Display a function code and its data on the same screen. Also this menu is used to change the function code data or check whether the data has been changed from the factory default. | 3.4.4.3 |
| 3 | Monitoring the running status (OPR MNTR) | Display the running information required for maintenance or test running. | 3.4.4.4 |
| 4 | Checking I/O signal status (I/O CHECK) | Display external interface information. | 3.4.4.5 |
| 5 | Reading maintenance information (MAINTENANCE) | Display maintenance information including cumulative run time. | 3.4.4.6 |
| 6 | Measuring load factor (LOAD FCTR) | Measure the maximum output current, average output current, and average braking power. | 3.4.4.7 |
| 7 | Reading alarm information *1 (ALM INF) | Display recent four alarm codes. Also this menu is used to view the information on the running status at the time the alarm occurred. | 3.4.4.8 |
| 8 | Viewing causes of alarm (ALM CAUSE) | Display the cause of the alarm. | 3.4.4.9 |
| 9 | Reading communications information (COMM INFO) | Not supported. | - |
| 10 | Copying data (DATA COPY) | Read or write function code data, as well as verifying it. | 3.4.4.10 |
| 11 | Checking changed function codes (CHANGES) | Display only the function code data that has been changed from the factory default. | 3.4.4.11 |
| 12 | Setting the calendar clock (DATE/TIME) | Display/hide the date and time and adjust the display format and data. | 3.4.4.12 |
| 13 | Compatibility with conventional inverter models (FORMER INV) | Not supported. | - |
| 14 | Limiting function codes to be displayed (LIMITED FC) | <ul style="list-style-type: none"> • Select whether to display all function codes or limited ones (selected in Loader). • Cancel the directory structure of function codes. | 3.4.4.13 |

*1 Alarm information will not be saved when only the auxiliary power input for the control circuit is turned on.

The screen transition and hierarchy structure in Running and Programming modes are shown below.



* If the screen system is password-protected, no menu can be selected until you enter the password.

■ Menu screen

```

0. LANGUAGE
1. DATA SET
2. DATA CHECK
3. OPR MNTR
ΛV→MENU SHIFT▼
    
```

Pressing the (PRG) key in Running mode calls up the menu screen.

Select the target menu by moving the cursor (flashing rectangle) with (▲/▼) key.

■ Configuring function code data

Figure 3.4-8 shows the LCD screen transition for Menu #0 "DATA SET."

A hierarchy exists among those screens that are shifted in the order of "Menu screen," "List of function code groups," and "List of function codes."

On the modification screen of the target function code, you can modify or check its data.





Figure 3.4-8 Configuration of Screens for "DATA SET"


■ Screen samples for changing function code data

The "list of function codes" shows function codes, their names, and operation guides.



The "function code data modification screen" shows the function code, its name, its data (before and after change), allowable entry range, and operation guides.

<Before change>



Function code # and name


*: Function code that has been changed from factory default

Data

Allowable entry range

Operation guide

<Changing data>



Data before change

Data being changed

Figure 3.4-9 Screen Samples for Changing Function Code Data

Simultaneous keying of "Ⓞ + Ⓜ" keys" switches the lower portion of the screen from the allowable entry range to the factory default. The same simultaneous keying switches it back to the allowable entry range.

A function code consists of an alphabet denoting a function code group and numerals.

Table 3.4-7 Function Code List

| Function Code Group | Function | Description |
|---|--|--|
| F codes (Fundamental functions) | Fundamental functions | Functions to be used for basic motor running |
| E codes (Extension terminal functions) | Terminal functions | Functions concerning the selection of operation of the control circuit terminals; Functions concerning the display on the LED monitor |
| C codes (Control functions of frequency) | Control functions | Functions associated with speed settings |
| P codes (Motor 1 parameters) | Motor 1 parameters | Functions for configuring characteristics parameters (such as capacity) of the 1st motor |
| H codes (High performance functions) | High-level functions | Highly added-value functions; Functions for sophisticated control |
| A codes (Motor 2, 3 parameters) | Motor 2 parameters Motor 3 parameters | Functions for configuring characteristics parameters (such as capacity) of the 2nd or 3rd motor |
| o codes (Option functions) | Optional functions | Functions concerning optional features (The o codes are displayed only when the corresponding option is mounted on the inverter.) |
| L codes (Lift functions) | Vertical carrier machine functions | Functions to be used for vertical carrier machines |
| U codes (User functions) | User-defined functions | Functions to be used for UPAC option cards, etc. |
| SF code (Safety functions) | Safety functions | Functions concerning the safety card OPC-VG1-SAFE |
| S codes (Command functions) | Command data | These function codes can be modified via the integrated RS-485 interface or fieldbus options (e.g., T-Link, SX-bus). The S fields are write-only and the M fields, read-only. |
| M codes (Monitor functions) | Monitor data | |

■ Function codes requiring simultaneous keying

To modify the data for function code F00 (Data protection), H01 (Auto-tuning), H02 (Save All function), H03 (Data initialization), H142 (Mock alarm), L01 (Password data 1) or L02 (Password data 2), simultaneous keying of "STOP + ⏏ keys" or "STOP + ⏏ keys" is required.

■ Changing, validating, and saving function code data when the invert is running


Some function codes can be modified while the inverter is running, whereas others cannot. Further, depending on the function code, modifications may or may not become effective immediately. For details, refer to the "Change when running" column in Chapter 4, Section 4.2.3.

■ Keypad directory structure

The keypad has a directory structure that includes the related function codes in a directory to make it easy to select a target function code from many function codes.

For example, function codes C01 to C04 are all related with the mechanical resonance point of the load and treated as the same function so that C02 to C04 are not located in the parent directory. At the right of C01, "→" appears indicating that C01 has a child directory. To access the child directory, move the cursor to that function code using the ⏏ and ⏏ keys and then press the ⏏ or ⏏ key.


An example of selecting a function code with a child directory



Jumping by function code group


To call up a function code in a different group (E to M), press the $\text{SHIFT} \leftarrow$ and UP keys or $\text{SHIFT} \rightarrow$ and DOWN keys simultaneously to jump to the previous or next function code group.

In the case of a function code group having 100 or more function codes, this function jumps function codes in units of 100. (For example, F00 \Rightarrow E01 \Rightarrow E101 \Rightarrow ...)



3.4.4.1 Selecting language -- Menu #0 "LANGUAGE"

Menu #0 "LANGUAGE" in Programming mode is used to select the display language from a choice of four languages (English, Japanese, Chinese and Korean) on the LCD monitor.



To display this menu screen, press the PRG key in Running mode to switch to Programming mode.

Move the cursor at the left of the screen to "0. LANGUAGE" using the \uparrow and \downarrow keys. Then press the F.FUNC. DATA key to switch to the language selection screen.

Move the pointer \rightarrow to the desired language using the \uparrow and \downarrow keys.


Press F.FUNC. DATA key to establish the selected language.

After a second, the screen automatically switches back to the submenu.

3.4.4.2 Configuring function codes -- Menu #1 "DATA SET"

Menu #1 "DATA SET" in Programming mode is used to configure function codes.

This section gives a description of the basic key operation, following the example of the data changing flow shown below. This example shows how to change F03 data (M1 maximum speed) from 1500 r/min to 1200 r/min.



To display this menu screen, press the (PRG) key in Running mode to switch to Programming mode. Move the cursor (flashing rectangle) at the left of the screen to "1. DATA SET" using the (↑) and (↓) keys. Then press the (F.FUNC DATA) key to switch to the function code configuration screen.

Function code groups (F, E, C, P...) appear.

Move the cursor to the desired function code group using the (↑) and (↓) keys.

Move the cursor to the desired function code using the (↑) and (↓) keys.


At the right of F03, "→" appears indicating that F03 has a child directory. To access the child directory, move the cursor to that function code using the (↑) and (↓) keys and then press the (F.FUNC DATA) or (SHIFT) key.



Press the (F.FUNC DATA) key to move to the lower directory.


Press the (F.FUNC DATA) key to establish the desired function code.

Press the (SHIFT) key to move the cursor from the units place to the ten-thousands place.

Press the (SHIFT) key to move the cursor from the ten-thousands place to the hundreds place.



Change the function code data using the  and  keys.
 (In this example, change from 1500 r/min to 1200 r/min.)

Press the  key to establish the function code data.


3.4.4.3 Checking function code data -- Menu #2 "DATA CHECK"

Menu #2 "DATA CHECK" in Programming mode is used to check function codes (together with their data) that have been changed. The function codes whose data have been changed from factory defaults are marked with *.

This section gives a description of the basic key operation, following the example of the data checking flow shown below. This example shows how to change F03 data (M1 maximum speed) from 1500 r/min to 1200 r/min.

In any of the following cases, change of function code data will be saved only into the volatile memory (RAM) and not be saved into the non-volatile memory. Such data is displayed with white letters on black background.

- After tuning, the All Save function is not performed ($H02 \neq 1$).
- After changing function code data via the communications link, the All Save function is not specified ($H02 \neq 1$).
- When terminal command *LU-CCL* ("Cancel undervoltage alarm") on any X terminal is enabled, function code data is changed.



To display this menu screen, press the PRG key in Running mode to switch to Programming mode. Move the cursor (flashing rectangle) at the left of the screen to "2. DATA CHECK" using the \uparrow and \downarrow keys. Then press the F.FUNC DATA key to switch to the function code configuration screen.

Function code groups (F, E, C, P...) appear.

Move the cursor to the desired function code group using the \uparrow and \downarrow keys.

The function codes whose data has been changed from factory defaults are marked with an asterisk (*).


Move the cursor to the desired function code using the \uparrow and \downarrow keys.


At the right of F03, \rightarrow appears indicating that F03 has a child directory. To access the child directory, move the cursor to that function code using the \uparrow and \downarrow keys and then press the F.FUNC DATA or SHIFT key.

Press the F.FUNC DATA key to move to the lower directory.

Press F.FUNC DATA key to establish the desired function code.

Press the SHIFT key to move the changeable digit place (blinking), then change the function code data using the \uparrow and \downarrow keys.




Press  key to establish the function code data.

3.4.4.4 Monitoring the running status -- Menu #3 "OPR MNTR"

Menu #3 "OPR MNTR" in Programming mode is used to check the running status during maintenance and test running.

Simultaneous keying of the $\text{SHIFT} + \text{HELP}$ keys holds the displayed data. The same simultaneous keying again reverts to the normal display. When the display is in the hold state, the "DATA HOLD" is shown at the bottom of the screen.







Table 3.4-8 Running Status Items

| | Symbol | Item | Description |
|----------|--|-------------------------------|--|
| (1) | HD | Current rating | HD (High Duty) mode selected (F80 = 0, 2) |
| | MD | | MD (Medium Duty) mode selected (F80 = 3) |
| | LD | | LD (Low Duty) mode selected (F80 = 1) |
| (2) | HAND | Speed command source | Keypad |
| | 12± | | Voltage input on terminal [12] (with polarity) |
| | 12 | | Voltage input on terminal [12] (without polarity) |
| | U/D1 | | UP/DOWN control (Default = 0) |
| | U/D2 | | UP/DOWN control (Default = Previous value) |
| | U/D3 | | UP/DOWN control (Default = CPR1, 2) |
| | MULTI | | Terminal command <i>SS8</i> , <i>SS4</i> , <i>SS2</i> , <i>SSI</i> ("Select multistep speed") |
| | LINK | | Terminal command <i>LE</i> ("Enable communications link via RS-485 or fieldbus") H30: Communications Link Function (Mode selection) |
| | PTI | | Terminal command <i>SYC</i> ("Synchronization command") enabled |
| | LOCK | | Terminal command <i>LOCK</i> ("Servo-lock command") |
| | JOG | | Jogging speed |
| | LDR | | "FRENIC-VG Loader" |
| | AI-V | | Voltage input on analog input terminal AI-V |
| | AI-C | | Current input on analog input terminal AI-C |
| LOCAL | Keypad in local mode | | |
| (3) | ---- | PID control | PID control disabled |
| | PID | | PID control enabled |
| (4) | M1 | Motor selected | Motor 1 selected |
| | M2 | | Motor 2 selected |
| | M3 | | Motor 3 selected |
| (5) | PG_V | Drive control | Vector control with speed sensor |
| | SENS_LES | | Vector control without speed sensor |
| | EMU | | Simulation mode |
| | PMPG | | Vector control for PMSM with speed sensor |
| | V/F | | V/f control for IM |
| | MW_PGV_M | | Vector control for IM with speed sensor (Multiplex master) |
| | MW_PGV_S | | Vector control for IM with speed sensor (Multiplex slave) |
| | MW_LES_M | | Vector control for IM without speed sensor (Multiplex master) |
| MW_LES_S | Vector control for IM without speed sensor (Multiplex slave) | | |
| (6) | ---- | Run command | Both Run forward and Run reverse commands being OFF or ON |
| | FWD | | Run forward command |
| | REV | | Run reverse command |
| (7) | ---- | Current limit | No current limit |
| | IL | | Current limiting |
| (8) | ---- | Undervoltage Voltage limit | Neither undervoltage nor voltage limited |
| | LU | | Undervoltage detected |
| | VL | | Voltage limited |
| (9) | ---- | Torque limit | No torque limit |
| | TL | | Torque limiting |
| (10) | HAND | Run command source | Keypad (F02 = 0) |
| | TERM | | External signals to terminals [FWD] and [REV] (F02 = 1) |
| | COMM | | Via communications link |
| | LOCAL | | Keypad in Local mode |
| (11) | ---- | Cause of trip | No cause of trip |
| | STP1 | | Input on STOP1 terminal |
| | STP2 | | Input on STOP2 terminal |
| | STP3 | | Input on STOP3 terminal |
| | BX | | Coast to a stop |
| (12) | INTL | PID command source | Internal speed command |
| | AI | | Analog input |
| | LINK | | Communications link |
| | KP-ON | | Terminal command <i>KP/PID</i> ON ("Cancel PID control") |
| (13) | ---- | PID output usage | PID output disabled |
| | T-LIM | | Torque limiter |
| | T-REF | | Torque command |
| | N-REF | | Speed command |
| | N-AUX | | Auxiliary speed (e.g., dancer control) |

3.4.4.5 Checking I/O signal status -- Menu #4 "I/O CHECK"


Menu #4 "I/O CHECK" in Programming mode is used to check the I/O states of digital and analog signals during maintenance or test running.

Simultaneous keying of the (SHIFT) + (HELP) keys holds the displayed data. The same simultaneous keying again reverts to the normal display. When the display is in the hold state, the "DATA HOLD" is shown at the bottom of the screen.



To display this menu screen, press the (PRG) key in Running mode to switch to Programming mode.

Move the cursor (flashing rectangle) at the left of the screen to "4. I/O CHECK" using the (UP) and (DOWN) keys. Then press the (PRG) key.



Digital input signals at the control circuit terminal block


: Signal OFF, : Signal ON

Normal open/close settings of X terminals specified by function code E14 are reflected to these signals.




Digital input signals at the control circuit terminal block

: Signal OFF, : Signal ON




Digital input signals via communications link

: Signal OFF, : Signal ON



Output signals from transistors at the control circuit terminal block


: Signal OFF, : Signal ON



Analog input signals at the control circuit terminal block


- ← Analog input signal (12)
- ← Analog input signal (Ai1)
- ← Analog input signal (Ai2) (voltage/current)

The unit of Ai2 can be switched between V and mA by function code E50. When E50 ≠ 26, the unit is V and when E50 = 26, mA.



Analog output signals at the control circuit terminal block

- ← Analog output signal (Ao1)
- ← Analog output signal (Ao2)
- ← Analog output signal (Ao3)




← This screen is used to check the inverter running status.


: Signal OFF, : Signal ON

FWD: Forward operation
 REV: Reverse operation
 EXT: Pre-exciting
 INT: Inverter shut off
 BRK: Braking


NUV: DC link bus voltage established
 TL: Torque limiting
 VL: Voltage limiting
 IL: Current limiting

ACC: Accelerating
 DEC: Decelerating
 ALM: Alarm output (for any fault)






← Indicates the input status of the DIOB option.
 □: Signal OFF, ■: Signal ON
 (This page appears by mounting the DIO option card OPC-VG1-DIO and turning SW2 to the DIOB position.)



← Indicates the output status of the DIOB option.
 □: Signal OFF, ■: Signal ON
 (This page appears by mounting the DIO option card OPC-VG1-DIO and turning SW2 to the DIOB position.)



← Indicates the I/O status of the SAFE option.
 □: Signal OFF, ■: Signal ON
 (This page appears by mounting the optional functional safety card OPC-VG1-SAFE.)

3.4.4.6 Reading maintenance information -- Menu #5 "MAINTENANCE"


Menu #5 "MAINTENANCE" in Programming mode shows information necessary for performing maintenance on the inverter.

Simultaneous keying of the (SHIFT) + (HELP) keys holds the displayed data. The same simultaneous keying again reverts to the normal display. When the display is in the hold state, the "DATA HOLD" is shown at the bottom of the screen.




To display this menu screen, press the (PRG) key in Running mode to switch to Programming mode.


Move the cursor (flashing rectangle) at the left of the screen to "5. MAINTENANCE" using the (▲) and (▼) keys. Then press the (F.MC) key.




- ← Cumulative run time
- ← DC link bus voltage
- ← Max. temperature inside the inverter (Refreshed every one hour.)
- ← Max. temperature of heat sink (Refreshed every one hour.)




- ← Max. effective current (within an hour)
- ← Main capacitor capacity




- ← Cumulative run time of capacitors on the printed circuit board (Refreshed every 10 hours)
- ← Estimated remaining life of the capacitor on the printed circuit board (fixed)
- ← Cumulative run time of the cooling fan (Refreshed every 10 hours)
- ← Estimated remaining life of the cooling fan (fixed)



- ← (1) Number of communication retries for keypad
- ← (2) Number of communication retries, (5) Latest error code for RS-485 (See Table 3.4-9.)
- ← (3) Number of communication retries, (6) Latest error code for T-Link/CC-Link/SX-bus (See Table 3.4-10.)
- ← (4) Number of communication retries, (7) Latest error code for high-speed serial communication dedicated terminal block (Available soon)




- ← ROM version of main control CPU (MAIN)
- ← ROM version of motor control CPU (MTR)
- ← ROM version of keypad (KP)



- ← ROM version of 8-bit digital option CPU (OP1)
- ← ROM version of 8-bit digital option CPU (OP2)
- ← ROM version of 16-bit digital option CPU

"----" when no option is mounted.



- ← ROM version (Not used.)
- ← ROM version of optional functional safety card CPU-S1
- ← ROM version of optional functional safety card CPU-S2

"----" when no option is mounted.




Table 3.4-9 List of RS-485 Error Codes

| Display # | Data for function code M26 Values in parentheses are in hexadecimal. | Error content |
|-----------|---|------------------------------------|
| -- | 0 (0H) | No error |
| 01 | 74 (4AH) | Format error |
| | 75 (4BH) | Command error |
| 02 | 78 (4EH) | Function code error |
| 03 | 80 (50H) | Data error |
| 04 | 71 (47H) | Checksum error, CRC error |
| 05 | 72 (48H) | Parity error |
| 06 | 73 (49H) | Overrun error, framing error |
| 07 | 76 (4CH) | Communications link priority error |
| | 79 (4FH) | Write-protected |
| | 81 (51H) | Error during writing |

Table 3.4-10 List of Bus Error Codes

The following display numbers are shown as a bus error code.

| Display # | Upper digits (T-Link) | Upper digits (CC-Link) | Lower digits (SX-bus) |
|-----------|---|-----------------------------|---|
| -- | No error | No error | No error |
| 1 | Light alarm: Noise | | Light alarm: Communications data error |
| 2 | Heavy alarm: Wire break, Hardware defective, Mounting failure | Light alarm (CC-Link error) | Heavy alarm 1: Wire break |
| 3 | | Heavy alarm (option error) | Heavy alarm 2: Hardware defective, Mounting failure |


3.4.4.7 Measuring load factor -- Menu #6 "LOAD FCTR"

Menu #6 "LOAD FCTR" in Programming mode is used to measure the maximum output current, the average output current, and the average braking power.





To display this menu screen, press the **PRG** key in Running mode to switch to Programming mode.

Move the cursor (flashing rectangle) at the left of the screen to "6. LOAD FCTR" using the **▲** and **▼** keys. Then press the **FUNC DATA** key.




← Measurement period

Change the measurement period using the **SHIFT**, **▲** and **▼** keys.




← Measurement period (600 seconds)

Press the **FUNC DATA** key to start measurement.




← Indicates the remaining measurement period. When this value comes to zero, measurement is completed.



- ← Reverts to the initial value.
- ← Maximum current
- ← Average current
- ← Average braking power (motor rated output/100%)


3.4.4.8 Reading alarm information -- Menu #7 "ALM INF"

Menu #7 "ALM INF" in Programming mode shows the past four alarm codes and the related alarm information on the current inverter conditions detected when the alarm occurred.




To display this menu screen, press the **(PRG)** key in Running mode to switch to Programming mode.

Move the cursor (flashing rectangle) at the left of the screen to "7. ALM INF" using the **(▲)** and **(▼)** keys. Then press the **(F.FUNC DATA)** key.




- ← (1) Latest alarm code (5) Latest alarm, ID (9) Latest alarm, no. of occurrences (always 1)
 - ← (2) 1st last alarm code (6) 1st last alarm, ID (10) 1st last alarm, no. of occurrences
 - ← (3) 2nd last alarm code (7) 2nd last alarm, ID (11) 2nd last alarm, no. of occurrences
 - ← (4) 3rd last alarm code (8) 3rd last alarm, ID (12) 3rd last alarm, no. of occurrences
- Alarm ID: Blank (Alarm caused by the inverter), O (Alarm caused by multiplex system or other inverters)


Use the **(▲)** and **(▼)** keys to select the desired alarm.




Press the **(F.FUNC DATA)** key to establish the selected alarm.




- ← Date when an alarm occurred
 - ← Time when an alarm occurred
- Note: To record accurate date and time, it is necessary to mount a memory backup battery (Option for inverters of up to 22 kW, Included as standard for those of 30 kW or above) and adjust the date and time.




- ← Date when an alarm was removed
 - ← Time when an alarm was removed
- Note: To record accurate date and time, it is necessary to mount a memory backup battery (Option for inverters of up to 22 kW, Included as standard for those of 30 kW or above) and adjust the date and time.




- ← Speed setting 4 upon the occurrence of alarm
 - ← Detected speed 1 upon the occurrence of alarm
 - ← Reference output frequency upon the occurrence of alarm
 - ← Reference torque upon the occurrence of alarm
- The value is rounded to the first decimal place.
If the absolute value of the detected speed is 10,000 or larger, the value is rounded to an integer.




- ← Motor temperature upon the occurrence of alarm ("---" appears when no NTC is mounted)
- ← Detected output current upon the occurrence of alarm
- ← Detected output voltage upon the occurrence of alarm
- ← Reference magnetic-flux value upon the occurrence of alarm



- ← Cumulative operation hours upon the occurrence of alarm
 - ← Reference motor output (in kW or HP) upon the occurrence of alarm *
 - ← Inverter inside air temperature upon the occurrence of alarm (real-time value)
 - ← Heat sink temperature upon the occurrence of alarm (real-time value)
- * kW or HP can be selected with code F60.






3.4.4.9 Viewing causes of alarm -- Menu #8 "ALM CAUSE"

Menu #8 "ALM CAUSE" in Programming mode shows the past four alarm codes and the related alarm information on the current inverter conditions detected when the alarm occurred.




To display this menu screen, press the **PRG** key in Running mode to switch to Programming mode.

Move the cursor (flashing rectangle) at the left of the screen to "8. ALM CAUSE" using the **▲** and **▼** keys. Then press the **F.FUNC DATA** key.



- ← (37) Multiple alarms, 4th
- ← (36) Multiple alarms, 3rd
- ← (35) Multiple alarms, 2nd
- ← (34) Multiple alarms, 1st
- ← (1) Latest alarm code (5) Latest alarm, ID (9) Latest alarm, no. of occurrences (always 1)
- ← (2) 1st last alarm code (6) 1st last alarm, ID (10) 1st last alarm, no. of occurrences
- ← (3) 2nd last alarm code (7) 2nd last alarm, ID (11) 2nd last alarm, no. of occurrences
- ← (4) 3rd last alarm code (8) 3rd last alarm, ID (12) 3rd last alarm, no. of occurrences
- ← (13) 4th last alarm code (20) 4th last alarm, ID (27) 4th last alarm, no. of occurrences
- ← (14) 5th last alarm code (21) 5th last alarm, ID (28) 5th last alarm, no. of occurrences
- ← (15) 6th last alarm code (22) 6th last alarm, ID (29) 6th last alarm, no. of occurrences
- ← (16) 7th last alarm code (23) 7th last alarm, ID (30) 7th last alarm, no. of occurrences
- ← (17) 8th last alarm code (24) 8th last alarm, ID (31) 8th last alarm, no. of occurrences
- ← (18) 9th last alarm code (25) 9th last alarm, ID (32) 9th last alarm, no. of occurrences
- ← (19) 10th last alarm code (26) 10th last alarm, ID (33) 10th last alarm, no. of occurrences

Use the **▲** and **▼** keys to select the desired alarm and press the **F.FUNC DATA** key to establish the selected alarm.



← Indicates cause of the alarm selected from alarm history
Shown at the left is the **THR OPEN** alarm.

If all the information for the selected alarm is not shown on the screen at a time, scroll over the descriptive information using the **▲** and **▼** keys.

< Alarm ID Details >

| Display | Function |
|---------|---------------------------------|
| Blank | Ordinary alarm |
| ○ | Alarm caused by other inverters |

3.4.4.10 Copying data -- Menu #10 "DATA COPY"

Menu #10 "DATA COPY" in Programming mode provides "Read," "Write," and "Verify" functions, enabling the following applications. The keypad can hold three sets of function code data in its internal memory to use for three different inverters.

- (a) Reading function code data already configured in an inverter and then writing that function code data altogether into another inverter.
- (b) Copying the function code data saved in the inverter memory into the keypad memory for backup.
- (c) Saving function code data in the keypad as master data for data management; that is, saving more than one set of function code data in the keypad and writing a set of data suited to the machinery into the target inverter.





Table 3.4-11 details the data copying functions.

Table 3.4-11 List of Data Copying Functions

| Operation | Description |
|---------------------|---|
| Read: Read data | Reads out function code data from the inverter memory and stores it into the keypad memory. |
| Write: Write data | Writes the data held in the selected area of the keypad memory into the target inverter memory. |
| Verify: Verify data | Verifies the data held in the keypad memory against that in the inverter memory. |

To display this menu screen, press the **(PRG)** key in Running mode to switch to Programming mode. Move the cursor (flashing rectangle) at the left of the screen to "10. DATA COPY" using the **(↑)** and **(↓)** keys. Then press the **(F/NC DATA)** key.

Use the **(↑)** and **(↓)** keys to select ""Read," "Write," or "Verify."




Error Processing in Menu #10 "DATA COPY"

When the inverter is running or the data protection is enabled, attempting data copying causes the inverter to automatically stop its output. Take necessary measures, referring to the error processing given below.



1) Data change not allowed during running

If you attempt to perform a write operation when the inverter is running or to start running the inverter during a write operation, then an error occurs with the message shown at right.


Stop the inverter, press the  key, and perform a write operation again.


Attempted to write during running

```
<COPY;KP-INV>
---  →400-1-4
      WRITE
CANNOT WRITE
```

To cancel, press , .

2) Choice impossible/Inverter type mismatch

When the data area is empty ("- - -" shown) on the data selection screen of the keypad in a write or verify operation, pressing the  key causes an error with the message shown at right.



When there is a mismatch of inverter type information (inverter type and voltage series, etc.), pressing the  calls up the confirmation screen asking whether to continue processing or not.

No data stored

```
<WRITE;DATA>
KP1:-----
KP2:045-1-2
KP3:350-1-4
CANNOT SELECT
```



Inverter type info mismatch

```
UNMATCH TYPE
WRITTEN TOO ?
→ YES
NO
```

To cancel, press , .




3) Verify error

If there is a mismatch between the data stored in the keypad memory and the one in the inverter memory, then the "ERROR" and the function code number appear and the inverter temporarily halts data checking.

To continue the subsequent data checking, press the  key; to terminate it, press the  key.

Data discrepancy

```
<COPY;KP-INV>
KP1=400-1-4
      VERIFY
ERROR:E12
11% 75/677
```

To continue, press .
To terminate, press , .



4) Data protection enabled

If the copy destination inverter is data-protected (F00 = 1), the message appears as shown at right.

To perform a write operation, change the F00 setting to enable data modification.

Data protection enabled with F00

```
<COPY;KP-INV>
KP1=400-1-4
      WRITE
ERROR:F01
DATA PRCTD
```



To cancel, press , .

- 5) When the **WE-KP** terminal command ("Enable data change with keypad") is assigned to a digital input terminal (function code data = 19) and it is OFF, the message appears as shown at right.

Turn the **WE-KP** ON and perform a write operation again.

Data change with keypad is disabled

```
<COPY;KP-INV>
KP1=400-1-4
  WRITE
ERROR:F01
NO SIGNAL(WE)
```

To cancel, press , .



- 6) [FWD]/[REV] terminal being ON

If the ready-to-run signal is OFF (e.g., only auxiliary power supply) and the [FWD]/[REV] terminal is ON via a contact, then the message appears as shown at right.

Open the [FWD]/[REV] terminal and perform a write operation again.


[FWD]/[REV] terminal being ON

```
<COPY;KP-INV>
KP1=400-1-4
  WRITE
ERROR:F01
FWD/REV ON
```

To cancel, press , .

3.4.4.11 Checking changed function codes -- Menu #11 "CHANGES"

Menu #11 "CHANGES" in Programming mode shows only the function codes whose data has been changed from the factory defaults.



To display this menu screen, press the **PRG** key in Running mode to switch to Programming mode.

Move the cursor (flashing rectangle) at the left of the screen to "11. CHANGES" using the **▲** and **▼** keys. Then press the **F.FUNC DATA** key.

The function codes whose data has been changed from factory defaults are marked with an asterisk (*).

Just as in Section 3.4.4.2, "Configuring function codes--Menu #1 "DATA SET," the function code data can be modified.


3.4.4.12 Setting the calendar clock -- Menu #12 "DATE/TIME"

Menu #12 "DATE/TIME" in Programming mode is used to select the format of the calendar clock to be displayed in the operation guide line in Running mode and set the date and time.

⚠ CAUTION

After mounting a memory backup battery (option for inverters of 22 kW or below, included as standard for those of 33 kW or above), set the date and time. When a memory backup battery is not mounted, the calendar clock does not work correctly.

1) Setting the date and time



To display this menu screen, press the **PRG** key in Running mode to switch to Programming mode.

Move the cursor (flashing rectangle) at the left of the screen to "12. DATE/TIME" using the **▲** and **▼** keys. Then press the **F.FUNC DATA** key.

Press **F.FUNC DATA** key to establish the desired menu.

Use the **SHIFT** key to move the cursor to the desired item.


Change the date and time using the **▲** and **▼** keys.

If the relationship between the changed year, month, day, and time is invalid, "CANNOT SET" appears when the **F.FUNC DATA** key is pressed.

After a second, the screen automatically switches back to the submenu.

Tip The calendar clock can also be set with FRENIC-VG Loader. For details, refer to the FRENIC-VG Loader Instruction Manual.

2) Selecting the display format



To display this menu screen, press the **PRG** key in Running mode to switch to Programming mode.

Move the cursor (flashing rectangle) at the left of the screen to "12. DATE/TIME" using the **↑** and **↓** keys. Then press the **F12** key.

Press **F12** key to establish the desired menu.

Move the pointer **→** using the **↑** and **↓** keys to the desired menu.


Press **F12** key to establish the desired menu.

Change the date format data using the **↑** and **↓** keys.

<List of date formats>

| | |
|---------------------|------------------|
| y y y y / m m / d d | Year/Month/Date |
| d d / m m / y y y y | Date/Month/Year |
| m m / d d / y y y y | Month/Date/Year |
| m m m d d , y y y y | Month Date, Year |
| <OFF> | No display |

Press **F12** key to establish the newly specified date format.



Change the time format data using the \uparrow and \downarrow keys.

<List of time formats>

| | |
|-------------|-----------------------------------|
| hh:mm:ss | 0-24 hour: minutes: seconds |
| hh:mm:ss AM | 0-12 hour: minutes: seconds AM/PM |
| AM hh:mm:ss | AM/PM 0-12 hour: minutes: seconds |
| <OFF> | No display |

Press FUNC DATA key to establish the newly specified time format.


After a second, the screen automatically switches back to the submenu.

3.4.4.13 Limiting function codes to be displayed -- Menu #14 "LIMITED FC"

Menu #14 "LIMITED FC" in Programming mode is used to display/hide the directory and select whether to display all function codes or limited ones selected in Loader.

For details, refer to the "Function code edit" section in the FRENIC-VG Loader Instruction Manual.

Shown below is an example of selecting limited ones.



To display this menu screen, press the PRG key in Running mode to switch to Programming mode.

Move the cursor (flashing rectangle) at the left of the screen to "14. LIMITED FC" using the \uparrow and \downarrow keys. Then press the FUNC DATA key.


Move the pointer \rightarrow using the \uparrow and \downarrow keys to the desired menu.

Press FUNC DATA key to select "LIMITED."

After a second, the screen automatically switches back to the submenu.

3.5 Test Run Procedure

Make a test run of the motor using the flowchart given below.



3.5.1 Checking prior to powering On

Check the following before powering on the inverter.

- (1) Check the wiring to the inverter input terminals L1/R, L2/S and L3/T and output terminals U, V, and W. Also check that the grounding wires are connected to the grounding terminals (⊕G) correctly. (See Figure 3.5-1.)

⚠ WARNING


- Never connect power supply wires to the inverter output terminals U, V, and W. Doing so and turning the power ON breaks the inverter.
 - Be sure to connect the grounding wires of the inverter and the motor to the ground electrodes.
- Otherwise, an electric shock could occur.**

- (2) Check the control circuit terminals and main circuit terminals for short circuits or ground faults.
- (3) Check for loose terminals, connectors and screws.
- (4) Check that the motor is separated from mechanical equipment.
- (5) Make sure that all switches of devices connected to the inverter are turned OFF. Powering on the inverter with any of those switches being ON may cause an unexpected motor operation.
- (6) Check that safety measures are taken against runaway of the equipment, e.g., a defense to prevent people from access to the equipment.
- (7) Check that a power factor correction DC reactor (DCR) is connected to terminals P1 and P(+).
(Inverters of 75 kW or above and LD-mode inverters of 55 kW are provided together with a DCR as standard. Be sure to connect the DCR to the inverter.)
- (8) Check that the PG (pulse generator) wiring is correct.

⚠ CAUTION

Wrong wiring may break the PG.

If the inverter is powered on with wrong wiring, disconnect the PG signal wires from the inverter, keep only the PG powered on via the PGP and PGM, and then check that each signal is correctly output with an oscilloscope or recorder.



Note: In principle, the shielded sheath of wires should be connected to ground. If the inverter is significantly affected by external induction noise, however, connection to the common terminal (PGM, THC) may be effective to suppress the influence of noise.

Figure 3.5-1 Connection of Main Circuit Terminals (Vector dedicated motor connected)

3.5.2 Powering ON and checking

⚠ WARNING

- Be sure to mount the front cover before turning the power ON. Do not remove the cover when the inverter power is ON.
 - Do not operate switches with wet hands.
- Otherwise, an electric shock could occur.**

Turn the power ON and check the following points. The following is a case when no function code data is changed from the factory defaults.

- (1) Check that the LED monitor displays \square (indicating that the reference speed is 0 r/min) that is blinking. (See Figure 3.5-2.)
If the LED monitor displays any number except \square , press \triangle / ∇ key to set \square .
- (2) Check that the built-in cooling fans rotate.



Figure 3.5-2 Display of the LED Monitor at Power-on

3.5.2.1 Checking the input state of PG (pulse generator) signals

Before proceeding to a test run of the inverter, rotate the motor shaft and check the digital input state of PG (pulse generator) signals on the screen shown below.

To call up the screen, switch the inverter operation mode from the Running mode to the Programming mode, select Menu #4 "I/O CHECK" on the menu screen, and select page 15 (shown below) using the \triangle / ∇ keys.

For detailed operation procedure, refer to Section 3.4.4.5.

| | |
|---------------------------------------|---|
| SD = ± × × × × P / s | ← PG (SD) signal input info (inverter or option)* |
| LD = ± × × × × P / s | ← PG (LD) signal input info (option) |
| PR = ± × × × × P / s | ← PG (PR) signal input info (option) |
| PD = ± × × × × P / s | ← PG (PD) signal input info (option) |
| \triangle / ∇ → PAGE SHIF 15 | |

* When a PG (SD) option is mounted, the PG (SD) signal input info appears; when it is not, the inverter PG signal input info appears.

3.5.2.2 Mounting direction of a PG (pulse generator) and PG signals

The forward rotational direction of the dedicated motor (MVK type) is CCW when viewed from the motor output shaft as shown in Figure 3.5-3.

During rotation in the forward direction, the PG output pulse forms a forward rotation signal (B phase advanced by 90 degrees) shown in Figure 3.5-4, and during rotation in the reverse direction, a reverse rotation signal (A phase advanced by 90 degrees).

In the case of motors other than the dedicated one, for example, to mount an external PG, directly connect it to the motor, using a coupling, etc.




Figure 3.5-3 Forward Rotational Direction of Motor and PG




Figure 3.5-4 PG (Pulse Generator) Signal

3.5.3 Selecting a desired motor drive control

The FRENIC-VG supports the following motor drive controls.

| Data for P01 | M1 drive control | Speed feedback | Speed control | Refer to: |
|--------------|--|-----------------|--|------------------------------------|
| 0 | Vector control for IM with speed sensor | Yes | Speed control with automatic speed regulator (ASR) | Section 3.5.3.1 |
| 1 | Vector control for IM without speed sensor | Estimated speed | | Section 3.5.3.2 |
| 2 | Simulation mode | Yes | | Chapter 4, Section 4.3.4 "P codes" |
| 3 | Vector control for PMSM with speed sensor | Yes | | Section 3.5.3.3 |
| 5 | V/f control for IM | No | Frequency control | Section 3.5.3.4 |

3.5.3.1 Vector control for IM with speed sensor

Under vector control, the inverter detects the motor's rotational position and speed according to PG feedback signals and uses them for speed control. In addition, it decomposes the motor drive current into the exciting and torque current components, and controls each of components in vector.

The desired response can be obtained by adjusting the control constants (PI constants) with the speed regulator (PI controller).

This control enables the speed control with higher accuracy and quicker response than the vector control without speed sensor.

(A recommended motor for this control is a Fuji VG motor exclusively designed for vector control.)

Note Vector control regulating the motor current requires some voltage margin between the voltage that the inverter can output and the induced voltage of the motor. Usually a general-purpose motor is so designed that the voltage matches the commercial power. Under the control, therefore, it is necessary to suppress the motor terminal voltage to the lower level in order to secure the voltage margin required.

However, driving the motor with the motor terminal voltage suppressed to the lower level cannot generate the rated torque even if the rated current originally specified for the motor is applied. To ensure the rated torque, it is necessary to review the rated current. (This also applies to vector control without speed sensor.)

■ For Fuji VG motor exclusively designed for vector control

Configure the function codes as listed below. The machinery design values (maximum speed, acceleration time, and deceleration time) should match your machinery ones.

Book For details on how to modify the function code data, see Section 3.4.4.2 "Configuring function codes -- Menu #1 "DATA SET." For details, refer to Chapter 4, Section 4.3 "Details of Function Codes."


| Function code | Name | Function code data | Factory default |
|--------------------|--|---|--|
| P01 A01 | M1 Drive Control M2 Drive Control | 0: Vector control for IM with speed sensor | 0: Vector control for IM with speed sensor |
| A101 | M3 Drive Control | | 5: V/f control for IM |
| P02 | M1 Selection | Motor to be applied | Motor to be applied |
| P28 A30 A130 | M1 PG Pulse Resolution M2 PG Pulse Resolution M3 PG Pulse Resolution | 1024 | 1024 |
| P30 A31 A131 | M1 Thermistor Type M2 Thermistor Type M3 Thermistor Type | 1: NTC thermistor | 1: NTC thermistor |
| F03 | M1 Maximum Speed M2 Maximum Speed M3 Maximum Speed | Machinery design values (Note) For a test-driving of the motor, increase values so that they are longer than your machinery design values. If the specified time is short, the inverter may not run the motor properly. | 1500 r/min |
| F07 | Acceleration Time 1 (Note) | | 5.00 s |
| F08 | Deceleration Time 1 (Note) | | 5.00 s |

■ For motors except Fuji VG motor


To use motors except a Fuji VG motor when their motor parameters to be set to function codes are known, perform auto-tuning to automatically configure them.

Configure the function codes as listed below according to the motor ratings and your machinery design values (maximum speed, acceleration time, and deceleration time). The motor ratings are printed on the motor's nameplate. For your machinery design values, ask system designers about them.


After configuring the function codes, perform motor parameter auto-tuning (H01 = 3 or 4).

 For details on how to modify the function code data, see Section 3.4.4.2 "Configuring function codes -- Menu #1 "DATA SET." For details, refer to Chapter 4, Section 4.3 "Details of Function Codes."

| Function code | Name | Function code data | Factory default | |
|--------------------|---|---|---|------------|
| P01 A01 | M1 Drive Control M2 Drive Control | 0: Vector control for IM with speed sensor | 0: Vector control for IM with speed sensor | |
| A101 | M3 Drive Control | | 5: V/f control for IM | |
| P02 | M1 Selection | 37: Others (No modification is required for M2 or M3.) | Motor to be applied | |
| P28 A30 A130 | M1 Pulse Resolution M2 Pulse Resolution M3 Pulse Resolution | Match the specifications of the PG to be used. | 1024 | |
| P30 A31 A131 | M1 Thermistor Type M2 Thermistor Type M3 Thermistor Type | 0: No thermistor | 1: NTC thermistor | |
| F04 A05 A105 | M1 Rated Speed M2 Rated Speed M3 Rated Speed | Motor ratings (printed on the nameplate of the motor) | 1500 r/min | |
| F05 | M1 Rated Voltage | | Rated voltage of nominal applied motors | |
| A04 A104 | M2 Rated Voltage M3 Rated Voltage | | 80 V | |
| P03 | M1 Rated Capacity | | Capacity of nominal applied motors | |
| A02 A102 | M2 Rated Capacity M3 Rated Capacity | | 0.00 kW | |
| P04 | M1 Rated Current | | Rated current of nominal applied motors | |
| A03 A103 | M2 Rated Current M3 Rated Current | | 0.01 A | |
| P05 A07 A107 | M1 Poles M2 Poles M3 Poles | | 4 poles | |
| F03 A06 A106 | M1 Maximum Speed M2 Maximum Speed M3 Maximum Speed | | Machinery design values (Note) For a test-driving of the motor, increase values so that they are longer than your machinery design values. If the specified time is short, the inverter may not run the motor properly. | 1500 r/min |
| F07 | Acceleration Time 1 (Note) | | | 5.00 s |
| F08 | Deceleration Time 1 (Note) | | 5.00 s | |

 For the motor parameter auto-tuning procedure (H01 = 3 or 4), refer to Chapter 4, Section 4.3.5 "H Codes."

| Function code | Name | Function code data | Factory default |
|---------------|------------------|---|-----------------|
| H01 | Tuning Selection | 3: Auto tuning with motor stopped 4: Auto tuning with motor rotating | 0: Disable |

 **Note** Performing motor parameter auto-tuning (H01 = 3 or 4) automatically changes the data of function codes P06 through P11 and P15 through P21 for M1, A08 through A13 and A17 through A23 for M2, and A108 through A113 and A117 through A123 for M3. Be careful with this data change.

After tuning, be sure to perform the Save All function (H02 = 1) to save the tuned data into the inverter (writing into the nonvolatile memory).

3.5.3.2 Vector control for IM without speed sensor

Under this control, the inverter estimates the motor speed based on the inverter's output voltage and current to use the estimated speed for speed control. In addition, it controls the motor current and motor torque with quick response and high accuracy under vector control. No PG (pulse generator) is required.


The desired response can be obtained by adjusting the control constants (PI constants) and using the speed regulator (PI controller).

Applying "vector control without speed sensor" requires auto-tuning regardless of the motor type. (Even driving a Fuji VG motor exclusively designed for vector control requires auto-tuning.)


Configure the function codes as listed below according to the motor ratings and your machinery design values (maximum speed, acceleration time, and deceleration time). The motor ratings are printed on the motor's nameplate. For your machinery design values, ask system designers about them.

■ For Fuji VG motor exclusively designed for vector control


Configure the function codes as listed below and perform motor parameter auto-tuning (H01 = 2)

 For details on how to modify the function code data, see Section 3.4.4.2 "Configuring function codes -- Menu #1 "DATA SET." For details, refer to Chapter 4, Section 4.3 "Details of Function Codes."

| Function code | Name | Function code data | Factory default |
|--------------------|--|---|--|
| P01 A01 | M1 Drive Control M2 Drive Control | 0: Vector control for IM with speed sensor | 0: Vector control for IM with speed sensor |
| A101 | M3 Drive Control | | 5: V/f control for IM |
| P02 | M1 Selection | 37: Others (No modification is required for M2 or M3.) | Motor to be applied |
| P30 A31 A131 | M1 PG Pulse Resolution M2 PG Pulse Resolution M3 PG Pulse Resolution | 1: NTC thermistor | 1: NTC thermistor |
| F03 A06 A106 | M1 Thermistor Type M2 Thermistor Type M3 Thermistor Type | Machinery design values (Note) For a test-driving of the motor, increase values so that they are longer than your machinery design values. If the specified time is short, the inverter may not run the motor properly. | 1500 r/min |
| F07 | M1 Maximum Speed M2 Maximum Speed M3 Maximum Speed | | 5.00 s |
| F08 | Acceleration Time 1 (Note) | | 5.00 s |

 For the motor parameter auto-tuning procedure (H01 = 2), refer to Chapter 4, Section 4.3.5 "H Codes."

| Function code | Name | Function code data | Factory default |
|---------------|------------------|----------------------------------|-----------------|
| H01 | Tuning Selection | 2: Auto-tuning (R1, L σ) | 0: Disable |

 **Note** Performing motor parameter auto-tuning (H01 = 2) automatically changes the data of function codes P06 and P07 for M1, A08 and A09 for M2, and A108 and A109 for M3. Be careful with this data change.

After tuning, be sure to perform the Save All function (H02 = 1) to save the tuned data into the inverter (writing into the nonvolatile memory).

■ For motors except Fuji VG motor

Configure the function codes as listed below and perform motor parameter auto-tuning (H01 = 3 or 4)

📖 For details on how to modify the function code data, see Section 3.4.4.2 "Configuring function codes -- Menu #1 "DATA SET." For details, refer to Chapter 4, Section 4.3 "Details of Function Codes."

| Function code | Name | Function code data | Factory default | |
|--------------------|--|--|--|------------|
| P01 A01 A101 | M1 Drive Control M2 Drive Control M3 Drive Control | 0: Vector control for IM with speed sensor | 0: Vector control for IM with speed sensor 5: V/f control for IM | |
| P02 | M1 Selection | 37: Others (No modification is required for M2 or M3.) | Motor to be applied | |
| P30 A31 A131 | M1 Thermistor Type M2 Thermistor Type M3 Thermistor Type | 0: No thermistor | 1: NTC thermistor | |
| F04 A05 A105 | M1 Rated Speed M2 Rated Speed M3 Rated Speed | Motor ratings (printed on the nameplate of the motor) | 1500 r/min | |
| F05 | M1 Rated Voltage | | Rated voltage of nominal applied motors | |
| A04 A104 | M2 Rated Voltage M3 Rated Voltage | | 80 V | |
| P03 | M1 Rated Capacity | | Capacity of nominal applied motors | |
| A02 A102 | M2 Rated Capacity M3 Rated Capacity | | 0.00 kW | |
| P04 | M1 Rated Current | | Rated current of nominal applied motors | |
| A03 A103 | M2 Rated Current M3 Rated Current | | 0.01 A | |
| P05 A07 A107 | M1 Poles M2 Poles M3 Poles | | 4 poles | |
| F03 A06 A106 | M1 Maximum Speed M2 Maximum Speed M3 Maximum Speed | | Machinery design values (Note) For a test-driving of the motor, increase values so that they are longer than your machinery design values. If the specified time is short, the inverter may not run the motor properly. | 1500 r/min |
| F07 | Acceleration Time 1 (Note) | | | 5.00 s |
| F08 | Deceleration Time 1 (Note) | | 5.00 s | |

📖 For the motor parameter auto-tuning procedure (H01 = 3 or 4), refer to Chapter 4, Section 4.3.5 "H Codes."

| Function code | Name | Function code data | Factory default |
|---------------|------------------|---|-----------------|
| H01 | Tuning Selection | 3: Auto tuning with motor stopped 4: Auto tuning with motor rotating | 0: Disable |

Note Performing motor parameter auto-tuning (H01 = 3 or 4) automatically changes the data of function codes P06 through P11 and P15 through P21 for M1, A08 through A13 and A17 through A23 for M2, and A108 through A113 and A117 through A123 for M3. Be careful with this data change.

After tuning, be sure to perform the Save All function (H02 = 1) to save the tuned data into the inverter (writing into the nonvolatile memory).

3.5.3.3 Vector control for PMSM with speed sensor and magnetic pole position sensor


Under this control, the inverter detects the motor's rotational position, speed and magnetic pole position according to feedback signals sent from the speed sensor and magnetic pole position sensor for speed control. In addition, it decomposes the motor drive current into the exciting and torque current components, and controls each of components in vector.

The desired response can be obtained by adjusting the control constants (PI constants) with the speed regulator (PI controller).


(A recommended motor for this control is Fuji GNF2 series exclusively designed for vector control.)

■ For Fuji GNF2 motor exclusively designed for vector control

Configure the function codes as listed below. The machinery design values (maximum speed, acceleration time, and deceleration time) should match your machinery ones. For details, contact your Fuji Electric representative.

 For details on how to modify the function code data, see Section 3.4.4.2 "Configuring function codes -- Menu #1 "DATA SET." For details, refer to Chapter 4, Section 4.3 "Details of Function Codes."

| Function code | Name | Function code data | Factory default |
|--------------------|---|---|--|
| P01 A01 | M1 Drive Control M2 Drive Control | 3: Vector control for PMSM with speed sensor | 0: Vector control for IM with speed sensor |
| A101 | M3 Drive Control | | 5: V/f control for IM |
| P02 | M1 Selection | 37: Others (No modification is required for M2 or M3.) | Motor to be applied |
| o10 A60 A160 | M1 Magnetic Pole Position Sensor Offset M2 Magnetic Pole Position Sensor Offset M3 Magnetic Pole Position Sensor Offset | 0.0 to 359.9 (0.0° to 359.9° CCW) These function codes are used to adjust the magnetic pole position. Refer to Section 3.5.4.2 "Test run procedure for permanent magnet synchronous motor (PMSM), [3] Setting the magnetic pole position offset value." | 0.0 |
| F03 A06 A106 | M1 Maximum Speed M2 Maximum Speed M3 Maximum Speed | Machinery design values (Note) For a test-driving of the motor, increase values so that they are longer than your machinery design values. If the specified time is short, the inverter may not run the motor properly. | 1500 r/min |
| F07 | Acceleration Time 1 (Note) | | 5.00 s |
| F08 | Deceleration Time 1 (Note) | | 5.00 s |

 **Note** Since vector control for a Fuji GNF2 motor with speed sensor uses motor parameters, the following conditions should be satisfied; otherwise, full control performance may not be obtained.

- A single motor should be connected per inverter.
- Motor parameters are properly configured.

Table 3.5-1 PMSM (GNF2) Function Code Table 1

| Motor Type | Motor Capacity | Rated Voltage | Rated Current | Num. of poles | Rated Speed | Maximum Speed | F03 (A106) | F04 (A05) | F05 (A04) | F40 | F44 | P01 (A01) | P02 | P03 (A102) | P04 (A02) | P05 (A07) | P06 (A08) | P07 (A09) | P08 (A10) | P09 (A11) | P10 (A12) | P11 (A13) | P12 (A14) | P13 (A15) | P14 (A16) | P15 (A17) | P16 (A18) | P17 (A19) | P18 (A20) | P19 (A21) | P20 (A22) | P21 (A23) | | |
|------------|----------------|---------------|---------------|---------------|-------------|---------------|------------|-----------|-----------|-----|-----|-----------|---------|------------|-----------|-----------|-----------|-----------|-----------|-----------|-----------|-----------|-----------|-----------|-----------|-----------|-----------|-----------|-----------|-----------|-----------|-----------|------|-----|
| GNF2114A | 5.5 | 185 | 20 | 6 | 1500 | 2000 | 2000 | 1500 | 185 | 3 | 150 | 3 | P-OTHER | 5.50 | 20.00 | 6 | 4.02 | 45.57 | 9.76 | 14.96 | 0.001 | 0.001 | 5.45 | 0.00 | 0.00 | 0.00 | 0.00 | 0.00 | 0.00 | 0.00 | 0.00 | 0.00 | 0.00 | 164 |
| GNF2115A | 7.5 | 185 | 29 | 6 | 1500 | 2000 | 2000 | 1500 | 185 | 3 | 150 | 3 | P-OTHER | 7.50 | 29.00 | 6 | 4.76 | 51.21 | 14.30 | 19.94 | 0.001 | 0.001 | 5.33 | 0.00 | 0.00 | 0.00 | 0.00 | 0.00 | 0.00 | 0.00 | 0.00 | 0.00 | 0.00 | 164 |
| GNF2117A | 11 | 185 | 42 | 6 | 1500 | 2000 | 2000 | 1500 | 185 | 3 | 150 | 3 | P-OTHER | 11.00 | 42.00 | 6 | 4.44 | 59.11 | 21.62 | 29.39 | 0.001 | 0.001 | 4.55 | 0.00 | 0.00 | 0.00 | 0.00 | 0.00 | 0.00 | 0.00 | 0.00 | 0.00 | 0.00 | 160 |
| GNF2118A | 15 | 185 | 57 | 6 | 1500 | 2000 | 2000 | 1500 | 185 | 3 | 150 | 3 | P-OTHER | 15.00 | 57.00 | 6 | 4.03 | 45.01 | 26.38 | 41.74 | 0.001 | 0.001 | 4.67 | 0.00 | 0.00 | 0.00 | 0.00 | 0.00 | 0.00 | 0.00 | 0.00 | 0.00 | 0.00 | 157 |
| GNF2136A | 18.5 | 180 | 71 | 6 | 1500 | 2000 | 2000 | 1500 | 180 | 3 | 150 | 3 | P-OTHER | 18.50 | 71.00 | 6 | 2.99 | 51.83 | 38.21 | 47.88 | 0.001 | 0.001 | 4.32 | 0.00 | 0.00 | 0.00 | 0.00 | 0.00 | 0.00 | 0.00 | 0.00 | 0.00 | 0.00 | 161 |
| GNF2137A | 22 | 185 | 82 | 6 | 1500 | 2000 | 2000 | 1500 | 185 | 3 | 150 | 3 | P-OTHER | 22.00 | 82.00 | 6 | 2.93 | 37.62 | 34.95 | 62.56 | 0.001 | 0.001 | 4.09 | 0.00 | 0.00 | 0.00 | 0.00 | 0.00 | 0.00 | 0.00 | 0.00 | 0.00 | 0.00 | 160 |
| GNF2138A | 30 | 180 | 113 | 6 | 1500 | 2000 | 2000 | 1500 | 180 | 3 | 150 | 3 | P-OTHER | 30.00 | 113.00 | 6 | 2.94 | 41.50 | 55.27 | 83.16 | 0.001 | 0.001 | 4.00 | 0.00 | 0.00 | 0.00 | 0.00 | 0.00 | 0.00 | 0.00 | 0.00 | 0.00 | 0.00 | 157 |
| GNF2165A | 37 | 185 | 140 | 6 | 1500 | 2000 | 2000 | 1500 | 185 | 3 | 150 | 3 | P-OTHER | 37.00 | 140.00 | 6 | 2.76 | 51.88 | 80.41 | 90.78 | 0.001 | 0.001 | 2.97 | 0.00 | 0.00 | 0.00 | 0.00 | 0.00 | 0.00 | 0.00 | 0.00 | 0.00 | 0.00 | 152 |
| GNF2167A | 45 | 185 | 165 | 6 | 1500 | 2000 | 2000 | 1500 | 185 | 3 | 150 | 3 | P-OTHER | 45.00 | 165.00 | 6 | 2.28 | 45.11 | 94.10 | 112.6 | 0.001 | 0.001 | 3.10 | 0.00 | 0.00 | 0.00 | 0.00 | 0.00 | 0.00 | 0.00 | 0.00 | 0.00 | 0.00 | 151 |
| GNF2185A | 55 | 185 | 200 | 6 | 1500 | 2000 | 2000 | 1500 | 185 | 3 | 150 | 3 | P-OTHER | 55.00 | 200.00 | 6 | 2.47 | 47.65 | 122.1 | 126.6 | 0.001 | 0.001 | 3.27 | 0.00 | 0.00 | 0.00 | 0.00 | 0.00 | 0.00 | 0.00 | 0.00 | 0.00 | 0.00 | 162 |
| GNF2187A | 75 | 185 | 270 | 6 | 1500 | 2000 | 2000 | 1500 | 185 | 3 | 150 | 3 | P-OTHER | 75.00 | 270.00 | 6 | 2.12 | 45.27 | 161.8 | 176.4 | 0.001 | 0.001 | 3.20 | 0.00 | 0.00 | 0.00 | 0.00 | 0.00 | 0.00 | 0.00 | 0.00 | 0.00 | 0.00 | 160 |
| GNF2207A | 90 | 185 | 316 | 6 | 1500 | 2000 | 2000 | 1500 | 185 | 3 | 150 | 3 | P-OTHER | 90.00 | 316.00 | 6 | 1.99 | 43.92 | 205.7 | 195.1 | 0.001 | 0.001 | 2.67 | 0.00 | 0.00 | 0.00 | 0.00 | 0.00 | 0.00 | 0.00 | 0.00 | 0.00 | 0.00 | 165 |
| GNF2114A | 5.5 | 370 | 10 | 6 | 1500 | 2000 | 2000 | 1500 | 370 | 3 | 150 | 3 | P-OTHER | 5.50 | 10.00 | 6 | 4.02 | 45.57 | 4.88 | 7.48 | 0.001 | 0.001 | 5.45 | 0.00 | 0.00 | 0.00 | 0.00 | 0.00 | 0.00 | 0.00 | 0.00 | 0.00 | 0.00 | 328 |
| GNF2115A | 7.5 | 370 | 15 | 6 | 1500 | 2000 | 2000 | 1500 | 370 | 3 | 150 | 3 | P-OTHER | 7.50 | 15.00 | 6 | 4.93 | 52.97 | 7.15 | 9.97 | 0.001 | 0.001 | 5.33 | 0.00 | 0.00 | 0.00 | 0.00 | 0.00 | 0.00 | 0.00 | 0.00 | 0.00 | 0.00 | 328 |
| GNF2117A | 11 | 370 | 21 | 6 | 1500 | 2000 | 2000 | 1500 | 370 | 3 | 150 | 3 | P-OTHER | 11.00 | 21.00 | 6 | 4.44 | 59.11 | 10.81 | 14.70 | 0.001 | 0.001 | 4.55 | 0.00 | 0.00 | 0.00 | 0.00 | 0.00 | 0.00 | 0.00 | 0.00 | 0.00 | 0.00 | 320 |
| GNF2118A | 15 | 370 | 29 | 6 | 1500 | 2000 | 2000 | 1500 | 370 | 3 | 150 | 3 | P-OTHER | 15.00 | 29.00 | 6 | 4.10 | 45.80 | 13.09 | 20.90 | 0.001 | 0.001 | 4.67 | 0.00 | 0.00 | 0.00 | 0.00 | 0.00 | 0.00 | 0.00 | 0.00 | 0.00 | 0.00 | 314 |
| GNF2136A | 18.5 | 360 | 36 | 6 | 1500 | 2000 | 2000 | 1500 | 360 | 3 | 150 | 3 | P-OTHER | 18.50 | 36.00 | 6 | 3.03 | 52.56 | 19.11 | 23.93 | 0.001 | 0.001 | 4.32 | 0.00 | 0.00 | 0.00 | 0.00 | 0.00 | 0.00 | 0.00 | 0.00 | 0.00 | 0.00 | 322 |
| GNF2137A | 22 | 370 | 41 | 6 | 1500 | 2000 | 2000 | 1500 | 370 | 3 | 150 | 3 | P-OTHER | 22.00 | 41.00 | 6 | 2.93 | 37.62 | 17.48 | 31.28 | 0.001 | 0.001 | 4.09 | 0.00 | 0.00 | 0.00 | 0.00 | 0.00 | 0.00 | 0.00 | 0.00 | 0.00 | 0.00 | 320 |
| GNF2139A | 30 | 360 | 57 | 6 | 1500 | 2000 | 2000 | 1500 | 360 | 3 | 150 | 3 | P-OTHER | 30.00 | 57.00 | 6 | 2.96 | 41.87 | 27.18 | 41.75 | 0.001 | 0.001 | 4.00 | 0.00 | 0.00 | 0.00 | 0.00 | 0.00 | 0.00 | 0.00 | 0.00 | 0.00 | 0.00 | 314 |
| GNF2165A | 37 | 370 | 70 | 6 | 1500 | 2000 | 2000 | 1500 | 370 | 3 | 150 | 3 | P-OTHER | 37.00 | 70.00 | 6 | 2.75 | 51.88 | 40.20 | 45.39 | 0.001 | 0.001 | 2.97 | 0.00 | 0.00 | 0.00 | 0.00 | 0.00 | 0.00 | 0.00 | 0.00 | 0.00 | 0.00 | 304 |
| GNF2167A | 45 | 370 | 83 | 6 | 1500 | 2000 | 2000 | 1500 | 370 | 3 | 150 | 3 | P-OTHER | 45.00 | 83.00 | 6 | 2.30 | 45.38 | 47.05 | 56.30 | 0.001 | 0.001 | 3.11 | 0.00 | 0.00 | 0.00 | 0.00 | 0.00 | 0.00 | 0.00 | 0.00 | 0.00 | 0.00 | 302 |
| GNF2185A | 55 | 370 | 100 | 6 | 1500 | 2000 | 2000 | 1500 | 370 | 3 | 150 | 3 | P-OTHER | 55.00 | 100.00 | 6 | 2.47 | 47.65 | 61.33 | 62.46 | 0.001 | 0.001 | 3.27 | 0.00 | 0.00 | 0.00 | 0.00 | 0.00 | 0.00 | 0.00 | 0.00 | 0.00 | 0.00 | 324 |
| GNF2187A | 75 | 370 | 135 | 6 | 1500 | 2000 | 2000 | 1500 | 370 | 3 | 150 | 3 | P-OTHER | 75.00 | 135.00 | 6 | 2.12 | 45.27 | 80.90 | 88.18 | 0.001 | 0.001 | 3.20 | 0.00 | 0.00 | 0.00 | 0.00 | 0.00 | 0.00 | 0.00 | 0.00 | 0.00 | 0.00 | 321 |
| GNF2207A | 90 | 370 | 158 | 6 | 1500 | 2000 | 2000 | 1500 | 370 | 3 | 150 | 3 | P-OTHER | 90.00 | 158.00 | 6 | 1.99 | 43.92 | 102.8 | 97.55 | 0.001 | 0.001 | 2.67 | 0.00 | 0.00 | 0.00 | 0.00 | 0.00 | 0.00 | 0.00 | 0.00 | 0.00 | 0.00 | 338 |

Table 3.5-1 PMSM (GNF2) Function Code Table 2


| Motor Type | Motor Capacity | Rated Voltage | P22 (A24) (A124) | P23 (A25) (A125) | P24 (A26) (A126) | P25 (A27) (A127) | P26 (A28) (A128) | P27 (A29) (A129) | P28 (A30) (A130) | P30 (A31) (A131) | P33 (A53) (A153) | P42 (A62) (A162) | P43 (A63) (A163) | P44 (A64) (A164) | P45 (A65) (A165) | P46 (A66) (A166) | P47 (A67) (A167) | P48 (A68) (A168) | P49 (A69) (A169) | P50 (A70) (A170) | P51 (A71) (A171) | H51 (H52) (H121) | H104 (H105) (H124) | H160 (H170) (H180) | H161 (H171) (H181) | H162 (H172) (H182) | H163 (H173) (H183) | H164 (H174) (H184) | α09 (A59) (A159) | α11 (A61) (A161) |
|------------|----------------|---------------|------------------|------------------|------------------|------------------|------------------|------------------|------------------|------------------|------------------|------------------|------------------|------------------|------------------|------------------|------------------|------------------|------------------|------------------|------------------|------------------|--------------------|--------------------|--------------------|--------------------|--------------------|--------------------|------------------|------------------|
| GNF2114A | 5.5 | 185 | 1.100 | 1.000 | 1.000 | 0.000 | 2.0 | 1.0 | 1024 | 1 | 185 | 95.0 | 100.0 | 50.0 | 0.90 | 0.85 | -0.170 | 0.050 | -3.00 | -3.00 | -0.150 | 0.018 | 1110 | 0 | 80 | 1.0 | 80 | 0 | 1 | 2.258 |
| GNF2115A | 7.5 | 185 | 1.100 | 1.000 | 1.000 | 0.000 | 2.0 | 1.0 | 1024 | 1 | 185 | 95.0 | 100.0 | 72.5 | 1.00 | 0.88 | -0.120 | -0.120 | 0.00 | -3.00 | -2.00 | 0.021 | 1110 | 0 | 80 | 1.0 | 80 | 0 | 1 | 2.204 |
| GNF2117A | 11 | 185 | 1.100 | 1.000 | 1.000 | 0.000 | 2.0 | 1.0 | 1024 | 1 | 185 | 95.0 | 100.0 | 105.0 | 1.00 | 1.15 | -0.100 | -0.250 | -2.00 | -3.00 | -0.170 | 0.027 | 1110 | 0 | 80 | 1.0 | 80 | 0 | 1 | 2.009 |
| GNF2118A | 15 | 185 | 1.100 | 1.000 | 1.000 | 0.000 | 2.0 | 1.0 | 1024 | 1 | 185 | 95.0 | 98.3 | 142.5 | 0.95 | 0.95 | -0.100 | -0.100 | -0.50 | -2.50 | -0.200 | 0.036 | 1110 | 0 | 80 | 1.0 | 80 | 0 | 1 | 2.397 |
| GNF2136A | 18.5 | 180 | 1.100 | 1.000 | 1.000 | 0.000 | 2.0 | 1.0 | 1024 | 1 | 180 | 95.0 | 100.0 | 177.5 | 0.95 | 0.95 | -0.120 | -0.200 | -2.00 | -3.00 | -0.200 | 0.065 | 1110 | 0 | 80 | 1.0 | 80 | 0 | 1 | 2.242 |
| GNF2137A | 22 | 185 | 1.100 | 1.000 | 1.000 | 0.000 | 2.0 | 1.0 | 1024 | 1 | 185 | 95.0 | 100.0 | 205.0 | 0.90 | 0.90 | -0.200 | -0.300 | 0.00 | -3.00 | -0.200 | 0.070 | 1110 | 0 | 80 | 1.0 | 80 | 0 | 1 | 2.548 |
| GNF2139A | 30 | 180 | 1.100 | 1.000 | 1.000 | 0.000 | 2.0 | 1.0 | 1024 | 1 | 180 | 95.0 | 99.9 | 282.5 | 0.90 | 0.90 | -0.150 | -0.150 | -1.00 | -2.00 | -0.200 | 0.090 | 1110 | 0 | 80 | 1.0 | 80 | 0 | 1 | 2.494 |
| GNF2165A | 37 | 185 | 1.100 | 1.000 | 1.000 | 0.000 | 2.0 | 1.0 | 1024 | 1 | 185 | 95.0 | 100.0 | 350.0 | 1.02 | 1.00 | -0.100 | -0.100 | -2.00 | -3.00 | -0.200 | 0.153 | 1110 | 0 | 80 | 1.0 | 80 | 0 | 1 | 2.595 |
| GNF2167A | 45 | 185 | 1.100 | 1.000 | 1.000 | 0.000 | 2.0 | 1.0 | 1024 | 1 | 185 | 95.0 | 98.8 | 412.5 | 0.93 | 0.93 | -0.170 | -0.140 | 0.00 | -2.00 | -0.200 | 0.191 | 1110 | 0 | 80 | 1.0 | 80 | 0 | 1 | 2.770 |
| GNF2185A | 55 | 185 | 1.100 | 1.000 | 1.000 | 0.000 | 2.0 | 1.0 | 1024 | 1 | 185 | 95.0 | 100.0 | 500.0 | 0.95 | 1.00 | -0.100 | -0.100 | -3.00 | -4.00 | -0.200 | 0.350 | 1110 | 0 | 80 | 1.0 | 80 | 0 | 1 | 2.792 |
| GNF2187A | 75 | 185 | 1.100 | 1.000 | 1.000 | 0.000 | 2.0 | 1.0 | 1024 | 1 | 185 | 95.0 | 98.1 | 675.0 | 0.97 | 0.95 | -0.150 | -0.150 | 0.00 | -3.50 | -0.200 | 0.467 | 1110 | 0 | 80 | 1.0 | 80 | 0 | 1 | 2.816 |
| GNF2207A | 90 | 185 | 1.100 | 1.000 | 1.000 | 0.000 | 2.0 | 1.0 | 1024 | 1 | 185 | 95.0 | 100.0 | 790.0 | 1.00 | 1.10 | -0.050 | -0.030 | 0.00 | -3.00 | -0.200 | 0.805 | 1110 | 0 | 80 | 1.0 | 80 | 0 | 1 | 2.929 |
| GNF2114A | 5.5 | 370 | 1.100 | 1.000 | 1.000 | 0.000 | 2.0 | 1.0 | 1024 | 1 | 370 | 95.0 | 100.0 | 25.0 | 0.90 | 0.85 | -0.170 | 0.050 | -3.00 | -3.00 | -0.150 | 0.018 | 1110 | 0 | 80 | 1.0 | 80 | 0 | 1 | 2.258 |
| GNF2115A | 7.5 | 370 | 1.100 | 1.000 | 1.000 | 0.000 | 2.0 | 1.0 | 1024 | 1 | 370 | 95.0 | 100.0 | 36.3 | 1.00 | 0.88 | -0.120 | -0.120 | 0.00 | -3.00 | -0.200 | 0.021 | 1110 | 0 | 80 | 1.0 | 80 | 0 | 1 | 2.204 |
| GNF2117A | 11 | 370 | 1.100 | 1.000 | 1.000 | 0.000 | 2.0 | 1.0 | 1024 | 1 | 370 | 95.0 | 100.0 | 52.5 | 1.00 | 1.15 | -0.100 | -0.250 | -2.00 | -3.00 | -0.170 | 0.027 | 1110 | 0 | 80 | 1.0 | 80 | 0 | 1 | 2.009 |
| GNF2118A | 15 | 370 | 1.100 | 1.000 | 1.000 | 0.000 | 2.0 | 1.0 | 1024 | 1 | 370 | 95.0 | 98.3 | 71.3 | 0.95 | 0.95 | -0.100 | -0.100 | -0.50 | -2.50 | -0.200 | 0.036 | 1110 | 0 | 80 | 1.0 | 80 | 0 | 1 | 2.397 |
| GNF2136A | 18.5 | 360 | 1.100 | 1.000 | 1.000 | 0.000 | 2.0 | 1.0 | 1024 | 1 | 360 | 95.0 | 100.0 | 88.8 | 0.95 | 0.95 | -0.120 | -0.200 | -2.00 | -3.00 | -0.200 | 0.065 | 1110 | 0 | 80 | 1.0 | 80 | 0 | 1 | 2.242 |
| GNF2137A | 22 | 370 | 1.100 | 1.000 | 1.000 | 0.000 | 2.0 | 1.0 | 1024 | 1 | 370 | 95.0 | 100.0 | 102.5 | 0.90 | 0.90 | -0.200 | -0.300 | 0.00 | -3.00 | -0.200 | 0.070 | 1110 | 0 | 80 | 1.0 | 80 | 0 | 1 | 2.548 |
| GNF2139A | 30 | 360 | 1.100 | 1.000 | 1.000 | 0.000 | 2.0 | 1.0 | 1024 | 1 | 360 | 95.0 | 99.9 | 141.3 | 0.90 | 0.90 | -0.150 | -0.150 | -1.00 | -2.00 | -0.200 | 0.090 | 1110 | 0 | 80 | 1.0 | 80 | 0 | 1 | 2.494 |
| GNF2165A | 37 | 370 | 1.100 | 1.000 | 1.000 | 0.000 | 2.0 | 1.0 | 1024 | 1 | 370 | 95.0 | 100.0 | 175.0 | 1.02 | 1.00 | -0.100 | -0.100 | -2.00 | -3.00 | -0.200 | 0.153 | 1110 | 0 | 80 | 1.0 | 80 | 0 | 1 | 2.595 |
| GNF2167A | 45 | 370 | 1.100 | 1.000 | 1.000 | 0.000 | 2.0 | 1.0 | 1024 | 1 | 370 | 95.0 | 98.8 | 206.2 | 0.93 | 0.93 | -0.170 | -0.140 | 0.00 | -2.00 | -0.200 | 0.191 | 1110 | 0 | 80 | 1.0 | 80 | 0 | 1 | 2.776 |
| GNF2185A | 55 | 370 | 1.100 | 1.000 | 1.000 | 0.000 | 2.0 | 1.0 | 1024 | 1 | 370 | 95.0 | 100.0 | 250.0 | 0.95 | 1.00 | -0.100 | -0.100 | -3.00 | -4.00 | -0.200 | 0.350 | 1110 | 0 | 80 | 1.0 | 80 | 0 | 1 | 2.792 |
| GNF2187A | 75 | 370 | 1.100 | 1.000 | 1.000 | 0.000 | 2.0 | 1.0 | 1024 | 1 | 370 | 95.0 | 98.1 | 337.5 | 0.97 | 0.95 | -0.150 | -0.150 | 0.00 | -3.50 | -0.200 | 0.467 | 1110 | 0 | 80 | 1.0 | 80 | 0 | 1 | 2.816 |
| GNF2207A | 90 | 370 | 1.100 | 1.000 | 1.000 | 0.000 | 2.0 | 1.0 | 1024 | 1 | 370 | 95.0 | 100.0 | 395.0 | 1.00 | 1.10 | -0.050 | -0.030 | 0.00 | -3.00 | -0.200 | 0.805 | 1110 | 0 | 80 | 1.0 | 80 | 0 | 1 | 2.929 |

3.5.3.4 V/f control for IM

Under this control, the inverter drives a motor with the voltage and frequency according to the V/f pattern specified by function codes.

■ For Fuji VG motor exclusively designed for vector control

Configure the function codes as listed below. The machinery design values (maximum speed, acceleration time, and deceleration time) should match your machinery ones.

 For details on how to modify the function code data, see Section 3.4.4.2 "Configuring function codes -- Menu #1 "DATA SET.""

| Function code | Name | Function code data | Factory default |
|--------------------|--|---|---|
| P01 A01 | M1 Drive Control M2 Drive Control | 5: V/f control for IM | 0: Vector control for IM with speed sensor |
| A101 | M3 Drive Control | | 5: V/f control for IM |
| P02 | M1 Selection | Motor to be applied | Motor to be applied |
| P30 A31 A131 | M1 Thermistor Type M2 Thermistor Type M3 Thermistor Type | 1: NTC thermistor (Specify the thermistor as needed.) | 1: NTC thermistor |
| F04 A05 A105 | M1 Rated Speed M2 Rated Speed M3 Rated Speed | Motor ratings (printed on the nameplate of the motor) | 1500 r/min |
| F05 | M1 Rated Voltage | | Rated voltage of nominal applied motors |
| A04 A104 | M2 Rated Voltage M3 Rated Voltage | | 80 V |
| P33 | M1 Maximum Output Voltage | | Three-phase 200 V class series: 200 (V) Thee-phase 400 V class series: 400 (V) |
| A53 A153 | M2 Maximum Output Voltage M3 Maximum Output Voltage | | 80 V |
| F03 A06 A106 | M1 Maximum Speed M2 Maximum Speed M3 Maximum Speed | Machinery design values (Note) For a test-driving of the motor, increase values so that they are longer than your machinery design values. If the specified time is short, the inverter may not run the motor properly. | 1500 r/min |
| F07 | Acceleration time 1 (Note) | | 5.00 s |
| F08 | Deceleration time 1 (Note) | | 5.00 s |
| P35 A55 A155 | M1 Torque Boost M2 Torque Boost M3 Torque Boost | 2.0 (For constant torque load) (Note) In applications requiring a starting torque, adjust the torque boost (P35, A55, A155) within the range from 2.0 to 20.0.) | 0.0 (Auto torque boost) |


■ **For motors except Fuji VG motor**

Configure the function codes as listed below according to the motor ratings and your machinery design values (maximum speed, acceleration time, and deceleration time). The motor ratings are printed on the motor's nameplate. For your machinery design values, ask system designers about them.


In applications requiring a starting torque, adjust the torque boost (P35, A55, A155) within the range from 2.0 to 20.0, or perform motor parameter auto-tuning (H01 = 2) and then set the torque boost (P31, A55, A155) to 0.0 (auto torque boost).

📖 For details on how to modify the function code data, see Section 3.4.4.2 "Configuring function codes -- Menu #1 "DATA SET."

| Function code | Name | Function code data | Factory default |
|--------------------|--|--|---|
| P01 A01 | M1 Drive Control M2 Drive Control | 5: V/f control for IM | 0: Vector control for IM with speed sensor |
| A101 | M3 Drive Control | | 5: V/f control for IM |
| P02 | M1 Selection | 37: Others (No modification is required for M2 or M3.) | Motor to be applied |
| P30 A31 A131 | M1 Thermistor Type M2 Thermistor Type M3 Thermistor Type | 0: No thermistor | 1: NTC thermistor |
| F04 A05 A105 | M1 Rated Speed M2 Rated Speed M3 Rated Speed | Motor ratings (printed on the nameplate of the motor) | 1500 r/min |
| F05 | M1 Rated Voltage | | Rated voltage of nominal applied motors |
| A04 A104 | M2 Rated Voltage M3 Rated Voltage | | 80 V |
| P33 | M1 Maximum Output Voltage | | Three-phase 200 V class series: 200 (V) Thee-phase 400 V class series: 400 (V) |
| A53 A153 | M2 Maximum Output Voltage M3 Maximum Output Voltage | | 80 V |
| P03 | M1 Rated Capacity | | Capacity of nominal applied motors |
| A02 A102 | M2 Rated Capacity M3 Rated Capacity | | 0.00 kW |
| P04 | M1 Rated Current | | Rated current of nominal applied motors |
| A03 A103 | M2 Rated Current M3 Rated Current | | 0.01 A |
| P05 A07 A107 | M1 Poles M2 Poles M3 Poles | | 4 poles |
| F03 A06 A106 | M1 Maximum Speed M2 Maximum Speed M3 Maximum Speed | Machinery design values (Note) For a test-driving of the motor, increase values so that they are longer than your machinery design values. If the specified time is short, the inverter may not run the motor properly. | 1500 r/min |
| F07 | Acceleration time 1 (Note) | | 5.00 s |
| F08 | Deceleration time 1 (Note) | | 5.00 s |
| P35 A55 A155 | M1 Torque Boost M2 Torque Boost M3 Torque Boost | 2.0 (For constant torque load) | 0.0 (Auto torque boost) |
| P06 | M1 %R1 | To use the auto torque boost function (P35, A55, A155 = 0.0), be sure to perform motor parameter auto-tuning (H01 =2). | Depends on the rated capacity. |
| A08 A108 | M2 %R1 M3 %R1 | | 0.00% |
| P07 | M1 %X | | Depends on the rated capacity. |
| A09 A109 | M2 %X M3 %X | | 0.00% |

 For the motor parameter auto-tuning procedure (H01 = 2), refer to Chapter 4, Section 4.3.5 "H Codes."

| Function code | Name | Function code data | Factory default |
|---------------|------------------|----------------------------------|-----------------|
| H01 | Tuning Selection | 2: Auto-tuning (R1, L σ) | 0: Disable |

 **Note** Performing motor parameter auto-tuning (H01 = 2) automatically changes the data of function codes P06 and P07 for M1, A08 and A09 for M2, and A108 and A109 for M3. Be careful with this data change.

After tuning, be sure to perform the Save All function (H02 = 1) to save the tuned data into the inverter (writing into the nonvolatile memory).

3.5.4 Running the inverter for operation check

WARNING

- If the user configures the function codes without completely understanding this Instruction Manual and the FRENIC-VG User's Manual, the motor may rotate with a torque or at a speed not permitted for the machine.
- When making a test run with a permanent magnet synchronous motor (PMSM), be sure to observe the test run procedure given in Section 3.5.4.2. If wiring between the inverter and motor or PG wiring is wrong, or the magnetic pole position offset is improper, the motor may run out of control.

An accident or injuries may result.

After completion of preparations for a test run as described above, start running the inverter for motor operation check using the following procedure.

CAUTION

If any abnormality is found in the inverter or motor, immediately stop operation and investigate the cause referring to Chapter 13, "TROUBLESHOOTING."

3.5.4.1 Test run procedure for induction motor (IM)

- (1) Turn the power ON and check that the reference speed is \square r/min and it is blinking on the LED monitor.
- (2) Set a low reference speed such as \square r/min, using \triangle / ∇ keys. (Check that the speed is blinking on the LED monitor.)
- (3) To run the motor in the forward direction, press the FWD key; to run it in the reverse direction, press the REV key. (Check that the speed is lit on the LED monitor.)
- (4) Press the STOP key to stop the motor.

< Check points during a test run >

- Check that the motor is running in the forward direction when it is driven with the FWD key.
- Check that the motor is running in the reverse direction when it is driven with the REV key.
- Check for smooth rotation without motor humming or excessive vibration.
- Check for smooth acceleration and deceleration.

When no abnormality is found, press the FWD or REV key again to start driving the motor, then increase the reference speed using \triangle / ∇ keys. Check the above points again.

3.5.4.2 Test run procedure for permanent magnet synchronous motor (PMSM)

[1] Before proceeding with a test run

This section provides a test run procedure for the configuration consisting of the FRENIC-VG, the interface card for PMPG drive (OPC-VG1-PMPG), and a PMSM using a UVW phase detection PG (including GNF2 motor).

For a test run using a PMSM, it is recommended that the motor be disconnected from the equipment for testing it by itself. If it is impossible to drive the motor by itself due to the equipment, however, make a test run under the conditions that cause no problems even if the motor runs continuously in one direction (forward or reverse).

[2] Preparation for a test run

- (1) Before turning the inverter power ON, make checking given in Section 3.5.1 "Checking prior to powering On."
- (2) Check that wiring of the encoder (PG) is correct.
(For the connection diagram, refer to Chapter 2, Section 2.3.1.2 "In combination with a dedicated PMSM (GNF2 type).")

| ⚠ CAUTION | |
|---|--|
| Wrong wiring may break the PG. | |
| If the inverter is powered on with wrong wiring, disconnect the PG signal wires from the inverter, keep only the PG powered on via the PGP and PGM, and then check that each signal is correctly output with an oscilloscope or recorder. | |

- (3) Turn the power ON, make a note of the current configuration of all function codes, and then change the function code data as listed in Table 3.5-2.
- (4) Check that the magnetic pole position offset (o10) is set to the previously specified value or adjusted value.

Replacing the motor or encoder requires adjustment of the magnetic pole position offset again.

Table 3.5-2 Configuration for Test Run of PMSM

| Function code | Name | Current configuration before test run (Values given below are factory defaults) | | Configuration for test run | |
|---------------|--------------------------|--|---|----------------------------|---|
| F01 | Speed Command N1 | 0 | The current configuration of function codes differs depending upon the equipment specifications. Make a note of the current configuration and then change the function code data as shown at the right. | 0 | 0: Enable the and keys on the keypad (Digital speed setting) |
| F02 | Operation Method | 0 | | 0 | 0: Enable the , and keys on the keypad to run or stop the motor. |
| F03 | Maximum Speed M1 | 1500 r/min | | 750 r/min | Set about half of the current value (before test run). |
| F40 | Torque Limiter Mode 1 | 0 (Disable) | | 3 | 3: Torque current limit |
| F44 | Torque Limiter Level 1 | 150% | | 10% | If motor power wires or encoder wires are wrongly connected, the motor may run out of control, breaking the equipment. To suppress abrupt acceleration at the time of runaway, decrease the torque limiter level. |
| E45 | Speed Disagreement Alarm | 00 (Disable) | | 01 | Speed disagreement alarm: <u>Enable</u> Power supply phase loss detection: Disable |

Note 1: If the moment of inertia of the coupled equipment is large, the motor may not run at a test run. If it happens, adjust the torque limiter level 1 properly.

Note 2: After a test run, revert the function code data to the previous values.

[3] Setting the magnetic pole position offset value**⚠ CAUTION**

Be sure to adjust the magnetic pole position offset value (see below for the adjustment procedure):

- when the inverter runs for the first time after purchase
- after replacement of a motor, PG or inverter

Running the inverter with the magnetic pole position offset value (o10, A60, A160) not adjusted or with the position deviated greatly from the true value could run the motor in the opposite direction or out of control in the worst case.

An accident or injuries could occur.

When driving a PMSM for the first time, be sure to set the magnetic pole position offset value to the inverter with the following function code(s) beforehand.

M1: Function code o10

M2: Function code A60

M3: Function code A160

Select the adjustment procedure from the following three depending on the situation.

(1) When the magnetic pole position offset value is printed on the label attached to the motor

GNF2 motors have a magnetic pole position label on the motor power line (U phase) on which the magnetic pole position offset value is printed. See Figure 3.5-5. Set the value to the function code (o10, A60, A160).

As shown in Figure 3.5-6, there are two types of magnetic pole position labels.




Figure 3.5-5 Magnetic Pole Position Offset Label Attaching Position Example




Figure 3.5-6 Magnetic Pole Position Offset Labels

Note Once a pulse generator (PG) is removed from the motor, it is necessary to adjust the magnetic pole position offset value.

(2) Automatic adjustment of the magnetic pole position offset value

When you mount a PG on the motor or replace the PG at the site for motors having no magnetic pole position offset label, perform automatic adjustment with the tuning function (H71 = 5).

Upon normal end of tuning, the magnetic pole position offset data is automatically saved into function code o10 (Magnetic pole position offset).

Requisites for tuning the magnetic pole position offset

- ① Running the motor does not bring the machinery into dangerous situations.
- ② There is no load fluctuation at the machinery and the motor rotation is stabilized.

If any of the above conditions is not satisfied, separate the motor from the machinery and perform the magnetic pole position offset tuning.

- ③ Automatic adjustment of the magnetic pole position offset value can apply only to the absolute UVW encoders (o09 = 1).

For encoders other than the absolute UVW ones, perform manual adjustment given in item (3) later.

Tuning procedure

- ① Before starting tuning, configure the following function codes.
 P01 = 3 (Select PMSM)
 o09 = 1 (Select absolute UVW encoders)
 F02 = 0 (Select keypad for operation)
- ② Set H71 to "5" (Select magnetic pole position offset tuning).
 (The H71 data can be changed by simultaneous keying of STOP + ^ / v keys.)
- ③ Press the FWD key to start tuning.
- ④ Upon completion of tuning, the data of H71 automatically reverts to "0."
- ⑤ The tuning result is saved into o10.

Note: When motor 2 (M2) or motor 3 (M3) is selected, use the following functions in tuning as listed below.

| Motor 1 (M1) | Motor 2 (M2) | Motor 3 (M3) |
|--------------|--------------|--------------|
| P01 | A01 | A101 |
| o09 | A59 | A159 |
| o10 | A60 | A160 |

Function codes applied for adjustment

The following function codes are applied for adjustment in tuning. Usually, their factory default values should be retained.

- H161 (M1 pull-in current command)
- H171 (M2 pull-in current command)
- H181 (M3 pull-in current command)

Setting range: 10 to 200(%), Factory default: 80(%)
(Assuming the setting of P04 (M1 rated current) as 100%)

Note: If the motor sticks to the stop state, increasing the current value preset to the above function codes may resolve the problem.

- H162 (M1 pull-in frequency)
- H172 (M2 pull-in frequency)
- H182 (M3 pull-in frequency)

Setting range: 0.1 to 10.0 (Hz), Factory default: 1.0 (Hz)

Note: If the motor vibrates abnormally, decreasing the frequency value preset to the above function codes may resolve the problem.

Tuning Errors



If tuning fails, check the configuration of the function codes and wiring according to the instructions given below.

- ① The "NOT EXECUTE" appears on the keypad.

When M1 is selected, P02 ≠ 37 (OTHER).

⇒ Set P02 to "37."

The JOG mode is selected. (The JOG indicator on the keypad is lit.)

⇒ Cancel the JOG mode by simultaneous keying of  +  keys.

⇒ Turn the digital input **JOG** OFF (if ON).

- ② Alarm $\overline{Er-5}$ occurs.

P01 ≠ 3, o09 ≠ 1, or H160 ≠ 0.

⇒ Set P01 to "3," o09 to "1," or H160 to "0."

Any of the digital inputs **BX**, **STOP1**, **STOP2**, and **STOP3** is ON.

Either one of the functional safety input terminals [EN1] and [EN2] is OFF.

⇒ Turn **BX**, **STOP1**, **STOP2**, and **STOP3** OFF and turn [EN1] and [EN2] ON; otherwise, turning cannot start.

- ③ Alarm $\overline{Er-7}$ occurs.

A phase loss may have occurred in connection between the inverter and motor.

⇒ Correct the connection between the inverter and motor.

Brake applies to the motor.

⇒ During tuning, be sure to enable the motor to rotate.

The motor cannot rotate. The motor is vibrating abnormally.

⇒ For motor 1: Adjust the settings of H161 (M1 pull-in current command) and H162 (M1 pull-in frequency).

⇒ For motor 2: Adjust the settings of H171 (M2 pull-in current command) and H172 (M2 pull-in frequency).

⇒ For motor 3: Adjust the settings of H181 (M3 pull-in current command) and H182 (M3 pull-in frequency).

④ Alarm $F_{\overline{L}}$ occurs.

The PG wiring may be wrong.

⇒ Correct the PG wiring.

| |
|--|
|  WARNING |
|--|

| |
|--|
| Starting magnetic pole position offset tuning rotates the motor. Before starting tuning, be sure to check that running the motor does not cause any dangerous situation. |
|--|

| |
|---|
| An accident or injuries could occur. |
|---|

(3) Manual adjustment of the magnetic pole position offset value

If magnetic pole position offset tuning cannot be used, adjust the offset value manually according to the instructions given below.

Configuring function code data beforehand

- E69 (Terminal [Ao1] function) = 26 (U phase voltage)
- E70 (Terminal [Ao2] function) = 39 (Magnetic pole position signal *SMP*)
- E84 (Ao1-Ao5 filter setting) = 0.000 s (Cancel filter)

Adjustment procedure

Rotate the motor shaft by hand to check that the positional relationship between the waveforms on Ao1 and Ao2 is as shown below. If the waveforms are greatly misaligned, adjust the data of function code o10 to align the waveforms as shown below.




Figure 3.5-7 Adjustment of Magnetic Pole Position

Note If a PG alarm occurs during adjustment, the PG connection may be wrong. Check the PG wiring.

[4] Test run

- (1) Turn the power ON and check that the reference speed is \square r/min and it is blinking on the LED monitor.
- (2) Set a low reference speed such as \square r/min, using \triangle / ∇ keys. (Check that the speed is blinking on the LED monitor.)
- (3) Set the maximum speed (F03) to \square r/min.
- (4) Shift the LCD monitor to Menu #3 "OPR MNTR" to show the speed (N*, N).
- (5) To run the motor in the forward direction, press the FWD key; to run it in the reverse direction, press the REV key.

| | | | | |
|---|---|---------|---|-----|
| N* | = | xxxxxx. | x | r/m |
| N | = | xxxxxx. | x | r/m |
| f* | = | xxxxx. | x | H z |
| TRQ | = | xxxxx. | x | % |
| $\wedge \vee \rightarrow$ PAGE SHIFT 1 | | | | |

- Check that:
- The speed on the LED monitor comes ON instead of blinking
 - The motor accelerates up to the specified speed.
 - There is no abnormal discrepancy between the reference speed (*N) and the detected speed (N) shown on the LCD monitor.
- (6) Press the STOP key to stop the motor.
 - (7) If no alarm occurs or no problem is found in motor running, increase the speed with the \triangle / ∇ keys.
 - (8) Turn the run command OFF.

< Check points during a test run >

- Check that the motor is running in the forward direction when it is driven with the FWD key.
- Check that the motor is running in the reverse direction when it is driven with the REV key.
- Check for smooth rotation without motor humming or excessive vibration.
- Check for smooth acceleration and deceleration.

When no abnormality is found, press the FWD or REV key again to start driving the motor, then increase the reference speed using \triangle / ∇ keys. Check the above points during a test run.

[5] Troubleshooting for motor abnormality

If any of the following abnormalities is found during a test run, follow the troubleshooting procedure in Table 3.5-3.

- Turning the inverter ON triggers a PG alarm.
- Entering a run command triggers a PG or Er alarm.
- Entering a run command does not run the motor or increase the speed.

Table 3.5-3 Troubleshooting for Motor Abnormality

| Possible Causes | What to Check and Suggested Measures |
|---|--|
| (1) Setting of torque limiter level 1 too small relative to the load. | Check the setting of the torque limiter level 1 (F44). \rightarrow Increase the F44 data in increments of 5%. |
| (2) Wrong wiring between the inverter and motor. | Check the wiring between the inverter and motor. \rightarrow Correct the wiring. |
| (3) Wrong PG wiring. | Check the wiring of the PG. \rightarrow Correct the wiring. |
| (4) PMSM magnetic pole position not matched. | Check the magnetic pole position. \rightarrow Adjust the magnetic pole position (o10, A60, A160), referring to "■ Adjusting the magnetic pole position" in Section 3.5.3.3. |

3.5.5 Selecting a speed command source


A speed command source is the keypad (\triangleleft / \triangleright keys) by factory default. This section provides the speed command setting procedures using the speed command sources of the keypad, external potentiometer, and speed selection terminal commands.

3.5.5.1 Setting up a speed command from the keypad

Follow the procedure given below.

- (1) Configure the function codes as listed below.


| Function code | Name | Function code data | Factory default |
|---------------|-------------------------|--|-----------------|
| F01 | Speed Command Source N1 | 0: Keypad (\triangleleft / \triangleright keys) | 0 |


-  **Note**
- When the inverter is in Programming or Alarm mode, speed command setting with \triangleleft / \triangleright keys is disabled. To enable it, switch to Running mode.
 - If any of higher priority speed command sources (multistep speed commands and speed commands via communications link) is specified, the inverter may run at an unexpected speed.

- (2) Press the \triangleleft / \triangleright key to display the current speed command on the LED monitor. The least significant digit blinks.

- (3) To change the speed command, press the \triangleleft / \triangleright key again.

When you start specifying the speed command with the \triangleleft / \triangleright key, the least significant digit on the display blinks; that is, the cursor lies in the least significant digit. Holding down the \triangleleft / \triangleright key changes data in the least significant digit and generates a carry, while the cursor remains in the least significant digit.

- (4) To save the new setting into the inverter's memory, press the  key.

-  For details on how to modify the function code data, see Section 3.4.4.2 "Configuring function codes -- Menu #1 "DATA SET."

3.5.5.2 Setting up a speed command with an external potentiometer


Follow the procedure given below.


- (1) Configure the function codes as listed below.

| Function code | Name | Function code data | Factory default |
|---------------|-------------------------|---|-----------------|
| F01 | Speed Command Source N1 | 1: Analog voltage input to terminal [12] (0 to ± 10 V) | 0 |

- (2) Connect an external potentiometer to terminals [11] through [13] of the inverter.

- (3) Rotate the external potentiometer to apply voltage to terminal [12] for a speed command input.

-  For precautions in wiring, refer to Section 3.3 "Mounting and Wiring the Inverter."

-  For details on how to modify the function code data, see Section 3.4.4.2 "Configuring function codes -- Menu #1 "DATA SET."

3.5.5.3 Setting up a speed command with multistep speed selection

Follow the procedure given below.

- (1) Configure the function codes as listed below.

| Function code | Name | Function code data | Factory default |
|---------------|----------------------------------|---|-----------------|
| E01 to E14 | Terminal [X1] to [X14] Functions | 0, 1, 2, 3: Multistep speed 1 to 15 (0: <i>SSI</i> , 1: <i>SS2</i> , 2: <i>SS4</i> , 3: <i>SS8</i>) | 0 |
| C05 to C19 | Multistep speed 1 to 15 | 0 to 30000 r/min, 0.00 to 100.00%, or 0.0 to 999.9 m/m | 0 |

Terminals [X11] to [X14] are available only when an optional OPC-VG1-DIOA is mounted.


Assign signals *SSI*, *SS2*, *SS4* and *SS8* to four out of digital input terminals [X1] to [X14] by four out of function codes E01 to E14 (data = 0, 1, 2 and 3). Specify multistep speed commands with C05 to C19.


Turning digital signals *SSI*, *SS2*, *SS4* and *SS8* ON/OFF selectively switches the multistep speed commands specified beforehand.

| Combination of input signals | | | | Selected speed command | |
|------------------------------|-----------------|-----------------|-----------------|--------------------------|--|
| 3 <i>SS8</i> | 2 <i>SS4</i> | 1 <i>SS2</i> | 0 <i>SSI</i> | | |
| OFF | OFF | OFF | ON | C05 (Multistep speed 1) | Function codes C05 to C19 Data setting range: 0 to 30000 r/min or 0.00 to 100.00% or 0.0 to 999.9 m/m |
| OFF | OFF | ON | OFF | C06 (Multistep speed 2) | |
| OFF | OFF | ON | ON | C07 (Multistep speed 3) | |
| OFF | ON | OFF | OFF | C08 (Multistep speed 4) | |
| OFF | ON | OFF | ON | C09 (Multistep speed 5) | |
| OFF | ON | ON | OFF | C10 (Multistep speed 6) | |
| OFF | ON | ON | ON | C11 (Multistep speed 7) | |
| ON | OFF | OFF | OFF | C12 (Multistep speed 8) | |
| ON | OFF | OFF | ON | C13 (Multistep speed 9) | |
| ON | OFF | ON | OFF | C14 (Multistep speed 10) | |
| ON | OFF | ON | ON | C15 (Multistep speed 11) | |
| ON | ON | OFF | OFF | C16 (Multistep speed 12) | |
| ON | ON | OFF | ON | C17 (Multistep speed 13) | |
| ON | ON | ON | OFF | C18 N-14/CREP1 | |
| ON | ON | ON | ON | C19 N-15/CREP2 | |

- (2) Connect a multistep speed switch to an X terminal and [CM].
- (3) Turn the multistep speed switch ON (short-circuit). The combination of those input signals switches a multistep speed command.

 For precautions in wiring, refer to Section 3.3 "Mounting and Wiring the Inverter."

 For details on how to modify the function code data, see Section 3.4.4.2 "Configuring function codes -- Menu #1 "DATA SET."

 **Note** Enabling a multistep speed command with a multistep speed switch (ON between X terminal and [CM]) disables the speed command source N1 specified by F01.

3.5.6 Selecting a run command source

A run command source is the keypad (FWD / REV / STOP keys) by factory default.


3.5.6.1 Setting up a run command from the keypad

Follow the procedure given below.

- (1) Configure the function codes as listed below.

| Function code | Name | Function code data | Factory default |
|---------------|------------------|-----------------------------------|-----------------------------------|
| F02 | Operation Method | 0: Keypad (FWD / REV / STOP keys) | 0: Keypad (FWD / REV / STOP keys) |

- (2) Press the FWD key to run the motor in the forward direction. Press the STOP key to stop it.
 (3) Press the REV key to run the motor in the reverse direction. Press the STOP key to stop it.


 For details on how to modify the function code data, see Section 3.4.4.2 "Configuring function codes -- Menu #1 "DATA SET."

3.5.6.2 Setting up a run command with digital input signals (terminals [FWD] and [REV])


Follow the procedure given below.

- (1) Configure the function codes as listed below.


| Function code | Name | Function code data | Factory default |
|---------------|------------------|----------------------------------|-----------------------------------|
| F02 | Operation Method | 1: External digital input signal | 0: Keypad (FWD / REV / STOP keys) |


 **Note** If terminal [FWD] and [REV] are ON, the F02 data cannot be changed. First turn those terminals OFF and then change the F02 data.

- (2) Connect the run forward switch between terminals [FWD] and [CM] and the run reverse switch between [REV] and [CM].

 **Note** Make sure that the SINK/SOURCE slide switch (SW1) is turned to the SINK position. If SW1 is in the SOURCE position, the inverter cannot run the motor.

- (3) Turn the run forward switch or run reverse switch ON (short-circuit) to run the motor in the forward or reverse direction, respectively.

 For precautions in wiring, refer to Section 3.3 "Mounting and Wiring the Inverter."

 For details on how to modify the function code data, see Section 3.4.4.2 "Configuring function codes -- Menu #1 "DATA SET."

Chapter 4

CONTROL AND OPERATION


This chapter provides the main block diagrams for the control logic of the FRENIC-VG series of inverters. It also contains overview tables of function codes and details of function codes.

Contents


| | | |
|---------|--|-------|
| 4.1 | Block Diagrams for Control Logic | 4-1 |
| 4.1.1 | Operation Command | 4-1 |
| 4.1.2 | Speed Command Selection Section..... | 4-2 |
| 4.1.3 | Acceleration/deceleration Calculation, Speed Limiting, and Position Control Input Section..... | 4-3 |
| 4.1.4 | Motor Speed/Line Speed Detection | 4-4 |
| 4.1.5 | Pulse Train Command Input Section and Position Detection Section..... | 4-5 |
| 4.1.6 | Speed Control (ASR) and Torque Command Section | 4-6 |
| 4.1.7 | Torque Limit, Torque Current Command, and Magnetic-flux Command Section..... | 4-7 |
| 4.1.8 | Current Control and Vector Control Section | 4-8 |
| 4.1.9 | PID Calculation Section..... | 4-9 |
| 4.1.10 | Load Adaptive Control Section | 4-10 |
| 4.1.11 | Motor Temperature Detection Section | 4-11 |
| 4.1.12 | Function Selection Digital Input | 4-12 |
| 4.1.13 | Function Selection Digital Output/Fault Output | 4-13 |
| 4.1.14 | Function Selection Analog Input/Output..... | 4-14 |
| 4.1.15 | Link Command Function Selection..... | 4-15 |
| 4.1.16 | Enabling to Write to/Recording Function Codes..... | 4-16 |
| 4.2 | Function Code Tables..... | 4-17 |
| 4.2.1 | Function Code Groups and Function Codes..... | 4-17 |
| 4.2.2 | About the Contents of Column Headers in Function Code Tables..... | 4-18 |
| 4.2.3 | Function Code Tables..... | 4-19 |
| 4.2.4 | Data Format List | 4-59 |
| 4.2.4.1 | Data Type 0 to 13 | 4-59 |
| 4.2.4.2 | Data Type 12 to 145 | 4-59 |
| 4.3 | Details of Function Codes..... | 4-76 |
| 4.3.1 | F codes (Fundamental Functions) | 4-76 |
| 4.3.2 | E codes (Extension Terminal Functions)..... | 4-118 |
| 4.3.3 | C codes (Control Functions) | 4-190 |
| 4.3.4 | P codes (Motor Parameter Functions) | 4-196 |
| 4.3.5 | H codes (High Performance Functions) | 4-211 |
| 4.3.6 | A codes (Alternative Motor Functions)..... | 4-264 |
| 4.3.7 | o codes (Option Functions) | 4-267 |
| 4.3.8 | L codes (Lift Functions)..... | 4-275 |

4.1 Block Diagrams for Control Logic

4.1.1 Operation Command




4.1.4 Motor Speed/Line Speed Detection



- 1) The OPC-VG1-PG (or OPC-VG1-PGo) has SW1 to switch the functions between motor speed detection, line speed detection, motor rotation position, pulse train command input, etc. For details, refer to Section 6.2 "PG Interface Expansion Card."
 - a) PG (SD): For mounting a line driver or open collector PG to the motor to detect the motor speed.
 - b) PG (SD): For using a line driver or open collector PG to detect the line speed of the process line, etc.
- 2) Under V/f control, speed detection and speed estimation calculations are invalid. (Note that monitoring of PG pulses is possible on the keypad.)
- 3) To detect the line speed with a TG (tachometer generator) for control, use the FV converter (OPC-VG1-FV or MCA-VG1-FV). The FV converter output should be entered to Ai (LINE-N).
- 4) The simulation mode selected by P01 (M1 drive control, data = 2) takes effect for M1, M2 and M3. Therefore, simulation (sequence) can be checked for a motor selected by F79 or an X terminal command.


4.1.5 Pulse Train Command Input Section and Position Detection Section



- 1) The OPC-VG1-PG (or OPC-VG1-PGo) has SW1 to switch the functions between motor speed detection, line speed detection, motor rotation position, pulse train command input, etc. For details, refer to Section 6.2 "PG Interface Expansion Card."
 - a) PG (PR): For synchronous operation with pulse train command input of line driver or open collector encoder signals.
 - b) PG (PD): For positioning (orientation) control with pulse train command input of line driver or open collector encoder signals.
- 2) As output through terminals [FA] and [FB], one of the following four items can be selected: pulse command value, converted pulse of internal speed command, detected pulse value, and detected motor speed.


States of all switches indicate factory setting.

4.1.6 Speed Control (ASR) and Torque Command Section




- 1) Selecting **RT1** or **RT2** (Select ASR and ACC/DEC time) switches the ASR and S-curve acceleration/deceleration functions at the same time.
- 2) In torque control mode or torque current control mode, the ASR output is held to zero.
- 3) Under V/f control, the load disturbance and oscillation suppressing observers are invalid.

4.1.7 Torque Limit, Torque Current Command, and Magnetic-flux Command Section




4.1.8 Current Control and Vector Control Section



1) This block diagram shows a control block for vector control for an induction motor with a speed sensor. Vector control instantly converts the fixed coordinates (U, V, W) to the rotation coordinates (d: magnetic flux, q: torque shaft) and decomposes the components into magnetic flux and torque component as an DC machine for mainly controlling the torque component only. The vector control without a speed sensor uses induced voltage to estimate the motor speed and performs vector control using the estimated speed. Driving a permanent magnet synchronous motor does not include magnetic flux calculation.


2) For ease of understanding, the block diagram is shown with motor M1 selected. When M2 or M3 is selected, replace M1-related function codes with M2- or M3-related ones, referring to the function codes list.

4.1.9 PID Calculation Section




- 1) When H20 (PID control, Mode selection) = 0, PID calculation is held to zero.
- 2) The **PID-OUT** (PID output value) is available under any of the following. Refer to the corresponding block diagrams given in Section 4.1.
 - Speed command: H27 (PID control, Speed command selection) = 1
 - Auxiliary speed command: H27 = 2
 - Torque command: H27 = 0 and H41 (Torque command source) = 5
 - Torque limiter: H27 = 0 and F42 or F43 (Torque limiter level 1 or 2 source) = 5

4.1.10 Load Adaptive Control Section




4.1.11 Motor Temperature Detection Section




- 1) For thermistor, you can select NTC, PTC thermistor or analog input.
 NTC (Negative Temperature Characteristic) thermistor: a thermistor having a negative relation between temperature and its resistance.
 PTC (Positive Temperature Characteristic) thermistor: a thermistor having a positive relation between temperature and its resistance.
- 2) The motor temperature monitor displays only when an NTC thermistor is connected or Ai [M-TMP] is input. When a PTC thermistor is connected, "--" appears.
- 3) Though thermistor is used for motor overheat protection, you can use an NTC thermistor for the secondary resistor compensation (R2 compensation) in primary angular frequency calculation to realize accurate torque control without being influenced by the motor temperature as described Section 4.1.8 "Current control and vector control section".

4.1.12 Function Selection Digital Input




- 1) Digital contact inputs are:
 Integrated standard input: Nine points from X1 to X9
 Optional OPC-VG1-DIOA: Four points from X11 to X14
 Optional OPC-VG1-DI: 16-bit data
 COM (link) system
- 2) The input (S06) from the COM (link) system does not replace the previous input, but is ORed with the previous input.
- 3) E14 "Normally open/normally closed" is applied only to standard input (X1 to X9) and ON/OFF state is applied to input after inverting with software.
- 4) To use the digital contact input data directly from the UPAC or SIU system, select **U-DI** (Universal DI).




4.1.13 Function Selection Digital Output/Fault Output

- 1) Five standard digital outputs via [Y1] to [Y4] and [Y5A] (relay) are available. Up to eight digital outputs via [Y11] to [Y18] on the optional OPC-VG1-DIOA can be added.
- 2) For direct digital output (related function code S07) from the COM (link) system, UPAC or SIU system, assign **U-DO** (Universal DO) to any of [Y2] through [Y18] using any of E16 through E27 (data = 25).
- 3) E28 (Y terminal function, Normal open/close) applies only to standard inputs ([Y1] to [Y4] and [Y5A]). The open/close setting specifies inversion of the ON/OFF state for output.




4.1.14 Function Selection Analog Input/Output

- 1) The I/O check tester function is displayed to one decimal place on the LCD screen.
- 2) For direct input of analog data (Ai) to an optional UPAC or SIU system, assign **U-AI** (Universal AI) to any of [Ai1] through [Ai4] using any of E49 through E52 (data = 14).
- 3) For direct output of analog data (Ao) from an optional UPAC or SIU system, assign **U-AO** (Universal AO) to any of [Ao1] through [Ao5] using any of E69 through E73 (data = 30).
- 4) To read out analog input data (Ai) to the COM (link) system (T-link, SX bus, field bus).
 - Assign **U-AI** (Universal AI) to any of [Ai1] through [Ai4] using any of E49 through E52 (data = 14).
 - Access to function code U61 (Ai1), U62 (Ai2), U63 (Ai3) or U64 (Ai4). Note that mounting an optional UPAC disables this function.
- 5) The COM (link) system is shown as **COM (link)**.
Be careful. It is dependent on the H30 and LE as described in Section 4.1.6.




4.1.15 Link Command Function Selection



States of all switches indicate factory setting.

1) Inverter analog input functions such as AUX-N1 (Auxiliary speed setting 1) and N-OR (Speed override) can be assigned from the COM (link) for use.


4.1.16 Enabling to Write to/Recording Function Codes



- 1) Later writing has always priority. Data written last is maintained and previous data is deleted on writing.
- 2) The all save and initialization procedures take about 2s. You cannot change data in this period.
- 3) When you have not assigned the [WE-KP] or the [WE-LK] to X functions, they are assumed as "ON".
- 4) You cannot enable or disable to write data from the UPAC, SIU system.
- 5) Data from the COM (link) or the UPAC are written to the RAM and are deleted when you turn off the power. If you want to keep them, execute the all save procedure.
- 6) The H30 and [LE] define the access from the COM (link) to the function S area separately. See the block diagrams for operation commands and speed reference.
- 7) You cannot use the COM (link) to change the function code P02.

4.2 Function Code Tables

4.2.1 Function Code Groups and Function Codes



| Function code group | | Function codes | Remarks | |
|--|-----------------|----------------|--|--|
| <u>F</u> undamental functions | F codes | F00 to F85 | | |
| <u>E</u> xtension terminal functions | E codes | E01 to E118 | E51, E52 | For the OPC-VG1-AIO option. |
| | | | E55, E56 | |
| | | | E59, E60 | |
| | | | E63, E64 | |
| | | | E67, E68 | |
| | | | E72, E73 | |
| | | | E77, E78 | |
| | | | E82, E83 | |
| | | | E103, E104 | |
| | | | E107, E108 | |
| <u>C</u> ontrol functions | C codes | C01 to C73 | | |
| Motor 1 <u>P</u> arameters | P codes | P01 to P51 | For M1. | |
| <u>H</u> igh performance function | H codes | H01 to H228 | | |
| <u>A</u> lternative motor parameters | A codes | A01 to A171 | For M2 and M3. | |
| <u>o</u> ption functions | o codes | o01 to o197 | o01 to o04 | For the OPC-VG1-DIA, DIB option. |
| | | | o05 | For the OPC-VG1-PG (PD) option. |
| | | | o06 to o08 | For the OPC-VG1-PG (LD) option. |
| | | | o09 to o11 | For the OPC-VG1-PMPG option. |
| | | | o12 to o19 | For the OPC-VG1-PG (PR) option. |
| | | | o30 to o32 | For communications options. (e.g., OPC-VG1-TL, OPC-VG1-CCL). |
| | | | o33, o34, o50 | For the high-speed serial communication terminal block OPC-VG1-TBSI. |
| | | | o38 to o40 | For the OPC-VG1-UPAC option. |
| | | | o101 to o197 | For communications options. |
| <u>L</u> ift functions | L codes | L01 to L15 | | |
| <u>U</u> ser functions | U codes | U01 to U64 | For the UPAC option. | |
| | | U101 to U150 | For manufacturers. | |
| <u>Sa</u> Fety functions | SF codes | SF00 to SF31 | For the functional safety card option. For details, refer to the Functional Safety Card Instruction Manual (INR-SI47-1541). | |
| <u>S</u> erial communication functions | S codes | S01 to S17 | Commands | Accessible via the communications link (T-Link, RS-485, SX-bus, ESX-bus and fieldbus), and via the UPAC. |
| <u>M</u> onitoring functions | M codes | M01 to M222 | Data monitor | Accessible in local mode (keypad), via the communications link (T-Link, RS-485, SX-bus, ESX-bus and fieldbus), and via the UPAC. |

4.2.2 About the Contents of Column Headers in Function Code Tables

| Column Headers | | Description |
|------------------------------|----------|--|
| Function code | | Function code group and code number |
| Communications address | 485 No. | Address to be used to refer to or change function code data using a communications option. Available for all communications options except OPC-VG1-TL. |
| | Link No. | Address to be used to refer to or change function code data using a communications option (OPC-VG1-TL, OPC-VG1-SX, etc.). Blank link number fields mean that the corresponding function codes cannot be accessed via a field option. |
| Name | | Name assigned to a function code. |
| Dir. | | Number of subdirectories in the keypad directory structure. 0: Parent directory having no subdirectories 1: Subdirectory 2 or more: Parent directory having the specified number of subdirectories |
| Data setting range | | Allowable data setting range and definition of each data. |
| Change when running | | Indicates whether the function code data can be changed or not when the inverter is running. Y: Possible, N: Impossible |
| Default setting | | Data preset by factory default. If data is changed from the factory default, it is displayed with an asterisk (*) on the keypad. Using function code H03 reverts changed function code data to the default values. |
| Data copying | | Indicates whether or not the function code data can be copied when you copy the data stored in the keypad memory of a source inverter to other destination inverters. |
| Initialization | | Indicates whether or not the function code data can be initialized to the default value by function code H03 (Data initialization). Y: Possible, N: Impossible |
| Format type | | Indicates a format type to be used to refer to or change function code data via the communications link. |
| Drive control (Availability) | | Indicates whether or not the function code is available to the individual drive controls. Y: Available, N: Not available Drive controls: VC w/ PG: Vector control for induction motor (IM) with speed sensor VC w/o PG: Vector control for induction motor (IM) without speed sensor V/f: V/f control for induction motor (IM) VC for PMSM: Vector control for permanent magnet synchronous motor (PMSM) with speed sensor |

4.2.3 Function Code Tables

■ F codes (Fundamental Functions)

| Function code | Communications address | | Name | Dir. | Data setting range | Change when running | Default setting | Data copying | Initialization | Format type | Drive control | | | Remarks |
|---------------|------------------------|----------|---|------|---|---------------------|-----------------|--------------|----------------|-------------|---------------|-----------|-----|---------|
| | 485 No. | Link No. | | | | | | | | | VC w/ PG | VC w/o PG | V/f | |
| F00 | 0h | 50h | Data Protection | 0 | 0 or 1 0: Enable data change 1: Protect data This write-protects data from the keypad. H29 defines write-protect from the communications link (T-link, RS-485, etc.) | N | 0 | N | Y | 40 | Y | Y | Y | Y |
| F01 | 1h | h | Speed Command N1 | 0 | 0 to 9 0: Keypad (⏏/⏏) keys 1: Analog input to terminal [12](0 to ±10V) 2: Analog input to terminal [12](0 to +10V) 3: UP/DOWN control (Initial speed = 0) 4: UP/DOWN control (Initial speed = Last value) 5: UP/DOWN control (Initial speed = Creep speed 1 or 2) 6: DIA card input 7: DIB card input 8: N-REFV input to terminal [Ai1] 9: N-REFC input to terminal [Ai2] F01 defines the command source that specifies a speed command. | N | 0 | Y | Y | 41 | Y | Y | Y | Y |
| F02 | 2h | h | Operation Method | 0 | 0 or 1 0: Keypad (FWD/REV/STOP) keys (Local mode) 1: External signals to terminals FWD/REV (Remote mode) F02 defines a run command source | N | 0 | Y | Y | 42 | Y | Y | Y | Y |
| F03 | 3h | 51h | Maximum Speed M1 | 3 | 50 to 30000 r/min | N | 1500 | Y | N | 0 | Y | Y | Y | Y |
| F04 | 4h | 52h | Rated Speed M1 | 1 | 50 to 30000 r/min | N | * | Y | N | 0 | Y | Y | Y | Y |
| F05 | 5h | 53h | Rated Voltage M1 | 1 | 80 to 999 V | N | * | Y | N | 0 | Y | Y | Y | Y |
| F07 | 7h | 54h | Acceleration Time 1 | 0 | 0.01 to 99.99 s 100.0 to 999.9 s 1000 to 3600 s | Y | 5.00 | Y | Y | 13 | Y | Y | Y | Y |
| F08 | 8h | 55h | Deceleration Time 1 | 0 | 0.01 to 99.99 s 100.0 to 999.9 s 1000 to 3600 s | Y | 5.00 | Y | Y | 13 | Y | Y | Y | Y |
| F10 | Ah | 56h | M1 Electronic Thermal Overload Protection (Select motor characteristics) | 3 | 0 to 2 0: Disable (For a VG-dedicated motor) 1: Enable (For a general-purpose motor with shaft-driven cooling fan) 2: Enable (For an inverter-driven motor with separately powered cooling fan) | Y | 0 | Y | N | 85 | Y | Y | Y | Y |
| F11 | Bh | 57h | (Detection level) | 1 | 0.01 to 99.99 A 100.0 to 999.9 A 1000 to 2000 A | Y | * | Y | N | 13 | Y | Y | Y | Y |
| F12 | Ch | 58h | (Thermal time constant) | 1 | 0.5 to 75.0 min | Y | * | Y | N | 2 | Y | Y | Y | Y |
| F14 | Eh | h | Restart Mode after Momentary Power Failure (Mode selection) | 0 | 0 to 5 0: No restart (Trip immediately, with alarm $\mathcal{L}\mathcal{L}$) 1: No restart (Trip after recovery from power failure, with alarm $\mathcal{L}\mathcal{L}$) 2: No restart (Trip after decelerate-to-stop, with alarm $\mathcal{L}\mathcal{L}$) 3: Restart (Continue to run) 4: Restart at the frequency at which the power failure occurred 5: Restart at the starting frequency | Y | 0 | Y | Y | 0 | Y | Y | Y | Y |
| F17 | 11h | h | Gain (for terminal [12] input) | 0 | 0.0 to 200.0% Ratio to analog speed setting on terminal [12]. Limited to ±110% of the maximum speed. | Y | 100.0 | Y | Y | 2 | Y | Y | Y | Y |
| F18 | 12h | h | Bias (for terminal [12] input) | 0 | -30000 to 30000 r/min Bias to analog speed setting on terminal [12]. Limited to ±110% of the maximum speed | Y | 0 | Y | Y | 5 | Y | Y | Y | Y |
| F20 | 14h | 59h | DC Braking (Braking starting speed) | 3 | 0 to 3600 r/min | Y | 0 | Y | Y | 0 | Y | Y | Y | N |
| F21 | 15h | 5Ah | (Braking level) | 1 | 0 to 100% | Y | 0 | Y | Y | 16 | Y | Y | Y | N |
| F22 | 16h | 5Bh | (Braking time) | 1 | 0.0 to 30.0 s 0.0: Disable 0.1 to 30.0 s | Y | 0.0 | Y | Y | 2 | Y | Y | Y | N |

*Depending upon the inverter's capacity.

| Function code | Communications address | | Name | Dir. | Data setting range | Change when running | Default setting | Data copying | Initialization | Format type | Drive control | | | Remarks | |
|---------------|------------------------|----------|--------------------------------------|------|---|---------------------|--|--------------|----------------|-------------|---------------|-----------|-----|---------|-------------|
| | 485 No. | Link No. | | | | | | | | | VC w/ PG | VC w/o PG | V/f | | VC for PMSM |
| F23 | 17h | 5Ch | Starting Speed (Speed) | 0 | 0.0 to 150.0 r/min Limited in order not to lower to 0.1 Hz or below (under vector control w/o speed sensor and V/f control). Use F23 for assuring the torque at startup. | N | 0.0 | Y | Y | 2 | Y | Y | Y | Y | |
| F24 | 18h | 5Dh | (Holding time) | 0 | 0.00 to 10.00 s | N | 0.00 | Y | Y | 3 | Y | Y | Y | Y | |
| F26 | 1Ah | 5Eh | Motor Sound (Carrier frequency) | 0 | 2 to 15 kHz 2: 2 kHz 3: 3 kHz 4: 4 kHz 5: 5 kHz 6: 6 kHz 7: 7 kHz 8, 9: 8 kHz 10, 11: 10 kHz 12, 13, 14: 12 kHz 15: 15 kHz This controls the carrier frequency to reduce an audible noise generated by the motor or electromagnetic noise from the inverter itself, to suppress the resonance with the machinery, and to decrease a leakage current from the output circuit wirings. | N | 8 for 55 kW or below 7 for 75 kW or above | Y | Y | 10 | Y | Y | Y | Y | |
| F36 | 24h | h | 30RY Drive Mode | 0 | 0 or 1 0: Excite relay (30) when an alarm occurs 1: Excite relay (30) when the inverter power is normally established | N | 0 | Y | Y | 43 | Y | Y | Y | Y | |
| F37 | 25h | 60h | Stop Speed (Speed) | 3 | 0.0 to 150.0 r/min Limited in order not to lower to 0.1 Hz or below (under vector control w/o speed sensor and V/f control). | N | 10.0 | Y | Y | 2 | Y | Y | Y | Y | |
| F38 | 26h | 61h | (Detection mode) | 1 | 0 or 1 0: Detected speed 1: Reference speed Fixed at "1" under V/f control | N | 0 | Y | Y | 90 | Y | N | N | Y | |
| F39 | 27h | 62h | (Zero speed control holding time) | 1 | 0.00 to 10.00 s Applies to when timing the application of the mechanical brake. | N | 0.50 | Y | Y | 3 | Y | N | N | Y | |
| F40 | 28h | 63h | Torque Limiter Mode 1 | 12 | 0 to 3 0: Disable limiter 1: Enable torque limiter 2: Enable power limiter 3: Enable torque current limiter | N | 0 | Y | Y | 44 | Y | Y | N | Y | |
| F41 | 29h | 64h | Torque Limiter Mode 2 | 1 | 0 to 3 0: Level 1 to all four quadrants 1: Level 1 to driving, Level 2 to braking 2: Level 1 to upper limit, Level 2 to lower limit 3: Level 1/Level 2 (switchable) to all four quadrants Levels 1 and 2 are specified by the source defined by F42 and F43, respectively. | N | 0 | Y | Y | 45 | Y | Y | Y | Y | |
| F42 | 2Ah | 65h | Torque Limiter Level 1 Source | 1 | 0 to 5 0: Function code F44 1: TL-REF1 input to terminal [Ai] 2: DIA card 3: DIB card 4: Communications link 5: PID output | N | 0 | Y | Y | 46 | Y | Y | Y | Y | |
| F43 | 2Bh | 66h | Torque Limiter Level 2 Source | 1 | 0 to 5 0: Function code F45 1: TL-REF1 input to terminal [Ai] 2: DIA card 3: DIB card 4: Communications link 5: PID output | N | 0 | Y | Y | 47 | Y | Y | Y | Y | |
| F44 | 2Ch | 67h | Torque Limiter Level 1 | 1 | -300 to 300% | Y | 150 | Y | Y | 5 | Y | Y | Y | Y | |
| F45 | 2Dh | 68h | Torque Limiter Level 2 | 1 | -300 to 300% | Y | 10 | Y | Y | 5 | Y | Y | Y | Y | |
| F46 | 2Eh | 69h | Mechanical Loss Compensation | 1 | -300.00 to 300.00% | Y | 0.00 | Y | Y | 7 | Y | Y | N | Y | |
| F47 | 2Fh | 6Ah | Torque Bias T1 | 1 | -300.00 to 300.00% Torque biases T1 to T3 are switchable with DI. | Y | 0.00 | Y | Y | 7 | Y | Y | N | Y | |
| F48 | 30h | h | Torque Bias T2 | 1 | -300.00 to 300.00% | Y | 0.00 | Y | Y | 7 | Y | Y | N | Y | |
| F49 | 31h | h | Torque Bias T3 | 1 | -300.00 to 300.00% | Y | 0.00 | Y | Y | 7 | Y | Y | N | Y | |
| F50 | 32h | h | Torque Bias Startup Timer | 1 | 0.00 to 1.00 s F50 specifies the time required for generating 300% torque. | Y | 0.00 | Y | Y | 3 | Y | Y | N | Y | |
| F51 | 33h | FBh | Torque Command Monitor (Polarity) | 1 | 0 or 1 0: Torque polarity 1: + for driving, - for braking F51 specifies the polarity of torque related data output (e.g., Ao monitor, LED monitor, and LCD monitor). | Y | 0 | Y | Y | 48 | Y | Y | Y | Y | |

| Function code | Communica-tions address | | Name | Dir. | Data setting range | Change when running | Default setting | Data copying | Initialization | Format type | Drive control | | | Remarks | |
|---------------|-------------------------|----------|--|------|--|---------------------|-----------------|--------------|----------------|-------------|---------------|-----------|----|---------|-------------|
| | 485 No. | Link No. | | | | | | | | | VC w/ PG | VC w/o PG | Vf | | VC for PMSM |
| F52 | 34h | h | LED Monitor (Display coefficient A) | 8 | -999.00 to 999.00 F52 specifies the conversion coefficient for displaying the load shaft speed and line speed on the LED monitor. Display value = Motor speed x (0.01 to 200.00) Only the setting range from 0.01 to 200.00 takes effect. The specification out of the range is limited. | Y | 1.00 | Y | Y | 12 | Y | Y | Y | | |
| F53 | 35h | h | (Display coefficient B) | 1 | -999.00 to 999.00 Display coefficient A: Maximum value Display coefficient B: Minimum value F52 and F53 specify the conversion coefficients for displaying the PID command, PID feedback amount, and PID output (process command). Display value = (Command or feedback value) x (Display coefficient A - B) + B | Y | 1.00 | Y | Y | 12 | Y | Y | Y | | |
| F54 | 36h | h | LED Monitor (Display filter) | 1 | 0.0 to 5.0 s | Y | 0.2 | Y | Y | 2 | Y | Y | Y | | |
| F55 | 37h | h | (Item selection) | 1 | 00 to 32 00: Detected speed 1 or Reference speed (r/min) (switchable with F56) 01: Reference speed 4 (ASR input) (r/min) 02: Output frequency (after slip compensation) (Hz) 03: Reference torque current (%) 04: Reference torque (%) 05: Calculated torque (%) 06: Power consumption (Motor output) (kW or HP, switchable with F60) 07: Output current (A) 08: Output voltage (V) 09: DC link bus voltage (V) 10: Magnetic flux command (%) 11: Calculated magnetic flux (%) 12: Motor temperature (°C) (When no NTC thermistor is used, "---" appears.) 13: Load shaft speed (r/min) (Detected or commanded, switchable with F56) 14: Line speed (m/min) (Detected or commanded, switchable with F56) 15: Ai adjustment value on [I2] (%) 16: Ai adjustment value on [Ai1] (%) 17: Ai adjustment value on [Ai2] (%) 18: Ai adjustment value on [Ai3] (%) 19: Ai adjustment value on [Ai4] (%) The following data will be hidden depending upon the mode or options. 20: PID command (%) 21: PID feedback amount (%) 22: PID output (%) 23: Option monitor 1 (HEX) 24: Option monitor 2 (HEX) 25: Option monitor 3 (DEC) 26: Option monitor 4 (DEC) 27: Option monitor 5 (DEC) 28: Option monitor 6 (DEC) 29: - 30: Load factor (%) 31: Input power (kW or HP, switchable with F60) 32: Input watt-hour (x 100 kWh) | Y | 0 | Y | Y | 49 | | | | | |
| F56 | 38h | h | (Display when stopped) | 1 | 0 or 1 0: Reference speed 1: Detected speed F56 switches the display data between the reference speed and detected one when the motor stops. It applies to the speed (F55 = 0), the load shaft speed (F55 = 13), and the line speed (F55 = 14). | Y | 0 | Y | Y | 50 | Y | Y | Y | | |

| Function code | Communications address | | Name | Dir. | Data setting range | Change when running | Default setting | Data copying | Initialization | Format type | Drive control | | | | Remarks |
|---------------|------------------------|----------|-----------------------------------|------|--|---------------------|-----------------|--------------|----------------|-------------|---------------|-----------|----|-------------|---------|
| | 485 No. | Link No. | | | | | | | | | VC w/ PG | VC w/o PG | Vf | VC for PMSM | |
| F57 | 39h | h | LCD Monitor (Item selection) | 1 | 0 or 1 0: Running status, rotation direction and operation guide 1: Bar charts for detected speed 1, current and reference torque F57 switches the Running mode screen. | Y | 0 | Y | Y | 51 | Y | Y | Y | Y | |
| F58 | 3Ah | h | (Language selection) | 1 | 0 to 7 0: Japanese 1: English 2-5: - 6: Chinese 7: Korean | Y | 0 | Y | N | 52 | Y | Y | Y | Y | |
| F59 | 3Bh | | (Contrast control) | 1 | 0 (Low) to 10 (High) | Y | 5 | Y | Y | 0 | Y | Y | Y | Y | |
| F60 | 3Ch | | Output Unit (HP/kW) | 0 | 0 or 1 0: kW 1: HP F60 switches the display unit between kW and HP on the LED monitor and LCD monitor for the power consumption (F55 = 6) and input power (F55 = 31). It also switches the display table between kW and HP for motor 1 selection (P02). | Y | 0 | Y | Y | 53 | Y | Y | Y | Y | |
| F61 | 3Dh | 6Bh | ASR1 (P-gain) | 10 | 0.1 to 500.0 times | Y | 10.0 | Y | Y | 2 | Y | Y | N | Y | |
| F62 | 3Eh | 6Ch | (Integral constant) | 1 | 0.000 to 10.000 s P control when F62 = 0.000 | Y | 0.200 | Y | Y | 4 | Y | Y | N | Y | |
| F63 | 3Fh | 6Dh | (Feedforward gain) | 1 | 0.000 to 9.999 s | Y | 0.000 | Y | Y | 4 | Y | Y | N | Y | |
| F64 | 40h | 6Eh | (Input filter) | 1 | 0.000 to 5.000 s | Y | 0.040 | Y | Y | 4 | Y | Y | Y | Y | |
| F65 | 41h | 6Fh | (Detection filter) | 1 | 0.000 to 0.100 s F65 specifies a time constant of the first order delay filter for detected speed. | Y | 0.005 | Y | Y | 4 | Y | Y | N | Y | |
| F66 | 42h | 70h | (Output filter) | 1 | 0.000 to 0.100 s F66 specifies a time constant of the first order delay filter for torque command. | N | 0.002 | Y | Y | 4 | Y | Y | N | Y | |
| F67 | 43h | 71h | S-curve Acceleration 1 (Start) | 1 | 0 to 50% | Y | 0 | Y | Y | 0 | Y | Y | Y | Y | |
| F68 | 44h | 72h | (End) | 1 | 0 to 50% | Y | 0 | Y | Y | 0 | Y | Y | Y | Y | |
| F69 | 45h | 73h | S-curve Deceleration 1 (Start) | 1 | 0 to 50% | Y | 0 | Y | Y | 0 | Y | Y | Y | Y | |
| F70 | 46h | 74h | (End) | 1 | 0 to 50% | Y | 0 | Y | Y | 0 | Y | Y | Y | Y | |
| F72 | 48h | h | Pre-excitation Mode | 4 | 0 or 1 0: Cause pre-excitation at the time of startup (Pre-excitation continues for the duration specified by F74.) 1: Cause pre-excitation at the time of startup and stop. (Pre-excitation continues for the duration specified by F74 or until the magnetic flux command reaches the detection level specified by E48, whichever is earlier.) | N | 0 | Y | Y | 230 | Y | Y | N | N | |
| F73 | 49h | h | Magnetic Flux Level at Light Load | 1 | 10 to 100% | Y | 100 | Y | Y | 16 | Y | N | N | N | |
| F74 | 4Ah | 75h | Pre-excitation (Duration) | 1 | 0.0 to 10.0 s Turning a run command (FWD, REV) ON automatically continues pre-excitation for the duration specified by F74. | N | 0.0 | Y | Y | 2 | Y | Y | N | N | |
| F75 | 4Bh | 76h | (Initial level) | 1 | 100 to 400% | N | 100 | Y | Y | 0 | Y | Y | N | N | |
| F76 | 4Ch | h | Speed Limiter (Mode) | 3 | 0 to 3 0: Level 1 for forward rotation, Level 2 for reverse rotation 1: Level 1 for both forward and reverse rotations 2: Level 1 for upper limit, Level 2 for lower limit 3: Level 1 for forward rotation, Level 2 for reverse rotation (Terminal [12] input added as a bias) | N | 0 | Y | Y | 91 | Y | Y | Y | Y | |
| F77 | 4Dh | 4Fh | (Level 1) | 1 | -110.0 to 110.0% | Y | 100.0 | Y | Y | 6 | Y | Y | Y | Y | |
| F78 | 4Eh | FEh | (Level 2) | 1 | -110.0 to 110.0% | Y | 100.0 | Y | Y | 6 | Y | Y | Y | Y | |
| F79 | 4Fh | 77h | Motor Selection (M1, M2, M3) | 0 | 0 to 2 0: Select M1 (Note that switching of contacts by X terminal functions has priority over this function code setting.) 1: Select M2 (X terminal functions disabled) 2: Select M3 (X terminal functions disabled) Select a motor to be used from M1, M2 and M3. | N | 0 | Y | N | 54 | Y | Y | Y | Y | |

| Function code | Communications address | | Name | Dir. | Data setting range | Change when running | Default setting | Data copying | | Format type | Drive control | | | Remarks |
|---------------|------------------------|----------|--|------|---|---------------------|-----------------|----------------|----------------|-------------|---------------|-----------|-----|---------|
| | 485 No. | Link No. | | | | | | Initialization | Initialization | | VC w/ PG | VC w/o PG | V/f | |
| F80 | 50h | h | Switching between HD, MD and LD Drive Modes | 0 | 0 to 3 0, 2: HD (High duty mode, overload capability 150%-1 min./200%-3 sec.) 1: LD (Low duty mode, overload capability 120%-1 min.) 3: MD (Medium duty mode, overload capability 150%-1 min.) F80 switches the drive mode between the HD, MD and LD. | N | 0 | Y | N | 56 | Y | Y | Y | Y |
| F81 | 51h | h | Offset for Speed Setting on Terminal [12] | 3 | -30000 to 30000 r/min F81 specifies the offset for analog speed input on terminal [12]. | Y | 0 | Y | Y | 5 | Y | Y | Y | Y |
| F82 *1 | 52h | h | Dead Zone for Speed Setting on Terminal [12] | 1 | 0.0 to 150.0 r/min F82 specifies the dead zone speed for analog speed input on terminal [12] to limit the speed setting value within the range of ±F82 data to 0 r/min. | Y | 0 | Y | Y | 2 | Y | Y | Y | Y |
| F83 | 53h | h | Filter for Speed Setting on Terminal [12] | 1 | 0.000 to 5.000 s | Y | 0.005 | Y | Y | 4 | Y | Y | Y | Y |
| F84 | 54h | h | Display Coefficient for Input Watt-hour Data | 0 | 0.000 to 9999 F84 specifies a display coefficient for displaying the input watt-hour data (M116). M116 = F84 x M115 (Input watt-hour, kWh) Specification of 0.000 clears the input watt-hour data. | Y | 0.010 | Y | Y | 101 | Y | Y | Y | Y |
| F85 | 55h | h | Display Filter for Calculated Torque | 0 | 0.000 to 1.000 s F85 specifies a display filter for calculated torque output for monitoring (LED monitor and LCD monitor). | Y | 0.100 | Y | Y | 4 | Y | Y | Y | Y |

*1 Available in the ROM version H1/2 0019 or later.

■ E codes (Extension Terminal Functions)

| Function code | Communications address | | Name | Dir. | Data setting range | Change when running | Default setting | Data copying | Initialization | Format type | Drive control | | | Remarks |
|---------------|------------------------|----------|------------------------|------|---|---------------------|-----------------|--------------|----------------|-------------|---------------|-----------|----|---------|
| | 485 No. | Link No. | | | | | | | | | VC w/ PG | VC w/o PG | Vf | |
| E01 | 101h | 78h | Terminal [X1] Function | 13 | 00 to 79 | N | 0 | Y | Y | 57 | | | | |
| | | | | | 00: 01, 02, 03: Select multistep speed (1 to 15 steps) 00: SS1 , 01: SS2 , 02: SS4 , 03: SS8 | | | | | | Y | Y | Y | Y |
| | | | | | 4,5: Select ASR and ACC/DEC time (4 steps) 4: RT1 , 5: RT2 | | | | | | Y | Y | Y | Y |
| | | | | | 6: Enable 3-wire operation HLD | | | | | | Y | Y | Y | Y |
| | | | | | 7: Coast to a stop BX | | | | | | Y | Y | Y | Y |
| | | | | | 8: Reset alarm RST | | | | | | Y | Y | Y | Y |
| | | | | | 9: Enable external alarm trip THR | | | | | | Y | Y | Y | Y |
| | | | | | 10: Ready for jogging JOG | | | | | | Y | Y | Y | Y |
| | | | | | 11: Select speed command N2/N1 N2/N1 | | | | | | Y | Y | Y | Y |
| | | | | | 12: Select motor 2 M-CH2 | | | | | | Y | Y | Y | Y |
| | | | | | 13: Select motor 3 M-CH3 | | | | | | Y | Y | Y | Y |
| | | | | | 14: Enable DC braking DCBRK | | | | | | Y | Y | Y | N |
| | | | | | 15: Clear ACC/DEC to zero CLR | | | | | | Y | Y | Y | Y |
| | | | | | 16: Switch creep speed under UP/DOWN control CRP-N2/N1 | | | | | | Y | Y | Y | Y |
| | | | | | 17: UP (Increase speed) UP | | | | | | Y | Y | Y | Y |
| | | | | | 18: DOWN (Decrease speed) DOWN | | | | | | Y | Y | Y | Y |
| | | | | | 19: Enable data change with keypad WE-KP | | | | | | Y | Y | Y | Y |
| | | | | | 20: Cancel PID control KP/PID | | | | | | Y | Y | Y | Y |
| | | | | | 21: Switch normal/inverse operation IVS | | | | | | Y | Y | Y | Y |
| | | | | | 22: Interlock (52-2) IL | | | | | | Y | Y | Y | Y |
| | | | | | 23: Enable data change via communications link WE-LK | | | | | | Y | Y | Y | Y |
| | | | | | 24: Enable communications link LE | | | | | | Y | Y | Y | Y |
| | | | | | 25: Universal DI U-DI | | | | | | Y | Y | Y | Y |
| | | | | | 26: Enable auto search for idling motor speed at starting STM | | | | | | Y | Y | Y | Y |
| | | | | | 27: Synchronous operation command (PG (PR) optional function) SYC | | | | | | Y | N | N | Y |
| | | | | | 28: Lock at zero speed LOCK | | | | | | Y | N | N | Y |
| | | | | | 29: Pre-excitation EXITE | | | | | | Y | Y | N | N |
| | | | | | 30: Cancel speed limiter (Related codes: F76, F77, F78) N-LIM | | | | | | Y | Y | Y | Y |
| | | | | | 31: Cancel H41 (Torque command) H41-CCL | | | | | | Y | Y | N | Y |
| | | | | | 32: Cancel H42 (Torque current command) H42-CCL | | | | | | Y | Y | N | Y |
| | | | | | 33: Cancel H43 (Magnetic flux command) H43-CCL | | | | | | Y | N | N | N |
| | | | | | 34: Cancel F40 (Torque limiter mode 1) F40-CCL | | | | | | Y | Y | N | Y |
| | | | | | 35: Select torque limiter level 2/1 TL2/TL1 | | | | | | Y | Y | Y | Y |
| | | | | | 36: Bypass ACC/DEC processor BPS | | | | | | Y | Y | Y | Y |
| | | | | | 37, 38: Select torque bias command 37: TB1 , 38: TB2 | | | | | | Y | Y | N | Y |
| | | | | | 39: Select droop control DROOP | | | | | | Y | Y | N | Y |
| | | | | | 40: Zero-hold Ai1 ZH-AI1 | | | | | | Y | Y | Y | Y |
| | | | | | 41: Zero-hold Ai2 ZH-AI2 | | | | | | Y | Y | Y | Y |
| | | | | | 42: Zero-hold Ai3 (AIO optional function) ZH-AI3 | | | | | | Y | Y | Y | Y |
| | | | | | 43: Zero-hold Ai4 (AIO optional function) ZH-AI4 | | | | | | Y | Y | Y | Y |
| | | | | | 44: Reverse Ai1 polarity REV-AI1 | | | | | | Y | Y | Y | Y |
| | | | | | 45: Reverse Ai2 polarity REV-AI2 | | | | | | Y | Y | Y | Y |
| | | | | | 46: Reverse Ai3 polarity (AIO optional function) REV-AI3 | | | | | | Y | Y | Y | Y |
| | | | | | 47: Reverse Ai4 polarity (AIO optional function) REV-AI4 | | | | | | Y | Y | Y | Y |
| | | | | | 48: Inverse PID output PID-INV | | | | | | Y | Y | Y | Y |
| | | | | | 49: Cancel PG alarm PG-CCL | | | | | | Y | N | N | Y |
| | | | | | 50: Cancel undervoltage alarm LU-CCL | | | | | | Y | Y | Y | Y |
| | | | | | 51: Hold Ai torque bias H-TB | | | | | | Y | Y | N | Y |
| | | | | | 52: STOP1 (Decelerate to stop with normal deceleration time) STOP1 | | | | | | Y | Y | Y | Y |
| | | | | | 53: STOP2 (Decelerate to stop with deceleration time 4) STOP2 | | | | | | Y | Y | Y | Y |
| | | | | | 54: STOP3 (Decelerate to stop with max. braking torque, ignoring the deceleration time setting) STOP3 | | | | | | Y | Y | Y | Y |
| | | | | | 55: Latch DIA data (DIA optional function) DIA | | | | | | Y | Y | Y | Y |
| | | | | | 56: Latch DIB data (DIB optional function) DIB | | | | | | Y | Y | Y | Y |

| Function code | Communications address | | Name | Dir. | Data setting range | Change when running | Default setting | Data copying | Initialization | Format type | Drive control | | | | Remarks |
|------------------------------|------------------------|----------|---|------|---|---------------------|-----------------|--------------|----------------|-------------|---------------|-----------|----|-------------|---------|
| | 485 No. | Link No. | | | | | | | | | VC w/ PG | VC w/o PG | Vf | VC for PMSM | |
| E01 | 101h | 78h | Terminal [X1] Function | 13 | 57: Cancel multiplex system MT-CCL | N | 1 | Y | Y | 57 | Y | N | Y | N | |
| | | | | | 58-67: Custom Di1-Di10 C-DI1 to C-DI10 | | | | | | Y | N | Y | Y | |
| | | | | | 68: Select load adaptive parameters 2/1 (Available soon) AN-P2/1 | | | | | | Y | N | N | Y | |
| | | | | | 69: Cancel PID components PID-CCL | | | | | | Y | Y | Y | Y | |
| | | | | | 70: Enable PID FF component PID-FF | | | | | | Y | Y | Y | Y | |
| | | | | | 71: Reset completion of speed limit calculation (Available soon) NL-RST | | | | | | Y | N | N | Y | |
| | | | | | 72: Toggle signal 1 TGL1 | | | | | | Y | Y | Y | Y | |
| | | | | | 73: Toggle signal 2 TGL2 | | | | | | Y | Y | Y | Y | |
| | | | | | 74: Cause external mock alarm FTB | | | | | | Y | Y | Y | Y | |
| | | | | | 75: Cancel NTC thermistor alarm NTC-CCL | | | | | | Y | Y | Y | Y | |
| | | | | | 76: Cancel lifetime alarm signal LF-CCL | | | | | | Y | Y | Y | Y | |
| | | | | | 77: -- | | | | | | - | - | - | - | |
| | | | | | 78: Switch PID feedback signals PID-1/2 | | | | | | Y | Y | Y | Y | |
| | | | | | 79: Select PID torque bias TB-PID | | | | | | Y | Y | N | Y | |
| E02 | 102h | 79h | Terminal [X2] Function | 1 | 0 to 79 (See Terminal [X1] Function.) | N | 1 | Y | Y | 57 | Y | Y | Y | Y | |
| E03 | 103h | 7Ah | Terminal [X3] Function | 1 | 0 to 79 (See Terminal [X1] Function.) | N | 2 | Y | Y | 57 | Y | Y | Y | Y | |
| E04 | 104h | 7Bh | Terminal [X4] Function | 1 | 0 to 79 (See Terminal [X1] Function.) | N | 3 | Y | Y | 57 | Y | Y | Y | Y | |
| E05 | 105h | 7Ch | Terminal [X5] Function | 1 | 0 to 79 (See Terminal [X1] Function.) | N | 4 | Y | Y | 57 | Y | Y | Y | Y | |
| E06 | 106h | 7Dh | Terminal [X6] Function | 1 | 0 to 79 (See Terminal [X1] Function.) | N | 5 | Y | Y | 57 | Y | Y | Y | Y | |
| E07 | 107h | 7Eh | Terminal [X7] Function | 1 | 0 to 79 (See Terminal [X1] Function.) | N | 7 | Y | Y | 57 | Y | Y | Y | Y | |
| E08 | 108h | 7Fh | Terminal [X8] Function | 1 | 0 to 79 (See Terminal [X1] Function.) | N | 8 | Y | Y | 57 | Y | Y | Y | Y | |
| E09 | 109h | 80h | Terminal [X9] Function | 1 | 0 to 79 (See Terminal [X1] Function.) | N | 9 | Y | Y | 57 | Y | Y | Y | Y | |
| E10 | 10Ah | 81h | Terminal [X11] Function | 1 | 0 to 79 (See Terminal [X1] Function.) | N | 25 | Y | Y | 57 | Y | Y | Y | Y | |
| E11 | 10Bh | 82h | Terminal [X12] Function | 1 | 0 to 79 (See Terminal [X1] Function.) | N | 25 | Y | Y | 57 | Y | Y | Y | Y | |
| E12 | 10Ch | 83h | Terminal [X13] Function | 1 | 0 to 79 (See Terminal [X1] Function.) | N | 25 | Y | Y | 57 | Y | Y | Y | Y | |
| E13 | 10Dh | 84h | Terminal [X14] Function | 1 | 0 to 79 (See Terminal [X1] Function.) | N | 25 | Y | Y | 57 | Y | Y | Y | Y | |
| E14 | 10Eh | h | X Terminal Function (Normal open/close) | 0 | 0000 to 01FF 0: Normal open 1: Normal close E14 specifies whether to open or close the contact for terminals [X1] to [X9]. | N | 0000 | Y | Y | 35 | Y | Y | Y | Y | |
| E15 | 10Fh | 85h | Terminal [Y1] Function | 13 | 00 to 84 | N | 1 | Y | Y | 58 | Y | Y | Y | Y | |
| | | | | | 00: Inverter running RUN | | | | | | Y | Y | Y | Y | |
| | | | | | 01: Speed valid N-EX | | | | | | Y | Y | Y | Y | |
| | | | | | 02: Speed agreement 1 N-AG1 | | | | | | Y | Y | N | Y | |
| | | | | | 03: Speed arrival signal N-AR | | | | | | Y | Y | Y | Y | |
| | | | | | 04: Speed detected 1 N-DT1 | | | | | | Y | Y | Y | Y | |
| | | | | | 05: Speed detected 2 N-DT2 | | | | | | Y | Y | Y | Y | |
| | | | | | 06: Speed detected 3 N-DT3 | | | | | | Y | Y | Y | Y | |
| | | | | | 07: Undervoltage detected (Inverter stopped) LU | | | | | | Y | Y | Y | Y | |
| | | | | | 08: Torque polarity detected (braking/driving) B/D | | | | | | Y | Y | N | Y | |
| | | | | | 09: Torque limiting TL | | | | | | Y | Y | Y | Y | |
| | | | | | 10: Torque detected 1 T-DT1 | | | | | | Y | Y | Y | Y | |
| | | | | | 11: Torque detected 2 T-DT2 | | | | | | Y | Y | Y | Y | |
| | | | | | 12: Keypad operation enabled KP | | | | | | Y | Y | Y | Y | |
| | | | | | 13: Inverter stopped STOP | | | | | | Y | Y | Y | Y | |
| | | | | | 14: Inverter ready to run RDY | | | | | | Y | Y | Y | Y | |
| | | | | | 15: Magnetic flux detected MF-DT | | | | | | Y | Y | N | N | |
| | | | | | 16: Motor M2 selected SW-M2 | | | | | | Y | Y | Y | Y | |
| | | | | | 17: Motor M3 selected SW-M3 | | | | | | Y | Y | Y | Y | |
| | | | | | 18: Brake release signal BRK | | | | | | Y | Y | N | Y | |
| | | | | | 19: Alarm content 1 AL1 | | | | | | Y | Y | Y | Y | |
| | | | | | 20: Alarm content 2 AL2 | | | | | | Y | Y | Y | Y | |
| | | | | | 21: Alarm content 4 AL4 | | | | | | Y | Y | Y | Y | |
| | | | | | 22: Alarm content 8 AL8 | | | | | | Y | Y | Y | Y | |
| | | | | | 23: Cooling fan in operation FAN | | | | | | Y | Y | Y | Y | |
| | | | | | 24: Resetting TRY | | | | | | Y | Y | Y | Y | |
| 25: Universal DO U-DO | Y | Y | Y | Y | | | | | | | | | | | |

| Function code | Communications address | | Name | Dir. | Data setting range | Change when running | Default setting | Data copying | Initialization | Format type | Drive control | | | | Remarks | | | | | | | | | | | |
|---------------|------------------------|----------|------------------------|------|---|---------------------|-----------------|--------------|----------------|-------------|---------------|-----------|------------------------|-------------|---------|---------------------------------------|---|----|---|---|----|---|---|---|---|--|
| | 485 No. | Link No. | | | | | | | | | VC w/ PG | VC w/o PG | Vf | VC for PMSM | | | | | | | | | | | | |
| E15 | 10Fh | 85h | Terminal [Y1] Function | 13 | 26: Heat sink overheat early warning INV-OH | | | | | | Y | Y | Y | Y | | | | | | | | | | | | |
| | | | | | 27: Synchronization completion signal SY-C | | | | | | Y | N | N | N | | | | | | | | | | | | |
| | | | | | 28: Lifetime alarm LIFE | | | | | | Y | Y | Y | Y | | | | | | | | | | | | |
| | | | | | 29: Under acceleration U-ACC | | | | | | Y | Y | Y | Y | | | | | | | | | | | | |
| | | | | | 30: Under deceleration U-DEC | | | | | | Y | Y | Y | Y | | | | | | | | | | | | |
| | | | | | 31: Inverter overload early warning INV-OL | | | | | | Y | Y | Y | Y | | | | | | | | | | | | |
| | | | | | 32: Motor overheat early warning M-OH | | | | | | Y | Y | Y | Y | | | | | | | | | | | | |
| | | | | | 33: Motor overload early warning M-OL | | | | | | Y | Y | Y | Y | | | | | | | | | | | | |
| | | | | | 34: DB overload early warning DB-OL | | | | | | Y | Y | N | Y | | | | | | | | | | | | |
| | | | | | 35: Link transmission error LK-ERR | | | | | | Y | Y | Y | Y | | | | | | | | | | | | |
| | | | | | 36: In limiting under load adaptive control ANL | | | | | | Y | N | N | Y | | | | | | | | | | | | |
| | | | | | 37: In calculation under load adaptive control ANC | | | | | | Y | N | N | Y | | | | | | | | | | | | |
| | | | | | 38: Analog torque bias being held TBHI | | | | | | Y | Y | N | Y | | | | | | | | | | | | |
| | | | | | 39 to 48: Custom Do1-Do10 C-DO1 to C-DO10 | | | | | | Y | Y | Y | Y | | | | | | | | | | | | |
| | | | | | 49: - | | | | | | - | - | - | - | | | | | | | | | | | | |
| | | | | | 51: Multiplex system communications link being established MTS | | | | | | Y | N | Y | N | | | | | | | | | | | | |
| | | | | | 52: Answerback to cancellation of multiplex system MEC-AB | | | | | | Y | N | Y | N | | | | | | | | | | | | |
| | | | | | 53: Multiplex system master selected MSS | | | | | | Y | N | Y | N | | | | | | | | | | | | |
| | | | | | 54: Multiplex system local station failure AL-SF | | | | | | Y | N | Y | N | | | | | | | | | | | | |
| | | | | | 55: Stopped due to communications link error LES | | | | | | Y | Y | Y | Y | | | | | | | | | | | | |
| | | | | | 56: Alarm output (for any alarm) ALM | | | | | | Y | Y | Y | Y | | | | | | | | | | | | |
| | | | | | 57: Light alarm L-ALM | | | | | | Y | Y | Y | Y | | | | | | | | | | | | |
| | | | | | 58: Maintenance timer MNT | | | | | | Y | Y | Y | Y | | | | | | | | | | | | |
| | | | | | 59: Braking transistor broken DBAL | | | | | | Y | Y | Y | Y | | | | | | | | | | | | |
| | | | | | 60: DC fan locked DCFL | | | | | | Y | Y | Y | Y | | | | | | | | | | | | |
| | | | | | 61: Speed agreement 2 N-AG2 | | | | | | Y | Y | N | Y | | | | | | | | | | | | |
| | | | | | 62: Speed agreement 3 N-AG3 | | | | | | Y | Y | N | Y | | | | | | | | | | | | |
| | | | | | 63: Axial fan stopped MFAN | | | | | | Y | Y | Y | Y | | | | | | | | | | | | |
| | | | | | 64: Arbitrarily assigned RDY (*1) AS-RDY | | | | | | - | - | - | - | | | | | | | | | | | | |
| | | | | | 65: - | | | | | | - | - | - | - | | | | | | | | | | | | |
| | | | | | 66: Answerback to droop control enabled DSAB | | | | | | Y | Y | N | Y | | | | | | | | | | | | |
| | | | | | 67: Answerback to cancellation of torque command/torque current command (H41-CCL/H42-CCL) TCL-C | | | | | | Y | Y | N | Y | | | | | | | | | | | | |
| | | | | | 68: Answerback to cancellation of torque limiter mode 1 (F40-CCL) F40-AB | | | | | | Y | Y | N | Y | | | | | | | | | | | | |
| | | | | | 71: 73 ON command PRT-73 | | | | | | Y | Y | Y | Y | | | | | | | | | | | | |
| | | | | | 72: Turn ON Y-terminal test output Y-ON | | | | | | Y | Y | Y | Y | | | | | | | | | | | | |
| | | | | | 73: Turn OFF Y-terminal test output Y-OFF | | | | | | Y | Y | Y | Y | | | | | | | | | | | | |
| | | | | | 74: -- | | | | | | - | - | - | - | | | | | | | | | | | | |
| | | | | | 75: System clock battery lifetime expired BATT | | | | | | Y | Y | Y | Y | | | | | | | | | | | | |
| | | | | | 76: -- | | | | | | - | - | - | - | | | | | | | | | | | | |
| | | | | | 77: SPGT battery warning (Available soon) SPGT-B | | | | | | Y | Y | Y | Y | | | | | | | | | | | | |
| | | | | | 78: -- | | | | | | - | - | - | - | | | | | | | | | | | | |
| | | | | | 79: -- | | | | | | - | - | - | - | | | | | | | | | | | | |
| | | | | | 80: EN terminal detection circuit failure DECF | | | | | | Y | Y | Y | Y | | | | | | | | | | | | |
| | | | | | 81: EN terminal OFF ENOFF | | | | | | Y | Y | Y | Y | | | | | | | | | | | | |
| | | | | | 82: Safety function in progress SF-RUN | | | | | | Y | Y | Y | Y | | | | | | | | | | | | |
| | | | | | 83: -- | | | | | | - | - | - | - | | | | | | | | | | | | |
| | | | | | 84: STO under testing SF-TST | | | | | | Y | Y | Y | Y | | | | | | | | | | | | |
| | | | | | E16 | | | | | | 110h | 86h | Terminal [Y2] Function | 1 | | 0 to 75 (See Terminal [Y1] Function.) | N | 2 | Y | Y | 58 | Y | Y | Y | Y | |
| | | | | | E17 | | | | | | 111h | 87h | Terminal [Y3] Function | 1 | | 0 to 75 (See Terminal [Y1] Function.) | N | 3 | Y | Y | 58 | Y | Y | Y | Y | |
| | | | | | E18 | | | | | | 112h | 88h | Terminal [Y4] Function | 1 | | 0 to 75 (See Terminal [Y1] Function.) | N | 4 | Y | Y | 58 | Y | Y | Y | Y | |
| | | | | | E19 | | | | | | 113h | 89h | Terminal [Y5] Function | 1 | | 0 to 75 (See Terminal [Y1] Function.) | N | 14 | Y | Y | 58 | Y | Y | Y | Y | |

*1 Available in the ROM version H1/2 0200, which supports PROFINET-IRT.

*2 Available in the ROM version H1/2 0020 or later.

| Function code | Communications address | | Name | Dir. | Data setting range | Change when running | Default setting | Data copying | Initialization | Format type | Drive control | | | Remarks |
|---------------|------------------------|----------|---|------|--|---------------------|-----------------|--------------|----------------|-------------|---------------|-----------|-----|---------|
| | 485 No. | Link No. | | | | | | | | | VC w/ PG | VC w/o PG | V/f | |
| E20 | 114h | 8Ah | Terminal [Y11] Function | 1 | 0 to 75 (See Terminal [Y1] Function.) | N | 26 | Y | Y | 58 | Y | Y | Y | Y |
| E21 | 115h | 8Bh | Terminal [Y12] Function | 1 | 0 to 75 (See Terminal [Y1] Function.) | N | 26 | Y | Y | 58 | Y | Y | Y | Y |
| E22 | 116h | 8Ch | Terminal [Y13] Function | 1 | 0 to 75 (See Terminal [Y1] Function.) | N | 26 | Y | Y | 58 | Y | Y | Y | Y |
| E23 | 117h | 8Dh | Terminal [Y14] Function | 1 | 0 to 75 (See Terminal [Y1] Function.) | N | 26 | Y | Y | 58 | Y | Y | Y | Y |
| E24 | 118h | 8Eh | Terminal [Y15] Function | 1 | 0 to 75 (See Terminal [Y1] Function.) | N | 26 | Y | Y | 58 | Y | Y | Y | Y |
| E25 | 119h | 8Fh | Terminal [Y16] Function | 1 | 0 to 75 (See Terminal [Y1] Function.) | N | 26 | Y | Y | 58 | Y | Y | Y | Y |
| E26 | 11Ah | 90h | Terminal [Y17] Function | 1 | 0 to 75 (See Terminal [Y1] Function.) | N | 26 | Y | Y | 58 | Y | Y | Y | Y |
| E27 | 11Bh | 91h | Terminal [Y18] Function | 1 | 0 to 75 (See Terminal [Y1] Function.) | N | 26 | Y | Y | 58 | Y | Y | Y | Y |
| E28 | 11Ch | h | Y Terminal Function (Normal open/close) | 0 | 0000 to 001F 0: Normal open 1: Normal close | N | 0000 | Y | Y | 36 | Y | Y | Y | Y |
| E29 | 11Dh | 92h | PG Pulse Output Selection | 0 | 0 to 10 0: No dividing 1: 1/2 2: 1/4 3: 1/8 4: 1/16 5: 1/32 6: 1/64 0 to 6: Internal PG input is divided before output. 7: Internal speed command: Pulse oscillation mode 8: PG (PD): Detected pulse input oscillation mode 9: PG (PR): Pulse command input oscillation mode 10: Integrated PG, PG (SD): Detected speed pulse input oscillation mode 7 to 10: Input pulse is arbitrarily divided before output. (AB 90° phase difference signal) | N | 0 | Y | Y | 92 | Y | N | N | Y |
| E30 | 11Eh | h | Motor Overheat Protection (Temperature) | 8 | 50 to 200°C | Y | 150 | Y | Y | 0 | Y | Y | Y | Y |
| E31 | 11Fh | h | Motor Overheat Early Warning (Temperature) | 1 | 50 to 200°C | Y | 75 | Y | Y | 0 | Y | Y | Y | Y |
| E32 | 120h | CDh | M1-M3 PTC Activation Level | 1 | 0.00 to 5.00 V The PTC is activated if the input voltage of the PTC terminal exceeds this activation level when the PTC thermistor is selected (P30/A31/A131 = 2). | N | 1.60 | Y | Y | 3 | Y | Y | Y | Y |
| E33 | 121h | h | Inverter Overload Early Warning | 1 | 25 to 100% | Y | 90 | Y | Y | 0 | Y | Y | Y | Y |
| E34 | 122h | h | Motor Overload Early Warning | 1 | 25 to 100% | Y | 90 | Y | Y | 0 | Y | Y | Y | Y |
| E35 | 123h | h | DB Overload Protection | 1 | 0 to 100% E35 specifies %ED of the braking resistor relative to the inverter capacity. When E35 = 0, the overload protection function (\overline{OBH}) is disabled. | Y | 0 | Y | Y | 0 | Y | Y | N | Y |
| E36 | 124h | h | DB Overload Early Warning | 1 | 0 to 100% | Y | 80 | Y | Y | 0 | Y | Y | N | Y |
| E37 | 125h | h | DB Thermal Time Constant | 1 | 0 to 1000 s | Y | 300 | Y | Y | 0 | Y | Y | N | Y |
| E38 | 126h | 93h | Speed Detection Mode | 8 | 000 to 111 Detection mode of 0xE39/E40/E41 0: Detected speed 1: Reference speed Under V/f control, only the specified reference speed is valid. | Y | 000 | Y | Y | 9 | Y | Y | N | Y |
| E39 | 127h | 94h | Speed Detection Level 1 | 1 | 0 to 30000 r/min If N-FB1± (Detected speed 1) or N-REF4 (Reference speed 4) exceeds this speed detection level 1, the inverter issues the detection signal. | Y | 1500 | Y | Y | 0 | Y | Y | Y | Y |
| E40 | 128h | 95h | Speed Detection Level 2 | 1 | -30000 to 30000 r/min | Y | 1500 | Y | Y | 5 | Y | Y | Y | Y |
| E41 | 129h | 96h | Speed Detection Level 3 | 1 | -30000 to 30000 r/min | Y | 1500 | Y | Y | 5 | Y | Y | Y | Y |
| E42 | 12Ah | 97h | Speed Arrival (Detection width) | 1 | 1.0 to 20.0% If the detected speed comes within the range of N-REF2 (Reference speed 2) ± this detection width, the inverter issues the detection signal. | Y | 3.0 | Y | Y | 2 | Y | Y | N | Y |
| E43 | 12Bh | 98h | Speed Agreement (Detection width) | 1 | 1.0 to 20.0% If N-FB2± (Detected speed 2) is within the range of N-REF4 (Reference speed 4) ± this detection width, the inverter issues the detection signal. | Y | 3.0 | Y | Y | 2 | Y | Y | N | Y |
| E44 | 12Ch | 99h | (Off-delay timer) | 1 | 0.000 to 5.000 s | Y | 0.100 | Y | Y | 4 | Y | Y | N | Y |
| E45 | 12Dh | 9Ah | Speed Disagreement Alarm/Phase Loss Detection Level | 1 | 00 to 21 Units place: Speed disagreement alarm ($\overline{E-9}$) 0: Disable 1: Enable Tenths place: Power supply phase loss detection (\overline{L} \rightarrow) 0: Standard level 1: For particular manufacturers. 2: Cancel | N | 00 | Y | Y | 9 | Y | Y | N | Y |
| E46 | 12Eh | 9Bh | Torque Detection Level 1 | 3 | 0 to 300% Calculated value under V/f control. If the torque command exceeds this setting, the inverter issues the detection signal. | Y | 30 | Y | Y | 16 | Y | Y | Y | Y |

| Function code | Communications address | | Name | Dir. | Data setting range | Change when running | Default setting | Data copying | Initialization | Format type | Drive control | | | Remarks |
|--|------------------------|----------|-------------------------------|------|--|---------------------|-----------------|--------------|----------------|-------------|---------------|-----------|----|---------|
| | 485 No. | Link No. | | | | | | | | | VC w/ PG | VC w/o PG | Vf | |
| E47 | 12Fh | 9Ch | Torque Detection Level 2 | 1 | 0 to 300% | Y | 30 | Y | Y | 16 | Y | Y | Y | Y |
| E48 | 130h | 9Dh | Magnetic Flux Detection Level | 1 | 10 to 100% If the magnetic flux value calculated exceeds this setting, the inverter issues the detection signal. | N | 100 | Y | Y | 16 | Y | Y | N | N |
| E49 | 131h | h | Terminal [Ai1] Function | 4 | 00 to 27 | N | 0 | Y | Y | 59 | Y | Y | Y | Y |
| | | | | | 00: Shut down input signal OFF - | | | | | | Y | Y | Y | Y |
| | | | | | 01: Auxiliary speed setting 1 AUX-N1 ±10V/±Nmax | | | | | | Y | Y | Y | Y |
| | | | | | 02: Auxiliary speed setting 2 AUX-N2 ±10V/±Nmax | | | | | | Y | Y | Y | Y |
| | | | | | 03: Torque limiter level 1 TL-REF1 ±10V/±150% | | | | | | Y | Y | Y | Y |
| | | | | | 04: Torque limiter level 2 TL-REF2 ±10V/±150% | | | | | | Y | Y | Y | Y |
| | | | | | 05: Torque bias TB-REF ±10V/±150% | | | | | | Y | Y | N | Y |
| | | | | | 06: Torque command T-REF ±10V/±150% | | | | | | Y | Y | N | Y |
| | | | | | 07: Torque current command IT-REF ±10V/±150% | | | | | | Y | Y | N | Y |
| | | | | | 08: Creep speed 1 for UP/DOWN control CRP-N1 ±10V/±Nmax | | | | | | Y | Y | Y | Y |
| | | | | | 09: Creep speed 2 for UP/DOWN control CRP-N2 ±10V/±Nmax | | | | | | Y | Y | Y | Y |
| | | | | | 10: Magnetic flux reference MF-REF +10V/+100% | | | | | | Y | N | N | N |
| | | | | | 11: Detect line speed LINE-N ±10V/±Nmax | | | | | | Y | Y | Y | Y |
| | | | | | 12: Motor temperature M-TMP +10V/200°C | | | | | | Y | Y | Y | Y |
| | | | | | 13: Speed override N-OR ±10V/±50% | | | | | | Y | Y | Y | Y |
| | | | | | 14: Universal Ai U-AI ±10V/±4000(h) | | | | | | Y | Y | Y | Y |
| | | | | | 15: PID feedback 1 PID-FB1 ±10V/±20000(d) | | | | | | Y | Y | Y | Y |
| | | | | | 16: PID reference value PID-REF ±10V/±20000(d) | | | | | | Y | Y | Y | Y |
| | | | | | 17: PID correction gain PID-G ±10V/±4000(h) | | | | | | Y | Y | Y | Y |
| | | | | | 18 to 24: Custom Ai1 to Ai7 C-AI1 to C-AI7 | | | | | | Y | Y | Y | Y |
| 25: Main speed setting N-REFV ±10V/±Nmax | Y | Y | Y | Y | | | | | | | | | | |
| 26: Current input speed setting (4-20 mADC) N-REFC ±10V/±Nmax (Data 26 is available only on [Ai2].) | Y | Y | Y | Y | | | | | | | | | | |
| 27: PID feedback amount 2 PID-FB2 ±10V/±20000 (d) | Y | Y | Y | Y | | | | | | | | | | |
| E50 | 132h | h | Terminal [Ai2] Function | 1 | 0 to 27 (Refer to Terminal [Ai1] Function.) | N | 0 | Y | Y | 59 | Y | Y | Y | Y |
| E51 | 133h | h | Terminal [Ai3] Function | 1 | 0 to 27 (Refer to Terminal [Ai1] Function.) (Data 26 is available only on [Ai2].) | N | 0 | Y | Y | 59 | Y | Y | Y | Y |
| E52 | 134h | h | Terminal [Ai4] Function | 1 | 0 to 27 (Refer to Terminal [Ai1] Function.) (Data 26 is available only on [Ai2].) | N | 0 | Y | Y | 59 | Y | Y | Y | Y |
| E53 | 135h | h | Ai1 Gain | 4 | -10.000 to 10.000 times | Y | 1.000 | Y | Y | 8 | Y | Y | Y | Y |
| E54 | 136h | h | Ai2 Gain | 1 | -10.000 to 10.000 times | Y | 1.000 | Y | Y | 8 | Y | Y | Y | Y |
| E55 | 137h | h | Ai3 Gain | 1 | -10.000 to 10.000 times (Displays if AIO option is mounted) | Y | 1.000 | Y | Y | 8 | Y | Y | Y | Y |
| E56 | 138h | h | Ai4 Gain | 1 | -10.000 to 10.000 times (Displays if AIO option is mounted) | Y | 1.000 | Y | Y | 8 | Y | Y | Y | Y |
| E57 | 139h | h | Ai1 Bias | 4 | -100.0 to 100.0% | Y | 0.0 | Y | Y | 6 | Y | Y | Y | Y |
| E58 | 13Ah | h | Ai2 Bias | 1 | -100.0 to 100.0% | Y | 0.0 | Y | Y | 6 | Y | Y | Y | Y |
| E59 | 13Bh | h | Ai3 Bias | 1 | -100.0 to 100.0% (Displays if AIO option is mounted) | Y | 0.0 | Y | Y | 6 | Y | Y | Y | Y |
| E60 | 13Ch | h | Ai4 Bias | 1 | -100.0 to 100.0% (Displays if AIO option is mounted) | Y | 0.0 | Y | Y | 6 | Y | Y | Y | Y |
| E61 | 13Dh | h | Ai1 Filter | 4 | 0.000 to 0.500 s | Y | 0.010 | Y | Y | 4 | Y | Y | Y | Y |
| E62 | 13Eh | h | Ai2 Filter | 1 | 0.000 to 0.500 s | Y | 0.010 | Y | Y | 4 | Y | Y | Y | Y |
| E63 | 13Fh | h | Ai3 Filter | 1 | 0.000 to 0.500 s | Y | 0.010 | Y | Y | 4 | Y | Y | Y | Y |
| E64 | 140h | h | Ai4 Filter | 1 | 0.000 to 0.500 s | Y | 0.010 | Y | Y | 4 | Y | Y | Y | Y |
| E65 | 141h | h | Up/Down Limiter (Ai1) | 4 | 0.00 to 60.00 s E65 specifies the duration required when the inverter internal data changes from 0 V to 10 V if the voltage on terminal [Ai1] changes from 0 V to 10 V. | Y | 0.00 | Y | Y | 3 | Y | Y | Y | Y |
| E66 | 142h | h | Up/Down Limiter (Ai2) | 1 | 0.00 to 60.00 s | Y | 0.00 | Y | Y | 3 | Y | Y | Y | Y |
| E67 | 143h | h | Up/Down Limiter (Ai3) | 1 | 0.00 to 60.00 s | Y | 0.00 | Y | Y | 3 | Y | Y | Y | Y |
| E68 | 144h | h | Up/Down Limiter (Ai4) | 1 | 0.00 to 60.00 s | Y | 0.00 | Y | Y | 3 | Y | Y | Y | Y |

| Function code | Communications address | | Name | Dir. | Data setting range | Change when running | Default setting | Data copying | Initialization | Format type | Drive control | | | | Remarks |
|---|------------------------|----------|--|------|---|---------------------|-----------------|--------------|----------------|-------------|---------------|-----------|----|-------------|---------|
| | 485 No. | Link No. | | | | | | | | | VC w/ PG | VC w/o PG | Vf | VC for PMSM | |
| E69 | 145h | h | Terminal [Ao1] Function | 5 | 00 to 40 | Y | 1 | Y | Y | 60 | | | | | |
| | | | | | 00: Detected speed 1 (Speed indicator, one-way deflection) N-FB1+ ±Nmax/10V | | | | | | Y | Y | N | Y | |
| | | | | | 01: Detected speed 1 (Speed indicator, two-way deflection) N-FB1± ±Nmax/±10V | | | | | | Y | Y | N | Y | |
| | | | | | 02: Reference speed 2 (before ACC/DEC processing) N-REF2 ±Nmax/±10V | | | | | | Y | Y | Y | Y | |
| | | | | | 03: Reference speed 4 (ASR input) N-REF4 ±Nmax/±10V | | | | | | Y | Y | Y | Y | |
| | | | | | 04: Detected speed 2 (ASR input) N-FB2± ±Nmax/±10V | | | | | | Y | Y | N | Y | |
| | | | | | 05: Detected line speed LINE-N± ±Nmax/±10V | | | | | | Y | Y | Y | Y | |
| | | | | | 06: Torque current command (Torque ammeter, one-way deflection) IT-REF± ±150%/±10V | | | | | | Y | Y | N | Y | |
| | | | | | 07: Torque current command (Torque ammeter, two-way deflection) IT-REF+ ±150%/10V | | | | | | Y | Y | N | Y | |
| | | | | | 08: Torque command (Torque meter, two-way deflection) T-REF± ±150%/±10V | | | | | | Y | Y | N | Y | |
| | | | | | 09: Torque command (Torque meter, one-way deflection) T-REF+ ±150%/10V | | | | | | Y | Y | N | Y | |
| | | | | | 10: Motor current I-AC 200%/10V | | | | | | Y | Y | Y | Y | |
| | | | | | 11: Motor voltage V-AC 200%/10V | | | | | | Y | Y | Y | Y | |
| | | | | | 12: Input power (Motor output) PWR 200%/10V | | | | | | Y | Y | Y | Y | |
| | | | | | 13: DC link bus voltage V-DC 800V/10V | | | | | | Y | Y | Y | Y | |
| | | | | | 14: +10V test voltage output P10 +10 VDC equivalent | | | | | | Y | Y | Y | Y | |
| | | | | | 15: -10V test voltage output N10 -10 VDC equivalent | | | | | | Y | Y | Y | Y | |
| | | | | | 16: Motor temperature TMP-M ±200°C/±10V | | | | | | Y | Y | Y | Y | |
| | | | | | 30: Universal AO U-AO - | | | | | | Y | Y | Y | Y | |
| | | | | | 31-37: Custom Ao1-Ao7 C-AO1 to C-AO7 | | | | | | Y | Y | Y | Y | |
| 38: Input power PWR-IN 200%/10V | Y | Y | Y | Y | | | | | | | | | | | |
| 39: Magnetic pole position signal SMP TOP/5V | N | N | N | Y | | | | | | | | | | | |
| 40: PID output value PID-OUT ±200%/±10V | Y | Y | Y | Y | | | | | | | | | | | |
| E70 | 146h | h | Terminal [Ao2] Function | 1 | 0 to 40 (Refer to Terminal [Ao1] function.) | Y | 6 | Y | Y | 60 | Y | Y | Y | Y | |
| E71 | 147h | h | Terminal [Ao3] Function | 1 | 0 to 40 (Refer to Terminal [Ao1] function.) | Y | 3 | Y | Y | 60 | Y | Y | Y | Y | |
| E72 | 148h | h | Terminal [Ao4] Function | 1 | 0 to 40 (Refer to Terminal [Ao1] function.) | Y | 0 | Y | Y | 60 | Y | Y | Y | Y | |
| E73 | 149h | h | Terminal [Ao5] Function | 1 | 0 to 40 (Refer to Terminal [Ao1] function.) | Y | 0 | Y | Y | 60 | Y | Y | Y | Y | |
| E74 | 14Ah | h | Ao1 Gain | 5 | -100.00 to 100.00 times | Y | 1.00 | Y | Y | 7 | Y | Y | Y | Y | |
| E75 | 14Bh | h | Ao2 Gain | 1 | -100.00 to 100.00 times | Y | 1.00 | Y | Y | 7 | Y | Y | Y | Y | |
| E76 | 14Ch | h | Ao3 Gain | 1 | -100.00 to 100.00 times | Y | 1.00 | Y | Y | 7 | Y | Y | Y | Y | |
| E77 | 14Dh | h | Ao4 Gain | 1 | -100.00 to 100.00 times (Displays if AIO option is mounted) | Y | 1.00 | Y | Y | 7 | Y | Y | Y | Y | |
| E78 | 14Eh | h | Ao5 Gain | 1 | -100.00 to 100.00 times (Displays if AIO option is mounted) | Y | 1.00 | Y | Y | 7 | Y | Y | Y | Y | |
| E79 | 14Fh | h | Ao1 Bias | 5 | -100.0 to 100.0% | Y | 0.0 | Y | Y | 6 | Y | Y | Y | Y | |
| E80 | 150h | h | Ao2 Bias | 1 | -100.0 to 100.0% | Y | 0.0 | Y | Y | 6 | Y | Y | Y | Y | |
| E81 | 151h | h | Ao3 Bias | 1 | -100.0 to 100.0% | Y | 0.0 | Y | Y | 6 | Y | Y | Y | Y | |
| E82 | 152h | h | Ao4 Bias | 1 | -100.0 to 100.0% (Displays if AIO option is mounted) | Y | 0.0 | Y | Y | 6 | Y | Y | Y | Y | |
| E83 | 153h | h | Ao5 Bias | 1 | -100.0 to 100.0% (Displays if AIO option is mounted) | Y | 0.0 | Y | Y | 6 | Y | Y | Y | Y | |
| E84 | 154h | h | Ao1-Ao5 Filter | 0 | 0.000 to 0.500 s | Y | 0.010 | Y | Y | 4 | Y | Y | Y | Y | |
| E90 | 15Ah | h | Link Command Function Selection 1 (Available soon) | 2 | 00 to 13 | Y | 0 | Y | Y | 231 | | | | | |
| | | | | | 00: Shut down input signal OFF | | | | | | Y | Y | Y | Y | |
| | | | | | 01: Auxiliary speed setting 1 AUX-N1 | | | | | | Y | Y | Y | Y | |
| | | | | | 02: Auxiliary speed setting 2 AUX-N2 | | | | | | Y | Y | Y | Y | |
| | | | | | 03: Torque bias level TB-REF | | | | | | Y | Y | N | Y | |
| | | | | | 04: Creep speed 1 for UP/DOWN control CRP-N1 | | | | | | Y | Y | Y | Y | |
| | | | | | 05: Creep speed 2 for UP/DOWN control CRP-N2 | | | | | | Y | Y | Y | Y | |
| | | | | | 06: Detect line speed LINE-N | | | | | | Y | Y | Y | Y | |
| | | | | | 07: Motor temperature M-TMP | | | | | | Y | Y | Y | Y | |
| | | | | | 08: Speed override N-OR | | | | | | Y | Y | Y | Y | |
| | | | | | 09: PID feedback amount 1 PID-FB1 | | | | | | Y | Y | Y | Y | |
| | | | | | 10: PID command amount PID-REF | | | | | | Y | Y | Y | Y | |
| | | | | | 11: PID correction gain PID-G | | | | | | Y | Y | Y | Y | |
| | | | | | 12: PID feedback amount 2 PID-FB2 | | | | | | Y | Y | Y | Y | |
| 13: Observer torque FB OBS-TFB | Y | Y | N | Y | | | | | | | | | | | |

| Function code | Communications address | | Name | Dir. | Data setting range | Change when running | Default setting | Data copying | Initialization | Format type | Drive control | | | Remarks | |
|---------------|------------------------|----------|---|------|--|---------------------|-----------------|--------------|----------------|-------------|---------------|-----------|-----|---------|-------------|
| | 485 No. | Link No. | | | | | | | | | VC w/ PG | VC w/o PG | V/f | | VC for PMSM |
| E91 | 15Bh | h | Link Command Function Selection 2 (Available soon) | 1 | 00 to 12 When E91 ≠ 0 (OFF), analog setting via the communications link (S17) has priority over Ai input specified by Ai function selection. (Refer to the Link Command Function Selection 1.) | Y | 0 | Y | Y | 231 | Y | Y | Y | Y | |
| E101 | 1E01h | h | Ai1 Offset | 4 | -100.00 to 100.00% | Y | 0.00 | Y | Y | 7 | Y | Y | Y | Y | |
| E102 | 1E02h | h | Ai2 Offset | 1 | -100.00 to 100.00% | Y | 0.00 | Y | Y | 7 | Y | Y | Y | Y | |
| E103 | 1E03h | h | Ai3 Offset | 1 | -100.00 to 100.00% (Displays if AIO option is mounted) | Y | 0.00 | Y | Y | 7 | Y | Y | Y | Y | |
| E104 | 1E04h | h | Ai4 Offset | 1 | -100.00 to 100.00% (Displays if AIO option is mounted) | Y | 0.00 | Y | Y | 7 | Y | Y | Y | Y | |
| E105 | 1E05h | h | Ai1 Dead Zone | 4 | 0.00 to 10.00% Limits all command values except input values to 0 V. | Y | 0.00 | Y | Y | 3 | Y | Y | Y | Y | |
| E106 | 1E06h | h | Ai2 Dead Zone | 1 | 0.00 to 10.00% | Y | 0.00 | Y | Y | 3 | Y | Y | Y | Y | |
| E107 | 1E07h | h | Ai3 Dead Zone | 1 | 0.00 to 10.00% (Displays if AIO option is mounted) | Y | 0.00 | Y | Y | 3 | Y | Y | Y | Y | |
| E108 | 1E08h | h | Ai4 Dead Zone | 1 | 0.00 to 10.00% (Displays if AIO option is mounted) | Y | 0.00 | Y | Y | 3 | Y | Y | Y | Y | |
| E109 | 1E09h | h | Dividing Ratio for FA, FB Pulse Output (Numerator) | 2 | 1 to 65535 Specifies the numerator of the dividing ratio for FA and FB pulse output. | N | 1000 | Y | Y | 0 | Y | N | N | Y | |
| E110 | 1E0Ah | h | (Denominator) | 1 | 1 to 65535 Specifies the denominator of the dividing ratio for FA and FB pulse output. | N | 1000 | Y | Y | 0 | Y | N | N | Y | |
| E114 | 1E0Eh | h | Speed Agreement 2 (Detection width) | 4 | 1.0 to 20.0% If N-FB2± (Detected speed 2) is within the range of N-REF4 (Reference speed 4) ± this detection width, the inverter issues the speed agreement signal N-AG2 . | Y | 3.0 | Y | Y | 2 | Y | Y | N | Y | |
| E115 | 1E0Fh | h | (Off-delay timer) | 1 | 0.000 to 5.000 s Specifies the off-delay timer of the speed agreement signal N-AG2 . | Y | 0.100 | Y | Y | 4 | Y | Y | N | Y | |
| E116 | 1E10h | h | Speed Agreement 3 (Detection width) | 1 | 1.0 to 20.0% If N-FB2± (Detected speed 2) is within the range of N-REF4 (Reference speed 4) ± this detection width, the inverter issues the speed agreement signal N-AG3 . | Y | 3.0 | Y | Y | 2 | Y | Y | N | Y | |
| E117 | 1E11h | h | (Off-delay timer) | 1 | 0.000 to 5.000 s Specifies the off-delay timer of the speed agreement signal N-AG3 . | Y | 0.100 | Y | Y | 4 | Y | Y | N | Y | |
| E118 | 1E12h | h | Temperature for Axial Fan Stop Signal | 0 | 0 to 200°C If the NTC detection temperature of the motor having an NTC thermistor drops below this setting, the inverter turns ON the axial fan stopped signal MFAN . | Y | 0 | Y | Y | 0 | Y | Y | Y | Y | |

■ C codes (Control Functions)

| Function code | Communications address | | Name | Dir. | Data setting range | Change when running | Default setting | Data copying | Initialization | Format type | Drive control | | | Remarks | |
|---------------|------------------------|----------|--|------|--|---------------------|-----------------|--------------|----------------|-------------|---------------|-----------|-----|---------|-------------|
| | 485 No. | Link No. | | | | | | | | | VC w/ PG | VC w/o PG | V/f | | VC for PMSM |
| C01 | 201h | h | Jump Speed 1 | 4 | 0 to 30000 r/min Enables the inverter to jump over a point on the reference speed in order to skip a resonance point of the driven machinery (load) and the motor speed. Up to three different jump points can be specified. | Y | 0 | Y | Y | 0 | Y | Y | Y | Y | |
| C02 | 202h | h | Jump Speed 2 | 1 | 0 to 30000 r/min | Y | 0 | Y | Y | 0 | Y | Y | Y | Y | |
| C03 | 203h | h | Jump Speed 3 | 1 | 0 to 30000 r/min | Y | 0 | Y | Y | 0 | Y | Y | Y | Y | |
| C04 | 204h | h | Hysteresis Width for Jump Speed | 1 | 0 to 1000 r/min | Y | 0 | Y | Y | 0 | Y | Y | Y | Y | |
| C05 | 205h | 9Eh | Multistep Speed 1 | 17 | 0 to 30000 r/min / 0.00 to 100.00% / 0.0 to 999.9 m/min (Switchable by C21) Multistep speeds 1 to 15 can be switched by turning terminal commands SS1 , SS2 , SS4 and SS8 ON/OFF. | Y | 0/0.00/0.0 | Y | Y | 0 | Y | Y | Y | Y | |
| C06 | 206h | 9Fh | Multistep Speed 2 | 1 | 0 to 30000 r/min / 0.00 to 100.00% / 0.0 to 999.9 m/min (Switchable by C21) | Y | 0/0.00/0.0 | Y | Y | 0 | Y | Y | Y | Y | |
| C07 | 207h | A0h | Multistep Speed 3 | 1 | 0 to 30000 r/min / 0.00 to 100.00% / 0.0 to 999.9 m/min (Switchable by C21) | Y | 0/0.00/0.0 | Y | Y | 0 | Y | Y | Y | Y | |
| C08 | 208h | A1h | Multistep Speed 4 | 1 | 0 to 30000 r/min / 0.00 to 100.00% / 0.0 to 999.9 m/min (Switchable by C21) | Y | 0/0.00/0.0 | Y | Y | 0 | Y | Y | Y | Y | |
| C09 | 209h | A2h | Multistep Speed 5 | 1 | 0 to 30000 r/min / 0.00 to 100.00% / 0.0 to 999.9 m/min (Switchable by C21) | Y | 0/0.00/0.0 | Y | Y | 0 | Y | Y | Y | Y | |
| C10 | 20Ah | A3h | Multistep Speed 6 | 1 | 0 to 30000 r/min / 0.00 to 100.00% / 0.0 to 999.9 m/min (Switchable by C21) | Y | 0/0.00/0.0 | Y | Y | 0 | Y | Y | Y | Y | |
| C11 | 20Bh | A4h | Multistep Speed 7 | 1 | 0 to 30000 r/min / 0.00 to 100.00% / 0.0 to 999.9 m/min (Switchable by C21) | Y | 0/0.00/0.0 | Y | Y | 0 | Y | Y | Y | Y | |
| C12 | 20Ch | h | Multistep Speed 8 | 1 | 0 to 30000 r/min / 0.00 to 100.00% / 0.0 to 999.9 m/min (Switchable by C21) | Y | 0/0.00/0.0 | Y | Y | 0 | Y | Y | Y | Y | |
| C13 | 20Dh | h | Multistep Speed 9 | 1 | 0 to 30000 r/min / 0.00 to 100.00% / 0.0 to 999.9 m/min (Switchable by C21) | Y | 0/0.00/0.0 | Y | Y | 0 | Y | Y | Y | Y | |
| C14 | 20Eh | h | Multistep Speed 10 | 1 | 0 to 30000 r/min / 0.00 to 100.00% / 0.0 to 999.9 m/min (Switchable by C21) | Y | 0/0.00/0.0 | Y | Y | 0 | Y | Y | Y | Y | |
| C15 | 20Fh | h | Multistep Speed 11 | 1 | 0 to 30000 r/min / 0.00 to 100.00% / 0.0 to 999.9 m/min (Switchable by C21) | Y | 0/0.00/0.0 | Y | Y | 0 | Y | Y | Y | Y | |
| C16 | 210h | h | Multistep Speed 12 | 1 | 0 to 30000 r/min / 0.00 to 100.00% / 0.0 to 999.9 m/min (Switchable by C21) | Y | 0/0.00/0.0 | Y | Y | 0 | Y | Y | Y | Y | |
| C17 | 211h | h | Multistep Speed 13 | 1 | 0 to 30000 r/min / 0.00 to 100.00% / 0.0 to 999.9 m/min (Switchable by C21) | Y | 0/0.00/0.0 | Y | Y | 0 | Y | Y | Y | Y | |
| C18 | 212h | h | Multistep Speed 14/ Creeping Speed 1 | 1 | 0 to 30000 r/min / 0.00 to 100.00% / 0.0 to 999.9 m/min (Switchable by C21) C18 and C19 apply also to the creep speed under UP/DOWN control. | Y | 0/0.00/0.0 | Y | Y | 0 | Y | Y | Y | Y | |
| C19 | 213h | h | Multistep Speed 15/ Creeping Speed 2 | 1 | 0 to 30000 r/min / 0.00 to 100.00% / 0.0 to 999.9 m/min (Switchable by C21) | Y | 0/0.00/0.0 | Y | Y | 0 | Y | Y | Y | Y | |
| C20 | 214h | h | Multistep Speed Agreement Timer | 1 | 0.000 to 0.100 s When SS1 , SS2 , SS4 and SS8 are kept at the same status for the duration specified by this function code, the inverter switches the reference speed. | Y | 0.000 | Y | Y | 4 | Y | Y | Y | Y | |
| C21 | 215h | h | Multistep Speed Configuration Definition | 1 | 0 to 2 0: 0 to 30000 r/min 1: 0.00 to 100.00% 2: 0.0 to 999.9 m/min Defines the unit of multistep speed specified by C05 to C19. When C21 = 1, the percentage of the maximum speed (F03/A06/A106) of the selected motor applies. | N | 0 | Y | Y | 93 | Y | Y | Y | Y | |
| C25 | 219h | h | Speed Command N2 | 0 | 0 to 9 0: Keypad (⏏) keys 1: Analog input to terminal [12](0 to ±10V) 2: Analog input to terminal [12](0 to +10V) 3: UP/DOWN control (Initial speed = 0) 4: UP/DOWN control (Initial speed = Last value) 5: UP/DOWN control (Initial speed = Creep speed 1, 2) 6: DIA card input 7: DIB card input 8: N-REFV input to terminal [Ai1] 9: N-REFC input to terminal [Ai2] The speed command specified by this function code takes effect when X terminal command N2/N1 is turned ON. | N | 0 | Y | Y | 41 | Y | Y | Y | Y | |
| C29 | 21Dh | h | Jogging Speed | 0 | 0 to 30000 r/min Specifies the speed to be applied when the motor jogs. | Y | 50 | Y | Y | 0 | Y | Y | Y | Y | |
| C30 | 21Eh | h | ASR-JOG (P-gain) | 9 | 0.1 to 500.0 times | Y | 10.0 | Y | Y | 2 | Y | Y | N | Y | |
| C31 | 21Fh | h | (I-constant) | 1 | 0.000 to 10.000 s P control when C31 = 0.000 | Y | 0.200 | Y | Y | 4 | Y | Y | N | Y | |

| Function code | Communications address | | Name | Dir. | Data setting range | Change when running | Default setting | Data copying | Initialization | Format type | Drive control | | | Remarks |
|---------------|------------------------|----------|---|------|--|---------------------|-----------------|--------------|----------------|-------------|---------------|-----------|----|---------|
| | 485 No. | Link No. | | | | | | | | | VC w/ PG | VC w/o PG | Vf | |
| C32 | 220h | h | (Input filter) | 1 | 0.000 to 5.000 s | Y | 0.040 | Y | Y | 4 | Y | Y | Y | Y |
| C33 | 221h | h | (Detection filter) | 1 | 0.000 to 0.100 s | Y | 0.005 | Y | Y | 4 | Y | Y | N | Y |
| C34 | 222h | h | (Output filter) | 1 | 0.000 to 0.100 s | N | 0.002 | Y | Y | 4 | Y | Y | N | Y |
| C35 | 223h | h | Acceleration Time for Jogging | 1 | 0.01 to 99.99 s 100.0 to 999.9 s 1000 to 3600 s | Y | 5.00 | Y | Y | 13 | Y | Y | Y | Y |
| C36 | 224h | h | Deceleration Time for Jogging | 1 | 0.01 to 99.99 s 100.0 to 999.9 s 1000 to 3600 s | Y | 5.00 | Y | Y | 13 | Y | Y | Y | Y |
| C37 | 225h | h | S-curve JOG (Start side) | 1 | 0 to 50% | Y | 0 | Y | Y | 0 | Y | Y | Y | Y |
| C38 | 226h | h | S-curve JOG (End side) | 1 | 0 to 50% | Y | 0 | Y | Y | 0 | Y | Y | Y | Y |
| C40 | 228h | h | ASR2 (P-gain) | 10 | 0.1 to 500.0 times | Y | 10.0 | Y | Y | 2 | Y | Y | N | Y |
| C41 | 229h | h | (I-constant) | 1 | 0.000 to 10.000 s P control when C41 = 0.000 | Y | 0.200 | Y | Y | 4 | Y | Y | N | Y |
| C42 | 22Ah | h | (Feedforward gain) | 1 | 0.000 to 9.999 s | Y | 0.000 | Y | Y | 4 | Y | Y | N | Y |
| C43 | 22Bh | h | (Input filter) | 1 | 0.000 to 5.000 s | Y | 0.040 | Y | Y | 4 | Y | Y | Y | Y |
| C44 | 22Ch | h | (Detection filter) | 1 | 0.000 to 0.100 s | Y | 0.005 | Y | Y | 4 | Y | Y | N | Y |
| C45 | 22Dh | h | (Output filter) | 1 | 0.000 to 0.100 s | N | 0.002 | Y | Y | 4 | Y | Y | N | Y |
| C46 | 22Eh | h | Acceleration Time 2 | 1 | 0.01 to 99.99 s 100.0 to 999.9 s 1000 to 3600 s | Y | 5.00 | Y | Y | 13 | Y | Y | Y | Y |
| C47 | 22Fh | h | Deceleration Time 2 | 1 | 0.01 to 99.99 s 100.0 to 999.9 s 1000 to 3600 s | Y | 5.00 | Y | Y | 13 | Y | Y | Y | Y |
| C48 | 230h | h | S-curve 2 (Start side) | 1 | 0 to 50% | Y | 0 | Y | Y | 0 | Y | Y | Y | Y |
| C49 | 231h | h | S-curve 2 (End side) | 1 | 0 to 50% | Y | 0 | Y | Y | 0 | Y | Y | Y | Y |
| C50 | 232h | h | ASR3 (P-gain) | 10 | 0.1 to 500.0 times | Y | 10.0 | Y | Y | 2 | Y | Y | N | Y |
| C51 | 233h | h | (I-constant) | 1 | 0.000 to 10.000 s P control when C41 = 0.000 | Y | 0.200 | Y | Y | 4 | Y | Y | N | Y |
| C52 | 234h | h | (Feedforward gain) | 1 | 0.000 to 9.999 s | Y | 0.000 | Y | Y | 4 | Y | Y | N | Y |
| C53 | 235h | h | (Input filter) | 1 | 0.000 to 5.000 s | Y | 0.040 | Y | Y | 4 | Y | Y | Y | Y |
| C54 | 236h | h | (Detection filter) | 1 | 0.000 to 0.100 s | Y | 0.005 | Y | Y | 4 | Y | Y | N | Y |
| C55 | 237h | h | (Output filter) | 1 | 0.000 to 0.100 s | N | 0.002 | Y | Y | 4 | Y | Y | N | Y |
| C56 | 238h | h | Acceleration Time 3 | 1 | 0.01 to 99.99 s 100.0 to 999.9 s 1000 to 3600 s | Y | 5.00 | Y | Y | 13 | Y | Y | Y | Y |
| C57 | 239h | h | Deceleration Time 3 | 1 | 0.01 to 99.99 s 100.0 to 999.9 s 1000 to 3600 s | Y | 5.00 | Y | Y | 13 | Y | Y | Y | Y |
| C58 | 23Ah | h | S-curve 3 (Start side) | 1 | 0 to 50% | Y | 0 | Y | Y | 0 | Y | Y | Y | Y |
| C59 | 23Bh | h | S-curve 3 (End side) | 1 | 0 to 50% | Y | 0 | Y | Y | 0 | Y | Y | Y | Y |
| C60 | 23Ch | h | ASR4 (P-gain) | 10 | 0.1 to 500.0 times | Y | 10.0 | Y | Y | 2 | Y | Y | N | Y |
| C61 | 23Dh | h | (I-gain) | 1 | 0.000 to 10.000 s P control when C41 = 0.000 | Y | 0.200 | Y | Y | 4 | Y | Y | N | Y |
| C62 | 23Eh | h | (Feedforward gain) | 1 | 0.000 to 9.999 s | Y | 0.000 | Y | Y | 4 | Y | Y | N | Y |
| C63 | 23Fh | h | (Input filter) | 1 | 0.000 to 5.000 s | Y | 0.040 | Y | Y | 4 | Y | Y | Y | Y |
| C64 | 240h | h | (Detection filter) | 1 | 0.000 to 0.100 s | Y | 0.005 | Y | Y | 4 | Y | Y | N | Y |
| C65 | 241h | h | (Output filter) | 1 | 0.000 to 0.100 s | N | 0.002 | Y | Y | 4 | Y | Y | N | Y |
| C66 | 242h | h | Acceleration Time 4 | 1 | 0.01 to 99.99 s 100.0 to 999.9 s 1000 to 3600 s | Y | 5.00 | Y | Y | 13 | Y | Y | Y | Y |
| C67 | 243h | h | Deceleration Time 4 | 1 | 0.01 to 99.99 s 100.0 to 999.9 s 1000 to 3600 s | Y | 5.00 | Y | Y | 13 | Y | Y | Y | Y |
| C68 | 244h | h | S-curve 4 (Start side) | 1 | 0 to 50% | Y | 0 | Y | Y | 0 | Y | Y | Y | Y |
| C69 | 245h | h | S-curve 4 (End side) | 1 | 0 to 50% | Y | 0 | Y | Y | 0 | Y | Y | Y | Y |
| C70 | 246h | h | ASR Switching Time | 0 | 0.00 to 2.55 s | Y | 1.00 | Y | Y | 3 | Y | Y | N | Y |
| C71 | 247h | A5h | ACC/DEC Switching Speed | 0 | 0.00 to 100.00% | Y | 0.00 | Y | Y | 3 | Y | Y | Y | Y |
| C72 | 248h | A6h | ASR Switching Time | 0 | 0.00 to 100.00% | Y | 0.00 | Y | Y | 3 | Y | Y | N | Y |
| C73 | 249h | h | Creep Speed Switching (under UP/DOWN control) | 0 | 00 to 11 (Creep Speed 1)(Creep Speed 2) 0: Function code setting (C18, C19) 1: Analog input (CRP1, CRP2) | N | 00 | Y | Y | 9 | Y | Y | Y | Y |

■ P codes (Motor Parameter Functions M1)

| Function code | Communications address | | Name | Dir. | Data setting range | Change when running | Default setting | Data copying | Initialization | Format type | Drive control | | | Remarks | |
|---------------|------------------------|----------|---|------|---|---------------------|-----------------|--------------|----------------|-------------|---------------|-----------|-----|---------|--|
| | 485 No. | Link No. | | | | | | | | | VC w/ PG | VC w/o PG | V/f | | |
| P01 | 301h | h | M1 Drive Control | 0 | 0 to 5 0: Vector control for IM with speed sensor 1: Vector control for IM without speed sensor 2: Simulation mode 3: Vector control for PMSM with speed sensor 4: -- 5: V/f control for IM | N | 0 | Y | N | 55 | Y | Y | Y | Y | |
| P02 | 302h | h | M1 Motor Selection | 26 | 00 to 50 Display (kW, HP) changes by setting F60. 00 to 35: Settings for VG-dedicated motors Data at F04, F05, and P03 to P27 are automatically set and write-protected. 36: P-OTHER (P-OTR on the keypad) Data at F04, F05, and P03 to P27 are write-protected and cannot be overwritten. 37: OTHER Data at F04, F05, and P03 to P27 are write-protected and cannot be overwritten. 38 to 50: Settings for the motor only for FRENIC-VG (8-series) Data at F04, F05, and P03 to P27 are automatically set and write-protected. For the relationship between the setting data and the motor type, refer to "List of Applicable Motors" in Section 4.3.4, P02 codes. | N | * | Y | N | 82 | Y | Y | Y | Y | |
| P03 | 303h | A7h | M1 Rated Capacity | 1 | For inverters of 400 kW or below 0.00 to 500.00 kW when F60 = 0 0.00 to 600.00 HP when F60 = 1 For inverters of 500 kW or above 0.00 to 1200 kW when F60 = 0 0.00 to 1600 HP when F60 = 1 For multivinding motors, set the motor capacity per wiring. | N | * | Y | N | 3 13 | Y | Y | Y | Y | |
| P04 | 304h | A8h | M1 Rated Current | 1 | 0.01 to 99.99 A 100.0 to 999.9 A 1000 to 2000 A | N | * | Y | N | 13 | Y | Y | Y | Y | |
| P05 | 305h | A9h | M1 Number of Poles | 1 | 2 to 100 poles | N | 4 | Y | N | 1 | Y | Y | Y | Y | |
| P06 | 306h | AAh | M1 %R1 | 1 | 0.00 to 30.00% | Y | * | Y | N | 3 | Y | Y | Y | Y | |
| P07 | 307h | ABh | M1 %X | 1 | 0.00 to 200.00% | Y | * | Y | N | 3 | Y | Y | Y | Y | |
| P08 | 308h | ACH | M1 Exciting Current/Magnetic Flux Weakening Current (-Id) | 1 | 0.01 to 99.99 A 100.0 to 999.9 A 1000 to 2000 A | Y | * | Y | N | 13 | Y | Y | Y | Y | |
| P09 | 309h | ADh | M1 Torque Current | 1 | 0.01 to 99.99 A 100.0 to 999.9 A 1000 to 2000 A | Y | * | Y | N | 13 | Y | Y | N | Y | |
| P10 | 30Ah | AEh | M1 Slip Frequency (For driving) | 1 | 0.001 to 10.000 Hz | Y | * | Y | N | 4 | Y | Y | N | N | |
| P11 | 30Bh | AFh | M1 Slip Frequency (For braking) | 1 | 0.001 to 10.000 Hz | Y | * | Y | N | 4 | Y | Y | N | N | |
| P12 | 30Ch | B0h | M1 Iron Loss Factor 1 | 1 | 0.00 to 10.00% | Y | * | Y | N | 3 | Y | Y | N | Y | |
| P13 | 30Dh | B1h | M1 Iron Loss Factor 2 | 1 | 0.00 to 10.00% | Y | * | Y | N | 3 | Y | Y | N | Y | |
| P14 | 30Eh | B2h | M1 Iron Loss Factor 3 | 1 | 0.00 to 10.00% | Y | * | Y | N | 3 | Y | Y | N | Y | |
| P15 | 30Fh | B3h | M1 Magnetic Saturation Factor 1 | 1 | 0.0 to 100.0% Compensation factor for exciting current when the magnetic flux command is 93.75% | Y | * | Y | N | 2 | Y | Y | N | N | |
| P16 | 310h | B4h | M1 Magnetic Saturation Factor 2 | 1 | 0.0 to 100.0% Compensation factor for exciting current when the magnetic flux command is 87.5% | Y | * | Y | N | 2 | Y | Y | N | N | |
| P17 | 311h | B5h | M1 Magnetic Saturation Factor 3 | 1 | 0.0 to 100.0% Compensation factor for exciting current when the magnetic flux command is 75% | Y | * | Y | N | 2 | Y | Y | N | N | |
| P18 | 312h | B6h | M1 Magnetic Saturation Factor 4 | 1 | 0.0 to 100.0% Compensation factor for exciting current when the magnetic flux command is 62.5% | Y | * | Y | N | 2 | Y | Y | N | N | |
| P19 | 313h | B7h | M1 Magnetic Saturation Factor 5 | 1 | 0.0 to 100.0% Compensation factor for exciting current when the magnetic flux command is 50% | Y | * | Y | N | 2 | Y | Y | N | N | |
| P20 | 314h | B8h | M1 Secondary Time Constant | 1 | 0.001 to 9.999 s | Y | * | Y | N | 4 | Y | Y | N | N | |
| P21 | 315h | B9h | M1 Induced Voltage Factor | 1 | 0 to 999 V | Y | * | Y | N | 0 | Y | Y | N | Y | |
| P22 | 316h | BAh | M1 R2 Correction Factor 1 | 1 | 0.500 to 5.000 | Y | * | Y | N | 4 | Y | Y | N | Y | |
| P23 | 317h | BBh | M1 R2 Correction Factor 2 | 1 | 0.500 to 5.000 | Y | * | Y | N | 4 | Y | Y | N | Y | |
| P24 | 318h | BCh | M1 R2 Correction Factor 3 | 1 | 0.010 to 5.000 | Y | * | Y | N | 4 | Y | Y | N | N | |
| P25 | 319h | BDh | M1 Exciting Current Correction Factor | 1 | 0.000 to 5.000 | Y | * | Y | N | 4 | Y | Y | N | N | |
| P26 | 31Ah | BEh | M1 ACR (P-gain) | 1 | 0.1 to 20.0 | Y | 1.0 | Y | N | 2 | Y | Y | N | Y | |
| P27 | 31Bh | BFh | M1 (I-time) | 1 | 0.1 to 100.0 ms | Y | 1.0 | Y | N | 2 | Y | Y | N | Y | |

*Depending upon the inverter's capacity.

| Function code | Communications address | | Name | Dir. | Data setting range | Change when running | Default setting | Data copying | Initialization | Format type | Drive control | | | Remarks |
|---------------|------------------------|----------|---|------|--|---------------------|-----------------|--------------|----------------|-------------|---------------|-----------|-----|---------|
| | 485 No. | Link No. | | | | | | | | | VC w/ PG | VC w/o PG | V/f | |
| P28 | 31Ch | C0h | M1 Pulse Resolution | 0 | 100 to 60000 | N | 1024 | Y | N | 0 | Y | N | N | Y |
| P29 | 31Dh | D6h | M1 External PG Correction Factor | 0 | 0000 to 4FFF | N | 4000 | Y | N | 9 | Y | N | N | N |
| P30 | 31Eh | C1h | M1 Thermistor Selection | 0 | 0 to 3 0: No thermistor 1: NTC thermistor 2: PTC thermistor 3: Ai (<i>M-TMP</i>) The protection level of the motor protective functions should be specified by E30 to E32. | N | 1 | Y | N | 84 | Y | Y | Y | Y |
| P32 | 320h | h | M1 Online Auto-tuning | 0 | 0 or 1 0: Disable 1: Enable Enabling this auto-tuning activates the compensation function for the resistance change caused by the temperature rise of the motor running. | Y | 0 | Y | N | 0 | Y | Y | N | N |
| P33 | 321h | h | M1 Maximum Output Voltage/ Maximum Voltage Limit | 0 | 80 to 999 V | Y | 220/ 440 | Y | N | 0 | N | N | Y | Y |
| P34 | 322h | h | M1 Slip Compensation | 3 | -20.000 to 5.000 Hz | Y | 0.000 | Y | N | 8 | N | N | Y | N |
| P35 | 323h | h | M1 Torque Boost | 1 | 0.0 to 20.0 Exclusive to V/f control. 0.0: Auto torque boost (for constant torque load) 0.1 to 0.9: For variable torque load 1.0 to 1.9: For proportional torque load 2.0 to 20.0: For constant torque load | Y | 0.0 | Y | N | 2 | N | N | Y | N |
| P36 | 324h | h | M1 Output Current Fluctuation Damping Gain | 1 | 0.00 to 1.00 | Y | 0.20 | Y | N | 3 | N | N | Y | N |
| P42 | 32Ah | h | M1 q-axis Inductance Magnetic Saturation Coefficient | 10 | 0 to 100% | Y | 100.0 | Y | N | 0 | N | N | N | Y |
| P43 | 32Bh | h | M1 Magnetic Flux Limiting Value | 1 | 50.0 to 150.0% | Y | * | Y | N | 2 | N | N | N | Y |
| P44 | 32Ch | h | M1 Overcurrent Protection Level | 1 | 0.00: Disable 0.01 to 99.99 A 100.0 to 999.9 A 1000 to 5000 A Specifies the allowable current value to prevent the permanent magnet of a PMSM from getting demagnetized. If the current exceeding this setting flows, an overcurrent alarm (\overline{OC}) occurs. | N | 0.00 | Y | N | 13 | N | N | N | Y |
| P45 | 32Dh | h | M1 Torque Correction Gain 1 | 1 | 0.00 to 10.00 | Y | * | Y | N | 3 | N | N | N | Y |
| P46 | 32Eh | h | M1 Torque Correction Gain 2 | 1 | 0.00 to 10.00 | Y | * | Y | N | 3 | N | N | N | Y |
| P47 | 32Fh | h | M1 Torque Correction Gain 3 | 1 | -1.000 to 1.000 | Y | * | Y | N | 8 | N | N | N | Y |
| P48 | 330h | h | M1 Torque Correction Gain 4 | 1 | -1.000 to 1.000 | Y | * | Y | N | 8 | N | N | N | Y |
| P49 | 331h | h | M1 Torque Correction Gain 5 | 1 | -50.00 to 50.00 | Y | * | Y | N | 7 | N | N | N | Y |
| P50 | 332h | h | M1 Torque Correction Gain 6 | 1 | -50.00 to 50.00 | Y | * | Y | N | 7 | N | N | N | Y |
| P51 | 333h | h | M1 Torque Correction Gain 7 | 1 | -1.000 to 1.000 | Y | * | Y | N | 8 | N | N | N | Y |

*Depending upon the inverter's capacity.

■ H codes (High Performance Functions)

| Function code | Communications address | | Name | Dir. | Data setting range | Change when running | Default setting | Data copying | Initialization | Format type | Drive control | | | Remarks | |
|---------------|------------------------|----------|--|------|---|---------------------|-----------------|--------------|----------------|-------------|---------------|-----------|-----|---------|-------------|
| | 485 No. | Link No. | | | | | | | | | VC w/ PG | VC w/o PG | V/f | | VC for PMSM |
| H01 | 401h | h | Auto-tuning | 0 | 0 to 4 0: Disable 1: ASR auto-tuning (Available soon) 2: Motor parameter auto-tuning (R1, L _σ) 3: Auto-tuning with the motor stopped 4: Auto-tuning with the motor running Upon completion of auto-tuning, the H01 data automatically reverts to "0." To save the tuned data, perform the Save all function (H02). | N | 0 | N | N | 61 | Y | Y | Y | Y | |
| H02 | 402h | Eh | Save All Function | 0 | 0 or 1 When tuning is executed at H01 and the internal data is written, or when the data is written by way of the link system (T-Link, field bus, and RS-458, etc.), the data goes out when the power supply of the inverter is turned off. This function must operate when preservation is necessary. After writing the data, this function's data code automatically returns to 0. | Y | 0 | N | N | 11 | Y | Y | Y | Y | |
| H03 | 403h | h | Data Initialization | 0 | 0 or 1 Setting H03 to "1" reverts the function code data modified by the customer to the factory defaults. Initialization targets include all fields of F, E, C, H, o, L and U codes except motor parameter fields (P, A), F04, F05, F10 to F12, and F58. Upon completion of the initialization, the H03 data automatically reverts to "0." | N | 0 | N | N | 11 | Y | Y | Y | Y | |
| H04 | 404h | h | Auto-reset (Times) | 0 | 0 to 10 0: Disable 1 to 10 times The auto-resetting signal can be output to the output terminal. | N | 0 | Y | Y | 0 | Y | Y | Y | Y | |
| H05 | 405h | H | Auto-reset (Reset interval) | 0 | 0.01 to 20.00 s | N | 5.00 | Y | Y | 3 | Y | Y | Y | Y | |
| H06 | 406h | h | Cooling Fan ON/OFF Control | 0 | 0 or 1 0: Disable 1: Enable This control detects the temperature of the heat sink in the inverter unit and turns the cooling fan ON/OFF automatically. It is possible to output the <i>FAN</i> (Cooling fan in operation) signal in conjunction with this function. | N | 0 | Y | Y | 68 | Y | Y | Y | Y | |
| H08 | 408h | h | Rev. Phase Sequence Lock | 0 | 0 or 1 0: Disable 1: Enable | Y | 0 | Y | Y | 68 | Y | N | N | Y | |
| H09 | 409h | C2h | Starting Mode (Auto search) | 0 | 0 to 2 0: Disable 1: Enable (At restart after momentary power failure) 2: Enable Auto search detects the idling motor speed at starting and drives the motor at the same speed without stopping it. | Y | 2 | Y | Y | 0 | N | Y | Y | N | |
| H10 | 40Ah | C3h | Energy-saving Operation | 0 | 0 or 1 0: Disable 1: Enable | N | 0 | Y | Y | 68 | Y | N | N | N | |
| H11 | 40Bh | h | Automatic Operation OFF Function | 0 | 0 to 4 0: Decelerate to stop when FWD-CM or REV-CM is opened 1: The inverter is turned off below the stop speed even for ON between FWD-CM and REV-CM. 2: Coast to stop when FWD-CM or REV-CM is opened 3: Decelerate to stop using ASR when FWD-CM or REV-CM is opened (under torque control) 4: Coast to stop when FWD-CM or REV-CM is opened (under torque control) | Y | 0 | Y | Y | 0 | Y | Y | Y | Y | |
| H13 | 40Dh | C4h | Restart Mode after Momentary Power Failure (Wait time) | 5 | 0.1 to 5.0 s | N | 0.5 | Y | Y | 2 | Y | Y | Y | Y | |
| H14 | 40Eh | h | (Decrease rate in speed) | 1 | 1 to 3600 r/min/s | Y | 500 | Y | Y | 0 | N | N | Y | N | |
| H15 | 40Fh | h | (Continuous running level) | 1 | 3-phase 200 V: 200 to 300 V 3-phase 400 V: 400 to 600 V This setting applies when F14 = 2 (Trip after recovery from power failure) or F14 = 3 (Continue to run). | Y | 235/470 | Y | Y | 0 | Y | Y | Y | Y | |
| H16 | 410h | h | (Run command self-hold setting) | 1 | 0 or 1 0: Setting made by H17 1: Maximum time (The inverter self-holds the run command while the control power supply in the inverter is established or until the DC link bus voltage comes to almost "0.") | N | 1 | Y | Y | 94 | Y | Y | Y | Y | |
| H17 | 411h | h | (Run command self-hold time) | 1 | 0.0 to 30.0 s | N | 30.0 | Y | Y | 2 | Y | Y | Y | Y | |

| Function code | Communications address | | Name | Dir. | Data setting range | Change when running | Default setting | Data copying | Initialization | Format type | Drive control | | | Remarks |
|---------------|------------------------|----------|---|------|--|---------------------|-----------------|--------------|----------------|-------------|---------------|-----------|----|---------|
| | 485 No. | Link No. | | | | | | | | | VC w/ PG | VC w/o PG | Vf | |
| H19 | 413h | C5h | Active Drive | 0 | 0 or 1 0: Disable 1: Enable Under vector control, this function automatically limits the output torque to avoid an overload trip, etc. | N | 0 | Y | Y | 68 | Y | Y | Y | Y |
| H20 | 414h | C6h | PID Control (Mode selection) | 8 | 0 to 3 0: Inactive 1: Active 2: Inverse action 1 3: Inverse action 2 | N | 0 | Y | Y | 69 | Y | Y | Y | Y |
| H21 | 415h | C7h | (Command selection) | 1 | 0 or 1 0: Keypad or input to terminal [12] 1: Analog input PID-REF | Y | 0 | Y | Y | 70 | Y | Y | Y | Y |
| H22 | 416h | C9h | (P-action) | 1 | 0.000 to 10.000 times | Y | 1.000 | Y | Y | 4 | Y | Y | Y | Y |
| H23 | 417h | CAh | (I-action) | 1 | 0.00 to 100.00 s | Y | 1.00 | Y | Y | 3 | Y | Y | Y | Y |
| H24 | 418h | CBh | (D-action) | 1 | 0.000 to 10.000 s | Y | 0.000 | Y | Y | 4 | Y | Y | Y | Y |
| H25 | 419h | C8h | (Upper limit) | 1 | -300 to 300% | N | 100 | Y | Y | 5 | Y | Y | Y | Y |
| H26 | 41Ah | CCh | (Lower limit) | 1 | -300 to 300% | N | -100 | Y | Y | 5 | Y | Y | Y | Y |
| H27 | 41Bh | CEh | (Speed command selection) | 1 | 0 to 2 0: Disable 1: Select PID 2: Select auxiliary speed | N | 0 | Y | Y | 95 | Y | Y | Y | Y |
| H28 | 41Ch | CFh | Droop Control | 0 | 0.0 to 25.0% | Y | 0.0 | Y | Y | 2 | Y | Y | N | Y |
| H29 | 41Dh | h | Communications Link Function (Data protection via link) | 2 | 0 or 1 0: Writable to function code fields 1: Write-protect function code fields Setting H29 to "1" protects function code data from getting changed mistakenly via the link (T-Link, RS-485, etc.). Via the link, data can be written to the "function code fields" (given above) or "command data fields" (S fields). The S fields are defined by H30. | Y | 0 | Y | Y | 40 | Y | Y | Y | Y |
| H30 | 41Eh | D0h | (Link operation) | 1 | 0 to 3 Monitor Command data Run command (FWD, REV) 0: Y N N 1: Y Y N 2: Y N Y 3: Y Y Y | Y | 0 | Y | Y | 72 | Y | Y | Y | Y |
| H31 | 41Fh | h | RS-485 Communication (Station address) | 10 | 0 to 255 Broadcast: (0: RTU), (99: Fuji) Address: 1 to 255 Specify the station address of RS-485. | N | 1 | Y | N | 0 | Y | Y | Y | Y |
| H32 | 420h | h | (Error processing) | 1 | 0 to 3 0: Immediately trip with $E-S$ 1: Trip with $E-S$ after running for the period specified by timer H33. 2: Trip with $E-S$ if a communications error persists exceeding the period specified by timer H33. 3: Continue to run | Y | 3 | Y | Y | 73 | Y | Y | Y | Y |
| H33 | 421h | h | (Timer) | 1 | 0.01 to 20.00 s | Y | 2.00 | Y | Y | 3 | Y | Y | Y | Y |
| H34 | 422h | h | (Baud rate) | 1 | 0 to 4 0: 38400 bps 1: 19200 bps 2: 9600 bps 3: 4800 bps 4: 2400 bps | Y | 0 | Y | N | 74 | Y | Y | Y | Y |
| H35 | 423h | h | (Data length) | 1 | 0 or 1 0: 8 bits 1: 7 bits | Y | 0 | Y | N | 75 | Y | Y | Y | Y |
| H36 | 424h | h | (Parity check) | 1 | 0 to 2 0: None 1: Even parity 2: Odd parity | Y | 1 | Y | N | 76 | Y | Y | Y | Y |
| H37 | 425h | h | (Stop bits) | 1 | 0 or 1 0: 2 bits 1: 1 bit | Y | 1 | Y | N | 77 | Y | Y | Y | Y |
| H38 | 426h | h | (Communications line break time) | 1 | 0.0 to 60.0 s 0.0: Disable detection 0.1 to 60.0: Enable detection | Y | 60.0 | Y | Y | 2 | Y | Y | Y | Y |
| H39 | 427h | h | (Response interval) | 1 | 0.00 to 1.00 s | Y | 0.01 | Y | Y | 3 | Y | Y | Y | Y |
| H40 | 428h | h | (Protocol selection) | 1 | 0 to 2 0: Fuji general-purpose inverter protocol 1: SX protocol (Loader protocol) 2: Modbus RTU protocol To use FRENIC-VG Loader, set H40 to "1." | N | 1 | Y | N | 78 | Y | Y | Y | Y |

| Function code | Communications address | | Name | Dir. | Data setting range | Change when running | Default setting | Data copying | Initialization | Format type | Drive control | | | Remarks |
|---------------|------------------------|----------|--------------------------------------|------|---|---------------------|-----------------|--------------|----------------|-------------|---------------|-----------|----|---------|
| | 485 No. | Link No. | | | | | | | | | VC w/ PG | VC w/o PG | Vf | |
| H41 | 429h | D1h | Torque Command Source | 4 | 0 to 5 0: Internal ASR output 1: Ai terminal input T-REF 2: DIA card 3: DIB card 4: Communications link 5: PID | N | 0 | Y | Y | 64 | Y | Y | N | Y |
| H42 | 42Ah | D2h | Torque Current Command Source | 1 | 0 to 4 0: Internal ASR output 1: Ai terminal input IT-REF 2: DIA card 3: DIB card 4: Communications link | N | 0 | Y | Y | 65 | Y | Y | N | Y |
| H43 | 42Bh | D3h | Magnetic Flux Command Source | 1 | 0 to 3 0: Internal calculation 1: Ai terminal input MF-REF 2: Function code H44 3: Communications link | N | 0 | Y | Y | 66 | Y | N | N | N |
| H44 | 42Ch | D4h | Magnetic Flux Command Value | 1 | 10 to 100% | N | 100 | Y | Y | 16 | Y | N | N | N |
| H46 | 42Eh | D7h | Observer (Mode selection) | 7 | 0 to 2 0: Disable 1: Enable (Load disturbance observer) 2: Enable (Oscillation suppressing observer) | N | 0 | Y | Y | 79 | Y | Y | N | Y |
| H47 | 42Fh | D8h | (M1 compensation gain) | 1 | 0.00 to 1.00 times | Y | 0.00 | Y | Y | 3 | Y | Y | N | Y |
| H48 | 430h | h | (M2 compensation gain) | 1 | 0.00 to 1.00 times | Y | 0.00 | Y | Y | 3 | Y | Y | N | Y |
| H49 | 431h | D9h | (M1 I-time) | 1 | 0.005 to 1.000 s | Y | 0.100 | Y | Y | 4 | Y | Y | N | Y |
| H50 | 432h | h | (M2 I-time) | 1 | 0.005 to 1.000 s | Y | 0.100 | Y | Y | 4 | Y | Y | N | Y |
| H51 | 433h | DAh | (M1 load inertia) | 1 | 0.001 to 50,000 kg·m ² The magnification is switchable by H228. | Y | * | Y | N | 4 | Y | Y | N | Y |
| H52 | 434h | h | (M2 load inertia) | 1 | 0.001 to 50,000 kg·m ² The magnification is switchable by H228. | Y | 0.001 | Y | N | 4 | Y | Y | N | Y |
| H53 | 435h | D5h | Line Speed Feedback Selection | 0 | 0 to 3 0: Disable line speed (Integrated PG enabled) Note that Ai input or PG (LD) should be high level-select in UPAC. 1: Detect analog line speed (AI-LINE) 2: Detect digital line speed (PG(LD)) 3: High level selected signal (Select high level of motor speed and line speed.) | Y | 0 | Y | Y | 67 | Y | Y | Y | Y |
| H55 | 437h | h | Zero Speed Control (Gain) | 2 | 0 to 100 times For details, refer to X terminal command LOCK assigned by any of E01 to E13. | Y | 5 | Y | Y | 0 | Y | N | N | Y |
| H56 | 438h | h | (Completion range) | 1 | 0 to 100 pulses | Y | 100 | Y | Y | 0 | Y | N | N | Y |
| H57 | 439h | h | Overvoltage Suppression | 2 | 0 or 1 0: Disable 1: Enable | N | 0 | Y | Y | 68 | Y | Y | Y | Y |
| H58 | 43Ah | h | Overcurrent Suppression | 1 | 0 or 1 0: Disable 1: Enable | N | 0 | Y | Y | 68 | Y | Y | Y | Y |
| H60 | 43Ch | h | Load Adaptive Control (Definition 1) | 7 | 0 to 3 0: Disable 1: Method 1 2: Method 2 3: Method 3 | N | 0 | Y | Y | 80 | Y | N | N | Y |
| H61 | 43Dh | h | (Definition 2) | 1 | 0 or 1 0: Winding up in forward rotation 1: Winding down in forward rotation | N | 0 | Y | Y | 81 | Y | N | N | Y |
| H62 | 43Eh | h | (Winding-up speed) | 1 | 0.0 to 999.9 m/min | N | 0.0 | Y | Y | 2 | Y | N | N | Y |
| H63 | 43Fh | h | (Counter weight) | 1 | 0.00 to 600.00 t | N | 0.00 | Y | Y | 3 | Y | N | N | Y |
| H64 | 440h | h | (Safety coefficient) | 1 | 0.50 to 1.20 | N | 1.00 | Y | Y | 3 | Y | N | N | Y |
| H65 | 441h | h | (Machine efficiency) | 1 | 0.500 to 1.000 | N | 0.500 | Y | Y | 4 | Y | N | N | Y |
| H66 | 442h | h | (Rated load) | 1 | 0.00 to 600.00 t | N | 0.00 | Y | Y | 3 | Y | N | N | Y |
| H68 | 444h | h | Alarm Data Deletion | 0 | 0 or 1 Setting H68 to "1" deletes all of the alarm history, alarm causes and alarm information held in the inverter memory. After that, the H68 data automatically reverts to "0." | Y | 0 | N | N | 11 | Y | Y | Y | Y |
| H70 | 446h | h | Reserved 1 | 2 | 0 to 9999 Reserved. (Do not access this function code.) | N | 0 | Y | N | 0 | Y | Y | N | Y |
| H71 | 447h | h | Reserved 2 | 1 | 0 to 10 5: Magnetic pole position offset tuning When you mount a PG on the motor or replace the PG at the site for motors having no magnetic pole position offset label, perform automatic adjustment with the tuning function (H71 = 5) | N | 0 | N | N | 62 | Y | Y | Y | Y |
| H74 | 44Ah | h | PG Detection Circuit Self-diagnosis | 0 | 0 or 1 0: Disable 1: Enable This function performs self-diagnosis of the speed detection circuit by pulse generator signals (PA, PB). | N | 0 | Y | Y | 225 | Y | Y | N | Y |

*Depending upon the inverter's capacity.

| Function code | Communications address | | Name | Dir. | Data setting range | Change when running | Default setting | Data copying | Initialization | Format type | Drive control | | | Remarks |
|---------------|------------------------|----------|---|------|--|---------------------|-----------------|--------------|----------------|-------------|---------------|-----------|----|---------|
| | 485 No. | Link No. | | | | | | | | | VC w/ PG | VC w/o PG | Vf | |
| H75 | 44Bh | h | Phase Sequence Configuration of Main Circuit Output Wires | 0 | 0 or 1 0: Positive phase U-V-W 1: Negative phase U-W-V Switches the phase sequence of the inverter main circuit. | N | 0 | Y | Y | 197 | Y | Y | Y | Y |
| H76 | 44Ch | h | Main Power Down Detection | 0 | 0 or 1 0: Disable 1: Enable Enable this function to enable the AC power monitor. Disable this function when DC power is supplied, e.g., connecting with a power regenerative converter. | Y | 0 | Y | Y | 0 | Y | Y | Y | Y |
| H77 | 44Dh | h | Cooling Fan ON/OFF Control Continuation Timer | 0 | 0 to 600 s Specifies the condition of the cooling fan ON/OFF control by H06. | Y | 600 | Y | Y | 0 | Y | Y | Y | Y |
| H78 | 44Eh | h | Initialization of Startup Counter/ Total Run Time | 6 | 0 to 6 0: Disable 1: M1 number of startups 2: M2 number of startups 3: M3 number of startups 4: M1 cumulative run time 5: M2 cumulative run time 6: M3 cumulative run time Initializes the number of startups and cumulative run time. | N | 0 | N | N | 0 | Y | Y | Y | Y |
| H79 | 44Fh | h | Initialization of Cumulative Run Time of Cooling Fan | 1 | 0 to 65535 (in units of 10 hours) Initializes the cumulative run time when the cooling fan is replaced. Usually, write "0" after replacement. | N | 0 | N | N | 0 | Y | Y | Y | Y |
| H80 | 450h | h | Capacitance Measurement of DC Link Bus Capacitor | 1 | 0 to 32767 When the capacitance measurement is user mode (H104), setting this function code at "0" and shutting down the inverter power starts measuring the initial value of the capacitance and sets the measurement result to this function code. | N | 0 | N | Y | 0 | Y | Y | Y | Y |
| H81 | 451h | h | Initialization of Service Life of DC Link Bus Capacitor | 1 | 0 to 65535 (in units of 10 hours) Initializes the elapsed time of the DC link bus capacitor. | N | 0 | N | Y | 0 | Y | Y | Y | Y |
| H82 | 452h | h | Startup Count for Maintenance | 1 | 0 to 65535 Specifies the number of startups for performing maintenance of the machinery. | Y | 0 | N | Y | 0 | Y | Y | Y | Y |
| H83 | 453h | h | Maintenance Interval | 1 | 0 to 65535 (in units of 10 hours) Specifies the maintenance interval for performing maintenance of the machinery. | Y | 8760 | N | Y | 0 | Y | Y | Y | Y |
| H84 *1 | 454h | h | Speed calculation period when extremely low speed (for maker) | 0 | 0.0 to 200.0ms The sampling period setting of the encoder pulse in extremely low speed region. This is a function code for maker. Do not access this function code. | N | 0.0 | Y | Y | 2 | Y | N | N | Y |
| H85 | 455h | h | Calendar Clock (Year/month) (Day/hour) (Minute/second) (Setting up clock) | 4 | 0000 to FFFF Upper two digits: Year, Lower two digits: Month | Y | 0001 | N | Y | 143 | Y | Y | Y | Y |
| H86 | 456h | h | | 1 | 0000 to FFFF Upper two digits: Date, Lower two digits: Time | Y | 0100 | N | Y | 144 | Y | Y | Y | Y |
| H87 | 457h | h | | 1 | 0000 to FFFF Upper two digits: Minute, Lower two digits: Second | Y | 0000 | N | Y | 145 | Y | Y | Y | Y |
| H88 | 458h | h | | 1 | 0 or 1 0: Disable 1: Write the current date and time Setting H88 to "1" sets up the calendar clock in accordance with the settings of H85 to H87. After that, the H88 data automatically reverts to "0." | Y | 0 | N | N | 11 | Y | Y | Y | Y |
| H90 | 45Ah | h | Overspeed Alarm Detection Level | 0 | 100 to 160% | Y | 120 | Y | Y | 0 | Y | Y | N | Y |
| H96 *1 | 460h | h | ASR operation selecting | 0 | 0 to 3 0: P priority (VG1) 1: I priority (compatible with VM5) 2: P priority (compatible with VM5) 3: For maker (Do not select this) | N | 0 | Y | Y | 201 | Y | Y | N | Y |
| H101 | 1F01h | h | PID Command Filter Time Constant | 0 | 0 to 5000 ms Specifies the time constant of the PID command filter (after switched by H21). | Y | 0 | Y | Y | 0 | Y | Y | Y | Y |

*1 Available in the ROM version H1/2 0067 or later

| Function code | Communications address | | Name | Dir. | Data setting range | Change when running | Default setting | Data copying | Initialization | Format type | Drive control | | | Remarks |
|---------------|------------------------|----------|---|------|---|---------------------|-----------------|--------------|----------------|-------------|---------------|-----------|-----|---------|
| | 485 No. | Link No. | | | | | | | | | VC w/ PG | VC w/o PG | V/f | |
| H103 | 1F03h | h | Protective/Maintenance Function Selection 1 | 9 | 0000 to 1111 Selects the protective functions individually. (0: Disable, 1: Enable) Thousands digit: Start delay (L_{DL}) Hundreds digit: Ground fault (EF) Tenths digit: Output phase loss (DPL) Units digit: Braking transistor broken (dbb) | Y | 0101 | Y | Y | 9 | Y | Y | Y | |
| H104 | 1F04h | h | Protective/Maintenance Function Selection 2 | 1 | 0000 to 1111 Selects the protective/maintenance functions individually. (0: Disable, 1: Enable) Thousands digit: PG wire break alarm (PG) Hundreds digit: Lower the carrier frequency Tenths digit: Judge the life of DC link bus capacitor Units digit: Select life judgment threshold of DC link bus capacitor (0: Factory default level, 1: User setup level) | Y | 1110 | Y | Y | 9 | Y | Y | Y | |
| H105 | 1F05h | h | Protective/Maintenance Function Selection 3 | 1 | 0000 to 1111 Selects the protective/maintenance functions individually. (0: Disable, 1: Enable) Thousands digit: -- Hundreds digit: Speed disaccord alarm $E-S$ operation 1 *1 Tenths digit: Speed disaccord alarm $E-S$ operation 2 *1 Units digit: Save the integrated value of motor electronic thermal | Y | 0000 | Y | Y | 9 | Y | Y | Y | |
| H106 | 1F06h | h | Light Alarm Object Definition 1 | 1 | 0000 to 1111 (0: Heavy alarm ($E-r$), 1: Light alarm ($L-RL$)) Thousands digit: OH "Motor overheat" Hundreds digit: $OL 1-OL 3$ "Motor 1 to 3 overload" Tenths digit: rb "NTC thermistor wire break error" Units digit: HE "External alarm" | N | 0000 | Y | Y | 9 | Y | Y | Y | |
| H107 | 1F07h | h | Light Alarm Object Definition 2 | 1 | 0000 to 1111 (0: Heavy alarm ($E-r$), 1: Light alarm ($L-RL$)) Thousands digit: $E-S$ "RS-485 communications error" Hundreds digit: $E-4$ "Network error" Tenths digit: Reserved Units digit: $R-E$ "Toggle abnormality error" | N | 0000 | Y | Y | 9 | Y | Y | Y | |
| H108 | 1F08h | h | Light Alarm Object Definition 3 | 1 | 0000 to 1111 (0: Heavy alarm ($E-r$), 1: Light alarm ($L-RL$)) Thousands digit: $E-r$ "Mock alarm" Hundreds digit: dFF "DC fan locked" Tenths digit: $E-S$ "Speed mismatch" L_{DL} "Start delay" Units digit: $R-E$ "E-SX bus tact synchronization error" | N | 0000 | Y | Y | 9 | Y | Y | Y | |
| H109 | 1F09h | h | Light Alarm Object Definition 4 | 1 | 0000 to 1111 (0: Heavy alarm ($E-r$), 1: Light alarm ($L-RL$)) Thousands digit: Reserved Hundreds digit: Reserved Tenths digit: Reserved Units digit: Reserved | N | 0000 | Y | Y | 9 | Y | Y | Y | |
| H110 | 1F0Ah | h | Light Alarm Object Definition 5 | 1 | 0000 to 1111 (0: Cancel light alarm, 1: Light alarm ($L-RL$)) Thousands digit: OH "Motor overheat early warning" OL "Motor overload early warning" Hundreds digit: bP "Battery life expired" Tenths digit: L_{LF} "Life time early warning" Units digit: $OH OL$ "Heat sink overheat early warning / overload early warning" | N | 0000 | Y | Y | 9 | Y | Y | Y | |
| H111 | 1F0Bh | h | Light Alarm Object Definition 6 | 1 | 0 or 1 0: Disable ($L-RL$ not shown) 1: Enable ($L-RL$ shown) Specified whether or not to display $L-RL$ on the LED monitor when a light alarm occurs. | N | 1 | Y | Y | 68 | Y | Y | Y | |
| H112 | 1F0Ch | h | M1 Magnetic Saturation Extension Coefficient 6 | 7 | 0.0 to 100.0% Compensation factor for exciting current when the magnetic flux command is 43.75%. | Y | 43.8 | Y | N | 2 | Y | N | N | |
| H113 | 1F0Dh | h | M1 Magnetic Saturation Extension Coefficient 7 | 1 | 0.0 to 100.0% Compensation factor for exciting current when the magnetic flux command is 37.5%. | Y | 37.5 | Y | N | 2 | Y | N | N | |
| H114 | 1F0Eh | h | M1 Magnetic Saturation Extension Coefficient 8 | 1 | 0.0 to 100.0% Compensation factor for exciting current when the magnetic flux command is 31.25%. | Y | 31.3 | Y | N | 2 | Y | N | N | |
| H115 | 1F0Fh | h | M1 Magnetic Saturation Extension Coefficient 9 | 1 | 0.0 to 100.0% Compensation factor for exciting current when the magnetic flux command is 25%. | Y | 25.0 | Y | N | 2 | Y | N | N | |
| H116 | 1F10h | h | M1 Magnetic Saturation Extension Coefficient 10 | 1 | 0.0 to 100.0% Compensation factor for exciting current when the magnetic flux command is 18.75%. | Y | 18.8 | Y | N | 2 | Y | N | N | |

*1 Available in the ROM version H1/2 0067 or later

| Function code | Communications address | | Name | Dir. | Data setting range | Change when running | Default setting | Data copying | Initialization | Format type | Drive control | | | Remarks | |
|---------------|------------------------|----------|--|------|---|---------------------|-----------------|--------------|----------------|-------------|---------------|-----------|----|---------|-------------|
| | 485 No. | Link No. | | | | | | | | | VC w/ PG | VC w/o PG | Vf | | VC for PMSM |
| H117 | 1F11h | h | M1 Magnetic Saturation Extension Coefficient 11 | 1 | 0.0 to 100.0% Compensation factor for exciting current when the magnetic flux command is 12.5%. | Y | 12.5 | Y | N | 2 | Y | N | N | N | |
| H118 | 1F12h | h | M1 Magnetic Saturation Extension Coefficient 12 | 1 | 0.0 to 100.0% Compensation factor for exciting current when the magnetic flux command is 6.25%. | Y | 6.3 | Y | N | 2 | Y | N | N | N | |
| H125 | 1F19h | h | Observer (M3 compensation gain) | 1 | 0.00 to 1.00 times | Y | 0.00 | Y | Y | 3 | Y | Y | N | Y | |
| H126 | 1F1Ah | h | (M3 integral time) | 1 | 0.005 to 1.000 s | Y | 0.100 | Y | Y | 4 | Y | Y | N | Y | |
| H127 | 1F1Bh | h | (M3 load inertia) | 1 | 0.001 to 50.000 kg·m ² The magnification is switchable by H228. | Y | 0.001 | Y | Y | 4 | Y | Y | N | Y | |
| H134 | 1F22h | h | Speed Drop Detection Delay Timer | 5 | 0.000 to 10.000 s | N | 0.000 | Y | Y | 4 | N | Y | N | N | |
| H135 | 1F23h | h | Speed Command Detection Level (FWD) | 1 | 0.0 to 150.0 r/min | N | 0.0 | Y | Y | 2 | N | Y | N | N | |
| H136 | 1F24h | h | (REV) | 1 | 0.0 to 150.0 r/min | N | 0.0 | Y | Y | 2 | N | Y | N | N | |
| H137 | 1F25h | h | Speed Drop Detection Level | 1 | 0.0 to 150.0 r/min | N | 0.0 | Y | Y | 2 | N | Y | N | N | |
| H138 | 1F26h | h | Speed Command Detection Delay Timer | 1 | 0.000 to 10.000 s | N | 0.000 | Y | Y | 4 | N | Y | N | N | |
| H140 | 1F28h | h | Start Delay Detection (Detection level) | 1 | 0.0 to 300.0% | Y | 150.0 | Y | Y | 2 | Y | Y | N | Y | |
| H141 | 1F29h | h | (Detection timer) | 1 | 0.000 to 10.000 s | Y | 1.000 | Y | Y | 0 | Y | Y | N | Y | |
| H142 | 1F2Ah | h | Mock Alarm | 0 | 0 or 1 0: Disable 1: Cause a mock alarm When H108 does not define a mock alarm as a light alarm, a heavy alarm ($\overline{L-L}$) occurs; when it defines a mock alarm as a light alarm, a light alarm ($L-\overline{L}$) occurs. Holding down the STOP and RESET keys simultaneously for three seconds also causes a mock alarm. | Y | 0 | N | N | 11 | Y | Y | Y | Y | |
| H144 | 1F2Ch | h | Toggle Data Error Timer | 0 | 0.01 to 20.00 s H144 specifies the toggle data error detection time. | Y | 0.10 | Y | Y | 3 | Y | Y | Y | Y | |
| H145 | 1F2Dh | h | Reverse Run Prevention for Vector Control without Speed Sensor (Lower limit frequency selection) | 3 | 0 to 3 0: Disable 1: Enable for FWD unipolar operation 2: Enable for REV unipolar operation 3: Enable for FWD/REV bipolar operation | N | 0 | Y | Y | 202 | N | Y | N | N | |
| H146 | 1F2Eh | h | (Lower limit frequency, FWD) | 1 | 0.000 to 10.000 Hz | N | 0.000 | Y | Y | 4 | N | Y | N | N | |
| H147 | 1F2Fh | h | (Lower limit frequency, REV) | 1 | 0.000 to 10.000 Hz | N | 0.000 | Y | Y | 4 | N | Y | N | N | |
| H148 | 1F30h | h | Estimated Primary Frequency Filter | 0 | 0 to 100 ms Increase this setting if the speed fluctuation is large under vector control without speed sensor. | N | 0 | Y | Y | 0 | N | Y | N | N | |
| H149 | 1F31h | h | Machine Runaway Detection Speed Setting | 0 | 0.0 to 20.0% 0.0: Disable 0.1 to 20.0% Assuming the maximum speed as 100%. | N | 0.0 | Y | Y | 2 | Y | Y | N | Y | |
| H160 | 1F3Ch | h | M1 Initial Magnetic Pole Position Detection Mode | 3 | 0 to 3 0: Pull-in by current for IPMSM (Interior Permanent Magnet Synchronous Motor) 1-3: - | N | 0 | Y | N | 0 | N | N | N | Y | |
| H161 | 1F3Dh | h | M1 Pull-in Current Command | 1 | 10 to 200% 100%/Motor rated current | N | 80 | Y | N | 0 | N | N | N | Y | |
| H162 | 1F3Eh | h | M1 Pull-in Frequency | 1 | 0.1 to 10.0 Hz | N | 1.0 | Y | N | 2 | N | N | N | Y | |
| H170 | 1F46h | h | M2 Initial Magnetic Pole Position Detection Mode | 3 | 0 to 3 0: Pull-in by current for IPMSM (Interior Permanent Magnet Synchronous Motor) 1-3: - | N | 0 | Y | N | 0 | N | N | N | Y | |
| H171 | 1F47h | h | M2 Pull-in Current Command | 1 | 10 to 200% 100%/Motor rated current | N | 80 | Y | N | 0 | N | N | N | Y | |
| H172 | 1F48h | h | M2 Pull-in Frequency | 1 | 0.1 to 10.0 Hz | N | 1.0 | Y | N | 2 | N | N | N | Y | |

| Function code | Communications address | | Name | Dir. | Data setting range | Change when running | Default setting | Data copying | Initialization | Format type | Drive control | | | Remarks | |
|---------------|------------------------|----------|--|------|--|---------------------|-----------------|--------------|----------------|-------------|---------------|-----------|----|---------|-------------|
| | 485 No. | Link No. | | | | | | | | | VC w/ PG | VC w/o PG | Vf | | VC for PMSM |
| H180 | 1F50h | h | M3 Initial Magnetic Pole Position Detection Mode | 8 | 0 to 3 0: Pull-in by current for IPMSM (Interior Permanent Magnet Synchronous Motor) 1-3: - | N | 0 | Y | N | 0 | N | N | N | Y | |
| H181 | 1F51h | h | M3 Pull-in Current Command | 1 | 10 to 200% 100%/Motor rated current | N | 80 | Y | N | 0 | N | N | N | Y | |
| H182 | 1F52h | h | M3 Pull-in Frequency | 1 | 0.1 to 10.0 Hz | N | 1.0 | Y | N | 2 | N | N | N | Y | |
| H201 | 2001h | h | Load Adaptive Control (Load adaptive control parameter switching) (Available soon) | 13 | 0 or 1 0: Enable H51/H64/H65, Disable H202-H213 1: Disable H51/H64/H65, Enable H202-H213 | N | 0 | Y | Y | 0 | Y | N | N | Y | |
| H202 | 2002h | h | (Load inertia for winding up 1) (Available soon) | 1 | 0.001 to 50.000 kg·m ² Applies to winding-up operation when AN-P2/1 is OFF. The magnification is switchable by H228. | N | 0.001 | Y | Y | 4 | Y | N | N | Y | |
| H203 | 2003h | h | (Safety coefficient for winding up 1) (Available soon) | 1 | 0.50 to 1.20 Applies to winding-up operation when AN-P2/1 is OFF. | N | 1.00 | Y | Y | 3 | Y | N | N | Y | |
| H204 | 2004h | h | (Mechanical efficiency for winding up 1) (Available soon) | 1 | 0.500 to 1.000 Applies to winding-up operation when AN-P2/1 is OFF. | N | 0.500 | Y | Y | 4 | Y | N | N | Y | |
| H205 | 2005h | h | (Load inertia for winding up 2) (Available soon) | 1 | 0.001 to 50.000 kg·m ² Applies to winding-up operation when AN-P2/1 is ON. The magnification is switchable by H228. | N | 0.001 | Y | Y | 4 | Y | N | N | Y | |
| H206 | 2006h | h | (Safety coefficient for winding up 2) (Available soon) | 1 | 0.50 to 1.20 Applies to winding-up operation when AN-P2/1 is ON. | N | 1.00 | Y | Y | 3 | Y | N | N | Y | |
| H207 | 2007h | h | (Mechanical efficiency for winding up 2) (Available soon) | 1 | 0.500 to 1.000 Applies to winding-up operation when AN-P2/1 is ON. | N | 0.500 | Y | Y | 4 | Y | N | N | Y | |
| H208 | 2008h | h | (Load inertia for winding down 1) (Available soon) | 1 | 0.001 to 50.000 kg·m ² Applies to winding-down operation when AN-P2/1 is OFF. The magnification is switchable by H228. | N | 0.001 | Y | Y | 4 | Y | N | N | Y | |
| H209 | 2009h | h | (Safety coefficient for winding down 1) (Available soon) | 1 | 0.50 to 1.20 Applies to winding-down operation when AN-P2/1 is OFF. | N | 1.00 | Y | Y | 3 | Y | N | N | Y | |
| H210 | 200Ah | h | (Mechanical efficiency for winding down 1) (Available soon) | 1 | 0.500 to 1.000 Applies to winding-down operation when AN-P2/1 is OFF. | N | 0.500 | Y | Y | 4 | Y | N | N | Y | |
| H211 | 200Bh | h | (Load inertia for winding down 2) (Available soon) | 1 | 0.001 to 50.000 kg·m ² Applies to winding-down operation when AN-P2/1 is ON. The magnification is switchable by H228. | N | 0.001 | Y | Y | 4 | Y | N | N | Y | |
| H212 | 200Ch | h | (Safety coefficient for winding down 2) (Available soon) | 1 | 0.50 to 1.20 Applies to winding-down operation when AN-P2/1 is ON. | N | 1.00 | Y | Y | 3 | Y | N | N | Y | |
| H213 | 200Dh | h | (Mechanical efficiency for winding down 2) (Available soon) | 1 | 0.500 to 1.000 Applies to winding-down operation when AN-P2/1 is ON. | N | 0.500 | Y | Y | 4 | Y | N | N | Y | |
| H214 | 200Eh | h | (Multi-limit speed pattern function) (Available soon) | 14 | 0 or 1 0: Enable H60, Disable H215-H224 1: Disable H60, Enable H215-H224 | N | 0 | Y | Y | 0 | Y | N | N | Y | |
| H215 | 200Fh | h | (Multi-limit speed pattern at max. speed) (Available soon) | 1 | 0.1 to 100.0% Specifies the torque level at the maximum speed. | N | 50.0 | Y | Y | 2 | Y | N | N | Y | |
| H216 | 2010h | h | (Multi-limit speed pattern at rated speed) (Available soon) | 1 | 0.1 to 100.0% Specifies the torque level at the rated speed. | N | 100.0 | Y | Y | 2 | Y | N | N | Y | |
| H217 | 2011h | h | (Multi-limit speed pattern at rated speed x 1.1) (Available soon) | 1 | 0.1 to 100.0% Specifies the torque level at the rated speed*1.1. | N | 90.9 | Y | Y | 2 | Y | N | N | Y | |
| H218 | 2012h | h | (Multi-limit speed pattern at rated speed x 1.2) (Available soon) | 1 | 0.1 to 100.0% Specifies the torque level at the rated speed*1.2. | N | 83.3 | Y | Y | 2 | Y | N | N | Y | |
| H219 | 2013h | h | (Multi-limit speed pattern at rated speed x 1.4) (Available soon) | 1 | 0.1 to 100.0% Specifies the torque level at the rated speed*1.4. | N | 71.4 | Y | Y | 2 | Y | N | N | Y | |
| H220 | 2014h | h | (Multi-limit speed pattern at rated speed x 1.6) (Available soon) | 1 | 0.1 to 100.0% Specifies the torque level at the rated speed*1.6. | N | 62.5 | Y | Y | 2 | Y | N | N | Y | |
| H221 | 2015h | h | (Multi-limit speed pattern at rated speed x 1.8) (Available soon) | 1 | 0.1 to 100.0% Specifies the torque level at the rated speed*1.8. | N | 55.5 | Y | Y | 2 | Y | N | N | Y | |
| H222 | 2016h | h | (Multi-limit speed pattern at rated speed x 2.0) (Available soon) | 1 | 0.1 to 100.0% Specifies the torque level at the rated speed*2.0. | N | 50.0 | Y | Y | 2 | Y | N | N | Y | |

| Function code | Communications address | | Name | Dir. | Data setting range | Change when running | Default setting | Data copying | Initialization | Format type | Drive control | | | Remarks |
|---------------|------------------------|----------|---|------|---|---------------------|---|--------------|----------------|-------------|---------------|-----------|-----|---------|
| | 485 No. | Link No. | | | | | | | | | VC w/ PG | VC w/o PG | V/f | |
| H223 | 2017h | h | (Multi-limit speed pattern at rated speed x 2.5) (Available soon) | 1 | 0.1 to 100.0% Specifies the torque level at the rated speed*2.5. | N | 40.0 | Y | Y | 2 | Y | N | N | Y |
| H224 | 2018h | h | (Multi-limit speed pattern at rated speed x 3.0) (Available soon) | 1 | 0.1 to 100.0% Specifies the torque level at the rated speed*3.0. | N | 33.3 | Y | Y | 2 | Y | N | N | Y |
| H225 | 2019h | h | (Limit speed discrimination zone, Start speed) (Available soon) | 1 | 0.1 to 100.0% Specifies the starting speed of the discrimination zone. The rated speed is assumed as 100%. | N | 75.0 | Y | Y | 2 | Y | N | N | Y |
| H226 | 201Ah | h | (Limit speed discrimination zone, Completion speed) (Available soon) | 1 | 0.1 to 100.0% Specifies the end speed of the discrimination zone. The rated speed is assumed as 100%. | N | 93.7 | Y | Y | 2 | Y | N | N | Y |
| H227 | 201Bh | h | (Function definition 3) (Available soon) | 1 | 0 to 2 0: Calculate the limit speed for winding-up and winding-down individually 1: Drive winding-down operation using the last limited speed result Enable the winding-down limit calculation under specific conditions 2: Drive winding-down operation using the last limited speed result Limit the winding-down speed with the rated speed under specific conditions | N | 0 | Y | Y | 0 | Y | N | N | Y |
| H228 | 201Ch | h | Load Inertia Magnification Setting | 0 | 0 to 2 0: 1 time (0.001 to 50.000 kg·m ²) 1: 10 times (0.01 to 500.00 kg·m ²) 2: 100 times (0.1 to 5000.0 kg·m ²) Switches the magnification of the load inertia (H51, H52, H202, H205, H208, H211). | N | 630 kW or less: 0 710 kW, or more: 1 | Y | Y | 193 | Y | N | N | Y |
| H322 | 2116h | | Notch Filter 1 (Resonance frequency) (Attenuation level) (Frequency range) | 6 | 10 to 2000 Hz | Y | 1000 | Y | Y | 0 | Y | Y | N | Y |
| H323 | 2117h | | | 1 | 0 to 40 dB | Y | 0 | Y | Y | 0 | Y | Y | N | Y |
| H324 | 2118h | | | 1 | 0 to 3 | Y | 2 | Y | Y | 0 | Y | Y | N | Y |
| H325 | 2119h | | Notch Filter 2 (Resonance frequency) (Attenuation level) (Frequency range) | 1 | 10 to 2000 Hz | Y | 1000 | Y | Y | 0 | Y | Y | N | Y |
| H326 | 211Ah | | | 1 | 0 to 40 dB | Y | 0 | Y | Y | 0 | Y | Y | N | Y |
| H327 | 211Bh | | | 1 | 0 to 3 | Y | 2 | Y | Y | 0 | Y | Y | N | Y |

■ A codes (Alternative Motor Parameter Functions M2/M3)

| Function code | Communications address | | Name | Dir. | Data setting range | Change when running | Default setting | Data copying | Initialization | Format type | Drive control | | | Remarks |
|---------------|------------------------|----------|--|------|---|---------------------|-----------------|--------------|----------------|-------------|---------------|-----------|-----|---------|
| | 485 No. | Link No. | | | | | | | | | VC w/ PG | VC w/o PG | V/f | |
| A01 | 501h | h | M2 Drive Control | 29 | 0 to 5 0: Vector control for IM with speed sensor 1: Vector control for IM without speed sensor 2: - 3: Vector control for PMSM with speed sensor 4: - 5: V/f control for IM | N | 0 | Y | N | 228 | Y | Y | Y | Y |
| A02 | 502h | h | M2 Rated Capacity | 1 | For inverters of 400 kW or below 0.00 to 500.00 kW when F60 = 0 0.00 to 600.00 HP when F60 = 1 For inverters of 500 kW or above 0.00 to 1200 kW when F60 = 0 0.00 to 1600 HP when F60 = 1 For multiwinding motors, set the motor capacity per wiring. | N | 0.00 | Y | N | 3 13 | Y | Y | Y | Y |
| A03 | 503h | h | M2 Rated Current | 1 | 0.01 to 99.99 A 100.0 to 999.9 A 1000 to 2000 A | N | 0.01 | Y | N | 13 | Y | Y | Y | Y |
| A04 | 504h | h | M2 Rated Voltage | 1 | 80 to 999 V | N | 80 | Y | N | 0 | Y | Y | Y | Y |
| A05 | 505h | h | M2 Rated Speed | 1 | 50 to 30000 r/min | N | 1500 | Y | N | 0 | Y | Y | Y | Y |
| A06 | 506h | h | M2 Max. Speed | 1 | 50 to 30000 r/min | N | 1500 | Y | N | 0 | Y | Y | Y | Y |
| A07 | 507h | h | M2 Number of Poles | 1 | 2 to 100 poles | N | 4 | Y | N | 1 | Y | Y | Y | Y |
| A08 | 508h | h | M2 %R1 | 1 | 0.00 to 30.00% | Y | 0.00 | Y | N | 3 | Y | Y | Y | Y |
| A09 | 509h | h | M2 %X | 1 | 0.00 to 200.00% | Y | 0.00 | Y | N | 3 | Y | Y | Y | Y |
| A10 | 50Ah | h | M2 Exciting Current/Magnetic Flux Weakening Current (-Id) | 1 | 0.01 to 99.99 A 100.0 to 999.9 A 1000 to 2000 A | Y | 0.01 | Y | N | 13 | Y | Y | Y | Y |
| A11 | 50Bh | h | M2 Torque Current | 1 | 0.01 to 99.99 A 100.0 to 999.9 A 1000 to 2000 A | Y | 0.01 | Y | N | 13 | Y | Y | N | Y |
| A12 | 50Ch | h | M2 Slip Frequency (For driving) | 1 | 0.001 to 10.000 Hz | Y | 0.001 | Y | N | 4 | Y | Y | N | N |
| A13 | 50Dh | h | M2 Slip Frequency (For braking) | 1 | 0.001 to 10.000 Hz | Y | 0.001 | Y | N | 4 | Y | Y | N | N |
| A14 | 50Eh | h | M2 Iron Loss Factor 1 | 1 | 0.00 to 10.00% | Y | 0.00 | Y | N | 3 | Y | Y | N | Y |
| A15 | 50Fh | h | M2 Iron Loss Factor 2 | 1 | 0.00 to 10.00% | Y | 0.00 | Y | N | 3 | Y | Y | N | Y |
| A16 | 510h | h | M2 Iron Loss Factor 3 | 1 | 0.00 to 10.00% | Y | 0.00 | Y | N | 3 | Y | Y | N | Y |
| A17 | 511h | h | M2 Magnetic Saturation Factor 1 | 1 | 0.0 to 100.0% | Y | 93.8 | Y | N | 2 | Y | Y | N | N |
| A18 | 512h | h | M2 Magnetic Saturation Factor 2 | 1 | 0.0 to 100.0% | Y | 87.5 | Y | N | 2 | Y | Y | N | N |
| A19 | 513h | h | M2 Magnetic Saturation Factor 3 | 1 | 0.0 to 100.0% | Y | 75.0 | Y | N | 2 | Y | Y | N | N |
| A20 | 514h | h | M2 Magnetic Saturation Factor 4 | 1 | 0.0 to 100.0% | Y | 62.5 | Y | N | 2 | Y | Y | N | N |
| A21 | 515h | h | M2 Magnetic Saturation Factor 5 | 1 | 0.0 to 100.0% | Y | 50.0 | Y | N | 2 | Y | Y | N | N |
| A22 | 516h | h | M2 Secondary Time Constant | 1 | 0.001 to 9.999 s | Y | 0.001 | Y | N | 4 | Y | Y | N | N |
| A23 | 517h | h | M2 Induced Voltage Factor | 1 | 0 to 999 V | Y | 0 | Y | N | 0 | Y | Y | N | Y |
| A24 | 518h | h | M2 R2 Correction Factor 1 | 1 | 0.000 to 5.000 | Y | 1.000 | Y | N | 4 | Y | Y | N | Y |
| A25 | 519h | h | M2 R2 Correction Factor 2 | 1 | 0.000 to 5.000 | Y | 1.000 | Y | N | 4 | Y | Y | N | N |
| A26 | 51Ah | h | M2 R2 Correction Factor 3 | 1 | 0.010 to 5.000 | Y | 1.000 | Y | N | 4 | Y | Y | N | N |
| A27 | 51Bh | h | M2 Exciting Current Correction Factor | 1 | 0.000 to 5.000 | Y | 0.000 | Y | N | 4 | Y | Y | N | N |
| A28 | 51Ch | h | M2 ACR (P-gain) | 1 | 0.1 to 20.0 | Y | 1.0 | Y | N | 2 | Y | Y | N | Y |
| A29 | 51Dh | h | (I-time) | 1 | 0.1 to 100.0 ms | Y | 1.0 | Y | N | 2 | Y | Y | N | Y |
| A30 | 51Eh | h | M2 Pulse Resolution | 0 | 100 to 60000 | N | 1024 | Y | N | 0 | Y | N | N | Y |
| A31 | 51Fh | h | M2 Thermistor Selection | 0 | 0 to 3 0: No thermistor 1: NTC thermistor 2: PTC thermistor 3: Ai (M-TMP) The protection level of the motor protective functions should be specified by E30 to E32. | N | 1 | Y | N | 84 | Y | Y | Y | Y |
| A32 | 520h | h | M2 Electronic Thermal Overload Protection (Select motor characteristics) | 3 | 0 to 2 0: Disable (For a VG-dedicated motor) 1: Enable (For a general-purpose motor with shaft-driven cooling fan) 2: Enable (For an inverter-driven motor with separately powered cooling fan) | Y | 0 | Y | N | 85 | Y | Y | Y | Y |
| A33 | 521h | h | (Detection level) | 1 | 0.01 to 99.99 A 100.0 to 999.9 A 1000 to 2000 A | Y | 0.01 | Y | N | 13 | Y | Y | Y | Y |
| A34 | 522h | h | (Thermal time constant) | 1 | 0.5 to 75.0 min | Y | 0.5 | Y | N | 2 | Y | Y | Y | Y |
| A51 | 533h | h | M2 External PG Correction Factor | 0 | 0000 to 4FFF | N | 4000 | Y | N | 9 | Y | N | N | N |

| Function code | Communications address | | Name | Dir. | Data setting range | Change when running | Default setting | Data copying | | Format type | Drive control | | | Remarks | |
|---------------|------------------------|----------|---|------|--|---------------------|-----------------|----------------|----------------|-------------|---------------|-----------|-----|---------|-------------|
| | 485 No. | Link No. | | | | | | Initialization | Initialization | | VC w/ PG | VC w/o PG | V/f | | VC for PMSM |
| A52 | 534h | h | M2 Online Auto-tuning | 0 | 0 or 1 0: Disable 1: Enable | Y | 0 | Y | N | 0 | Y | Y | N | N | |
| A53 | 535h | h | M2 Maximum Output Voltage/ Maximum Voltage Limit | 0 | 80 to 999 V | Y | 80 | Y | N | 0 | N | N | Y | Y | |
| A54 | 536h | h | M2 Slip Compensation | 3 | -20.000 to 5.000 Hz | Y | 0.000 | Y | N | 8 | N | N | Y | N | |
| A55 | 537h | h | M2 Torque Boost | 1 | 0.0 to 20.0 Exclusive to V/f control. 0.0: Auto torque boost (for constant torque load) 0.1 to 0.9: For variable torque load 1.0 to 1.9: For proportional torque load 2.0 to 20.0: For constant torque load | Y | 0.0 | Y | N | 2 | N | N | Y | N | |
| A56 | 538h | h | M2 Output Current Fluctuation Damping Gain | 1 | 0.00 to 1.00 | Y | 0.20 | Y | N | 3 | N | N | Y | N | |
| A59 | 53Bh | h | M2 ABS Signal Input Definition | 13 | 0 to 16 Specifies the operation interface to detect the magnetic pole position, in accordance with the encoder specifications. 0: 1 bit (Terminal; F0) Z-phase interface 1: 3 bits (Terminal: F0/F1/F2) U-,V-,W-phase interface 2: 4 bits (Terminal; F0/F1/F2/F3) Gray code interface 3-5: Reserved. 6: SPGT 17-bit serial interface 7-16: Reserved. | N | 0 | Y | N | 0 | N | N | N | Y | |
| A60 | 53Ch | h | M2 Magnetic Pole Position Offset | 1 | 0.0 to 359.9 (0° to 359.9° CCW) Specifies the offset value for the PG reference position and the actual motor magnetic pole position. | Y | 0.0 | Y | N | 2 | N | N | N | Y | |
| A61 | 53Dh | h | M2 Salient Pole Ratio (%Xq/%Xd) | 1 | 1.000 to 5.000 Specifies the saliency ratio of PMSM. Setting = Lq/Ld To drive a SPM motor, set 1.000. | N | 1.000 | Y | N | 4 | N | N | N | Y | |
| A62 | 53Eh | h | M2 q-axis Inductance Magnetic Saturation Coefficient | 9 | 0.0 to 100.0% | Y | 100.0 | Y | N | 2 | N | N | N | Y | |
| A63 | 53Fh | h | M2 Magnetic Flux Limiting Value | 1 | 50.0 to 150.0% | Y | * | Y | N | 2 | N | N | N | Y | |
| A64 | 540h | h | M2 Overcurrent Protection Level | 1 | 0.00: Disable 0.01 to 99.99 A 100.0 to 999.9 A 1000 to 5000 A Specifies the allowable current value to prevent the permanent magnet of a PMSM from getting demagnetized. If the current exceeding this setting flows, an overcurrent alarm (\overline{OC}) occurs. | N | * | Y | N | 0 | N | N | N | Y | |
| A65 | 541h | h | M2 Torque Correction Gain 1 | 1 | 0.00 to 10.00 | Y | 1.00 | Y | N | 3 | N | N | N | Y | |
| A66 | 542h | h | M2 Torque Correction Gain 2 | 1 | 0.00 to 10.00 | Y | 1.00 | Y | N | 3 | N | N | N | Y | |
| A67 | 543h | h | M2 Torque Correction Gain 3 | 1 | -1000 to 1000 | Y | 0.000 | Y | N | 8 | N | N | N | Y | |
| A68 | 544h | h | M2 Torque Correction Gain 4 | 1 | -1000 to 1000 | Y | 0.000 | Y | N | 8 | N | N | N | Y | |
| A69 | 545h | h | M2 Torque Correction Gain 5 | 1 | -50.0 to 50.0 | Y | 0.00 | Y | N | 7 | N | N | N | Y | |
| A70 | 546h | h | M2 Torque Correction Gain 6 | 1 | -50.0 to 50.0 | Y | 0.00 | Y | N | 7 | N | N | N | Y | |
| A71 | 546h | h | M2 Torque Correction Gain 7 | 1 | -1000 to 1000 | Y | 0.000 | Y | N | 8 | N | N | N | Y | |
| A101 | 2401h | h | M3 Drive Control | 29 | 0 to 5 0: Vector control for IM with speed sensor 1: Vector control for IM without speed sensor 2: - 3: Vector control for PMSM with speed sensor 4: - 5: V/f control for IM | N | 5 | Y | N | 228 | Y | Y | Y | Y | |
| A102 | 2402h | E5h | M3 Rated Capacity | 1 | For inverters of 400 kW or below 0.00 to 500.00 kW when F60 = 0 0.00 to 600.00 HP when F60 = 1 For inverters of 500 kW or above 0.00 to 1200 kW when F60 = 0 0.00 to 1600 HP when F60 = 1 For multiwinding motors, set the motor capacity per wiring. | N | 0.00 | Y | N | 3 | Y | Y | Y | Y | |
| A103 | 2403h | E6h | M3 Rated Current | 1 | 0.01 to 99.99 A 100.0 to 999.9 A 1000 to 2000 A | N | 0.01 | Y | N | 13 | Y | Y | Y | Y | |
| A104 | 2404h | E7h | M3 Rated Voltage | 1 | 80 to 999 V | N | 80 | Y | N | 0 | Y | Y | Y | Y | |

*Depending upon the inverter's capacity.

| Function code | Communications address | | Name | Dir. | Data setting range | Change when running | Default setting | Data copying | Initialization | Format type | Drive control | | | Remarks |
|---------------|------------------------|----------|--|------|---|---------------------|-----------------|--------------|----------------|-------------|---------------|-----------|-----|---------|
| | 485 No. | Link No. | | | | | | | | | VC w/ PG | VC w/o PG | V/f | |
| A105 | 2405h | E9h | M3 Rated Speed | 1 | 50 to 30000 r/min | N | 1500 | Y | N | 0 | Y | Y | Y | Y |
| A106 | 2406h | EAh | M3 Max. Speed | 1 | 50 to 30000 r/min | N | 1500 | Y | N | 0 | Y | Y | Y | Y |
| A107 | 2407h | EBh | M3 Number of Poles | 1 | 2 to 100 poles | N | 4 | Y | N | 1 | Y | Y | Y | Y |
| A108 | 2408h | ECh | M3 %R1 | 1 | 0.00 to 30.00% | Y | 0.00 | Y | N | 3 | Y | Y | Y | Y |
| A109 | 2409h | EDh | M3 %X | 1 | 0.00 to 200.00% | Y | 0.00 | Y | N | 3 | Y | Y | Y | Y |
| A110 | 240Ah | EEh | M3 Exciting Current/Magnetic Flux Weakening Current (-Id) | 1 | 0.01 to 99.99 A 100.0 to 999.9 A 1000 to 2000 A | Y | 0.01 | Y | N | 13 | Y | Y | Y | Y |
| A111 | 240Bh | h | M3 Torque Current | 1 | 0.01 to 99.99 A 100.0 to 999.9 A 1000 to 2000 A | Y | 0.01 | Y | N | 13 | Y | Y | N | Y |
| A112 | 240Ch | h | M3 Slip Frequency (For driving) | 1 | 0.001 to 10.000 Hz | Y | 0.001 | Y | N | 4 | Y | Y | N | N |
| A113 | 240Dh | h | M3 Slip Frequency (For braking) | 1 | 0.001 to 10.000 Hz | Y | 0.001 | Y | N | 4 | Y | Y | N | N |
| A114 | 240Eh | h | M3 Iron Loss Factor 1 | 1 | 0.00 to 10.00% | Y | 0.00 | Y | N | 3 | Y | Y | N | N |
| A115 | 240Fh | h | M3 Iron Loss Factor 2 | 1 | 0.00 to 10.00% | Y | 0.00 | Y | N | 3 | Y | Y | N | Y |
| A116 | 2410h | h | M3 Iron Loss Factor 3 | 1 | 0.00 to 10.00% | Y | 0.00 | Y | N | 3 | Y | Y | N | Y |
| A117 | 2411h | h | M3 Magnetic Saturation Factor 1 | 1 | 0.0 to 100.0% | Y | 93.8 | Y | N | 2 | Y | Y | N | N |
| A118 | 2412h | h | M3 Magnetic Saturation Factor 2 | 1 | 0.0 to 100.0% | Y | 87.5 | Y | N | 2 | Y | Y | N | N |
| A119 | 2413h | h | M3 Magnetic Saturation Factor 3 | 1 | 0.0 to 100.0% | Y | 75.0 | Y | N | 2 | Y | Y | N | N |
| A120 | 2414h | h | M3 Magnetic Saturation Factor 4 | 1 | 0.0 to 100.0% | Y | 62.5 | Y | N | 2 | Y | Y | N | N |
| A121 | 2415h | h | M3 Magnetic Saturation Factor 5 | 1 | 0.0 to 100.0% | Y | 50.0 | Y | N | 2 | Y | Y | N | N |
| A122 | 2416h | h | M3 Secondary Time constant | 1 | 0.001 to 9.999 s | Y | 0.001 | Y | N | 4 | Y | Y | N | N |
| A123 | 2417h | h | M3 Induced Voltage Factor | 1 | 0 to 999 V | Y | 0 | Y | N | 0 | Y | Y | N | Y |
| A124 | 2418h | h | M3 R2 Correction Factor 1 | 1 | 0.500 to 5.000 | Y | 1.000 | Y | N | 4 | Y | Y | N | Y |
| A125 | 2419h | h | M3 R2 Correction Factor 2 | 1 | 0.500 to 5.000 | Y | 1.000 | Y | N | 4 | Y | Y | N | N |
| A126 | 241Ah | h | M3 R2 Correction Factor 3 | 1 | 0.010 to 5.000 | Y | 1.000 | Y | N | 4 | Y | Y | N | N |
| A127 | 241Bh | h | M3 Exciting Current Correction Factor | 1 | 0.000 to 5.000 | Y | 0.000 | Y | N | 4 | Y | Y | N | N |
| A128 | 241Ch | h | M3 ACR P Gain | 1 | 0.1 to 20.0 | Y | 1.0 | Y | N | 2 | Y | Y | N | Y |
| A129 | 241Dh | h | M3 ACR I time Constant | 1 | 0.1 to 100.0 ms | Y | 1.0 | Y | N | 2 | Y | Y | N | Y |
| A130 | 241Eh | h | M3 Pulse Resolution | 0 | 100 to 60000 | N | 1024 | Y | N | 0 | Y | N | N | Y |
| A131 | 241Fh | F1h | M3 Thermistor Selection | 0 | 0 to 3 0: No thermistor 1: NTC thermistor 2: PTC thermistor 3: Ai (M-TMP) The protection level of the motor protective functions should be specified by E30 to E32. | N | 1 | Y | N | 84 | Y | Y | Y | Y |
| A132 | 2420h | F2h | M3 Electronic Thermal Overload Protection (Select motor characteristics) | 3 | 0 to 2 0: Disable (For a VG-dedicated motor) 1: Enable (For a general-purpose motor with shaft-driven cooling fan) 2: Enable (For an inverter-driven motor with separately powered cooling fan) Using an NTC thermistor of a VG-dedicated motor activates the motor overheat protection. If it happens, disable the electronic thermal overload protection. | Y | 0 | Y | N | 85 | Y | Y | Y | Y |
| A133 | 2421h | F3h | (Detection level) | 1 | 0.01 to 99.99 A 100.0 to 999.9 A 1000 to 2000 A | Y | 0.01 | Y | N | 13 | Y | Y | Y | Y |
| A134 | 2422h | F4h | (Thermal time constant) | 1 | 0.5 to 75.0 min | Y | 0.5 | Y | N | 2 | Y | Y | Y | Y |
| A151 | 2433h | h | M2 External PG Correction Coefficient | 0 | 0000 to 4FFF | N | 4000 | Y | N | 9 | Y | N | N | N |
| A152 | 2434h | h | M3 Online Auto-tuning | 0 | 0 to 1 0: Disable 1: Enable | Y | 0 | Y | N | 68 | Y | Y | N | N |
| A153 | 2435h | E8h | M3 Maximum Output Voltage (at V/f maximum speed) | 0 | 80 to 999 V | Y | 80 | Y | N | 0 | N | N | Y | Y |
| A154 | 2436h | EFh | M3 Slip Compensation | 3 | -20.000 to 5.000 Hz | Y | 0.000 | Y | N | 8 | N | N | Y | N |
| A155 | 2437h | F0h | M3 Torque Boost | 1 | 0.0 to 20.0 Exclusive to V/f control. 0.0: Auto torque boost (for constant torque load) 0.1 to 0.9: For variable torque load 1.0 to 1.9: For proportional torque load 2.0 to 20.0: For constant torque load | Y | 0.0 | Y | N | 2 | N | N | Y | N |
| A156 | 2438h | h | M3 Output Current Fluctuation Damping Gain | 1 | 0.00 to 1.00 | Y | 0.20 | Y | N | 3 | N | N | Y | N |

| Function code | Communications address | | Name | Dir. | Data setting range | Change when running | Default setting | Data copying | | Format type | Drive control | | | Remarks |
|---------------|------------------------|----------|--|------|---|---------------------|-----------------|--------------|---|-------------|---------------|-----------|----|---------|
| | 485 No. | Link No. | | | | | | Y | N | | VC w/ PG | VC w/o PG | Vf | |
| A159 | 243Bh | h | M3 ABS Signal Input Definition | 13 | 0 to 16 Specifies the operation interface to detect the magnetic pole position, in accordance with the encoder specifications. 0: 1 bit (Terminal; F0) Z-phase interface 1: 3 bits (Terminal: F0/F1/F2) U-,V-,W-phase interface 2: 4 bits (Terminal; F0/F1/F2/F3) Gray code interface 3-5: Reserved. 6: SPGT 17-bit serial interface 7-16: Reserved. | N | 0 | Y | N | 0 | N | N | N | Y |
| A160 | 243Ch | h | M3 Magnetic Pole Position Offset | 1 | 0.0 to 359.9 (0° to 359.9° CCW) Specifies the offset value for the PG reference position and the actual motor magnetic pole position. | Y | 0.0 | Y | N | 2 | N | N | N | Y |
| A161 | 243Dh | h | M3 Salient Pole Ratio (%Xq/%Xd) | 1 | 1.000 to 5.000 Specifies the saliency ratio of PMSM. Setting = Lq/Ld To drive a SPM motor, set 1.000. | N | 1.000 | Y | N | 4 | N | N | N | Y |
| A162 | 243Ch | h | M3 q-axis Inductance Magnetic Saturation Coefficient | 1 | 0.0 to 100.0% | Y | 1.000 | Y | N | 2 | N | N | N | Y |
| A163 | 243Dh | h | M3 Magnetic Flux Limiting Value | 1 | 50.0 to 150.0% | Y | 1.000 | Y | N | 2 | N | N | N | Y |
| A164 | 2440h | h | M3 Overcurrent Protection Level | 1 | 0.00: Disable 0.01 to 99.99 A 100.0 to 999.9 A 1000 to 5000 A Specifies the allowable current value to prevent the permanent magnet of a PMSM from getting demagnetized. If the current exceeding this setting flows, an overcurrent alarm (\overline{OC}) occurs. | N | 0.00 | Y | N | 0 | N | N | N | Y |
| A165 | 2441h | h | M3 Torque Correction Gain 1 | 1 | 0.00 to 10.00 | Y | 1.00 | Y | N | 3 | N | N | N | Y |
| A166 | 2442h | h | M3 Torque Correction Gain 2 | 1 | 0.00 to 10.00 | Y | 1.00 | Y | N | 3 | N | N | N | Y |
| A167 | 2443h | h | M3 Torque Correction Gain 3 | 1 | -1.000 to 1.000 | Y | 0.000 | Y | N | 8 | N | N | N | Y |
| A168 | 2444h | h | M3 Torque Correction Gain 4 | 1 | -1.000 to 1.000 | Y | 0.000 | Y | N | 8 | N | N | N | Y |
| A169 | 2445h | h | M3 Torque Correction Gain 5 | 1 | -50.0 to 50.0 | Y | 0.00 | Y | N | 7 | N | N | N | Y |
| A170 | 2446h | h | M3 Torque Correction Gain 6 | 1 | -50.0 to 50.0 | Y | 0.00 | Y | N | 7 | N | N | N | Y |
| A171 | 2447h | h | M3 Torque Correction Gain 7 | 1 | -1.000 to 1.000 | Y | 0.000 | Y | N | 8 | N | N | N | Y |

■ o codes (Option Functions)

| Function code | Communications address | | Name | Dir. | Data setting range | Change when running | Default setting | Data copying | Initialization | Format type | Drive control | | | Remarks |
|---------------|------------------------|----------|--|------|---|---------------------|-----------------|--------------|----------------|-------------|---------------|-----------|----|---------|
| | 485 No. | Link No. | | | | | | | | | VC w/ PG | VC w/o PG | Vf | |
| o01 | 601h | F5h | DIA Function Selection | 4 | 0 or 1 0 : Binary 1 : BCD | N | 0 | Y | Y | 86 | Y | Y | Y | Y |
| o02 | 602h | F6h | DIB Function Selection | 1 | 0 or 1 0 : Binary 1 : BCD | N | 0 | Y | Y | 86 | Y | Y | Y | Y |
| o03 | 603h | h | DIA BCD Input Speed Setting | 1 | 99 to 7999 | N | 1000 | Y | Y | 0 | Y | Y | Y | Y |
| o04 | 604h | h | DIB BCD Input Speed Setting | 1 | 99 to 7999 | N | 1000 | Y | Y | 0 | Y | Y | Y | Y |
| o05 | 605h | h | PG (PD) Option Setting (Feedback pulse) | 0 | 0 to 1 0: Build-in PG 1: PG(PD) option | N | 0 | Y | Y | 96 | Y | N | N | Y |
| o06 | 606h | h | (Digital line speed detection definition, PG pulses) | 3 | 100 to 60000 P/R | Y | 1024 | Y | Y | 0 | Y | Y | Y | Y |
| o07 | 607h | h | (Digital line speed detection definition, Detection pulse correction 1) | 1 | 1 to 9999 | Y | 1000 | Y | Y | 0 | Y | Y | Y | Y |
| o08 | 608h | h | (Digital line speed detection definition, Detection pulse correction 2) | 1 | 1 to 9999 | Y | 1000 | Y | Y | 0 | Y | Y | Y | Y |
| o09 | 609h | h | M1 Absolute Signal Input Definition | 3 | 0 to 16 Specifies the operation interface to detect the magnetic pole position, in accordance with the encoder specifications. 0: 1 bit (Terminal; F0) Z-phase interface 1: 3 bits (Terminal: F0/F1/F2) U-,V-,W-phase interface 2: 4 bits (Terminal; F0/F1/F2/F3) Gray code interface 3-5: Reserved. 6: SPGT 17-bit serial interface 7-16: Reserved. | N | 0 | Y | N | 0 | N | N | N | Y |
| o10 | 60Ah | h | M1 Magnetic Pole Position Offset | 1 | 0.0 to 359.9 (0° to 359.9° CCW) Specifies the offset value for the PG reference position and the actual motor magnetic pole position. | Y | 0.0 | Y | N | 2 | N | N | N | Y |
| o11 | 60Bh | h | M1 Salient Pole Rate (%Xq/%Xd) | 1 | 1.000 to 5.000 Specifies the saliency ratio of PMSM. Setting = Lq/Ld To drive an SPM motor, set 1.000. | N | 1.000 | Y | N | 4 | N | N | N | Y |
| o12 | 60Ch | h | Command Pulse Selection | 8 | 0 or 1 0: PG(PD) option 1: Internal speed command | N | 0 | Y | Y | 97 | Y | N | N | Y |
| o13 | 60Dh | h | Pulse Train Input Form | 1 | 0 to 2 0: Phase difference 90° between A-phase and B-phase 1: A-phase : Reference pulse, B-phase :Reference sign 2: A-phase : Forward pulse, B-phase : Reverse pulse | N | 0 | Y | Y | 98 | Y | N | N | Y |
| o14 | 60Eh | F7h | Command Pulse Correction 1 | 1 | 1 to 9999 | Y | 1000 | Y | Y | 0 | Y | N | N | Y |
| o15 | 60Fh | F8h | Command Pulse Correction 2 | 1 | 1 to 9999 | Y | 1000 | Y | Y | 0 | Y | N | N | Y |
| o16 | 610h | F9h | APR Gain 1 | 1 | 0.1 to 999.9 times | Y | 1.0 | Y | Y | 2 | Y | N | N | Y |
| o17 | 611h | FAh | Feedforward Gain 1 | 1 | 0.0 to 1.5 times | Y | 0.0 | Y | Y | 2 | Y | N | N | Y |
| o18 | 612h | h | Overdeviation Width | 1 | 0 to 65535 pulses | Y | 65535 | Y | Y | 0 | Y | N | N | Y |
| o19 | 613h | h | Zero Deviation Width | 1 | 0 to 1000 pulses | Y | 20 | Y | Y | 0 | Y | N | N | Y |
| o20 | 614h | h | APR Gain 2 (Available soon) | 1 | 0.1 to 999.9 times | Y | 1.0 | Y | Y | 2 | Y | N | N | Y |
| o21 | 615h | h | F/F Gain 2 (Available soon) | 1 | 0.0 to 1.5 times | Y | 0.0 | Y | Y | 2 | Y | N | N | Y |
| o22 | 616h | h | Position Control Gain Switching (Available soon) | 3 | 0 to 3 0: Disable 1: Positional deviation (x 10) 2: Detected speed (10000/Maximum speed) 3: Speed command (10000/Maximum speed) Select a trigger to switch between the 1st and 2nd gains of the position control system. Switching gains can reduce noise or vibration when the inverter is stopped. | Y | 0 | Y | Y | 229 | Y | N | N | Y |
| o23 | 617h | h | Position Control Gain Switching Level (Available soon) | 1 | 0 to 10000 | Y | 0 | Y | Y | 0 | Y | N | N | Y |
| o24 | 618h | h | Position Control Gain Switching Time (Available soon) | 1 | 0 to 1000 ms | Y | 0 | Y | Y | 0 | Y | N | N | Y |
| o30 | 61Eh | h | (Communications error processing) | 3 | 0 to 3 0: Immediately trip with alarm E_{r-4} 1: Trip with alarm E_{r-4} after running for the period specified by timer o31 2: Trip with alarm (E_{r-4}) if the communication error remains exceeding the period specified by timer o31. 3: Continue to run Specifies the error processing to be performed if a communications link error occurs. For CC-Link, when o30 = 0 to 3, the inverter produces different operation. | N | 0 | Y | Y | 73 | Y | Y | Y | Y |

| Function code | Communications address | | Name | Dir. | Data setting range | Change when running | Default setting | Data copying | Initialization | Format type | Drive control | | | Remarks | |
|---------------|------------------------|----------|---|------|---|---------------------|-----------------|--------------|----------------|-------------|---------------|-----------|-----|---------|-------------|
| | 485 No. | Link No. | | | | | | | | | VC w/ PG | VC w/o PG | V/f | | VC for PMSM |
| o31 | 61Fh | | (Timer) | 1 | 0.01 to 20.00 s Specifies the duration from an occurrence of communications problem on the link until the inverter cause a communications error. | N | 0.10 | Y | Y | 3 | Y | Y | Y | Y | |
| o32 | 620h | | (Link format selection) | 1 | 0 to 4 0: Link format 1 1: Link format 2 2: Link format 3 3: Link format 4 4: Link format 5 | N | 0 | Y | N | 87 | Y | Y | Y | Y | |
| o33 *1 | 621h | FDh | Multiplex System (Control mode) | 2 | 0 to 2 0: Disable 1: Multiwinding motor control system 2: Multiplex system 1 (Direct parallel connection) Selects whether or not to use a high-speed serial communications terminal block as a component of the multiwinding system or multiplex system. Refer to MT-CCL (Cancel multiplex system) in the description of E01 to E13 (Terminal X Function). | N | 0 | Y | Y | 232 | Y | N | N | N | |
| o34 | 622h | | (No. of slave stations) | 1 | 1 to 5 Specifies the numbers of slave units except a master unit when the multiplex system is enabled. | N | 1 | Y | Y | 0 | Y | N | N | N | |
| o38 *1 | 626h | | UPAC Start/Stop | 3 | 0: Stop UPAC 1: Start UPAC 2: Start UPAC (Initial start-up) Starts or stops the UPAC option. | N | 0 | Y | Y | 68 | Y | Y | Y | Y | |
| o39 *1 | 627h | | UPAC Memory Mode | 1 | 00 to 1F Setting "0" or "1" to one of bits 1 to 5 holds or zero-clears the corresponding memory area when the UPAC option is stopped for change, respectively. Bit 1: IQ area Bit 2: M area Bit 3: RM area Bit 4: FM area Bit 5: SFM area o39 defines whether to hold or zero-clear the designated memory area when the UPAC option is switched from start to stop or it is stopped. | N | 00 | Y | Y | 9 | Y | Y | Y | Y | |
| o40 *1 | 628h | | UPAC Address | 1 | 100 to 255 Specifies the UPAC station address required for access from a computer to the UPAC option in RS-485 communication. | N | 100 | Y | N | 0 | Y | Y | Y | Y | |
| o50 | 632h | | Station Address Assignment for Multiplex System | 0 | 0 to 5 0: Master 1-5: Slave 1 to 5 | N | 0 | N | Y | 0 | Y | N | N | N | |
| o101 | 2501h | | Reflection of Arbitrary Assignment *2 | 0 | 0 or 1 After data writing, o101 data automatically reverts to "0." | N | 0 | N | N | 11 | Y | Y | Y | Y | |
| o122 | 2516h | | Write Function Code Assignment 1 | 0 | 0000 to FFFF | Y | 0000 | Y | Y | 9 | Y | Y | Y | Y | |
| o123 | 2517h | | Write Function Code Assignment 2 | 0 | 0000 to FFFF | Y | 0000 | Y | Y | 9 | Y | Y | Y | Y | |
| o124 | 2518h | | Write Function Code Assignment 3 | 0 | 0000 to FFFF | Y | 0000 | Y | Y | 9 | Y | Y | Y | Y | |

*1 Available in the ROM version H1/2 0020 or later.

*2 Available in the ROM version H1/2 02□□, which supports PROFINET-IRT.

| Function code | Communica-tions address | | Name | Dir. | Data setting range | Change when running | Default setting | Data copying | | Format type | Drive control | | | Remarks |
|---------------|-------------------------|----------|---------------------------------------|------|--------------------|---------------------|-----------------|--------------|----------------|-------------|---------------|-----------|----|---------|
| | 485 No. | Link No. | | | | | | Data copying | Initialization | | VC w/ PG | VC w/o PG | Vf | |
| o125 | 2519h | h | Write Function Code Assignment 4 | 0 | 0000 to FFFF | Y | 0000 | Y | Y | 9 | Y | Y | Y | Y |
| o126 | 251Ah | h | Write Function Code Assignment 5 | 0 | 0000 to FFFF | Y | 0000 | Y | Y | 9 | Y | Y | Y | Y |
| o127 | 251Bh | h | Write Function Code Assignment 6 | 0 | 0000 to FFFF | Y | 0000 | Y | Y | 9 | Y | Y | Y | Y |
| o128 | 251Ch | h | Write Function Code Assignment 7 | 0 | 0000 to FFFF | Y | 0000 | Y | Y | 9 | Y | Y | Y | Y |
| o129 | 251Dh | h | Write Function Code Assignment 8 | 0 | 0000 to FFFF | Y | 0000 | Y | Y | 9 | Y | Y | Y | Y |
| o130 | 251Eh | h | Write Function Code Assignment 9 | 0 | 0000 to FFFF | Y | 0000 | Y | Y | 9 | Y | Y | Y | Y |
| o131 | 251Fh | h | Write Function Code Assignment 10 | 0 | 0000 to FFFF | Y | 0000 | Y | Y | 9 | Y | Y | Y | Y |
| o132 | 2520h | h | Write Function Code Assignment 11 | 0 | 0000 to FFFF | Y | 0000 | Y | Y | 9 | Y | Y | Y | Y |
| o133 | 2521h | h | Write Function Code Assignment 12 | 0 | 0000 to FFFF | Y | 0000 | Y | Y | 9 | Y | Y | Y | Y |
| o160 | 253Ch | h | Read Function Code Assignment 1 | 0 | 0000 to FFFF | Y | 0000 | Y | Y | 9 | Y | Y | Y | Y |
| o161 | 253Dh | h | Read Function Code Assignment 2 | 0 | 0000 to FFFF | Y | 0000 | Y | Y | 9 | Y | Y | Y | Y |
| o162 | 253Eh | h | Read Function Code Assignment 3 (*1) | 0 | 0000 to FFFF | Y | 0000 | Y | Y | 9 | Y | Y | Y | Y |
| o163 | 253Fh | h | Read Function Code Assignment 4 (*1) | 0 | 0000 to FFFF | Y | 0000 | Y | Y | 9 | Y | Y | Y | Y |
| o164 | 2540h | h | Read Function Code Assignment 5 (*1) | 0 | 0000 to FFFF | Y | 0000 | Y | Y | 9 | Y | Y | Y | Y |
| o165 | 2541H | h | Read Function Code Assignment 6 (*1) | 0 | 0000 to FFFF | Y | 0000 | Y | Y | 9 | Y | Y | Y | Y |
| o166 | 2542h | h | Read Function Code Assignment 7 (*1) | 0 | 0000 to FFFF | Y | 0000 | Y | Y | 9 | Y | Y | Y | Y |
| o167 | 2543h | h | Read Function Code Assignment 8 (*1) | 0 | 0000 to FFFF | Y | 0000 | Y | Y | 9 | Y | Y | Y | Y |
| o168 | 2544h | h | Read Function Code Assignment 9 (*1) | 0 | 0000 to FFFF | Y | 0000 | Y | Y | 9 | Y | Y | Y | Y |
| o169 | 2545h | h | Read Function Code Assignment 10 (*1) | 0 | 0000 to FFFF | Y | 0000 | Y | Y | 9 | Y | Y | Y | Y |
| o170 | 2546h | h | Read Function Code Assignment 11 (*1) | 0 | 0000 to FFFF | Y | 0000 | Y | Y | 9 | Y | Y | Y | Y |
| o171 | 2547h | h | Read Function Code Assignment 12 (*1) | 0 | 0000 to FFFF | Y | 0000 | Y | Y | 9 | Y | Y | Y | Y |

*1 Available in the ROM version H1/2 02□□, which supports PROFINET-IRT.

■ L codes (Lift Functions)

| Function code | Communications address | | Name | Dir. | Data setting range | Change when running | Default setting | Data copying | Initialization | Format type | Drive control | | | Remarks | |
|---------------|------------------------|----------|------------------------|------|--|---------------------|-----------------|--------------|----------------|-------------|---------------|-----------|-----|---------|-------------|
| | 485 No. | Link No. | | | | | | | | | VC w/ PG | VC w/o PG | V/f | | VC for PMSM |
| L01 | 901h | h | Password Data 1 | 0 | 0 to 9999 A maximum of 8-digit password can be specified with L01 and L02 to restrict access to function code data or check it. Setting either one of L01 and L02 at any numeral except "0" enables password protection. | Y | 0 | N | N | 0 | Y | Y | N | Y | |
| L02 | 902h | h | Password Data 2 | 0 | 0 to 9999 | Y | 0 | N | N | 0 | Y | Y | N | Y | |
| L03 | 903h | h | Lift Rated Speed | 0 | 0.0 to 999.9 m/min | Y | 100.0 | Y | Y | 2 | Y | Y | N | Y | |
| L04 | 904h | h | Preset S-curve Pattern | 11 | 0 to 2 0: Disable Normal accel/decel, S-curve (15 steps, S-curve 5) 1: Method 1 For VG3/VG5, accel/decel can be controlled via terminal [12] with SS1 , SS2 , and SS4 all OFF. 2: Method 2 For VG7, zero speed is selected with SS1 , SS2 . Select S-curve pattern and application of multistep speed. | Y | 0 | Y | Y | 80 | Y | Y | N | Y | |
| L05 | 905h | h | S-curve Pattern 1 | 1 | 0 to 50% | Y | 0 | Y | Y | 0 | Y | Y | N | Y | |
| L06 | 906h | h | S-curve Pattern 2 | 1 | 0 to 50% | Y | 0 | Y | Y | 0 | Y | Y | N | Y | |
| L07 | 907h | h | S-curve Pattern 3 | 1 | 0 to 50% | Y | 0 | Y | Y | 0 | Y | Y | N | Y | |
| L08 | 908h | h | S-curve Pattern 4 | 1 | 0 to 50% | Y | 0 | Y | Y | 0 | Y | Y | N | Y | |
| L09 | 909h | h | S-curve Pattern 5 | 1 | 0 to 50% | Y | 0 | Y | Y | 0 | Y | Y | N | Y | |
| L10 | 90Ah | h | S-curve Pattern 6 | 1 | 0 to 50% | Y | 0 | Y | Y | 0 | Y | Y | N | Y | |
| L11 | 90Bh | h | S-curve Pattern 7 | 1 | 0 to 50% | Y | 0 | Y | Y | 0 | Y | Y | N | Y | |
| L12 | 90Ch | h | S-curve Pattern 8 | 1 | 0 to 50% | Y | 0 | Y | Y | 0 | Y | Y | N | Y | |
| L13 | 90Dh | h | S-curve Pattern 9 | 1 | 0 to 50% | Y | 0 | Y | Y | 0 | Y | Y | N | Y | |
| L14 | 90Eh | h | S-curve Pattern 10 | 1 | 0 to 50% | Y | 0 | Y | Y | 0 | Y | Y | N | Y | |

■ U codes (User Functions)

| Function code | Communications address | | Name | Dir. | Data setting range | Change when running | Default setting | Data copying | Initialization | Format type | Drive control | | | Remarks |
|---------------|------------------------|----------|--|------|--------------------|---------------------|-----------------|--------------|----------------|-------------|---------------|-----------|-----|---------|
| | 485 No. | Link No. | | | | | | | | | VC w/ PG | VC w/o PG | Vfr | |
| U01 | B01h | DBh | USER P1 | 0 | -32768 to 32767 | Y | 0 | Y | Y | 5 | Y | Y | Y | Y |
| U02 | B02h | DCh | USER P2 | 0 | -32768 to 32767 | Y | 0 | Y | Y | 5 | Y | Y | Y | Y |
| U03 | B03h | DDh | USER P3 | 0 | -32768 to 32767 | Y | 0 | Y | Y | 5 | Y | Y | Y | Y |
| U04 | B04h | DEh | USER P4 | 0 | -32768 to 32767 | Y | 0 | Y | Y | 5 | Y | Y | Y | Y |
| U05 | B05h | DFh | USER P5 | 0 | -32768 to 32767 | Y | 0 | Y | Y | 5 | Y | Y | Y | Y |
| U06 | B06h | E0h | USER P6 | 0 | -32768 to 32767 | Y | 0 | Y | Y | 5 | Y | Y | Y | Y |
| U07 | B07h | E1h | USER P7 | 0 | -32768 to 32767 | Y | 0 | Y | Y | 5 | Y | Y | Y | Y |
| U08 | B08h | E2h | USER P8 | 0 | -32768 to 32767 | Y | 0 | Y | Y | 5 | Y | Y | Y | Y |
| U09 | B09h | E3h | USER P9 | 0 | -32768 to 32767 | Y | 0 | Y | Y | 5 | Y | Y | Y | Y |
| U10 | B0Ah | E4h | USER P10 | 0 | -32768 to 32767 | Y | 0 | Y | Y | 5 | Y | Y | Y | Y |
| U11 | B0Bh | h | USER P11 SX bus / E-SX Bus Communications Format | 0 | -32768 to 32767 | Y | 0 | Y | Y | 5 | Y | Y | Y | Y |
| U12 | B0Ch | h | USER P12 | 0 | -32768 to 32767 | Y | 0 | Y | Y | 5 | Y | Y | Y | Y |
| U13 | B0Dh | h | USER P13 SX Bus Station Number Monitor | 0 | -32768 to 32767 | Y | 0 | Y | Y | 5 | Y | Y | Y | Y |
| U14 | B0Eh | h | USER P14 | 0 | -32768 to 32767 | Y | 0 | Y | Y | 5 | Y | Y | Y | Y |
| U15 | B0Fh | h | USER P15 | 0 | -32768 to 32767 | Y | 0 | Y | Y | 5 | Y | Y | Y | Y |
| U16 | B10h | h | USER P16 | 0 | -32768 to 32767 | Y | 0 | Y | Y | 5 | Y | Y | Y | Y |
| U17 | B11h | h | USER P17 | 0 | -32768 to 32767 | Y | 0 | Y | Y | 5 | Y | Y | Y | Y |
| U18 | B12h | h | USER P18 | 0 | -32768 to 32767 | Y | 0 | Y | Y | 5 | Y | Y | Y | Y |
| U19 | B13h | h | USER P19 | 0 | -32768 to 32767 | Y | 0 | Y | Y | 5 | Y | Y | Y | Y |
| U20 | B14h | h | USER P20 | 0 | -32768 to 32767 | Y | 0 | Y | Y | 5 | Y | Y | Y | Y |
| U21 | B15h | h | USER P21 | 0 | -32768 to 32767 | Y | 0 | Y | Y | 5 | Y | Y | Y | Y |
| U22 | B16h | h | USER P22 | 0 | -32768 to 32767 | Y | 0 | Y | Y | 5 | Y | Y | Y | Y |
| U23 | B17h | h | USER P23 | 0 | -32768 to 32767 | Y | 0 | Y | Y | 5 | Y | Y | Y | Y |
| U24 | B18h | h | USER P24 | 0 | -32768 to 32767 | Y | 0 | Y | Y | 5 | Y | Y | Y | Y |
| U25 | B19h | h | USER P25 | 0 | -32768 to 32767 | Y | 0 | Y | Y | 5 | Y | Y | Y | Y |
| U26 | B1Ah | h | USER P26 | 0 | -32768 to 32767 | Y | 0 | Y | Y | 5 | Y | Y | Y | Y |
| U27 | B1Bh | h | USER P27 | 0 | -32768 to 32767 | Y | 0 | Y | Y | 5 | Y | Y | Y | Y |
| U28 | B1Ch | h | USER P28 | 0 | -32768 to 32767 | Y | 0 | Y | Y | 5 | Y | Y | Y | Y |
| U29 | B1Dh | h | USER P29 | 0 | -32768 to 32767 | Y | 0 | Y | Y | 5 | Y | Y | Y | Y |
| U30 | B1Eh | h | USER P30 | 0 | -32768 to 32767 | Y | 0 | Y | Y | 5 | Y | Y | Y | Y |
| U31 | B1Fh | h | USER P31 | 0 | -32768 to 32767 | Y | 0 | Y | Y | 5 | Y | Y | Y | Y |
| U32 | B20h | h | USER P32 | 0 | -32768 to 32767 | Y | 0 | Y | Y | 5 | Y | Y | Y | Y |
| U33 | B21h | h | USER P33 | 0 | -32768 to 32767 | Y | 0 | Y | Y | 5 | Y | Y | Y | Y |
| U34 | B22h | h | USER P34 | 0 | -32768 to 32767 | Y | 0 | Y | Y | 5 | Y | Y | Y | Y |
| U35 | B23h | h | USER P35 | 0 | -32768 to 32767 | Y | 0 | Y | Y | 5 | Y | Y | Y | Y |
| U36 | B24h | h | USER P36 | 0 | -32768 to 32767 | Y | 0 | Y | Y | 5 | Y | Y | Y | Y |
| U37 | B25h | h | USER P37 | 0 | -32768 to 32767 | Y | 0 | Y | Y | 5 | Y | Y | Y | Y |
| U38 | B26h | h | USER P38 | 0 | -32768 to 32767 | Y | 0 | Y | Y | 5 | Y | Y | Y | Y |
| U39 | B27h | h | USER P39 | 0 | -32768 to 32767 | Y | 0 | Y | Y | 5 | Y | Y | Y | Y |
| U40 | B28h | h | USER P40 | 0 | -32768 to 32767 | Y | 0 | Y | Y | 5 | Y | Y | Y | Y |
| U41 | B29h | h | USER P41 | 0 | -32768 to 32767 | Y | 0 | Y | Y | 5 | Y | Y | Y | Y |
| U42 | B2Ah | h | USER P42 | 0 | -32768 to 32767 | Y | 0 | Y | Y | 5 | Y | Y | Y | Y |
| U43 | B2Bh | h | USER P43 | 0 | -32768 to 32767 | Y | 0 | Y | Y | 5 | Y | Y | Y | Y |
| U44 | B2Ch | h | USER P44 | 0 | -32768 to 32767 | Y | 0 | Y | Y | 5 | Y | Y | Y | Y |
| U45 | B2Dh | h | USER P45 | 0 | -32768 to 32767 | Y | 0 | Y | Y | 5 | Y | Y | Y | Y |
| U46 | B2Eh | h | USER P46 | 0 | -32768 to 32767 | Y | 0 | Y | Y | 5 | Y | Y | Y | Y |
| U47 | B2Fh | h | USER P47 | 0 | -32768 to 32767 | Y | 0 | Y | Y | 5 | Y | Y | Y | Y |
| U48 | B30h | h | USER P48 | 0 | -32768 to 32767 | Y | 0 | Y | Y | 5 | Y | Y | Y | Y |
| U49 | B31h | h | USER P49 | 0 | -32768 to 32767 | Y | 0 | Y | Y | 5 | Y | Y | Y | Y |
| U50 | B32h | h | USER P50 | 0 | -32768 to 32767 | Y | 0 | Y | Y | 5 | Y | Y | Y | Y |
| U51 | B33h | h | USER P51 | 0 | -32768 to 32767 | Y | 0 | Y | Y | 5 | Y | Y | Y | Y |
| U52 | B34h | h | USER P52 | 0 | -32768 to 32767 | Y | 0 | Y | Y | 5 | Y | Y | Y | Y |
| U53 | B35h | h | USER P53 | 0 | -32768 to 32767 | Y | 0 | Y | Y | 5 | Y | Y | Y | Y |
| U54 | B36h | h | USER P54 | 0 | -32768 to 32767 | Y | 0 | Y | Y | 5 | Y | Y | Y | Y |
| U55 | B37h | h | USER P55 | 0 | -32768 to 32767 | Y | 0 | Y | Y | 5 | Y | Y | Y | Y |
| U56 | B38h | h | USER P56 | 0 | -32768 to 32767 | Y | 0 | Y | Y | 5 | Y | Y | Y | Y |
| U57 | B39h | h | USER P57 | 0 | -32768 to 32767 | Y | 0 | Y | Y | 5 | Y | Y | Y | Y |
| U58 | B3Ah | h | USER P58 | 0 | -32768 to 32767 | Y | 0 | Y | Y | 5 | Y | Y | Y | Y |
| U59 | B3Bh | h | USER P59 | 0 | -32768 to 32767 | Y | 0 | Y | Y | 5 | Y | Y | Y | Y |
| U60 | B3Ch | h | USER P60 | 0 | -32768 to 32767 | Y | 0 | Y | Y | 5 | Y | Y | Y | Y |
| U61 | B3Dh | 4Bh | USER P61/U-Ai1 | 0 | -32768 to 32767 | Y | 0 | Y | Y | 5 | Y | Y | Y | Y |
| U62 | B3Eh | 4Ch | USER P62/U-Ai2 | 0 | -32768 to 32767 | Y | 0 | Y | Y | 5 | Y | Y | Y | Y |
| U63 | B3Fh | 4Dh | USER P63/U-Ai3 | 0 | -32768 to 32767 | Y | 0 | Y | Y | 5 | Y | Y | Y | Y |
| U64 | B40h | 4Eh | USER P64/U-Ai4 | 0 | -32768 to 32767 | Y | 0 | Y | Y | 5 | Y | Y | Y | Y |

| Function code | Communications address | | Name | Dir. | Data setting range | Change when running | Default setting | Data copying | Initialization | Format type | Drive control | | | Remarks |
|---------------|------------------------|----------|-----------|------|--------------------|---------------------|-----------------|--------------|----------------|-------------|---------------|-----------|----|---------|
| | 485 No. | Link No. | | | | | | | | | VC w/ PG | VC w/o PG | Vf | |
| U101 | 2701h | h | USER P101 | 0 | -32768 to 32767 | Y | 0 | Y | Y | 5 | Y | Y | Y | |
| U102 | 2702h | h | USER P102 | 0 | -32768 to 32767 | Y | 0 | Y | Y | 5 | Y | Y | Y | |
| U103 | 2703h | h | USER P103 | 0 | -32768 to 32767 | Y | 0 | Y | Y | 5 | Y | Y | Y | |
| U104 | 2704h | h | USER P104 | 0 | -32768 to 32767 | Y | 0 | Y | Y | 5 | Y | Y | Y | |
| U105 | 2705h | h | USER P105 | 0 | -32768 to 32767 | Y | 0 | Y | Y | 5 | Y | Y | Y | |
| U106 | 2706h | h | USER P106 | 0 | -32768 to 32767 | Y | 0 | Y | Y | 5 | Y | Y | Y | |
| U107 | 2707h | h | USER P107 | 0 | -32768 to 32767 | Y | 0 | Y | Y | 5 | Y | Y | Y | |
| U108 | 2708h | h | USER P108 | 0 | -32768 to 32767 | Y | 0 | Y | Y | 5 | Y | Y | Y | |
| U109 | 2709h | h | USER P109 | 0 | -32768 to 32767 | Y | 0 | Y | Y | 5 | Y | Y | Y | |
| U110 | 270Ah | h | USER P110 | 0 | -32768 to 32767 | Y | 0 | Y | Y | 5 | Y | Y | Y | |
| U111 | 270Bh | h | USER P111 | 0 | -32768 to 32767 | Y | 0 | Y | Y | 5 | Y | Y | Y | |
| U112 | 270Ch | h | USER P112 | 0 | -32768 to 32767 | Y | 0 | Y | Y | 5 | Y | Y | Y | |
| U113 | 270Dh | h | USER P113 | 0 | -32768 to 32767 | Y | 0 | Y | Y | 5 | Y | Y | Y | |
| U114 | 270Eh | h | USER P114 | 0 | -32768 to 32767 | Y | 0 | Y | Y | 5 | Y | Y | Y | |
| U115 | 270Fh | h | USER P115 | 0 | -32768 to 32767 | Y | 0 | Y | Y | 5 | Y | Y | Y | |
| U116 | 2710h | h | USER P116 | 0 | -32768 to 32767 | Y | 0 | Y | Y | 5 | Y | Y | Y | |
| U117 | 2711h | h | USER P117 | 0 | -32768 to 32767 | Y | 0 | Y | Y | 5 | Y | Y | Y | |
| U118 | 2712h | h | USER P118 | 0 | -32768 to 32767 | Y | 0 | Y | Y | 5 | Y | Y | Y | |
| U119 | 2713h | h | USER P119 | 0 | -32768 to 32767 | Y | 0 | Y | Y | 5 | Y | Y | Y | |
| U120 | 2714h | h | USER P120 | 0 | -32768 to 32767 | Y | 0 | Y | Y | 5 | Y | Y | Y | |
| U121 | 2715h | h | USER P121 | 0 | -32768 to 32767 | Y | 0 | Y | Y | 5 | Y | Y | Y | |
| U122 | 2716h | h | USER P122 | 0 | -32768 to 32767 | Y | 0 | Y | Y | 5 | Y | Y | Y | |
| U123 | 2717h | h | USER P123 | 0 | -32768 to 32767 | Y | 0 | Y | Y | 5 | Y | Y | Y | |
| U124 | 2718h | h | USER P124 | 0 | -32768 to 32767 | Y | 0 | Y | Y | 5 | Y | Y | Y | |
| U125 | 2719h | h | USER P125 | 0 | -32768 to 32767 | Y | 0 | Y | Y | 5 | Y | Y | Y | |
| U126 | 271Ah | h | USER P126 | 0 | -32768 to 32767 | Y | 0 | Y | Y | 5 | Y | Y | Y | |
| U127 | 271Bh | h | USER P127 | 0 | -32768 to 32767 | Y | 0 | Y | Y | 5 | Y | Y | Y | |
| U128 | 271Ch | h | USER P128 | 0 | -32768 to 32767 | Y | 0 | Y | Y | 5 | Y | Y | Y | |
| U129 | 271Dh | h | USER P129 | 0 | -32768 to 32767 | Y | 0 | Y | Y | 5 | Y | Y | Y | |
| U130 | 271Eh | h | USER P130 | 0 | -32768 to 32767 | Y | 0 | Y | Y | 5 | Y | Y | Y | |
| U131 | 271Fh | h | USER P131 | 0 | -32768 to 32767 | Y | 0 | Y | Y | 5 | Y | Y | Y | |
| U132 | 2720h | h | USER P132 | 0 | -32768 to 32767 | Y | 0 | Y | Y | 5 | Y | Y | Y | |
| U133 | 2721h | h | USER P133 | 0 | -32768 to 32767 | Y | 0 | Y | Y | 5 | Y | Y | Y | |
| U134 | 2722h | h | USER P134 | 0 | -32768 to 32767 | Y | 0 | Y | Y | 5 | Y | Y | Y | |
| U135 | 2723h | h | USER P135 | 0 | -32768 to 32767 | Y | 0 | Y | Y | 5 | Y | Y | Y | |
| U136 | 2724h | h | USER P136 | 0 | -32768 to 32767 | Y | 0 | Y | Y | 5 | Y | Y | Y | |
| U137 | 2725h | h | USER P137 | 0 | -32768 to 32767 | Y | 0 | Y | Y | 5 | Y | Y | Y | |
| U138 | 2726h | h | USER P138 | 0 | -32768 to 32767 | Y | 0 | Y | Y | 5 | Y | Y | Y | |
| U139 | 2727h | h | USER P139 | 0 | -32768 to 32767 | Y | 0 | Y | Y | 5 | Y | Y | Y | |
| U140 | 2728h | h | USER P140 | 0 | -32768 to 32767 | Y | 0 | Y | Y | 5 | Y | Y | Y | |
| U141 | 2729h | h | USER P141 | 0 | -32768 to 32767 | Y | 0 | Y | Y | 5 | Y | Y | Y | |
| U142 | 272Ah | h | USER P142 | 0 | -32768 to 32767 | Y | 0 | Y | Y | 5 | Y | Y | Y | |
| U143 | 272Bh | h | USER P143 | 0 | -32768 to 32767 | Y | 0 | Y | Y | 5 | Y | Y | Y | |
| U144 | 272Ch | h | USER P144 | 0 | -32768 to 32767 | Y | 0 | Y | Y | 5 | Y | Y | Y | |
| U145 | 272Dh | h | USER P145 | 0 | -32768 to 32767 | Y | 0 | Y | Y | 5 | Y | Y | Y | |
| U146 | 272Eh | h | USER P146 | 0 | -32768 to 32767 | Y | 0 | Y | Y | 5 | Y | Y | Y | |
| U147 | 272Fh | h | USER P147 | 0 | -32768 to 32767 | Y | 0 | Y | Y | 5 | Y | Y | Y | |
| U148 | 2730h | h | USER P148 | 0 | -32768 to 32767 | Y | 0 | Y | Y | 5 | Y | Y | Y | |
| U149 | 2731h | h | USER P149 | 0 | -32768 to 32767 | Y | 0 | Y | Y | 5 | Y | Y | Y | |
| U150 | 2732h | h | USER P150 | 0 | -32768 to 32767 | Y | 0 | Y | Y | 5 | Y | Y | Y | |

■ SF codes (Safety Functions)

| Function code | Communications address | | Name | Dir. | Data setting range | Change when running | Default setting | Data copying | | Format type | Drive control | | | Remarks |
|---------------|------------------------|----------|---|------|--|---------------------|-----------------|----------------|----------------|-------------|---------------|-----------|-----|---------|
| | 485 No. | Link No. | | | | | | Initialization | Initialization | | VC w/ PG | VC w/o PG | V/f | |
| SF00 | 2800h | | h Password state monitor | 0 | 0 or 1 0: Locked 1: Unlocked | N | 0 | N | N | 0 | Y | Y | Y | Y |
| SF01 | 2801h | | h SS1 Level | 0 | 30 to 30000 r/m | N | 150 | N | N | 0 | Y | Y | Y | Y |
| SF02 | 2802h | | h SS1 Timer | 0 | 0.01 to 99.99 s 100.0 to 999.9 s 1000 to 3600 s | N | 10.00 | N | N | 13 | Y | Y | Y | Y |
| SF03 | 2803h | | h SS1/SLS Deceleration Time | 0 | 0.01 to 99.99 s 100.0 to 999.9 s 1000 to 3600 s | N | 5.00 | N | N | 13 | Y | Y | Y | Y |
| SF04 | 2804h | | h SLS Level | 0 | 30 to 30000 r/m | N | 300 | N | N | 0 | Y | Y | Y | Y |
| SF05 | 2805h | | h SLS Timer | 0 | 0.01 to 99.99 s 100.0 to 999.9 s 1000 to 3600 s | N | 10.00 | N | N | 13 | Y | Y | Y | Y |
| SF06 | 2806h | | h SS1/SLS Upper Limit | 0 | 0 to 30000 r/m | N | 300 | N | N | 0 | Y | Y | Y | Y |
| SF07 | 2807h | | h Motor Maximum Speed | 0 | 50 to 30000 r/m | N | 1500 | N | N | 0 | Y | Y | Y | Y |
| SF08 | 2808h | | h Upper Limit Monitor Wait Time | 0 | 0.00 to 99.99 s 100.0 to 999.9 s 1000 to 3600 s | N | 0.00 | N | N | 13 | Y | Y | Y | Y |
| SF09 | 2809h | | h PG Failure Detection Function | 0 | 0 or 1 0: Disable 1: Enable | N | 1 | N | N | 68 | Y | Y | Y | Y |
| SF10 | 280Ah | | h PG Pulse Resolution | 0 | 300 to 60000 | N | 1024 | N | N | 0 | Y | Y | Y | Y |
| SF11 | 280Bh | | h Speed Detection Filter | 0 | 0.000 to 0.100 s | N | 0.010 | N | N | 4 | Y | Y | Y | Y |
| SF12 | 280Ch | | h STO Diagnostic Forecast Time | 0 | 0.0 to 1.0 s | N | 0.0 | N | N | 2 | Y | Y | Y | Y |
| SF20 | 2814h | | h Terminal [SL1]/[SL2] Function | 0 | 0 to 2 0: No function 1: SS1 function 2: SLS function | N | 0 | N | N | 219 | Y | Y | Y | Y |
| SF21 | 2815h | | h SS1 Stop Mode | 0 | 0 or 1 0: Speed monitor 1: Time monitor | N | 1 | N | N | 220 | Y | Y | Y | Y |
| SF22 | 2816h | | h Encoder Selection | 0 | 0 to 2 0: Unrecommended PG or no PG 1: Recommended 15V encoder 2: Recommended 12V encoder | N | 0 | N | N | 221 | Y | Y | Y | Y |
| SF23 | 2817h | | h Fault Reaction Selection | 0 | 0 or 1 0: STO (SBC if enabled) 1: SS1 | N | 0 | N | N | 222 | Y | Y | Y | Y |
| SF24 | 2818h | | h SBC Function Selection | 0 | 0 to 2 0: Disable 1: Enable, Via safety relay 2: Enable, Brake direct connection | N | 0 | N | N | 224 | Y | Y | Y | Y |
| SF25 | 2819h | | h SS1 Error Processing | 0 | 0 to 1 0: Select fault reaction 1: Select light alarm | N | 0 | N | N | 227 | Y | Y | Y | Y |
| SF26 | 281Ah | | h SLS Deceleration Error Processing | 0 | 0 to 1 0: Select fault reaction 1: Select light alarm | N | 0 | N | N | 223 | Y | Y | Y | Y |
| SF27 | 281Bh | | h SLS Upper Limit Error Processing | 0 | 0 to 1 0: Select fault reaction 1: Select light alarm | N | 0 | N | N | 223 | Y | Y | Y | Y |
| SF28 | 281Ch | | h Save All of Safety-related Function Codes | 0 | 0 or 1 0: No save 1: Save all (Automatically reverts to "0") | N | - | N | N | 0 | Y | Y | Y | Y |
| SF30 | 281Eh | | h Safety-related Password Authentication 1 | 0 | 0000 to FFFF | N | 0000 | N | N | 9 | Y | Y | Y | Y |
| SF31 | 281Fh | | h Safety-related Password Authentication 2 | 0 | 0000 to FFFF | N | 0000 | N | N | 9 | Y | Y | Y | Y |

*1 The SF00 through SF31 function codes are available in the ROM version H1/2 0020 or later.

■ S codes (Serial Communication Functions)

| Function code | Communications address | | Name | Dir. | Data setting range | Change when running | Default setting | Data copying | Initialization | Format type | Drive control | | | Remarks | |
|---------------|------------------------|----------|---|------|--|---------------------|-----------------|--------------|----------------|-------------|---------------|-----------|-----|---------|-------------|
| | 485 No. | Link No. | | | | | | | | | VC w/ PG | VC w/o PG | V/f | | VC for PMSM |
| S01 | 701h | 1h | Reference Frequency/Speed 1 | 7 | -20000 to 20000 : (data)*Nmax/20000 r/min | Y | - | N | N | 5 | Y | Y | Y | Y | |
| S02 | 702h | 2h | Torque Command | 1 | -327.68 to 327.67% : 0.01%/1d | Y | - | N | N | 7 | Y | Y | N | Y | |
| S03 | 703h | 3h | Torque Current Command | 1 | -327.68 to 327.67% : 0.01%/1d | Y | - | N | N | 7 | Y | Y | N | Y | |
| S04 | 704h | 4h | Magnetic-flux Command | 1 | -327.68 to 327.67% : 0.01%/1d | Y | - | N | N | 7 | Y | N | N | N | |
| S05 | 705h | 5h | Orientation Position Command | 1 | 0000 to FFFF | Y | - | N | N | 9 | Y | N | N | Y | |
| S06 | 706h | 6h | Run Command 1 | 1 | 0000 to FFFF | Y | - | N | N | 32 | Y | Y | Y | Y | |
| S07 | 707h | 7h | Universal Do | 1 | 0000 to FFFF | Y | - | N | N | 33 | Y | Y | Y | Y | |
| S08 | 708h | 8h | Acceleration Time | 2 | 0.0 to 3600.0 s | Y | - | N | N | 2 | Y | Y | Y | Y | |
| S09 | 709h | 9h | Deceleration Time | 1 | 0.0 to 3600.0 s | Y | - | N | N | 2 | Y | Y | Y | Y | |
| S10 | 70Ah | Ah | Torque Limiter Level 1 | 2 | -327.68 to 327.67% : 0.01%/1d | Y | - | N | N | 7 | Y | Y | N | Y | |
| S11 | 70Bh | Bh | Torque Limiter Level 2 | 1 | -327.68 to 327.67% : 0.01%/1d | Y | - | N | N | 7 | Y | Y | N | Y | |
| S12 | 70Ch | Ch | Run Command 2 | 0 | 0000 to FFFF | Y | - | N | N | 9 | Y | Y | Y | Y | |
| S13 | 70Dh | h | Universal Ao | 0 | -16384 to 16384 (-10V to +10V) | Y | - | N | N | 5 | Y | Y | Y | Y | |
| S16 | 710h | h | General-purpose Setting 1 (Available soon) | 2 | -32768 to 32767 Assign functions using E90. | Y | - | N | N | 5 | Y | Y | Y | Y | |
| S17 | 711h | h | General-purpose Setting 2 (Available soon) | 1 | -32768 to 32767 Assign functions using E91. | Y | - | N | N | 5 | Y | Y | Y | Y | |

■ M codes (Monitoring Functions)

| Function code | Communications address | | Name | Dir. | Data setting range | Change when running | Default setting | Data copying | Initialization | Format type | Drive control | | | Remarks | |
|---------------|------------------------|----------|---|------|--|---------------------|-----------------|--------------|----------------|-------------|---------------|-----------|-----|---------|--|
| | 485 No. | Link No. | | | | | | | | | VC w/ PG | VC w/o PG | V/f | | |
| M01 | 801h | Fh | Reference Speed 4 (ASR input) | 15 | -32000 to 32000 : (data)*Nmax/20000 r/min | N | - | N | N | 5 | Y | Y | Y | Y | |
| M02 | 802h | 10h | Torque Command | 1 | 0.01%/1d | N | - | N | N | 7 | Y | Y | N | Y | |
| M03 | 803h | 11h | Torque Current Command | 1 | 0.01%/1d | N | - | N | N | 7 | Y | Y | N | Y | |
| M04 | 804h | 12h | Magnetic-flux Command | 1 | 0.01%/1d | N | - | N | N | 7 | Y | Y | N | N | |
| M05 | 805h | 13h | Output Frequency Command | 1 | 0.1 Hz/1d | N | - | N | N | 2 | Y | Y | Y | Y | |
| M06 | 806h | 14h | Detected Speed | 1 | -32000 to 32000 : (data)*Nmax/20000 r/min | N | - | N | N | 5 | Y | Y | N | Y | |
| M07 | 807h | 15h | Calculated Torque | 1 | 0.01%/1d | N | - | N | N | 7 | Y | Y | Y | Y | |
| M08 | 808h | 16h | Calculated Torque Current | 1 | 0.01%/1d | N | - | N | N | 7 | Y | Y | Y | Y | |
| M09 | 809h | 17h | Output Frequency | 1 | 0.1 Hz/1d | N | - | N | N | 2 | Y | Y | Y | Y | |
| M10 | 80Ah | 18h | Motor Output | 1 | 0.1 kW/1d | N | - | N | N | 2 | Y | Y | Y | Y | |
| M11 | 80Bh | 19h | Effective Output Current | 1 | 0.1 A/1d | N | - | N | N | 2 | Y | Y | Y | Y | |
| M12 | 80Ch | 1Ah | Effective Output Voltage | 1 | 0.1 V/1d | N | - | N | N | 2 | Y | Y | Y | Y | |
| M13 | 80Dh | 1Bh | Final Run Command | 1 | 0000 to FFFF | N | - | N | N | 32 | Y | Y | Y | Y | |
| M14 | 80Eh | 1Ch | Running Status | 1 | 0000 to FFFF | N | - | N | N | 21 | Y | Y | Y | Y | |
| M15 | 80Fh | 1Dh | Output Terminals Y1-Y18 | 1 | 0000 to FFFF | N | - | N | N | 33 | Y | Y | Y | Y | |
| M16 | 810h | 1Eh | Latest Alarm Data (Multiple alarm, Trip cause) | 4 | 0000 to 5540 | N | - | N | N | 14 | Y | Y | Y | Y | |
| M17 | 811h | 1Fh | Latest Alarm History | 1 | 0000 to FF40 | N | - | N | N | 15 | Y | Y | Y | Y | |
| M18 | 812h | 20h | 1st Last Alarm History | 1 | 0000 to FF40 | N | - | N | N | 15 | Y | Y | Y | Y | |
| M19 | 813h | 21h | 2nd Last Alarm History | 1 | 0000 to FF40 | N | - | N | N | 15 | Y | Y | Y | Y | |
| M20 | 814h | 22h | Cumulative Run Time | 7 | 0 to 65535 h | N | - | N | N | 0 | Y | Y | Y | Y | |
| M21 | 815h | 23h | DC Link Bus Voltage | 1 | 1 V/1d | N | - | N | N | 0 | Y | Y | Y | Y | |
| M22 | 816h | 24h | Motor Temperature | 1 | 1°C/1d | N | - | N | N | 5 | Y | Y | Y | Y | |
| M23 | 817h | 25h | Model Code | 1 | 0000 to FFFF 200V class series : 1313h 400V class series : 1314h | N | - | N | N | 29 | Y | Y | Y | Y | |
| M24 | 818h | 26h | Capacity Code | 1 | 0 to 34 | N | - | N | N | 28 | Y | Y | Y | Y | |
| M25 | 819h | 27h | Inverter ROM (Main Control) Version | 1 | 0000 to FFFF | N | - | N | N | 9 | Y | Y | Y | Y | |
| M26 | 81Ah | 28h | Communications Error Code | 1 | 0000 to FFFF | N | - | N | N | 34 | Y | Y | Y | Y | |
| M27 | 81Bh | 29h | Alarm (Latest) Speed Command | 19 | -32000 to 32000 : (data)*Nmax/20000 r/min | N | - | N | N | 5 | Y | Y | Y | Y | |
| M28 | 81Ch | 2Ah | Alarm (Latest) Torque Command | 1 | 0.01%/1d | N | - | N | N | 7 | Y | Y | N | Y | |
| M29 | 81Dh | 2Bh | Alarm (Latest) Torque Current Command | 1 | 0.01%/1d | N | - | N | N | 7 | Y | Y | N | Y | |
| M30 | 81Eh | 2Ch | Alarm (Latest) Magnetic-flux command | 1 | 0.01%/1d | N | - | N | N | 7 | Y | Y | N | N | |
| M31 | 81Fh | 2Dh | Alarm (Latest) Output Frequency Command | 1 | 0.1 Hz/1d | N | - | N | N | 2 | Y | Y | Y | Y | |
| M32 | 820h | 2Eh | Alarm (Latest) Detected Speed | 1 | -32000 to 32000 : (data)*Nmax/20000 r/min | N | - | N | N | 5 | Y | Y | N | Y | |
| M33 | 821h | 2Fh | Alarm (Latest) Calculated Torque | 1 | 0.01%/1d | N | - | N | N | 7 | Y | Y | Y | Y | |
| M34 | 822h | 30h | Alarm (Latest) Calculated Torque Current | 1 | 0.01%/1d | N | - | N | N | 7 | Y | Y | Y | Y | |
| M35 | 823h | 31h | Alarm (Latest) Output Frequency | 1 | 0.1 Hz/1d | N | - | N | N | 2 | Y | Y | Y | Y | |
| M36 | 824h | 32h | Alarm (Latest) Motor Output | 1 | 0.1 kW/1d | N | - | N | N | 2 | Y | Y | Y | Y | |
| M37 | 825h | 33h | Alarm (Latest) Effective Output Current | 1 | 0.1 A/1d | N | - | N | N | 2 | Y | Y | Y | Y | |
| M38 | 826h | 34h | Alarm (Latest) Effective Output Voltage | 1 | 0.1 V/1d | N | - | N | N | 2 | Y | Y | Y | Y | |
| M39 | 827h | 35h | Alarm (Latest) Run Command | 1 | 0000 to FFFF | N | - | N | N | 32 | Y | Y | Y | Y | |
| M40 | 828h | 36h | Alarm (Latest) Running Status | 1 | 0000 to FFFF | N | - | N | N | 21 | Y | Y | Y | Y | |
| M41 | 829h | 37h | Alarm (Latest) Output Signal | 1 | 0000 to FFFF | N | - | N | N | 33 | Y | Y | Y | Y | |
| M42 | 82Ah | 38h | Alarm (Latest) Cumulative Run Time | 1 | 0 to 65535 h | N | - | N | N | 0 | Y | Y | Y | Y | |
| M43 | 82Bh | 39h | Alarm (Latest) DC Link Bus Voltage | 1 | 1 V/1d | N | - | N | N | 0 | Y | Y | Y | Y | |
| M44 | 82Ch | 3Ah | Alarm (Latest) Inverter Internal Temperature | 1 | 1°C/1d | N | - | N | N | 5 | Y | Y | Y | Y | |
| M45 | 82Dh | 3Bh | Alarm (Latest) Heat Sink Temperature | 1 | 1°C/1d | N | - | N | N | 5 | Y | Y | Y | Y | |
| M46 | 82Eh | 3Ch | Capacity of Main Circuit Capacitor | 3 | 0 to 100% | N | - | N | N | 0 | Y | Y | Y | Y | |
| M47 | 82Fh | 3Dh | Service Life of Electrolytic Capacitor on PCB | 1 | 0 to 65535 (10h) | N | - | N | N | 0 | Y | Y | Y | Y | |
| M48 | 830h | 3Eh | Cooling Fan Service Life | 1 | 0 to 65535 (10h) | N | - | N | N | 0 | Y | Y | Y | Y | |

| Function code | Communications address | | Name | Dir. | Data setting range | Change when running | Default setting | Data copying | Initialization | Format type | Drive control | | | Remarks |
|---------------|------------------------|----------|--|------|---|---------------------|-----------------|--------------|----------------|-------------|---------------|-----------|----|---------|
| | 485 No. | Link No. | | | | | | | | | VC w/ PG | VC w/o PG | Vf | |
| M49 | 831h | 3Fh | Reference Speed 1 (before multistep speed command) | 3 | -32000 to 32000 : (data)*Nmax/20000 r/min | N | - | N | N | 5 | Y | Y | Y | Y |
| M50 | 832h | 40h | Reference Speed 2 (before calculation of acceleration/deceleration) | 1 | -32000 to 32000 : (data)*Nmax/20000 r/min | N | - | N | N | 5 | Y | Y | Y | Y |
| M51 | 833h | 41h | Reference Speed 3 (after speed limiting) | 1 | -32000 to 32000 : (data)*Nmax/20000 r/min | N | - | N | N | 5 | Y | Y | Y | Y |
| M52 | 834h | 42h | Control Output 1 | 3 | 0000 to FFFF | N | - | N | N | 125 | Y | Y | Y | Y |
| M53 | 835h | 43h | Control Output 2 | 1 | 0000 to FFFF | N | - | N | N | 126 | Y | Y | Y | Y |
| M54 | 836h | 44h | Control Output 3 | 1 | 0000 to FFFF | N | - | N | N | 127 | Y | Y | Y | Y |
| M55 | 837h | 45h | Option Monitor 1 | 6 | 0000 to FFFF | N | - | N | N | 9 | Y | Y | Y | Y |
| M56 | 838h | 46h | Option Monitor 2 | 1 | 0000 to FFFF | N | - | N | N | 9 | Y | Y | Y | Y |
| M57 | 839h | 47h | Option Monitor 3 | 1 | 0 to 65535 | N | - | N | N | 0 | Y | Y | Y | Y |
| M58 | 83Ah | 48h | Option Monitor 4 | 1 | 0 to 65535 | N | - | N | N | 0 | Y | Y | Y | Y |
| M59 | 83Bh | 49h | Option Monitor 5 | 1 | -32768 to 32767 | N | - | N | N | 5 | Y | Y | Y | Y |
| M60 | 83Ch | 4Ah | Option Monitor 6 | 1 | -32768 to 32767 | N | - | N | N | 5 | Y | Y | Y | Y |
| M61 | 83Dh | h | Current Date, Year/Month | 3 | 0000 to FFFF Upper 2 digits: Year, Lower 2 digits: Month | N | - | N | N | 143 | Y | Y | Y | Y |
| M62 | 83Eh | h | Current Date, Day/Hour | 1 | 0000 to FFFF Upper 2 digits: Day, Lower 2 digits: Hour | N | - | N | N | 144 | Y | Y | Y | Y |
| M63 | 83Fh | h | Current Date, Minute/Second | 1 | 0000 to FFFF Upper 2 digits: Minute, Lower 2 digits: Second | N | - | N | N | 145 | Y | Y | Y | Y |
| M64 | 840h | h | Date of Occurrence of Latest Alarm, Year/Month | 3 | 0000 to FFFF Upper 2 digits: Year, Lower 2 digits: Month | N | - | N | N | 143 | Y | Y | Y | Y |
| M65 | 841h | h | Date of Occurrence of Latest Alarm, Day/Hour | 1 | 0000 to FFFF Upper 2 digits: Day, Lower 2 digits: Hour | N | - | N | N | 144 | Y | Y | Y | Y |
| M66 | 842h | h | Date of Occurrence of Latest Alarm, Minute/Second | 1 | 0000 to FFFF Upper 2 digits: Minute, Lower 2 digits: Second | N | - | N | N | 145 | Y | Y | Y | Y |
| M67 | 843h | h | Date of Removal of Latest Alarm, Year/Month | 3 | 0000 to FFFF Upper 2 digits: Year, Lower 2 digits: Month | N | - | N | N | 143 | Y | Y | Y | Y |
| M68 | 844h | h | Date of Removal of Latest Alarm, Day/Hour | 1 | 0000 to FFFF Upper 2 digits: Day, Lower 2 digits: Hour | N | - | N | N | 144 | Y | Y | Y | Y |
| M69 | 845h | h | Date of Removal of Latest Alarm, Minute/Second | 1 | 0000 to FFFF Upper 2 digits: Minute, Lower 2 digits: Second | N | - | N | N | 145 | Y | Y | Y | Y |
| M70 | 846h | h | Latest Alarm Extension ID | 18 | 0 or 1 0: Alarm at the local station 1: Alarm at the remote station | N | - | N | N | 212 | Y | Y | Y | Y |
| M71 | 847h | h | Latest Multiple Alarm, 2nd | 1 | 0000 to FFFF | N | - | N | N | 14 | Y | Y | Y | Y |
| M72 | 848h | h | Latest Multiple Alarm, 3rd | 1 | 0000 to FFFF | N | - | N | N | 14 | Y | Y | Y | Y |
| M73 | 849h | h | Latest Multiple Alarm, 4th | 1 | 0000 to FFFF | N | - | N | N | 14 | Y | Y | Y | Y |
| M74 | 84Ah | h | Latest Multiple Alarm, 5th | 1 | 0000 to FFFF | N | - | N | N | 14 | Y | Y | Y | Y |
| M75 | 84Bh | h | Latest Alarm, Subcode | 1 | 0000 to FFFF | N | - | N | N | 9 | Y | Y | Y | Y |
| M76 | 84Ch | h | Latest Alarm, Maximum Speed | 1 | 0 to 65535 r/min | N | - | N | N | 0 | Y | Y | Y | Y |
| M77 | 84Dh | h | Latest Alarm, Input Power | 1 | 0.0 to 6553.5 kW | N | - | N | N | 2 | Y | Y | Y | Y |
| M78 | 84Eh | h | Latest Alarm, Motor Temperature | 1 | 1°C/1d | N | - | N | N | 5 | Y | Y | Y | Y |
| M79 | 84Fh | h | Latest Alarm, Running Status 2 (a) | 1 | 0000 to FFFF | N | - | N | N | 141 | Y | Y | Y | Y |
| M80 | 850h | h | Latest Alarm, Running Status 2 (b) | 1 | 0000 to FFFF | N | - | N | N | 142 | Y | Y | Y | Y |
| M81 | 851h | h | Latest Alarm, Run Command (Communications Link) | 1 | 0000 to FFFF | N | - | N | N | 32 | Y | Y | Y | Y |
| M82 | 852h | h | Latest Alarm, Run Command 2 (Communications Link) | 1 | 0000 to FFFF | N | - | N | N | 9 | Y | Y | Y | Y |
| M83 | 853h | h | Latest Alarm, For Particular Manufacturers | 1 | 0000 to FFFF | N | - | N | N | 9 | Y | Y | Y | Y |
| M84 | 854h | h | Latest Alarm, M1 Number of Startups | 1 | 0 to 65535 times | N | - | N | N | 0 | Y | Y | Y | Y |
| M85 | 855h | h | Latest Alarm, M2 Number of Startups | 1 | 0 to 65535 times | N | - | N | N | 0 | Y | Y | Y | Y |
| M86 | 856h | h | Latest Alarm, M3 Number of Startups | 1 | 0 to 65535 times | N | - | N | N | 0 | Y | Y | Y | Y |
| M87 | 857h | h | Latest Alarm, EN Terminal Input | 1 | 0000 to FFFF | N | - | N | N | 100 | Y | Y | Y | Y |
| M93 | 85Dh | h | Light Alarm (Latest) | 4 | 0 to 255 | N | - | N | N | 102 | Y | Y | Y | Y |
| M94 | 85Eh | h | Light Alarm (2nd last) | 1 | 0 to 255 | N | - | N | N | 102 | Y | Y | Y | Y |
| M95 | 85Fh | h | Light Alarm (3rd last) | 1 | 0 to 255 | N | - | N | N | 102 | Y | Y | Y | Y |
| M96 | 860h | h | Light Alarm (4th last) | 1 | 0 to 255 | N | - | N | N | 102 | Y | Y | Y | Y |
| M98 | 862h | h | EN Terminal Input | 0 | 0000 to FFFF | N | - | N | N | 100 | Y | Y | Y | Y |
| M100 | 2900h | h | Effective Parameter Set Condition | 0 | 0000 to FFFF | N | - | N | N | 9 | Y | Y | Y | Y |

| Function code | Communications address | | Name | Dir. | Data setting range | Change when running | Default setting | Data copying | Initialization | Format type | Drive control | | | | Remarks |
|---------------|------------------------|----------|--|------|--|---------------------|-----------------|--------------|----------------|-------------|---------------|-----------|-----|-------------|---------|
| | 485 No. | Link No. | | | | | | | | | VC w/ PG | VC w/o PG | V/f | VC for PMSM | |
| M101 | 2901h | h | Run Command 2 (Communications Link) | 0 | 0000 to FFFF Monitors X terminal functions to be used exclusively via the communications link. | N | - | N | N | 32 | Y | Y | Y | Y | |
| M102 | 2902h | h | Load Factor | 0 | -327.68 to 327.67% Motor load factor, Motor rated load/100% | N | - | N | N | 7 | Y | Y | Y | Y | |
| M103 | 2903h | h | Input Power | 0 | 0.0 to 6553.5 kW Input power to inverter | N | - | N | N | 2 | Y | Y | Y | Y | |
| M104 | 2904h | h | Running Status 2(a) | 0 | 0000 to FFFF | N | - | N | N | 141 | Y | Y | Y | Y | |
| M105 | 2905h | h | Running Status 2(b) | 0 | 0000 to FFFF | N | - | N | N | 142 | Y | Y | Y | Y | |
| M106 | 2906h | h | Detected Load Shaft Speed | 0 | -32000 to 32000 : (data)*Nmax/20000 r/min | N | - | N | N | 5 | Y | Y | Y | Y | |
| M107 | 2907h | h | Detected Line Speed | 0 | -32000 to 32000 : (data)*Nmax/20000 r/min | N | - | N | N | 5 | Y | Y | Y | Y | |
| M108 | 2908h | h | PID Command Value | 0 | -327.68 to 327.67% | N | - | N | N | 7 | Y | Y | Y | Y | |
| M109 | 2909h | h | PID Feedback Amount | 0 | -327.68 to 327.67% | N | - | N | N | 7 | Y | Y | Y | Y | |
| M110 | 290Ah | h | PID Output | 0 | -327.68 to 327.67% | N | - | N | N | 7 | Y | Y | Y | Y | |
| M112 | 290Ch | h | Remaining allowance for M1 motor overload | 3 | 0 to 65535% When M112 = 0 (%), the inverter issues OL1 alarm. | N | - | N | N | 0 | Y | Y | Y | Y | |
| M113 | 290Dh | h | Remaining allowance for M2 motor overload | 1 | 0 to 65535% When M113 = 0 (%), the inverter issues OL2 alarm. | N | - | N | N | 0 | Y | Y | Y | Y | |
| M114 | 290Eh | h | Remaining allowance for M3 motor overload | 1 | 0 to 65535% When M114 = 0 (%), the inverter issues OL3 alarm. | N | - | N | N | 0 | Y | Y | Y | Y | |
| M115 | 290Fh | h | Input Watt-hour | 4 | 0.000 to 9999 100 kWh/1.000d Limited at 999900 kWh. | N | - | N | N | 101 | Y | Y | Y | Y | |
| M116 | 2910h | h | Input Watt-hour Data | 1 | 0000 to 9999 100 kWh/1.000d * Display coefficient M116 = M115 (Input watt-hour) x F84 (Display coefficient for input watt-hour data) Specifying the electric rate per 100 kWh with F84 shows the electricity price. | N | - | N | N | 101 | Y | Y | Y | Y | |
| M117 | 2911h | h | Input Watt-hour (Lower 16 bits) | 1 | (81920d/unit 100% rating)(kW) x Cumulative time (s) x 2 ⁽⁻¹⁶⁾ | N | - | N | N | 9 | Y | Y | Y | Y | |
| M118 | 2912h | h | Input Watt-hour (Upper 16 bits) | 1 | (81920d/unit 100% rating)(kW) x Cumulative time (s) x 2 ⁽⁻³²⁾ | N | - | N | N | 9 | Y | Y | Y | Y | |
| M119 | 2913h | h | Inverter Internal Temperature (Real-time value) | 2 | -32768 to 32767°C | N | - | N | N | 5 | Y | Y | Y | Y | |
| M120 | 2914h | h | Heat Sink Temperature (Real-time value) | 1 | -32768 to 32767°C | N | - | N | N | 5 | Y | Y | Y | Y | |
| M121 | 2915h | h | Main Circuit Capacitor Service Life (Elapsed time) | 0 | 0 to 65535 (10h) | N | - | N | N | 0 | Y | Y | Y | Y | |
| M123 | 2917h | h | M1 Number of Startups | 3 | 0 to 65535 times | N | - | N | N | 0 | Y | Y | Y | Y | |
| M124 | 2918h | h | M2 Number of Startups | 1 | 0 to 65535 times | N | - | N | N | 0 | Y | Y | Y | Y | |
| M125 | 2919h | h | M3 Number of Startups | 1 | 0 to 65535 times | N | - | N | N | 0 | Y | Y | Y | Y | |
| M126 | 291Ah | h | M1 Cumulative Motor Run Time | 3 | 0 to 65535 (10h) | N | - | N | N | 0 | Y | Y | Y | Y | |
| M127 | 291Bh | h | M2 Cumulative Motor Run Time | 1 | 0 to 65535 (10h) | N | - | N | N | 0 | Y | Y | Y | Y | |
| M128 | 291Ch | h | M3 Cumulative Motor Run Time | 1 | 0 to 65535 (10h) | N | - | N | N | 0 | Y | Y | Y | Y | |
| M129 | 291Dh | h | Run Command (Via communications link) | 0 | 0000 to FFFF | N | - | N | N | 32 | Y | Y | Y | Y | |
| M130 | 291Eh | h | Torque Bias | 0 | -327.68 to 327.67% | N | - | N | N | 7 | Y | Y | N | Y | |
| M131 | 291Fh | h | Magnetic Pole Position Signal | 0 | -32768 to 32767 | N | - | N | N | 5 | N | N | N | Y | |
| M132 | 2920h | h | Universal AO1 | 0 | 0000 to FFFF | N | - | N | N | 9 | Y | Y | Y | Y | |
| M133 | 2921h | h | Option AO1 | 0 | 0000 to FFFF | N | - | N | N | 9 | Y | Y | Y | Y | |
| M134 | 2922h | h | Control Input 1 | 0 | 0000 to FFFF | N | - | N | N | 133 | Y | Y | Y | Y | |
| M135 | 2923h | h | Control Input 2 | 0 | 0000 to FFFF | N | - | N | N | 134 | Y | Y | Y | Y | |
| M136 | 2924h | h | Control Input 3 | 0 | 0000 to FFFF | N | - | N | N | 135 | Y | Y | Y | Y | |
| M137 | 2925h | h | Control Input 4 | 0 | 0000 to FFFF | N | - | N | N | 136 | Y | Y | Y | Y | |
| M138 | 2926h | h | Control Input 5 | 0 | 0000 to FFFF | N | - | N | N | 137 | Y | Y | Y | Y | |
| M139 | 2927h | h | Control Input 6 | 0 | 0000 to FFFF | N | - | N | N | 138 | Y | Y | Y | Y | |
| M140 | 2928h | h | Control Input 7 | 0 | 0000 to FFFF | N | - | N | N | 139 | Y | Y | Y | Y | |
| M141 | 2929h | h | Control Input 8 | 0 | 0000 to FFFF | N | - | N | N | 140 | Y | Y | Y | Y | |
| M142 | 292Ah | h | Control Output 4 | 0 | 0000 to FFFF (bit 0: E-SX bus tact synchronizing signal) | N | - | N | N | 128 | Y | Y | Y | Y | |
| M143 | 292Bh | h | Control Output 5 | 0 | 0000 to FFFF | N | - | N | N | 129 | Y | Y | Y | Y | |
| M144 | 292Ch | h | Control Output 6 | 0 | 0000 to FFFF | N | - | N | N | 130 | Y | Y | Y | Y | |
| M146 | 292Eh | h | Detected Speed 2 | 0 | -32000 to 32000: (data) * Nmax / 20000 r/min | N | - | N | N | 5 | Y | Y | N | Y | |
| M147 | 292Fh | h | Exciting Current Command | 0 | -327.68 to 327.67% | N | - | N | N | 7 | Y | Y | N | N | |
| M148 | 2930h | h | Detected Exciting Current | 0 | -327.68 to 327.67% | N | - | N | N | 7 | Y | Y | N | N | |
| M149 | 2931h | h | Magnetic-flux Calculation | 0 | 0.00 to 655.35% | N | - | N | N | 3 | Y | Y | N | N | |
| M161 | 293Dh | h | Ai Adjustment Value (I2) | 5 | -32768 to 32767 | N | - | N | N | 5 | Y | Y | Y | Y | |
| M162 | 293Eh | h | Ai Adjustment Value (Ai1) | 1 | -32768 to 32767 | N | - | N | N | 5 | Y | Y | Y | Y | |
| M163 | 293Fh | h | Ai Adjustment Value (Ai2) | 1 | -32768 to 32767 | N | - | N | N | 5 | Y | Y | Y | Y | |
| M164 | 2940h | h | Ai Adjustment Value (Ai3) | 1 | -32768 to 32767 | N | - | N | N | 5 | Y | Y | Y | Y | |
| M165 | 2941h | h | Ai Adjustment Value (Ai4) | 1 | -32768 to 32767 | N | - | N | N | 5 | Y | Y | Y | Y | |

| Function code | Communications address | | Name | Dir. | Data setting range | Change when running | Default setting | Data copying | Initialization | Format type | Drive control | | | Remarks | |
|---------------|------------------------|----------|--|------|--|---------------------|-----------------|--------------|----------------|-------------|---------------|-----------|-----|---------|-------------|
| | 485 No. | Link No. | | | | | | | | | VC w/ PG | VC w/o PG | V/f | | VC for PMSM |
| M166 | 2942h | | h Input Signal (Terminal) | 0 | 0000 to FFFF | N | - | N | N | 32 | Y | Y | Y | Y | |
| M167 | 2943h | | h Analog Input Signal (I2) | 3 | -32768 to 32767 (-16384 to 16384 : -10V to +10V) | N | - | N | N | 5 | Y | Y | Y | Y | |
| M168 | 2944h | | h Analog Input Signal (Ai1) | 1 | -32768 to 32767 (-16384 to 16384 : -10V to +10V) | N | - | N | N | 5 | Y | Y | Y | Y | |
| M169 | 2945h | | h Analog Input Signal (Ai2) | 1 | -32768 to 32767 (-16384 to 16384 : -10V to +10V) | N | - | N | N | 5 | Y | Y | Y | Y | |
| M170 | 2946h | | h Analog Output Signal (Ao1) | 3 | -32768 to 32767 (-16384 to 16384 : -10V to +10V) | N | - | N | N | 5 | Y | Y | Y | Y | |
| M171 | 2947h | | h Analog Output Signal (Ao2) | 1 | -32768 to 32767 (-16384 to 16384 : -10V to +10V) | N | - | N | N | 5 | Y | Y | Y | Y | |
| M172 | 2948h | | h Analog Output Signal (Ao3) | 1 | -32768 to 32767 (-16384 to 16384 : -10V to +10V) | N | - | N | N | 5 | Y | Y | Y | Y | |
| M173 | 2949h | | h AIO Input/Output Status 1(Ai3) | 4 | -32768 to 32767 | N | - | N | N | 5 | Y | Y | Y | Y | |
| M174 | 294Ah | | h AIO Input/Output Status 1(Ai4) | 1 | -32768 to 32767 | N | - | N | N | 5 | Y | Y | Y | Y | |
| M175 | 294Bh | | h AIO Input/Output Status 2(Ao4) | 1 | -32768 to 32767 | N | - | N | N | 5 | Y | Y | Y | Y | |
| M176 | 294Ch | | h AIO Input/Output Status 2(Ao5) | 1 | -32768 to 32767 | N | - | N | N | 5 | Y | Y | Y | Y | |
| M177 | 294Dh | | h PG(SD) Input Pulse | 4 | -32768 to 32767 | N | - | N | N | 5 | Y | Y | Y | Y | |
| M178 | 294Eh | | h PG(LD) Input Pulse | 1 | -32768 to 32767 | N | - | N | N | 5 | Y | Y | Y | Y | |
| M179 | 294Fh | | h PG(PR) Input Pulse | 1 | -32768 to 32767 | N | - | N | N | 5 | Y | Y | Y | Y | |
| M180 | 2950h | | h PG(PD) Input Pulse | 1 | -32768 to 32767 | N | - | N | N | 5 | Y | Y | Y | Y | |
| M181 | 2951h | | h DIOA Input Status (Terminal) | 0 | 0000 to FFFF | N | - | N | N | 146 | Y | Y | Y | Y | |
| M182 | 2952h | | h DIOA Input Status (Via communications link) | 0 | 0000 to FFFF | N | - | N | N | 146 | Y | Y | Y | Y | |
| M183 | 2953h | | h DIOB Option Input Status | 0 | 0000 to FFFF | N | - | N | N | 26 | Y | Y | Y | Y | |
| M184 | 2954h | | h DIOB Option Output Status | 0 | 0000 to FFFF | N | - | N | N | 27 | Y | Y | Y | Y | |
| M193 | 295Dh | | h General-purpose Setting 1 Monitor (Available soon) | 0 | -32768 to 32767 Monitors the S16 setting. | N | - | N | N | 5 | Y | Y | Y | Y | |
| M194 | 295Eh | | h General-purpose Setting 2 Monitor (Available soon) | 0 | -32768 to 32767 Monitors the S17 setting. | N | - | N | N | 5 | Y | Y | Y | Y | |
| M200 | 2A00h | | h Pulse Train Position Command Monitor | 5 | 0000 to FFFF | N | - | N | N | 9 | Y | N | N | Y | |
| M201 | 2A01h | | h Position Detection Monitor | 1 | 0000 to FFFF | N | - | N | N | 9 | Y | N | N | Y | |
| M202 | 2A02h | | h Position Detection (Z-phase Input) Monitor | 1 | 0000 to FFFF | N | - | N | N | 9 | Y | N | N | Y | |
| M220 | 2A14h | | h Load Compensating Speed Control Value | 3 | -32000 to 32000: (data)*Nmax/20000 r/min | N | - | N | N | 5 | Y | Y | N | Y | |
| M221 | 2A15h | | h Hoisting Load Calculation Result Monitor | 1 | 0 to 65535 kg | N | - | N | N | 0 | Y | Y | N | Y | |
| M222 | 2A16h | | h Travel Torque Calculation Monitor | 1 | -327.68 to 327.67% | N | - | N | N | 7 | Y | Y | N | Y | |

4.2.4 Data Format List

You can use the following formats to access function codes through the link and these formats are common to the FRENIC-VG.

4.2.4.1 Data Type 0 to 13


You can basically exchange data in the data types from 0 to 13.

| Code | Description | Display/setting | Resolution | Notes |
|------|----------------------|-----------------------------|------------|--|
| 0 | Integer | 0, 1, 2, 3, | 1 | |
| 1 | Integer | 0, 2, 4, 6, | 2 | Only for pole number of motor |
| 2 | Fixed point | 0.0, 0.1, 0.2, | 0.1 | |
| 3 | | 0.00, 0.01, 0.02, | 0.01 | |
| 4 | | 0.001, 0.002, 0.003, | 0.001 | |
| 5 | Integer (signed) | -2, -1, 0, 1, 2, | 1 | |
| 6 | Fixed point (signed) | -0.1, 0.0, 0.1, | 0.1 | |
| 7 | | -0.01, 0.00, 0.01, | 0.01 | |
| 8 | | -0.001, 0.000, 0.001, | 0.001 | |
| 9 | Hexadecimal | 1A8E | 1h | Initial cursor position is left end. Cursor does not move automatically. When setting range is from 00 to 11, you should specify individual digits to set only 00, 01, 10, or 11. |
| 10 | Special data 3 | 0.75, 1, 2, ... 14, 15 | | Carrier frequency setting |
| 11 | Operation data | | 1 | Reset to 0 after writing |
| 12 | Exponent/mantissa 1 | | 0.01 | |
| 13 | Exponent/mantissa 2 | | 0.01 | |


4.2.4.2 Data Type 12 to 145

The following data have special formats.


Type [12]: Time, current, power, PID process values



Type [13]: Current and others




Type [14]: Cause of alarm




Alarm codes

| Code | Display | Description | Code | Display | Description | Code | Display | Description |
|------|------------|--|------|------------|--|------|-------------|--|
| 0 | --- | No alarm | 22 | <i>OH2</i> | External alarm | 44 | <i>RrC</i> | Error code C for specific user application |
| 1 | --- | IPM error | 23 | <i>OH3</i> | Inverter internal overheat | 45 | <i>Rrd</i> | Error code D for specific user application |
| 2 | <i>dbH</i> | Braking resistor overheated | 24 | <i>OH4</i> | Motor overheat | 46 | <i>RrE</i> | Error code E for specific user application |
| 3 | <i>dLF</i> | DC fuse blown | 25 | <i>OL1</i> | Motor 1 overload | 47 | <i>RrF</i> | Error code F for specific user application |
| 4 | <i>dD</i> | Excessive positioning deviation | 26 | <i>OL2</i> | Motor 2 overload | 48 | <i>dbA</i> | Braking transistor broken |
| 5 | <i>EF</i> | Ground fault | 27 | <i>OL3</i> | Motor 3 overload | 49 | <i>ECF</i> | Functional safety circuit failure |
| 6 | <i>Er1</i> | Memory error | 28 | <i>OLU</i> | Inverter overload | 50 | <i>ErH</i> | Hardware error |
| 7 | <i>Er2</i> | Keypad communications error | 29 | <i>OS</i> | Overspeed | 51 | <i>Err</i> | Mock alarm |
| 8 | <i>Er3</i> | CPU error | 30 | <i>OU</i> | Overvoltage | 52 | <i>LdC</i> | Start delay |
| 9 | <i>Er4</i> | Network error | 31 | <i>PbF</i> | Charger circuit fault | 53 | <i>dFR</i> | DC fan locked |
| 10 | <i>Er5</i> | RS-485 communications error | 32 | <i>Pg</i> | PG wire break | 54 | <i>Et1</i> | PG failure |
| 11 | <i>Er6</i> | Operation error | 33 | <i>Rr1</i> | Error code 1 for specific user application | 55 | --- | No alarm |
| 12 | <i>Er7</i> | Output wiring fault | 34 | <i>Rr2</i> | Error code 2 for specific user application | 56 | <i>EC</i> | PG communication error |
| 13 | <i>Er8</i> | A/D converter error | 35 | <i>Rr3</i> | Error code 3 for specific user application | 57 | --- | No alarm |
| 14 | <i>Er9</i> | Speed not agreed | 36 | <i>Rr4</i> | Error code 4 for specific user application | 58 | --- | No alarm |
| 15 | <i>ErA</i> | UPAC error | 37 | <i>Rr5</i> | Error code 5 for specific user application | 59 | --- | No alarm |
| 16 | <i>ErB</i> | Inter-inverter communications link error | 38 | <i>Rr6</i> | Error code 6 for specific user application | 60 | --- | No alarm |
| 17 | <i>L n</i> | Power supply phase loss | 39 | <i>Rr7</i> | Error code 7 for specific user application | 61 | <i>OPL</i> | Output phase loss |
| 18 | <i>LU</i> | Undervoltage | 40 | <i>Rr8</i> | Error code 8 for specific user application | 62 | <i>S iF</i> | Functional safety card error |
| 19 | <i>nrB</i> | NTC thermistor wire break error | 41 | <i>Rr9</i> | Error code 9 for specific user application | 63 | <i>SrF</i> | Functional safety card error |
| 20 | <i>OL</i> | Overcurrent | 42 | <i>RrA</i> | Error code A for specific user application | 64 | --- | No alarm |
| 21 | <i>OH1</i> | Heat sink overheat | 43 | <i>RrB</i> | Error code B for specific user application | | | |


Type [15]: Alarm history



Type [16]: Percentage




Type [21]: Operation status



Type [26]: DIOB option input state

Type [27]: DIOB option output state



Type [28]: Inverter capacity

| Code | Inverter capacity | Code | Inverter capacity | Code | Inverter capacity | Code | Inverter capacity | Code | Inverter capacity |
|------|-------------------|------|-------------------|------|-------------------|------|-------------------|------|-------------------|
| 0 | 0.05 | 8 | 5.5 | 16 | 45 | 24 | 220 | 32 | 630 |
| 1 | 0.1 | 9 | 7.5 | 17 | 55 | 25 | 250 | 33 | 710 |
| 2 | 0.2 | 10 | 11 | 18 | 75 | 26 | 280 | 34 | 800 |
| 3 | 0.4 | 11 | 15 | 19 | 90 | 27 | 315 | | |
| 4 | 0.75 | 12 | 18.5 | 20 | 110 | 28 | 355 | | |
| 5 | 1.5 | 13 | 22 | 21 | 132 | 29 | 400 | | |
| 6 | 2.2 | 14 | 30 | 22 | 160 | 30 | OTHER | | |
| 7 | 3.7 | 15 | 37 | 23 | 200 | 31 | 500 | | |


Type [29]: Inverter model (common to entire Fuji inverter system)

The number is fixed to 1313h or 1314h for the FRENIC-VG.

200 V system: fixed to 1313h

400 V system: fixed to 1314h

Type [31]: Speed



Data (0 to ±20,000) → (0 to ±24,000 × r/min): (Data) × Nmax/20,000 conversion



(Example) When the maximum speed is Nmax = 1,500 r/min,

- If you want to direct a speed command of 1,000 r/min,
Specify a data of $\frac{1,000}{1,500} \times 20,000 \rightarrow \underline{13,333}$


- If the read out data is 3,500,
You can determine the speed is $\frac{1,500}{20,000} \times 3,500 \rightarrow 262.5$ r/min

Type [32]: Operation commands, [33]: Y1 to Y18

This type is the same as S06 and S07.



Type [34]: Communication error codes



Description of alarms in the communication through the link (RS-485, T-Link, SX-bus, E-SX bus). The following data is set to the monitor data M26 according to the communication status. The codes listed in the column "KEYPAD panel display" is displayed on the KEYPAD panel as a communication error .

| M26 (HEX.) | KEYPAD panel display | Communication error name | Description | |
|------------|----------------------|---|--|---|
| 0 (0H) | - | No communication error | Normal communication A data is written to an unused address of the function code (writing to address out of the specified range is defined separately). Data is read from missing function code address in the middle of continuous read. The data will be "0000". Writing to the S area while link operation is disabled. The data will not be reflected and cause no error. A data out of range is written to the S area. The data is written after adjusted to the upper or the lower limit. Access from another link or the KEYPAD panel occurs during data writing (EEPROM other than the S area is accessed). Writing to operation data (such as tuning or initialization) during multiple function codes are being written once through the link. The inverter decides that the procedure is canceled and continues the writing. Writing to/reading from option function codes that are not displayed on the KEYPAD panel. | |
| 1 to 32 | - | - | - | |
| 33 to 70 | - | Not used | | |
| 71 (47H) | 04 | Checksum error, CRC error | Software error | Checksum value or CRC value does not match. |
| 72 (48H) | 05 | Parity error | Hardware error | Parity does not match. |
| 73 (49H) | 06 | Others (such as overrun, framing) | | Physical (reception) errors other than above. |
| 74 (4AH) | 01 | Format error | Incorrect format. Characters requesting transmission are incorrect. Characters terminating transmission are not in the specified order. | |
| 75 (4BH) | 01 | Command error | Codes other than the specified commands are transmitted. | |
| 76 (4CH) | 07 | Link priority error | Writing to the S area through RS-485 while a link option is installed. Writing to the S area through a link with lower priority while multiple link options are installed. | |
| 77 (4DH) | 07 | No right to write function code data | Not used | |
| 78 (4EH) | 02 | Function code error | Access to a data out of the address range of the function codes (such as access to a data over F80). Writing data over 16 words. | |
| 79 (4FH) | 07 | Error on writing to write-disabled data | Write-disabled function codes (Read-only data or the M area). Function codes write-disabled during operation. Writing through the link to data out of the S area in "write-disabled through link" mode. Note that F00 or "Write enable for KEYPAD" cannot protect from writing through the link. Function codes that cannot be written through the link (link function codes: H31 to 40). Writing to M1 function code (P) area when motor parameters are protected. Writing through the link in the copy mode operation of the KEYPAD panel. | |
| 80 (50H) | 03 | Data | Written data is out of the setting range in the area other than the S area. | |
| 81 (51H) | 07 | Error during writing | Another writing request comes from the same source while writing function code data (EEPROM other than the S area is accessed). | |

Note: The alarm codes 1 to 32 constitute a code system specific to the FRENIC-VG different from the assignment for the general-purpose inverters.


The communication error codes 71 to 81 are common to the different models. Note that some causes of alarm are specific to models.

The KEYPAD panel does not display raw communication error codes but the values in the "KEYPAD panel display" column in the table above.

The KEYPAD panel displays "**" when it receives data that does not have a corresponding "KEYPAD panel display" in the table above.

Type [35]: X function normally open/closed

Type [36]: Y function normally open/closed




Type [40 to 99]

These types are reserved for the manufacturer. Users can consider these types as type [0] to use.


Type [82]: M1 Motor selection

| Code | kW display | HP display | Code | kW display | HP display | Code | kW display | HP display |
|------|------------|------------|------|------------|------------|------|------------|------------|
| 0 | 00: 0.75-2 | 00: 1-2 | 17 | 17: 3.7-4 | 17: 5-4 | 34 | 34: 200-4 | 34: 250-4 |
| 1 | 01: 1.5-2 | 01: 2-2 | 18 | 18: 5.5-4 | 18: 7.5-4 | 35 | 35: 220-4 | 35: 300-4 |
| 2 | 02: 2.2-2 | 02: 3-2 | 19 | 19: 7.5-4 | 19: 10-4 | 36 | 36: P-OTR | 36: P-OTR |
| 3 | 03: 3.7-2 | 03: 5-2 | 20 | 20: 11-4 | 20: 15-4 | 37 | 37: OTHER | 37: OTHER |
| 4 | 04: 5.5-2 | 04: 7.5-2 | 21 | 21: 15-4 | 21: 20-4 | 38 | 38: 30-2A | 38: 40-2A |
| 5 | 05: 7.5-2 | 05: 10-2 | 22 | 22: 18.5-4 | 22: 25-4 | 39 | 39: 55-2A | 39: 75-2A |
| 6 | 06: 11-2 | 06: 15-2 | 23 | 23: 22-4 | 23: 30-4 | 40 | 40: 75-2A | 40: 100-2A |
| 7 | 07: 15-2 | 07: 20-2 | 24 | 24: 30-4 | 24: 40-4 | 41 | 41: 90-2A | 41: 125-2A |
| 8 | 08: 18.5-2 | 08: 25-2 | 25 | 25: 37-4 | 25: 50-4 | 42 | 42: 30-4A | 42: 40-4A |
| 9 | 09: 22-2 | 09: 30-2 | 26 | 26: 45-4Y | 26: 60-4Y | 43 | 43: 55-4A | 43: 75-4A |
| 10 | 10: 30-2 | 10: 40-2 | 27 | 27: 45-4S | 27: 60-4S | 44 | 44: 75-4A | 44: 100-4A |
| 11 | 11: 37-2 | 11: 50-2 | 28 | 28: 55-4 | 28: 75-4 | 45 | 45: 90-4A | 45: 125-4A |
| 12 | 12: 45-2Y | 12: 60-2Y | 29 | 29: 75-4 | 29: 100-4 | 46 | 46: 110-4A | 46: 150-4A |
| 13 | 13: 45-2S | 13: 60-2S | 30 | 30: 90-4 | 30: 125-4 | 47 | 47: 132-4A | 47: 175-4A |
| 14 | 14: 55-2 | 14: 75-2 | 31 | 31: 110-4 | 31: 150-4 | 48 | 48: 160-4A | 48: 200-4A |
| 15 | 15: 75-2 | 15: 100-2 | 32 | 32: 132-4 | 32: 175-4 | 49 | 49: 200-4A | 49: 250-4A |
| 16 | 16: 90-2 | 16: 125-2 | 33 | 33: 160-4 | 33: 200-4 | 50 | 50: 220-4A | 50: 300-4A |


Type [100]: EN Input terminals



Type [101]: (Power)





Type [102]: (Cause of alarm)




Light alarm codes


| Code | Display | Description | Code | Display | Description | Code | Display | Description |
|------|---------|---------------------------------|------|---------|-------------------------------------|------|---------|--|
| 0 | --- | No alarm | 30 | --- | No alarm | 60 | --- | No alarm |
| 1 | --- | No alarm | 31 | --- | No alarm | 61 | --- | No alarm |
| 2 | --- | No alarm | 32 | --- | No alarm | 62 | --- | No alarm |
| 3 | --- | No alarm | 33 | --- | No alarm | 63 | --- | No alarm |
| 4 | --- | No alarm | 34 | --- | No alarm | 64 | --- | No alarm |
| 5 | --- | No alarm | 35 | --- | No alarm | 65 | --- | No alarm |
| 6 | --- | No alarm | 36 | --- | No alarm | 66 | --- | No alarm |
| 7 | --- | No alarm | 37 | --- | No alarm | 67 | --- | No alarm |
| 8 | --- | No alarm | 38 | --- | No alarm | 68 | --- | No alarm |
| 9 | Er4 | Network error | 39 | --- | No alarm | 69 | --- | No alarm |
| 10 | Er5 | RS-485 communications error | 40 | --- | No alarm | 70 | --- | No alarm |
| 11 | --- | No alarm | 41 | --- | No alarm | 71 | --- | No alarm |
| 12 | --- | No alarm | 42 | --- | No alarm | 72 | --- | No alarm |
| 13 | --- | No alarm | 43 | --- | No alarm | 73 | --- | No alarm |
| 14 | Er9 | Speed mismatch | 44 | --- | No alarm | 74 | --- | No alarm |
| 15 | --- | No alarm | 45 | --- | No alarm | 75 | --- | No alarm |
| 16 | --- | No alarm | 46 | ArE | E-SX bus tact synchronization error | 76 | --- | No alarm |
| 17 | --- | No alarm | 47 | ArF | Error code F for particular users | 77 | --- | No alarm |
| 18 | --- | No alarm | 48 | --- | No alarm | 78 | --- | No alarm |
| 19 | nrb | NTC thermistor wire break error | 49 | --- | No alarm | 79 | --- | No alarm |
| 20 | --- | No alarm | 50 | --- | No alarm | 80 | --- | No alarm |
| 21 | --- | No alarm | 51 | Err | Mock alarm | 81 | LiF | Life time early warning |
| 22 | OH2 | External alarm | 52 | LOC | Start delay | 82 | OH | Heat sink overheat early warning |
| 23 | --- | No alarm | 53 | dFA | DC fan locked | 83 | OL | Overload early warning |
| 24 | OH4 | Motor overheat | 54 | --- | No alarm | 84 | MOH | No alarm |
| 25 | OL1 | Motor 1 overload (M1) | 55 | --- | No alarm | 85 | MOL | No alarm |
| 26 | OL2 | Motor 2 overload (M2) | 56 | --- | No alarm | 86 | --- | No alarm |
| 27 | OL3 | Motor 3 overload (M3) | 57 | --- | No alarm | 87 | BaT | Battery life expired |
| 28 | --- | No alarm | 58 | --- | No alarm | 88 | SnF | Safety printed circuit board light alarm |
| 29 | --- | No alarm | 59 | --- | No alarm | | | |

Type [125]: Control output 1Type [126]: Control output 2


Type [127]: Control output 3




Type [128]: Control output 4



Type [129]: Control output 5




Type [130]: Control output 6






*Output from bits 0 to 3 is available in the ROM version H1/2 0020 or later.

Type [133]: Control input 1




Type [134]: Control input 2




Type [135]: Control input 3Type [136]: Control input 4

Type [137]: Control input 5



Type [138]: Control input 6




Type [139]: Control input 7


Type [140]: Control input 8

In preparation

Type [141]: Operation status 2(a)




Type [142]: Operation status 2(b)




(*1) Current limit, voltage limit and torque limit are the same as information in Type [21].


Type [143]: Calendar clock [Year/month]




Type [144]: Calendar clock [Day/hour]



Type [145]: Calendar clock [Minute/second]



Type [146]: DIOA Input/output status



4.3 Details of Function Codes

4.3.1 F codes (Fundamental Functions)

| | |
|------------|------------------------|
| F00 | Data Protection |
|------------|------------------------|

F00 specifies whether to protect setting data from accidentally getting changed from the keypad. When the data protection is enabled, the "DATA PRTC" displays on the LCD monitor.

This data protection applies to access to data from the keypad. The data protection for access via the communications link (RS-485, T-Link, SX-bus, fieldbus, etc.) can be defined with H29.

F 0 0 D A T A P R T C

Data = 0: Allow data change. 0: CHGOK
 1: Protect data. 1: PROTECT

Setting procedure

- 0 → 1: Press the and keys simultaneously to change the value from 0 to 1, then press the key to establish the change.
- 1 → 0: Press the and keys simultaneously to change the value from 1 to 0, then press the key to establish the change.

| | |
|------------|-------------------------|
| F01 | Speed Command N1 |
|------------|-------------------------|

F01 sets a command source that specifies a reference speed.

Using the terminal command *N2/NI* assigned to any digital input terminal switches a command source between the Speed command N1 specified by F01 and Speed command N2 specified by C25. For details about switching, refer to the *N2/NI* in the descriptions of E01 through E13 (data = 11).

F 0 1 S P D C M D 1

| | |
|---|--------------------|
| Data = 0: Enable the and keys on the keypad. | <u>0: KEYPAD</u> |
| 1: Enable the voltage input to terminal [12] (0 to ±10 VDC) | <u>1: 12INPUT</u> |
| 2: Enable the voltage input to terminal [12] (0 to +10 VDC) | <u>2: 12(ABS)</u> |
| 3: Enable UP and DOWN terminal commands*1 (Initial value: 0) | <u>3: U/D(0)</u> |
| 4: Enable UP and DOWN terminal commands*1 (Initial value: Last value) | <u>4: U/D(BEF)</u> |
| 5: Enable UP and DOWN terminal commands*1 (Initial value: CRP1, CRP2) | <u>5: U/D(CRP)</u> |
| 6: Enable a DIA card | <u>6: DIA CARD</u> |
| 7: Enable a DIB card | <u>7: DIB CARD</u> |
| 8: Enable the reference speed setting to terminal [Ai1] to [Ai4]. (0 to ±10 VDC)*2 | <u>8: N-REFV</u> |
| 9: Enable the current input to terminal [Ai2] (4 to 20 mADC)*3 | <u>9: N-REFC</u> |


*1 The **UP** and **DOWN** should be assigned to digital input terminals (X terminals) with E01 to E13 (data = 17 and 18) beforehand. For the initial and last values of the UP/DOWN function, refer to **UP** and **DOWN** in function codes E01 to E13.

*2 The **N-REFV** (Main speed setting) should be assigned to one of analog input terminals ([Ai1] to [Ai4]) with E49 to E52 (data = 25) beforehand.

*3 Exclusive to terminal [Ai2]. The **N-REFC** (Current input speed setting) should be assigned to analog input terminal [Ai2] with E50 (data = 26) beforehand.

Check the specified speed command with Menu #3 "Operation status monitor" on the keypad.

Shown at the right is the OPR MTR screen that appears when the inverter is running at 1200 r/min.



| | |
|------------|-------------------------|
| F02 | Operation Method |
|------------|-------------------------|

F02 selects a command source that specifies a run command.

F 0 2 O P R M E T H O D

- Data = 0: Enable the (FWD), (REV), and (STOP) keys on the keypad (Local mode). 0: KEYPAD
 1: Enable input terminal commands *FWD* and *REV* (Remote mode). 1: FWD, REV


The remote and local modes can be switched also by pressing the and keys simultaneously. This key operation changes the setting of F02.

When H30 (Communications link operation) = "2" or "3," link operation has priority over the setting of F02.

When F02 = 0, entering a run command from the keypad turns the green LED lamp ON. When F02 = 1, to check the command status, use Menu #4 "I/O Checking" (REM screen) on the keypad and check that the box of the current input (*FWD* or *REV*) appears black (■).

Shown at the right is the I/O screen that appears when *FWD* is externally turned ON.

Note that the COMM screen in Menu #4 "I/O Checking" shows commands entered via the communications link. It has no relationship with terminal block commands.



| | |
|------------|-------------------------|
| F03 | Maximum Speed M1 |
|------------|-------------------------|

F03 specifies the maximum speed (r/min) for motor 1. Specifying the maximum speed exceeding the rating of the equipment driven by the inverter may damage the motor or the machinery. Make sure that the maximum speed setting matches the equipment rating.

The ratio between the inverter rated speed and the maximum speed should be 1 : 6 or below.

F 0 3 M 1 — M A X

Data setting range: 50 to 30000 (r/min)

| |
|--|
| ⚠ CAUTION |
| <p>Settings of some function codes (relating to the acceleration/deceleration time and the ASR P gain of analog speed setting) are based on the maximum speed (F03). Changing the maximum speed in the already adjusted system in order to decrease the top speed may cause the inverter to malfunction.</p> <p>It is therefore necessary to change the ASR P gain (F61/C40/C50/C60) in proportion to the change of the F03 setting. When F03 = 1500 and F61 = 10.0, for example, changing the F03 setting from 1500 to 150 will cause hunting. This change means that the ASR P gain is multiplied by 10 (1500/150), so be sure to change the F61 setting from 10.0 to 1.0.</p> |

| | |
|------------|-----------------------|
| F04 | Rated Speed M1 |
|------------|-----------------------|

F04 specifies the rated speed in the constant torque range of motor 1. Set the rated speed printed on the nameplate labeled on the motor.

Selecting a VG-dedicated motor with P02 automatically configures the F04 data and does not allow it to be changed. Selecting the "P-OTR" with P02 does not allow the F04 data to be changed.

The ratio between the inverter rated speed and the maximum speed should be 1 : 6 or below.

F 0 4 M 1 — N r

Data setting range: 50 to 30000 (r/min)

| | |
|------------|-------------------------|
| F05 | Rated Voltage M1 |
|------------|-------------------------|

F05 specifies the rating of the output voltage to be supplied to motor 1. Set the rated voltage printed on the nameplate labeled on the motor.

Selecting a VG-dedicated motor with P02 automatically configures the F05 data and does not allow it to be changed. Selecting the "P-OTR" with P02 does not allow the F05 data to be changed.

| | | | | | | | | | | | | | |
|---|---|---|---|---|---|---|---|--|--|--|--|--|--|
| F | 0 | 5 | M | 1 | - | V | r | | | | | | |
|---|---|---|---|---|---|---|---|--|--|--|--|--|--|

Data setting range: 80 to 999 (V)

| | |
|------------|----------------------------|
| F07 | Acceleration Time 1 |
|------------|----------------------------|

| | |
|------------|----------------------------|
| F08 | Deceleration Time 1 |
|------------|----------------------------|

F07 specifies the acceleration time, the length of time required for the speed to increase from "0" to the maximum speed. F08 specifies the deceleration time, the length of time required for the speed to decrease from the maximum speed down to "0."



The actual acceleration/deceleration time is calculated based on the maximum speed (F03, A06, A106). See the expression given below.

$$\text{Actual acceleration/deceleration time} = \text{F07/F08 setting} \times \frac{\text{Reference speed}}{\text{Maximum speed (F03, A06, A106)}}$$

If the S-curve acceleration/deceleration is selected, the actual acceleration/deceleration time becomes longer than the specified time. For details, refer to the description of F67.

| | | | | | | | | | | |
|---|---|---|---|---|---|---|---|---|---|---|
| F | 0 | 7 | A | C | C | T | I | M | E | 1 |
| F | 0 | 8 | D | E | C | T | I | M | E | 1 |

Data setting range: 0.01 to 99.99 (s)
 100.0 to 999.9 (s)
 1000 to 3600 (s)



Writing data to S08 (Acceleration time) or S09 (Deceleration time) via the communications link (RS-485, T-Link, SX-bus, or fieldbus) automatically copies the data to F07 or F08 as is, respectively.

| | |
|------------|---|
| F10 | M1 Electronic Thermal Overload Protection (Select motor characteristics) |
| F11 | M1 Electronic Thermal Overload Protection (Detection level) |
| F12 | M1 Electronic Thermal Overload Protection (Thermal time constant) |

F10 through F12 specify the thermal characteristics of the motor (motor rotation, output current and running time) for its electronic thermal overload protection that is used to detect overload conditions of the motor inside the inverter. This function protects motor M1. When a dedicated motor for the FRENIC-VG is used, disable this function (no setting is required).

F 1 0 M 1 - E O L - S E L

- Select motor characteristics

When a dedicated motor for the FRENIC-VG is used, connecting an NTC thermistor built in the motor with the FRENIC-VG activates the motor overheat protection so that no electronic thermal overload protection is required. Disable this function.

If the motor overheat protection by an NTC thermistor is not available, use F10 to select the motor cooling mechanisms (shaft-driven cooling fan or separately powered cooling fan) to specify its characteristics.

When 150% of the current specified by F11 flows for the time specified by F12, the inverter activates the motor overload protection and issues an alarm \overline{OL} .

- Data = 0: Disable (For a dedicated motor for the FRENIC-VG. Protected by an NTC thermistor)
- 1: Enable (For a general-purpose motor with shaft-driven cooling fan)
- 2: Enable (For a Fuji inverter-driven motor with separately powered cooling fan)

F 1 1 M 1 - E O L - L V L


- Detection level

F11 specifies the level (current value) at which the electronic thermal overload protection becomes activated.

In general, set the F11 data to 1.0 to 1.1 times of the M1 rated current specified by P04.

By factory default, F11 data is set to the rated current of the Fuji general-purpose motor. To connect any other motor, change the setting.

- Data setting range: 0.01 to 99.99 (A)
- 100.0 to 999.9 (A)
- 1,000 to 2,000 (A)



F 1 2 M 1 — E O L — T C

- Thermal time constant

F12 specifies the thermal time constant of the motor. If the current of 150% of the overload detection level specified by F11 flows for the time specified by F12, the electronic thermal overload protection becomes activated to detect the motor overload.

The thermal time constant for general-purpose motors including Fuji motors is approx. 5 minutes for motors of 22 kW or below and 10 minutes for motors of 30 kW or above by factory default


Data setting range: 0.5 to 75.0 (min)

(Example) When the F12 data is set at 5 minutes

As shown at the right, the electronic thermal overload protection is activated to detect an alarm condition (alarm code $\overline{L} /$) when the output current of 150% of the overload detection level (specified by F11) flows for 5 minutes, and 120% for approx. 13 minutes.

Since the current flowing through a motor is not usually constant, the average current in a certain period is used to start the timer for the electronic thermal overload protection.

Note: In the case of the load which is repeatedly and very frequently driven by a motor, the motor current fluctuates largely so that it may enter the short-time rating (100% or more) range of the motor repeatedly. If it happens, refer to Chapter 9, Section 9.1.3.4 "Calculating the RMS rating of the motor" to calculate the equivalent effective current and limit this value under the rated current of a motor (in the case of a separately-powered cooling fan).



F14 Restart Mode after Momentary Power Failure (Mode selection)

F14 specifies the action to be taken by the inverter such as trip and restart in the event of a momentary power failure. You can select a function for detecting power failure and activating protective operation (alarm output, alarm display, inverter output cutoff) for undervoltage or an automatic restart function without stopping a coasting motor after the supply voltage recovery.









See the following table for more information on this function.

The restart mode related function codes include H13 to H17 (Restart Mode after Momentary Power Failure, Wait time, Decrease rate in speed, Continuous running level, Run command self-hold setting and Run command self-hold time), H09 (Starting Mode, Auto search), and E01 (Terminal [X1] Function *STM*, data = 26 "Enable auto search for idling motor speed at starting"). Also be familiar with these functions.

To restart the inverter after momentary power failure under V/f control, enable the overcurrent suppression (H58 = 1).

F 1 4 R E S T A R T

| Data for F14 | Function name | Operation on power failure | Operation on power recovery | |
|--------------|--|--|---|--|
| 0 | Inactive (immediate inverter trip) | If undervoltage is detected, the protective function $\underline{\underline{L}}/\underline{\underline{L}}'$ is activated and output is turned off. | The inverter does not restart. | Enter commands for resetting the protective function and starting operation. |
| 1 | Inactive (inverter trip on recovery) | If undervoltage is detected, the protective function is not activated and output will be turned off. | The protective function $\underline{\underline{L}}/\underline{\underline{L}}'$ is activated, but the operation does not restart, | |
| 2 | Inactive (inverter trip after deceleration to a stop on power failure) | When the holding DC level (H15) "Restart after momentary power failure" is reached, the inverter decelerates a motor to stop. The DC voltage of the main circuit sharpens the deceleration slope so that the undervoltage protective function $\underline{\underline{L}}/\underline{\underline{L}}'$ is not activated. The inverter collects the inertia energy of the load and controls the motor until it stops, then the undervoltage protective function $\underline{\underline{L}}/\underline{\underline{L}}'$ is activated. If the amount of inertia energy from the load is small, and the undervoltage level is achieved during deceleration, the undervoltage protective function $\underline{\underline{L}}/\underline{\underline{L}}'$ is then activated. | The protective function is activated, but the operation does not restart, | |
| 3 | Active (continuous operation) | When the holding DC level is reached, energy is collected from the inertia amount of the load to extend the operation continuation time. If undervoltage is detected, the protective function is not activated, but the output is turned off. | Operation restarts automatically. For a power recovery during a continued operation, the inverter accelerates to the original speed. If the inverter detected an undervoltage, operation automatically restarts at the speed when the undervoltage is detected. | |
| 4 | Active (restart at the speed on power failure) | If undervoltage is detected, the protective function is not activated and the output is turned off. | <u>Vector control & H09 ≥ 1</u> The inverter performs auto search for idling motor speed and restarts running the motor at the same speed as the motor. | |
| | | | <u>V/f control or H09 = 0</u> The inverter restarts running the motor at the speed at which the power failure occurred. | |
| 5 | Active (restart at the starting speed) | If undervoltage is detected, the protective function is not activated and the output is turned off. | <u>Vector control & H09 ≥ 1</u> The inverter performs auto search for idling motor speed and restarts running the motor at the same speed as the motor. | |
| | | | <u>V/f control or H09 = 0</u> The automatically restarts running the motor at 0 r/min. | |




F17 Gain (for terminal [12] input)

F17 specifies the proportion to the reference speed value (analog input) from control terminal [12]. The reference speed is limited to 110% (1.1 times) of \pm maximum speed (F03).

Note: The reference speed value is finally limited by the speed limiter (F76, F77, F78).

F 1 7 G A I N (1 2)

Data setting range: 0.0 to 200.0 (%)




F18 Bias (for terminal [12] input)

F18 specifies a bias speed to be added to the reference speed value (analog input) from control terminal [12]. The bias speed is limited to \pm maximum speed (F03). The reference speed is limited to 110% (1.1 times) of \pm maximum speed (F03).

Note: The reference speed value is finally limited by the speed limiter (F76, F77, F78).

F 1 8 B I A S (1 2)

Data setting range: 0 to 30,000 (r/min)



| | |
|------------|--|
| F20 | DC Braking (Braking starting speed) |
| F21 | DC Braking (Braking level) |
| F22 | DC Braking (Braking time) |

If you apply a DC voltage to an operating motor (set the output frequency to zero), the motor generates a braking torque to decelerate to stop. This is referred to as DC brake and these functions specify the setting. If a motor does not stop within a DC braking time, the motor will coast. You can assign a digital input **DCBRK** to start the DC brake.

F 2 0 D C B R K N

- Starting speed

Set the starting speed of the DC brake during decelerating.

Setting range: 0 to 3,600 (r/min)

F 2 1 D C B R K L V L

- Braking level

Sets the output current level of the DC braking. You can specify as a percentage of the inverter rated output (100%) with a minimum unit of 1%.

Setting range: 0 to 100 (%)

F 2 2 D C B R K t

- Braking time


Sets the operation time for the DC braking

Setting range: 0.0: Inactive
0.1 to 30.0 (s)

DC brake operation

The DC brake is applied for a specified time after the speed reaches the starting speed level on deceleration of a motor. The inverter running (RUN) signal maintains ON during the DC braking and the inverter stoppage (STOP) signal turns on when the DC brake is activated.

Specify the slip frequency conversion speed level at F20. If a very large value is specified, the control becomes unstable, possibly causing overvoltage protection being activated.



⚠ CAUTION

The brake function of the inverter does not provide a mechanical hold.
You may be injured.

| | |
|-----|-------------------------------|
| F23 | Starting Speed (Speed) |
| F24 | Starting Speed (Holding time) |

You can set a starting speed to assure a starting torque.

Under vector control

This function acts to release a mechanical brake. If you enter the operation command after setting the starting speed to 0 r/min, the brake will be released after the magnetic-flux and the torque reach a certain level. See E15 to E27 "Y function selection" for brake release signal.

Under V/f control


You can accelerate a motor after operating the motor at a starting speed for a certain period to establish the magnetic-flux on start.

F 2 3 S T A R T N

- Starting speed
 Sets the rotation at start.
 Setting range: 0.0 to 150.0 (r/min)

F 2 4 H L D S T A R T t

- Holding time
 Sets the period for maintaining the starting time.
 Setting range: 0.00 to 10.00 (s)



Note: The holding time is not activated when you switch between forward and reverse rotation. The acceleration time does not include the holding time.

F26**Motor Sound (Carrier frequency)**

F26 controls the carrier frequency to reduce an audible noise generated by the motor or electromagnetic noise from the inverter itself, avoid resonance with the machinery, and reduce the leakage current from the output (secondary) circuit.

| | | | | | | | | | | |
|----------|----------|----------|----------|----------|----------|----------|----------|----------|----------|----------|
| F | 2 | 6 | M | T | R | S | O | U | N | D |
|----------|----------|----------|----------|----------|----------|----------|----------|----------|----------|----------|

Data setting range: 2 to 15 (kHz) (The upper limit differs depending upon the capacity and current rating (HD/LD/MD).)

| | |
|------------------------------------|----------------|
| Carrier frequency | 2 to 15 kHz |
| Motor sound noise emission | High to low |
| Ripples in output current waveform | Large to small |
| Leakage current | Low to high |
| Electromagnetic noise emission | Low to high |

Note 1: Specifying a too low carrier frequency causes the output current waveform to have a large amount of ripples (harmonics components). As a result, the motor loss increases, causing the motor temperature to rise. Specifying a high carrier frequency increases the motor loss, causing the inverter temperature to rise.

Note 2: When F26 = 9, 8 kHz of the carrier frequency applies, when F26=11, 10 kHz, when F26 = 13 or 14, 12 kHz.

Note 3: Running a permanent magnet synchronous motor (PMSM) at a low carrier frequency may heat the permanent magnet due to the output current harmonics, resulting in demagnetization. When decreasing the carrier frequency setting, be sure to check the allowable carrier frequency of the motor.


F36 **30RY Drive Mode**

F36 selects whether to activate (excite) the alarm output relay (30RY) in a normal state or in an abnormal state.

F 3 6 R Y M O D E

Data setting range: 0, 1

| Data for F36 | Normal state | Abnormal state |
|--------------|-----------------------------|-----------------------------|
| 0 | 30A-30C: OFF 30B-30C: ON | 30A-30C: ON 30B-30C: OFF |
| 1 | 30A-30C: ON 30B-30C: OFF | 30A-30C: OFF 30B-30C: ON |



Note When F36 = 1, the contacts between 30A and 30C are connected after the inverter control voltage is established (about five seconds after turning on). Since the relay is excited in a normal state, the relay can detect a wire break in the alarm output line.

F37 **Stop Speed (Speed)**

F38 **Stop Speed (Detection mode)**

F39 **Stop Speed (Zero speed holding time)**

F 3 7 S T O P N

- Stop speed

F37 specifies the stop speed.

Data setting range: 0.0 to 150.0 (r/min)

F 3 8 D E T S I G N A L

- Detection mode

F38 specifies whether to detect the stop speed with the reference speed (Reference speed 4 (ASR input)) or detected speed (Detected speed 1).

Data setting range: 0: Detected speed
1: Reference speed

However, under V/f control or vector control without speed sensor, the reference speed only takes effect irrespective of the F38 setting.

Under V/f control, the inverter stops its output when it detects the output frequency (M05), irrespective of the F38 setting.

F 3 9 H L D S T O P t


- Zero speed holding time

Data setting range: 0.00 to 10.00 (s)

The **RUN** signal ("Inverter running") will turn off at the end of the Zero speed holding time for continuing operation after the motor speed reaches the stop speed level.

This function is used to adjust the timing to apply a mechanical brake.

Under V/f control or vector control without speed sensor, however, this function is invalid. Even under vector control, when H41 (Torque command source) \neq 0 or H42 (Torque current command source) \neq 0, this function is invalid.



| | |
|------------|------------------------------|
| F40 | Torque Limiter Mode 1 |
| F41 | Torque Limiter Mode 2 |

F40 specifies torque limiter mode 1 in which the torque limiter, power limiter or torque current limiter can be selected. In the mode, it is also possible to disable those limiters. Turning ON the terminal command **F40-CCL** ("Cancel F40"), which is functionally equivalent to F40 set at "0," also disables those limiters.

F 4 0 T L I M M O D E 1

Data setting range: 0: Disable limiters

1: Enable torque limiter

2: Enable power limiter

3: Enable torque current limiter


Under V/f control, the torque current limiter is enabled irrespective of whether F40 is set at 1, 2 or 3.

Background information

The right graph shows a continuous permissible torque (not short-time rating) for forward rotation driving in the speed control range (0 to Rated speed to 200%). The control generally reduces magnetic-flux above the rated speed to extend the speed control range. The reduced output current in the right graph shows that the control reduces the current corresponding to the amount of the reduced magnetic-flux. This reduces the increase of the induced motor voltage to restrain the increase of the voltage output proportional to the speed.


Under the rated speed, the rated torque is effective. Since the torque is proportional to the product of the exciting current and the torque current, the current is limited in practice.

Over the rated speed, since the inverter capacity (output: power) restricts the torque, the output torque decreases in inverse proportion to the speed. The torque limiter condition switches depending upon whether the speed is less than or exceeds the rated speed.



You can use the "Operation monitor" of the "I/O check" of the KEYPAD panel to review the state of the torque limiter, the power limiter and torque current limiter status

■ TL in the right figure shows the torque limiter is active. When the torque limiter is not applied, the display turns to □ TL. You can also read the function code M14 "Operation status" through the link to confirm the state.



F41 specifies torque limiter mode 2 in which the configuration of target quadrants can be selected.

F 4 1 T L I M M O D E 2

Data setting range: 0: Level 1 to all four quadrants
 1: Level 1 to driving, Level 2 to braking
 2: Level 1 to upper limit, Level 2 to lower limit
 3: Level 1/Level 2 (switchable) to all four quadrants

The next section describes the actual limitations determined by the values set at F40 and F41. For level 1 and level 2 of each limitation, see the descriptions of F42 and F43.

Under V/f control, setting F41 at "3" produces the same result as "0."

Description and application of the limiter mode 1


| Limiter type | Limiter description | Application |
|--|---|---|
| Disable limiters F40 = 0 or F40-CCL = ON | Limits the torque by the maximum output current (One-minute, ten-second ratings) in the entire speed limiting range. $\tau (\text{Torque \%}) = \frac{\sqrt{I_{\max}^2 - I_m^2 - \left(I_r \times \frac{\text{Iron loss coefficient}}{100}\right)^2}}{I_r} \times 100(\%)$ (Ex.) In the case of HD-mode inverters of 30 kW, 200 V, with FRENIC-VG dedicated motor, the maximum driving torque is 214%. I _{max} (Short-time rated current) = 238 (A) I _m (Exciting current: P08) = 53.42 (A) I _t (Torque current: P09) = 108.18 (A) Iron loss coefficient: P12 = 2.50% $\tau (\text{Torque \%}) = \frac{\sqrt{238^2 - 53.42^2 - \left(\frac{108.18 \times 2.50}{100}\right)^2}}{108.18} \times 100(\%)$ $\approx 214(\%)$ | Use for the shortest acceleration/deceleration with the inverter. Note: Check the operation sequence to avoid activating the protective function due to the inverter over load or the motor overload. For braking, check if disabled limiters do not cause any problems when you select braking resistor capacity for the operation sequence if you use power regenerative devices (RHR or RHC series) or connect braking resistors. |
| Enable torque limiter F41 = 1 | Limits the output of the speed control unit (ASR). Restrain the torque (N·m) in terms of the percentage of the rated torque of a motor assumed as 100%. The maximum output current of the inverter may limit the torque in the constant output range depending on the set value for the limiter. | Use for constant torque control involving speed control and torque limiting such as winding or tension control. |
| Enable power limiter F41 = 2 | Limits the torque by the power in the entire speed control range. Restrain the output capacity (power: kW) in terms of the percentage of the rated capacity of an inverter assumed as 100%. The maximum output current of the inverter may limit the torque in the constant torque range depending on the set value for the limiter. | Use for limiting braking torque such as stopping by braking capacity (power). Use for braking that uses the capacity of a braking resistor. Also use for stopping that uses only the inverter loss (kW) when you do not use an external braking resistor (DB). |
| Enable torque current limiter F41 = 3 | Limits the torque in the constant torque range and limits the power in the constant output range. Restricts the torque current command in terms of the percentage of the rated torque current assumed as 100%. Since this control limits the torque current to a constant level, the control reduces the magnetic-flux in the constant output range, resulting in reducing torque accordingly. | Enables a limiter restricting below the short-time rated torque. Use when you limit the output torque for the motor temporarily. |

See the following pages for detailed application examples.

(1) Disable limiters

| Code | Set value | Description |
|------|------------|------------------|
| F40 | 0 | Disable limiters |
| F41 | 0, 1, 2, 3 | Not effective |

- Limits the torque by the maximum output current (one-minute, three-second ratings) in the entire speed limiting range. Use for the shortest acceleration/deceleration with the inverter.
- For driving, check the operation sequence to avoid activating the protective function due to the inverter overload or the motor overload.
- For braking, check if disabled limiters do not cause any problems when you select braking resistor capacity for the operation sequence if you use power regenerative devices (RHC series) or connect braking resistors.




(2) Enable torque limiter

(2)-1 Level 1 to all four quadrants

| Code | Set value | Description |
|------|-----------|-------------------------------|
| F40 | 1 | Enable torque limiter |
| F41 | 0 | Level 1 to all four quadrants |


- The short-time rated torque limits the torque where the Level 1 exceeds the short-time rated torque as in the right figure.
- Though you can specify the Level 1 both in plus and minus values, you do not have to use a minus value, since it is interpreted as a plus value.



(2)-2 Level 1 to driving, Level 2 to braking

| Code | Set value | Description |
|------|-----------|--|
| F40 | 1 | Enable torque limiter |
| F41 | 1 | Level 1 to driving, Level 2 to braking |



- The short-time rated torque limits the torque where the Level 1 or the Level 2 exceeds the short-time rated torque as in the right figure.
- Though you can specify the Level 1 and the Level 2 both in plus and minus values, you do not have to use a minus value, since it is interpreted as a plus value.
- You can use this specification to set the Level 1 as the short-time rated torque for driving and to set the Level 2 as the braking torque limiter due to the brake capacity for braking.
- You cannot use the digital input **TL2/TL1** to switch between the Level 1 and the Level 2.



(2)-3 Level 1 to upper limit, Level 2 to lower limit

| Code | Set value | Description |
|------|-----------|--|
| F40 | 1 | Enable torque limiter |
| F41 | 2 | Level 1 to upper limit, Level 2 to lower limit |

- Plus and minus values specify Level 1 and Level 2. Make sure the setting polarity is correct. Usually **Level 1 is set to plus and Level 2 is set to minus**.
- The short-time rated torque limits the torque where the Level 1 or the Level 2 exceeds the short-time rated torque as in the right figure.
- You cannot use the digital input **TL2/TL1** to switch between the Level 1 and the Level 2.
- When you assign plus values both to the Level 1 and the Level 2, the entire valid torque range stays in plus (Level 1 > Level 2).
- When you assign minus values both to the Level 1 and the Level 2, the entire valid torque range stays in minus ($|\text{Level 1}| < |\text{Level 2}|$. e.g. Level 1=-10 and Level 2=-100).
- Use for applications such as winding control where starting torque is required (right figure).



CAUTION


If you set the Level 2 larger than Level 1, the output torque will be fixed to the Level 1. Unless you want this operation, never use this setting. A motor may become out of control and dangerous.

Accidents or physical injuries may occur.

(2)-4 Level 1/Level 2 (switchable) to all four quadrants

| Code | Set value | Description |
|------|-----------|--|
| F40 | 1 | Enable torque limiter |
| F41 | 3 | Level 1/Level 2 (switchable) to all four quadrants |

- When you turn on with assigning the torque limiter (Level 1, Level 2 selection) **TL2/TLI** signal to a digital input signal, you can switch between the Level 1 and the Level 2.



- The short-time rated torque limits the torque where the Level 1 or the Level 2 exceeds the short-time rated torque.
- Though you can specify the Level 1 and the Level 2 both in plus and minus values, you do not have to use a minus value, since it is interpreted as a plus value.

(3) Enable power limiter

(3)-1 Level 1 to all four quadrants


| Code | Set value | Description |
|------|-----------|-------------------------------|
| F40 | 2 | Enable power limiter |
| F41 | 0 | Level 1 to all four quadrants |

Since there is not such an application, this setting is not recommended although setting is possible.

(3)-2 Level 1 to driving, Level 2 to braking

| Code | Set value | Description |
|------|-----------|--|
| F40 | 2 | Enable power limiter |
| F41 | 1 | Level 1 to driving, Level 2 to braking |

- The short-time rated torque limits the torque where the Level 1 or the Level 2 exceeds the short-time rated torque as in the right figure.
- Though you can specify the Level 1 and the Level 2 both in plus and minus values, you do not have to use a minus value, since it is interpreted as a plus value.
- If you set the Level 1 as the short-time rated torque for driving and set a capacity corresponding to the inverter loss for braking, you can use the inverter loss to enable the shortest stop without an external braking resistor.
- Use this setting for an application such as applying brake with the capacity of a braking resistor.



(3)-3 Level 1 to upper limit, Level 2 to lower limit

| Code | Set value | Description |
|------|-----------|--|
| F40 | 2 | Enable power limiter |
| F41 | 2 | Level 1 to upper limit, Level 2 to lower limit |

Since there is not such an application, this setting is not recommended although setting is possible.

(3)-4 Level 1/Level 2 (switchable) to all four quadrants

| Code | Set value | Description |
|------|-----------|--|
| F40 | 2 | Torque limiter enabled |
| F41 | 3 | Level 1/Level 2 (switchable) to all four quadrants |


Since there is not such an application, this setting is not recommended although setting is possible.

(4) Enable torque current limiter

(4)-1 Level 1 to all four quadrants

| Code | Set value | Description |
|------|-----------|-------------------------------|
| F40 | 3 | Enable torque current limiter |
| F41 | 0 | Level 1 to all four quadrants |


- Unless you set the Level 1 over the short-time rated torque, the short-time rated torque does not limit the torque.
- When protective actions (inverter overload $OL1$ or motor overload $OL1, OL2, OL3$) occur frequently, you can lower the setting level to avoid this phenomenon.
- Though you can specify the Level 1 both in plus and minus values, you do not have to use a minus value, since it is interpreted as a plus value.



(4)-2 Level 1 to driving, Level 2 to braking

| Code | Set value | Description |
|------|-----------|--|
| F40 | 3 | Enable torque current limiter |
| F41 | 1 | Level 1 to driving, Level 2 to braking |

- Unless you set the Level 1 and Level 2 over the short-time rated torque, the short-time rated torque does not limit the torque.
- Though you can specify the Level 1 and the Level 2 both in plus and minus values, you do not have to use a minus value, since it is interpreted as a plus value.
- You can use this specification to set the Level 1 as the short-time rated torque for driving and to set the Level 2 as the braking torque limiter due to the brake capacity for braking.
- You cannot use the digital input $TL2/TL1$ to switch between the Level 1 and the Level 2.



(4)-3 Level 1 to upper limit, Level 2 to lower limit


| Code | Set value | Description |
|------|-----------|--|
| F40 | 3 | Enable torque current limiter |
| F41 | 2 | Level 1 to upper limit, Level 2 to lower limit |

Since there is not such an application, this setting is not recommended although setting is possible.

(4)-4 Level 1/Level 2 (switchable) to all four quadrants

| Code | Set value | Description |
|------|-----------|--|
| F40 | 3 | Enable torque current limiter |
| F41 | 3 | Level 1/Level 2 (switchable) to all four quadrants |

- When you turn on with assigning the torque limiter **TL2/TL1** (Level 1, Level 2 selection) to a digital input signal, you can switch between the Level 1 and the Level 2.



- Unless you set the Level 1 and Level 2 over the short-time rated torque, the short-time rated torque does not limit the torque.
- When protective actions (inverter overload $OL1$ or motor overload $OL1, OL2, OL3$) occur frequently, you can lower the setting level to avoid this phenomenon. Though you can specify the Level 1 and Level 2 with both in plus and minus values, you do not have to use a minus value, since it is interpreted as a plus value.

| | |
|------------|--------------------------------------|
| F42 | Torque Limiter Level 1 Source |
| F43 | Torque Limiter Level 2 Source |

Selects a mean that sets the torque limiter. These means are the function code, the analog input, the digital input card (DIA, DIB), the link (RS-485, T-Link, SX, field bus) and the PID output (PIDOUT)

When this function is activated (the torque limiter takes effect), the acceleration and the deceleration become longer than the set values.

| | | | | | | | | | | | | |
|----------|----------|----------|----------|----------|----------|----------|----------|----------|----------|----------|----------|----------|
| F | 4 | 2 | T | - | L | I | M | - | L | V | L | 1 |
| F | 4 | 3 | T | - | L | I | M | - | L | V | L | 2 |

- Level 1

Selects a mean that sets the Level 1

Data setting range: 0 (Function code F44)

- 1 (Ai *TL-REF1*)
- 2 (DIA card)
- 3 (DIB card)
- 4 (Communications link)
- 5 (PID output)

- Level 2

Selects a mean that sets the Level 2

Data setting range: 0 (Function code F45)

- 1 (Ai *TL-REF2*)
- 2 (DIA card)
- 3 (DIB card)
- 4 (Communications link)
- 5 (PID output)

< Setting example >

(1) Preparation

- Set 1, 2, or 3 to the function code F40 to enable the limiter.
- Use the function code F41 to set how to use the limiter Level 1 and Level 2.
- Use the function code F42 and F43 to assign inputs to the Level 1 and Level 2. If you want to set only the Level 1, use F42 only. Go to one of the steps from the following (2) to (6) according to the setting thus far.

(2) When using the function code

- Set 0 to both of the function code F42 and F43.
- Set a data for the Level 1 to F44 and that for the Level 2 to F45.

(3) When using the analog input

- Set 1 to both of the function code F42 and F43.
- Use E49 to E52 to select which analog input terminals among Ai1 to 4 (Ai3 and Ai4 are optional AIO) are used. Here we assume that Ai1 and Ai2 are assigned to the Level 1 and the Level 2 respectively.
- Connect the wires to the Ai1 and Ai2. An input of 10V corresponds to 150% (torque, power and torque current).
- See the "I/O check" screen of the KEYPAD panel to check if the inverter correctly recognizes the input while you are varying the voltage input from 0 to ±10V.
- See the description of the function codes E53 to E68 for voltage input setting (offset, dead zone, gain, bias, filter, and increment/decrement limiter).

(4) When using the DIA or the DIB card

- Set the hardware switch on the digital input card either to DIA or DIB.
- Set the function code F42 and F43 to 2 or 3 to use the DIA or the DIB respectively.
- You can assign the DIA (F42=2) to the Level 1 and the DIB (F43=3) to the Level 2 when you use two digital input cards and set one to DIA and the other to DIB.
- Connect the wires for the DIA and DIB cards. See the DI option section or the instruction manual supplied with the product for more details.
- See the "I/O check" screen of the KEYPAD panel to check if the inverter correctly recognizes the digital input.

(5) When using the communications link

- Set the function codes F42 and F42 to 4.
- Determine which link to be used. Refer the individual sections of the function description to study the detail of the links (RS-485, T-Link, SX, field bus).
- Set 1 or 3 to the function code H30 to enable the command data through the link. Note that setting 3 disables the operation through the terminal block and the KEYPAD panel.
- Write data from a master device (such as PC or PLC) to S10 (Limiter level 1) and S11 (Limiter level 2). The writing is complete when the normal response is sent back. You cannot confirm the writing on the inverter side. Since writing to S area (command data) is performed on the RAM (volatile memory) and written data disappear when your turn the inverter off, you should write necessary data every time when you turns on the inverter.

(6) When using the PID output

- Set 5 to the function code F42. Also set 5 to F43 to assign the PID output. Usually set the PID output to the upper limit and use the function code to set the lower limit.
- See the PID control block diagram (Section 4.1.9) or the PID description section to wire the system.
- You can display the PID output on the LED monitor of the KEYPAD panel.

| | |
|------------|-------------------------------|
| F44 | Torque Limiter Level 1 |
| F45 | Torque Limiter Level 2 |

Sets the torque limiter values (Level 1 and Level 2)

| | | | | | | | | | | | | |
|----------|----------|----------|----------|----------|----------|----------|----------|----------|----------|----------|----------|----------|
| F | 4 | 4 | T | - | L | I | M | - | S | E | T | 1 |
| F | 4 | 5 | T | - | L | I | M | - | S | E | T | 2 |

Data setting range: -300 to 300 (%)

| | |
|------------|-------------------------------------|
| F46 | Mechanical Loss Compensation |
|------------|-------------------------------------|

Use to compensate the amount of the mechanical loss of a load.

| | | | | | | | | | | | |
|----------|----------|----------|----------|----------|----------|----------|----------|----------|----------|----------|----------|
| F | 4 | 6 | T | - | M | E | C | - | L | O | S |
|----------|----------|----------|----------|----------|----------|----------|----------|----------|----------|----------|----------|

Data setting range: -300.00 to 300.00 (%)

| | |
|------------|-----------------------|
| F47 | Torque Bias T1 |
|------------|-----------------------|


| | |
|------------|-----------------------|
| F48 | Torque Bias T2 |
|------------|-----------------------|

| | |
|------------|-----------------------|
| F49 | Torque Bias T3 |
|------------|-----------------------|

You can add these setting values to the torque command values. The addition is conducted on a stage before the torque limiter. You can use the function selection Di, the torque bias command 1 [TB1] and the torque bias command 2 [TB2] to switch among three torque biases (T1, T2, T3).

| | | | | | | | | | | | |
|----------|----------|----------|----------|----------|----------|----------|----------|----------|----------|--|--|
| F | 4 | 7 | T | - | B | I | A | S | 1 | | |
| F | 4 | 8 | T | - | B | I | A | S | 2 | | |
| F | 4 | 9 | T | - | B | I | A | S | 3 | | |

Data setting range: -300.00 to 300.00 (%)



| | |
|------------|----------------------------------|
| F50 | Torque Bias Startup Timer |
|------------|----------------------------------|

Sets the time to increase the torque by 300%.

If there is a shock at the start of operation with a torque bias added, adjust this timer.

| | | | | | | | | | | | | |
|----------|----------|----------|----------|----------|----------|----------|----------|----------|----------|----------|----------|----------|
| F | 5 | 0 | T | - | B | I | A | S | - | T | I | M |
|----------|----------|----------|----------|----------|----------|----------|----------|----------|----------|----------|----------|----------|

Data setting range: 0.00 to 1.00 (s)

F51 Torque Command Monitor (Polarity)


Sets the polarity for data display related to torque. (AO monitor, KEYPAD panel LED monitor, KEYPAD panel LCD monitor)

F 5 1 T - R E F - M N T R


Data setting range: 0 (Torque polarity)
 1 (+ for driving, - for braking)

The following table shows data related with torque. These values are displayed or transmitted with sign. Judge the meaning of signs from the F51 set value.

| Display and output | Setting | Related data |
|----------------------------------|--------------------------|---|
| KEYPAD panel LED monitor | 3 | Torque current command value |
| | 4 | Torque command value |
| | 5 | Calculated torque value |
| KEYPAD panel LCD monitor | Operation status monitor | Torque command value |
| | Alarm information | Torque command value on alarm |
| Analog output (AO1, 2, 3) | 6 | Torque current command value (torque ammeter, two-way deflection) |
| | 8 | Torque command value (torque meter, two-way deflection) |
| Function codes M (monitor codes) | M02 | Torque command value |
| | M03 | Torque current command value |
| | M07 | Calculated torque value |
| | M08 | Calculated torque current value |
| | M28 | Torque command value on alarm |
| | M29 | Torque current command value on alarm |
| | M33 | Calculated torque value on alarm |
| | M34 | Calculated torque current value on alarm |



F51 = 0 (Torque polarity)



F51 = 1 (+for driving, -for braking)

| | |
|------------|--|
| F52 | LED Monitor (Display coefficient A) |
|------------|--|

| | |
|------------|--|
| F53 | LED Monitor (Display coefficient B) |
|------------|--|

Use these coefficients as conversion coefficient to determine the display values (process amount) of the load speed/line speed, the reference/feedback value of the PID regulator on the KEYPAD panel LED.

Data setting range: Display coefficient A: -999.00 to +999.00
 Display coefficient B: -999.00 to +999.00

Load speed, line speed

Use the Display coefficient A of F52

Displayed value=Motor speed × (0.01 to 200.00)


The effective display range is 0.01 to 200.00 while the setting range is ±999.00. The minimum value 0.01 or the maximum value 200.00 replaces a value out of the display range. For example, you should specify as F52=0.02 when the motor speed is 1500 (r/min) and the line speed is 30 (m/min).

Reference and feedback values for the PID regulator

Use F52 Display coefficient A to set the maximum value for display data and use F53 Display coefficient B to set the minimum value for display data.

$$\text{Displayed value} = (\text{Reference or feedback value}) \times (\text{Display coefficient A} - \text{B}) + \text{B}$$

| | | | | | | | | | | | |
|----------|----------|----------|----------|----------|----------|----------|----------|--|--|--|--|
| F | 5 | 2 | C | O | E | F | A | | | | |
| F | 5 | 3 | C | O | E | F | B | | | | |



| | |
|------------|-------------------------------------|
| F54 | LED Monitor (Display filter) |
|------------|-------------------------------------|

You do not have to display an instant value for some continuously changing data on the LED monitor of the KEYPAD panel. You can apply a filter for those data to prevent the flicker due to the change of the value.

Specify the time constant of the primary filter.

| | | | | | | | | | | | |
|----------|----------|----------|----------|----------|----------|----------|----------|----------|----------|----------|----------|
| F | 5 | 4 | D | I | S | P | L | A | Y | F | L |
|----------|----------|----------|----------|----------|----------|----------|----------|----------|----------|----------|----------|

Data setting range: 0.0 to 5.0 (s)

F55**LED Monitor (Item selection)**

F55 specifies the running status item (listed below) to be monitored and displayed on the LED monitor.

F 5 5 L E D M N T R

| Data for F55 | Function | Unit | Description |
|--------------|--------------------------------|------------------------------|--|
| 00 | Detected speed 1 | (r/min) | F56 switches the display to be applied when the motor is stopped. |
| 01 | Reference speed 4 | (r/min) | ASR input data |
| 02 | Output frequency | (Hz) | Slip included |
| 03 | Torque current command value | (%) | |
| 04 | Reference torque | (%) | |
| 05 | Calculated torque | (%) | |
| 06 | Input power | (kW, HP) | Switchable between kW and HP with F60. |
| 07 | Output current | (A) | |
| 08 | Output voltage | (V) | |
| 09 | DC link bus voltage | (V) | |
| 10 | Magnetic-flux command value | (%) | |
| 11 | Calculated magnetic-flux value | (%) | |
| 12 | Motor temperature | (°C) | Displays --- when NTC thermistor is not installed |
| 13 | Load shaft speed | (r/min) | Use F56 to change display when motor is stopping |
| 14 | Line speed | (m/min) | |
| 15 | Ai adjustment value (I2) | (%) | |
| 16 | Ai adjustment value (Ai1) | (%) | |
| 17 | Ai adjustment value (Ai2) | (%) | |
| 18 | Ai adjustment value (Ai3) | (%) | Displayed when an option is used |
| 19 | Ai adjustment value (Ai4) | (%) | Displayed when an option is used |
| 20 | PID command value | (%) | Displayed in the PID mode |
| 21 | PID feedback value | (%) | |
| 22 | PID output value | (%) | |
| 23 | Option monitor 1 | (HEX) | Displayed when an option is used (HEX: Hexadecimal data) |
| 24 | Option monitor 2 | (HEX) | |
| 25 | Option monitor 3 | (DEC) | Displayed when an option is used (DEC: Decimal data) Positive data. |
| 26 | Option monitor 4 | (DEC) | |
| 27 | Option monitor 5 | (DEC) | Displayed when an option is used (DEC: Decimal data) Positive and negative data. |
| 28 | Option monitor 6 | (DEC) | |
| 30 | Load factor | (%) | |
| 31 | Input power | F60 = 0 (kW) F60 = 1 (HP) | |
| 32 | Input watt-hour | (kWh) | Input watt-hour = Display value x 100 (kWh) |

- Values 20 to 22 display when H20 (PID Control, Mode selection) is set at "1" (Active), "2" (Inverse action 1) or "3" (Inverse action 2), respectively.
- Values 18, 19, 23 to 28 display when specific control options are mounted. See the corresponding option section in Chapter 6 for more details.

F56**LED Monitor (Display when stopped)**

F56 switches the F55 data display between the detected data and reference data when the motor is stopped (No inverter output, STOP state).

F 5 6 L E D M N T R 2

Data setting range: 0 (Display reference data)
1 (Display detected data (actual data))

F56 takes effect when F55 = 0 (Detected speed 1), = 13 (Load shaft speed), or = 14 (Line speed).

F57**LCD Monitor (Item selection)**


F57 selects the display contents of the LCD monitor in the Running mode.

F 5 7 L C D M N T R

Data setting range: 0 (Running status, rotation direction, and date & time or operation guide)
1 (Bar graphs for motor speed, output current, and torque command value)

When F57 = 0


In running



At a stop



When F57 = 1



Full scale values for bar graphs

| Display item | Full scale value |
|----------------------|------------------------------------|
| Motor speed | Maximum speed (F03, A06, and A106) |
| Output current | Motor rated current × 200% |
| Torque command value | Rated torque × 200% |

Note: The scale is not adjustable.

| | |
|------------|---|
| F58 | LCD Monitor (Language selection) |
|------------|---|

F58 selects a language to be displayed on the LCD monitor.

F 5 8 L A N G U A G E

| Data for F58 | Displayed language | Data for F58 | Displayed language |
|--------------|--------------------|--------------|--------------------|
| 0 | Japanese | 6 | Chinese |
| 1 | English | 7 | Korean |

Note 1: The language in the LCD screens shown in this manual is English.

Note 2: L codes are displayed in Japanese, English or Chinese, P, A and o codes in Japanese or English, and U codes in English only.

Note 3: Even if Korean is selected, the function code names are shown in English.

Note 4: When F58 = 2 to 5, the LCD screens are shown in English.

| | |
|------------|---------------------------------------|
| F59 | LCD Monitor (Contrast control) |
|------------|---------------------------------------|

F59 controls the contrast of the LCD monitor. Increasing the data value increases the contrast and decreasing it decreases the contrast.

F 5 9 C O N T R A S T

| | | |
|--------------|------------------------|------|
| Data for F59 | 0, 1, 2 8, 9, 10 | |
| Screen | Light | Dark |

| | |
|------------|----------------------------|
| F60 | Output Unit (HP/kW) |
|------------|----------------------------|

F60 switches the display unit of the inverter output (input power) shown on the LED monitor and LCD monitor and the display unit of M1 motor selection (P02) between kW and HP.

F 6 0 k W / H P

Data setting range: 0 (kW)
1 (HP)

| | |
|------------|---------------------------------|
| F61 | ASR1 (P-gain) |
| F62 | ASR1 (Integral constant) |

F61 and F62 specifies the P-gain and integral constant of the ASR1.

| | | | | | | | | | | | | |
|----------|----------|----------|----------|----------|----------|----------|----------|----------|--|--|--|--|
| F | 6 | 1 | A | S | R | 1 | - | P | | | | |
| F | 6 | 2 | A | S | R | 1 | - | I | | | | |

Data setting range: F61 = 0.1 to 500.0 (times)

F62 = 0.000 to 10.000 (s) (Setting 0.000 disables the integral constant.)

■ P gain

Adjust according to the mechanical inertia (inertia and mechanical constant) connected to the motor shaft. The factory default value 10.0 corresponds to the inertia of a single FRENIC-VG motor. The following table provides a guideline for setting. If you drive a machine whose inertia is larger than that of the FRENIC-VG motor when converted into a motor shaft inertia, set a value larger than 10.0. See Chapter 2 "Specifications" for the inertia data of the standard motors.

| | |
|---------|---|
| Inertia | Single VG standard motor to Medium to Large |
| P gain | 10.0 to Medium to Large |

P gain = 1.0 is defined such that the torque command is 100% (corresponding to the maximum speed setting) when the speed deviation (speed command – observed speed) is 100%.

| |
|--|
| ⚠ CAUTION |
| <p>If you set a too large value to gain compared with the inertia, though you can get faster control response, the motor may present an overshoot or a hunting. Also the motor or the machine may generate oscillation due to mechanical resonance or over-amplified noise.</p> <p>If you set a too small value to gain compared with the inertia, the control response slows down and it may take time to settle down the speed fluctuation at low speed.</p> |

■ Constant of integration

Sets the constant of integration of the Automatic Speed Regulator (ASR). You can specify a value in the range from 0.000 to 10.000 s to set the speed deviation (speed command-observed speed) at steady state to zero. Setting 0.000 s disables the integration (P control only). The integration means to sum the deviation at a specified interval. A smaller interval means a smaller summation interval that presents faster response. On the other hand, larger interval extends summation interval to reduce the effect on the ASR. Set a small value to reach the speed reference faster while allowing overshoots.

| |
|--|
| ⚠ CAUTION |
| <p>Integration action is a delay element. The constant of integration corresponds to the gain of a delay element. Increasing the response of the integration action makes the delay element larger, destabilizing the control system including motors and machines. The instability presents overshoots and oscillations. Thus, one measure to restrain the mechanical resonance such as abnormal mechanical noises from motors and gears is to increase the constant of integration.</p> <p>However, if you do not want a slower response, the machine side may need measures such as reviewing machines presenting mechanical resonance. You can also use F66 "ASR output filter".</p> |

F63 ASR1 (Feedforward gain)


F63 specifies the feedforward gain for a feedforward control that adds torque determined by the change of the speed command to the torque command directly.

The PI control by the ASR is a feedback control adjusting the speed against the command according to its control result (Actual speed). This control can adjust deviations due to what are not measurable such as unexpected disturbances and uncertain characteristics of control subjects. However, known changes in command value are followed after they appear in the deviation (Speed command - Actual speed). Since you can obtain a control value (torque command) for a known factor, you can expect a faster control by adding it to the torque command directly. This function is provided for this purpose.

F 6 3 A S R 1 - F F

Data setting range: 0.000 to 9.999 (s)

It is effective when the inertia is known. The differences in follow-up speed against the command value between the feedforward and non-feedforward controls are conspicuous as shown in the figures below. Note that it is necessary to balance the PI constants of the feedback control and this setting to obtain the maximum effect.



Though increasing the P gain of the ASR realizes the effect described above, increased gain also increases response resulting in negative effects (such as mechanical resonance or vibration).

F64**ASR1 (Input filter)**

F64 specifies the time constant for the first-order lag filter applied to a reference speed. Usually do not change the factory default.

Use this filter when you cannot stabilize the analog speed setting voltage at control terminal [12] after you failed to eliminate the causes. If noise is the case, first try measures in hardware such as separating control wiring, grounding, or connecting a capacitor to the terminal [12] and [11] in parallel before you use F64 as a software measure.

| | | | | | | | | | | | |
|---|---|---|---|---|---|---|---|---|---|--|--|
| F | 6 | 4 | A | S | R | 1 | - | I | N | | |
|---|---|---|---|---|---|---|---|---|---|--|--|

Data setting range: 0.000 to 5.000 (s)

F65**ASR1 (Detection filter)**

F65 specifies the time constant for the first-order lag filter applied to the detected speed. Usually do not change the factory default. In particular, it is not necessary to change the factory default when a pulse generator (PG) is used for speed detection. Use an oscilloscope to check the waveform if the output of the PG is unstable.

Use this filter when you use the line speed detection signal *LINE-N* for speed detection and the ripple presents on the signal. Note that a large setting will reduce the response of the speed control loop. A too large setting may destabilize the control.

| | | | | | | | | | | | |
|---|---|---|---|---|---|---|---|---|---|---|--|
| F | 6 | 5 | A | S | R | 1 | - | D | E | T | |
|---|---|---|---|---|---|---|---|---|---|---|--|

Data setting range: 0.000 to 0.100 (s)

| | |
|------------|-----------------------------|
| F66 | ASR1 (Output filter) |
|------------|-----------------------------|

F66 specifies the time constant for the first-order lag filter applied to the torque command. Use this filter for a mechanical resonance after you failed to adjust the ASR gain or the constant of integration to eliminate it.

| | | | | | | | | | | |
|----------|----------|----------|----------|----------|----------|----------|----------|----------|----------|----------|
| F | 6 | 6 | A | S | R | 1 | - | O | U | T |
|----------|----------|----------|----------|----------|----------|----------|----------|----------|----------|----------|

Data setting range: 0.000 to 0.100 (s)

Check the cause and the oscillation frequency of a mechanical resonance such as a vibration by gear backrush or a rope vibration in a vertical transfer. You should take measures in the inverter side after you failed to investigate and fix machine devices to eliminate the resonance.

Measures to eliminate mechanical resonance

- 1) Reduce response speed
 - Reduce the ASR P gain to reduce the amplitude of the resonance.
 - Increase the ASR I constant to shift the resonance point to lower frequency to restrain the high frequency resonance.
- 2) Use ASR output filter
 - Though you can reduce the resonance amplitude, excessive filter elements may cause instability.
- 3) Use oscillation suppressing observer
 - See H46 "Observer type selection" for more details.

| | |
|------------|---------------------------------------|
| F67 | S-curve Acceleration 1 (Start) |
| F68 | S-curve Acceleration 1 (End) |
| F69 | S-curve Deceleration 1 (Start) |
| F70 | S-curve Deceleration 1 (End) |

These function codes arrange the speed reference value to form a curve at the start and the end of acceleration and deceleration. You can realize smooth acceleration and deceleration actions without shocks.


| | | | | | | | | | | | |
|----------|----------|----------|----------|----------|----------|----------|----------|----------|----------|----------|----------|
| F | 6 | 7 | S | - | A | C | C | - | S | T | 1 |
| F | 6 | 8 | S | - | A | C | C | - | A | R | 1 |
| F | 6 | 9 | S | - | D | E | C | - | S | T | 1 |
| F | 7 | 0 | S | - | D | E | C | - | A | R | 1 |

Data setting range: 0 to 50 (%)

Setting the S-curve extends acceleration time 1 (F07) and deceleration time 1 (F08) according to the following expressions.

$$t1(s) = \text{Acceleration time (s)} \times \left(1 + \frac{\text{S-curve acceleration start side (\%)}}{100(\%)} + \frac{\text{S-curve acceleration end side (\%)}}{100(\%)} \right) (s)$$

$$t2(s) = \text{Deceleration time (s)} \times \left(1 + \frac{\text{S-curve deceleration start side (\%)}}{100(\%)} + \frac{\text{S-curve deceleration end side (\%)}}{100(\%)} \right) (s)$$



F72

Pre-excitation Mode

F72 specifies when pre-excitation should start. Pre-excitation flows exciting current through a motor beforehand in order to make the response quicker at the start of motor driving.

F 7 2 P R E E X S E L

Data setting range: 0


Cause pre-excitation at the time of a startup. Pre-excitation continues for the duration specified by F74

1

Cause pre-excitation at the time of a startup and stop.

At the time of a startup, pre-excitation continues for the duration specified by F74 or until the magnetic flux command reaches the detection level specified by E48, whichever is earlier.

After a stop, pre-excitation continues until the duration specified by F74 elapses. It is effective for starting the motor immediately following a stop (when pre-excitation is in progress), e.g., for inching (intermittent running).



When F72 = 0, set the pre-excitation duration (F74) so that the motor starts rotating after the magnetic flux has been saturated (100%), as shown in the above graph.

Note: The motor may rotate during pre-excitation, so be sure to use a mechanical brake to avoid unexpected rotation.


Even if F72 = 1, under vector control without speed sensor or under torque control, pre-excitation after a motor stop does not occur. When H09 ≠ 0 (Auto search is enabled) under vector control without speed sensor, pre-excitation at a startup caused when H72 = 0 applies.

Whether a motor is during pre-excitation or in normal operation can be checked with the running status page in Menu #4 "I/O CHECK."
 ■EXT indicates "during pre-excitation" and □EXT, "in normal operation."

| | |
|-------------|----------------|
| 1500 | |
| ■FWD | □BRK |
| □REV | ■NUV |
| ■EXT | □TL |
| □INT | □VL |
| △V→PAGE | SHIFT 7 |

F73 Magnetic Flux Level at Light Load

You can specify a small value to reduce the electromagnetic noise of a motor at light load. The magnetic-flux command decreases according to the torque current command to reduce the electromagnetic noise.



F 7 3 M I N F L U X

Data setting range: 10 to 100 (%)

Note: F73 is valid only under vector control with speed sensor.

You can view the level (%) of the magnetic-flux command on the "Operation monitor" of the KEYPAD panel.

See "FLX*" (magnetic-flux command) on the operation monitor screen "Operation monitor".

The value is usually 100% and decreased in the low output range.

This function reduces the magnetic-flux according to the setting as shown in the graph. The graph shows that the magnetic-flux decreases to 60%

Under vector control without speed sensor, the magnetic flux level is fixed at 100%.

| | |
|-----------------|-------|
| 1500 | |
| TMP = | 30°C |
| I out = | 14.3A |
| V out = | 188V |
| FLX* = | 60% |
| ΔV→PAGE SHIFT 2 | |

F74 Pre-excitation (Duration)

F74 specifies the pre-excitation duration.

F 7 4 P R E E X t

Data setting range: 0.0 to 10.0 (s)

F75 Pre-excitation (Initial level)


Sets the initial level of the pre-excitation.

F 7 5 F L U X F O R C E

Data setting range: 100 to 400 (%)

When you want to reduce the pre-excitation time (function code F74) to establish the magnetic-flux quickly, set the exciting current high.

The transient response to the exciting current command until the magnetic-flux is established 100% depends on the secondary time constant of a motor (exciting inductance/resistor). This function applies more than 100% of the exciting current to establish the magnetic-flux faster. The initial level ends when the magnetic-flux is established 100%, and the exciting current returns 100%.



Under vector control without speed sensor and when H09 = 1 or 2 (Auto search is enabled), the data setting range is limited to 200 to 400%. Even if F75 is set at 100%, 200% applies.

If a trip occurs in auto search with 60 Hz or higher (1800 r/min in terms of 4-pole motor), increasing the F75 setting may improve the problem.

| | |
|------------|--------------------------------|
| F76 | Speed Limiter (Mode) |
| F77 | Speed Limiter (Level 1) |
| F78 | Speed Limiter (Level 2) |


The speed control and the torque control (torque control, torque current control) differs in the usage of these function codes.

Usage for speed control


Since the inverter usually (factory setting) controls speed (internal ASR enabled, motor controlled by speed command), and the speed limiter is applied to the speed command (See "(1) Speed control") You can use the function code H41 "Torque command selection" and H42 "Torque current command selection" to select a specification other than the "internal ASR enabled" to operate the inverter to control the torque. This is the case, the speed control is applied to the motor speed (speed detection/speed estimation). Since the inverter does not control the speed, the control adds negative torque bias to the torque command when the motor accelerates beyond the limiter value. You can use the [I2] input as a bias for the speed limiter instead of the speed command (see "(2) Torque control").

You can set ON to the digital input signal *N-LIM* to disable (cancel) the speed limiter function.

(1) For speed control



(2) For torque control



(1) Speed control

You can set the speed limit to the speed command value.

F 7 6 N - L I M - M O D E

- Method selection



- Data setting range: 0 (Limit forward (Level 1) and reverse (Level 2) individually.)
 1 (Limit forward and reverse in Level 1.)
 2 (Limit upper limit by Level 1 and the lower limit by Level 2.)
 3 (Reserved. (Equivalent to "0").)

F 7 7 N - L I M - L V L 1
F 7 8 N - L I M - L V L 2




- Level 1, 2

Data setting range: -110.0 to 110.0 (%)

When $F76 = 0$, the upper and lower limit levels during FWD and REV operations switch between Levels 1 and 2.



When $F76 = 1$ or 2 , the speed limiter acts as shown below.



⚠ CAUTION

Specify such that the limiter Level 1 > the limiter Level 2 for $F76 = 2$ (Upper limit by the Level 1 and the lower limit by the Level 2). If you specify as the limiter Level 1 < the limiter Level 2, the speed reference is fixed to the limiter Level 2. In this state, turning off the operation does reduce the speed reference and the operation continues.

You may be injured.

< Example of a setting inhibiting reverse rotation >

When you want to inhibit reverse rotation (forward rotation directed by reverse rotation command) while forward rotation command is directed, specify as $F76 = 0$, the limiter level 1 = 100.0% and the limiter level 2 = 0.0%.

(2) Torque control (torque command, torque current command)

F 7 6 N - L I M - M O D E

- Method selection

Data setting range: 0 (Limit forward and reverse individually. FWD and REV switch the levels.

1 (Level 1 limits forward and reverse.)

2 (Invalid (Even if specified, the setting is assumed to be "0."))



3 (Individual limiters for forward and reverse rotation. [12] input is added as a variable part of limiters.)

F 7 7 N - L I M - L V L 1
F 7 8 N - L I M - L V L 2


- Level 1, 2

Data setting range: -110.0 to 110.0 (%)


When F76 = 0, the upper and lower limit levels during FWD and REV operations switch between Levels 1 and 2.



When F76 = 1, the speed limiter acts as shown below.



When F76 = 3, input to [12] acts as a bias as shown below.




Input voltage for [12] is ± 10V at the maximum motor speed (± 100%).

Use C60 (ASR4-P) to adjust the speed stability under speed limit.

| ⚠ CAUTION |
|--|
| <p>When the magnetic flux decreasing function (F73) is used, the factory default of the ASR4 P-gain (C60 = 10) causes the response of the speed limiter to slower so that the speed may not be controlled. In particular, setting F73 data to an extremely small value (10% or 20%) may cause large speed hunting. If it happens, increase the C60 setting (ASR4 P-gain) or increase the F73 setting to stabilize the speed.</p> |

The torque limit in accordance with the line speed (input at [12]) can be added if F76 is "3."

To perform mechanically coupled operation with torque command handover (see the figure below), enter a slightly larger value (+5%) than that specified on the master as a speed limit level for the inverter (slave) driven under torque control.



Note Since the slave inverter runs under torque control, configure it to be controlled by the speed limiter if it malfunctions.

F79

Motor Selection (M1, M2, M3)

The FRENIC-VG can hold three sets of motor parameters (M1, M2 and M3) which can be selected by F79 or X terminal functions (*M-CH2* and *M-CH3*)

F 7 9 M 1 - 3 S E L E C T

Data setting range: 0 (Select M1. Note that the X terminal functions (*M-CH2*, *M-CH3*) have higher priority as shown below.)

When (*M-CH2* and *M-CH3*) = (OFF, OFF) or (ON, ON), or no *M-CH2* or *M-CH3* has been assigned, M1 is selected.

When (*M-CH2* and *M-CH3*) = (ON, OFF), M2 is selected.

When (*M-CH2* and *M-CH3*) = (OFF, ON), M3 is selected.

1 (Select M2.)

2 (Select M3.)


Merits and restrictions for selecting M1, M2, or M3

| | When M1 (1st motor) is selected | When M2 (2nd motor) is selected | When M3 (3rd motor) is selected |
|---|---|--|---|
| Control type | <u>Set by P01</u> Vector control for IM with speed sensor Vector control for IM without speed sensor Vector control for PMSM with speed sensor V/f control Simulation mode | <u>Set by A01</u> Vector control for IM with speed sensor Vector control for IM without speed sensor Vector control for PMSM with speed sensor V/f control | <u>Set by A101</u> Vector control for IM with speed sensor Vector control for IM without speed sensor Vector control for PMSM with speed sensor V/f control |
| Motor parameters | Function codes F03 to F05, F10 to F12, P03 to P51, H47, H49, H51, H112 to H118, H160 to H162, o09 to o11 When a FRENIC-VG motor is selected, the inverter automatically set data to the above function codes. | Function codes A02 to A71, H48, H50, H52, H170 to H172 To be set manually. | Function codes A102 to A171, H125 to H127, H180 to H182 To be set manually. |
| Protective functions specific to motor parameters | Provided. When a FRENIC-VG motor is selected with P02 (P02 = 0 to 35, 38 to 50) or P-OTHER is selected (P02 = 36), the write-protect function becomes activated. | Not provided. | Not provided. |

You can use the "Effective sets of motors/parameters" on the "I/O check" screen of the KEYPAD panel to check the currently selected motor set (M1, M2, M3).

If the motor set 2 is selected, ■ M2 is indicated.

Answer back signals are put on the DO output *SW-M2* and *SW-M3* to indicate whether the motor switch among motor set (M1, M2, M3) is completed in the inverter. See E15 to E27 for more information. We recommend to prepare a sequence to check the DO for the answer back when you use the terminal input signals *M-CH2* and *M-CH3* to switch motors.



It is recommended to activate overcurrent suppression function (H58 = 1) when M3 is selected (V/f control).

F80 **Switching between HD, MD and LD Drive Modes**

F80 specifies whether to drive the inverter in the high duty (HD), medium duty (MD) or low duty (LD) mode.

F 8 0 I r **S E L E C T**

- Data setting range: 0, 2 (High Duty, overload current 150%-1 min, 200%-3 sec.)
 1 (Low Duty, overload current 120%-1 min)
 2 (Middle Duty, overload torque 150%-1 min)


Overload current means to apply overload limiter by torque current (corresponding armature current of a DC motor), and the torque decreases in proportion to the decrease of the magnetic-flux above the rated speed (100%).

Note: Select peripheral equipment in accordance with the current rating. (Refer to the Chapter 8, "SELECTING PERIPHERAL EQUIPMENT.")

- Torque characteristics for HD mode

Application


Use for general constant torque applications including speed control with torque limit for winding machines, wire drawing machines, and test machines and control by direct torque command.



- Torque characteristics for LD/MD mode

Application

Use for applications that do not require overload capability for a short period such as extruding machines and centrifugal separators. Also suitable for applications where the operation cycle is short and torque is limited to 100% or less since the root-mean-square current exceeds the rated current of an inverter (Large press machines).



You can choose an inverter by one or two ranks lower than the HD-mode inverter. Note that the maximum carrier frequency is smaller than that in the HD mode. See Chapter 2, Section 2.1 "Standard Specifications" for more details

(Note) Replacing the HT-rating VG7 with the FRENIC-VG

The FRENIC-VG does not support the HT rating equivalent of the VG7. When replacing the HT-rating VG7, use the FRENIC-VG with one capacity rank higher.

Note that the 200 V class series inverters of 7.5 to 22 kW and 400 V class series ones of 18.5 to 22 kW can be replaced with the FRENIC-VG with the same capacity as long as the carrier frequency is 10 kHz or below.

| Drive mode | Inverter capacity (kW) | Carrier frequency (kHz) | Applied motor (relative to the inverter capacity) | Overload rating |
|---------------------------------------|---------------------------------------|-------------------------|---|-----------------------------------|
| HD "Heavy duty load" (F80 = 0) | 0.75 to 45 (200V) 3.7 to 55 (400V) | 2 to 15 | Same capacity | Current 150% 1 min 200% 3 s |
| | 55 to 90 (200V) 75 to 400 (400V) | 2 to 10 | | |
| | 500 to 630 (400V) | 2 to 5 | Same capacity | |
| MD "Medium duty load" (F80 = 3) | 90 to 400 (400V) | 2 to 4 | One rank higher capacity | Current 150% 1 min |
| LD "Low duty load" (F80 = 1) | 30 to 90 (200V) 30 to 630 (400V) | 2 to 10/6/4 | One rank higher capacity | Current 120% 1 min |

If the LD or MD mode is selected for the inverter capacity not available to the mode, the inverter runs in the HD mode.

F81 Offset for Speed Setting on Terminal [12]

F81 specifies an offset for analog speed input on terminal [12]. Use this setting for adjustment of out-of-offset signals sent from external equipment.

F 8 1 1 2 O F F S E T

Data setting range: -30000 to 30000 (r/min)


F82 Dead Zone for Speed Setting on Terminal [12]

F82 specifies the dead zone speed for analog speed input on terminal [12] to limit the \pm speed setting value within the range of \pm F82 data to 0 r/min.

(This function is available in the ROM version H1/2 0019 or later.)

F 8 2 1 2 B L I N D

Data setting range: 0.0 to 150.0 (r/min)



F83**Filter for Speed Setting on Terminal [12]**

F83 specifies a time constant determining the first order delay of the analog speed input on terminal [12].

| | | | | | | | | | | |
|---|---|---|---|---|---|---|---|---|---|---|
| F | 8 | 3 | 1 | 2 | F | I | L | T | E | R |
|---|---|---|---|---|---|---|---|---|---|---|

Data setting range: 0.000 to 5.000 (s)

F84**Display Coefficient for Input Watt-hour Data**

F84 specifies a display coefficient for displaying the input watt-hour data (M116).

Input watt-hour data (M116) = F84 x M115 (Input watt-hour) (Unit: 100 kWh)

| | | | | | | | | | |
|---|---|---|---|---|---|---|---|---|---|
| F | 8 | 4 | P | W | R | C | O | E | F |
|---|---|---|---|---|---|---|---|---|---|

Data setting range: 0.000 to 9999

(Specification of "0.000" clears the input watt-hour data and stops counting.)

Setting the F84 data to 1/1000 of the electric rate per 100 kWh enables the total electricity price (in units of ¥1,000) to be displayed. If the electric rate is ¥18 per kWh, for example, setting the F84 data to "1.8" displays 18.00 (thousand yen) if the input watt-hour data is 10.00 (100 kWh).

F85**Display Filter for Calculated Torque**

F85 specifies a display filter for outputting the calculated torque (Monitoring function code M07) on the LED and LCD monitors.

| | | | | | | | | | | | |
|---|---|---|---|---|---|---|---|---|---|---|---|
| F | 8 | 5 | T | R | Q | F | I | L | T | E | R |
|---|---|---|---|---|---|---|---|---|---|---|---|

Data setting range: 0.000 to 1.000 (s)

4.3.2 E codes (Extension Terminal Functions)

| E01 to E13 | X Terminal Function |
|------------|---------------------|
|------------|---------------------|

E01 to E13 assign commands (listed below) to general-purpose, programming digital input terminals, [X1] to [X9] and [X11] to [X14].

([X11] to [X14] are available when the optional OPC-VG1-DIOA is mounted or a communications option (e.g., RS-485, T-Link, SX-bus, and fieldbus) is mounted.)

Before using these terminal commands, see Chapter 4, Section 4.1 "Control Block Diagrams" and check the switching positions of the control contacts.


The FRENIC-VG runs under four drive controls: "Vector control for IM with speed sensor," "Vector control for IM without speed sensor," "V/f control for IM," and "Vector control for PMSM with speed sensor." Some terminal commands apply exclusively to the specific drive control, which is indicated in the "Drive control" column in the function code tables given in Section 4.2.

Using digital input terminals

A total of 13 digital inputs are available--nine on terminals [X1] to [X9] as standard and four on terminal [X11] to [X14] as option (when a DIOA option is mounted). Using the communications link (RS-485, T-Link, SX-bus and fieldbus) enables access to those 13 digital inputs.

Configuration procedure

- Select a desired function (**BX** ("Coast to a stop") in this example).
- Assign **BX** to any one of terminal [X1] to [X9] and [X11] to [X14]. To assign it to terminal [X3], for example, set "7" to Function code E03.
- Turn [X3] ON from external equipment to activate **BX** ("Coast to a stop"). Turn it OFF to deactivate **BX**.
- To check the ON/OFF status of [X3], use Menu #4 "I/O Checking" (REM screen) on the keypad and check that the box of the X3 appears black (■) as shown at the right.
- When accessing to the digital inputs via the communications link, see the COMM screen in Menu #4 "I/O Checking."



Configuring contacts ("normal open" or "normal close")

Terminals [X1] to [X9] can be configured individually as a "normal open" or "normal close" contact with Function code E14. For details refer to the description of E14.

| | | | | | | | | | | | |
|---|---|---|---|---|---|---|---|---|---|---|--|
| E | 0 | 1 | X | 1 | | F | U | N | C | | |
| | | | | | | | | | | | |
| E | 1 | 3 | X | 1 | 4 | | F | U | N | C | |

Data setting range: 00 to 83

| Function code data | Terminal commands assigned | Symbol | Function code data | Terminal commands assigned | Symbol |
|----------------------|---|--|--------------------|---|-----------------|
| 00 01 02 03 | Select multistep speed (1 to 15 steps) | <i>SS1</i> <i>SS2</i> <i>SS4</i> <i>SS8</i> | 27 | Synchronization operation command (PG (PR) optional function) | <i>SYC</i> |
| 04 05 | Select ASR and ACC/DEC time (4 steps) | <i>RT1</i> <i>RT2</i> | 28 | Lock at zero speed | <i>LOCK</i> |
| 06 | Enable 3-wire operation | <i>HLD</i> | 29 | Pre-excitation | <i>EXITE</i> |
| 07 | Coast to a stop | <i>BX</i> | 30 | Cancel speed limiter | <i>N-LIM</i> |
| 08 | Reset alarm | <i>RST</i> | 31 | Cancel H41 (Torque command) | <i>H41-CCL</i> |
| 09 | Enable external alarm trip | <i>THR</i> | 32 | Cancel H42 (Torque current command) | <i>H42-CCL</i> |
| 10 | Ready for jogging | <i>JOG</i> | 33 | Cancel H43 (Magnetic flux command) | <i>H43-CCL</i> |
| 11 | Select speed command N2/N1 | <i>N2/N1</i> | 34 | Cancel F40 (Torque limiter mode 1) | <i>F40-CCL</i> |
| 12 | Select motor 2 | <i>M-CH2</i> | 35 | Select torque limiter level 2/1 | <i>TL2/TL1</i> |
| 13 | Select motor 3 | <i>M-CH3</i> | 36 | Bypass ACC/DEC processor | <i>BPS</i> |
| 14 | Enable DC braking | <i>DCBRK</i> | 37, 38 | Select torque bias command | <i>TB1, TB2</i> |
| 15 | Clear ACC/DEC to zero | <i>CLR</i> | 39 | Select droop control | <i>DROOP</i> |
| 16 | Switch creep speed under UP/DOWN control | <i>CRP-N2/N1</i> | 40 | Zero-hold Ai1 | <i>ZH-AI1</i> |
| 17 | UP (Increase speed) | <i>UP</i> | 41 | Zero-hold Ai2 | <i>ZH-AI2</i> |
| 18 | DOWN (Decrease speed) | <i>DOWN</i> | 42 | Zero-hold Ai3 (AIO optional function) | <i>ZH-AI3</i> |
| 19 | Enable data change with keypad | <i>WE-KP</i> | 43 | Zero-hold Ai4 (AIO optional function) | <i>ZH-AI4</i> |
| 20 | Cancel PID control | <i>KP/PID</i> | 44 | Reverse Ai1 polarity | <i>REV-AI1</i> |
| 21 | Switch normal/inverse operation | <i>IVS</i> | 45 | Reverse Ai2 polarity | <i>REV-AI2</i> |
| 22 | Interlock (52-2) | <i>IL</i> | 46 | Reverse Ai3 polarity (AIO optional function) | <i>REV-AI3</i> |
| 23 | Enable data change via communications link | <i>WE-LK</i> | 47 | Reverse Ai4 polarity (AIO optional function) | <i>REV-AI4</i> |
| 24 | Enable communications link | <i>LE</i> | 48 | Inverse PID output | <i>PID-INV</i> |
| 25 | Universal DI | <i>U-DI</i> | 49 | Cancel PG alarm | <i>PG-CCL</i> |
| 26 | Enable auto search for idling motor speed at starting | <i>STM</i> | 50 | Cancel undervoltage alarm | <i>LU-CCL</i> |

| Function code data | Terminal commands assigned | Symbol | Function code data | Terminal commands assigned | Symbol |
|--------------------|---|------------------------|--------------------|------------------------------|----------------|
| 51 | Hold Ai torque bias | H-TB | 72 | Toggle signal 1 | TGL1 |
| 52 | STOP1 (Decelerate to stop with normal deceleration time) | STOP1 | 73 | Toggle signal 2 | TGL2 |
| 53 | STOP2 (Decelerate to stop with deceleration time 4) | STOP2 | 74 | Cause external mock alarm | FTB |
| 54 | STOP3 (Decelerate to stop with maximum braking torque, ignoring the deceleration time setting) | STOP3 | 75 | Cancel NTC thermistor alarm | NTC-CCL |
| 55 | Latch DIA data (DIA optional function) | DIA | 76 | Cancel lifetime alarm signal | LF-CCL |
| 56 | Latch DIB data (DIB optional function) | DIB | 78 | Switch PID feedback signals | PID-1/2 |
| 57 | Cancel multiplex system | MT-CCL | 79 | Select PID torque bias | TB-PID |
| 58-67 | Custom Di1-Di10 | C-DI1 to C-DI10 | | | |
| 68 | Select load adaptive parameters 2/1 (Available soon) | AN-P2/1 | | | |
| 69 | Cancel PID components | PID-CCL | | | |
| 70 | Enable PID FF component | PID-FF | | | |
| 71 | Reset completion of speed limit calculation (Available soon) | NL-RST | | | |

Function code data = 00, 01, 02, 03 Select multistep speed (1 to 15 steps) -- SS1, SS2, SS4, SS8

You can use external digital input signals to switch predetermined speeds specified by function codes from C05 to C19 "Multistep speed". Assign data 00 to 03 to digital terminals to select a speed by combining those terminal inputs.


| Input signal combination to select specified data | | | | Speed to be selected | |
|---|------------------|------------------|------------------|---|--|
| 03 SS8 | 02 SS4 | 01 SS2 | 00 SS1 | | |
| OFF | OFF | OFF | ON | C05 Multistep speed 1, N-1 | Related function codes C05 to C19 Setting range 0 to 30000 r/min or 0.00 to 100.00% or 0.0 to 999.9 m/min |
| OFF | OFF | ON | OFF | C06 Multistep speed 2, N-2 | |
| OFF | OFF | ON | ON | C07 Multistep speed 3, N-3 | |
| OFF | ON | OFF | OFF | C08 Multistep speed 4, N-4 | |
| OFF | ON | OFF | ON | C09 Multistep speed 5, N-5 | |
| OFF | ON | ON | OFF | C10 Multistep speed 6, N-6 | |
| OFF | ON | ON | ON | C11 Multistep speed 7, N-7 | |
| ON | OFF | OFF | OFF | C12 Multistep speed 8, N-8 | |
| ON | OFF | OFF | ON | C13 Multistep speed 9, N-9 | |
| ON | OFF | ON | OFF | C14 Multistep speed 10, N-10 | |
| ON | OFF | ON | ON | C15 Multistep speed 11, N-11 | |
| ON | ON | OFF | OFF | C16 Multistep speed 12, N-12 | |
| ON | ON | OFF | ON | C17 Multistep speed 13, N-13 | |
| ON | ON | ON | OFF | C18 Multistep speed 14, N-14/ Creep speed 1, CREP1 | |
| ON | ON | ON | ON | C19 Multistep speed 15, N-15/ Creep speed 2, CREP2 | |

Function code data = 04, 05 Select ASR and ACC/DEC time (4 steps) -- RT1, RT2


You can switch predetermined acceleration/deceleration times, ASR constants and S-curve accelerations/decelerations specified by function codes through external digital input signals. Assign data 04 to 05 to digital terminals to select acceleration/deceleration times, ASR constants and S-curve accelerations/decelerations.

| Input signal combination to select specified data | | Acceleration/deceleration times to be selected | |
|---|------------------|---|--|
| 05 <i>RT2</i> | 04 <i>RT1</i> | | |
| OFF | OFF | F07 Acceleration Time 1 F08 Deceleration Time 1 F61 to F66 ASR1 constants F67 S-curve Acceleration 1 (Start) F68 S-curve Acceleration 1 (End) F69 S-curve Deceleration 1 (Start) F70 S-curve Deceleration 1 (End) | Related function codes F07, 08, F61 to F70 C40 to C69 |
| OFF | ON | C40 to C45 ASR 2 constants C46 Acceleration Time 2 C47 Deceleration Time 2 C48 S-curve 2 (Start side) C49 S-curve 2 (End side) | |
| ON | OFF | C50 to C55 ASR 3 constants C56 Acceleration Time 3 C57 Deceleration Time 3 C58 S-curve 3 (Start side) C59 S-curve 3 (End side) | |
| ON | ON | C60 to C65 ASR 4 constants C66 Acceleration Time 4 C67 Deceleration Time 4 C68 S-curve 4 (Start side) C69 S-curve 4 (End side) | |

Example: Four and five are assigned to the terminals [X2] and [X3].



* If you switch the acceleration/deceleration times, the ASR constants and S-curve actions are switched simultaneously. You can see which set is currently selected from (1, 2, 3, 4) on the "I/O check" screen of the KEYPAD panel. When the data set 3 is selected, "■PARA3" is indicated on the display.




Function code data = 06

Enable 3-wire operation -- *HLD*

Use for 3-wire operation. When ***HLD-CM*** is ON, the FWD or the REV signal is self-held, and is canceled when ***HLD-CM*** is OFF.

When you want use this ***HLD*** function, you should assign a data 06 to a desired digital input terminal.




Function code data = 07 Coast to a stop-- *BX*

The inverter output is turned off and the motor enters into the coast-to-stop state, when ***BX-CM*** is ON.

The signal does not cause an alarm output. Also, this signal is not self-held.

When you want use this ***BX*** function, you should assign data a 07 to a desired digital input terminal.



Function code data = 08 Reset alarm -- *RST*

Switching the ***RST-CM*** from OFF to ON cancels the alarm relay output and the alarm display and restart operation while the protective function is active.

When you want use this ***RST*** function, you should assign a data 08 to a desired digital input terminal.



Function code data = 09 Enable external alarm trip -- *THR*

The factory setting for the trip command is an "NO terminal" (normally open).

When you use the trip command as an "NC terminal" (normally closed), follow the procedure described below.

When ***THR-CM*** is ON, the operation is assumed as normal. When ***THR-CM*** is turned OFF, the inverter output is turned off (motor is in the coast-to-stop state) and the alarm "OH2" is issued. You can use the trip command for the overheat protection of an external resistor.

<Application and notes>

- The ***THR*** function is assigned to the X9 terminal in the factory setting (function code E09=9, THR). Use the X9 as an external alarm as it is.
- Use the function code E14 "X function normally open/normally closed" to set the X9 terminal to an "NC terminal". To set as an "NC terminal", move the 9th ■ (X9 terminal) from the OP side to the CL side and use the  key to write.
- When you turn on the inverter while X9 ***THR-CM*** is open, the "OH2" alarm is issued. This is a normal state.
- Connect X9 ***THR*** and [CM] to the overheat detection contact of the braking resistor or the like.
- If you do not connect a braking resistor, short-circuit the ***THR-CM*** or move the 9th ■ (X9 terminal) from the CL side to the OP side again and use the  key to write.

Function code data = 10 Ready for jogging -- JOG

Use this function for an inching action such as work adjustment. You can operate at the jogging speed specified by the function C29 "Jogging speed" by turning on the signal between **JOG** and **CM** while the operation command (FWD-CM or REV-CM) is ON. You can also use the KEYPAD panel to switch to the jogging mode.

When you want to use this **JOG** function, you should assign a data 10 to a desired digital input terminal.

The function codes related to the jogging operation are C29 to C38. A dedicated speed control setting (such as gain) is available.

The indicator stays at the JOG position on the LCD monitor of the KEYPAD panel during the jogging operation.

Function code data = 11 Select speed command -- N2/N1

Use an external digital input signal to switch the speed setting method predetermined with function F01 "speed setting N1" and C25 "speed setting N2."

If you do not specify, F01 is selected.

| Input signal to select specified data | Speed setting method to be selected |
|---------------------------------------|-------------------------------------|
| 11 | |
| OFF | F01 Speed Command N1 |
| ON | C25 Speed Command N2 |

Function code data = 12, 13 Select motor 2, 3 -- M-CH2, M-CH3

You can use the external digital input signals to switch the predetermined motor parameters. You can use the terminal to switch only when F79 "Motor selection (M1, 2, 3)" is set to 0. If F79=1, the selection is fixed to the M2. If F79=2, the selection is fixed to the M3.


The switching result becomes effective when the operation command to the inverter is ON and the motor is in the stop state.

| Input signal combination to select specified data | | Motor to be selected | Related codes |
|---|--------------------|----------------------|---|
| 13 <i>M-CH3</i> | 12 <i>M-CH2</i> | | |
| OFF | OFF | First motor | F03 to F05, F10 to F12, P01 to P51, H47, H49, H51, H112 to H118, H160 to H162, o09 to o11 |
| OFF | ON | Second motor | A01 to A71, H48, H50, H52, H170 to H172 |
| ON | OFF | Third motor | A101 to A171, H125 to H127, H180 to H182 |
| ON | ON | First motor | F03 to F05, F10 to F12, P01 to P51, H47, H49, H51, H112 to H118, H160 to H162, o09 to o11 |

Note: Both **M-CH2** and **M-CH3** are ON, the first motor is selected. See also the description of the function code F79.

Note: When inverter is stopped, if motor switch 1/2 is changed during rotation of the connected motor (during naturally coasting or coasting with a load), the analog speed detection output, digital speed detection signal or the like may cause unpredictable operation.

Function code data = 14 Enable DC braking -- *DCBRK*

When the external digital input signal is ON and the operation command is turned OFF (when you press the  key during the KEYPAD panel operation, or the both [FWD] and [REV] terminals are OFF during the external signal operation), the DC braking starts after the motor speed decreases to the predetermined rotation specified by the function code F20 "DC brake (Starting speed)", and the braking continues while the input signal is ON.

The longer period between F22 "DC brake (Braking time)" or the ON duration of the input signal *DCBRK* is selected.

Note that turning on the operation command will resume the operation. See also the description of the function codes F20 to 22.

| Input signal to select specified data | Action to be selected |
|---------------------------------------|-----------------------|
| 14 | |
| OFF | DC braking active |
| ON | DC braking inactive |

Function code data = 15 Clear ACC/DEC to zero -- *CLR*

During the UP/DOWN operation, this digital input signal clears the acceleration/deceleration speed and operates the inverter at 0 r/min or the creep speed specified by the C18 and 19 "Multistep speed".

Function code data = 16 Switch creep speed under UP/DOWN control -- *CRP-N2/N1*

The external digital input signal switches the creep speed at the UP/DOWN selector unit.

| Input signal to select specified data | Specified speed to be selected |
|---------------------------------------|---|
| 16 | |
| OFF | C18 Multistep Speed 15, N-15/Creep Speed 1, CREP1 |
| ON | C19 Multistep Speed 16, N-16/Creep Speed 2, CREP2 |

Function code data = 17 UP (Increase speed) -- *UP*

The external digital input signal increase the speed during the signal is ON. The maximum speed restricts the speed. The acceleration follows the specified acceleration time and S-curve acceleration.


Function code data = 18 DOWN (Decrease speed) -- *DOWN*

The external digital input signal decrease the speed during the signal is ON. The deceleration follows the specified deceleration time and S-curve deceleration. The current speed is maintained when the *UP* and the *DOWN* are pressed at the same time (no acceleration/deceleration).

There are three types of the UP/DOWN operations depending on the initial values. You can use the speed setting function (function code F01 or C25) to select them.

(1) UP/DOWN, Initial value = 0 r/min, N1 (F01)/N2 (C25) = 3

The following graph shows an operation with this function (The S-curve specification is not active in this example).




- A: Operates at 0 r/min speed command
- B: Accelerates in forward direction
- C: Fixed to the speed command value when [UP] is set to OFF
- D: Restricted by the maximum speed after acceleration in forward direction
- E: Decelerates in forward direction
- F: Fixed to the speed command value when [DOWN] is set to OFF
- G: Decelerates to stop
- H: Operates at 0r/min speed command value
- I: Accelerates in reverse direction
- J: Fixed to the speed command value when [UP] is set to OFF
- K: Resets to 0r/min when [CLR] is set to ON
- L: Accelerates in forward direction
- M: Simultaneous [UP] and [DOWN] are treated as OFF. Fixed to the speed command value when both [UP] and [DOWN] are turned ON
- N: Decelerates to stop
- O: Continues operation at the speed just after [FWD] is set to ON.

(2) UP/DOWN, Initial value = Last value), N1 (F01)/N2 (C25) = 4

The following graph shows an operation with this function (The S-curve specification is not active in this example).

The last value is defined as the speed command value adopted when the last operation command (FWD, REV) is turned OFF. The last value is stored in the non-volatile memory (memory that retains data even when the power has been switched OFF), and becomes effective when the power is supplied again.




- A: Accelerates in forward direction up to "+Last speed command value (speed command value just before the operation command is set to OFF)"
- B: Accelerates in forward direction
- C: Fixed to the speed command value when [UP] is set to OFF
- D: Restricted by the maximum speed after acceleration in forward direction
- E: Decelerates to stop. Fixed to the speed command value when [DOWN] is set to OFF
- F: Stores the speed as a last value when the [FWD] is set to OFF. Accelerates in forward direction to the last value when the [FWD] is set to ON. Decelerates to stop when the [FWD] is set to OFF.
- G: Accelerates in reverse direction up to "-Last speed command value"
- H: Accelerates in reverse direction
- I: Fixed to the speed command value when [UP] is turned OFF
- J: Resets to 0 r/min when [CLR] is turned ON
- K: Accelerates in forward direction
- L: Simultaneous [UP] and [DOWN] are treated as OFF. Fixed to the speed command value when both [UP] and [DOWN] are turned ON
- M: Decelerates to stop. Stores the speed as a last value when the [FWD] is set to OFF.
- N: Accelerates in forward direction up to "+Last speed command value".

(3) UP/DOWN, Initial value = Creep speed 1 or 2, N1 (F01)/N2 (C25) = 5

The following graph shows an operation with this function (The S-curve specification is not active in this example).

- You can use the terminal inputs **CRP-N2/N1** to select the creep speed 1 or the creep speed 2.
- You should specify the function code C73 "Creep speed switching (on UP/DOWN control)" to choose the function codes C18 and C19 or the analog input signals (**CRP-N1** and **CRP-N2**). See the description of the C73 for more details.
- Because priority is given on the clearing process even if [FWD] or [REV] is turned off while [CLR] is turned on, the motor speed remains the creeping speed.
- The creeping speed continues even if the creeping speed is decreased after it is reached.
- A: Converted into an absolute value and processed into the input creep speed.



- A: Accelerates in forward direction up to "+creep speed"
- B: Acceleration in forward direction
- C: Fixed to the speed command value when [UP] is turned OFF
- D: Restricted by the maximum speed after acceleration in forward direction
- E: Decelerates in forward direction down to "+creep speed"
- F: Deceleration to stop
- G: Accelerates in reverse direction to "-creep speed"
- H: Acceleration in reverse direction
- I: Fixed to the speed command value when [UP] is turned OFF
- J: Resets to creep speed when [CLR] is set to ON
- K: Deceleration to stop
- L: Acceleration in forward direction
- M: Simultaneous [UP] and [DOWN] are treated as OFF. Fixed to the speed command value when both [UP] and [DOWN] are turned ON
- N: Deceleration to stop
- O: If [FWD] is turned off temporarily and restored again during deceleration, the speed at the timing of activation of FWD is held if the speed is equal to or larger than the creeping speed. If the speed has dropped below the creeping speed, the speed increases to the creeping speed upon activation of FWD.

Function code data = 19 Enable data change with keypad -- WE-KP

This function enables changes to the function codes through the KEYPAD panel only when the digital input signal **WE-KP** is applied to prevent unauthorized changes. You can make changes when 19 is not assigned to a terminal. This function enables/disables changes through the KEYPAD panel. Use "Write enable through link" to enable/disable changes through the link.

| Input signal to select specified data | Function to be selected |
|---------------------------------------|--------------------------|
| 19 | |
| OFF | Changes to data disabled |
| ON | Changes to data enabled |

Note: You cannot change the function codes if you set this data to a terminal by mistake. If this is a case, set ON to the terminal, and then set a correct data.

Function code data = 20 Cancel PID control -- KP/PID

The external digital input signal disables the PID control.

| Input signal to select specified data | Function to be selected |
|---------------------------------------|-------------------------|
| 20 | |
| OFF | PID control enabled |
| ON | PID control disabled |

Function code data = 21 Switch normal/inverse operation -- IVS

The external digital input signal switches the direction of the motor rotation.

| Input signal to select specified data | Rotation direction to be selected | | Normal/inverse |
|---------------------------------------|-----------------------------------|------------------|-------------------|
| | FWD command | REV command | |
| 21 | Forward rotation | Reverse rotation | Normal operation |
| OFF | Forward rotation | Reverse rotation | Normal operation |
| ON | Reverse rotation | Forward rotation | Inverse operation |

Function code data = 22 Interlock (52-2) -- IL

When a magnetic contactor is provided to the output of the inverter, this magnetic contactor (52-2) opens to slow down the voltage drop in the DC circuit at a momentary power failure. As a result, the inverter may not detect the power failure to recover from the momentary power failure smoothly.

In such a case, use an external device to give a digital signal for informing the inverter of the momentary power failure.

The motor will restart smoothly after the power failure. Valid if the setting of F14 (restart after momentary power failure (action selection)) is "3," "4" or "5."

| Input signal to select specified data | Function to be selected |
|---------------------------------------|--|
| 22 | |
| OFF | Momentary power failure detection through digital input disabled |
| ON | Momentary power failure detection through digital input enabled |

Function code data = 23 Enable data change via communications link -- WE-LK

This function enables changes to the function codes through RS-485, T-Link, SX, or field bus only when the digital input signal is applied to prevent unauthorized changes. You can make changes when 23 is not assigned to a terminal. Use aforementioned "Write enable for KEYPAD" to enable/disable changes through the KEYPAD.

| Input signal to select specified data | Function to be selected | Applicable communication system |
|---------------------------------------|--------------------------|---------------------------------|
| 23 | | |
| OFF | Changes to data disabled | Integrated RS-485 |
| ON | Changes to data enabled | T-Link, SX-bus, Fieldbus |

Note: This function does not restrict the writing to the function code S (such as operation command, speed command) areas dedicated to the communication system. The next function "Operation selection through link" enables/disables writing to the S area.

Function code data = 24 Enable communications link -- LE

The external digital input enables/disables the speed command and the operation command through the link (communication system). Assign a data 24 to a desired digital input terminal and the input signal applied to it switches between the enabled state and the disabled state.

When the operation selection is enabled or this function is not assigned, you can specify the sources of commands.

| Input signal to select specified data | Function to be selected |
|---------------------------------------|---|
| 24 | |
| OFF | Link commands disabled (link disabled regardless of setting by H30) |
| ON | Link commands enabled (setting by H30 enabled) |


When the link is enabled, the following priority applies if speed commands and operation commands come from multiple communication systems.

| Priority | Operation command (FWD, REV), speed command | Description of source of commands |
|----------|---|---|
| 1 | Field options | One option selected from T-Link, SX-bus, and fieldbus can be installed at a time. |
| 2 | Integrated RS-485 | Disabled when the option above is installed. |

<Application example 1>

When you specify the operation command and the speed command from the KEYPAD panel and use the terminal function [LE] to switch to the operation command and the speed command from the PLC, the KEYPAD panel will be enabled if the terminal [LE] is OFF, and the PLC will be enabled if the terminal [LE] is ON.


The description "Not assigned (*)" in the following table on the next page indicates that a function 24 [LE] is not assigned to an X function terminal. If this is a case, the setting by the function code H30 becomes effective. The PLC operation requires option cards (If you use RS-485, an integrated function is available). See the descriptions of the option or RS-485 for more details.



| | Set value | Description | Terminal [LE] | | |
|-----------------------------|-----------|--|---------------|----------|------------------|
| | | | OFF | ON | Not assigned (*) |
| Function code specification | F01 = 0 | Operation command from KEYPAD panel | Enabled | Disabled | |
| | F02 = 0 | Speed command from KEYPAD panel | | | |
| | H30 = 3 | Initial setting enabling both speed command and operation command through link (PLC) | Disabled | Enabled | |

<Application example 2>

When you select the operation command from the external signal ([FWD], [REV]) and the speed command from the analog terminal [12] input (0±10V) or the RS-485 communication (from master device such as a personal computer) using [LE] function, the analog terminal [12] will be enabled if the terminal [LE] is OFF, and the RS-485 will be enabled if the terminal [LE] is ON.



If you use RS-485, an integrated function is available. See the descriptions of RS-485 for more details.

| | Set value | Description | Terminal [LE] | | |
|-----------------------------|-----------|--|--|----------|------------------|
| | | | OFF | ON | Not assigned (*) |
| Function code specification | F01 = 1 | Operation command from [FWD] and [REV] | Enabled (External signal is always selected) | | |
| | F02 = 1 | Speed command from analog input at terminal [12] | Enabled | Disabled | |
| | H30 = 1 | Initial setting enabling only speed command from link (RS-485) | Disabled | Enabled | |

Function code data = 25 Universal DI -- U-DI

You can assign a data 25 to a digital terminal to designate it as a universal DI terminal. This function is provided to check the existence of an input signal through communication and does not affect the inverter operation.

There are following applications for this signal.


- 1) Check the ON/OFF state of the input signal through RS-485, T-Link, SX-bus, or fieldbus.
- 2) Use for an input to software created with the UPAC option without affecting the inverter operation.

<Application example>

You do not have enough numbers of I/O and want to use inverter control terminals to switch the control of a PLC program. If you choose [X1] as a control terminal:

- 1) Set the function code E01 "X1 function selection" to 25. This specification makes this input neglected by the inverter.
- 2) Use the PLC to read out (polling) the function code M13 "Operation method (final command)" through communication.
- 3) Since the data type of M13 is 32 (type), refer to the bit assignment under that data type to check the corresponding bit of X1 input.

Note that you can read out input information of an input terminal using the code M13 without assigning the *U-DI* to the terminal. The significance of the assignment is to avoid activating an assigned function to the terminal unless you do not assign the *U-DI*.



Function code data = 26 Enable auto search for idling motor speed at starting -- STM

The external digital input signal enables/disables the function H09 "Start mode (Auto search)".

When inverter is in "vector control of induction motor with PG" mode (P01 = 0) or "vector control of synchronous motor with PG" mode (P01 = 3), the starting mode (auto search) is always enabled.

Assign a data 26 to a desired digital input terminal and the input signal applied to it switches between the enabled state and the disabled state.

| Input signal to select specified data | Function to be selected |
|---------------------------------------|--|
| 26 | |
| OFF | Follow the setting of H09 (startup characteristics (rotating motor pickup mode)). |
| ON | The startup characteristics function is valid irrespective of the setting of H09 (rotating motor startup characteristics (pickup mode)). |

Function code data = 27 Synchronization operation command (PG (PR) optional function) -- *SYC*

This function switches between the speed command converted from a pulse train received as a position command via the position control and other speed command. You can use this function for a synchronized operation. You need an optional PG (PR).

Assign a data 27 to a desired digital input terminal and the state of the input signal applied to it selects the function.


| Input signal to select specified data | Function to be selected |
|---------------------------------------|---|
| 27 | |
| OFF | Synchronized speed disabled (Other speed command enabled) |
| ON | Synchronized speed enabled |

Also see E29 "PG pulse output selection", o12 to 19 "PG (PR) options", and the description on the PG (PR) options.

Note that the Zero speed locking command **LOCK** is disabled during the pulse train position control with **SYC**.

<Application example 1> Synchronized operation by receiving pulse


Apply a pulse train signal from the external pulse generator to the PG (PR) options of multiple inverters to be synchronized. The position command received by the option is converted into a synchronized speed command and the **SYC** enables the speed command.



<Application example 2> Synchronized operation by pulse generation

Pulse signal converted (oscillated) from an internal speed command (such as [12] input or multistep speed command) is also converted into a speed command through the position control and the *SYC* enables the resulting speed command. You can put the converted pulse signal to the output and apply it to the other inverters to synchronize the inverter with other inverters.

The motor speed of the master and the PG pulse number determines the pulse frequency. When you use a PG with 1024 P/R at 1500 r/min, the frequency is $1500 \times 1024 / 60 = 25.6$ kHz. The pulse compensation is available on the slave side. See the function codes o14 and o15 or the PG (PR) option for more details.




The complete synchronization (± 2 pulses or less) is possible both in the application example 1 and 2 during both transient and steady states.

About differences in methods

| Method | Merits | Demerits |
|--|---|---|
| <Application example 1> Synchronized operation by receiving pulse | No position deviation | One PG (PR) option necessary Pulse generator necessary |
| <Application example 2> Synchronized operation by pulse generation | No position deviation One PG (PR) option can be omitted. No pulse generator | None |
| Master-slave operation (Master directly applies its PG signal to slaves) | None | Position deviation |

<Application example> Synchronized operation for three or more inverters

Set E29 "PG pulse output selection" to 9 to directly supply the position command applied to the PG (PR) option to the [FA] and the [FB] of the integrated PG.




Function code data = 28 Lock at zero speed -- LOCK

The external digital input signal conducts servo lock. Assign data 28 **LOCK** to a terminal and set the input signal ON.

| Input signal to select specified data | Function to be selected |
|---------------------------------------|--------------------------|
| 28 | Function to be selected |
| OFF | Normal state |
| ON | Zero speed locking state |

- 1) The inverter decelerates to stop (following an effective deceleration time setting) from the speed just after the **LOCK** is set to ON.
- 2) Position control (servo locking state) is applied with respect to the motor position (angle) when the speed command of the acceleration/deceleration calculation unit reaches to zero. The acceleration/deceleration calculation unit declines a step speed command directed by the user in a specified acceleration/ deceleration time.
- 3) You can supply a resistive torque up to the short-time rating. The function code H55 "Zero speed control (Gain)" and the speed control system (ASR gain) control the magnitude of the torque in relation to the position deviation (position error).
- 4) Balance the speed control (ASR) gain (function codes F and C) and the position control gain (H55) to adjust the gain. The system may become unstable to present low frequency hunting when you increase the setting of the H55 while leaving ASR gain small.



- 5) A signal indicating completed servo locking appears on the DO as "Synchronization completion signal" when the position deviation converges into the setting range of the H56 "Zero speed control (completion range)".

When PG (PR) option is used for synchronization control by pulse train, the zero speed locking command becomes invalid.

- 6) Because only one rotation is detected if the motor turns due to an external force after it is locked at zero speed, the DO output (synchronous control complete **SYC**) may be turned on each time the predetermined position passes.



Function code data = 29 Pre-excitation -- EXITE

The external digital input signal switches the inverter in pre-exciting state. Assign a data 29 to a desired digital input terminal and the state of the input signal applied to it selects the function. When the operation command (FWD, REV) is set to ON, the state changes from pre-exciting to normal.

| Input signal to select specified data | Function to be selected |
|---------------------------------------|-------------------------|
| 29 | |
| OFF | Normal state |
| ON | Pre-exciting state |

You can also use the function codes F72, F74 and F75 to start the pre-exciting. See also the description of these functions.

You can use the "Operation status" of the "I/O check" screen of the KEYPAD panel to see whether the inverter is in the pre-exciting state or in the normal state. The EXT indicates the pre-exciting state and the EXT indicates the normal operation. You can also read out the function code M14 "Operation status" through the link.



Function code data = 30 Cancel speed limiter -- N-LIM

The external digital input signal disables the speed command limiter. Assign a data 30 to a desired digital input terminal and the state of the input signal applied to it selects the function. See the description of the function code F76 for more information on the speed command limiter function.

| Input signal to select specified data | Function to be selected |
|---------------------------------------|-------------------------|
| 30 | |
| OFF | Speed limiter enabled |
| ON | Speed limiter disabled |

Function code data = 31 Cancel H41 (Torque command) -- H41-CCL

The external digital input signal cancels the setting specified by the H41 "Torque command selection" (0: internal ASR enabled). Assign a data 31 to a desired digital input terminal and the state of the input signal applied to it selects the function.

| Input signal to select specified data | Function to be selected |
|---------------------------------------|---|
| 31 | |
| OFF | H41 setting enabled |
| ON | H41 setting disabled (internal ASR enabled) |

Application

Use for applications that switch between speed control (internal ASR) and torque command control.

Function code data = 32 Cancel H42 (Torque current command) -- H42-CCL

The external digital input signal cancels the setting specified by the H42 "Torque current command" (0: internal ASR enabled). Assign a data 32 to a desired digital input terminal and the state of the input signal applied to it selects the function.

| Input signal to select specified data | Function to be selected |
|---------------------------------------|---|
| 32 | |
| OFF | H42 setting enabled |
| ON | H42 setting disabled (internal ASR enabled) |

Application

Use for applications that switch between speed control (internal ASR) and torque current command control.

Function code data = 33 Cancel H43 (Magnetic flux command) -- H43-CCL

The external digital input signal cancels the setting specified by the H43 "Magnetic-flux command selection" (0: internal calculation enabled). Assign a data 33 to a desired digital input terminal and the state of the input signal applied to it selects the function.

| Input signal to select specified data | Function to be selected |
|---------------------------------------|---|
| 33 | |
| OFF | H43 setting enabled |
| ON | H43 setting disabled (internal calculation enabled) |

Function code data = 34 Cancel F40 (Torque limiter mode 1) -- F40-CCL

The external digital input signal cancels the setting specified by F40 "Torque limiter mode 1" (0: limiter disabled). Assign a data 34 to a desired digital input terminal and the state of the input signal applied to it switches between the enabled state and the disabled state.

| Input signal to select specified data | Function to be selected |
|---------------------------------------|---|
| 34 | |
| OFF | F40 setting enabled |
| ON | F40 setting disabled (limiter disabled) |

Function code data = 35 Select torque limiter level 2/1 -- TL2/TL1

The external digital input signal switches the torque limiter value (level 1 or 2). Assign a data 35 to a desired digital input terminal and the state of the input signal applied to it switches between the level 1 and the level 2. This function is effective only when F41 "Torque limiter mode 2"=3.

| Input signal to select specified data | Function to be selected |
|---------------------------------------|---|
| 35 | |
| OFF | F42: Torque limiter value (level 1) selection |
| ON | F43: Torque limiter value (level 2) selection |


Function code data = 36 Bypass ACC/DEC processor -- BPS

The external digital input signal bypasses the acceleration/deceleration calculation unit to disable the acceleration/deceleration time and the S-curve specifications. Assign a data 36 to a desired digital input terminal and the state of the input signal applied to it switches between the enabled state and the disabled state.

(The resultant setting is the same as the acceleration/deceleration time: 0.00s and the S-curve acceleration/deceleration: 0%)

| Input signal to select specified data | | Function to be selected |
|---------------------------------------|--|--|
| 36 | | |
| OFF | | Acceleration/deceleration calculation unit enabled |
| ON | | Acceleration/deceleration calculation unit enabled |

The speed command from the acceleration/deceleration calculation unit follows the acceleration/deceleration and S-curve settings as shown in the figure. Setting the **BPS** to ON cancels these functions to control the motor speed following a step-form speed command.



Use the dedicated jogging operation function codes (C30 to C38), not the **BPS**, for jogging operation.

Restrictions

- When you use the **BPS**, control functions such as the UP/DOWN control and the active drive (when V/f control is selected) are also disabled.
- The **BPS** does not affect the auxiliary speed setting 2 and the PID calculation output (speed command). For details, refer to the control block diagrams.

| | | |
|---|--|--|
| ⚠ CAUTION | | |
| Setting the BPS ON accelerates/decelerates the motor rapidly and the motor may accelerate at its maximum permissible torque and decelerate down to the zero speed. Use the BPS after you confirm that these are permissible actions of the mechanical system and the braking devices you use. | | |
| You may be injured. | | |

Function code data = 37, 38 Select torque bias command -- TBI, TB2

The external input digital signals can be used to switch among three types of torque biases predetermined by F47 to 49 "Torque bias T1, T2, and T3". See the function code F47 to 49 for more details.

| Input signal combination to select specified data | | Torque bias to be selected |
|---|---------------|----------------------------|
| 38 TB2 | 37 TBI | |
| OFF | OFF | Torque bias disabled |
| OFF | ON | F47 torque bias T1 enabled |
| ON | OFF | F48 torque bias T2 enabled |
| ON | ON | F49 torque bias T3 enabled |

Function code data = 39 Select droop control -- DROOP

The external digital input signal switches between the droop control enabled state and the droop control disabled state. Assign a data 39 to a desired digital input terminal and the state of the input signal applied to it selects the function. See the function code H28 "Droop control" for more details.

| Input signal to select specified data | Function to be selected |
|---------------------------------------|-------------------------|
| 39 | Function to be selected |
| OFF | Droop control disabled |
| ON | Droop control enabled |

Function code data = 40 Zero-hold Ai1 -- ZH-AI1

Function code data = 41 Zero-hold Ai2 -- ZH-AI2

Function code data = 42 Zero-hold Ai3 (AIO optional function) -- ZH-AI3

Function code data = 43 Zero-hold Ai4 (AIO optional function) -- ZH-AI4

The external digital input signals fix the individual analog signals Ai1 to 4 to "0: input voltage invalid". Assign a data to a desired digital input terminal and the state of the input signal applied to it selects the function.

You need optional OPC-VG1-AIO for Ai3 and Ai4.

| Input signal to select specified data | Function to be selected |
|---------------------------------------|-------------------------|
| 40 to 43 | Function to be selected |
| OFF | Ai input enabled ON |
| ON | Ai input held to zero |

Function code data = 44 Reverse Ai1 polarity -- REV-AI1

Function code data = 45 Reverse Ai2 polarity -- REV-AI2

Function code data = 46


Reverse Ai3 polarity (AIO optional function) -- REV-AI3

Function code data = 47

Reverse Ai4 polarity (AIO optional function) -- REV-AI4

The external digital input signals invert the polarity of the input data from Ai1 to 4. Assign a data to a desired digital input terminal and the state of the input signal applied to it selects the function.


You need optional OPC-VG1-AIO for Ai3 and Ai4.



| Input signal to select specified data | Function to be selected |
|---------------------------------------|-------------------------|
| 44 to 47 | Function to be selected |
| OFF | Normal operation |
| ON | Inverted polarity |

Function code data = 48 Inverse PID output -- PID-INV

The external digital input signal switches the PID output *PIDOUT* between the normal operation and the inverse operation. Assign a data 48 to a desired digital input terminal and the state of the input signal applied to it selects the function.



| | |
|---------------------------------------|------------------------------|
| Input signal to select specified data | Function to be selected |
| 48 | |
| OFF | Normal PID output operation |
| ON | Inverse PID output operation |

Function code data = 49 Cancel PG alarm -- PG-CCL

The external digital input signal cancels the PG alarm (P_{PG}). This function is available when you select "vector control" for the function code P01, A01, or A101.

The inverter does not issue the alarm even when the PG wiring is disconnected during the input signal is ON. Assign a data 49 to a desired digital input terminal and the existence of the input signal cancels the PG alarm.

| | |
|---------------------------------------|--------------------------------|
| Input signal to select specified data | Function to be selected |
| 49 | |
| OFF | Normal operation |
| ON | PG alarm (P_{PG}) canceled |


Actions on detecting PG disconnection

| | | |
|------------------|-------------------------|--------------------------------|
| Alarm operation | <i>PG-CCL</i> = OFF | <i>PG-CCL</i> = ON |
| | Normal operation | PG alarm (P_{PG}) canceled |
| KEYPAD panel | Alarm mode | Operation mode |
| Alarm history | Recorded | Not recorded |
| Alarm DO output | PG disconnection output | No output |
| 30X relay output | Alarm output | No output |
| Inverter output | Shut down | Normal operation |

Application

Since this is a special function, limit your application to the following cases. When you use the function code E14 "X function normally open/normally closed", you can set to "normally closed (ON)" without actually short-circuiting terminals.

- 1) Use to apply the power to a system and test the system without connecting the PG signal.
- 2) When you use two motors by switching them with one unit, a momentary disconnection will present and the PG alarm (PG) is issued if the PGs are switched externally. Cancel the PG alarm (PG) at the sequence timing when the PGs are switched.
- 3) Monitoring the current on the signal line detects the PG disconnection. The false detection may occur when the PG wiring has high impedance causing low current. Usually **0.6 mA or less** is considered as a disconnection. If this is the case, you can operate with canceling the PG alarm as an emergency mean.



Operation with PG disconnected

A motor rotates at a slip frequency regardless of the speed command when the PG is disconnected (either PGP, PGM, PA, or PB is disconnected) and the PG alarm is canceled (**PG-CCL = ON**).

Since the calculation of the speed control system (ASR) will saturate and increase the torque command and the torque current command to the maximum, either the inverter overload (OL1) or the motor overloads (OL2, OL3) when you use an electronic thermal overload relay will enter the alarm mode (Note that if you invert the A phase and the B phase of the PG signal, it will present the same phenomenon).

If you are sure that the PG wiring is disconnected, do not operate with canceling the PG alarm.

<Control mechanism>

The vector control of the FRENIC-VG is a slip frequency type vector control. The inverter obtains the motor speed (ω_r) from the PG signal and the slip frequency (ω_s) from the current detection to determine the output frequency to the motor ($\omega_l = \omega_r + \omega_s$). In case of a PG disconnection, the motor speed is 0 ($\omega_r = 0$) and the output frequency to the motor becomes the **slip frequency ω_s** .

In the speed control system (ASR), since the motor speed (ω_r) does not follow the speed command (ω_r^*), the speed control system (ASR) conducts an integral operation (I constant of ASR) to increase the speed deviation ($\omega_r^* - \omega_r$) and the saturation is reached in a short period. The output of the ASR is the torque command and this torque command is fixed to the maximum value resulting in an overload alarm (OL1).

Function code data = 50 Cancel undervoltage alarm -- LU-CCL

The external digital input signal cancels the undervoltage alarm (L L'). When the input signal is ON, the alarm is canceled.

Assign a data 50 to a desired digital input terminal and the existence of the input signal cancels the undervoltage alarm (L L').

| | |
|---------------------------------------|------------------------------------|
| Input signal to select specified data | Function to be selected |
| 50 | |
| OFF | |
| ON | Undervoltage alarm (L L') canceled |

Actions on detecting undervoltage inside the inverter


| Alarm operation | LU-CCL = OFF | LU-CCL = ON |
|---|------------------|------------------------------------|
| | Normal operation | Undervoltage alarm (L L') canceled |
| KEYPAD panel | Alarm mode | Running mode |
| Alarm history | Recorded | Not recorded |
| Alarm DO output | Output | No output |
| DO output for Stopping on undervoltage [LU] | Output | No output |
| 30X relay output | Output | No output |
| Inverter output | Shut down | Normal operation |

Application

Since this is a special function, limit your application to the following cases.

- 1) When the control power is supplied via [R0] and [T0] separately, shutting down the main circuit power causes the inverter to detect an undervoltage alarm (L L') and enter the Alarm mode. To avoid the alarm, use **LU-CCL**.
- 2) To drive a lifting unit or the like at the time of a power failure, use **LU-CCL**. Inverters of 30 kW or below (200 V class series) or those of 55 kW or below (400 V class series) can run even on the voltage lower than the undervoltage level (180 V for 200 V class series and 360 V for 400 V class series) as long as the inverter runs at the low speed, so use **LU-CCL** when configuring a system using an uninterruptible power supply (UPS), battery, stand-by generator and so on.

Note: To run inverters of 37 kW or above (200 V class series) or those of 75 kW or above (400 V class series) on the voltage lower than the undervoltage level, it is necessary to connect terminals R1, T1 to power source and to switch the connector of fan power.



- 3) During cancellation of an undervoltage alarm, no parameter change or operation is allowed from the keypad as well as from Loader.

Function code data = 51 Hold Ai torque bias -- *H-TB*

The external digital input signal directs to preserve the torque bias data supplied via an analog input. Assign data 51 to a desired digital input terminal and the existence of the input signal preserves the analog data.

| Input signal to select specified data | Function to be selected |
|---------------------------------------|---------------------------|
| 51 | |
| OFF | Torque bias hold disabled |
| ON | Torque bias hold enabled |

Function code data = 52 STOP1 (Decelerate to stop with normal deceleration time) -- *STOP1*

The external digital input signal directs to decelerate to stop with the currently specified/effective deceleration time and S-curve decelerations on start/end sides.

Assign data 52 to a desired digital input terminal and the existence of the input signal activates the operation.

| Input signal to select specified data | Function to be selected |
|---------------------------------------|--|
| 52 | |
| OFF | Normal operation |
| ON | Deceleration to stop (effective deceleration time) |

Function code data = 53 STOP2 (Decelerate to stop with deceleration time 4) -- *STOP2*

The external digital input signal directs to decelerate to stop with the C67 "Deceleration time 4" and C68 and C69 "S-curve start/end side 4".

Assign data 53 to a desired digital input terminal and the existence of the input signal activates the operation.

| Input signal to select specified data | Function to be selected |
|---------------------------------------|--|
| 53 | |
| OFF | Normal operation |
| ON | Deceleration to stop (Deceleration time 4) |


Function code data = 54 STOP3 (Decelerate to stop with maximum braking torque) -- STOP3

Turning this external digital input signal ON causes the motor to decelerate to a stop with the maximum braking torque (or the torque limiter value in terms of the inverter maximum current when the torque limiter is disabled), ignoring the specified deceleration time. Note that, after the actual speed exceeds the rated speed the braking torque will be reduced.

When a braking unit (150% maximum torque) of the same capacity as the inverter is used, an overvoltage alarm (\overline{OL}) may occur during deceleration to a stop. To avoid the alarm, use a braking unit with one rank higher or set the torque limiter value (braking) to 150%.

Assign data 54 to a desired digital input terminal and the existence of the input signal activates the operation.

| Input signal to select specified data | Function to be selected | |
|---------------------------------------|-------------------------|--|
| 54 | Function to be selected | |
| OFF | | Normal operation |
| ON | | Deceleration to stop (with maximum braking torque) |



Function code data = 55 Latch DIA data -- DIA

Function code data = 56 Latch DIB data -- DIB

The external digital input signal enables to read in a data through the DI option (OPC-VG1-DIA, DIB). The data is read when the input signal *DIA* or *DIB* is ON and the data is held when the input signal *DIA* or *DIB* is OFF. See the DI option section for more details.


| Input signal to select specified data | Function to be selected | |
|---------------------------------------|-------------------------|----------------------|
| 55 | Function to be selected | |
| OFF | | Hold <i>DIA</i> data |
| ON | | Read <i>DIA</i> data |

| Input signal to select specified data | Function to be selected | |
|---------------------------------------|-------------------------|----------------------|
| 56 | Function to be selected | |
| OFF | | Hold <i>DIB</i> data |
| ON | | Read <i>DIB</i> data |

Function code data = 57 Cancel multiplex system -- MT-CCL

The external digital input signal cancels the multiwinding drive with SI (MWS) option (OPC-VG1-TBSI) and switches to the standard single winding motor drive. The function code to switch to the multiwinding drive is o33 "Multiwinding system".

The right figure shows easy connection for changing drives between 2-winding motor and single-winding motor. In this circuit, the slave unit does not need operation command or feedback of PG, NTC signals. With change of motors, PG and NTC signals must be changed as well as the 2nd power circuit. To change PG and NTC signals, use the DI option (OPC-VG1-CPG).



For details of the multiplex system, refer to the description of Options.

| Input signal to select specified data | Function to be selected when o33 = 1 (Multiwinding system) |
|---------------------------------------|--|
| 57 | |
| OFF | Multiwinding motor drive |
| ON | Single winding motor drive (Multiwinding cancelled) |

Function code data = 58 to 67 Custom Di1-Di10 -- C-DI1 to C-DI10

Di terminal for manufacturer. Do not assign.

Function code data = 68 Select load adaptive parameters 2/1 -- AN-P2/1 (Available soon)

Turning this signal ON or OFF selects the load adaptive parameter 2 or 1, respectively.

| Input signal to select specified data | Function to be selected |
|---------------------------------------|---------------------------|
| 68 | |
| OFF | Load adaptive parameter 1 |
| ON | Load adaptive parameter 2 |

Function code data = 69 Cancel PID components -- PID-CCL

When an integrated PID function is used, turning this signal ON zero-holds the PID output and clears the PID integral component memory.

| Input signal to select specified data | Function to be selected |
|---------------------------------------|---|
| 69 | |
| OFF | Do not zero-hold the PID output. |
| ON | Zero-hold the PID output. Clear the PID integral component memory. |

Function code data = 70 Enable PID FF component -- PID-FF

When an integrated PID function is used, turning this signal ON enables the feedforward component.

| Input signal to select specified data | Function to be selected |
|---------------------------------------|-----------------------------------|
| 70 | |
| OFF | Disable PID feedforward component |
| ON | Enable PID feedforward component |

Function code data = 71 Reset completion of speed limit calculation -- NL-RST (Available soon)

Turning this signal ON clears the load adaptive calculation result and calculates the limit speed again at the next acceleration time in the same direction.

| Input signal to select specified data | Function to be selected |
|---------------------------------------|--|
| 71 | |
| OFF | Do not reset completion of speed limit calculation |
| ON | Reset completion of speed limit calculation |

For details, refer to H214 to H227 (Load adaptive control parameter setting 2).

Function code data = 72 Toggle signal 1 -- TGL1**Function code data = 73 Toggle signal 2 -- TGL2**

Assigning toggle signals 1 and 2 to two X terminals enables the toggle monitor control. If either one of those signals is not assigned, the toggle monitor control becomes disabled.

■ What is toggle monitor control

The toggle monitor control monitors whether the inverter and the host equipment mutually *function normally*. The "*function normally*" means not "no alarm has occurred" but "CPUs and I/O devices of both the inverter and the host equipment have not stopped."

(1) Toggle monitor method

- This monitor is available to operations via the T-link, SX bus^(*1), E-SX bus^(*2) communications link.
- Operations via digital input terminals are not assumed.

When H30 = 2 or 3, the target bit is operated via the communications link.

The toggle control uses digital inputs on X11 to X14 and does not use those on X1 to X9.

Toggle data (PLC ⇒ VG1) uses 2 bits out of bits 11 to 14 of function code S06 [Type 32].

The host equipment uses the above 2-bit data to transfer toggle data to the inverter in the sequence of 00→01→10→11→00 at the constant cycle.

The inverter checks that the transferred toggle data is incremented.

If the inverter detects a toggle data error during running and the error is not recovered within the detection time specified by H144, then the inverter trips with an alarm ($F7r$ - F).

*1 For SX bus communication, the bus tact cycle of applications that send a transmission toggle at the MICREX-SX side should be 1 ms or more.

*2 As well, for E-SX but communication, the bus tact cycle should be 0.5 ms or more

(2) Toggle error detection alarm ($\overline{F7-F}$)


The toggle error detection alarm ($\overline{F7-F}$) is treated as a heavy alarm.

H144 specifies the toggle signal error detection time.

| No. | Parameter name | Data setting range | Initial value | Remarks |
|------|-------------------------|--------------------|---------------|--|
| H144 | Toggle data error timer | 0.01 to 20.00 s | 0.10 s | Acts as a toggle signal error monitor timer. |

A toggle error detection alarm ($\overline{F7-F}$) occurs upon detection of any of the following conditions when a run command is given via the communications link or during running initiated by an auxiliary excitation command or DC braking command.

- When a toggle signal has never been changed, a run command or **EXITE** ("Pre-excitation")/**DCBRK** ("Enable DC braking") is entered.




The 2-bit signal has never been changed after the power was turned ON.



Note: When the power is turned ON, a run command is entered with the start of toggle signal monitor, an alarm $\overline{F7-F}$ is issued. Therefore, enter a run command after at least one cycle of toggle signal like 00→01→10→11.


- During running, no change has occurred in a toggle signal for more than the detection time specified by H144.




- During running, a toggle signal does not respond in the sequence of 00→01→10→11.

If a change in a toggle signal is abnormal, the inverter immediately trips as a PLC program error. After detection of the error, normal sequence (00→01→10→11) of 2-bit signals is judged as a normal recovery.

Alarm occurrence example 1



Alarm occurrence example 2 (Normal recovery after detection of an alarm)



Note: If a toggle error detection alarm (F_{i-r}) occurs during pre-excitation or DC braking, disable (turn OFF) the **EXCITE** or **DCBRK** command, respectively. If the command remains enabled (ON), turning the alarm reset signal ON causes repeating of instantaneous cancellation and recurrence of F_{i-r} alarm (chattering).

Function code data = 74 Cause external mock alarm -- FTB

This external digital input signal causes a mock alarm (E_{i-r}) in the inverter.

The factory default of this signal is Normal open contact.

When terminals [FTB] and [CM] are opened, it is treated as normal. Closing those terminals shuts down the inverter output so that the motor coasts to a stop.

For setting to use as Normal close contact, refer to the description of external alarm (E_{i-r}).

Function code data = 75 Cancel NTC thermistor alarm -- NTC-CCL

This external digital input signal cancels an NTC thermistor wire break alarm (r_{i-r}).

Function code data = 76 Cancel lifetime alarm signal -- LF-CCL

This external digital input signal cancels a lifetime alarm signal **LIFE**.

Function code data = 78 Switch PID feedback signals -- PID-1/2

This external digital input signal switches between the PID feedback 1 **PID-FB1** and PID feedback 2 **PID-FB2**, which are assigned to analog input terminals.

| Input signal to select specified data | PID feedback to be selected (Analog input terminal) |
|---------------------------------------|--|
| 78 | |
| OFF | 15: PID feedback 1 PID-FB1 |
| ON | 27: PID feedback 2 PID-FB2 |

Function code data = 79 Select PID torque bias -- TB-PID

This external digital input signal enables PID output to be used as a torque bias.


| Input signal to select specified data | Function to be selected |
|---------------------------------------|-------------------------------------|
| 79 | |
| OFF | Disable PID output as a torque bias |
| ON | Enable PID output as a torque bias |

| | |
|------------|--|
| E14 | X Terminal Function (Normal open/close) |
|------------|--|

E14 configures terminals [X1] to [X9] individually as a "normal open" or "normal close" contact by software when they have no connections.

OP: Normal open
 CL: Normal close

Use this function for configuring a "normal close" contact for terminal command **THR** ("Enable external alarm trip"), for example.



Configuration change example via the RS-485 communications link

To configure terminal [X9] (**THR**) as a "normal close" contact and other X terminals, as a "normal open" contact, use the following.

- (1) Assign bits in accordance with format [35]. Refer to Chapter 4, Section 4.2.4.2 "Data type 12-145."
 To configure terminal [X9] as a "normal close" contact, the bit assignment is 0000 0001 0000 0000 (in binary).
- (2) Convert the bit assignment from binary to hexadecimal format.
 0000 0001 0000 0000 (binary) = 0100 (hexadecimal)
 Set the hexadecimal data to E14 for configuring terminal [X9].

| | | | | | | | | | | | | |
|---|---|---|---|--|---|---|---|---|---|---|--|--|
| E | 1 | 4 | X | | N | O | R | M | A | L | | |
|---|---|---|---|--|---|---|---|---|---|---|--|--|

E15 to E27**Y Terminal Function**

Part of control signals and monitor signals can be selected and output to the terminals [Y1] to [Y18] and [Y5A]. The transistor signals are output to the terminals [Y1] to [Y18] and the relay contact signal to [Y5A]. Use of terminal functions from [Y11] to [Y18] requires the optional OPC-VG1-DIOA.

The valid and invalid functions vary according to the drive control (vector control for IM with/without speed sensor, vector control without speed sensor, V/f control and vector control for PMSM with speed sensor). For details, refer to the function code tables in Section 4.2.


<Using digital output>

You can use a total of 13 terminals, which are five terminals from Y1 to Y4 and Y5A as standard and eight terminals from Y11 to Y18 (when a DIOA option is used). Similarly to the link function (RS-485, T-Link, SX, Field Bus), you can refer to the output of 13 points through the communications link.

You can use the function codes M52, M53, M54, M142, M143 and M144 (control output 1 to 6) to read all information (85 bits in total) that are available for the DO outputs through the communications link (RS-485, T-Link, SX bus, and fieldbus) and UPAC. For details, refer to M52 to M54 (data types 125 to 127) and M142 to M144 (data types 128 to 130) in the function code tables.

Setting procedure

- Select a function you want to use. We select the "Operation ready output" command as an example.
- Assign the "Operation ready output" command to one of the available terminals (Y1 to Y4, Y5A, Y11 to Y18). If you want to assign it to Y3, write a data, "14:RDY", to the function code E17 "Y3 function selection".
- Y3 terminal is set to ON after you turn on and the operation becomes ready.
- See the "I/O check" screen of the KEYPAD panel to confirm the ON/OFF status of the Y3. If you switch the Y3 from OFF to ON, Y3 changes to Y3 on the screen shown on the right.



<You can specify as "NO terminal" or "NC terminal">

You can use the function code E28 to specify the state of individual terminals (standard 5 terminals only) as normally open ("NO terminal") or normally closed ("NC terminal"). See the function description of E28 for more information.

| | | | | |
|-------|-------|---------|--|--|
| E 1 5 | Y 1 | F U N C | | |
| E 1 6 | Y 2 | F U N C | | |
| E 1 7 | Y 3 | F U N C | | |
| E 1 8 | Y 4 | F U N C | | |
| E 1 9 | Y 5 | F U N C | | |
| E 2 0 | Y 1 1 | F U N C | | |
| E 2 1 | Y 1 2 | F U N C | | |
| E 2 2 | Y 1 3 | F U N C | | |
| E 2 3 | Y 1 4 | F U N C | | |
| E 2 4 | Y 1 5 | F U N C | | |
| E 2 5 | Y 1 6 | F U N C | | |
| E 2 6 | Y 1 7 | F U N C | | |
| E 2 7 | Y 1 8 | F U N C | | |

Data setting range: 00 to 84

| Function code data | Terminal commands assigned | Symbol | Function code data | Terminal commands assigned | Symbol |
|--------------------|--|--------------|--------------------|--|------------------------|
| 00 | Inverter running | RUN | 24 | Resetting | TRY |
| 01 | Speed valid | N-EX | 25 | Universal DO | U-DO |
| 02 | Speed agreement 1 | N-AG1 | 26 | Heat sink overheat early warning | INV-OH |
| 03 | Speed arrival signal | N-AR | 27 | Synchronization completion signal | SY-C |
| 04 | Speed detected 1 | N-DT1 | 28 | Lifetime alarm | LIFE |
| 05 | Speed detected 2 | N-DT2 | 29 | Under acceleration | U-ACC |
| 06 | Speed detected 3 | N-DT3 | 30 | Under deceleration | U-DEC |
| 07 | Undervoltage detected (Inverter stopped) | LU | 31 | Inverter overload early warning | INV-OL |
| 08 | Torque polarity detected (braking/driving) | B/D | 32 | Motor overheat early warning | M-OH |
| 09 | Torque limiting | TL | 33 | Motor overload early warning | M-OL |
| 10 | Torque detected 1 | T-DT1 | 34 | DB overload early warning | DB-OL |
| 11 | Torque detected 2 | T-DT2 | 35 | Link transmission error | LK-ERR |
| 12 | Keypad operation enabled | KP | 36 | In limiting under load adaptive control | ANL |
| 13 | Inverter stopped | STOP | 37 | In calculation under load adaptive control | ANC |
| 14 | Inverter ready to run | RDY | 38 | Analog torque bias being held | TBH |
| 15 | Magnetic flux detected | MF-DT | 39-48 | Custom Do1 to Do10 | C-DO1 to C-DO10 |
| 16 | Motor M2 selected | SW-M2 | | | |
| 17 | Motor M3 selected | SW-M3 | 49 | - | - |
| 18 | Brake release signal | BRK | 50 | - | - |
| 19 | Alarm content 1 | AL1 | 51 | Multiplex system communications link being established | MTS |
| 20 | Alarm content 2 | AL2 | 52 | Answerback to cancellation of multiplex system | MEC-AB |
| 21 | Alarm content 4 | AL4 | 53 | Multiplex system master selected | MSS |
| 22 | Alarm content 8 | AL8 | 54 | Multiplex system local station failure | AL-SF |
| 23 | Cooling fan in operation | FAN | 55 | Stopped due to communications link error | LES |

| Function code data | Terminal commands assigned | Symbol | Function code data | Terminal commands assigned | Symbol |
|--------------------|---|---------------|--------------------|---------------------------------------|---------------|
| 56 | Alarm output (for any alarm) | ALM | 72 | Turn ON Y-terminal test output | Y-ON |
| 57 | Light alarm | L-ALM | 73 | Turn OFF Y-terminal test output | Y-OFF |
| 58 | Maintenance timer | MNT | 74 | - | - |
| 59 | Braking transistor broken | DBAL | 75 | System clock battery lifetime expired | BATT |
| 60 | DC fan locked | DCFL | 76 | - | - |
| 61 | Speed agreement 2 | N-AG2 | 77 | SPGT battery warning (Available soon) | SPGT-B |
| 62 | Speed agreement 3 | N-AG3 | 78 | - | - |
| 63 | Axial fan stopped | MFAN | 79 | - | - |
| 64 | - | - | 80 *1 | EN terminal detection circuit failure | DECF |
| 65 | - | - | 81 *1 | EN terminal OFF | ENOFF |
| 66 | Answerback to droop control enabled | DSAB | 82 *1 | Safety function in progress | SF-RUN |
| 67 | Answerback to cancellation of torque command/torque current command | TCL-C | 83 | - | - |
| 68 | Answerback to cancellation of torque limiter mode 1 | F40-AB | 84 *1 | STO under testing | SF-TST |
| 71 | 73 ON command | PRT-73 | | | |

*1 Function code data 80 to 82 and 84 are available in the ROM version H1/2 0020 or later.

Function code data = 00 Inverter running -- RUN


"Running" is defined as a state when the inverter supplies output. This signal is ON when the inverter is running and OFF when the inverter is stopping.

The inverter does not stop when it is decelerating after you turn OFF the FWD or the REV signal. The inverter shuts down the output and stops when the speed becomes less than the speed specified by F37 "Stop speed" and the zero speed continues for the time specified by F39 "Zero speed holding time". The status is running during DC braking, pre-exciting, and servo locking (synchronized control completed).

Function code data = 01 Speed valid -- N-EX

Turns ON when the absolute value of the speed command or the actual speed is more than the value specified by the function code F37 "Stop speed", and OFF when the value is less than the "Stop speed".

You can use the function code F38 "Stop speed (Detection method)" to select either the speed command or the actual speed.



Function code data = 02 Speed agreement 1 -- N-AG1

Turns ON when motor M1 is selected and the actual speed value falls in the detection range specified by the speed command value (Reference speed 4: ASR input).

See the function description of E44 "Speed agreement (Detection range) (Off delay timer)" and E45 "Enable/disable alarm for speed disagreement".

When motor M1 is not selected, this signal is always OFF.

Function code data = 03 Speed arrival signal -- *N-AR*

Turns ON when the actual speed value reaches the speed command value (Speed command 1: acceleration/deceleration calculation unit input). See the function description of E42.

Function code data = 04, 05, 06 Speed detected 1, 2, 3 -- *N-DT1, N-DT2, N-DT3*

Turns ON when the observed speed reaches the Speed detection level 1 (E39), level 2 (E40), or level 3 (E41). See the function description of E39, 40, and 41.

Function code data = 07 Undervoltage detected (Inverter stopped) -- *LU*

Turns ON when the undervoltage protective function is active, or the DC link circuit voltage of the main circuit decreases down below the undervoltage detection level. This function is not active when the "undervoltage alarm cancel" signal is ON.

This signal turns OFF when the voltage recovers to exceed the undervoltage detection level.

Undervoltage detection level: 180 V for 200 V class series and 360 V for 400 V class series

Function code data = 08 Torque polarity detected (braking/driving) -- *B/D*

Provides a signal indicating whether the torque is for driving or for braking by detecting the polarity of the calculated torque inside the inverter.

Turns OFF for the driving torque and turns ON for the braking torque.




Function code data = 09 Torque limiting -- *TL*

Turns on when the torque command is limited by the torque limiter 1 or 2.

Function code data = 10, 11 Torque detected 1, 2 -- *T-DT1, T-DT2*

Turns on when the torque command increases over the Torque detection level 1 or 2 (E46 or E47).

Function code data = 12 Keypad operation enabled -- *KP*

Turns ON when the operation command keys (, , ) directing running/stopping are effective (F02 "Operation method"=0).

Function code data = 13 Inverter stopped -- *STOP*

Supplies an inverted signal of the [RUN] signal indicating zero speed. Provides the ON signal during DC braking, pre-exciting, and servo locking (synchronized control completed).

Function code data = 14 Inverter ready to run -- *RDY*

Turns ON when the inverter is ready for the operation, for example, the power supply to the main and the control circuits are established or the inverter protective function is not active. Under a normal condition, the inverter becomes ready in about one second after you turn on. During operation with the UPAC option (o38 ≠ 0), [RDY] is turned on upon UPAC operation in addition to the above-mentioned condition. (It takes about 2 or 3s.)

This signal is turned off if the coast-to-stop command is turned on.

When the SX bus interface card (OPC-VG1-SX) or E-SX bus interface card (OPC-VG1-ESX) is mounted, the ON-conditions of *RDY* are as follows.

When commands via the SX bus or E-SX bus are enabled (H30 = 2 or 3 and *LE* = ON), *RDY* comes ON the moment the SX bus or E-SX bus becomes ready to communicate.

When commands via the SX bus or E-SX bus are disabled (H30 = 0 or 1 or *LE* = OFF), *RDY* comes ON as usual.

Function code data = 15 Magnetic flux detected -- *MF-DT*

Turns ON when the calculated magnetic-flux value exceeds the magnetic-flux detection level (E48-5%).

Function code data = 16, 17 Motor M2, M3 selected -- SW-M2, SW-M3

Provides the motor switching signal to the magnetic contactor for a motor according to the selected motor M1, M2, or M3 selected by the function code F79 or X control terminal.

| Combination of the output signals | | Motor to be selected |
|-----------------------------------|-------|----------------------|
| SW-M2 | SW-M3 | |
| OFF | OFF | Motor 1 |
| OFF | ON | Motor 2 |
| ON | OFF | Motor 3 |

Function code data = 18 Brake release signal -- BRK (Not available under V/f control)


Provides the mechanical brake apply/release signal.

There are the torque bias (F47 to F50), torque detection levels 1 and 2 (E46, E47), magnetic-flux detection level (E48) and speed command detection level (H135, H136) as parameters (user-defined) for releasing (opening) brake.

There are the speed detection level 1 (E38, E39), speed decrease detection delay timer (H134, H137, H138) and speed command detection level (H135, H136) as parameter for applying brake.

Usually you should assign the brake releasing signal to the relay output (Y5A and Y5C) of the FRENIC-VG standard DO. This signal is connected to the external mechanical brake (BRX relay). The action of the mechanical brake is "NC contact".

Y5A-Y5C: Closing this releases brake and opening this applies brake.



Servo locking function (braking not by a mechanical brake but by the inverter output torque) is also available. See the zero speed locking command in E01 to E13 "X function selection" for more details. We recommend to use the servo lock function not independently but together with a mechanical brake.

< Setting >

Brake release sequence

When all of the following conditions 1) to 6) are met, **BRK** ("Brake release signal") is turned ON to release the mechanical brake.

- 1) **RDY** ("Inverter ready to run") ON
After main power ON → DC link bus voltage established → initialization completed, **RDY** comes ON.
- 2) Current detection
If the inverter detects current of 30% or more of the P08 (M1 exciting current), A10 (M2 exciting current) or A110 (M3 exciting current) when M1, M2 or M3 is selected, respectively, it judges the state as "current detected."
- 3) Completion of torque bias startup
Torque bias can be added with F46 (Mechanical loss compensation), F47 to F49 (Torque bias T1 to T3) and F50 (Torque bias startup timer). The inverter defines the elapse of the time specified by F50 as completion of torque bias startup.
When no torque bias is added, the inverter judges **RUN** ("Inverter running") ON as completion of torque bias startup.
- 4) Both **FWD** ("Run forward") and **T-DT1** ("Torque detected 1") ON, or both **REV** ("Run reverse") ON and **T-DT2** ("Torque detected 2") ON
For **FWD**, specify the torque detection level 1 with E46; for **REV**, specify the torque detection level 2 with E47. When the torque command comes to be the torque detection level 1/2 or above, **T-DT1** or **T-DT2** is turned ON, respectively.
- 5) **MF-DT** ("Magnetic-flux detected") ON
This signal is turned ON when the calculated magnetic-flux value comes to be "Magnetic-flux detection level (E48) - 5%" or above.
- 6) **N-DT1** ("Speed detected 1"), **N-DT2** ("Speed detected 2") or **N-DT3** ("Speed detected 3") ON
For **FWD** or **REV**, the speed detection signal is turned ON when the reference speed (before acceleration/deceleration) comes to be the speed command detection level (H135 or H136) or above.

Brake applying sequence

When any one of the following conditions 1) to 6) is met, **BRK** ("Brake release signal") is turned OFF to apply the mechanical brake.

- 1) Both run command (**FWD** or **REV**) and **N-DT1** ("Speed detected 1") OFF
Specify the speed detection mode with E38 and the speed detection level 1 with E39. When "**N-FBI±** ("Detected speed 1") / **N-REF4** ("Reference speed 4") ≤ (Speed detection level (E39) - 1% of maximum speed)," **N-DT1** goes OFF.
If the speed detection level 1 (E39) is 1% or below of the maximum speed, **N-DT1** goes OFF when "**N-FBI±** ("Detected speed 1") / **N-REF4** ("Reference speed 4") = 0 (r/min).
Note: Under vector control without speed sensor, select **N-REF4** ("Reference speed 4"). (E38 = 1**).
- 2) **RDY** ("Inverter ready to run") OFF
- 3) **RUN** ("Inverter running") OFF
- 4) Inverter protective function (alarm) activated
- 5) **N-DT1** ("Speed detected 1"), **N-DT2** ("Speed detected 2") or **N-DT3** ("Speed detected 3") ON
For **FWD** or **REV**, the speed detection signal is turned ON when both the reference speed (before acceleration/deceleration) and the reference speed (after acceleration/deceleration) drops to "Speed command detection level (H135 or H136) - 0.5%" or below.
(When H135 or H136 = 0.0 r/min, this condition is invalid.)
- 6) When the detected speed is kept at the speed decrease detection level (H137) or below during the time specified by the speed command detection delay timer (H138), the brake is applied irrespective of the presence of a run command.
(When H137 = 0.0 r/min, this condition is invalid.)

Starting speed/Stop speed

Brake application and release timings can be adjusted with the starting speed (F23, F24) and stop speed (F37 to F39).

(1) At the time of start

Starting speed without torque bias:

In order not to release brake during acceleration, set the starting speed (F23) to 0.1 r/min or above and set the torque detection level 1, 2 (E46, E47) so that **T-DT1** or **T-DT2** ("Torque detected 1 or 2") comes ON within the holding time (F24).


Starting speed with torque bias:

Set the starting speed (F23) to 0.0 r/min and set the torque detection level 1, 2 (E46, E47) so that **BRD** ("Brake release signal") comes ON within the holding time (F24).

(2) At the time of stop

Adjust the braking conditions to apply brake within the zero speed control holding time (F39).

Specifying the zero speed control (F37 = 0.0 r/min) and the speed detection level 1 (E39 = 0 r/min) enables **BRD** ("Brake release signal") to go off after the motor (machine) stops completely.



Function code data = 19, 20, 21, 22 Alarm content -- AL1, AL2, AL4, AL8

Provides the operation status of the inverter protection function.

| Alarm description (Inverter protective function) | Output terminal | | | |
|--|-----------------|-----|-----|-----|
| | AL1 | AL2 | AL4 | AL8 |
| No alarm | OFF | OFF | OFF | OFF |
| Overcurrent (<i>EF, OL</i>) | ON | OFF | OFF | OFF |
| Overvoltage (<i>OU</i>) | OFF | ON | OFF | OFF |
| Undervoltage (<i>LU</i>) | ON | ON | OFF | OFF |
| Main circuit error (<i>dCF, Pbf, dbA, ECF</i>) | OFF | OFF | ON | OFF |
| CPU system error (<i>Er 1, Er 3, Er 8, Er A*1</i>) Functional safety card error (<i>S iF*1, S rF*1</i>) | ON | OFF | ON | OFF |
| Overheat (<i>dbH, OH 1, OH 3, OH 4, dFA</i>) | OFF | ON | ON | OFF |
| Overload (<i>OL 1, OL 2, OL 3, OLU</i>) | ON | ON | ON | OFF |
| Speed error (<i>dO, Er 9, OS, LDC</i>) | OFF | OFF | OFF | ON |
| Input phase loss (<i>L ir, DIPL</i>) | ON | OFF | OFF | ON |
| Inverter output circuit error (<i>Er 7</i>) | OFF | ON | OFF | ON |
| Communication error (<i>Er 2, Er 4, Er 5, Er b</i>) | ON | ON | OFF | ON |
| Signal disconnection (<i>r-rb, PG</i>) | OFF | OFF | ON | ON |
| Operation procedure error (<i>Er 6</i>) | ON | OFF | ON | ON |
| External fault (<i>OH 2, Err</i>) | OFF | ON | ON | ON |
| Others (<i>Er H, A r 1 to A r F</i>) | ON | ON | ON | ON |

*1 Available in the ROM version H1/2 0020 or later.

Function code data = 23 Cooling fan in operation -- FAN

This signal is associated with H06 "Fan stop operation" and is present when the cooling fan is operating.

Function code data = 24 Resetting -- TRY

This signal is issued when the protective function is conducting the retry operation if you set one or more to H04 "Auto reset (Times)".

Function code data = 25 Universal DO -- U-DO

You assign a data 25 to a digital output terminal to use it as a universal DO terminal. You can turn on/off through RS-485, field bus, and UPAC. This function simply set ON and OFF to the transistor and relay outputs without affecting the inverter functions.

The applications of this signal are:


- 1) To set ON/OFF to the control terminal directly through RS-485 or field bus.
- 2) To put the output which are assigned by the software created by the UPAC option on a DO of the control terminals.

<Application>

You do not have enough numbers of I/O and want to use an inverter control terminal for a control output of a PLC program.

If you use the control terminal [Y1]:


- 1) Set 25 **U-DO** to the function code E15 "Y1 function selection". Now the inverter does not use the Y1 terminal internally and you can use the terminal for the output of the communication.
- 2) Use the PLC to write "1" to the corresponding bit (data type: 33) of the function code S07 "Universal DO". You will write "0001 [h] " for [Y1].



Function code data = 26 Heat sink overheat early warning -- INV-OH

The heat sink overheat early warning will be issued when the temperature of the heat sink reaches the temperature five degrees less than the detection level of "Heat sink overheat alarm" (L/H I). This is an early warning for the "Heat sink overheat alarm" which is present when the ambient temperature of the heat sink that cools the rectifier diode and the IGBT (PWM switching device) due to the failure of the cooling fan.

The heat sink overheat level (X°C) is set within the range of about 80 to 110°C based on the inverter capacity and short-time rating (HD, LD, and MD), and user cannot change it.



Function code data = 27 Synchronization completion signal -- SY-C

Turns ON when the synchronization completes within the pulse width specified by the function o19 "Deviation zero range" during the synchronizing operation with an option OPC-VG1-PG (PR). See the option section for more details.

It also turns ON when the lock completes within the pulse width specified by the function H56 "Zero speed control (completion range)". See the function description of the zero speed locking command (function code E01 to E13).

Function code data = 28 Lifetime alarm -- LIFE

Turns ON when any one of the DC link bus capacitor (capacitance), the electrolytic capacitors on the control print circuit boards (cumulative running time), and the cooling fans (cumulative running time) approaches the end of the lifetime. This signal turns ON also when the DC fan stops.

The lifetime is judged by the following criteria and this signal comes ON if any one of the above components reaches the end-of-life criteria. The lifetime information can be monitored in Menu #5 Maintenance or with monitoring function codes (M codes) on the LCD monitor in real-time.

| Object of life prediction | Prediction function | End-of-life criteria | On the LCD monitor (Monitoring function codes) |
|---|--|--|--|
| DC link bus capacitor | <u>Measurement of discharging time</u> Measures the discharging time of the DC link bus capacitor when the main power is shut down and calculates the capacitance. For details, refer to Function code H80 "Capacitance Measurement of DC Link Bus Capacitor." | 85.0% or lower of the initial capacitance at shipment (Units digit of H104 = 0) 85% or lower of the reference capacitance* under ordinary operating conditions at the user site (Units digit of H104 = 1) *To be measured when the inverter is set up. | CAP: Capacitance (%) (M46) |
| | <u>ON-time counting</u> Counts the time elapsed when the voltage is applied to the DC link bus capacitor, while correcting it according to the capacitance measured above. | Exceeding 87,600 hours (10 years) | CAPEH: Elapsed time (h) (M121) CAPRH: Remaining time (h) |
| Electrolytic capacitors on printed circuit boards | Counts the time elapsed when the voltage is applied to the capacitors. | Exceeding 87,600 hours (10 years) | TCAP: Elapsed time (h) (M47) |
| Cooling fans | Counts the run time of the cooling fans. | Exceeding 87,600 hours (10 years) Note that this is an estimated life expectancy at the inverter ambient temperature of 40°C. | TFAN: Elapsed time (h) (M48) |

This function indicates merely an approximate life span. Daily inspection and periodic inspection are necessary to avoid failures and keep operating at high reliability over a long period of time. (Refer to the Instruction Manual.)

Function code data = 29 Under acceleration -- U-ACC

Function code data = 30 Under deceleration -- U-DEC

Turns ON during acceleration or deceleration.

Acceleration or deceleration is determined by comparing the input to the acceleration/deceleration calculation unit (Speed reference 1) and the detected speed value. The Under-acceleration/ deceleration signal turns OFF when the speed reaches to a level specified by the function code E42 "Speed equivalent (Detection range)".

Function code data =31 Inverter overload early warning -- INV-OL

Provides the overload early warning signal at a level specified by the Inverter overload early warning (E33). See the E33 "Inverter overload early warning" for more details.

Function code data =32 Motor overhear early warning -- M-OH

Provides the overhear early warning signal at a level specified by the Motor overhear early warning (E31). See the E31 "Motor overhear early warning" for more details.

Function code data =33 Motor overload early warning -- M-OL

Provides the overload early warning signal at a level specified by the Inverter overload early warning (E34). See the E34 "Inverter overload early warning" for more details.

Function code data = 34 DB overload early warning -- *DB-OL*

Provides the overload early warning signal at a level specified by the DB overload early warning (E36). See the E36 "DB overload early warning" for more details.

Function code data = 35 Link transmission error -- *LK-ERR*

Turns ON when a communication error occurs in the transmission through the link (RS-485, T-Link, SX, field bus). Turns OFF when the communication returns to normal.

Function code data = 36 In limiting under load adaptive control -- *ANL*

This signal comes ON when the reference speed is limited with the speed limiter value calculated under load adaptive control. It goes OFF when any one of the following OR conditions is met.

OR conditions

- Inverter stop (Drive OFF)
- Terminal command *N-LIM* ("Cancel speed limiter") = ON
- During pre-excitation
- Polarity change of speed command (Speed reference 4: ASR input)
- *N-FBI±* ("Detected speed 1") < 50% of rated speed and *NL-RST* ("Reset completion of speed limit calculation") = ON

Function code data = 37 In calculation under load adaptive control -- *ANC*

This signal comes ON during calculation of a movable load and speed limiter value under load adaptive control. It goes OFF when any one of the following OR conditions is met.

OR conditions

- Inverter stop (Drive OFF)
- During pre-excitation
- Polarity change of speed command (Speed reference 4: ASR input)
- *N-FBI±* ("Detected speed 1") < 50% of rated speed and *NL-RST* ("Reset completion of speed limit calculation") = ON
- *N-FBI±* ("Detected speed 1") ≥ H226 ("Limit speed discrimination zone, Completion speed")
- *N-FBI±* ("Detected speed 1") < H226 ("Limit speed discrimination zone, Start speed") and Limit speed calculation incomplete

For *ANL* and *ANC*, refer to the description given for function codes H60 to H66 and H201 to H228 (Load adaptive control).

Function code data = 38 Analog torque bias being held -- *TBH*

This signal is turned ON when an analog torque bias hold command is entered.

Function code data = 39-47 Custom Do1 to Do9 -- *C-DOI to C-DO9*

Do terminals for manufacturer.

Function code data = 48 Custom Do10 -- *C-DO10*

This signal comes ON in tact synchronization so that it is possible to check whether the tact cycle of the E-SX bus is synchronized with the inverter control cycle.

Function code data = 51 Multiplex system communications link being established -- *MTS*

This signal comes ON when the communications link of the multiplex system has been established.

Function code data = 52 Answerback to cancellation of multiplex system -- *MEC-AB*

This is an answerback signal for switching the digital input *MT-CCL* ("Cancel multiplex system").

Function code data = 53 Multiplex system master selected -- *MSS*

This signal comes ON when the master unit is configured with the multiplex system selected.

Function code data = 54 Multiplex system local station failure -- *AL-SF*

If an alarm occurs in a multiplex system, only the inverter (local station) that detects failure outputs this signal.

In the single-machine mode, this signal is functionally equivalent to "Alarm output (for any alarm)."

Function code data = 55 Stopped due to communications link error -- *LES*

This signal applies when the CC-Link interface card is mounted. It comes ON when the inverter switches to a stop operation due to an occurrence of an alarm E_{r-4} or E_{r-5} . Removing the alarm and restarting the inverter turns this signal OFF.

Function code data = 56 Alarm output (for any alarm) -- *ALM*

The ALM can be output also via the Y terminal.

Function code data = 57 Light alarm -- *L-ALM*

This signal comes ON when a light alarm has occurred. Removing the alarm factor automatically turns this signal OFF.

Function code data = 58 Maintenance timer -- *MNT*

This signal comes ON when the total of the M1, M2 and M3 startups (M123 to M125) exceeds the H82 setting or the total of the M1, M2 and M3 cumulative motor run time (M126 to M128) exceeds the H83 setting.

Modifying either of the H82 or H83 setting that constitutes a forecasting factor turns this signal OFF.

Function code data = 59 Braking transistor broken -- *DBAL*

This signal comes ON when the error factor of a braking transistor alarm ($C_{b}^{1}E_{r}^{1}$) arises. Even if the alarm is defined as a light alarm, this signal comes ON.

Function code data = 60 DC fan locked -- *DCFL*

This signal comes ON when the DC fan for circulating air inside the inverter is stopped for two seconds.

The above inverter state also constitutes a heavy or light alarm factor. Alarms can be defined by H108 as a heavy or light alarm.

Function code data = 61 Speed agreement 2 -- *N-AG2*

This signal applies when motor M2 is selected. It comes ON when the deviation of the detected speed from the speed command value (Reference speed 4: ASR input) is within the allowable range.

For details, refer to the descriptions of E114 and E115 (Speed Agreement 2, Detection width and Off-delay timer) and E45 (Speed Disagreement Alarm/Phase Loss Detection Level).

When motor M2 is not selected, this signal is always OFF.

Function code data = 62 Speed agreement 3 -- *N-AG3*

This signal applies when motor M3 is selected. It comes ON when the deviation of the detected speed from the speed command value (Reference speed 4: ASR input) is within the allowable range.

For details, refer to the descriptions of E116 and E117 (Speed Agreement 3, Detection width and Off-delay timer) and E45 (Speed Disagreement Alarm/Phase Loss Detection Level).

When motor M3 is not selected, this signal is always OFF.

Function code data = 63 Axial fan stopped -- *MFAN*

This signal comes ON when the NTC detection temperature of the motor having an NTC thermistor drops below the setting specified by E118 and the inverter is stopped.

Function code data = 64 Arbitrarily assigned RDY -- *AS-RDY* (Available soon)**Function code data = 66 Answerback to droop control enabled -- *DSAB***

This signal is turned ON when the droop control is activated by turning ON the *DROOP* signal on an X terminal.

When the inverter is stopped or under torque control, even turning ON the *DROOP* signal does not turn this signal ON.

Function code data = 67 Answerback to cancellation of torque command/torque current command -- *TCL-C*

This is an answerback signal for switching between *H41-CCL* (Cancel H41 (Torque command)) and *H42-CCL* (Cancel H42 (Torque current command)).

Function code data = 68 Answerback to cancellation of torque limiter mode 1 -- *F40-AB*

This is an answerback signal for switching *F40-CCL* (Cancel F40 (Torque limiter mode 1)).

Function code data = 71 73 ON command -- *PRT-73*

When a charger circuit is configured outside the inverter, use this signal as a 73 ON command for switching the charger resistor bypass circuit. Turning this signal ON bypasses the charger resistor.

Function code data = 72 Turn ON Y-terminal test output -- *Y-ON*

This signal comes ON when it is assigned to the Y terminal function. Use this signal to check the connection of Y terminals.

Function code data = 73 Turn OFF Y-terminal test output -- *Y-OFF*

This signal comes OFF when it is assigned to the Y terminal function. Use this signal to check the connection of Y terminals.

Function code data = 75 System clock battery lifetime expired -- *BATT*

This signal comes ON when the battery voltage level of the integrated battery (option for inverters of 22 kW or below, included as standard for those of 30 kW or above) drops. If this signal comes ON, replace the integrated battery as soon as possible.

Function code data = 77 SPGT battery warning -- *SPGT-B* (Available soon)

Function code data = 80 EN terminal detection circuit failure -- *DECF* (Available soon)

This signal comes ON when a functional safety circuit failure is detected.

Function code data = 81 EN terminal OFF -- *ENOFF* (Available soon)

This signal comes ON when Enable input on the EN1 and EN2 terminals is OFF.

Function code data = 82 Safety function in progress -- *SF-RUN*

Function code data = 84 STO under testing -- *SF-TST*

These signals are available when the functional safety card is mounted.

 For details, refer to the Functional Safety Card Instruction Manual (INR-SI47-1541).



Function code data 80, 81, 82 and 84 are available in the ROM version H1/2 0020.

E28**Y Terminal Function (Normal open/close)**

E28 specifies whether to open or close output terminals [Y1] to [Y5] by software.

OP: Open

CL: Close (short-circuit)

E 2 8 Y N O R M A L

Example of configuration change through RS-485 or other communications links

To configure Y2 and Y5 as normally closed contacts and configure other Y functions as normally open contacts

- 1) Perform bit assignment in binary according to type [36] (refer to Section 4.2.3.2 Data Type).
- 2) Next, convert the bit-assigned binary data into a hexadecimal.
0000 0000 0001 0010 (binary) = 0012 (hexadecimal) Enter this hexadecimal data.

E29**PG Pulse Output Selection**

Use this function to provide different applications with the PG pulse signal.

E 2 9 P G - P L S - O U T

- 1) You can divide the pulse signal to supply. Set value: 0: 1/1, 1: 1/2, 2: 1/4, 3: 1/8, 4: 1/16, 5: 1/32, 6: 1/64
The input signal to the integrated PG is divided for output as presented above. You can use the divided signal for digital speedometer.
- 2) You can convert the internal speed command (digital and analog) into pulse to supply. See the <Application example 2> of Synchronization command *SYC* of the function codes E01 to E13 for more details.
When E29 = 7: Pulse generation mode (A, B: Signals with 90° phase difference)
- 3) Converting the input via the PG interface card into arbitrary pulses to output
When E29 = 8: OPC-VG1-PG (PD), pulse train detection input is directly supplied to the pulse output.
When E29 = 9: OPC-VG1-PG (PR), pulse train command input is directly supplied to the pulse output.
See the <Application example 3> of Synchronization command *SYC* of the function codes E01 to E13 for more details.
- 4) Converting the speed detection pulse input into arbitrary pulses to output
When E29 = 10: Integrated PG, PG (SD), Detected speed pulse input oscillation mode
When E29 = 7 to 10, arbitrary pulses can be output. For details, refer to the description of E109 and E110.

E30**Motor Overheat Protection (Temperature)**

Sets the temperature at which the motor overheat alarm ($\overline{M-H}$) is issued. Specify the protection level according to the isolation class of the motor.

E 3 0 M - P R T - C

Data setting range: 50 to 200 (°C)

Note: The E30 setting takes effect when the selected motor (M1, M2 or M3) uses an NTC thermistor or the analog input signal *M-TMP* ("Motor temperature") is selected.

E31**Motor Overheat Early Warning (Temperature)**

Sets the temperature at which the motor overheat early warning is issued before the overheat protection becomes active. The early warning signal is put on the DO to which **M-OH** is assigned.

E 3 1 M - W A R N - T

Data setting range: 50 to 200 (°C)

Note: This function is invalid if the PTC thermistor is used.


E32**M1-M3 PTC Activation Level**

Activated when the input voltage from a PTC becomes higher than the specified voltage (activation level) if you select to use a thermistor.

E 3 2 M - P T C - L V L


Data setting range: 0.00 to 5.00 (V)

Connect a PTC thermistor as shown below.



The warning temperature depends on a PTC thermistor and the resistor of the PTC thermistor changes drastically at the warning temperature. The activation (voltage) level is specified by this change of the resistor.

PTC thermistor internal resistance



The voltage level (activation level) can be calculated with the following expression.

$$\text{Voltage level (V)} = 5 \text{ V} / (\text{Rp} + 270000) \times \text{Rp}$$

Set the Rp within the following range.

$$\text{Rp1} < \text{Rp} < \text{Rp2}$$

To determine Rp easily, use the following expression.

$$\text{Rp} (\Omega) = (\text{Rp1} + \text{Rp2}) / 2$$

Note: The above expression for determining the voltage level differs from that to be used for the VG7.

When a PTC thermistor wire breaks, the inverter recognizes $\text{Rp} = (\Omega)$ and issues a motor overheat alarm **Oh4**.

E33**Inverter Overload Early Warning**

Sets the level at which the overload early warning is issued before the Inverter overload protection becomes active. When you set 100%, the early warning is simultaneously issued with the overload protection (\overline{OL}). The early warning signal is put on the DO to which **INV-OL** is assigned.

E 3 3 I N V - O L W A R N

Data setting range: 25 to 100 (%)

E34**Motor Overload Early Warning**

Sets the level at which the overload early warning is issued before the Motor overload protection becomes active. When you set 100%, the early warning is simultaneously issued with the overload protection (\overline{OL}). The early warning signal is put on the DO to which **M-OL** is assigned.

E 3 4 M - O L - W A R N

Data setting range: 25 to 100 (%)

E35**DB Overload Protection**

Sets in %ED with respect to the inverter capacity. When you use a braking resistor with 10%ED, set as 10%. When the set value is zero, the overload protection (\overline{OL}) becomes disabled.

E 3 5 D B - O L - P R T C

Data setting range: 0 to 100 (%)

E36**DB Overload Early Warning**

Sets the level at which the overload early warning is issued before the DB overload protection becomes active. When you set 100%, the early warning is simultaneously issued with the overload protection (\overline{OL}). The early warning signal is put on the DO to which **DB-OL** is assigned.

E 3 6 D B - O L - W A R N

Data setting range: 0 to 100 (%)

E37**DB Thermal Time Constant**

Sets the thermal time constant of a DB resistor to be used.

E 3 7 D B - T H - T C

Data setting range: 0 to 1,000 (s)

| | |
|------------|--------------------------------|
| E38 | Speed Detection Mode |
| E39 | Speed Detection Level 1 |
| E40 | Speed Detection Level 2 |
| E41 | Speed Detection Level 3 |

If the detected speed or reference speed, which is selectable with E38, exceeds the speed detection level specified by E39, E40 or E41, the inverter outputs Speed detected 1 (*N-DT1*), Speed detected 2 (*N-DT2*), or Speed detected 3 (*N-DT3*), respectively.

E38 specifies which output (detected speed or reference speed) should be the base for speed detection in each of E39, E40 and E41.

- Detected speed: *N-FB2*±(Detected speed 2) (ASR input)
- Reference speed: *N-REF4* (Reference speed 4) (ASR input)

| | | | | | | | | | | |
|--------------|----------|----------|----------|----------|----------|----------|----------|----------|----------|----------|
| E 3 8 | N | D | T | | M | E | T | H | O | D |
| E 3 9 | N | D | T | 1 | - | L | V | L | | |
| E 4 0 | N | D | T | 2 | - | L | V | L | | |
| E 4 1 | N | D | T | 3 | - | L | V | L | | |

■ **Speed detection level (E39 to E41)**

The hysteresis width to switch the Speed detection signal from ON to OFF is 1% of the maximum speed (100%/maximum speed).

If the specified speed detection level exceeds the maximum speed, the inverter interprets the detection level as the maximum speed.

If the specified speed detection level is 1% or less of the maximum speed, the inverter operation differs for Speed detection 1 and Speed detection 2 or 3, as described below.

E39 (Speed detection level 1): Detection using absolute speed value

Data setting range: 0 to 30000 (r/min)


If the detection level is set at "0" (r/min), the Speed detection signal comes ON when the detected speed or reference speed is "0" (r/min) or more.

E40, E41 (Detection level 2, 3): Detection using speed with polarity, Positive operation in the forward rotation direction


Data setting range: 0 to ±30000 (r/min)

If the detection level is set at "0" (r/min), the Speed detection signal comes ON when the inverter starts running.

Speed detection 1, Speed detection 2, 3 in forward rotation direction



Speed detection 2, 3 in reverse rotation direction



N-DT*: Denotes any of *N-DT1*, *N-DT2*, and *N-DT3*

■ Speed detection mode (E38)

E38 specifies which output (Detected speed 2 or Reference speed 4) should be the base for speed detection. As shown below, it can make the definition of the speed detection levels for E39, E40, and E41 individually.

Data setting range: 000 to 111

E38 =

- Definition for E39 (*N-DT1*)
- Definition for E40 (*N-DT2*)
- Definition for E41 (*N-DT3*)

- 0: Detected speed 2 (*N-FB2±*)
(Under vector control without speed sensor, the estimated speed value is applied as Detected speed 2.)
- 1: Reference speed 4 (*N-REF4*) (ASR input)

E42 **Speed Arrival (Detection width)**

If the detected speed comes within the reference speed detection width specified by E42, the inverter outputs the Speed arrival signal *N-AR*.

- Detected speed: *N-FB2±* (Detected speed 2) (ASR input)
- Reference speed: *N-REF2* (Reference speed 2) (Before ACC/DEC processing)

E 4 2 **N A R - H Y S T R**


Data setting range: 1.0 to 20.0 (%)

The hysteresis width to switch the Speed arrival signal from ON to OFF is 1% of the maximum speed (100%/maximum speed).

The detection width specified by E42 (equally applied to positive and negative directions) is used for speed arrival processing.

$$N-AG \text{ ON condition} = -E42 \leq \frac{N-REF2 - |N-FB2 \pm|}{\text{Maximum speed}} \times 100.0\% \leq E42$$

$$N-AG \text{ OFF condition} = -(E42 + 1.0\%) \leq \frac{N-REF2 - |N-FB2 \pm|}{\text{Maximum speed}} \times 100.0\% \leq (E42 + 1.0\%)$$



| | |
|------------|--|
| E43 | Speed Agreement (Detection width) |
| E44 | Speed Agreement (Off-delay timer) |

If the detected speed agrees with the reference speed (ASR input) (or comes within the detection width specified by E43), the inverter outputs the Speed agreement signal *N-AG1*.

- Detected speed: *N-FB2*± (Detected speed 2) (ASR input)
- Reference speed: *N-REF4* (Reference speed 4)

| | | | | | | | | | | |
|----------|----------|----------|----------|----------|----------|----------|----------|----------|----------|----------|
| E | 4 | 3 | N | A | G | H | Y | D | T | R |
| E | 4 | 4 | N | A | G | D | E | L | A | Y |

Data setting range: E43 = 1.0 to 20.0 (%)
E44 = 0.000 to 5.000 (s)

An off-delay timer can be set for output of the Speed agreement signal.

E43, E44 and Speed agreement signal *N-AG1* are valid when motor M1 is selected.

For Speed agreement signal *N-AG2* or *N-AG3* to be applied when motor M2 or M3 is selected, respectively, refer to the descriptions of E114 to E117.


The hysteresis width to switch the Speed agreement signal from ON to OFF is 1% of the maximum speed (100%/maximum speed).

The detection width specified by E43 (equally applied to positive and negative directions) is used for speed agreement processing.


$$N-AG1 \text{ ON condition} = -E43 \leq \frac{N-REF4 - |N-FB2 \pm|}{\text{Maximum speed}} \times 100.0\% \leq E43$$

$$N-AG1 \text{ OFF condition} = -(E43 + 1.0\%) \leq \frac{N-REF4 - |N-FB2 \pm|}{\text{Maximum speed}} \times 100.0\% \leq (E43 + 1.0\%)$$

Off-delay timer is set:



Off-delay timer is not set:



| | |
|------------|---|
| E45 | Speed Disagreement Alarm/ Phase Loss Detection Level |
|------------|---|


E45 specifies whether the Speed disagreement alarm ($\overline{E-5}$) is issued or not when the deviation between the Speed reference 4 (ASR input) and the Detected speed 2 remains for a certain period.

E 4 5 N - U E - A L M

Setting:

| | |
|----------------------------|---|
| Speed disagreement alarm | 0: Disable 1: Enable |
| Phase loss detection level | 0: Standard level 1: Level for manufacturer 2: Cancel |

When **BRK** (Brake release signal) is assigned to a Y terminal and $H149 \neq 0.0$, the speed disagreement alarm ($\overline{E-5}$) takes effect and the speed agreement specified by E43 and E44 takes no effect.



Note To use a PG amplifier (isolated signal conditioner), enable the above function. Using a PG amplifier may prevent the inverter from detecting a wire break between the motor and PG amplifier. (The recommended PG amplifier has no wire break detection function.)

| | |
|------------|---------------------------------|
| E46 | Torque Detection Level 1 |
|------------|---------------------------------|

| | |
|------------|---------------------------------|
| E47 | Torque Detection Level 2 |
|------------|---------------------------------|

Provides a detection signal when the torque command exceeds a specified value. You can specify two levels of detection level, level 1 and level 2. 100% means a torque command of the continuous rating. The detection signals appear on the DO's to which the *T-DT1* and *T-DT2* are assigned.

| | | | | | | | | | | | |
|----------|----------|----------|----------|----------|----------|----------|----------|----------|----------|----------|--|
| E | 4 | 6 | T | D | T | 1 | - | L | V | L | |
| E | 4 | 7 | T | D | T | 2 | - | L | V | L | |

Data setting range: 0 to 300.0 (%)

Note: The calculated torque value is used for determination in V/f control.

| | |
|------------|--------------------------------------|
| E48 | Magnetic Flux Detection Level |
|------------|--------------------------------------|

Provides a detection signal when the calculated magnetic-flux value exceeds a specified value. The detection signal appears on the DO to which the *M-DT* is assigned.

| | | | | | | | | | | | |
|----------|----------|----------|----------|----------|----------|----------|----------|----------|----------|----------|--|
| E | 4 | 8 | M | F | D | T | - | L | V | L | |
|----------|----------|----------|----------|----------|----------|----------|----------|----------|----------|----------|--|

Data setting range: 10 to 100 (%)

| | |
|-------------------|-----------------------------|
| E49 to E52 | Ai Terminal Function |
|-------------------|-----------------------------|

E49 to E52 select functions to be assigned to analog input terminals [Ai1] to [Ai4], respectively.

Some functions are not available depending upon the drive control (vector control with/without speed sensor, V/f control and synchronous motor drive). For details, refer to Section 4.2 "Function Code Tables."

| | | | | | | | | | | |
|----------|----------|----------|----------|----------|----------|----------|----------|----------|----------|--|
| E | 4 | 9 | A | i | 1 | F | U | N | C | |
| E | 5 | 0 | A | i | 2 | F | U | N | C | |
| E | 5 | 1 | A | i | 3 | F | U | N | C | |
| E | 5 | 2 | A | i | 4 | F | U | N | C | |

Data setting range: 00 to 27

| Function code data | Terminal commands assigned | Symbol | Scale | Remarks |
|--------------------|-----------------------------------|----------------|-----------------|---------------------------------------|
| 00 | Shut down input signal | <i>OFF</i> | — | — |
| 01 | Auxiliary speed setting 1 | <i>AUX-N1</i> | ±10V/±Nmax | Nmax: Maximum Speed (F03, A06, A106) |
| 02 | Auxiliary speed setting 2 | <i>AUX-N2</i> | ±10V/±Nmax | Nmax: Maximum Speed (F03, A06, A106) |
| 03 | Torque limiter level 1 | <i>TL-REF1</i> | ±10V/±150% | 100%: Motor rated torque |
| 04 | Torque limiter level 2 | <i>TL-REF2</i> | ±10V/±150% | 100%: Motor rated torque |
| 05 | Torque bias | <i>TB-REF</i> | ±10V/±150% | 100%: Motor rated torque |
| 06 | Torque command | <i>T-REF</i> | ±10V/±150% | 100%: Motor rated torque |
| 07 | Torque current command | <i>IT-REF</i> | ±10V/±150% | 100%: Torque Current (P09, A11, A111) |
| 08 | Creep speed 1 for UP/DOWN control | <i>CRP-N1</i> | ±10V/±Nmax | Nmax: Maximum Speed (F03, A06, A106) |
| 09 | Creep speed 2 for UP/DOWN control | <i>CRP-N2</i> | ±10V/±Nmax | Nmax: Maximum Speed (F03, A06, A106) |
| 10 | Magnetic flux reference | <i>MF-REF</i> | +10V/+100% | - |
| 11 | Detect line speed | <i>LINE-N</i> | ±10V/±Nmax | Nmax: Maximum Speed (F03, A06, A106) |
| 12 | Motor temperature | <i>M-TMP</i> | +10V/200°C | - |
| 13 | Speed override | <i>N-OR</i> | ±10V/±50% | - |
| 14 | Universal Ai | <i>U-AI</i> | ±10V/±4000 (h) | - |
| 15 | PID feedback 1 | <i>PID-FB1</i> | ±10V/±20000 (d) | - |
| 16 | PID reference value | <i>PID-REF</i> | ±10V/±20000 (d) | - |
| 17 | PID correction gain | <i>PID-G</i> | ±10V/±4000 (h) | - |
| 18-24 | Custom Ai1 to Ai7 | <i>C-AI1-7</i> | ±10V/±7FFF (h) | - |
| 25 | Main speed setting | <i>N-REFV</i> | ±10V /±Nmax | Nmax: Maximum Speed (F03, A06, A106) |
| 26 | Current input speed setting | <i>N-REFC</i> | 4-20 mADC/±Nmax | Nmax: Maximum Speed (F03, A06, A106) |
| 27 | PID feedback amount 2 | <i>PID-FB2</i> | ±10V/±20000 (d) | |

<Using analog input>

There are 28 types of analog input functions from 00 to 27 available. You cannot use all of these functions at the same time. You can use total of four terminals, which are two terminals, [Ai1] and [Ai2], as standard and two terminals, [Ai3] and [Ai4], using optional AIO. The maximum number you can use is four unless you switch externally.

When you assign the same function to [Ai1] and [Ai2], the input to [Ai2] will become effective. When you install the AIO option and assign the same function to [Ai1], [Ai2], [Ai3], and [Ai4], the input to [Ai4] will become effective. (Priority order 1: [Ai1], 2: [Ai2], 3: [Ai3], 4: [Ai4])

Note that you should assign [U-AI] to all the analog input terminals at the same time.

Note: The current input function on terminal [Ai2] applies only to the *N-REFC* (Current input speed setting). The function cannot be used on terminal [Ai1].

Setting procedure

- Select a function you want to use. We select the "Torque bias" as an example.
- Assign the "Torque bias" function to one of the available terminals ([Ai1] to [Ai4]). If you want to assign it to [Ai2], write a data, "5:TB-REF", to the function code E50 "Ai2 function selection".
- Apply a voltage of $\pm 10V/\pm 150\%$ to the analog terminal [Ai2] considering the scale conversion of the torque bias in mind. If you need the torque bias of 15%, you should apply +1.0V.
- See the "I/O check" screen of the KEYPAD panel to confirm that +1.0V is applied to [Ai2]. The right figure shows the screen you must view.
- You can specify the bias, the gain, the filter and the increment/decrement limiter applied to the analog input.

| | |
|------------------------|---------------|
| 1 5 0 0 | |
| 1 2 = | 0. 0 V |
| A i 1 = | 0. 2 V |
| A i 2 = | 1. 0 V |
| ∧V→PAGE SHIFT 5 | |

| Function | Application |
|-----------------------------|--|
| Bias | Sets the bias. |
| Gain | Use to enlarge a small voltage range or to reduce a large voltage range. Use a minus value to invert the polarity. |
| Filter | Use to eliminate high frequency ripple and noise on the input voltage. Since you apply a low-pass filter, excessive setting may slow down the response. |
| Increment/decrement limiter | Slants a step input voltage. The specified values work as rising and falling times. |

See the description of the individual function codes for more details.

- You can use the DI terminal input to hold the analog input to zero or to invert the polarity of the analog input. See Ai zero hold and Ai polarity change of E01 to E13 "X function selection" for more details.

See also the control block diagram to work with this function effectively.

Function code data = 00 Shut down input signal -- OFF

Select this signal to assign no function to an analog input terminal.

Make this setting when an analog input terminal is not to be used.

Function code data = 01, 02 Auxiliary speed setting 1, 2 -- AUX-N1, AUX-N2

Assign data "01" (*AUX-N1*) and "02" (*AUX-N2*) to desired analog input terminals to designate them as Auxiliary speed setting 1 and Auxiliary speed setting 2 terminals. See the table below and the control diagram for the points where the control inputs are applied. This function adds a speed ($\pm 10V$ corresponds \pm maximum speed) to main speed command values ([12] input and the multistep speed command). Two points are available to add a speed.

| Auxiliary speed setting | Point of application | Restrictions |
|-------------------------|--|--|
| 01 <i>AUX-N1</i> | After multistep speed command | Disabled when you use "0: KEYPAD panel" and "03, 04, 05: UP/DOWN functions" of the function codes F01 and C25. |
| 02 <i>AUX-N2</i> | After acceleration/deceleration calculation (acceleration/deceleration calculation applied to input is disabled) | |

If auxiliary speed setting 2 is larger than the stop speed level (F37), the motor keeps rotating at auxiliary speed setting 2 even after the operation command (FWD, REV) is turned off. In this case, use the Ai zero hold function with X function selection to zero-hold the Ai input simultaneously when the operation command is turned off.

Function code data = 03, 04 Torque limiter level 1, 2 -- *TL-REF1, TL-REF2*

Assign data "03" (*TL-REF1*) and "04" (*TL-REF2*) to desired analog input terminals to designate them as Torque limiter (level 1) and Torque limiter (level 2) terminals. See the function codes F40 to 43 for torque limiter.

Function code data = 05 Torque bias -- *TB-REF*

Assign data "05" (*TB-REF*) to a desired analog input terminal to designate it as Torque bias command terminal. See the function code F47 to 49 for more details.

Function code data = 06 Torque command -- *T-REF*

Assign data "06" (*T-REF*) to a desired analog input terminal to designate it as Torque command terminal. See the control block diagram and the function code H41 "Torque command selection" for more details.

Function code data = 07 Torque current command -- *IT-REF*

Assign data "07" (*IT-REF*) to a desired analog input terminal to designate it as Torque current command terminal. See the control block diagram and the function code H42 "Torque current command selection" for more details.

Function code data = 08, 09 Creep speed 1, 2 for UP/DOWN control -- *CRP-N1, CRP-N2*

Assign data "08" (*CRP-N1*) and "09" (*CRP-N2*) to desired analog input terminals to designate them as Creep speed 1 and Creep speed 2 terminals. See the UP/DOWN functions of the function codes E01 to 13 for more details.

The Ai input is processed as an absolute value.

Function code data = 10 Magnetic flux reference -- *MF-REF*

Assign data "10" (*MF-REF*) to a desired analog input terminal to designate it as Magnetic-flux command terminal. See the control block diagram and the function code H43 "Magnetic-flux command value" for more details.

Function code data = 11 Detect line speed -- *LINE-N*

Assign data "11" (*LINE-N*) to a desired analog input terminal to designate it as Detected line speed terminal. See the control block diagram and the function code H53 "Line speed feedback selection" for more details.

Function code data = 12 Motor temperature -- M-TMP

Assign data "12" (*M-TMP*) to a desired analog input terminal to designate it as Motor temperature terminal. When you use a FRENIC-VG dedicated motor, you can use the NTC thermistor supplied with a motor to detect the motor temperature and to protect the motor from overheat (UL1). When you use a motor with a PTC thermistor, you can use it for overheat protection. You can also use an electronic thermal relay for protection against motor overload (UL1, UL2, UL3).


You can use this function to build your own motor overheat protection system detecting the motor temperature directly without using method mentioned above.

You can use the function code E30 "Motor overheat protection" and E31 "Motor overheat early warning" to specify the detection levels.

Function code data = 13 Speed override -- N-OR

Assign data "13" (*N-OR*) to a desired analog input terminal to designate it as Speed override terminal.

You can supply +10V to override the speed with 150% of the speed reference and supply -10V to override with 50% of the speed reference. See the control diagram for a point of the control input.



| Speed override | Point of application | Restrictions |
|----------------|--------------------------------------|---|
| 13 <i>N-OR</i> | Just after Auxiliary speed setting 1 | Disabled when you use "0: KEYPAD panel" and "3, 4, 5: UP/DOWN functions" of the function codes F01 and C25. Used for acceleration/deceleration calculation. Restricted by the maximum speed. |

<Application example>


You can specify the coarse/fine adjustment of the speed.

- Specified maximum speed value: 1,500 r/min
- Specified speed reference value: 1,200 r/min (100%)
- Input voltage applied to the terminal [N-OR]: ±10V

Coarse adjustment

As shown in the right graph, the overridden value is 600r/min for -10 V input and is restricted by the maximum speed for +10 V input.

Applying voltage enables coarse speed adjustment around the speed reference (1,200 r/min).




Fine adjustment

Set the gain of used [Ai] to 0,01 (function code E53 to 56).

As shown in the right graph, the overridden value is 1194r/min for -10V input and is 1206 r/min for +10V input. Applying voltage enables fine speed adjustment around the speed reference (1,200 r/min).

Either the reference value of the maximum speed or the precision of the analog input determines the resolution. In this example, the resolution is determined by the former one: 0.08 r/min.



The larger value between the following values determines the resolution.

Reference value of the maximum speed: $1,500 \text{ r/min} \div \text{internal data } 20,000 = 0.075 \text{ r/min} \approx 0.08 \text{ r/min}$

Precision of the analog input: Unipolar scale (6 r/min) is divided into 15 bit.
Thus, $6 \text{ r/min} \div 32767 \text{ (15 bits)} \times 100 \text{ (scaling)} = 0.018 \text{ r/min}$

Function code data = 14 Universal Ai -- U-AI

Assign data "14" (U-AI) to a desired analog input terminal to designate it as Universal Ai terminal.

You can use this function to check the existence of the input signal through communication and this function does not affect the inverter operation.

You can use this signal to the following applications.

- 1) You can read out input signal as an analog data through RS-485 or optional field bus.
- 2) You can use Ai for an input to a software you create with the UPAC option or the PLC without affecting the inverter operation.


<Application example>

The right figure shows a diagram of a winding control utilizing dancer control.

The UPAC option uses PID control for dancer position control. The line speed command generated by adding the PID output to the line speed command for the winding off side received from [12] is supplied to the winding up side.

You can use an [Ai] terminal to read the dancer position detected by a potentiometer. If you assign Universal Ai U-AI to the AI input, the output of the potentiometer is directly available to the UPAC. See the description of the UPAC for more details on the UPAC.

You can also use U-AI to control in the same manner if you replace the UPAC option and the bus connector with the PLC and the communication line.



Function code data = 15 PID feedback 1 -- *PID-FB1*

Function code data = 16 PID reference value -- *PID-REF*

Function code data = 17 PID correction gain -- *PID-G*

Assign data "15" (*PID-FB*), "16" (*PID-REF*) and "17" (*PID-G*) to desired analog input terminals to designate them as PID feedback value, PID command value, and PID correction value terminals, respectively.

These terminals can be used as input terminals for feedback signals, command signals and correction signals in the process under PID control. See the function codes H19 to H26 for more details on the PID functions.

Function code data = 18-24 Custom Ai1 to Ai7 -- *C-AI1* to *C-AI7*

Reserved for options and special applications.

Function code data = 25 Main speed setting -- *N-REFV* ± 10 V/ $\pm N_{max}$ (N_{max} : Maximum speed F03, A06, A40)

The voltage (± 10 VDC, Maximum speed/ ± 10 V) applied to an analog input terminal makes analog speed setting.

When using *N-REFV* on terminal [Ai2], set F01 data at "08" (*N-REFV*).

Function code data = 26 Current input speed setting (4-20 mADC) -- *N-REFC* 4-20 mADC/ N_{max}

This analog input is available only on terminal [Ai2].

The current (4 to 20 mADC, Maximum speed/20 mADC) applied to terminal [Ai2] makes analog speed setting.

When using *N-REFC* on terminal [Ai2], set F01 data at "09" (*N-REFC*) and turn SW3 to the I position. (For configuration of SW3, refer to Section 3.3.3.9.)

Function code data = 27 PID feedback amount 2 -- *PID-FB2*

This analog input is used to input feedback signals under PID process control.

Analog inputs *PID-FB1* (PID feedback amount 1) and *PID-FB2* (PID feedback amount 2) can be switched by the digital input signal *PID-1/2* (Switch PID feedback signals, data = 78).

For details about the PID control, refer to the descriptions of H20 to H26.

E53 to E56

Ai Gain


These function codes specify gains to be applied to analog input terminals [Ai1] to [Ai4].

| | | | | | | | | | | | |
|---|---|---|---|---|---|---|---|---|---|--|--|
| E | 5 | 3 | G | A | I | N | A | i | 1 | | |
| E | 5 | 4 | G | A | I | N | A | i | 2 | | |
| E | 5 | 5 | G | A | I | N | A | i | 3 | | |
| E | 5 | 6 | G | A | I | N | A | i | 4 | | |

Data setting range: -10.000 to 10.000 (times)

Note: Terminals [Ai3] and [Ai4] are available only when you install OPC-VG1-AIO.

The data changed with the \uparrow or \downarrow key at the keypad panel is valid. To save to the backup memory, press the FUNC/DATA key.



E57 to E60

Ai Bias


These function codes specify biases to be applied to analog input terminals [Ai1] to [Ai4]. A value of 100% corresponds to a doubled offset value.

| | | | | | | | | | | | |
|---|---|---|---|---|---|---|---|---|---|--|--|
| E | 5 | 7 | B | I | A | S | A | i | 1 | | |
| E | 5 | 8 | B | I | A | S | A | i | 2 | | |
| E | 5 | 9 | B | I | A | S | A | i | 3 | | |
| E | 6 | 0 | B | I | A | S | A | i | 4 | | |

Data setting range: -100.0 to 100.0 (%)

Note: Terminals [Ai3] and [Ai4] are available only when you install OPC-VG1-AIO.

The data changed with the \uparrow or \downarrow key at the keypad panel is valid. To save to the backup memory, press the FUNC/DATA key.



E61 to E64**Ai Filter**

These function codes specify whether to apply a filter to analog input terminals [Ai1] to [Ai4], as well as specifying a time constant of the filter individually. The filter used here is a low-pass filter. The time constant means the time until the filter output data reaches 63% of the input data.

Since a large filter time constant decreases the response, consider the response of a mechanical system to determine the time constant. If the input voltage fluctuates due to noise, first try hardware measures, and then use this filter after you failed.

Use the function code (E65 to E68) to increase or decrease a command value gradually.

| | | |
|-------|-------------|-------|
| E 6 1 | F I L T E R | A i 1 |
| E 6 2 | F I L T E R | A i 2 |
| E 6 3 | F I L T E R | A i 3 |
| E 6 4 | F I L T E R | A i 4 |

Data setting range: 0.000 to 0.500 (s)

Note: Terminals [Ai3] and [Ai4] are available only when you install OPC-VG1-AIO.

E65 to E68**Up/Down Limiter (Ai)**

These function codes specify a time to increase a data inside the inverter from 0V to 10V when you change the input from 0 to 10V applied to analog input terminals [Ai1] to [Ai4].

<Application example>


When you use the analog torque command or the analog torque bias, you may not use a command that changes stepwise. A step-wise torque command may tear a paper in a paper rolling machine or present an elastic vibration (damping) when a subject matter has a large elastic modulus.

To avoid this phenomenon, though you should change the command with an external volume, you can use this Increment/decrement limiter to specify the automatic increase and decrease of an analog command value.

| | | |
|-------|-------|-----------|
| E 6 5 | A / D | L - A i 1 |
| E 6 6 | A / D | L - A i 2 |
| E 6 7 | A / D | L - A i 3 |
| E 6 8 | A / D | L - A i 4 |

Data setting range: 0.00 to 60.00 (s)


Note: Terminals [Ai3] and [Ai4] are available only when the OPC-VG1-AIO is mounted.



Appendix

This section shows an example specifying the bias, the gain, and the increment/decrement limiter of [Ai1] and assigning "Ai1 zero hold" to [X1] function and "Ai1 polarity change" to [X2] function. See also the control block diagram for better understanding. The filter function is not included in this example, since you can use this function to eliminate noise, but should not use actively.

| Function code | Set value |
|-----------------------------|---|
| E01: Terminal [X1] Function | 40: Zero-hold Ai1 ZH-AI1 |
| E02: Terminal [X2] Function | 44: Reverse Ai1 polarity REV-AI1 |
| E53: Ai1 Gain | 8.000 (magnification) |
| E57: Ai1 Bias | -50.0 (%) |
| E65: Up/Down Limiter (Ai1) | 2.00 s |



- The increment/decrement limiter set the time for the change of an internal control data by 8 V (-4 V ↔ 4 V) to $2.0 \text{ s} \times 8/10 = 1.6 \text{ s}$. Note that the increment/decrement limiter is applied not to the change of the input voltage from 0 to 1 V, but to the change of the internal data scaled by the gain.
- The change of the internal control data to 0 V follows the increment/decrement limiter when the zero hold signal **ZH-AI1** is applied.
- The change of the polarity of the internal control data follows the increment/decrement limiter when the polarity change signal **REV-AI1** is applied.

E69 to E73

Ao Terminal Function

E69 to E73 select functions to be assigned to analog output terminals [Ao1] to [Ao5], respectively.

Some functions are not available depending upon the drive control (vector control with/without speed sensor, V/f control and synchronous motor drive). For details, refer to Section 4.2 "Function Code Tables."

| | | |
|--------------|--------------|----------------|
| E 6 9 | A O 1 | F U N C |
| E 7 0 | A O 2 | F U N C |
| E 7 1 | A O 3 | F U N C |
| E 7 2 | A O 4 | F U N C |
| E 7 3 | A O 5 | F U N C |

Data setting range: 00 to 40

17 to 29 are reserved. Do not use them.

| Function code data | Terminal commands assigned | Symbol | Scale | Remarks |
|--------------------|---|----------------|--------------------|---------------------------------------|
| 00 | Detected speed 1 (Speed indicator, one-way deflection) | <i>N-FBI+</i> | +Nmax/10V | Nmax: Maximum Speed (F03, A06, A106) |
| 01 | Detected speed 1 (Speed indicator, two-way deflection) | <i>N-FBI±</i> | ±Nmax/±10V | Nmax: Maximum Speed (F03, A06, A106) |
| 02 | Reference speed 2 (before ACC/DEC processing) | <i>N-REF2</i> | ±Nmax/±10V | Nmax: Maximum Speed (F03, A06, A106) |
| 03 | Reference speed 4 (ASR input) | <i>N-REF4</i> | ±Nmax/±10V | Nmax: Maximum Speed (F03, A06, A106) |
| 04 | Detected speed 2 (ASR input) | <i>N-FB2±</i> | ±Nmax/±10V | Nmax: Maximum Speed (F03, A06, A106) |
| 05 | Detected line speed | <i>LINE-N±</i> | ±Nmax/±10V | Nmax: Maximum Speed (F03, A06, A106) |
| 06 | Torque current command (Torque ammeter, one-way deflection) | <i>IT-REF±</i> | ±150%/±10V | 100%: Torque Current (P09, A11, A111) |
| 07 | Torque current command (Torque ammeter, two-way deflection) | <i>IT-REF+</i> | +150%/10V | 100%: Torque Current (P09, A11, A111) |
| 08 | Torque command (Torque meter, two-way deflection) | <i>T-REF±</i> | ±150%/±10V | 100%: Motor rated torque |
| 09 | Torque command (Torque meter, one-way deflection) | <i>T-REF+</i> | +150%/10V | 100%: Motor rated torque |
| 10 | Motor current | <i>I-AC</i> | 200%/10V | 100%: Rated Current (P04, A03, A103) |
| 11 | Motor voltage | <i>V-AC</i> | 200%/10V | 100%: Rated Voltage (F05, A04, A104) |
| 12 | Input power (Motor output) | <i>PWR</i> | 200%/10V | 100%: Motor rated torque |
| 13 | DC link bus voltage | <i>V-DC</i> | 800V/10V | Maximum value 820V/10.25V |
| 14 | +10V test voltage output | <i>P10</i> | +10 VDC equivalent | - |
| 15 | -10V test voltage output | <i>N10</i> | -10 VDC equivalent | - |
| 16 | Motor temperature | <i>TMP-M</i> | ±200°V/±10V | - |
| 30 | Universal AO | <i>U-AO</i> | ±4000H/±10V | - |
| 31-37 | Custom Ao1-Ao7 | <i>C-AO1-7</i> | ±4000H/±10V | - |
| 38 | Input power | <i>PWR-IN</i> | 200%/10V | 100%: Inverter rated output |
| 39 | Magnetic pole position signal | <i>SMP</i> | TOP/5V | |
| 40 | PID output value | <i>PID-OUT</i> | ±200%/±10V | |

Note: Terminals [Ao4] and [Ao5] are available only when the OPC-VG1-AIO is mounted.

<Using analog output>

There are 5 types of analog output functions--three terminals [AO1], [AO2] and [AO3] as standard and additional two terminals [AO4] and [AO5] when an AIO option is mounted.

Setting procedure

- Check a device such as a meter including wires. Set data to 14 to check 10V output.
- Select a function you want to use. We select the "Detected Speed 1 (Speedometer, two-way deflection)" as an example.
- Assign the "Detected Speed 1 (Speedometer, two-way deflection)" function to one of the available terminals ([AO1] to [AO5]). To assign it to [AO2], write *N-FBI*± (data = 01) to the function code E70 "AO2 function selection".
- See the "I/O check" screen of the KEYPAD panel to confirm that [AO2] supplies +10.0V during operating a motor. The right figure shows the screen you must view.
- Connect a speedometer to the analog terminal [AO2].
- You can specify the bias, the gain, and the filter applied to the analog output.

| | |
|-----------------|--------|
| 1 5 0 0 | |
| AO1 = | 0. 0V |
| AO2 = | 10. 0V |
| AO3 = | 0. 0V |
| ΛV→PAGE SHIFT 6 | |

| Function | Application |
|----------|---|
| Bias | Sets the bias. |
| Gain | Use to enlarge a small voltage range or to reduce a large voltage range. Use a minus value to invert the polarity. |
| Filter | You do not need to change the factory set data 0.010 s (10 ms). This filter does work for the noise affecting a device (such as a meter) and wires between the device and [AO] terminal. Take necessary measures against noise outside of the inverter. |

See the description of the individual function codes for more details.

See also the control block diagram to work with this function effectively.

Output resolution

The AO converts 12-bit digital data into analog data for output. 11 bits are assigned to +12 V, thus binary data corresponding to 10V is 1705 ($2047 \times 10/12$).

When using +10 V to supply a speed reference corresponding to the maximum speed of 1500 r/min, for example, the resolution is $1500/1700 = \text{Approx. } 0.88 \text{ r/min}$.

Output cycle

Output is supplied with a sampling cycle of approx. 1 ms.

Function code data = 00 Detected speed 1 (Speed indicator, one-way deflection) -- *N-FBI+*

Function code data = 01 Detected speed 1 (Speed indicator, two-way deflection) -- *N-FBI±*

Assign data "00" (*N-FBI+*) and "01" (*N-FBI±*) to desired analog output terminals to designate them as speedometer functions.

Use *N-FBI+* for a unipolar meter and use *N-FBI±* for a bipolar meter. This function detects encoded motor speed and supplies a data after the speed detection calculation or the speed estimation calculation.


Function code data = 02 Reference speed 2 (before ACC/DEC processing) -- *N-REF2*

Function code data = 03 Reference speed 4 (ASR input) -- *N-REF4*

Function code data = 04 Detected speed 2 (ASR input) -- *N-FB2±*

Assign data "02" (*N-REF2*), "03" (*N-REF4*) and "04" (*N-FBI+*) to desired analog output terminals to output the speed reference and detected speed of each of them. You can use these functions to measure and observe the follow-up and the deviation of the Detected speed 2 (ASR input) against individual speed references externally. Note that the Speed agreement (the comparison between *N-REF2* and *N-FB2±*) and the Speed equivalent (*N-REF4* and *N-FB2±*) of the inverter DO output use these data for output.

The speed reference 3 in the right graph is not available for an AO output.



Function code data = 05 Detected line speed -- *LINE-N±*

Assign data "05" (*LINE-N±*) to a desired analog output terminal to designate it as line speed detection. The highest data among the analog line speed (*LINE-N*), the digital line speed, detected speed by PG (LD) and a data from integrated speed detection/estimation is provided to output.

Function code data = 06 Torque current command (Torque ammeter, two-way deflection) -- *IT-REF±*

Function code data = 07 Torque current command (Torque ammeter, one-way deflection) -- *IT-REF+*

Assign data "06" (*IT-REF±*) and "07" (*IT-REF+*) to desired analog output terminals to designate them as torque ammeters (see "Note: Torque Ammeters and Torque Meters" given below).

To use an analog output terminal as a unipolar meter, merely assign *IT-REF+*. To use it as a bipolar meter, assign *IT-REF±* and set the data of F51* (Torque command monitor, Polarity).

*F51 (Torque command monitor, Polarity)

F51 specifies the polarity of the monitor output for the four quadrants defining torque current characteristics. The F51 data applies to all torque-related monitor outputs.

Function code data = 08 Torque command (Torque meter, two-way deflection) -- *T-REF±*

Function code data = 09 Torque command (Torque meter, one-way deflection) -- *T-REF+*

Assign data "08" (*T-REF±*) and "09" (*T-REF+*) to desired analog output terminals to designate them as torque meters (see "Note: Torque Ammeters and Torque Meters" given below).

To use an analog output terminal as a unipolar meter, merely assign *T-REF+*. To use it as a bipolar meter, assign *T-REF±* and set the data of F51* (Torque command monitor, Polarity).

Note: Torque Ammeters and Torque Meters

A torque ammeter and a torque meter behave differently in the constant output range exceeding the rated speed (100%).


Torque ammeter: This is used as a load meter (equivalent to load-current detection type).

It outputs the actual torque current (%), based on the definition of the motor torque curve calculated internally as 100%.

Torque meter: This is used as an output equivalent to the actual torque reflecting torque decrement.

It outputs the actual torque (%), based on the definition of the motor rated torque as 100%.

Both the above meters output command values which can be used as real torque current and torque without problems since the FRENIC-VG controls the current.



Function code data = 10 Motor current -- *I-AC*

Function code data = 11 Motor voltage -- *V-AC*

Provide effective values of the output current and voltage supplied to the motor.

"100%" indicates the rated current and voltage of the motor.

Function code data = 12 Input power (Motor output) -- *PWR*

This analog signal outputs the motor output power. The "motor rated power (kW) x 2" is output as 10 V.

Function code data = 13 DC link bus voltage -- *V-DC*

See the control block diagram given in Section 4.1.8.

Function code data = 14 +10V test voltage output -- *P10*

This analog signal outputs +10 V for adjustment of an analog meter. (Use this signal for an analog meter externally connected.)

Function code data = 15 -10V test voltage output -- *N10*

This analog signal outputs -10 V for adjustment of an analog meter. (Use this signal for an analog meter externally connected.)

Function code data = 16 Motor temperature -- *TMP-M*

This analog signal outputs the motor temperature converted from input values selected by P30, A31 or A131 (M1, M2 or M3 thermistor selection).

Function code data = 30 Universal AO -- *U-AO*

This analog signal is used to monitor the processing result of software made by the UPAC option or PLC connected via the communications link (e.g., SX bus and RS-485).

The U-AO enables monitor output independent of the inverter operation.

Function code data = 31-37 Custom-Ao1 to Ao7 -- *C-Ao1 to C-Ao7*

Ao terminals for manufacturers. Do not assign these signals.

Function code data = 38 Input power -- *PWR-IN*


This analog signal outputs how much power is applied to the inverter. It outputs +10 V for the "inverter rated power (kW) x 2."

The purpose of this signal is to display the input power, so it does not display the regenerative power. For the combination with the power regenerative converter, use the converter's function code M10 "Input power."

Function code data = 39 Magnetic pole position signal -- *SMP*

This analog signal outputs the "pulse integrated value of the encoder attached to a PMSM" plus the magnetic pole position offset (o10 when motor M1 is selected), as a magnetic pole position signal. This signal operates only when PMSM control is selected.

Depending upon the whether the motor rotation is forward or reverse, the inverter operates as shown below. A single motor rotation outputs 1/2 cycle signal of the number of motor poles.



The *SMP* is used for adjustment of the magnetic pole position in Chapter 3, Section 3.5.3.3 "Vector control for PMSM with speed sensor and magnetic pole position sensor."

Function code data = 40 PID output value -- *PID-OUT*

Set this analog signal in order to monitor PID output values issued from the PID control processing block.


E74 to E78 **Ao Gain**

These function codes specify gains to be applied to analog output terminals [Ao1] to [Ao5].

| | | | | |
|-------|---------|-------|--|--|
| E 7 4 | G A I N | A O 1 | | |
| E 7 5 | G A I N | A O 2 | | |
| E 7 6 | G A I N | A O 3 | | |
| E 7 7 | G A I N | A O 4 | | |
| E 7 8 | G A I N | A O 5 | | |

Data setting range: -100.00 to 100.00 (times)

Note: [Ao4] and [Ao5] are available only when the OPC-VG1-AIO is mounted.




E79 to E83 **Ao Bias**

These function codes specify the bias of analog output Ao1 to Ao5.

| | | | | |
|-------|---------|-------|--|--|
| E 7 9 | B I A S | A O 1 | | |
| E 8 0 | B I A S | A O 2 | | |
| E 8 1 | B I A S | A O 3 | | |
| E 8 2 | B I A S | A O 4 | | |
| E 8 3 | B I A S | A O 5 | | |

Data setting range: -100.00 to 100.00 (%)

Note: [Ao4] and [Ao5] are available only when the OPC-VG1-AIO is mounted.



E84 **Ao1-Ao5 Filter**

E84 specifies the time constant of the output filters for the analog output Ao1 to Ao5 simultaneously.

| | | | | |
|-------|---------|-----------|--|--|
| E 8 4 | F I L T | A o 1 - 5 | | |
|-------|---------|-----------|--|--|

Data setting range: 0.000 to 0.500 (s)

Note: [Ao4] and [Ao5] are available only when the OPC-VG1-AIO is mounted.

| | |
|------------|---|
| E90 | Link Command Function Selection 1 (Available soon) |
| E91 | Link Command Function Selection 2 (Available soon) |

When E90 ≠ 0 (**OFF**) or E91 ≠ 0 (**OFF**), it is possible to select analog input data (Ai1 or Ai2) entered from the UPAC option or PLC via the communications link (link option that can use the link number of a communications address).

- To use the link command as the Ai1 function, function code S16 applies.
- To use the link command as the Ai2 function, function code S17 applies.

The setting made by E90 or E91 has priority over that made by E49 or E50 (Terminal Ai Function).

| | | | |
|--------------|--------------|----------------|--|
| E 9 0 | L N K | F U C 1 | |
| E 9 1 | L N K | F U C 2 | |

Data setting range: 00 to 12


| Data for E90 or E91 | Terminal commands assigned | Symbol | Scale | |
|---------------------|-------------------------------------|----------------|-------------------|---|
| | | | S code setting | Internal definition Internal range |
| 00 | Shut down input signal | OFF | — | |
| 01 | Auxiliary speed setting 1 | AUX-N1 | -20000d to 20000d | (data)*Nmax/20000d -Nmax to Nmax |
| 02 | Auxiliary speed setting 2 | AUX-N2 | -20000d to 20000d | (data)*Nmax/20000d -Nmax to Nmax |
| 03 | Torque bias level | TB-REF | -32768d to 32767d | 0.01%/1d -327.68 to 327.67% |
| 04 | Creep speed 1 for UP/DOWN control | CRP-N1 | -20000d to 20000d | (data)*Nmax/20000d -Nmax to Nmax |
| 05 | Creep speed 2 for UP/DOWN control | CRP-N2 | -20000d to 20000d | (data)*Nmax/20000d -Nmax to Nmax |
| 06 | Detect line speed | LINE-N | -20000d to 20000d | (data)*Nmax/20000d -Nmax to Nmax |
| 07 | Motor temperature | M-TMP | 0d to 200d | 1°C/1d 0 to 200°C |
| 08 | Speed override | N-OR | -5000d to 5000d | 0.01%/1d -50.00 to +50.00% |
| 09 | PID feedback amount 1 | PID-FB1 | -22000d to 22000d | 0.005%/1d -110.000 to 110.000% |
| 10 | PID command amount | PID-REF | -22000d to 22000d | 0.005%/1d -110.000 to 110.000% |
| 11 | PID correction gain | PID-G | -16384d to 16384d | 1 time/±16384d -1.0000 to 1.0000 times |
| 12 | PID feedback amount 2 | PID-FB2 | -22000d to 22000d | 0.005%/1d -110.000 to 110.000% |
| 13 | Observer torque FB (Available soon) | OBS-TFB | — | |

E101 to E104 **Ai Offset**

These function codes specify Ai offsets. Only changing the function code data with the \odot / \ominus keys makes the new data effective. To save it into the backup memory, it is necessary to press the FUNC/DATA key.

These function codes are functionally equivalent to E57 to E60.

Use these function codes for adjustment of out-of-offset signals sent from external equipment.



| | | |
|---------|-------|-----------|
| E 1 0 1 | A i 1 | O F S E T |
| E 1 0 2 | A i 2 | O F S E T |
| E 1 0 3 | A i 3 | O F S E T |
| E 1 0 4 | A i 4 | O F S E T |

Data setting range: -100.00 to 100.00 (%)

Note: [Ai3] and [Ai4] are available only when the OPC-VG1-AIO is mounted.


E105 to E108 **Ai Dead Zone**

These function codes specify Ai dead zones for analog input entered via analog input terminals [Ai1] to [Ai4]. Command values below this input will be limited to 0 V.

| | | |
|---------|-------|-----------|
| E 1 0 5 | A i 1 | B L I N D |
| E 1 0 6 | A i 2 | B L I N D |
| E 1 0 7 | A i 3 | B L I N D |
| E 1 0 8 | A i 4 | B L I N D |

Data setting range: 0.00 to 10.00 (%)

Note: [Ai3] and [Ai4] are available only when the OPC-VG1-AIO is mounted.



| | |
|-------------|---|
| E109 | Dividing Ratio for FA, FB Pulse Output (Numerator) |
|-------------|---|

| | |
|-------------|---|
| E110 | Dividing Ratio for FA, FB Pulse Output (Denominator) |
|-------------|---|

E109 and E110 specify the numerator and denominator of the dividing ratio for FA and FB pulse output. These settings are available when E29 = 7 to 10 or the SPGT option is mounted.

| | | | | | | | | | | |
|----------|----------|----------|----------|----------|----------|----------|----------|----------|----------|----------|
| E | 1 | 0 | 9 | P | L | S | N | U | M | E |
| E | 1 | 1 | 0 | P | L | S | D | E | N | O |

Data setting range: 1 to 65535

Note: Specify E109 and E110 data so that $E109 \leq E110$. Even when $E109 > E110$, the dividing ratio comes to be "1."

| | |
|-------------|--|
| E114 | Speed Agreement 2 (Detection width) |
|-------------|--|

| | |
|-------------|--|
| E115 | Speed Agreement 2 (Off-delay timer) |
|-------------|--|

These function codes apply when motor M2 is selected.

If the detected speed agrees with the reference speed (ASR input) (or comes within the detection width specified by E114), the inverter outputs the Speed agreement signal **N-AG2**.

- Detected speed: **N-FB2±** (Detected speed 2) (ASR input)
- Reference speed: **N-REF4** (Reference speed 4)

| | | | | | | | | | | | |
|----------|----------|----------|----------|----------|----------|----------|----------|----------|----------|----------|----------|
| E | 1 | 1 | 4 | N | - | A | G | 2 | R | N | G |
| E | 1 | 1 | 5 | N | - | A | G | 2 | T | I | M |

Data setting range: E114 = 1.0 to 20.0 (%)
E115 = 0.000 to 5.000 (s)

An off-delay timer can be set for output of the Speed agreement signal.

These function codes produce the same inverter operation as E43 and E44. For details, refer to the descriptions of those codes.

| | |
|-------------|--|
| E116 | Speed Agreement 3 (Detection width) |
|-------------|--|

| | |
|-------------|--|
| E117 | Speed Agreement 3 (Off-delay timer) |
|-------------|--|

These function codes apply when motor M3 is selected.

If the detected speed agrees with the reference speed (ASR input) (or comes within the detection width specified by E116), the inverter outputs the Speed agreement signal **N-AG3**.

These function codes produce the same inverter operation as E43 and E44. For details, refer to the descriptions of those codes.

| | | | | | | | | | | | |
|----------|----------|----------|----------|----------|----------|----------|----------|----------|----------|----------|----------|
| E | 1 | 1 | 6 | N | - | A | G | 3 | R | N | G |
| E | 1 | 1 | 7 | N | - | A | G | 3 | T | I | M |

Data setting range: E116 = 1.0 to 20.0 (%)
E117 = 0.000 to 5.000 (s)

E118**Temperature for Axial Fan Stop Signal**

When the NTC thermistor detection temperature of the motor equipped with an NTC thermistor drops below the setting made by E118, the inverter turns *MFAN* (Axial fan stop signal) ON.

The *MFAN* is used to stop the axial fan (cooling fan) of the motor when the motor is stopped.

Note that when the inverter is running, the *MFAN* signal is always OFF irrespective of the E118 setting.

| | | | | | | | | | | | |
|---|---|---|---|---|---|---|---|---|---|---|---|
| E | 1 | 1 | 8 | F | - | S | T | P | T | M | P |
|---|---|---|---|---|---|---|---|---|---|---|---|

Data setting range: 0 to 200 (°C)

Note 1: This function is available when the NTC thermistor is selected for the selected motor (M1, M2 or M3). When any other thermistor is selected, the *MFAN* is always OFF.

Note 2: For the VG5, VG7, and FRENIC-VG standard motors, set the temperature (E118) at 100°C or below. To avoid the temperature rise of the motor winding, when the NTC thermistor detection temperature exceeds 100°C, it is recommended that the inverter always be ventilated with a cooling fan(s).

4.3.3 C codes (Control Functions)

| | |
|-----|---------------------------------|
| C01 | Jump Speed 1 |
| C02 | Jump Speed 2 |
| C03 | Jump Speed 3 |
| C04 | Hysteresis Width for Jump Speed |


Jumps the speed reference to avoid mechanical resonance points of a load.

You can set three jump points. When you set the Jump speed 1 to 3 to 0 r/min, this function is disabled. The speed reference does not jump during acceleration/deceleration.

When specified ranges of jump speed overlap one another, the sum of them is considered as a jump range.


| | | | | | | | | | | |
|---|---|---|---|---|---|---|---|---|---|---|
| C | 0 | 1 | J | U | M | P | N | 1 | | |
| C | 0 | 2 | J | U | M | P | N | 2 | | |
| C | 0 | 3 | J | U | M | P | N | 3 | | |
| C | 0 | 4 | J | U | M | P | H | Y | S | T |

Data setting range: C01 to C03 = 0 to 30,000 (r/min)
C04 = 0 to 1,000 (r/min)



If the jump width is larger than twice the jump speed setting, the downward jump is limited at 0 r/min.


(Example) Jump speed = 100 (r/min)
Jump width = 300 (r/min)



C05 to C17 **Multistep Speed 1 to 13**

You can set ON or OFF to the terminal function *SSI*, *SS2*, *SS4*, and *SS8* to switch among Multistep speed 1 to 15 (refer to E01 to E13 "X function selection" for setting the terminal function).

When a terminal among *SSI*, *SS2*, *SS4*, and *SS8* is not defined, the terminal considered to be OFF. You can select 1r/min or 0.01% for a unit of a setting range according to the setting of C21 "Multistep setting definition". When you choose 0.01% for a unit, 100% is the maximum speed defined by the function code (F03, A06, or A106).



C 0 5 M U L T I N - 1

C 1 7 M U L T I N - 1 3

Data setting range: 0 to 30,000 (r/min), 0.00 to 100.00 (%) or 0.0 to 999.9 (m/min)

C18 **Multistep Speed 14/Creeping Speed 1**

C19 **Multistep Speed 15/Creeping Speed 2**

C18 and C19 also work as a creep speed function when you use the UP/DOWN function. See E01 to E09 "X function selection" for more details.

C 1 8 N - 1 4 / C R E P 1

C 1 9 N - 1 5 / C R E P 2

Data setting range: 0 to 30,000 (r/min), 0.00 to 100.00 (%) or 0.0 to 999.9 (m/min)


C20**Multistep Speed Agreement Timer**

When the terminal function *SSI*, *SS2*, *SS4*, and *SS8* do not change simultaneously, a speed reference out of the specification may be specified. When you use the Multistep speed reference agreement timer, the speed reference changes after *SSI*, *SS2*, *SS4*, and *SS8* maintain the same state for a time specified by the Multistep speed reference agreement timer. Use this timer to use two or more terminals simultaneously among *SSI*, *SS2*, *SS4*, and *SS8* to switch the speed. If you switch only one terminal, leave the setting to 0.000s.

< Application example >

This section shows an example to use terminals *SSI* and *SS2* to switch the multistep speed. When you want to change from the Multistep speed 1 to the Multistep speed 2, you should switch two terminals simultaneously.

- When you set the timer to 0.00s, the difference in switching timing of *SSI* and *SS2* activates the Multistep speed 3 for the delayed period and presents a operation pattern out of the specification as shown in the upper right graph.
- When you set the time of this function code to a period longer than the switching time, the switching to Multistep speed 2 occurs just when a specified time passes after *SSI* is set to OFF. You can avoid the Multistep speed 3 to be selected.



< Point >

The cycle sampling the terminal signals is about 500 μs (0.5 ms) in the FRENIC-VG. You do not have to set this function if your switching period is shorter than the sampling cycle.

C 2 0 M L T N T I M E

Data setting range: 0.000 to 0.100 (s)

C21**Multistep Speed Configuration Definition**

Sets the unit to specify the multistep speed.

C 2 1 M L T U N I T

Data setting range: 0 (Specify the multi-step speed in r/min.)

1 (Specify in increments of 0.01%.)

2 (Specify in m/min. (L03 lifter rated speed must be specified.))

If the C21 setting is changed, enter C05 through C19 again.

C25**Speed Command N2**

Sets a method to specify the speed command. When the X terminal function *N2/N1* is set to ON, the speed specified this function will be effective. See the description of F01 "Speed setting N1" for setting method you can select.

C 2 5 S P D C M D 2



| | |
|------------|----------------------|
| C29 | Jogging Speed |
|------------|----------------------|

C 2 9 J O G N

Data setting range: 0 to 30,000 (r/min)

Sets a speed for inching a motor in addition to the normal operation. You can use this function for positioning a work, for example.

You can choose the following two ways for the jogging operation.

- Turn on the X control terminal [JOG] to change to the jogging mode and set the operation command [FWD] or [REV] to ON.
- Set the  and  keys on the KEYPAD panel to ON simultaneously to switch to the jogging mode and set the operation command [FWD] or [REV] to ON.

| | |
|-------------------|--|
| C30 to C69 | ASR S-curve Acceleration/Deceleration 2, 3 and 4, and JOG Function Code Group |
|-------------------|--|

The function code group C30 to C38 becomes effective in the JOG mode.

The terminal input signal **RT1** and **RT2** set the function code group C40 to C69 to either enabled or disabled. The speed limit function response gain in the torque control mode is adjusted with C60 (ASR4-P).

See E01 to E13 "X function selection" and the control block diagram for the details of switching.


Acceleration/deceleration time: See the description of the function code F07 and F08.

S-curve setting: See the description of the function codes F67 to F70. Note that you can set only the two points, the start and end sides, for the S-curve acceleration/deceleration 2,3, and 4 and the JOG.

ASR setting: See the description of the function codes F61 to F65. Note that you cannot set the F/F gain to the ASR-JOG.

You can view the setting on the "I/O check" screen of the KEYPAD panel.

The right figure shows that the ASR2 and the S-curve deceleration (PARA 2) are selected.




| | |
|------------|---------------------------|
| C70 | ASR Switching Time |
|------------|---------------------------|

This function specifies the duration of the switching, when you use the X control terminals [RT1] and [RT2] to switch the ASRs.

This function change the P (gain) gradually in a specified time to reduce the mechanical shocks during the switching. Specify the time necessary to change the ASR gain 100 times.

The right figure shows an example to set the [RT1] to OFF, ON, then to ON to switch the gain between the ASR1 and ASR2.



$$t = \frac{|(ASR2\ P\ GAIN) - (ASR1\ P\ GAIN)|}{100} \times C70\ (s)$$

| | | | | | | | | | | |
|---|---|---|---|---|---|---|---|---|--|--|
| C | 7 | 0 | A | S | R | C | H | t | | |
|---|---|---|---|---|---|---|---|---|--|--|

Data setting range: 0.00 to 2.55 (s)


| | |
|------------|--------------------------------|
| C71 | ACC/DEC Switching Speed |
|------------|--------------------------------|

| | |
|------------|---------------------------|
| C72 | ASR Switching Time |
|------------|---------------------------|

| | | | | | | | | | | | |
|---|---|---|---|---|---|---|---|---|---|---|---|
| C | 7 | 1 | A | C | C | / | D | E | C | C | H |
| C | 7 | 2 | A | S | R | C | H | S | P | D | |

Data setting range: 0.00 to 100.00 (%)

If both X control terminals [RT1] and [RT2] are off, use the speed setting of this parameter to automatically switch the setting of acceleration/deceleration time ASR. (Deactivation of both [RT1] and [RT2] includes the case where [RT1] and [RT2] are not assigned to X control terminals.) When the speed setting (ASR input) exceeds the level specified at C71 and C72, changeover to acceleration/deceleration time 2 (ASR2) occurs. The hysteresis width is 1% of the maximum speed.



If the setting is "0.00%," changeover does not occur.

"100.00%" indicates the maximum speed set at function codes F03, A06 and A106.

C73 **Creep Speed Switching (under UP/DOWN control)**

Specifies whether to use a function or an analog input to set the creep speeds used in the UP/DOWN setting mode.

```
C 7 3 C R P S W I T C H
```

Data setting range: 00 to 11

Description:
 └─ First digit: Creep speed 2 (0: function code C19, 1: analog input *CRP-N2*)
 └─ Second digit: Creep speed 1 (0: function code C18, 1: analog input *CRP-N1*)

See the description of the UP/DOWN in the E01 to E13 "X function selection".


4.3.4 P codes (Motor Parameter Functions)

P codes specify motor parameters available when motor 1 (M1) is selected. To use motor 2 (M2) or motor 3 (M3), specify motor parameters with A codes.

M1, M2 and M3 can be switched with Function code F79 and terminal commands *M-CH2* and *M-CH3* (which are assigned to digital input terminals with E01 to E13). Refer to the related function code and terminal commands.

To check that M1 is selected, use Menu #4 "I/O Checking" on the keypad and check that the box of the M1 appears black (■) as shown at the right.

In addition to P codes, F03 to F05 and F10 to F12 are available when M1 is selected.



| | |
|------------|-------------------------|
| P01 | M1 Drive Control |
|------------|-------------------------|


P01 specifies the drive control for motor 1, which can be selected from the following motor drive controls. Refer to the description of P02 in conjunction with that of P01.

P 0 1 M 1 - C T L - M T D

- Data = 0: Vector control for IM with speed sensor
- 1: Vector control for IM without speed sensor
- 2: Simulation mode
- 3: Vector control for PMSM with speed sensor
- 5: V/f control for IM

About vector control

The right figure shows a rotating coordinate (d-q axes) of a rotor on a coordinate (α - β axes) generated by two-phase conversion from a stator coordinate (U, V, W). θ shows the rotation position and indicates the position of the magnetic-flux (d axis=direction of magnetic flux) observed on the fixed coordinate (α - β axes).



The alternating current (I) flowing through the stator generates a rotating magnetic field. The rotor coordinate (d-q axes) rotates at the frequency of this alternating current. If you observe the current (I) from the rotor coordinate (d-q axes), the current (I) seems stationary. Thus, the alternating current (I) can be considered direct current value on the rotor coordinate (d-q axes). You can decompose the current into the d axis element and the q axis element ($I \rightarrow I_q + I_d$). The d axis current (I_d) is defined as magnetic-flux current (exciting current) denoting a current required to generate a magnetic-flux. The q axis current (I_q) is defined as torque current (load current).

When a load changes to require I_q' (indicated by a dotted arrow in the figure) as the torque current, you should control the current by directing I' (indicated by a dotted arrow in the figure) as a current command while maintaining the magnetic-flux current (I_d). The control that maintains the magnetic-flux ($I_d = \text{constant}$) and changes the torque current (I_q) according to the load is referred as **vector control**. Since this control is similar to the control for the direct current motor where the magnetic-flux is maintained constant by the magnet and the rotor current is controlled according to the load, you can use the same control for an alternating current motor as for a direct current motor.

About vector control without speed sensor

This control utilizes vector control (similar to DC motor control) for a motor without a pulse generator. This control enables torque control, which is not available in V/f control. Use this control when you use existing general-purpose motors or motors to which you cannot install a PG.

Note that the control capability (such as speed control range, speed control response, and speed control accuracy) differs from that of control utilizing PG described in Chapter 2 "Specifications" when you select the control. If you need this capability, select vector control with PG for a motor with a PG.

Tune the motor parameter to control properly. Use the function code H01 to conduct tuning (set value 3 and 4).

<Control mechanism>

Vector control without speed sensor calculates the motor speed and the magnetic pole position. This control detects the output voltage and the output current and uses the motor parameters ($R1$, $L\sigma$) identified through tuning to calculate the induced voltage. The magnetic flux position is determined since the E_d element obtained by decomposing this induced voltage into the d axis direction is 0. Since the E_q element on the q axis direction corresponds to the induced motor voltage and is proportional to the motor speed, you can obtain the motor speed. This control has the following restrictions compared with vector control with PG.

- Speed control range is limited at low speed due to the inferior accuracy of the induced motor voltage compared with that at high speed.
- Speed control response is low due to the slow convergence of the internal calculation.
- Speed control accuracy is inferior due to the accuracy of the speed calculation based on the induced voltage.

About simulation mode

Selecting the simulation mode ($P01 = 2$) enables the inverter to internally run in a state similar to the actual run without connecting a motor. Use the simulation mode for checking the system including I/Os or for testing at the time of system startup.


When $P01 = 2$, the inverter shifts to the simulation mode irrespective of the current motor state.

As shown below, giving a torque command to a machine model (Load inertia: H51) accelerates the model to a certain speed according to the load inertia. Since speed control is a type of feedback control, the machine model rotates to follow the reference speed in the end.

The running state can be checked on the LED monitor and LCD monitor or with monitor codes (M field). Note that neither current detection nor voltage detection is performed so that both the "output current" and "output voltage" on the LCD monitor show "0."

Individual function codes and protective functions are available as long as they are not restricted.

During simulation mode, the inverter shuts off the base (its output) so that no voltage is developed in the secondary side (U, V, W). For safety, however, cut off the secondary side or shut it off with magnetic contactors or the like.



P02**M1 Motor Selection**

P02 specifies the motor type to be used.

The configuration procedure of the related function codes differs between the use of the VG-dedicated motors except Fuji VG1 5-series motors (Setting: "0.75-2" to "220-4" and "30-2A" to "220-4A") and that of other motors (Setting: OTHER).

When the VG-dedicated motor is used, selecting the combination of "Capacity (kW)-Voltage (2, 4)" from a choice of "0.75-2" to "220-4" and "30-2A" to "220-4A" automatically sets the optimum values of the standard motors (see the table given on the next page) to F04, F05 and P03 to P27 and then write-protects those function codes.

When any other motor (Fuji VG1 5-series motors, Fuji motors, VG3, etc.) is used, select "OTHER."

P 0 2 M 1 - S E L E C T

List of Applicable Motors

| P02 data | | Applicable Motor Models | P02 data | | Applicable Motor Models |
|------------|-----------|-------------------------|------------|------------|---|
| kW | HP | | kW | HP | |
| 00: 0.75-2 | 00: 1-2 | MVK6096, MVK6095A | 26: 45-4Y | 26: 60-4Y | MVK6208, MVK8208A |
| 01: 1.5-2 | 01: 2-2 | MVK6097, MVK8097A | 27: 45-4S | 27: 60-4S | MVK6208, MVK8208A |
| 02: 2.2-2 | 02: 3-2 | MVK6107, MVK8107A | 28: 55-4 | 28: 75-4 | MVK9250 |
| 03: 3.7-2 | 03: 5-2 | MVK6115, MVK8115A | 29: 75-4 | 29: 100-4 | MVK9252 |
| 04: 5.5-2 | 04: 7.5-2 | MVK6133, MVK8133A | 30: 90-4 | 30: 125-4 | MVK9280 |
| 05: 7.5-2 | 05: 10-2 | MVK6135, MVK8135A | 31: 110-4 | 31: 150-4 | MVK9282 |
| 06: 11-2 | 06: 15-2 | MVK6165, MVK8165A | 32: 132-4 | 32: 175-4 | MVK9310 |
| 07: 15-2 | 07: 20-2 | MVK6167, MVK8167A | 33: 160-4 | 33: 200-4 | MVK9312 |
| 08: 18.5-2 | 08: 25-2 | MVK6184, MVK8184A | 34: 200-4 | 34: 250-4 | MVK9316 |
| 09: 22-2 | 09: 30-2 | MVK6185, MVK8185A | 35: 220-4 | 35: 300-4 | MVK9318 |
| 10: 30-2 | 10: 40-2 | MVK6206 | 36: P-OTR | 36: P-OTR | -- |
| 11: 37-2 | 11: 50-2 | MVK6207, MVK8207A | 37: OTHER | 37: OTHER | Fuji VG1 5-series motors Fuji motors, VG3, etc |
| 12: 45-2Y | 12: 60-2Y | MVK6208, MVK8208A | 38: 30-2A | 38: 40-2A | MVK8187A |
| 13: 45-2S | 13: 60-2S | MVK6208, MVK8208A | 39: 55-2A | 39: 75-2A | MVK9250 |
| 14: 55-2 | 14: 75-2 | MVK9224A | 40: 75-2A | 40: 100-2A | MVK9254A |
| 15: 75-2 | 15: 100-2 | MVK9252 | 41: 90-2A | 41: 125-2A | MVK9256A |
| 16: 90-2 | 16: 125-2 | MVK9280 | 42: 30-4A | 42: 40-4A | MVK8187A |
| 17: 3.7-4 | 17: 5-4 | MVK6115, MVK8115A | 43: 55-4A | 43: 75-4A | MVK9224A |
| 18: 5.5-4 | 18: 7.5-4 | MVK6133, MVK8133A | 44: 75-4A | 44: 100-4A | MVK9254A |
| 19: 7.5-4 | 19: 10-4 | MVK6135, MVK8135A | 45: 90-4A | 45: 125-4A | MVK9256A |
| 20: 11-4 | 20: 15-4 | MVK6165, MVK8165A | 46: 110-4A | 46: 150-4A | MVK9284A |
| 21: 15-4 | 21: 20-4 | MVK6167, MVK8167A | 47: 132-4A | 47: 175-4A | MVK9286A |
| 22: 18.5-4 | 22: 25-4 | MVK6184, MVK8184A | 48: 160-4A | 48: 200-4A | MVK9311A |
| 23: 22-4 | 23: 30-4 | MVK6185, MVK8185A | 49: 200-4A | 49: 250-4A | MVK9311MA |
| 24: 30-4 | 24: 40-4 | MVK6206 | 50: 220-4A | 50: 300-4A | MVK9311NA |
| 25: 37-4 | 25: 50-4 | MVK6207, MVK6207A | | | |

Note: When using Fuji VG1 5-series motors, select "OTHER" for P02 and specify the motor parameters given in the User's Manual, Chapter 12.

The table below lists the function codes to be configured for IM when vector control is selected. Configure them sequentially from the top of the table.

Function codes to be configured for IM under vector control

| Function codes | | FRENIC-VG, VG7S, and VG5-dedicated motors | VG3-dedicated motors and VG1 5-series motors | Fuji special motors | Other motors (incl. other manufacturers' motors) |
|----------------|---|---|---|---|--|
| For M1 | Name | | | | |
| P01 | Drive control | 0: Vector control for IM with speed sensor | | Select either one of the following items depending upon whether a sensor is mounted. 0: Vector control for IM with speed sensor 1: Vector control for IM without speed sensor | |
| P02 | Motor selection | Select from a choice of "0.75-2" to "220-4" and "30-2A" to "220-4A." For the relationship between the setting data and the motor type, refer to Format [82] in the FRENIC-VG User's Manual, Chapter 4, Section 4.2.4.2, "Data type 12-145." | Select "37: OTHER." Selecting "36: P-OTR" automatically write-protects Function codes F04, F05, and P03 to P27. <u>Make this choice if needed after completion of configuration</u> of other function codes. | | |
| F04 | Rated speed | Configuring P02 automatically sets the following function code data and write-protects it. - Motor nameplate values - Optimum motor parameter values Turning the power OFF does not lose these values. Do not perform auto-tuning of motor parameters with H01. | Manually enter data given in the FRENIC-VG User's Manual, Chapter 12, "Replacement Information." Do not perform auto-tuning of motor parameters with H01. | For values to be set, consult your Fuji sales representative. | Enter the motor nameplate values manually. Perform auto-tuning of motor parameters, referring to the auto-tuning procedure given in the description of H01. |
| F05 | Rated voltage | | | | |
| P03 | Rated capacity | | | | |
| P04 | Rated current | | | | |
| P05 | No. of poles | | | | |
| P06 | %R1 | | | | |
| P07 | %X | | | | |
| P08 | Exciting current | | | | |
| P09 | Torque current | | | | |
| P10, P11 | Slip frequency of motor for driving and braking | | | | |
| P12-P14 | Iron loss factors 1-3 | | | | |
| P15-P19 | Magnetic saturation factors 1-5 | | | | |
| P20 | Secondary time constant | | | | |
| P21 | Induced voltage factor | | | | |
| P22-P24 | R2 correction factors 1-3 | | | | |
| P25 | Exciting current correction factor | | | | |
| P26, P27 | ACR P-gain, Integral constant | No change from the initial value is required. | | | |
| P28 | Pulse resolution | Specify the pulse resolution of the motor PG Not valid under vector control without speed sensor. | | | |
| P29 | External PG correction factor | If the motor PG is incorporated in the machinery, specify the correction factor to convert the number of pulses into the motor speed. Not valid under vector control without speed sensor. | | | |
| P30 | Thermistor selection | 1: NTC thermistor | | For details about motor protection, refer to the description of F10 in the FRENIC-VG User's Manual, Chapter 4, Section 4.3.1. | |
| F10 | Electronic thermal overload protection (Select motor characteristics) | 0: Disable (For VG-dedicated motors) | | | |
| P32 | Online auto-tuning | Select whether to enable the compensation function for the resistance change due to the temperature rise of the motor running. (No tuning starts when the NTC thermistor is enabled.) | | | |

| Function codes | | FRENIC-VG, VG7S, and VG5-dedicated motors | VG3-dedicated motors and VG1 5-series motors | Fuji special motors | Other motors (incl. other manufacturers' motors) |
|----------------|-------------------|---|--|---|--|
| For M1 | Name | | | | |
| H01 | Auto-tuning | Not required since configuring P02 as described above automatically sets the optimum values to the related function codes. Note that, perform auto-tuning (H01 = 2) when the impedance at the output side is not negligible because the wiring distance between the inverter and motor is long (100 m or more) or an output circuit filter (OFL) is connected. | | Required. Be sure to perform auto-tuning with actual wiring. Refer to the auto-tuning procedure given in the description of H01. | |
| H02 | Save all function | After performing auto-tuning with H01, be sure to execute the Save all function (H02 = 1) to write the tuning result into the non-volatile memory. Not required if no auto-tuning is performed. | | | |

Note: The VG-dedicated motors are the same as the VG7- and VG5-dedicated motors in shape and motor parameters.

The table below lists the function codes to be configured for PMSM when vector control is selected. Configure them sequentially from the top of the table.

When Fuji standard motors (GNF2 type) are used, the following function codes take effect. For other motors, consult your Fuji sales representative.

Function codes to be configured for PMSM under vector control

| Function codes | | FRENIC-VG dedicated motor | Other motors (incl. other manufacturers' motors) |
|----------------|---|--|--|
| For M1 | Name | | |
| P01 | Drive control | 3: Vector control for PMSM with speed sensor | |
| P02 | Motor selection | Select "37: OTHER." Selecting "36: P-OTR" automatically write-protects Function codes F04, F05, and P03 to P27. Make this choice if needed after completion of configuration of other function codes. | |
| P03 | Rated capacity | Manually enter the data given in Chapter 3, Section 3.5.3.3 "Vector control for PMSM with speed sensor and magnetic pole position sensor." | For values to be set, consult your Fuji sales representative. |
| P04 | Rated current | | |
| F05 | Rated voltage | | |
| F04 | Rated speed | | |
| F03 | Maximum speed | | |
| P05 | No. of poles | | |
| P06 | %R1 | | |
| P07 | %X | | |
| P08 | Magnetic flux weakening current | | |
| P09 | Torque current | | |
| P21 | Induced voltage factor | | |
| P26, P27 | ACR P-gain, Integral constant | | |
| P28 | Pulse resolution | | |
| P30 | Thermistor selection | | |
| F10 | Electronic thermal overload protection (Select motor characteristics) | 0: Disable (For VG standard motors) | For details about motor protection, refer to the description of F10. |
| P33 | Maximum voltage Limit | Manually enter the data given in Chapter 3, Section 3.5.3.3 "Vector control for PMSM with speed sensor and magnetic pole position sensor." | Specify the maximum voltage applicable to the motor. |
| o09 | Absolute signal input definition | | Specify the data in accordance with the encoder specifications. |
| o10 | Magnetic pole position offset | | For values to be set, consult your Fuji sales representative. |
| o11 | Salient pole rate (%Xq/%Xd) | | |
| P12-P14 | Iron loss factors 1-3 | | |
| P42 | q-axis induction magnetic saturation coefficient | | |
| P43 | Magnetic flux limiting value | | |
| P44 | Overcurrent protection level | | |
| P45-P51 | Torque correction gain 1-7 | | |

The table below lists the function codes to be configured for IM when V/f control is selected. Configure them sequentially from the top of the table.

Function codes to be configured for IM under V/f control

| Function codes | | FRENIC-VG, VG3-dedicated motors, and VG1 5-series motors | Other motors (incl. other manufacturers' motors) | |
|----------------|---|---|--|---|
| For M1 | Name | | | |
| P01 | Drive control | 5: V/f control for IM | | |
| P02 | Motor selection | Select "37: OTHER." Selecting "36: P-OTR" automatically write-protects Function codes F04, F05, and P03 to P27. <u>Make this choice if needed after completion of configuration</u> of other function codes. | | |
| P03 | Rated capacity | Manually enter data given in the FRENIC-VG User's Manual, Chapter 12, "Replacement Information." Do not perform auto-tuning of motor parameters with H01. | Enter the motor nameplate values manually. | |
| P04 | Rated current | | | |
| F03 | Maximum speed | | | |
| F04 | Rated speed | | | |
| F05 | Rated voltage | | | |
| P05 | No. of poles | | | |
| P06 | %R1 | | | Refer to the calculation procedures given in the description of P06 and P07 in the FRENIC-VG User's Manual, Chapter 4, Section 4.3.4. |
| P07 | %X | | | |
| P08 | Exciting current | Set the no-load current of the motor written on the motor test report. | | |
| P33 | Maximum output voltage | Set the maximum voltage of the motor. | | |
| P34 | Slip compensation | Refer to the calculation procedure given in the description of P34 in the FRENIC-VG User's Manual, Chapter 4, Section 4.3.4. | | |
| P35 | Torque boost | 0.0: Auto torque boost (factory default) If a starting torque is required, adjust the torque boost within the range of 0.1 to 20.0. | If the motor constant is unknown, set P35 to "2.0" (Manual boost). If a starting torque is required, adjust the torque boost within the range of 0.1 to 20.0. | |
| P30 | Thermistor selection | 1: NTC thermistor | | |
| F10 | Electronic thermal overload protection (Select motor characteristics) | 0: Disable (For VG-dedicated motors) | | |
| H01 | Tuning | Not required since configuring P02 as described above automatically sets the optimum values to the related function codes. Note that, perform auto-tuning (H01 = 2) when the impedance at the output side is not negligible because the wiring distance between the inverter and motor is long (100 m or more) or an output circuit filter (OFL) is connected. | Required. Be sure to perform auto-tuning with actual wiring. Refer to the auto-tuning procedure given in the description of H01. | |
| H02 | Save all function | After performing auto-tuning with H01, be sure to execute the Save all function to write the tuning data into the non-volatile memory. Not required if no auto-tuning is performed. | | |

Note: The VG-dedicated motors are the same as the VG7- and VG5-dedicated motors in shape and motor parameters.

P03**M1 Rated Capacity**

P03 specifies the rated capacity of motor 1. Set the motor nameplate value.

For a multiwinding motor, set the motor capacity per winding.

| | | | | | | | | | | | | | | | | | | | |
|---|---|---|---|---|---|---|---|---|--|--|--|--|--|--|--|--|--|--|--|
| P | 0 | 3 | M | 1 | - | C | A | P | | | | | | | | | | | |
|---|---|---|---|---|---|---|---|---|--|--|--|--|--|--|--|--|--|--|--|

Data setting range: For inverters of 400 kW or below
 0.00 to 500.00 (kW) when F60 = 0
 0.00 to 600.00 (HP) when F60 = 1
 For inverters of 500 kW or above
 0.00 to 1200.00 (kW) when F60 = 0
 0.00 to 1600.00 (HP) when F60 = 1

P04**M1 Rated Current**

P04 specifies the rated current of motor 1. Set the motor nameplate value.

| | | | | | | | | | | | | | | | | | | | |
|---|---|---|---|---|---|---|---|--|--|--|--|--|--|--|--|--|--|--|--|
| P | 0 | 4 | M | 1 | - | I | r | | | | | | | | | | | | |
|---|---|---|---|---|---|---|---|--|--|--|--|--|--|--|--|--|--|--|--|

Data setting range: 0.01 to 99.99 (A)
 100.0 to 999.9 (A)
 1000 to 2000 (A)

P05**M1 Number of Poles**

P05 specifies the number of poles of motor 1. Set the motor nameplate value.

| | | | | | | | | | | | | | | | | | | | |
|---|---|---|---|---|---|---|---|---|---|---|--|--|--|--|--|--|--|--|--|
| P | 0 | 5 | M | 1 | - | P | O | L | E | S | | | | | | | | | |
|---|---|---|---|---|---|---|---|---|---|---|--|--|--|--|--|--|--|--|--|

Data setting range: 2 to 100

| | |
|------------|---------------|
| P06 | M1 %R1 |
|------------|---------------|

P 0 6 M 1 - % R 1

Data setting range: 0.00 to 30.00 (%)

$$\%R1 = \left(\frac{R1 (\Omega) + \text{Cable resistance}(\Omega) \times P04 : \text{Motor rated current (A)}}{F05 : \text{Motor rated voltage (V)} / \sqrt{3}} \right) \times 100(\%)$$

Use a value corresponding to the Y connection for one phase to specify R1 (Ω).

Use a value corresponding to one winding of multiwinding motor.

| | |
|------------|--------------|
| P07 | M1 %X |
|------------|--------------|

P 0 7 M 1 - % X

Data setting range: 0.00 to 200.00 (%)

$$\%X = \left(\frac{L\sigma (H) + \text{Cable L (H)} \times P04 : \text{Motor rated current (A)}}{F05 : \text{Motor rated voltage (V)} / \sqrt{3}} \times 2\pi \left(\frac{P05 : \text{Pole numbers} \times F04 : \text{Rated speed (r/min)}}{120} \right) \right) \times 100(\%)$$

Use a value corresponding to the Y connection to specify Lσ (H).

Use a value corresponding to one winding of multiwinding motor.

| | |
|------------|--|
| P08 | M1 Exciting Current/Magnetic Flux Weakening Current (-Id) |
|------------|--|

Sets the effective current value of the motor 1 during no-load operation.

P 0 8 M 1 - I M

Data setting range: 0.01 to 99.99 (A)
 100.0 to 999.9 (A)
 1,000 to 2,000 (A)

| | |
|------------|--------------------------|
| P09 | M1 Torque Current |
|------------|--------------------------|

Sets the current contributing torque.

P 0 9 M 1 - I T

Data setting range: 0.01 to 99.99 (A)
 100.0 to 999.9 (A)
 1,000 to 2,000 (A)

$$P09 : \text{Torque current} = \sqrt{(P04 : \text{Rated current})^2 - (P08 : \text{Exciting current})^2} \text{ (A)}$$

| | |
|------------|--|
| P10 | M1 Slip Frequency (For driving) |
|------------|--|

| | |
|------------|--|
| P11 | M1 Slip Frequency (For braking) |
|------------|--|

Sets the slips of the motor at rated speed and under rated load.

| | | | | | | | | | | | | |
|----------|----------|----------|----------|----------|---|----------|----------|----------|----------|----------|--|--|
| P | 1 | 0 | M | 1 | - | S | L | I | P | d | | |
| P | 1 | 1 | M | 1 | - | S | L | I | P | b | | |

Data setting range: 0.001 to 10.000 (Hz)

$$\text{Slip frequency (Hz)} = \frac{\text{P05: Polenumbers} \times (\text{Synchronized speed}) (\text{r/min}) - \text{F04: Rated speed} (\text{r/min})}{120}$$

| | |
|------------|------------------------------|
| P12 | M1 Iron Loss Factor 1 |
|------------|------------------------------|

| | |
|------------|------------------------------|
| P13 | M1 Iron Loss Factor 2 |
|------------|------------------------------|

| | |
|------------|------------------------------|
| P14 | M1 Iron Loss Factor 3 |
|------------|------------------------------|

P12 to P14 specify iron loss factors to compensate the iron loss (hysteresis loss, eddy current loss) caused inside the motor.

When using motors other than Fuji standard motors, set the iron loss compensation at 0.00%..

| | | | | | | | | | | | | |
|----------|----------|----------|----------|----------|---|----------|----------|----------|----------|----------|--|--|
| P | 1 | 2 | M | 1 | - | L | O | S | S | 1 | | |
| P | 1 | 3 | M | 1 | - | L | O | S | S | 2 | | |
| P | 1 | 4 | M | 1 | - | L | O | S | S | 3 | | |

Data setting range: 0.00 to 10.00 (%)

| | |
|------------|--|
| P15 | M1 Magnetic Saturation Factor 1 |
|------------|--|

| | |
|------------|--|
| P16 | M1 Magnetic Saturation Factor 2 |
|------------|--|

| | |
|------------|--|
| P17 | M1 Magnetic Saturation Factor 3 |
|------------|--|

| | |
|------------|--|
| P18 | M1 Magnetic Saturation Factor 4 |
|------------|--|

| | |
|------------|--|
| P19 | M1 Magnetic Saturation Factor 5 |
|------------|--|

P15 to P19 specify the magnetic saturation factors for the exciting current to apply when the magnetic-flux command is 93.75%, 87.5%, 75%, 62.5% and 50%, respectively.

Since the relationship between the exciting current (that generates magnetic-flux in an IM) and the magnetic flux is non-linear. To compensate it, specify the factors with these function codes.

| | | | | | | | | | | | |
|----------|----------|----------|----------|----------|---|----------|----------|----------|----------|--|--|
| P | 1 | 5 | M | 1 | - | S | A | T | 1 | | |
| P | 1 | 6 | M | 1 | - | S | A | T | 2 | | |
| P | 1 | 7 | M | 1 | - | S | A | T | 3 | | |
| P | 1 | 8 | M | 1 | - | S | A | T | 4 | | |
| P | 1 | 9 | M | 1 | - | S | A | T | 5 | | |

Data setting range: 0.0 to 100.0 (%)

| | |
|------------|-----------------------------------|
| P20 | M1 Secondary Time Constant |
|------------|-----------------------------------|

The response of the magnetic-flux to the exciting current is a first-order lag. This time constant is defined as secondary time constant and you should set a value determined by the motor parameters as in the following equation. You can compensate the lag to lead.

P 2 0 M 1 - N D - T C

Data setting range: 0.001 to 9.999 (s)

Set value: Secondary time constant [s] = $L_m [H] / R_2 [\Omega]$
 L_m : Exciting inductance, R_2 : Resistance of secondary winding

| | |
|------------|----------------------------------|
| P21 | M1 Induced Voltage Factor |
|------------|----------------------------------|

The rotating magnetic field generated by the stator (primary winding) sections the rotor vertically to induce voltage on the secondary side in an induction machine. You can add voltage larger than this induced voltage to accelerate a motor. This function sets a coefficient to compensate this induced voltage.

P 2 1 M 1 - E M F - C O F

Data setting range: 0 to 999 (V)

Set value: Effective induced voltage substituted by the voltage between the windings at the rated speed.

| | |
|------------|----------------------------------|
| P22 | M1 R2 Correction Factor 1 |
|------------|----------------------------------|

| | |
|------------|----------------------------------|
| P23 | M1 R2 Correction Factor 2 |
|------------|----------------------------------|

| | |
|------------|----------------------------------|
| P24 | M1 R2 Correction Factor 3 |
|------------|----------------------------------|

The resistance of the rotor (secondary resistor) is used to calculate the slip frequency in vector control of slip frequency type. The change in secondary resistance due to the temperature increase caused by the frequent operation or load may degrade the torque control accuracy. The inverter detect the temperature with an NTC thermistor and use R_2 correction coefficient 1, 2, and 3 to estimate the rotor temperature to prevent the decrease of the torque control accuracy. Do not change these settings.

P 2 2 M 1 - R 2 C O R R 1
P 2 3 M 1 - R 2 C O R R 2
P 2 4 M 1 - R 2 C O R R 3

| | |
|------------|--|
| P25 | M1 Exciting Current Correction Factor |
|------------|--|

Corrects the exciting inductance. Do not change these settings.

P 2 5 M 1 - I M C O R R

| | |
|------------|------------------------|
| P26 | M1 ACR (P-gain) |
| P27 | M1 ACR (I-time) |

Vector control feeds back the motor output current to control a motor to follow the current command. These functions specify the gain and the integration time for the current control (ACR). Usually you do not have to change from the factory setting.

When a winding has a large inductance, you should set a large P gain to compensate it in general. When a winding has a small inductance, you should set a small P gain to prevent OC (overcurrent) due to the overshoot of the current.

You should specify the integration time to reduce the steady-state deviation between the current command and the actual current to zero. Do not specify too small value otherwise a current hunting occurs.

| | | | | | | | | | | | | |
|----------|----------|----------|----------|----------|----------|----------|----------|----------|----------|----------|--|--|
| P | 2 | 6 | M | 1 | - | A | C | R | - | P | | |
| P | 2 | 7 | M | 1 | - | A | C | R | - | I | | |

P26 setting range: 0.1 to 20.0

P27 setting range: 0.1 to 100.0 (ms)

| | |
|------------|----------------------------|
| P28 | M1 Pulse Resolution |
|------------|----------------------------|

P28 specifies the pulse resolution (P/R) of the speed detector PG of motor 1. Specification of a wrong value unstabilizes the detection of the speed and magnetic pole position, disabling accurate speed control or vector control.

| | | | | | | | | | | | | |
|----------|----------|----------|----------|----------|----------|----------|----------|----------|----------|----------|----------|----------|
| P | 2 | 8 | M | 1 | - | P | G | - | P | L | U | S |
|----------|----------|----------|----------|----------|----------|----------|----------|----------|----------|----------|----------|----------|

Data setting range: 100 to 60,000

| | |
|------------|---|
| P29 | M1 External PG Correction Factor |
|------------|---|

You need a correction coefficient to convert the output of a PG built in a machine system into the motor speed to control the speed. Set the coefficient here. Speed control by PG requires parameter setting at both P28 and P29.

| | | | | | | | | | | | | |
|----------|----------|----------|----------|----------|----------|----------|----------|----------|----------|--|--|--|
| P | 2 | 9 | P | G | - | C | O | M | P | | | |
|----------|----------|----------|----------|----------|----------|----------|----------|----------|----------|--|--|--|

Data setting range: 0000 to 4FFF (h)


When you do not use an external PG, do not change from 4000h. The value of 4000h corresponds to a gear ratio of 1:1, i.e., a PG directly coupled to a motor. When you use a PG directly coupled to a motor, if you set a value other than 4000h, you cannot conduct speed and vector controls accurately.

Setting procedure

Suppose the gear ratio is A:B, specify the function code P28 and P29 as indicated below.

$$\text{Function code P28 (M1-PG pulse number)} = \text{Integer part of } \left[k \left(\text{PG pulse number} \right) \times \frac{B}{A} \right]$$

$$\text{Function code P29 (M1 external PG correction coefficient)} = \left[\frac{\text{P28}}{k \times \frac{B}{A}} \right] \times 2^{14} \text{ (h)}$$



Setting example

If PG pulse number = 1,024 and the gear ratio A:B = 7:1, then:

$$\text{Function code P28(M1-PG pulse number)} = \text{Integer part of } \left| 1024(\text{PG pulse number}) \times \frac{1}{7} \right| = 146$$

$$\text{Function code P29(M1 external PG correction coefficient)} = \left[\frac{\text{P28}}{k \times \frac{B}{A}} \right] \times 2^{14} (\text{d}) = \left[\frac{146}{1024 \times \frac{1}{7}} \right] \times 2^{14} (\text{d}) = 16352 (\text{d}) = 3FE0 (\text{h})$$

| | |
|------------|--------------------------------|
| P30 | M1 Thermistor Selection |
|------------|--------------------------------|

P30 selects a thermistor type or an analog input (0 to 10 V) sent from the temperature sensor for motor protection.

For FRENIC-VG motors (VG7S, VG5 and VG3), select an NTC thermistor. If the motor has a PTC thermistor of overheat protection, select a PTC thermistor.

| | | | | | | | | | | | | | | |
|---|---|---|---|---|---|---|---|---|--|--|--|--|--|--|
| P | 3 | 0 | M | 1 | - | T | H | R | | | | | | |
|---|---|---|---|---|---|---|---|---|--|--|--|--|--|--|

- Data setting range: 0 (No thermistor)
 1 (NTC thermistor (for VG standard motors))
 2 (PTC thermistor)
 3 (Ai **M-TMP**)

The protection level of the motor can be specified by E30 (Motor Overheat Protection, Temperature).

| | |
|------------|------------------------------|
| P32 | M1 Online Auto-tuning |
|------------|------------------------------|

| | |
|------------|------------------------------|
| A52 | M2 Online Auto-tuning |
|------------|------------------------------|

| | |
|-------------|------------------------------|
| A152 | M3 Online Auto-tuning |
|-------------|------------------------------|

P32, A52 and A152 select whether or not to perform auto-tuning for compensating constants change due to temperature rise.

- Perform auto-tuning of motor constants.
- Be sure to test-run the combination of the inverter and motor beforehand.
- Auto-tuning is not available when an NTC thermistor is used.

| | | | | | | | | | | | | | | |
|---|---|---|---|---|---|---|---|---|---|---|---|---|--|--|
| P | 3 | 2 | M | 1 | - | O | N | T | U | N | E | | | |
| A | 5 | 2 | M | 2 | - | O | N | T | U | N | E | | | |
| A | 1 | 5 | 2 | M | 3 | - | O | N | T | U | N | E | | |

- Data setting range: 0 (Disable)
 1 (Enable)

| | |
|------------|--|
| P33 | M1 Maximum Output Voltage/Maximum Voltage Limit |
|------------|--|

P33 is provided for V/f control and vector control for PMSM. Under V/f control, the P33 setting applies to the maximum output voltage, so specify the output voltage of the inverter running at high speed. The voltage higher than the source voltage cannot be output.

Under vector control for PMSM, the P33 setting applies to the maximum voltage limit value, so specify the maximum voltage that the inverter can output. Do not specify the voltage less than the rated voltage.

| | | | | | | | | | | | | | | |
|---|---|---|---|---|---|---|---|---|---|--|--|--|--|--|
| P | 3 | 3 | M | 1 | - | V | m | a | x | | | | | |
|---|---|---|---|---|---|---|---|---|---|--|--|--|--|--|

Data setting range: 80 to 999 (V)

P34 M1 Slip Compensation

P34 is exclusive to V/f control. A change in the load torque will change the motor slip, resulting in the motor speed change. The slip compensation control adds a frequency proportional to the motor torque to the inverter output frequency and reduces the fluctuation of the motor speed due to torque change.

P 3 4 M 1 - S L I P d

Data setting range: -20.000 to 5.000 (Hz)

The slip compensation value can be calculated with the following expression.

$$\text{Slip compensation value} = \text{Base frequency} \times \frac{\text{Slip (r/min)}}{\text{Synchronous speed (r/min)}} \text{ (Hz)}$$

Where, Slip = Synchronous speed - Rated speed

When P34 = 0.000 (Hz), the slip compensation control is disabled.

P35 M1 Torque Boost

P35 is exclusive to V/f control. The following choices are available.


P 3 5 M 1 - B O O S T

- Load characteristics including automatic torque boost, variable torque load, proportional torque load, and constant torque load.
- Compensating insufficient magnetic-flux of a motor due to the voltage drop in the low frequency range and boosting torque at low speed operation (boosting V/f characteristic)

| Data setting range | Description |
|--------------------|---|
| 0.0 | Automatic torque boost characteristics to adjust torque boost value automatically for constant torque load changing linearly |
| 0.1 to 0.9 | Variable torque characteristics for fan/pump load |
| 1.0 to 1.9 | Linear torque characteristics for a load that has a middle characteristic between variable torque and constant torque characteristics |
| 2.0 to 20.0 | Constant torque characteristics changing linearly |

Torque characteristic

<Variable torque characteristics> <Proportional torque characteristics> <Constant torque characteristics>



Note: When replacing the VG7 (22 kW or below) with the VG1, specify the torque boost according to the torque boost conversion table in Chapter 12, Section 12.5.

■ **Guide for setting the torque boost**

When adjusting the starting torque with manual boost (Setting data: 2.0 to 20.0) since the motor characteristics are unknown, use the following as a guide.

| Motor capacity (kW) | Torque boost 1 to 3 P35, A55, A155 |
|---------------------|---------------------------------------|
| 0.4 | 5.2 to <u>8.4</u> to 11.6 |
| 0.75 to 2.2 | 5.1 to <u>8.1</u> to 11.2 |
| 3.7 | 4.5 to <u>7.0</u> to 9.4 |
| 5.5 | 4.2 to <u>6.4</u> to 8.6 |
| 7.5 | 4.0 to <u>6.0</u> to 7.9 |
| 11 | 3.6 to <u>5.2</u> to 6.7 |
| 15 | 3.3 to <u>4.5</u> to 5.8 |
| 18.5 to 22 | 3.0 to <u>4.0</u> to 5.0 |
| 30 to 630 | <u>2.0</u> to 5.0 |

Note: Increasing the torque boost value results in overexcitation in the low-speed domain. Keeping the inverter running with the overexcited state may cause the motor to overheat. Check the characteristics of the motor to be driven.

P36

M1 Output Current Fluctuation Damping Gain

P36 is exclusive to V/f control. When the inverter output current fluctuates due to the motor characteristics or backlash at the load side, adjust the damping gain. Do not change the factory default unless otherwise needed.

P 3 6 M 1 - D U M P G

Data setting range: 0.00 to 1.00

4.3.5 H codes (High Performance Functions)

| | |
|------------|--------------------|
| H01 | Auto-tuning |
|------------|--------------------|

For inverters connected with a standard motor, no motor parameter tuning is required.

Perform auto-tuning correctly, referring to the tables and the flowcharts given on the following pages.

Tuning procedure

Change the H01 data to the desired value by pressing the $\text{STOP} + \text{▲}$ keys or $\text{STOP} + \text{▼}$ keys (simultaneous keying), and then press the FUNC DATA key to start auto-tuning. Upon completion of auto-tuning, the H01 data automatically reverts to "0."

The tuning result is written to the volatile memory (RAM) that loses the data when the power is turned OFF. After completion of tuning, therefore, be sure to use the Save all function (H02) to write the data to the non-volatile memory.

The ASR auto-tuning (H01 = 1) should be performed, if needed, after motor parameters have been established (automatically, manually, or by tuning). (Available soon)

Tuning notes

Under any of the following conditions, no tuning is normally performed. Review the current settings.

- (1) "NOT EXECUTE" appears on the LCD monitor.

In the case of M1, when H01 = any of 2 to 4, P02 \neq 37 (OTHER).

⇒ Function codes to be tuned are write-protected. Set P02 to "37" (OTHER).

The JOG mode is selected. (The JOG indicator on the LCD monitor is lit.)

⇒ Cancel the JOG mode by pressing the $\text{STOP} + \text{▲}$ keys (simultaneous keying).

⇒ If digital input signal **JOG** is ON, turn it OFF.

Tuning is in progress from FRENIC-VG Loader.

⇒ When tuning is in progress from FRENIC-VG Loader, do not change function code data from the keypad.

- (2) Alarm $\bar{E}-\bar{E}$ (Operation error) occurs.

The simulation mode is selected (P01 = 2).

⇒ No tuning is possible in the simulation mode.

The "V/f control for IM" is selected (P01/A01/A101 = 5).

⇒ Under V/f control, tuning by H01 = 1, 3 or 4 cannot be performed.

The "Vector control for PMSM with speed sensor" is selected (P01/A01/A101 = 3).

⇒ Under Vector control for PMSM, tuning by H01 = 3 cannot be performed.

Any of digital input signals **BX**, **STOP1**, **STOP2** and **STOP3** is ON.

Either one of safety function input terminals [EN1] and [EN2] is OFF.

⇒ When any of **BX**, **STOP1**, **STOP2** and **STOP3** is ON and either of [EN1] and [EN2] is OFF, no tuning starts.

The multiwinding motor drive system is selected.

⇒ No tuning is possible in the multiwinding motor drive system.

Undervoltage is detected (Power OFF).

⇒ When undervoltage is detected, the inverter does not accept a run command, causing an $\bar{E}-\bar{E}$ error after 20 seconds from writing to H01.

- (3) Alarm $\bar{E}-\bar{7}$ (Output wiring fault) occurs.

A phase is missing in the connection between the inverter and the motor.

⇒ Connect the motor to the inverter correctly.

The brake is applied to the motor.

⇒ For auto-tuning with the motor running (H01 = 4), be sure to release the brake so that the motor can rotate.

H O 1 T U N I N G M O D E

The tuning type, data to be tuned, and tuning content differ depending upon the motor drive control. Select the tuning suitable for the drive control (P01).

When P01 = 0 or 1 (Vector control for IM with/without speed sensor) → go to [1] below.

When P01 = 5 (V/f control for IM) → go to [2] below.

[1] Under vector control for IM with/without speed sensor

| Data for H01 | Tuning type | | Data to be tuned | Tuning content | Usage |
|--------------|---|-------------------------------|---|---|---|
| 1 | ASR (Auto speed regulator) auto-tuning (To be performed after establishment of motor parameters) (Available soon) | | ASR-P (gain) ASR-I (integral constant) Compensation gain Integral time Load inertia | The inverter measures the motor-shaft converted load inertia (mechanical time constant) of the connected machinery, calculates the optimum gain and integral constant, and sets them to the corresponding function codes. | Perform this tuning for a motor integrated in the machinery to tune the ASR. Particularly, perform this tuning for using the observer (H46) if the motor-shaft converted load inertia is unknown. |
| 2 | Motor parameter tuning | R1, L σ | P06, P07 when M1 is selected A08, A09 when M2 is selected A108, A109 when M3 is selected | The inverter measures the motor primary resistance (%R1) and leakage reactance (L σ) at the rated speed and sets them to the corresponding motor parameters (M1, M2, or M3). | Perform this tuning for VG standard motors (VG3, VG5 and VG7) when the impedance at the output side is not negligible because the wiring distance between the inverter and motor is long (100 m or more) or an output circuit filter (OFL) is connected. |
| 3 | | Tuning with the motor stopped | P06 to P25 when M1 is selected A08 to A27 when M2 is selected A108 to A123 when M3 is selected | The inverter measures the %R1 and %X <u>with the motor stopped</u> , just as when H01 = 2. After that, the inverter measures the exciting current, rated load slip, magnetic saturation factors, induced voltage, secondary time constant, R2 compensation factors, exciting current compensation factors <u>with the motor stopped</u> , tunes them, and sets them to the corresponding motor parameters (M1, M2, or M3). | Perform this tuning beforehand when driving a non-standard motor or a special-purpose motor whose motor parameters are unknown. Perform this tuning when using the FRENIC-VG to drive a motor integrated in the existing machinery and not separated from it. Note that the tuning accuracy is slightly lower than that obtained by tuning with the motor running (H01 = 4). |
| 4 | | Tuning with the motor running | | The inverter measures the %R1 and %X <u>with the motor stopped</u> , just as when H01 = 2. After that, the inverter measures the exciting current, rated load slip, magnetic saturation factors, induced voltage, secondary time constant, R2 compensation factors, exciting current compensation factors <u>with the motor running</u> , tunes them, and sets them to the corresponding motor parameters (M1, M2, or M3). | Perform this tuning beforehand when driving a non-standard motor or a special-purpose motor whose motor parameters are unknown. Since this tuning involves motor rotation, separate the motor from the machinery and make sure that there is no danger in rotating the motor before performing this tuning. The motor runs in accordance with the specified acceleration/ deceleration time. |

[2] Under V/f control for IM


| Data for H01 | Tuning type | | Data to be tuned | Tuning content | Usage |
|--------------|--|---|--|--|--|
| 1 | ASR (Auto speed regulator) auto-tuning Not available under V/f control. | | -- | -- | -- |
| 2 | Motor parameter tuning | R1, L σ | P06, P07 when M1 is selected A08, A09 when M2 is selected A108, A109 when M3 is selected | The inverter measures the motor primary resistance (%R1) and leakage reactance (L σ) at the rated speed and sets them to the corresponding motor parameters (M1, M2, or M3). | Perform this tuning when the impedance at the output side is not negligible because the wiring distance between the inverter and motor is long (100 m or more) or an output circuit filter (OFL) is connected. |
| 3 | | Tuning with the motor stopped Not available under V/f control. | -- | -- | -- |
| 4 | | Tuning with the motor running Not available under V/f control. | -- | -- | -- |

 **CAUTION**


At the time of shipment, the torque boost function is set to "Auto torque boost." To use the inverter in applications requiring a starting torque, be sure to perform motor parameter auto-tuning.

An accident or injuries could occur.


ASR (Auto speed regulator) auto-tuning procedure (H01 = 1) (Available soon)



Motor parameter auto-tuning procedure (H01 = 2)



Auto-tuning (with the motor stopped/running) procedure (H01 = 3 or 4)



⚠ WARNING



When H01 = 1 or 4, the motor rotates during tuning. Make sure that there is no danger in rotating the motor. Injuries could occur.

H02**Save All Function**

When you execute H01 "Tuning operation" to rewrite the internal data or you rewrite data through the link (RS-485 or field bus), the data are written to the volatile memory (RAM) temporarily and the data are erased when you turn off the power. Execute this function when you want to save these data (to write to the non-volatile memory).



| | | | | | | | | | | | |
|---|---|---|---|---|---|---|---|---|---|--|--|
| H | 0 | 2 | A | L | L | S | A | V | E | | |
|---|---|---|---|---|---|---|---|---|---|--|--|

Set the value

1 and press  and  keys at the same time to execute.



When you use the All save, you may delete previous data.

H03**Data Initialization**

Set the value 1 and press  and  keys at the same time to initialize set values to the factory setting. When the initialization is complete, the set values return to zero automatically. Not all functions execute initialization. See the function code list for more details.

| | | | | | | | | | | | |
|---|---|---|---|---|---|---|---|---|---|---|--|
| H | 0 | 3 | D | A | T | A | I | N | I | T | |
|---|---|---|---|---|---|---|---|---|---|---|--|

Set the value

1 and press  and  keys at the same time to execute.

When you use the Data initializing, you may delete previous data.

H04**Auto-reset (Times)****H05****Auto-reset (Reset interval)**

The Auto-reset function cancels the inverter protective function to restart the inverter automatically without alarm and output shut-off after the inverter protective function is activated. These functions set the number of canceling the protective function and the wait time between the activation and the cancellation of the protective function.

| | | | | | | | | | | | | |
|---|---|---|---|---|---|---|---|---|---|---|---|---|
| H | 0 | 4 | A | U | T | O | - | R | E | S | E | T |
| H | 0 | 5 | R | E | S | E | T | I | N | T | | |

Setting range (number): 0: Auto-reset disabled
1 to 10 (times)

(Wait time): 0.01 to 20.00 (s)

Set H04 "Auto-reset (Number)" to 0 when you do not use the auto-reset function

Inverter protective functions you can reset to restart

| | |
|---|---|
| <i>OL</i> : Overcurrent | <i>ORH</i> : Braking resistor overheat |
| <i>OLV</i> : Overvoltage | <i>OL1, OL2, OL3</i> : Motor 1, 2, and 3 overload |
| <i>OH1</i> : Overheating at heat sink | <i>OLU</i> : Inverter overload |
| <i>OH3</i> : Inverter internal overheat | |

When you set 1 to 10 to H04 "Auto-reset (Number)", the auto-reset is activated and inverter start command is automatically directed after a time specified by H05 "Auto-reset (Reset interval)" has passed. If the cause of the alarm does not exist any more, the inverter starts without entering the alarm mode. Otherwise, the protective function is activated again to wait for the time specified by H05 "Auto-reset (Reset interval)". If the cause of the alarm still exists after the inverter restarts specified times by H04 "Auto-reset (Number)", then the inverter enters the alarm mode.


You can use the terminal [Y1] to [Y5] and [Y11] to [Y18] to monitor the retry operation. Note that if you want to use [Y11] to [Y18], you need the option OPC-VG1-DIOA. You can also use the link to poll M15 to read out the terminal information.

⚠ WARNING


When you select the restart function, the inverter may restart automatically depending on the cause a trip after the inverter stops due to the trip. You must design your machine such that the machine restarts without causing any danger to persons.

Otherwise the restart may cause accidents.

Retry successful case



Retry failed case



H06**Cooling Fan ON/OFF Control**

H06 specifies whether to enable automatic cooling fan ON/OFF control that detects the temperature of the heat sink inside the inverter unit when the main power is supplied to the inverter and turns the cooling fan ON or OFF.

The control turns the cooling fan OFF when the inverter is stopped and the temperature of the heat sink is kept under a certain level during the period (default: 10 minutes) specified by H77 (Cooling fan ON/OFF control continuation timer).

When the inverter is running, the cooling fan operates irrespective of the H06 setting.

The running status of the cooling fan can be monitored through terminals [Y1] to [Y5] and [Y11] to [Y18]. Note that [Y11] to [Y18] are available when the OPC-VG1-DIOA is mounted.

| | | | | | | | | | |
|---|---|---|---|---|---|---|---|---|---|
| H | 0 | 6 | F | A | N | S | T | O | P |
|---|---|---|---|---|---|---|---|---|---|

Set value: 0: Disable
1: Enable

Cooling fan and ROM version

When the cooling fan ON/OFF control is enabled, the cooling fan operation immediately after the main power is turned ON differs depending on the ROM version.

ROM version H1/2 0019 or earlier: Even if the inverter is not running, the cooling fan rotates during the period specified by H77.

ROM version H1/2 0020 or later: Until the start of inverter running, the cooling fan is not turned ON.

H08**Rev. Phase Sequence Lock**

You can inhibit the reverse rotation of a mechanical devise that should not do so. This function is not available when you use V/f control.

| | | | | | | | | | | |
|---|---|---|---|---|---|---|---|---|---|---|
| H | 0 | 8 | P | R | T | - | I | N | V | T |
|---|---|---|---|---|---|---|---|---|---|---|

Set value: 0: Disable
1: Enable

Use the function code F76 to F78 "Speed limiter" to inhibit the reverse operation directed by negative [12] input or [REV] input. This function uses torque control to inhibit the reverse operation due to an undershoot in stopping operation.

H09**Starting Mode (Auto search)**

Restarts a motor smoothly when the motor starts after a momentary power failure or an external force is coasting the motor.

Detects the speed of a motor and supplies the same speed as that of the motor to start. Thus, the motor starts smoothly without presenting any shocks.

Under UP/DOWN control, auto search mode is disabled.

When inverter is in "vector control of induction motor with PG" mode (P01 = 0) or "vector control of synchronous motor with PG" mode (P01 = 3), the starting mode (auto search) is always enabled.

When using the inverter under vector control without speed sensor, use auto search in 60 Hz (1800 r/min in terms of 4-pole motors) or below.

If a trip occurs in auto search in 60 Hz (1800 r/min in terms of 4-pole motors) or higher, the following may improve the problem.

- (1) Change the carrier frequency (F26),
- (2) Increase the initial level of pre-excitation (F75), and
- (3) Perform motor tuning.

Under vector control without speed sensor, the property cannot be satisfied due to external factors such as load conditions, motor parameters and wiring length, so make a sufficient operation check before actual operation.

H 0 9 S T A R T C H A R

Set value: 0: Disable
1: Enable


Setting range: 0, 1, and 2

| Set value | Normal start | Start after momentary power failure |
|-----------|--------------|-------------------------------------|
| 0 | Disabled | Disabled |
| 1 | Disabled | Enabled |
| 2 | Enabled | Enabled |

Description of the set values

- 1: Enabled when F14 "Restart mode after momentary power failure (Select)" is set to 3, 4, or 5. Also starts the motor at the coasting speed.
- 2: Starts the motor at the detected coasting speed after any start situation including the ON operation command regardless of the occurrence of a momentary power failure.

Assign a setting value 26 (Pick up start mode) to either of the terminal from [X1] to [X9] to switch this function externally to apply the function to a normal ON operation command.



H10 Energy-saving Operation

To reduces the output voltage automatically during constant speed operation with light load to operate at a state where the product of voltage and current (power) is the smallest. This function is not available for V/f control.

H 1 0 A U T O - E N G Y

Set value: 0: Disable
1: Enable

H11**Automatic Operation OFF Function**

Turns off the operation automatically when the motor speed decreases down under the F37 "Stop speed" while the FWD or REV command is present, or coasts the motor instead of decelerating the motor to stop when the input is set to OFF.

H 1 1 A U T O O F F

Set value: 0: The motor decelerates to stop when the FWD-CM and the REV-CM are OFF (normal).

- 1: The motor operation is set to OFF when the speed is F37 under the "Stop speed" while the FWD-CM and the REV-CM are ON.
- 2: The motor coasts to stop when the FWD-CM and the REV-CM are OFF.
- 3: The motor decelerates to stop with ASR when the FWD-CM and the REV-CM are OFF (under torque control).
- 4: The motor coasts to stop when the FWD-CM and the REV-CM are OFF (under torque control).

When H11 = 3 or 4 and under ASR control, the motor decelerates to stop (H11 = 0). When H11 = 0 to 2, the operation is common to the ASR control and torque control.

When H11 = 0 or 3, turn OFF in accordance with F37 (Stop speed).

When H11 = 1 under vector control without speed sensor or V/f control, auto search is automatically disabled.

When H11 = 2 or 3, the inverter will perform free ran when digital input signal STOP 1~3 is turned ON.

H13**Restart Mode after Momentary Power Failure (Wait time)**

Waits for a time specified this function after power recovery and restarts.

H 1 3 R E S T A R T t

Setting range: 0.1 to 5.0 (s)

H14**Restart Mode after Momentary Power Failure (Decrease rate in speed)**

In restart mode after momentary power failure under V/f control, if the inverter output frequency and motor rotation speed are not synchronized with each other, an overcurrent flows, activating the current limiter.

Upon detection of the current limiter operation, the inverter automatically increase the output frequency (r/min) to synchronize with the motor rotation speed. H14 specifies the decrease rate in speed (r/min/s).

H 1 4 F A L L R A T E

Setting range: 1 to 3,600 (r/min/s)



Increasing the decrease rate may perform regenerative control the moment the inverter output frequency (r/min) and the motor rotation speed are synchronized with each other, causing an overvoltage trip.

Decreasing it may lengthen the current limit operation duration until the synchronization, activating the inverter overload protection.

H15**Restart Mode after Momentary Power Failure (Continuous running level)**

If you select setting 2 (deceleration to a stop on power failure) or 3 (continuous operation) in Restart mode after momentary power failure (F14: Action selection), this function affects them. At both settings, control operation starts when the main circuit DC voltage drops below this setting level.

H 1 5 H O L D V

Setting range: 200V: 200 to 300 (V)

400V: 400 to 600 (V)

H16**Restart Mode after Momentary Power Failure (Run command self-hold setting)**

Holds the operation command when the control power supply is maintained in the inverter or until the main circuit DC power supply voltage decreases about to zero (recognized as "momentary power failure") when you specifies 1.

Holds the operation command for a time specified by the H17 "Auto-restart (Operation command selfhold time)" when you specifies 0.

H 1 6 S L F H L D S E L

Setting range: 0 or 1

0: Hold a run command for the time specified by H17

1: Hold a run command until the main circuit power comes to be almost zero

H17**Restart Mode after Momentary Power Failure (Run command self-hold time)**

When the power to the main power supply and the external control circuit (relay sequence) discontinues on power failure, the operation command given to the inverter becomes OFF in general.

This function sets the time to hold the operation command. When the period of a power failure exceeds the self-hold time, the inverter recognizes the power failure here cancels the "restart after momentary power failure" mode and restarts normally on power recovery (you can consider this setting as permissible momentary power failure time).

H 1 7 S E L F H O L D t

Setting range: 0.0 to 30.0 (s)

H19**Active Drive**

H19 specifies whether to enable active drive in which the inverter automatically limits the output torque to avoid an overload trip, etc. under vector control.

If 60s or a longer acceleration time is selected under V/f control, the acceleration time is automatically lengthened three-folded to avoid alarms.

H 1 9 A C T - D R I V E

Setting range: 0: Disable

1: Enable


Before a trip is caused due to an inverter overload (\overline{LL}), heat sink overheat (\overline{H}) or inverter inside overheat (\overline{H}), the torque command value is limited or the acceleration time is extended to avoid alarms.

H20 PID Control (Mode selection)

PID control uses a sensor attached to a subject of control to detect the controlled value (feedback value) and compares it with the reference value (such as speed reference). When there is a deviation between them, the control behaves to decrease the deviation to zero. This is a control to match the feedback value with the reference value.

This control is applied to process control such as dancer control, tension control and extruders.

You can select normal or inverse operation for the output of the PID regulator and set increase or decrease to the rotation of a motor receiving the output of the PID regulator.



```
H 2 0 P I D C O M N D
```

- Setting range: 0: Disabled
 1: Enabled (normal operation)
 2: Enabled (inverse operation 1)
 3: Enabled (inverse operation 2)

H21 PID Control (Command selection)

Select the source of the reference value applied to the PID regulator.

- Set value: 0: KEYPAD panel or [12] terminal input
 1: Analog input Ai **PID-REF**

You can assign **PID-FB** to an analog input Ai to specify the feed back value applied to the PID regulator. You cannot specify a feed back value other than this voltage input.

You can view the process values of the reference value and the feedback value according to set values of the F52 "Display coefficient A" and F53 "Display coefficient B". See the function description of F52 and F53 for more details.

```
H 2 1 P I D R E F E R
```

| | |
|-----|------------------------|
| H22 | PID Control (P-action) |
| H23 | PID Control (I-action) |
| H24 | PID Control (D-action) |

| | | | | | | | | | | |
|---|---|---|---|---|---|---|---|---|--|--|
| H | 2 | 2 | P | - | G | A | I | N | | |
| H | 2 | 3 | I | - | G | A | I | N | | |
| H | 2 | 4 | D | - | G | A | I | N | | |

H22 setting range: 0.000 to 10.000 (times)

H23 setting range: 0.00 to 100.00 (s)

H24 setting range: 0.000 to 10.000 (s)



In general, P: Gain, I: Integral time, or D: Differential time is not used individually, but use them by combining them as P control, PI control, PD control, and PID control.

P control action

This action is referred to as P control action when a manipulated value (Speed command, Auxiliary speed command, and Torque limiter) and deviation has a linear relation. Thus P control action provides a manipulated value proportional to the deviation.


Note that you cannot use only P control action to decrease the deviation to zero.

P: gain is a parameter to define a degree of the response to a deviation. When you set a large gain, you will have a quick response. Too large gain presents an oscillation. Too small gain slows down the response.



I control action

This action is referred to as I control action when a manipulated value (Speed command, Auxiliary speed command, and Torque limiter) changes at a speed in proportion to deviation. Thus, I control action provides an integrated deviation as a manipulated value. I control action behaves to conform the controlled value (feedback value) to the reference value (such as speed command). However I control cannot respond to a deviation changing quickly.




You can use I: integral time as a parameter to determine the effect of I control action. If you set a large integral time, you will have a slow response. A large integral time also decreases the repulsive force.

A small integral time quickens response. However, too small integral time will cause an oscillation.

D control action

This action is referred to as D control action when a manipulated value (Speed command, Auxiliary speed command, and Torque limiter) is proportional to differential of deviation. Thus D control action provides a differential of deviation as a manipulated value to respond a quick change.



You can use D: differential time as a parameter to determine the effect of D control action. A large differential time attenuates an oscillation caused by P control action quickly when a deviation occurs.

Too large differential time may induce even a larger oscillation. A small differential time decreases attenuation action applied to a deviation.

PI control action

When you use only P control action, the deviation still remains. PI control, P control action combined with I control action, is used in general to eliminate this residual deviation. PI control always behaves to eliminate a deviation due to a change of reference value or a continual disturbance. However if you increase I control action, the control cannot respond a fast deviation.

You can use only P control action for a load including an integral element.

PD control action

PD control action generates a larger manipulated value than that of D control action to restrain the increase of the deviation. When the deviation decreases, P control action is restrained.

If a subject of control contains an integral element, sole P control action will present an oscillating response due to the integral element. If this is a case, you can use PD control to attenuate the oscillation caused by sole P control action. You apply this control to a process that does not have selfdamping action.

PID control action


PID control action combines I control action, which acts to reduce deviation and D control action, which acts to restrain oscillation with P control action. You can obtain a stable response with no deviation.

This control is effective when applied to a load which respond slowly.

Adjusting PID setting


It is recommended that you use an oscilloscope to view a response waveform and adjust PID setting. Adjust the PID setting, using the procedure given below.

- Increase H22 "PID control setting (P control action)" (P gain) as long as it does not present an oscillation.
- Decrease H23 "PID control setting (I control action)" (I integral time) as long as it does not present an oscillation.
- Increase H24 "PID control setting (D control action)" (D differential time) as long as it does not present an oscillation.




Follow the procedure below to adjust the response waveform.


- To restrict overshoot
Increase H23 "PID control setting (I control action)" (I integral time). Decrease H24 "PID control setting (D control action)" (D differential time).
- To stabilize fast (accepting some overshoots.)
Decrease H23 "PID control setting (I control action)" (I integral time). Increase H24 "PID control setting (D control action)" (D differential time).



- To restrain an oscillation whose cycle is longer than H23 "PID control setting (I control action)" (I integral time).
Increase H23 "PID control setting (I control action)" (I integral time).



- To restrain a oscillation whose cycle is about the same as the H24 PID control setting (D control action)" (D differential time)
Decrease H24 "PID control setting (D control action)" (D differential time).
Decrease H22 "PID control setting (P control action)" (P gain) if you set 0.0 and the oscillation still exists



H25 **PID Control (Upper limit)**

H26 **PID Control (Lower limit)**

Set the upper and lower limiters applied to PID control.

| | | | | | | | | | | |
|---|---|---|---|---|---|---|---|---|---|---|
| H | 2 | 5 | P | I | D | U | P | P | E | R |
| H | 2 | 6 | P | I | D | L | O | W | E | R |

Setting range: -300 to 300 (%)

H27 **PID Control (Speed command selection)**

Selects a destination of PID output to be used as a speed command.

| | | | | | | | | | | |
|---|---|---|---|---|---|---|---|---|---|---|
| H | 2 | 7 | P | I | D | S | P | R | E | F |
|---|---|---|---|---|---|---|---|---|---|---|

- Setting 0: Disabled
- 1: PID
- 2: Auxiliary speed setting range: -300 to 300 (%)

| Usage | Destination of connection | Parameter setting |
|----------------------------------|---------------------------|------------------------|
| Parameter setting | Speed command | H27=1 |
| Dancer control | Auxiliary speed command | H27=2 |
| Torque control (tension control) | Torque command | H27=0 & H41=5 |
| | Torque control value | H27=0 & (F42 or F43=5) |

H28 **Droop Control**

When you use multiple motors to drive a single machine, a motor whose speed is higher has to drive a larger load. Droop operation balances load by adding a drooping characteristic to speed. This function is not available for V/f control.

| | | | | | | | | | | |
|---|---|---|---|---|---|---|---|--|--|--|
| H | 2 | 8 | D | R | O | O | P | | | |
|---|---|---|---|---|---|---|---|--|--|--|


Setting range: 0.0 to 25.0 (%)

Set a drooping amount at 100% of torque command.

A value set to 100% corresponds to the maximum speed. When the maximum speed is 1,500r/min and the drooping is set to 10%, then the drooping speed is -150.0 r/min at 100% of torque command (load).

The droop function becomes valid after the [DROOP] contact input and ON “DROOP ON” are turned on.

If the droop gain is too large, the motor speed may increase too much under a control load, causing an excessive speed alarm (OS). If this happens, decrease the gain.



H29**Communications Link Function (Data protection via link)**

Protects code data from false writing through different types of communication systems (such as integrated RS-485 and field bus).

H 2 9 L I N K P R O C T

Set value: 0: Write enabled
1: Write protected

You should use H30 "Serial link" to define the write operation to the S area (function codes including operation commands and speed commands) separately.

When you assign **WE-LINK** to a digital input, you can protect from writing by short-circuiting between [WE-LINK] and [COM].

H30**Communications Link Function (Link operation)**

Uses different types of communication systems (such as integrated RS-485 and field bus) to enable/disable command data (such as speed command, position command, torque command) and operation commands (FWD and REV), control inputs (X1-X9, X11-X14). Monitoring (access to M area) is always available. The command data correspond to S01 to S05 and S08 to S12. The operation commands correspond to the lowest two bits of S06.


When you assign **LE** to a digital input, you can connect between [LE] and [CM] to enable the setting by H30 and open to disable operations specified through the link (set to H30=0 regardless of the setting by H30).

H 3 0 L I N K F U N C

Set value:

| | Monitor | Command data (Speed commands, torque commands, etc.) | S06 | | Terminal block | |
|---|-----------------------|--|---|------------------------|-----------------------|--------------------------|
| | | | Run commands (FWD, REV) Control inputs (X1 to X9, X11 to X14) | Reset command (RST) | FWD, REV (F02 = 1) | X1 to X9 (X11 to X14) |
| 0 | <input type="radio"/> | × | × | <input type="radio"/> | <input type="radio"/> | <input type="radio"/> |
| 1 | <input type="radio"/> | ○ | × | <input type="radio"/> | <input type="radio"/> | <input type="radio"/> |
| 2 | <input type="radio"/> | × | ○ | <input type="radio"/> | × | <input type="radio"/> |
| 3 | <input type="radio"/> | ○ | ○ | <input type="radio"/> | × | <input type="radio"/> |

Note: If run commands and control inputs are enabled on both S06 and terminal block, they are ORed.



You can use the KEYPAD panel to check the operation commands from the link, and I/O check of control input.

H31 to H40**RS-485 Communication**

Protects code data from false writing through different types of communication systems (such as integrated RS-485 and field bus).

Sets different types of specifications for RS-485 communication. Specify according to your host device.

See "Standard RS-485 interface" for the communication protocol.

H31 Station address

Sets the station address of RS-485

Setting range: 0 to 255 (Broad cast: (0: RTU), (99: FUJI)/address: 1 to 255)

H32 Action on error occurrence

Setting range: 0 to 3

Setting: 0: Immediate trip upon communication error

- 1: Trip upon communication error after continuation of operation for the time set at H33 "timer interval"
- 2: Trip upon communication error if the error persists after the time set at H33 "timer action time" has elapsed
- 3: Operation continues even if a communication error occurs. (The transmitted operation command is automatically restored after the cause of the failure is removed.)

H33 Timer operation time

Specify a procedure when an error occurs and an error handling time.

Timer operation time: 0.01 to 20.00 (s)

H34 Transmission rate

Specifies transmission rate.

- Set value: 0: 38,400 (bps)
 1: 19,200 (bps)
 2: 9,600 (bps)
 3: 4,800 (bps)
 4: 2,400 (bps)

H35 Data length

Specifies data length.

- Set value: 0: 8 (bit)
 1: 7 (bit)

(The SX protocol and Modbus RTU protocol are fixed at 8 bits irrespective of the H35 setting.)

H36 Parity bit

Specifies parity bit.

Set value: 0: None

- 1: Even parity
- 2: Odd parity

(The SX protocol is fixed at the even parity irrespective of the H36 setting.)

H37 Stop bit

Specifies stop bit.

Set value: 0: 2 (bit)

1: 1 (bit)

(With the Modbus RTU protocol, the stop bit is automatically selected according to the parity bit selected at H36 irrespective of the H37 setting.)

H38 Continued communication disconnected time

Specifies a time to wait to provide a trip signal ($\overline{E_r-5}$) after detecting discontinued access due to disconnection during operation through RS-485 in a system where the station is always accessed in a certain period.

Setting range: 0: Detection disabled

0.1 to 60.0 (s)

H39 Interval time

Specifies a time between the completion of receiving a request from a host device (computer or PLC) and the start of responding to the request.

Setting range: 0.00 to 1.00 (s)

H40 Protocol selection

Specifies a communication protocol.

Set value: 0: FUJI general-purpose inverter protocol

1: SX bus protocol (loader protocol)

2: Modbus RTU protocol

To connect the inverter to FRENIC-VG Loader via the DX+/DX- control terminal (RS-485 communications link), set the H40 data to "1." When the inverter is connected via the USB terminal, it communicates regardless of the H40 setting.

To drive both FRENIC-VG inverters and Fuji general-purpose inverters via the common RS-485 communications link, set the H40 data to "0."

Note: Modbus RTU is a communication protocol defined by Modicon company.

H41**Torque Command Source**

Selects an element with which you provide the torque command. See the control block diagram for more details.

| | | | | | | | | | | |
|---|---|---|---|---|---|---|---|---|---|---|
| H | 4 | 1 | T | - | R | E | F | S | E | L |
|---|---|---|---|---|---|---|---|---|---|---|

Setting value: 0: Internal ASR data

- 1: Ai input *T-REF*
- 2: DIA card
- 3: DIB card
- 4: Link (S02)
- 5: PID output

Use also the speed limiter setting (F76 to F78) when you use the torque command

| |
|--|
|  WARNING |
|--|

Make sure to use the speed limiter in cooperation with the torque command or the torque current command. You can avoid the motor overrun.

Accidents or physical injuries may occur.

| |
|--|
|  WARNING |
|--|

- Under torque control, if the motor is rotated by the load with torque exceeding a torque command, even turning the run command OFF may not stop the motor but keep it running.

To shut down the inverter output, take measures such as "Switch to speed control and decelerate to stop," "Shut down with a coast-to-stop command (*BX*)," or "Use automatic operation OFF function (H11 = 2 to 4)."

Accidents or physical injuries may occur.

| |
|--|
|  WARNING |
|--|

- Under torque control, the inverter may not detect a power failure depending upon the load state. If it happens, input a power failure signal to the BX terminal to stop the inverter.

Accidents or physical injuries may occur.

H42**Torque Current Command Source**

Selects an element with which you provide the torque command. See the control block diagram for more details.

H 4 2 I T R E F S E L

Setting value: 0: Internal ASR data

- 1: Ai input *IT-REF*
- 2: DIA card
- 3: DIB card
- 4: Link (S03)

Use also the speed limiter setting (F76 to F78) when you use the torque command

 **WARNING**

Make sure to use the speed limiter in cooperation with the torque command or the torque current command. You can avoid the motor overrun.

Accidents or physical injuries may occur.

 **WARNING**

- Under torque control, if the motor is rotated by the load with torque exceeding a torque command, even turning the run command OFF may not stop the motor but keep it running.
To shut down the inverter output, take measures such as "Switch to speed control and decelerate to stop," "Shut down with a coast-to-stop command (*BX*)," or "Use automatic operation OFF function (H11 = 2 to 4)."

Accidents or physical injuries may occur.

 **WARNING**

- Under torque control, the inverter may not detect a power failure depending upon the load state. If it happens, input a power failure signal to the BX terminal to stop the inverter.

Accidents or physical injuries may occur.

H43**Magnetic Flux Command Source**

Selects an element with which you provide the magnetic-flux command.

If the Ai input and link are selected, magnetic flux command inputs within 10% are fixed at 10%.

H 4 3 M R E F S E L

Setting value: 0: Internal calculated value

- 1: Ai input *MF-REF*
- 2: Function code H44
- 3: Link (S04)

H44

Magnetic Flux Command Value

Specifies magnetic-flux command value. This function becomes available when you set 2 to H43.

| | | | | | | | | | | | | | | | | | | | |
|---|---|---|---|--|---|---|---|--|--|--|--|--|--|--|--|--|--|--|--|
| H | 4 | 4 | M | | R | E | F | | | | | | | | | | | | |
|---|---|---|---|--|---|---|---|--|--|--|--|--|--|--|--|--|--|--|--|

Setting value: 10 to 100 (%)

H46

Observer (Mode selection)

Specifies an inertia of a mechanical system or uses the ASR tuning to measure the inertia, operates an internal machine model in the inverter, estimates a load torque that becomes a disturbance element or a oscillation element, adds a value to the torque command to counteract the load torque to increase the speed response against a load disturbance and to damp an oscillation generated by the mechanical resonance quickly.

| | | | | | | | | | | | | | | | | | | | |
|---|---|---|---|---|---|--|---|---|---|---|--|--|--|--|--|--|--|--|--|
| H | 4 | 6 | O | B | S | | M | O | D | E | | | | | | | | | |
|---|---|---|---|---|---|--|---|---|---|---|--|--|--|--|--|--|--|--|--|

Setting value: 0: Disabled

1: Load disturbance observer

2: Oscillation suppressing observer

Note: When a load inertia specified by H51 or H52 and H127 has a large error, you cannot obtain an expected performance. Specify an accurate value.

H47, H48,
H125**Observer (M1, M2, M3 compensation gain)**H49, H50,
H126**Observer (M1, M2, M3 I-time)**H51, H52,
H127**Observer (M1, M2, M3 load inertia)**

Specifies the compensation gain, the integral time, and the load inertia for the observer function.

| | | | | | | | | | | | | | | | | | | | |
|---|---|---|---|---|---|---|---|---|---|---|---|---|---|--|--|--|--|--|--|
| H | 4 | 7 | M | 1 | - | O | B | S | - | P | | | | | | | | | |
| H | 4 | 8 | M | 2 | - | O | B | S | - | P | | | | | | | | | |
| H | 1 | 2 | 5 | M | 3 | - | O | B | S | - | P | | | | | | | | |
| H | 4 | 9 | M | 1 | - | O | B | S | - | I | | | | | | | | | |
| H | 5 | 0 | M | 2 | - | O | B | S | - | I | | | | | | | | | |
| H | 1 | 2 | 6 | M | 3 | - | O | B | S | - | I | | | | | | | | |
| H | 5 | 1 | M | 1 | - | I | N | E | R | T | I | A | | | | | | | |
| H | 5 | 2 | M | 2 | - | I | N | E | R | T | I | A | | | | | | | |
| H | 1 | 2 | 7 | M | 3 | - | I | N | E | R | T | I | A | | | | | | |

Setting range

H47, H48, H125: 0.00 to 1.00 (times)

H49, H50, H126: 0.005 to 1.000 (s)

H51, H52, H127: 0.001 to 50.000 (kg•m²)

To H51, H52 and H127 (Load inertia), set the motor shaft conversion value in kg•m². The load inertia can be also measured by ASR tuning specified by H01 (Auto-tuning). Using H228 can switch the magnification of the load inertia setting.

You can select an element for the speed feedback

H 5 3 N - F B S E L

Set value: 0: Line speed disabled (integrated PG enabled)

However, with UPAC, Ai input or PG(LD) high select

- 1: Analog line speed detection *LINE-N*
- 2: Digital line speed detection (optional OPC-VG1-PG (LD))
- 3: High selector (select the higher speed between the motor speed or line speed)

About High selector

When you conduct a line speed control, and a line PG fails and presents a speed feedback of 0r/min, the inverter provides a command corresponding the maximum torque (torque limiter value if you use it) to accelerate the motor to the maximum speed to follow up the speed command. To change the feedback input from the line PG to a motor PG to prevent overrun when the line PG is disconnected is referred as "High selector". Make sure to use this High selector when you do not have a protective mean to detect the PG disconnection for line speed control.


Note: When you use a motor PG and the optional OPC-VG1-PG (LD), a protective function of "PG disconnection alarm" becomes available.

If P01 (M1 control method) is set at "2" (simulation mode), the line speed feedback automatically becomes invalid.

<Application example of line speed control>

The right figure illustrates an example of line speed control with PG.

When the line PG output is digital pulse, then use Fuji PG card (OPC-VG1-PG (LD)). See also the description of o06, o07, and o08 and the control block diagram.



| | |
|-----|---------------------------------------|
| H55 | Zero Speed Control (Gain) |
| H56 | Zero Speed Control (Completion range) |

Specifies the gain of the servo locking command and the range of completion to provide the servo locking completion signal. See the section of *LOCK* of the function code E01 to E13 "X function selection"

H 5 5 Z E R O - G A I N

Setting range: 0 to 100 (times)

H 5 6 Z E R O - H I S S

Setting range: 0 to 100 (pulse)

| | |
|-----|-------------------------|
| H57 | Overvoltage Suppression |
|-----|-------------------------|

When the DC link circuit voltage exceeds the overvoltage protection level during braking operation, the overvoltage (OV) trip occurs. This function limits the braking torque to zero before the overvoltage trip during the braking operation. The link circuit voltage decreases after 0 limiting, and the brake torque recovers automatically. This operation repeats to restrain the overvoltage trip.

You can use only inverter loss energy to apply brake without braking devices (braking resistor and PWM converter). When you want to use this function, see also "Power limiter" of the function code F40 to F45 "Torque limiter"

H 5 7 O U P R E V E N T

Set value: 0: Disabled
1: Enabled

Note: The torque generated by the motor may decrease under a suppressed voltage state. Do not use this function for vertical transportation applications.

In case of V/f control, too short a deceleration setting may disable overvoltage suppression. If overvoltage suppression is disabled, extend the deceleration time.

H58**Overcurrent Suppression**

The overcurrent trip occurs when the motor current changes suddenly to become more than the protection level. The overcurrent suppressing function restrains the inverter from supplying a current more than the protection level when the load changes.

| | | | | | | | | | | | |
|---|---|---|---|---|---|---|---|---|---|---|---|
| H | 5 | 8 | O | C | P | R | E | V | E | N | T |
|---|---|---|---|---|---|---|---|---|---|---|---|

Set value: 0: Disabled
1: Enabled

Note: The torque generated by the motor may decrease under a suppressed voltage state. Do not use this function for vertical transportation applications.

H60 to H66**Load Adaptive Control**

This function is related with the load adaptive control (H201 to H227). Refer to Section 4.1 "Control Block Diagrams."

Use this function to lift faster in case of small loads when compared with the speed at the rated load, thereby improving the efficiency of operation of the equipment.

Internal calculation of the inverter estimates the load during acceleration up to the rated (base) motor speed to calculate the maximum operable speed and perform speed limit control. Operation at the same speed in the up- and down-winding cycles with the same load is a major feature. As well, the maximum speed calculation correction function is added so that the up-/down-winding operation at the rated load is always at the rated (base) motor speed. The function can be used for lifting equipment equipped with a counterweight.

| | | | | | | | | | | | |
|---|---|---|---|---|---|---|---|---|---|---|---|
| H | 6 | 0 | L | O | A | D | C | O | N | 1 | |
| H | 6 | 1 | L | O | A | D | C | O | N | 2 | |
| H | 6 | 2 | L | I | F | T | S | P | E | E | D |
| H | 6 | 3 | C | W | E | I | G | H | T | | |
| H | 6 | 4 | S | A | F | E | C | O | E | F | |
| H | 6 | 5 | M | E | F | F | I | C | I | E | N |
| H | 6 | 6 | R | L | O | A | D | | | | |

Note: The load adaptive control is valid with the M1 motor only. Specify the same torque limit value for driving and braking.

Use acceleration/deceleration time 1 during operation under load adaptive control. Do not change the acceleration/deceleration time setting during load adaptive control operation.

This function is related with the multi-limit speed pattern function (H214 to H227). For load adaptive control and multi-limit speed pattern, refer to Section 4.1 "Control Block Diagrams."

H51 Observer setting (load inertia of M1): 0.001 to 50.000 (kg•m²)

H202, H205, H208, H211 Load inertia: 0.001 to 50.000 (kg•m²)

Specify the inertia without a load converted to the M1 motor shaft.

Note: In a multi-winding system, specify the quotient of the total inertia divided by the number of windings. For example, for a motor with two windings, specify a half the total inertia.

H60 Load adaptive control definition 1

Select the control method.

Setting 0: The load adaptive control is made invalid.

1: Speed limit at almost same speed in up- and down-winding cycles

2: Regular speed limit

3: Limit invalid during driving operation and speed limit during braking operation

H61 Load adaptive control definition 2

Define the relationship between the direction of rotation of motor and lifting direction.

Setting 0: Winding up during forward rotation of motor

1: Winding down during forward rotation of motor

Note: Setting H201 data to "0" also reverses the torque polarity in travel torque calculation.

H62 Up-winding speed: 0.0 to 999.9 (m/min)

Specify the lifting speed at the rated (base) motor speed. Note that this is not the maximum speed.

H63 Weight of counterweigh: 0 to 600.00 (t)

Specify for lifting equipment equipped with a counterweight. Specify the weight of the counterweight.

H64, H203, H206, H209, H212 Safety coefficient: 0.50 to 1.20

Use the safety coefficient to adjust the motor output that is the basis of calculation of the speed limit value. Lowering the safety coefficient to less than 1.00 decreases the speed limit value.

H65, H204, H207, H210, H213 Machine efficiency: 0.500 to 1.000

Specify the total efficiency of the equipment.

H66 Rated load: 0 to 600.00 (t)

The parameter is necessary for the correction of the maximum speed calculation so that operation at the rated (base) motor speed is assured during up-/down-winding cycles at the rated load. Using H228 can switch the magnification of the setting.

Note: Include the mass of the spreader and head block, too, in the setting. For a multi-winding system, specify the quotient of the total mass divided by the number of windings. For example, for a motor with two windings, specify a half the total mass.

Specify H51, H202, H205, H208, H211 (Observer setting (M1 load inertia)), H61 (Load adaptive control definition 2), H62 (Winding-up speed), H63 (Weight of counterweight), and H65, H204, H207, H210, H213 (Machine efficiency) according to the specification of the machine. The speed limit is set in a constant-output pattern according to the rated motor output. The rated motor output serving as a basis for the calculation of the speed limit can be adjusted with H65, H203, H206, H209, H212 (Safety coefficient).

To operate at almost the same speed in the winding-up and winding-down cycles of the same load, specify setting "1" as H60 (Load adaptive control definition 1).

To operate at the rated (basic) motor speed in the winding-up and winding-down cycles of the rated load, specify H66 (Rated load). If the estimated inverter load exceeds the rated load, limit the motor speed using the rated speed (Basic speed).

To determine the maximum speed under consideration for the machine efficiency, specify setting "2" as H60 (Load adaptive control definition 1). The down-winding speed (during braking operation) becomes higher by the machine efficiency when compared with the winding-up speed (driving operation).

To invalidate load adaptive control during driving operation and validate the control only during braking operation, specify setting "3" as H60 (Load adaptive control definition 1). The control becomes invalid in the winding-up cycle (during driving operation) and the control becomes valid in the winding-down cycle.

To invalidate load adaptive control, set the H60 data (Load adaptive control definition 1) to "0" or turn ON the *N-LIM* (Cancel speed limiter) of the X terminal function. Doing so disables only the speed limiter triggered by load adaptive control. The estimated load and the speed limit value are calculated so that the speed limit value calculation result obtained with option monitor 6 mentioned later is also effective.

The limit value calculation result can be checked by using option monitor 6, M220 (Load compensating speed control value), M221 (Hoisting load calculation result monitor (kg)) or M222 (Travel torque calculation monitor (%)). (Valid if H60 (Load adaptive control, Definition 1) is set at "1," "2" or "3.")

The load adaptive control activation state can be checked by the Y terminal function.

ANL (In limiting under load adaptive control)

This signal comes ON when the reference speed is limited with the speed limit value calculated under load adaptive control.

ANC (In calculation under load adaptive control)


This signal is ON during calculation of live load and speed limit value under load adaptive control.

Turning this signal OFF updates the limit value calculation result obtained with option monitor 6 to the latest data.

For details about *ANL* and *ANC* signals, refer to the description of E15 to E27 (Y terminal function).


Speed limit pattern diagrams

If H60 (Load adaptive control definition 1) = 1



k1 indicates the motor torque determined from H66 (Rated load) and H62 (Rated lifting speed). The motor speed is limited by the base speed with the loads exceeding the rated load. The rated motor torque can be operated, using H64, H203, H206, H209, H212 (Safety coefficient).

If H60 (Load adaptive control definition 1) = 2 or 3



The limit speed is obtained from the relationship between the maximum motor torque and maximum torque necessary for acceleration/deceleration. The maximum motor torque can be operated, using H64, H203, H206, H209, H212 (Safety coefficient).

H68 Alarm Data Deletion

Deletes the alarm history and the alarm information maintained in the inverter completely.
 The corresponding functions are the KEYPAD panel alarm information, the alarm history and the source of alarms.
 Setting the H68 data to "1" clears all data and automatically returns to "0."

H 6 8 A L A R M D A T A

H70 Reserved 1

These functions are reserved for makers to adjust the inverter.

H 7 0 M A K E R 1

⚠ WARNING

Do not change.
Accident and/or injury may result.

H71 Reserved 2

When you mount a PG on the motor or replace the PG at the site for motors having no magnetic pole position offset label, perform automatic adjustment with the tuning function (H71 = 5)

H 7 1 M A K E R 2

Setting 5: Magnetic pole position offset tuning

H74 PG Detection Circuit Self-diagnosis

H74 performs self-diagnosis of the pulse generator 2-phase signal input terminals (PA and PB) and output terminals (FA and FB). Follow the procedure given below.

H 7 4 P G S E L F

Setting 0: Disable
 1: Perform PG detection circuit self-diagnosis

Preparation

- (1) Set the 1000's digit of H104 (PG wire break alarm) to "0" (Disable).
- (2) Set the E29 data (PG output pulse selection) to "7."
- (3) Disable the following functions and revert the following function codes to the defaults.


Functions to be disabled:

Jogging operation *JOG*, ASR acceleration/ deceleration time, and Pre-excitation

Function codes to be reverted to factory defaults:

F23 (Starting speed) = 0.0
 F24 (Starting speed, Holding time) = 0.00

- (4) Check that contact outputs *BX*, *STOP1*, *STOP2*, *STOP3* and *BPS* are OFF.
- (5) Shut down the inverter power.



-
- (6) After making sure that the inverter power is OFF, make a connection between PA and FA and between PB and FB with external wiring.
Set the pulse generator output (FA and FB) in complementary output (SW7 = 2, SW8 = 2).
(Refer to Section 3.3.3.9 "Setting up the slide switches.")
- (7) Turn the inverter power ON.

Starting diagnosis



- (1) Set the H74 data to "1."

The inverter outputs an automatically generated speed pattern from the pulse generator output terminals (FA and FB) and detects the speed pattern via the pulse generator 2-phase signal input terminals (PA and PB). It compares the detected speed pattern with the output one for diagnosis of the PG detection circuit.

- (2) If the diagnosis result is normal, the "COMPLETE OK!" appears on the LCD monitor.

If it is abnormal, the "PG CIR ERR" or "A/B PHASE ERR" appears.

After completion of diagnosis, the H74 data automatically reverts to "0."


The time required for the diagnosis is approximately 12 seconds. Pressing the  or  key during diagnosis cancels the diagnosis in midway.

After completion of diagnosis

- (1) Revert the settings of H104 and E29 to their original values.
- (2) Shut down the inverter power (including R0 and T0).
- (3) Remove the external wiring (connection between PA and FA and between PB and FB).
- (4) If the settings (SW7 and SW8) of the pulse generator output (FA and FB) have been modified, revert them to the original settings.

- Notes**
- When the optional PG(SD)/PGo(SD) card is mounted on the inverter, this function cannot be used. (E_r-E will result.)
 - The diagnosis can be performed only with the control power (R0 and T0) ON.
 - The diagnosis temporarily changes particular function code data, so be sure to shut down the inverter power after completion of diagnosis.

Display during PG detection circuit self-diagnosis



Change the data of the function code with the keys.

After "STOP+^ V ->DATA SET" appears, the FWD/STOP key operations appear alternately.

Start PG detection circuit self diagnosis with key ON.

When 100% appears, PG detection circuit self diagnosis is finished. Forcible stop is possible with STOP key or RESET key ON.

If the diagnosis result is normal, "COMPLETE OK!" appears.

After about 1.5 seconds, the function code list screen appears.

The H74 setting automatically returns to "0".

If the polarity of the detected speed value is reversed, "A/B PHASE ERR" appears.

Move to the function code setting screen with RESET key or STOP key ON.

If the speed detection circuit is abnormal, "PG CIR ERR" appears.

Move to the function code setting screen with RESET key or STOP key ON.

H75**Phase Sequence Configuration of Main Circuit Output Wires**

H75 switches the phase sequence of the main circuit to invert the phase without changing the motor wiring. For vector control with a PG, it is necessary to replace the PG signal wires PA and PB.

This function is available only under induction motor control.

Note: For vector control with a PG, it is necessary to match the motor rotation direction with the phase sequence of PG signals.

| | | | | | | | | | | | | | | | | | | | |
|---|---|---|---|---|---|--|---|---|---|--|--|--|--|--|--|--|--|--|--|
| H | 7 | 5 | U | V | W | | P | H | S | | | | | | | | | | |
|---|---|---|---|---|---|--|---|---|---|--|--|--|--|--|--|--|--|--|--|

Setting 0: UVW normal phase connection
1: UVW reverse phase connection

H76**Main Power Down Detection**

The main power break detection function monitors the main power of the inverter (RST AC voltage input). When set to "1", the monitor functions below operate.

If a main power break is detected while the inverter is stopped, the charge resistance bypass circuit in the inverter opens. If a brief main power break occurs while the inverter is stopped, charging will take place through the charge resistance circuit when the power is restored, enabling the suppression of surge current.

Note: If "0" (No main power AC input monitor) is set and the main power is turned off/on quickly while the inverter is stopped, the charge resistance in the inverter will be bypassed and excessive surge current may damage the inverter.

When the main power is OFF, a power interruption will be detected and inverter output will not start even if the DC link bus voltage is above the undervoltage level. During inverter output, a power interruption is detected based on the DC link bus voltage only.

When a main power break is detected, (underline) will appear in the LED monitor of the display.

However, when DC power is supplied and inverter AC input power is not supplied, such as when a power regeneration converter is connected, always set to "0" (No main power AC input monitor).

| | | | | | | | | | | | | | | | | | | | |
|---|---|---|---|---|---|--|---|---|---|--|--|--|--|--|--|--|--|--|--|
| H | 7 | 6 | R | S | T | | O | F | F | | | | | | | | | | |
|---|---|---|---|---|---|--|---|---|---|--|--|--|--|--|--|--|--|--|--|

Setting 0: No main power AC input monitor
1: Main power AC input monitor

H77**Cooling Fan ON/OFF Control Continuation Timer**

This sets the condition for the cooling fan ON-OFF function by H06. While the inverter is stopped, if the detected fan temperature is below a fixed value for the time set with this setting, the cooling fan turns OFF.

| | | | | | | | | | | | | | | | | | | | |
|---|---|---|---|---|---|---|---|--|--|--|--|--|--|--|--|--|--|--|--|
| H | 7 | 7 | F | - | T | I | M | | | | | | | | | | | | |
|---|---|---|---|---|---|---|---|--|--|--|--|--|--|--|--|--|--|--|--|

Setting: 0 to 600 sec

H78**Initialization of Startup Counter/Total Run Time**

This function initializes the M1 - M3 start counts and M1 - M3 cumulative run times (clear to zero). When doing maintenance work on the motor or machine, you can individually initialize the data of each.

| | | | | | | | | | | | |
|---|---|---|---|---|---|---|---|---|---|--|--|
| H | 7 | 8 | M | N | T | I | N | I | T | | |
|---|---|---|---|---|---|---|---|---|---|--|--|

Setting 0: No operation

- 1: Initialize M123 "M1 start count"
- 2: Initialize M124 "M2 start count"
- 3: Initialize M125 "M3 start count"
- 4: Initialize M126 "M1 cumulative run time"
- 5: Initialize M127 "M2 cumulative run time"
- 6: Initialize M128 "M3 cumulative run time"

H79**Initialization of Cumulative Run Time of Cooling Fan**

The data for the initial value setting of the cooling fan aggregate run time can be changed. When the cooling fan is replaced, set "1". When "1" is set, "0" is written to the aggregate time internally. When replacing the inverter control board, write down the data of this function code before replacing the board, and then reset the data after replacement to continue the aggregate run time. The setting automatically reverts to "0" after it is written.

| | | | | | | | | | | | |
|---|---|---|---|---|---|---|---|---|---|---|--|
| H | 7 | 9 | F | A | N | T | - | I | N | I | |
|---|---|---|---|---|---|---|---|---|---|---|--|

Setting: 0 to 65535 (units of 10 hours)

H80**Capacitance Measurement of DC Link Bus Capacitor**

When the capacitor capacitance measurement method is user mode (1's digit of H104 is 1), this function code is used. Read and understand the following explanation.

When initial value measurement of the user setting capacitor capacitance is started, the measurement result is written. When the inverter power is shut off with this setting set to "1", initial value measurement of the user setting capacitor capacitance starts and the measurement result is written to this code.

User mode capacitor capacitance measurement is performed when the power is shut off if the AND conditions below are met.

- Inverter is stopped
- Undervoltage alarm has not occurred
- Cooling fan is running (will be forcibly stopped by the inverter when the power is shut off)

| | | | | | | | | | | | |
|---|---|---|---|---|---|---|---|---|---|--|--|
| H | 8 | 0 | C | C | - | I | N | I | T | | |
|---|---|---|---|---|---|---|---|---|---|--|--|

Setting: 0 to 32767

When the capacitor capacitance measurement method is the factory default standard (1's digit of H104 is 0)

Measurement is performed when the power is shut off if all measurement conditions in the table below are ○. The measurement conditions vary depending on whether or not the predicted life (LIFE) is selected with Y function selection. The measurement result is shown in M46 "main circuit capacitor capacitance (%)" and M121 "main circuit capacitor life (elapsed time)". In the M121 elapsed time, the capacitance decrease rate and capacitor life time obtained by capacitor capacitance measurement are converted to an elapsed time that overwrites the previous value.

When the capacitor capacitance measurement method is the user measurement value standard (1's digit of H104 is 1)

The measurement conditions are different from the factory default standard. Refer to the table below.

| Measurement condition | Factory default standard (H104=***0) | | User measurement value standard (H104=***1) |
|---------------------------|--------------------------------------|-----------------|---|
| | No LIFE assignment | LIFE assignment | |
| Gate signal OFF | ○ | ○ | ○ |
| Cooling fan running | ○ | ○ | ○ |
| Not undervoltage | ○ | ○ | ○ |
| Terminal inputs all OFF | ○ *1 | ○ *1 | - |
| Option card not installed | ○ | - *2 | - |

*1 Terminal information after normal open/close processing.


*2 When life information (LIFE) is assigned, measurement is also performed when an option card other than UPAC is installed.

Measurement will take place under the following conditions, however, the result will not be correct.

- When a breaking unit or other inverter is connected to the P (+), N (-) main circuit terminals by DC bus connection.
- RS-485 communication is used.
- Power is supplied from the R0, T0 auxiliary power.

By assigning the life prediction (LIFE) signal to one of the function codes of the Y function selection setting (E15 to E19), a life prediction signal is output to the general-purpose output (Y1 to Y5) when all of the conditions below are met.

- M46 "main circuit capacitor capacitance (%)" is 85% or lower
- The 10's digit of H104 is 1 (default value)
- Life determination cancel LF-CCL is OFF



H81**Initialization of Service Life of DC Link Bus Capacitor**

The data for the initial value setting of the main circuit capacitor life aggregate time can be changed. When the main circuit capacitor is replaced, set "1". When "1" is set, "0" is written to the aggregate time internally. When replacing the inverter control board, write down this function code before replacing the board, and then reset after replacement to continue the aggregate time. The setting automatically reverts to "0" after it is written.

| | | | | | | | | | | | | |
|---|---|---|---|---|---|---|---|---|--|---|---|---|
| H | 8 | 1 | C | - | T | I | M | E | | I | N | I |
|---|---|---|---|---|---|---|---|---|--|---|---|---|

Setting: 0 to 65535 (units of 10 hours)

H82**Startup Count for Maintenance**

When the total value of M123 "M1 start count" to M125 "M3 start count" becomes larger than this setting, a maintenance prediction (MNT) signal is output. By setting a start count for machine maintenance, external notification of maintenance timing is possible. The function code is the same for each motor. When the setting is "0", the start count stops.

| | | | | | | | | | | | | |
|---|---|---|---|---|---|--|---|---|---|---|--|--|
| H | 8 | 2 | M | N | T | | S | T | R | T | | |
|---|---|---|---|---|---|--|---|---|---|---|--|--|

Setting: 0 to 65535

0: No operation

1 to 65535: Set startup times

H83**Maintenance Interval**

This sets the inverter run time for performing machine maintenance. When the total value of M126 "M1 cumulative run time" to M128 "M3 cumulative run time" becomes larger than this setting, a maintenance prediction (MNT) signal is output. The function code is the same for each motor.

| | | | | | | | | | | | | |
|---|---|---|---|---|---|--|---|---|---|---|--|--|
| H | 8 | 3 | M | N | T | | T | I | M | E | | |
|---|---|---|---|---|---|--|---|---|---|---|--|--|

Setting: 0 to 65535 (units of 10 hours)

0: No operation

1 to 65535: Set time

H84**Speed calculation period when extremely low speed (For maker)**

This function is reserved for makers to adjust the inverter.

| | | | | | | | | | | | | |
|---|---|---|---|---|---|--|---|---|---|---|---|---|
| H | 8 | 4 | S | P | D | | P | E | R | I | O | D |
|---|---|---|---|---|---|--|---|---|---|---|---|---|

| | |
|----------------|-----------------------|
| H85-H88 | Calendar Clock |
|----------------|-----------------------|

This is primarily used to set the date and time in the internal clock of the inverter via the communication option. The date and time can be displayed regularly on the LCD. The date and time are also used as a time stamp for detailed alarm information and the support loader trace-back function

The date and time can be easily set using the keyboard from "12. DATE TIME" in the menu of program mode.

By setting the date and time in H85 to H87 and then setting "1" in H88, the date and time are applied to the internal clock. The setting of H88 automatically reverts to "0" after the date and time are written.

| | | | | | | | | | | | |
|---|---|---|---|---|---|---|---|---|--|--|--|
| H | 8 | 5 | Y | / | M | S | E | T | | | |
| H | 8 | 6 | D | / | H | S | E | T | | | |
| H | 8 | 7 | M | / | S | S | E | T | | | |

Setting: 0 to FFFF

| | | | | | | | | | | | |
|---|---|---|---|---|---|---|---|---|---|--|--|
| H | 8 | 8 | W | R | - | T | I | M | E | | |
|---|---|---|---|---|---|---|---|---|---|--|--|

Setting 0: No operation
1: Write time

The setting range is January 1, 2000, 00:00:00 to December 31, 2099, 23:59:59.

For example to set April 1, 2011, 13:15:00, write the values below.

Set H85 = 0B04, H86 = 010D, H87 = 0F00 in hexadecimal.

Set H88 = 1 to write the above values to the internal clock.

Valid numbers for each item are shown below.

Year: 00h - 63h, Month: 01h - 0Ch, Day: 01h - 1Fh, Hour: 00h - 17h, Min: 00h - 3Bh, Sec: 00h - 3Bh

* If values other than the above are set and "write time" is performed with H88, the individual values that are out of range are invalidated and not applied to the clock. Values that are valid are applied to the clock.

| | |
|------------|--|
| H90 | Overspeed Alarm Detection Level |
|------------|--|

H90 specifies the detection level of the overspeed alarm ($\frac{f}{f_s}$). The data 100% represents the maximum speed.

Under V/f control, this setting is invalid.

| | | | | | | | | | | |
|---|---|---|---|---|---|---|---|--|--|--|
| H | 9 | 0 | O | S | L | V | L | | | |
|---|---|---|---|---|---|---|---|--|--|--|

Setting: 100 to 160%

Note: If "Maximum speed > Rated speed" and the rated output range is wide, set the H90 data under the following condition.

$$(\text{Maximum speed/Rated speed}) \times H90 \leq 720\%$$

H96 specifies the operation of torque limit when ASR is saturated

H 9 6 A S R O P E

Setting: 0 to 3

0: P priority (VG1)

1: I priority (compatible with VM5)

2: P priority (compatible with VM5)

3: For maker (do not select this)

*If H96 is set as 0, speed detection may not match with speed command when torque limit level is low. Therefore for P priority use please set it as 2.

P priority mode

The limit level of integration(I) output is calculated as torque limit level minus proportion(P) output.

$$\tau_{lim_I} = \tau_{lim} - \tau_P$$


ASR is able to escape from saturation quickly in this mode.

I priority mode


The limit level of integration(I) output equals torque limit level.

$$\tau_{lim_I} = \tau_{lim}$$


In this mode, because ASR I output limit level equals torque limit level, fluctuation of torque command is well restrained even when speed detection is fluctuating.



H96=0 : P priority (VG1)



H96=1 : I priority (compatible with VM5)



H96=2 : P priority (compatible with VM5)

H101 **PID Command Filter Time Constant**

H101 specifies the time constant for the PID command (after H21 switching) filter.

H 1 0 1 P I D F I L T

Setting: 0 to 5000 ms

H103 **Protective/Maintenance Function Selection 1**

Protection operations can be individually selected.
 To enable a protection operation, refer to the table below and set the appropriate digit to "1".

H 1 0 3 P R O T O P E 1

Setting: 0000 to 1111

- 1000's digit: Start delay alarm operation selection (L_{DL}) [0: Disable, 1: Enable] (default: 0)
- 100's digit: Grounding fault alarm operation selection (EF) [0: Disable, 1: Enable] (default: 1)
- 10's digit: Output open-phase alarm operation selection (OPL) [0: Disable, 1: Enable] (default: 0)
- 1's digit: Braking transistor error operation selection (BT) [0: Disable, 1: Enable] (default: 1)

Braking transistor error (1's digit)
 Selects whether errors of the braking transistor for braking resistor drive are detected.
 If you are not using a braking resistor and do not want this alarm to occur, set to "0".

Output open-phase (10's digit)
 Select whether the output open-phase alarm operates.

Grounding fault (100's digit)
 Select whether the grounding fault alarm operates.

Start delay (1000's digit)
 Select whether the start delay alarm operates.

H104**Protective/Maintenance Function Selection 2**

Protection operations and main circuit capacitor life determination operations can be individually selected. To enable a protection operation, refer to the table below and set the appropriate digit to "1".

| | | | | | | | | | | | |
|---|---|---|---|---|---|---|---|---|---|---|---|
| H | 1 | 0 | 4 | P | R | O | T | O | P | E | 2 |
|---|---|---|---|---|---|---|---|---|---|---|---|

Setting: 0000 to 1111

| | | |
|---------------|--|---|
| 1000's digit: | PG power break alarm (PG) operation selection | [0: Disable, 1: Enable] (default: 1) |
| 100's digit: | Carrier frequency reduction function selection | [0: Disable, 1: Enable] (default: 1) |
| 10's digit: | Main circuit capacitor life determination selection | [0: Disable, 1: Enable] (default: 1) |
| 1's digit: | Main circuit capacitor capacitance measurement selection | [0: Disable, 1: Enable] (default: 0) (0: Factory default standard, 1: User measurement standard) |

Main circuit capacitor capacitance measurement selection (1's digit)

Select whether the standard level for determining the life of the main circuit capacitor capacitance is the factory default standard or the user set standard. Also see the explanation of function code H80.

Main circuit capacitor life determination selection (10's digit)

Select whether decreased main circuit capacitor capacitance is the factor for the life prediction signal (LIFE). Also see the explanation of function code H80.

Carrier frequency auto reduction selection (100's digit)

This function automatically reduces the carrier frequency before an inverter cooling fan overheating (INV /) or inverter internal overheating (INV) alarm occurs in order to avoid the alarm. Select the operation of this function. When the carrier frequency is reduced, motor noise increases.

Note: When a synchronous motor is driven, the inverter carrier frequency is sometimes set higher to prevent overheating of the permanent magnet and demagnetization of the magnet due to inverter high frequency output current (excluding our GNF2 model). Carefully check the carrier frequency allowed by the motor before deciding the carrier frequency (F26) and carrier frequency auto reduction selection (H104) settings. If you cancel the carrier frequency auto reduction selection function (H104), exercise caution as the carrier frequency setting may cause a reduction of the unit's continuous rated current (for rated current reduction characteristics, refer to section 2.1.4). The setting of this digit cannot be changed during operation.

PG power break alarm selection (1000's digit)

Select whether the PG power loss alarm (PG) operates.

H105 Protective/Maintenance Function Selection 3 (Available soon)

Protection operations can be individually selected.

To enable a protection operation, refer to the table below and set the appropriate digit to "1".

H 1 0 5 P R O T O P E 3

Setting: 0000 to 1111

1000's digit: Not used

100's digit: Speed disaccord alarm E_r - S operation 1


10's digit: Speed disaccord alarm E_r - S operation 2

1's digit: Save the integrated value of motor electronic thermal

Specification of E_r - S alarm detection according to the combination of function codes

| E45 | H105 | E_r - S detection conditions | Remarks |
|----------|-------------|---|---|
| E45 = *0 | H105 = **** | E_r - S is disabled | |
| E45 = *1 | H105 = *00* | "Speed disaccord exists" and "speed command value and detected value are in opposite polarity" or "speed command value < speed detected value" | The same detection conditions of E_r - S with the old ROM |
| | H105 = *01* | "Speed disaccord exists" | |
| | H105 = *10* | "Speed disaccord exists" and "In run state" and "speed command value and detected value are in opposite polarity" or "speed command value < speed detected value" | Recommended |
| | H105 = *11* | "Speed disaccord exists" and "In run state" | |

Relationship between speed command value and detected value in E_r - S alarm detection specification.



Note) The definition of 100's and 10's digit of H105 is only valid in software version later than H1/2 0067.


H106 to H111**Light Alarm Object Definition 1 to 6**

When an error is detected and the error is a minor error, the light alarm ($L - FL$) display can be shown and operation can be continued without tripping the inverter.


"1" can be set in bits corresponding to any of the light alarm causes to treat those causes as light alarms and not have the alarm relay output (30RY) operate.

H 1 0 6 L - A L M 1


Setting: 0000 to 1111

**H 1 0 7 L - A L M 2**


Setting: 0000 to 1111

**H 1 0 8 L - A L M 3**


Setting: 0000 to 1111

**H 1 0 9 L - A L M 4**

Setting: 0000 to 1111

**H 1 1 0 L - A L M 5**

Setting: 0000 to 1111



Set whether the LED display shows [L-AL] when a light alarm occurs.

| | | | | | | | | | | | |
|---|---|---|---|---|---|---|---|---|---|--|--|
| H | 1 | 1 | 1 | L | - | A | L | M | 6 | | |
|---|---|---|---|---|---|---|---|---|---|--|--|

Setting: 0 to 1
 0: Disable (L-AL not displayed)
 1: Enable (L-AL displayed)

| | |
|--------------|--|
| H112 to H118 | M1 Magnetic Saturation Extension Coefficients 6-12 |
|--------------|--|

The excitation current (current that creates magnetic flux in the induction motor) and magnetic flux are in a non-linear relationship to maintain the saturation characteristics. When the saturation characteristics are significant in an application that exceeds a fixed output range of 1:2, set a correction factor.

For normal use, do not change.
 (These become function codes that expand the characteristics of P15 to P19.)

Only valid when vector control with speed sensor (induction motor) is selected. Only applies to the M1 motor. The M2 and M3 motors do not have a function code that is equivalent to this function code.

| | | | | | | | | | | | | |
|---|---|---|---|---|---|---|---|---|---|----|--|--|
| H | 1 | 1 | 2 | M | 1 | - | S | A | T | 6 | | |
| H | 1 | 1 | 3 | M | 1 | - | S | A | T | 7 | | |
| H | 1 | 1 | 4 | M | 1 | - | S | A | T | 8 | | |
| H | 1 | 1 | 5 | M | 1 | - | S | A | T | 9 | | |
| H | 1 | 1 | 6 | M | 1 | - | S | A | T | 10 | | |
| H | 1 | 1 | 7 | M | 1 | - | S | A | T | 11 | | |
| H | 1 | 1 | 8 | M | 1 | - | S | A | T | 12 | | |

Setting: 0.0 to 100.0%

| | |
|------|----------------------------------|
| H134 | Speed Drop Detection Delay Timer |
|------|----------------------------------|

Adds speed drop detection signal and speed setting detection signal conditions to the ON/OFF conditions of the break release signal (**BRK**). For details on **BRK**, refer to the explanation of 18: brake release signal (**BRK**) in function codes E01 - E13 (X terminal function).

Function code H134 sets the time interval from the point that the inverter is running until the speed drop detection function starts operating.

| | | | | | | | | | | | | |
|---|---|---|---|---|---|---|---|---|---|---|---|--|
| H | 1 | 3 | 4 | D | E | L | A | Y | T | I | M | |
|---|---|---|---|---|---|---|---|---|---|---|---|--|

Setting range: 0.000 to 10.000 s

| | |
|-------------|--|
| H135 | Speed Command Detection Level (forward) |
|-------------|--|

| | |
|-------------|--|
| H136 | Speed Command Detection Level (reverse) |
|-------------|--|


When speed setting 2 (before acceleration/deceleration calculation) rises higher than this setting, the speed setting detection signal turns ON. This is included in the brake release signal ON (brake release) conditions.

When speed setting 2 (before acceleration/deceleration calculation) or speed setting 3 (after acceleration/deceleration calculation) drops lower than this setting, the speed setting detection signal turns OFF. This is included in the brake release signal OFF (brake on) conditions. While running by run forward command, the H135 level is valid, and while running by run reverse command, the H136 level is valid.


| | | | | | | | | | | | | |
|---|---|---|---|---|---|---|---|---|---|---|---|---|
| H | 1 | 3 | 5 | N | R | E | F | L | E | V | L | F |
| H | 1 | 3 | 6 | N | R | E | F | L | E | V | L | R |

Setting range: 0.0 to 150.0 r/min

◆ Forward running (FWD ON)



◆ Reverse running (REV ON)




| | |
|-------------|-----------------------------------|
| H137 | Speed Drop Detection Level |
|-------------|-----------------------------------|

When the absolute value of the detected speed value falls below this setting, the speed drop detection signal turns ON and the brake release signal turns OFF (brake on).

| | | | | | | | | | | | |
|---|---|---|---|---|---|---|---|---|---|---|---|
| H | 1 | 3 | 7 | N | D | E | C | L | E | V | L |
|---|---|---|---|---|---|---|---|---|---|---|---|

Setting range: 0.0 to 150.0 r/min



| | |
|-------------|---|
| H138 | Speed Drop Detection Delay Timer |
|-------------|---|

On delay timer for the speed drop detection signal. When the on delay timer is operating, the speed drop detection signal does not turn ON when the detected speed value is higher than H138 + 1%.

H 1 3 8 N D E C T I M R

Setting range: 0.000 to 10.000 s

| | |
|-------------|--|
| H140 | Start Delay Detection (Detection level) |
|-------------|--|

| | |
|-------------|--|
| H141 | Start Delay Detection (Detection timer) |
|-------------|--|

When the torque current command value is higher than the level set with this function code, and the actual speed value or estimated speed value is lower than the speed set with function code F37 "Stop speed" over the time set in function code H141, the start delay alarm ($\overline{L-ALM}$) occurs.

H 1 4 0 S R T D L Y L

Setting range: 0.0 to 300.0%

H 1 4 1 S R T D L Y T

Setting range: 0.000 to 10.000 s

Note: Under vector control without speed sensor, whether the speed is less than the stop speed (F37) is judged by the estimated speed value. There may be deviations in alarm detection due to error in the estimated speed. The effect of estimated speed error is greater when the stop speed is low. Be aware of this when using this function code.

| | |
|-------------|-------------------|
| H142 | Mock Alarm |
|-------------|-------------------|

During setup, an alarm can be simulated to check the external sequence.

Setting method

Press the \odot and \wedge keys simultaneously or the \odot and \vee keys simultaneously, change to any set value, and then enter with the FUNC DATA key. After the mock alarm occurs, the set value automatically reverts to 0 and alarm reset can be performed.

If the mock alarm has been defined as a "light alarm" in function code H108 "light alarm definition 3", light alarm (L-ALM) can be assigned to one of the function codes of the Y function selection settings (E15 to E19) to allow the mock alarm status to be output to a general purpose output (Y1 to Y5). When this is done, the alarm relay output relay (30RY) does not operate. When defined as a "heavy alarm", the mock alarm status shows "E-".

Alarm data of the mock alarm (alarm history and other information related to the alarm) is recorded in the same way as alarm data during normal operation, and you can check the data.

To erase the alarm data after you have completed setup, use H68 "delete alarm data" in the same way as when deleting alarm data of an alarm that occurred during operation.

A mock alarm also occurs if you hold down \odot and FUNC DATA at least 3 seconds on the touch panel.

H 1 4 2 S I M A L M

Setting 0: No operation
 1: Mock alarm occurs

H144**Toggle Data Error Timer**

The error detection time for the toggle signal can be set.

Refer to the explanation of 72, 73: toggle signal 1, 2 in X function selection.

H 1 4 4 T G L E R R T

Setting range: 0.01 to 20.00 (sec)

H145**Reverse Run Prevention for Vector Control without Speed Sensor (Lower limit frequency selection)**

To improve speed control characteristics of ultra-low speed under vector control without speed sensor, a lower limit frequency can be set for the speed command value and estimated speed value (primary estimated frequency value).

H 1 4 5 L - L I M S E L

Setting range: 0 to 3

0: Disable


1: Enable for FWD polarity operation (enable in start delay during hoisting operation (FWD command, speed command+))

2: Enable for REV polarity operation (enable in start delay during lowering operation (REV command, speed command+))

3: Enable for both FWD and REV polarities (enable in start delay of both hoisting and lowering)


Limiting takes place in the shaded areas shown below. When the estimated speed value (primary estimated frequency value) is in a shaded area, the speed command is limited by the lower limit frequency.

Output frequency, final speed command




H145 = 0 (function disabled)

Output frequency, final speed command




H145 = 1 (FWD polarity enabled)

Output frequency, final speed command



H145 = 2 (REV polarity enabled)

Output frequency, final speed command



H145 = 3 (FWD/REV both enabled)

⚠ CAUTION

When enabling this function, set the start characteristic (H09) to 0 (no operation). When using the function with the speed setting by analog input near 0 (V), deviations in the analog voltage polarity will cause the limiting operation to become unstable. Take measures such as setting a dead zone (F82). There are restrictions on this function as noted above. Understand these restrictions before using the function.

| | |
|-------------|--|
| H146 | Reverse Run Prevention for Vector Control without Speed Sensor (Lower limit frequency, FWD) |
|-------------|--|

Set the lower limit frequency when H145 = 1 is set. As a guideline, set the motor slippage frequency.

H 1 4 6 L - L I M F W D

Setting range: 0.000 to 10.000 Hz

| | |
|-------------|--|
| H147 | Reverse Run Prevention for Vector Control without Speed Sensor (Lower limit frequency, REV) |
|-------------|--|

Set the lower limit frequency when H145 = 2 is set. As a guideline, set the motor slippage frequency.

H 1 4 7 L - L I M R E V

Setting range: 0.000 to 10.000 Hz

| | |
|-------------|---|
| H148 | Estimated Primary Frequency Filter |
|-------------|---|

Set the primary delay filter time constant for the estimated speed value (primary estimated frequency value).
Use for speed changes under vector control without speed sensor.

H 1 4 8 P R I - F F I L

Setting range: 0 to 100 ms

| | |
|-------------|--|
| H149 | Machine Runaway Detection Speed Setting |
|-------------|--|

This function is valid only when the **BRK** (Brake release signal) is assigned to a Y terminal.

If the deviation of the actual speed from the speed command (Speed setting 4: ASR input) exceeds the value specified by H149 when the inverter is running and after the brake release signal is turned ON, then the inverter regards it as a machine runaway and outputs a speed mismatch alarm (E₄-E₅).

No delay timer is provided for detection, so the inverter immediately causes an alarm.


If a false detection is made due to a speed deviation immediately following brake releasing, increase the H149 data.

The data 100% represents the maximum speed.


The detection conditions are different between this alarm and the speed disagreement alarm (E43 to E45). The speed disagreement alarm does not occur when the polarity of the speed command (Speed setting 4: ASR input) and that of the actual speed match with each other and the actual speed is less than the speed command. See the graphs given below.

H 1 4 9 M - S P D

Setting 0.0: Disable
0.1 to 20.0%



Speed mismatch alarm conditions
(machine runaway detection)



Speed disagreement alarm conditions (by E43 - E4)

Note: The operation of the speed mismatch alarm is defined by the function code E45 operation definition.

| | |
|-------------|---|
| H160 | M1 Initial Magnetic Pole Position Detection Mode |
| H170 | M2 Initial Magnetic Pole Position Detection Mode |
| H180 | M3 Initial Magnetic Pole Position Detection Mode |

Function codes for the synchronous motor. These set the initial magnetic pole position detection method.

| | | | | |
|----------------|------------|----------|------------|--------------|
| H 1 6 0 | M 1 | - | S M | I N I |
| H 1 7 0 | M 2 | - | S M | I N I |
| H 1 8 0 | M 3 | - | S M | I N I |

Setting 0: Pull-in by current for IPMSM (Interior Permanent Magnet Synchronous Motor)

Related function codes

Pull-in by current: Pull-in current command (H161, H171, and H181)
Pull-in frequency (H162, H172, and H182)

For the operating procedure of pull-in by current, refer to Chapter 3, Section 3.5.4.2 "Test run procedure for permanent magnet synchronous motor (PMSM)."

| | |
|-------------|-----------------------------------|
| H161 | M1 Pull-in Current Command |
| H171 | M2 Pull-in Current Command |
| H181 | M3 Pull-in Current Command |

Current command value for magnetic pole position detection. Normally there is no need to change the factory default value.

| | | | | |
|----------------|------------|----------|----------------|----------|
| H 1 6 1 | M 1 | - | D R A W | I |
| H 1 7 1 | M 2 | - | P R A W | I |
| H 1 8 1 | M 3 | - | P R A W | I |

Setting: 10 to 200% (100% / motor rated current)

| | |
|-------------|-----------------------------|
| H162 | M1 Pull-in Frequency |
| H172 | M2 Pull-in Frequency |
| H182 | M3 Pull-in Frequency |

Frequency command value for magnetic pole position detection. Normally there is no need to change the factory default value.

| | | | |
|----------------|------------|------------------|----------|
| H 1 6 2 | M 1 | - D R A W | F |
| H 1 7 2 | M 2 | - D R A W | F |
| H 1 8 2 | M 3 | - P R A W | F |

Setting: 0.1 to 10.0 Hz

| | |
|---------------------|--|
| H201 to H213 | Load Adaptive Control Parameter Settings 1 (Available soon) |
|---------------------|--|

Parameters used for load compensation control.
For details, refer to the explanation of functions H60 to H66.

| | | | |
|----------------|------------|--------------|------------|
| H 2 0 1 | L D | A D P | S W |
|----------------|------------|--------------|------------|

Settings 0: H51, H64, H65 enabled, H202-H213 disabled
1: H51, H64, H65 enabled, H202-H213 disabled

Set the inertia for M1 motor axis conversion not including the applied load.
For multi-winding systems, or for synchronous driving of a load with multiple motors, divide the total inertia by the number of windings or the number of motors and set the resulting value. For example, for a two-winding motor, set 1/2 the value of the total inertia.

Using H228 can switch the magnification of the load inertia setting.

H202, H205: Load inertia (hoisting 1, 2); H208, H211: Load inertia (lowering 1, 2)

| | | |
|----------------|----------------|--------------|
| H 2 0 2 | L D - J | U P 1 |
| H 2 0 5 | L D - J | U P 2 |
| H 2 0 8 | L D - J | U P 1 |
| H 2 1 1 | L D - J | U P 2 |

Setting: 0.001 to 50.000 kg·m²

H203, H206: Safety coefficient (hoisting 1, 2); H209, H212: Safety coefficient (lowering 1, 2)

| | | |
|----------------|----------------|--------------|
| H 2 0 3 | S A F E | U P 1 |
| H 2 0 6 | S A F E | U P 2 |
| H 2 0 9 | S A F E | D N 1 |
| H 2 1 2 | S A F E | D N 2 |

Setting: 0.5 to 1.20

H204, H207: Machine efficiency (hoisting 1, 2); H210, H213: Machine efficiency (lowering 1, 2)

Set the total efficiency of the machine.

| | | |
|----------------|----------------|--------------|
| H 2 0 4 | M - E F | U P 1 |
| H 2 0 7 | M - E F | U P 2 |
| H 2 1 0 | M - E F | D N 1 |
| H 2 1 3 | M - E F | D N 2 |

Setting: 0.500 to 1.000

H214 = 1 enables the multi restriction speed pattern function. For the relation to the H201 - H213 load compensation control function, refer to the explanation of functions H60 - H66.

Set the torque level of each limit speed point as indicated below.

H215 - H224: Multi limit speed pattern (*)

- * H215: Maximum speed, H216: Rated speed, H217: Rated speed × 1.1, H218: Rated speed × 1.2
- H219: Rated speed × 1.4, H220: Rated speed × 1.6, H221: Rated speed × 1.8, H222: Rated speed × 2.0
- H223: Rated speed × 2.5, H224: Rated speed × 3.0

| | | |
|----------------|------------------------|--|
| H 2 1 5 | M U L - N M A X | |
| H 2 1 6 | M U L - N R A T | |
| H 2 1 7 | M U L - L 1 . 1 | |
| H 2 1 8 | M U L - L 1 . 2 | |
| H 2 1 9 | M U L - L 1 . 4 | |
| H 2 2 0 | M U L - L 1 . 6 | |
| H 2 2 1 | M U L - L 1 . 8 | |
| H 2 2 2 | M U L - L 2 . 0 | |
| H 2 2 3 | M U L - L 2 . 5 | |
| H 2 2 4 | M U L - L 3 . 0 | |

Setting: 0.1 to 100.0%

<Setting notes>


A torque level setting for a limit speed point that exceeds the maximum speed will be invalid.

The settings for T1 to T9 should increase in order from T1 (T1 < T2 < ...T9).

Set the torque level Tnmax for the maximum speed to a smaller value than the torque levels set for the limit speed points less than the maximum speed.

The multi limit speed pattern (bold line below) is limited to within the rated motor torque pattern (fine line below).

<Limit pattern graph>




H225: Limit speed discrimination interval (start speed), H226: Limit speed discrimination interval (end speed)

The limit speed is calculated within the discrimination speed interval. Set with the rated speed 100%.

| | | | | | | | | | | | |
|---|---|---|---|---|---|---|---|---|---|---|---|
| H | 2 | 2 | 5 | L | I | M | - | N | S | R | T |
| H | 2 | 2 | 6 | L | I | M | - | N | E | N | T |

Setting: 0.1 to 100.0%



Within the calculation interval, the limit speed is calculated from the torque command that occurs and the instantaneous value of the acceleration data. When the speed reaches the limit completion speed, the average value of the calculated results is used as the final limit speed.

Example: When rated speed F04 = 1500 r/min, H225 = 75.0%, H226 = 93.7%, acceleration time F07 = 5 s, maximum speed F03 = 3000 r/min,

- Discrimination start speed = 1125.0 r/min (1500×0.75)
- Discrimination end speed = 1405.5 r/min (1500×0.937)
- Calculation interval $t = (1405.5 - 1125)/3000 \times 5 \text{ s} = 0.935 \text{ s}$

* In this example, operation takes place according to the speed command value. If a torque restriction is triggered or the detected speed value does not accord with the speed command, the time t will be different.


- When the discrimination start speed is greater than the discrimination end speed (H225 > H226), load compensation calculation is performed when the speed set for the discrimination end speed is reached.
- When the discrimination interval is short or the torque command value varies widely, deviations occur in the calculation results.
- When there are wide variations in the torque command value, adjust the speed control factor (ASR) to decrease the variations in the torque command value.

When a speed limit calculation reset signal (*NL-RST*) is assigned to the digital input signal and turned ON, the load compensation calculation result is cleared and the limit speed is recalculated the next time reacceleration occurs in the same direction.

Calculation result clear conditions

The speed command value has dropped to under 50% of the rated speed.

Input the speed limit calculation reset signal (*NL-RST*) 5 ms or more.



Calculation result is reset by signal input at 50% or less of rated speed.

Each time the polarity of the speed command value changes (hoisting ⇔ lowering), the limit speed is calculated when acceleration takes place, regardless of the speed limit calculation reset signal (NL-RST).

H227: Load compensation control definition 3

H 2 2 7 L O A D C O N 3

Setting value 0: Separate limit speed calculation for hoisting and lowering

1: A limit speed is calculated when hoisting. When lowering, the speed is limited by the result of the previous hoisting calculation.

However, when one of the following conditions obtains, limit speed calculation also takes place when lowering.


- 1) The first operation after powering on is lowering.
- 2) A limit speed was not calculated for the previous hoisting operation.
⇒ The previous hoisting took place at a speed under the H226 limit speed discrimination interval (end speed)
- 3) Lowering was performed after pre-excitation was stopped (Note 1)

2: A limit speed is calculated when hoisting. When lowering, the speed is limited by the result of the previous hoisting calculation.

However, when one of the following condition obtains, the lowering speed is limited by the rated speed.

- 1) The initial operation after powering on is lowering.
- 2) A limit speed was not calculated for the previous hoisting operation.
⇒ The previous hoisting took place at a speed under the H226 limit speed discrimination interval (end speed)
- 3) Lowering was performed after pre-excitation was stopped (Note 1)

Note 1: If the pre-excitation signal is turned OFF first when switching from pre-excitation operation to speed control operation (FWD/REV ON), condition (3) will obtain and the previous hoisting limit speed will be cleared. Use a sequence in which the pre-excitation signal is turned off after the run command is input, as shown below.



H228 Load Inertia Magnification Setting

H228 switches the magnification of "Load inertia" settings (H51, H52, H127, H202, H205, H208 and H211) and that of "Load adaptive control, Rated load" setting (H66).

H 2 2 8 I N R T 1 0

- Setting: 0 x 1 (0.001 to 50.000 kg•m²)
 1 x 10 (0.01 to 500.00 kg• m²)
 2 x 100 (0.1 to 5,000.0 kg• m²)

| | |
|------------|---|
| H322, H325 | Notch Filters 1 and 2 (Resonance frequency) |
| H323, H326 | Notch Filters 1 and 2 (Attenuation level) |
| H324, H327 | Notch Filters 1 and 2 (Frequency range) |

Set this to dampen resonance in the mechanical system. A maximum of 2 resonance points can be dampened. The notch filter functions take effect only when motor M1 is selected. (No effect for M2 or M3.)

| | | | | | | | | | | | | | |
|---|---|---|---|---|---|---|---|---|---|---|--|--|--|
| H | 3 | 2 | 2 | N | F | 1 | - | F | R | Q | | | |
| H | 3 | 2 | 5 | N | F | 2 | - | F | R | Q | | | |

Setting: 10 to 2,000 Hz

The notch filter frequency is limited internally based on the setting of F26 "carrier frequency". Carrier frequencies and corresponding notch filter setting ranges are shown below. If the setting exceeds the upper limit, the upper limit is applied.

- 2 kHz, 5 kHz, 10 kHz, 11 kHz : 10 to 2000 Hz
- 4 kHz, 7 kHz, 8 kHz, 9 kHz, 15 kHz : 10 to 1500 Hz
- 3 kHz, 6 kHz, 12 kHz, 13 kHz, 14 kHz : 10 to 1000 Hz

| | | | | | | | | | | | | | |
|---|---|---|---|---|---|---|---|---|---|---|--|--|--|
| H | 3 | 2 | 3 | N | F | 1 | - | A | T | T | | | |
| H | 3 | 2 | 6 | N | F | 2 | - | A | T | T | | | |


Setting: 0 to 40 dB (Setting "0" disables the notch filter function.)

| | | | | | | | | | | | | | |
|---|---|---|---|---|---|---|---|---|---|---|--|--|--|
| H | 3 | 2 | 4 | N | F | 1 | - | W | I | D | | | |
| H | 3 | 2 | 7 | N | F | 2 | - | W | I | D | | | |

Setting: 0 to 3

Setting method

Set a notch filter frequency, attenuation, and width appropriate for the resonance point in the machine. Four increments are available for the width setting. A larger setting allows a wider frequency band to be covered. Normally a setting of "2" is recommended.



| |
|--|
| ⚠ CAUTION |
| <ul style="list-style-type: none"> Setting an attenuation that is too large may cause unstable control. Do not set higher than necessary. |

4.3.6 A codes (Alternative Motor Functions)

A codes are motor parameters that become available when motor M2 or M3 is selected. These codes are used when a single FRENIC-VG drives two or three motors while switching them.

Any of M1 to M3 can select vector control or V/f control.

| | |
|--------------|------------------|
| A01 to A61 | M2 Drive Control |
| A101 to A161 | M3 Drive Control |

To select M2 or M3, use F79 (Motor Selection) and terminal input signals *M-CH2* and *M-CH3*.

See the individual descriptions and check in Menu #4 "I/O checking" that M2 or M3 is selected. ■ indicates "selected". Check that ■M2 or ■M3 is indicated.

A01 to A61 for M2 are functionally equivalent to A101 to A161 for M3 except that codes differ by one hundred. Those codes are functionally equivalent to P codes (M1).

| |
|---------------------|
| 1500 |
| □ PARA 1 □ M1 □ JOG |
| □ PARA 2 ■ M2 |
| □ PARA 3 □ M3 |
| □ PARA 4 |
| ▲ V → PAGE SHIFT 8 |

There are no P02-equivalent code for M2 and M3, so M2 and M3 motor parameters cannot be set automatically. For FRENIC-VG dedicated motors or VG series conventional motors, this manual provides motor parameters. Set them manually. For other motors, perform auto-tuning.

Auto-tuning initiated by H01 applies to the currently selected motor.

Function codes to be configured for IM under vector control

The table below lists the function codes to be configured for IM when vector control is selected. Configure them sequentially from the top of the table. (For details, refer to P02 (M1 Motor Selection)).

| Function codes | | | |
|----------------|----------|------------|--|
| M1 | M2 | M3 | Name |
| P01 | A01 | A101 | Drive control |
| P02 | - | - | Motor selection |
| F04 | A05 | A105 | Rated speed |
| F05 | A04 | A104 | Rated voltage |
| P03 | A02 | A102 | Rated capacity |
| P04 | A03 | A103 | Rated current |
| P05 | A07 | A107 | No. of poles |
| P06 | A08 | A108 | %R1 |
| P07 | A09 | A109 | %X |
| P08 | A10 | A110 | Magnetic flux weakening current |
| P09 | A11 | A111 | Torque current |
| P10, P11 | A12, A13 | A112, 113 | Slip frequency of motor for driving and braking |
| P12-P14 | A14-A16 | A114-A116 | Iron loss factors 1-3 |
| P15-P19 | A17-A21 | A117-A121 | Magnetic saturation factors 1-5 |
| P20 | A22 | A122 | Secondary time constant |
| P21 | A23 | A123 | Induced voltage factor |
| P22-P24 | A24-A26 | A124-A126 | R2 correction factors 1-3 |
| P25 | A27 | A127 | Exciting current correction factor |
| P26, P27 | A28, A29 | A128, A129 | ACR P-gain, Integral constant |
| P28 | A30 | A130 | Pulse resolution |
| P30 | A31 | A131 | Thermistor selection |
| F10 | A32 | A132 | Electronic thermal overload protection (Select motor characteristics) |
| H01 | H01 | H01 | Auto-tuning |

Note 1: FRENIC-VG dedicated motors are the same as the VG7 or VG5 standard motors in shape and electrical constants (motor parameters).

Function codes to be configured for PMSM under vector control

The table below lists the function codes to be configured for PMSM when vector control is selected. Configure them sequentially from the top of the table.

| | | | Function codes |
|----------|----------|------------|--|
| M1 | M2 | M3 | Name |
| P01 | A01 | A101 | Drive control |
| P03 | A02 | A102 | Rated capacity |
| P04 | A03 | A103 | Rated current |
| F05 | A04 | A104 | Rated voltage |
| F04 | A05 | A105 | Rated speed |
| F03 | A06 | A106 | Maximum speed |
| P05 | A07 | A107 | No. of poles |
| P06 | A08 | A108 | %R1 |
| P07 | A09 | A109 | %X |
| P08 | A10 | A110 | d-axis current |
| P09 | A11 | A111 | q-axis current |
| P21 | A23 | A123 | Induced voltage factor |
| P26, P27 | A28, A29 | A128, A129 | ACR P-gain, Integral constant |
| P28 | A30 | A130 | Pulse resolution |
| P30 | A31 | A131 | Thermistor selection |
| F10 | A32 | A132 | Electronic thermal overload protection (Select motor characteristics) |
| P33 | A53 | A153 | Maximum voltage Limit |
| o09 | A59 | A159 | Absolute signal input definition |
| o10 | A60 | A160 | Magnetic pole position offset |
| o11 | A61 | A161 | Salient pole rate (%Xq/%Xd) |
| P42 | A62 | A162 | q-axis induction magnetic saturation coefficient |
| P43 | A63 | A163 | Magnetic flux limiting value |
| P44 | A64 | A164 | Overcurrent protection level |
| P45-P51 | A65-A71 | A165-A171 | Torque correction gain 1 to 7 |

Function codes to be configured for IM under V/f control

The table below lists the function codes to be configured for IM when V/f control is selected. Configure them sequentially from the top of the table.

| | | | Function codes |
|-----|-----|------|--|
| M1 | M2 | M3 | Name |
| P01 | A01 | A101 | Drive control |
| P03 | A02 | A102 | Rated capacity |
| P04 | A03 | A103 | Rated current |
| F03 | A04 | A104 | Maximum speed |
| F04 | A05 | A105 | Rated speed |
| F05 | A06 | A106 | Rated voltage |
| P05 | A07 | A107 | No. of poles |
| P06 | A08 | A108 | %R1 |
| P07 | A09 | A109 | %X |
| P08 | A10 | A110 | Magnetic flux weakening current |
| P33 | A53 | A153 | Maximum voltage Limit |
| P34 | A54 | A154 | Slip compensation |
| P35 | A55 | A155 | Torque boost |
| P30 | A31 | A131 | Thermistor selection |
| F10 | A32 | A132 | Electronic thermal overload protection (Select motor characteristics) |
| H01 | | | Auto-tuning |
| H02 | | | Save all function |

4.3.7 o codes (Option Functions)

OPC-VG1-DIA, DIB

Use this option to specify the digital speed command, torque limiter value, torque command, and torque current command. When you install two option cards, you use hardware switches to distinguish them as DIA and DIB. See the control option section for more details.

| | |
|------------|-------------------------------|
| o01 | DIA Function Selection |
| o02 | DIB Function Selection |

Select the data format for the digital speed command, torque limiter value, torque command, and torque current command.

| | | | | | | | | | | | |
|---|---|---|---|---|---|---|---|---|---|--|--|
| o | 0 | 1 | D | I | A | F | U | N | C | | |
| o | 0 | 2 | D | I | B | F | U | N | C | | |

- 1) See the function description of the function code F01 "Speed setting N1" to use for the speed command.
- 2) See the function description of the function code F42 "Torque limiter value selection" to use for the torque limiter value.
- 3) See the function description of the function code H41 "Torque command selection" to use for the torque command.
- 4) See the function description of the function code H42 "Torque current command selection" to use for the torque current command.

Set value: 0 or 1
 0: Binary
 1: BCD

| | |
|------------|------------------------------------|
| o03 | DIA BCD Input Speed Setting |
| o04 | DIB BCD Input Speed Setting |

Specify BCD data for setting the maximum speed of DIA and DIB inputs. Use when you want to enter "machine operation speed" directly to specify input data.

| | | | | | | | | | | |
|---|---|---|---|---|---|---|---|---|---|---|
| o | 0 | 3 | B | C | D | C | M | N | D | A |
| o | 0 | 4 | B | C | D | C | M | N | D | B |

Data setting range: 99 to 7,999

OPC-VG1-PG/PGo

Use this option for the following applications.

- 1) Place the switch in the PD position to use position control (orientation) through pulse calculation.
- 2) Set the switch to LD to detect the line speed.
- 3) Place the switch in the PR position to use the pulse train synchronous operation.
- 4) Place the switch in the SD position to use for speed detection.

⚠ CAUTION

The model of the PG interface option varies according to the difference in the electric specification.
 OPC-VG1-PG: 5V line driver
 OPC-VG1-PGo: Open collector, voltage output

| | |
|------------|--|
| o05 | PG (PD) Option Setting (Feedback pulse) |
|------------|--|

Switches the source of the position detection signal between the integrated PG and the optional PG interface card. Use for synchronous operation and the position control for orientation.

| | | | | | | | | | | |
|---|---|---|---|---|---|---|---|---|---|---|
| o | 0 | 5 | P | L | S | F | E | D | S | L |
|---|---|---|---|---|---|---|---|---|---|---|

Data setting range: 0 (Integrated PG (15, 12V complementary output)
(PG interface card OPC-VG1-PMPG for PMSM drive))

1 (PG interface card OPC-VG1-PG (PD) (5V line driver output))

2 (High-resolution serial PG interface card OPC-VG1-SPGT) (Available soon)

When function code P01, A01, A101 (M1/M2/M3 Drive Control) = 3 (Vector control of PMSM) and the PG interface card OPC-VG1-PMPG for PMSM drive is mounted, setting o05 at "0" enables signals to the OPC-VG1-PMPG.

| | |
|------------|--|
| o06 | PG (PD) Option Setting (Digital line speed detection definition, PG pulses) |
|------------|--|

| | |
|------------|---|
| o07 | PG (PD) Option Setting (Digital line speed detection definition, Detection pulse correction 1) |
|------------|---|

| | |
|------------|---|
| o08 | PG (PD) Option Setting (Digital line speed detection definition, Detection pulse correction 2) |
|------------|---|

Specify to use the PG (LD) option for line speed control. A PG disconnection activates a protective function (P_{G} alarm).

The pulse correction is for speed detection. $Speed = (Correction\ 1 / Correction\ 2) \times Input\ pulse$

| | | | | | | | | | | | |
|---|---|---|---|---|---|---|---|---|---|---|---|
| o | 0 | 6 | L | S | - | P | G | D | E | F | |
| o | 0 | 7 | L | S | - | P | L | S | C | P | 1 |
| o | 0 | 8 | L | S | - | P | L | S | C | P | 2 |

Data setting range: o06 = 100 to 60,000 (P/R)

o07, o08 = 1 to 9,999

| | |
|-------------|--|
| o09 | M1 Absolute Signal Input Definition |
| A59 | M2 ABS Signal Input Definition |
| A159 | M3 ABS Signal Input Definition |

These function codes are exclusive to PMSM. They select the interface system of encoder ABS signals.

| | | | | | | | | | | | | |
|----------|----------|----------|----------|----------|----------|----------|----------|----------|----------|----------|----------|----------|
| o | 0 | 9 | M | 1 | - | A | B | S | D | E | F | |
| A | 5 | 9 | M | 2 | - | A | B | S | D | E | F | |
| A | 1 | 5 | 9 | M | 3 | - | A | B | S | D | E | F |

Data setting range: 0 (1 bit (terminal: F0). Z-phase interface)

1 (3 bits (terminals: F0, F1 and F2). U-/V-/W-phase interface)

2 (4 bits (terminals: F0, F1, F2 and F3). Gray code interface)

3 to 5 (Not used.)

6 (SPGT 17-bit serial interface)

7 to 16 (Not used.)

| | |
|-------------|---|
| o10 | M1 Magnetic Pole Position Offset |
| A60 | M2 Magnetic Pole Position Offset |
| A160 | M3 Magnetic Pole Position Offset |

These function codes are exclusive to PMSM. They define an offset value relative to the encoder reference position and actual motor magnetic pole position.

| | | | | | | | | | | | |
|----------|----------|----------|----------|----------|----------|----------|----------|----------|----------|----------|----------|
| o | 1 | 0 | M | 1 | - | S | M | O | F | S | |
| A | 6 | 0 | M | 2 | - | S | M | O | F | S | |
| A | 1 | 6 | 0 | M | 3 | - | S | M | O | F | S |

Data setting range: 0.0 to 359.9 CCW

Enter the offset value printed on the corresponding motor test report or adjust the magnetic pole position according to the adjustment procedure.

| | |
|-------------|--|
| o11 | M1 Salient Pole Rate (%Xq/%Xd) |
| A61 | M2 Salient Pole Ratio (%Xq/%Xd) |
| A161 | M3 Salient Pole Ratio (%Xq/%Xd) |

These function codes are exclusive to PMSM. They specify the difference in reactance due to the difference in magnetic resistance on the q axis and the d axis in terms of the ratio of the q axis value/d axis value.

| | | | | | | | | | | | |
|----------|----------|----------|----------|----------|----------|----------|----------|----------|----------|----------|----------|
| o | 1 | 1 | M | 1 | - | X | q | / | X | d | |
| A | 6 | 1 | M | 2 | - | X | q | / | X | d | |
| A | 1 | 6 | 1 | M | 3 | - | X | q | / | X | d |

Data setting range: 1.000 to 5.000

To drive an SPM motor, set 1,000.

It is necessary to calculate the salient pole ratio from the design value of each motor. When the design value is unknown, contact your Fuji Electric representative.

o12**Command Pulse Selection**

o12 selects a command pulse source.

| | | | | | | | | | | |
|-----------------------|---|---|---|---|---|---|---|---|---|---|
| <input type="radio"/> | 1 | 2 | P | L | S | R | E | F | S | L |
|-----------------------|---|---|---|---|---|---|---|---|---|---|

Data setting range: 0 (PG (PR) option)
1 (Internal speed command)

For details, see the control block diagram given in Section 4.1.5.

o13**Pulse Train Input Form**

Select the input form of the signal supplied to the PG (PR) option.

| | | | | | | | | | | |
|-----------------------|---|---|---|---|---|---|---|---|---|---|
| <input type="radio"/> | 1 | 3 | P | L | S | S | T | A | T | E |
|-----------------------|---|---|---|---|---|---|---|---|---|---|

Data setting range: 0 (90° phase difference between phases A and B)
1 (Phase A: Command pulse, Phase B: Command code (sign))
2 (Phase A: Forward pulse, Phase B: Reverse pulse)

This pulse configuration choice takes effect only against the pulse train command (PG (PR)).
Line speed detection (PG (LD)) with 90° phase difference only can be received.

o14**Command Pulse Correction 1****o15****Command Pulse Correction 2**

Set when you install the PG (PR) option card to conduct synchronized operation. You can change the position command data entered into the pulse train card to change the speed ratio between the master motor and the slave motor.

| | | | | | | | | | | |
|-----------------------|---|---|---|---|---|---|---|---|---|---|
| <input type="radio"/> | 1 | 4 | P | L | S | C | O | R | R | 1 |
| <input type="radio"/> | 1 | 5 | P | L | S | C | O | R | R | 2 |

Data setting range: 1 to 9,999

Internal data = Input pulse × (Pulse correction 1/Pulse correction 2)

o16**APR Gain 1**

You can specify a data to improve the position control response in pulse train operation. You can also reduce the steady-state deviation in the steady-state operation. Since too large setting may present a motor hunting, increase gradually from a small value to adjust.

| | | | | | | | | | | | | |
|-----------------------|---|---|---|---|---|---|---|---|---|---|---|---|
| <input type="radio"/> | 1 | 6 | A | P | R | - | P | - | G | A | I | N |
|-----------------------|---|---|---|---|---|---|---|---|---|---|---|---|

Data setting range: 0.1 to 999.9

o17**Feedforward Gain 1**

The setting can reduce the steady-state deviation. The setting of 1.0 provides the smallest deviation. You do not have to change from 0.0 in general.

| | | | | | | | | | |
|---|---|---|---|---|---|---|---|---|---|
| o | 1 | 7 | F | / | F | G | A | I | N |
|---|---|---|---|---|---|---|---|---|---|

Data setting range: 0.0 to 1.5

o18**Overdeviation Width**

The difference (deviation) between the internal position command and actual motor revolutions exceeds 10 folds of this setting, an "excessive deviation alarm (\square)" is caused, letting the motor coast to stop.

| | | | | | | | | | | |
|---|---|---|---|---|---|---|---|---|---|---|
| o | 1 | 8 | D | E | V | O | V | E | R | W |
|---|---|---|---|---|---|---|---|---|---|---|

Data setting range: 0 to 65,535

o19**Zero Deviation Width**

When the current position of the motor comes into this range of a reference position, the inverter provides the "zero deviation" signal. You can use the zero deviation signal to detect that the motor locates almost at the target position. The inverter provides the zero deviation signal on the DO to which you can assign a function.

| | | | | | | | | | | |
|---|---|---|---|---|---|---|---|---|---|---|
| o | 1 | 9 | D | E | V | Z | E | R | O | W |
|---|---|---|---|---|---|---|---|---|---|---|

Data setting range: 0 to 1,000

o20**APR Gain 2 (Available soon)****o21****F/F Gain 2 (Available soon)**

o20 and o21 are functionally equivalent to o16 (APR Gain 1) and o17 (F/F Gain 1), respectively.

| | | | | | | | | | | |
|---|---|---|---|---|---|---|---|---|---|---|
| o | 2 | 0 | A | P | R | G | A | I | N | 2 |
|---|---|---|---|---|---|---|---|---|---|---|

Data setting range: 0.1 to 999.9

| | | | | | | | | | | |
|---|---|---|---|---|---|---|---|---|---|---|
| o | 2 | 1 | F | / | F | G | A | I | N | 2 |
|---|---|---|---|---|---|---|---|---|---|---|

Data setting range: 0.0 to 1.5

o22 Position Control Gain Switching (Available soon)

o22 specifies a factor that switches between gain 1 (o16, o17) and gain 2 (o20, o21) of the APR and F/F in a position control system.

Switching the gain can reduce noise or vibration at the time of a stop under position control.

o 2 2 G A I N S E L

Data setting range: 0 (Disable)

1 (Positional deviation (x 10))

2 (Detected speed (10,000/maximum speed))

3 (Speed command (10,000/maximum speed))

When o22 = 0 (Disable), o16 (APR Gain 1) and o17 (F/F Gain 1) take effect.

o23 Position Control Gain Switching Level (Available soon)

o24 Position Control Gain Switching Time (Available soon)


If the detected value of a factor selected by o22 drops below the switching level specified by o23, the APR and F/F gains are switched from 1 to 2 in accordance with the switching time specified by o24. The hysteresis width is 1% of the maximum speed (Setting: 10,000).

o 2 3 S E L L V L

Data setting range: 0 to 10,000

In gain switching, the function codes are selected as follows.

| | APR gain | F/F gain |
|--------------------------|----------|----------|
| Switching level or above | o16 | o17 |
| Switching level or below | o20 | o21 |



o30 Link Option Configuration (Communications error processing)

o30 specifies error processing to be performed if a communications link error occurs.

o 3 0 M O D E O N E R

Data setting range: 0 to 3

0 (Immediately trip with $\overline{E}r\text{-}4$.)

1 (Continue to run for the time specified by o31 and then trip with $\overline{E}r\text{-}4$.)

2 (If a communications error has persisted for the time specified by o31, trip with $\overline{E}r\text{-}4$.)

3 (Continue to run even if a communications error occurs. Removing the error factor automatically restores the run command transferred via the communication link.)

o31**Link Option Configuration (Timer)**

If a communications link error occurs and persists during the period specified by o31, the inverter causes an alarm.

| | | | | | | | | | |
|---|---|---|---|---|---|---|---|---|---|
| o | 3 | 1 | T | I | M | E | R | T | L |
|---|---|---|---|---|---|---|---|---|---|

Data setting range: 0.01 to 20.00 (s)

o32**Link Option Configuration (Link format selection)**

o32 specifies the link format to be used by a link option (OPC-VG1-TL, OPC-VG1-CCL).

The setting content differs depending on options. For details, refer to Chapter 6, Section 6.4 "T-Link Interface Card" and Section 6.7 "CC-Link Interface Card."

| | | | | | | | | | | | |
|---|---|---|---|---|---|---|---|---|---|---|---|
| o | 3 | 2 | F | O | R | M | A | T | S | E | L |
|---|---|---|---|---|---|---|---|---|---|---|---|

Data setting range: 0 to 4

- 0 (Link format 1)
- 1 (Link format 2)
- 2 (Link format 3)
- 3 (Link format 4)
- 4 (Link format 5)

OPC-VG1-TBSI

Using this option can connect two or more inverters via the high-speed serial communications link, enabling multiwinding motors or motors in direct parallel connection to be driven.

o33**Multiplex System (Control mode)**

o33 specifies one of the following multiplex systems.

Refer to *MT-CCL* (Cancel multiplex system) in the description of E01 to E13 (Terminal X Function).

| | | | | | | | | | | | |
|---|---|---|---|---|---|---|---|---|---|---|---|
| o | 3 | 3 | M | W | S | A | C | T | I | V | E |
|---|---|---|---|---|---|---|---|---|---|---|---|

- Data setting range: 0 (Disable (single motor operation))
- 1 (Multiwinding motor control system)
 - 2 (Multiplex system 1) (Direct parallel connection) *
 - 3 (Multiplex system 2) (Not used.)
 - 4 (Reserved 1)
 - 5 (Reserved 2)

* Available in the ROM version H1/2 0020 or later.

o34**Multiplex System (No. of slave stations)**

Specifies the number of slave stations for the multiplex system.

| | | | | | | | | | | | |
|---|---|---|---|---|---|---|---|---|---|---|---|
| o | 3 | 4 | M | W | S | S | L | A | V | E | S |
|---|---|---|---|---|---|---|---|---|---|---|---|

Data setting range: 1 to 5

o50

Multiplex System (Station number assignment)

o50 assigns the station number of the multiplex system (High-speed serial communications terminal block OPC-VG1-TBS1).

| | | | | | | | | | | |
|---|---|---|---|---|---|---|---|---|---|---|
| o | 5 | 0 | M | W | S | S | T | - | N | O |
|---|---|---|---|---|---|---|---|---|---|---|

Data setting range: 0 (Master)
1 to 5 (Slave)

4.3.8 L codes (Lift Functions)






| | |
|-----|-----------------|
| L01 | Password Data 1 |
| L02 | Password Data 2 |

⚠ CAUTION

Handle the password with care. If you set the password by mistake, you cannot refer to or change the function code. The person who is responsible for specifying the password must manage the password carefully.

You can specify an 8-digit password by combining L01 and L02. You can use the password to restrict the change and the reference to the function codes. When you specify a non-zero value to either L01 or L02, the restriction by password will become effective.

Password setting procedure

Change the current value to an arbitrary value by pressing the  and  keys or  and  keys simultaneously, and then press the  key to establish it.

| | | | | | | | | | | | |
|---|---|---|---|---|---|---|---|---|---|---|---|
| L | 0 | 1 | P | A | S | S | W | O | R | D | 1 |
| L | 0 | 2 | P | A | S | S | W | O | R | D | 2 |

Setting range: 0 to 9,999

Setting password

When you set non-zero data to L01 or L02 and open the program menu, you will not view "1. Set data" and "2. Check data", but "3. Operation monitor" and the rest. See the figure right below.


Usual program menu screen
(password is not specified or is disabled)

| | |
|-----|------------|
| 0. | LANGUAGE |
| 1. | DATA SET |
| 2. | DATA CHECK |
| 3. | OPR MNTR |
| 4. | I/O CHECK |
| 5. | MAINTENANC |
| 6. | LOAD FCTR |
| 7. | ALM INF |
| 8. | ALM CAUSE |
| 9. | COMM INFO |
| 10. | DATA COPY |
| 11. | CHANGES |
| 12. | DATE/TIME |
| 13. | FORMER INV |
| 14. | LIMITED FC |

Program menu screen
when password is enabled


| | |
|----|------------|
| 3. | OPR MNTR |
| 4. | I/O CHECK |
| 5. | MAINTENANC |
| 6. | LOAD FCTR |
| 7. | ALM INF |
| 8. | ALM CAUSE |
| 9. | COMM INFO |

To disable password (ex. password: L01=10, L02=20)



Note: Canceling password described above will become ineffective after you turn off the inverter

To enable password again after disabled



L03**Lift Rated Speed**

This function code is necessary to calculate the estimated travel distance on deceleration.


L 0 3 L I F T - B A S E

Setting range: 0.0 to 999.9 (m/min)

About the estimated travel distance on deceleration

You can display an estimated travel distance from the deceleration start point to the stopping point to check the consistency of the decelerating pattern.

The estimated travel distance on deceleration is an addition of travel distance on deceleration from the lift operation speed to the creep speed and that from the creep speed to the zero speed and does not include the travel distance by the constant operation at the creep speed (L1, L2, L3 in the graph below).



The estimated travel distance on deceleration appears on the "Option monitor 3, 4" on the LED monitor of the KEYPAD panel.

This function is effective when L04=1 or 2.

Option monitor 3: Travel distance from the operation speed 1 after deceleration operation.

Option monitor 4: Travel distance from the operation speed 2 after deceleration operation.

Function data codes used for the estimated travel distance on deceleration.

| Description | L04=1 | | L04=2 | |
|--|-------|---|-------|-------------------|
| | Code | Name | Code | Name |
| Lift rated speed | L03 | Lift rated speed | ← | ← |
| Operation speed 1 | C09 | Multistep speed 5 | ← | ← |
| Operation speed 2 | C11 | Multistep speed 7 | C10 | Multistep speed 6 |
| Creep speed | C07 | Multistep speed 3 | ← | ← |
| Deceleration time from operation speed 1 | F08 | Deceleration time 1 | ← | ← |
| Deceleration time from operation speed 2 | C47 | Deceleration time 2 | ← | ← |
| Deceleration time from creep speed | C36 | Deceleration time JOG | ← | ← |
| S-curve setting on decelerating from operation speed 1 | L10 | S-curve 6 | ← | ← |
| S-curve setting on decelerating from operation speed 2 | L12 | S-curve 8 | ← | ← |
| S-curve setting on reaching creep speed | L07 | S-curve 3 | ← | ← |
| S-curve setting on decelerating from creep speed | L08 | S-curve 4 | ← | ← |
| S-curve setting on reaching zero speed | L06 | S-curve 2 | ← | ← |
| Delay time by the speed reference agreement timer | C20 | Multistep speed reference agreement timer | ← | ← |

| | |
|------------|-------------------------------|
| L04 | Preset S-curve Pattern |
|------------|-------------------------------|

Specifies the application of S-curve setting and the multistep speed.

L 0 4 S - C U R V E

Setting range: 0 to 2

- 0: FRENIC-VG standard (VG7S-compatible) multistep speed and S-curve setting
 15 steps of multistep speed (C05 to C19)
 S-curve applied to four sections (F67 to F70)
- 1: Lift application compatible with VG3N and VG5N
 7 steps of multistep speed (C05 to C11)
 S-curve applied to eight sections (L05 to L12)
- 2: FRENIC-VG (VG7S-compatible) lift application original mode
 7 steps of multistep speed (C05 to C11)
 S-curve applied to ten sections (L05 to L14)

| | |
|-------------------|---------------------------------|
| L05 to L14 | S-curve Patterns 1 to 10 |
|-------------------|---------------------------------|

L 0 5 S - C R V S E T 1

↓

L 1 4 S - C R V S E 1 0

Setting range: 0 to 50 (%)

Introduction to an operation example in each mode

(A) FRENIC-VG standard (VG7S-compatible) multistep speed and S-curve setting

Since this operation mode uses the standard multistep speed and the S-curve, see the description of the individual function codes.

(B) Lift application compatible with VG3N and VG5N

Set ON/OFF to the terminal functions *SS1*, *SS2*, and *SS4* to switch the multistep speed as described in the following table.

| Terminal function | | | Multistep speed setting | | |
|-------------------|-----|-----|-------------------------|-------------------|-----------------------------|
| SS4 | SS2 | SS1 | Code | Name | Description |
| OFF | OFF | OFF | — | — | External speed setting |
| OFF | OFF | ON | C05 | Multistep speed 1 | Zero speed |
| OFF | ON | OFF | C06 | Multistep speed 2 | Inching speed |
| OFF | ON | ON | C07 | Multistep speed 3 | Creep speed |
| ON | OFF | OFF | C08 | Multistep speed 4 | Maintenance operation speed |
| ON | OFF | ON | C09 | Multistep speed 5 | Operation speed 7 |
| ON | ON | OFF | C10 | Multistep speed 6 | Zero speed |
| ON | ON | ON | C11 | Multistep speed 7 | Operation speed 2 |


The following table shows how the acceleration/deceleration times are assigned to the multistep speed.

| Speed | | | Acceleration | | Deceleration | |
|-------|-------------------|-----------------------------|--------------|-----------------------|--------------|-----------------------|
| Code | Name | Description | Code | Name | Code | Name |
| C06 | Multistep speed 2 | Inching speed | F07 | Acceleration time 1 | F08 | Deceleration time 1 |
| C07 | Multistep speed 3 | Creep speed | C35 | Acceleration time JOG | C36 | Deceleration time JOG |
| C08 | Multistep speed 4 | Maintenance operation speed | F07 | Acceleration time 1 | F08 | Deceleration time 1 |
| C09 | Multistep speed 5 | Operation speed 1 | F07 | Acceleration time 1 | F08 | Deceleration time 1 |
| C11 | Multistep speed 7 | Operation speed 2 | C46 | Acceleration time 2 | C47 | Deceleration time 2 |


The following table shows how S-curve setting is applied to the multistep speed.

| S curve setting | | Application |
|-----------------|-----------|---|
| Code | Name | |
| L05 | S-curve 1 | Acceleration start side from Zero speed |
| L06 | S-curve 2 | Deceleration end side to Zero speed |
| L07 | S-curve 3 | Acceleration end side to Creep speed |
| L08 | S-curve 4 | Deceleration start side from Creep speed |
| L09 | S-curve 5 | Acceleration end side to Operation speed 1, Maintenance operation speed, or Inching speed |
| L10 | S-curve 6 | Deceleration start side from Operation speed 1, Maintenance operation speed, or Inching speed |
| L11 | S-curve 7 | Acceleration end side to Operation speed 2 |
| L12 | S-curve 8 | Deceleration start side from Operation speed 2 |


(1) Operation speed 1




(2) Operation speed 2



(3) Maintenance operation speed



(4) Inching speed



(C) FRENIC-VG (VG7S-compatible) lift application original mode

Set ON/OFF to the terminal functions *SS1*, *SS2*, and *SS4* to switch the multistep speed as described in the following table.

| Terminal function | | | Multistep speed setting | | |
|-------------------|-----|-----|-------------------------|-------------------|-----------------------------|
| SS4 | SS2 | SS1 | Code | Name | Description |
| OFF | OFF | OFF | — | — | Zero speed |
| OFF | OFF | ON | C05 | Multistep speed 1 | Emergency lift speed |
| OFF | ON | OFF | C06 | Multistep speed 2 | Inching speed |
| OFF | ON | ON | C07 | Multistep speed 3 | Creep speed |
| ON | OFF | OFF | C08 | Multistep speed 4 | Maintenance operation speed |
| ON | OFF | ON | C09 | Multistep speed 5 | Operation speed 1 |
| ON | ON | OFF | C10 | Multistep speed 6 | Operation speed 2 |
| ON | ON | ON | C11 | Multistep speed 7 | Operation speed 3 |


The following table shows how the acceleration/deceleration times are assigned to the multistep speed.

| Speed | | | Acceleration | | Deceleration | |
|-------|-------------------|-----------------------------|--------------|-----------------------|--------------|-----------------------|
| Code | Name | Description | Code | Name | Code | Name |
| C05 | Multistep speed 1 | Emergency lift speed | C56 | Acceleration time 3 | C57 | Deceleration time 3 |
| C06 | Multistep speed 2 | Inching speed | F07 | Acceleration time 1 | F08 | Deceleration time 1 |
| C07 | Multistep speed 3 | Creep speed | C35 | Acceleration time JOG | C36 | Deceleration time JOG |
| C08 | Multistep speed 4 | Maintenance operation speed | F07 | Acceleration time 1 | F08 | Deceleration time 1 |
| C09 | Multistep speed 5 | Operation speed 1 | F07 | Acceleration time 1 | F08 | Deceleration time 1 |
| C10 | Multistep speed 6 | Operation speed 2 | C46 | Acceleration time 2 | C47 | Deceleration time 2 |
| C11 | Multistep speed 7 | Operation speed 3 | C56 | Acceleration time 3 | C57 | Deceleration time 3 |


The following table shows how S-curve setting is applied to the multistep speed.

| S curve setting | | Application |
|-----------------|------------|---|
| Code | Name | |
| L05 | S-curve 1 | Acceleration start side from Zero speed |
| L06 | S-curve 2 | Deceleration end side to Zero speed |
| L07 | S-curve 3 | Acceleration end side to Creep speed |
| L08 | S-curve 4 | Deceleration start side from Creep speed |
| L09 | S-curve 5 | Acceleration end side to Operation speed 1, Maintenance operation speed, or Inching speed |
| L10 | S-curve 6 | Deceleration start side from Operation speed 1, Maintenance operation speed, or Inching speed |
| L11 | S-curve 7 | Acceleration end side to Operation speed 2 |
| L12 | S-curve 8 | Deceleration start side from Operation speed 2 |
| L13 | S-curve 9 | Acceleration end side to Operation speed 3 or Emergency lift speed |
| L14 | S-curve 10 | Deceleration start side from Operation speed 3 or Emergency lift speed |


(1) Operation speed 1




(2) Operation speed 2




(3) Operation speed 3




(4) Emergency lift speed




(5) Maintenance operation speed



(6) Inching speed



How to calculate acceleration/deceleration times and travel distance



[Description of symbols]

- Nmax (r/min): Maximum motor speed
- N1 (r/min): Speed reference before acceleration (after deceleration)
- N2 (r/min): Speed reference after acceleration (before deceleration)
- S1 (%): S-curve portion at the beginning of acceleration (at the end of deceleration)
- S2 (%): S-curve portion at the end of acceleration (at the beginning of deceleration)
- T (s): Acceleration (deceleration) reference time (time from zero to Nmax (Nmax to 0))
- Vmax (m/min): Elevation speed at the maximum motor speed (Maximum elevation speed)
- t (s): Acceleration (deceleration) time
- L (m): Travel distance

1) When the S curve portion fits in a specified speed range $\frac{N2 - N1}{Nmax} \geq \frac{S1 + S2}{100}$

Acceleration (deceleration) time

$$t = \left(\frac{N2 - N1}{Nmax} + \frac{S1 + S2}{100} \right) \times T \text{ [Equation 1]}$$

Travel distance

$$L = \frac{T \times Vmax}{120} \times \left[\frac{S1^2 - S2^2}{30000} + \frac{S2}{50} \times \frac{N2 - N1}{Nmax} + \left(\frac{N2 - N1}{Nmax} \right)^2 \right] + \frac{t \times Vmax}{60} \times \frac{N1}{Nmax} \text{ [Equation 2]}$$

2) When the S curve portion exceeds a specified speed range $\frac{N2 - N1}{Nmax} < \frac{S1 + S2}{100}$

Acceleration (deceleration) time

$$t = \frac{S1 + S2}{50} \sqrt{\frac{N2 - N1}{Nmax} \times \frac{100}{S1 + S2}} \times T \text{ [Equation 3]}$$

Travel distance

$$L = \left(\sqrt{\frac{N2 - N1}{Nmax} \times \frac{100}{S1 + S2}} \right)^3 \times \frac{T \times Vmax}{90} \times \frac{S1^2 + 2 \times S2^2 + 3 \times S1 \times S2}{10000} \times \frac{t \times Vmax}{60} \times \frac{N1}{Nmax} \text{ [Equation 4]}$$


Chapter 7 APPLICATION EXAMPLES

This chapter gives application examples of the FRENIC-VG series of inverters.

Contents

| | | |
|-----|--|-----|
| 7.1 | Large Crane and Overhead Crane | 7-1 |
| 7.2 | Application to Plants | 7-1 |
| 7.3 | Servo Press: Large Size for Automobiles, Small Size for Machines such as Crimping Terminal Processing Machines | 7-2 |
| 7.4 | Winding Equipment (Paper and Metal) | 7-2 |
| 7.5 | Feeding Part of Semiconductor Manufacturing Device, Wire Saw | 7-3 |
| 7.6 | Test Equipment for Automobiles | 7-3 |
| 7.7 | Shipboard Winch | 7-4 |
| 7.8 | Flying Shear | 7-4 |

7.1 Large Crane and Overhead Crane




High reliability

VG supports your facility with long life service and high reliability. The trace back function allows easy fault diagnosis.

System support

The bus system is supported to allow centralized control of elevation, traverse, and trolley, as well as centralized monitoring of running conditions.

7.2 Application to Plants




Control with high speed and high accuracy

In addition to high speed and high accuracy, VG contributes to stable facility operation with high reliability and long service life. The trace back function makes diagnosing the cause of problems easy when an abnormality arises.

System support

Centralized control and monitoring are achieved by supporting various fieldbuses.

7.3 Servo Press: Large Size for Automobiles, Small Size for Machines such as Crimping Terminal Processing Machines



Position control


The press position is controlled based on an instantaneous position command given by the CNC of the high order.

Control with high responsibility contributes to shortening of the operation cycle.

Precision synchronization control

Large machines are driven with several motors to increase thrust. Precision synchronization control of several inverters and motors using the high-speed bus system can be applied.

7.4 Winding Equipment (Paper and Metal)




Tension control

Tension-type winding control capability with high accuracy torque control has been improved. Dancer-type winding control capability by the speed control with high speed response has been improved.

System support

The controller that calculates winding diameter achieves constant tension control.

7.5 Feeding Part of Semiconductor Manufacturing Device, Wire Saw




Smooth torque characteristic

The smooth drive characteristic in which torque ripple is suppressed contributes to machining quality.

System support

The system has been made simple and highly efficient by connecting and controlling the spindle that drives wires and the small-capacity servo that drives the traverse axis and winding up and off axes in the same bus system.

7.6 Test Equipment for Automobiles




High-speed response control

High-speed rotation and torque control with high response are available for engine and transmission tests.

System support

The system can be supported in cases such as the vehicle body inertia simulation function for a brake test apparatus by combining with the controller.


7.7 Shipboard Winch



High reliability and tension control

Torque is controlled up to extra low speed using the sensorless feature.
Stable drive is maintained against load variation caused by waves.

7.8 Flying Shear



Position control

Position control is performed according to the position command given by the high-order CNC. The machine cuts the blank while moving at the same speed as the blank.

System support

The system is configured by a controller that calculates synchronous operation among the blank feed axis, cutter feed axis and cut axis.

Chapter 8

SELECTING PERIPHERAL EQUIPMENT

This chapter describes how to use a range of peripheral equipment and options, FRENIC-VG's configuration with them, and requirements and precautions for selecting wires and crimp terminals.

Contents

| | | |
|---------|---|------|
| 8.1 | Configuring the FRENIC-VG | 8-1 |
| 8.2 | Selecting Wires and Crimp Terminals | 8-2 |
| 8.3 | Recommended Wires | 8-6 |
| 8.4 | Peripheral Equipment | 8-20 |
| 8.4.1 | Molded case circuit breaker or residual-current-operated protective device/earth leakage circuit breaker/magnetic contactor | 8-20 |
| 8.4.1.1 | Functional overview | 8-20 |
| 8.4.1.2 | Connection example and criteria for selection of circuit breakers | 8-22 |
| 8.4.2 | Surge killer for L-load | 8-26 |
| 8.4.3 | Arrester | 8-27 |
| 8.4.4 | Surge absorber | 8-28 |
| 8.4.5 | Filter capacitor for radio noise reduction | 8-29 |
| 8.5 | Peripheral Equipment Options | 8-30 |
| 8.5.1 | Braking resistors (DBRs) and braking units | 8-30 |
| 8.5.1.1 | Braking resistors (DBRs) | 8-30 |
| 8.5.1.2 | Braking units | 8-30 |
| 8.5.1.3 | Specifications and connection example | 8-31 |
| 8.5.1.4 | External dimensions | 8-42 |
| 8.5.2 | Power regenerative PWM converters (RHC series) | 8-45 |
| 8.5.2.1 | Features | 8-45 |
| 8.5.2.2 | Specifications | 8-46 |
| 8.5.2.3 | Function specifications | 8-48 |
| 8.5.2.4 | Converter configuration | 8-52 |
| 8.5.2.5 | Basic connection diagrams | 8-54 |
| 8.5.2.6 | External dimensions | 8-56 |
| 8.5.2.7 | Generated loss | 8-64 |
| 8.5.3 | DC reactor (DCR) | 8-66 |
| 8.5.4 | AC reactor (ACR) | 8-71 |
| 8.5.5 | Surge suppression unit (SSU) | 8-76 |
| 8.5.6 | Output circuit filter (OFL) | 8-77 |
| 8.5.7 | Radio noise reducing zero phase reactor (ACL) | 8-81 |

| | | |
|---------|--|------|
| 8.5.8 | External cooling attachment..... | 8-82 |
| 8.6 | Battery..... | 8-84 |
| 8.6.1 | Overview of battery..... | 8-84 |
| 8.6.2 | Installing battery | 8-85 |
| 8.6.2.1 | Installing battery (for 22 kW or lower) | 8-85 |
| 8.6.2.2 | Installing battery (for 30 kW or higher) | 8-86 |
| 8.6.3 | Replacing battery | 8-87 |
| 8.6.4 | About marine or air transport of a lithium-metal battery | 8-87 |
| 8.7 | PG Amplifier (Isolated Signal Conditioner)..... | 8-88 |
| 8.7.1 | Recommended Pulse Amplifier Models..... | 8-88 |
| 8.7.2 | Specifications and description of terminals..... | 8-88 |
| 8.7.3 | Notes for connection and use | 8-89 |
| 8.7.3.1 | Connection diagram | 8-89 |
| 8.7.3.2 | Notes for use | 8-89 |
| 8.7.4 | External dimensions..... | 8-89 |

8.1 Configuring the FRENIC-VG

This section lists the names and features of peripheral equipment and options for the FRENIC-VG series of inverters and includes a configuration example for reference.




Figure 8.1 Quick Overview of Options

8.2 Selecting Wires and Crimp Terminals

This section contains information needed to select wires for connecting the inverter to commercial power lines, motor or any of the optional/peripheral equipment. The level of electric noise issued from the inverter or received by the inverter from external sources may vary depending upon wiring and routing. For more information about wiring and noise, refer to Appendix A “Advantageous Use of Inverters (Notes on electrical noise)” and the Fuji Electric technical information "Engineering Design of Panels."

Select wires that satisfy the following requirements:

- Sufficient capacity to flow the rated average current (allowable current capacity).
- Protective coordination with an MCCB or RCD/ELCB with overcurrent protection in the overcurrent zone.
- Voltage loss due to the wiring length is within the allowable range.
- Suitable for the type and size of terminals of the optional equipment to be used.

Recommended wires are listed below. Use these wires unless otherwise specified.

■ 600 V class of vinyl-insulated wires (IV wires)

Use this class of wire for the power circuits. This class of wire is hard to twist, so using it for the control signal circuits is not recommended. Maximum surrounding temperature for this wire is 60°C.

■ 600 V grade heat-resistant PVC insulated wires or 600 V polyethylene insulated wires (HIV wires)

As wires in this class are smaller in diameter and more flexible than IV wires and can be used at a higher surrounding temperature (75°C), they can be used for both of the main power and control signal circuits. To use this class of wire for the control circuits, you need to correctly twist the wires and keep the wiring length for equipment being connected as short as possible.

■ 600 V cross-linked polyethylene-insulated wires

Use this class of wire mainly for power and grounding circuits. These wires are smaller in diameter and more flexible than those of the IV and HIV classes of wires, meaning that these wires can be used to save on space and increase operation efficiency of your power system, even in high temperature environments. Maximum surrounding temperature for this wire is 90°C. The (Boardlex) wire range available from Furukawa Electric Co., Ltd. satisfies these requirements.

■ Shielded-Twisted cables for internal wiring of electronic/electric equipment

Use this category of cables for the control circuits of the inverter so as to prevent the signal lines from being affected by noise from external sources, including the power input/output lines of the inverter themselves. Even if the signal lines are inside the power control panel, always use this category of cables when the length of wiring is longer than normal. Cables satisfying these requirements are the Furukawa's BEAMEX S shielded cables of the XEBV and XEWV ranges.

Currents Flowing through Inverter Terminals


Table 8.1 summarizes average (effective) electric currents flowing across the terminals of each inverter model for ease of reference when selecting peripheral equipment, options and electric wires for each inverter--including supplied power voltage and applicable motor rating.

Table 8.1 Currents Flowing through Inverter

HD (High Duty) mode: Heavy duty load applications
LD (Low Duty) mode: Light duty load applications

| Power supply voltage | Nominal applied motor (kW) | Inverter type | Specifications | 50 Hz, 200 V | | | 60 Hz, 220 V | | |
|----------------------|----------------------------|----------------|----------------|-----------------------|---------|-------------------------|-----------------------|------|-------------------------|
| | | | | Input RMS current (A) | | DC link bus current (A) | Input RMS current (A) | | DC link bus current (A) |
| | | | | DC reactor (DCR) | | | DC reactor (DCR) | | |
| | | | | w/ DCR | w/o DCR | w/ DCR | w/o DCR | | |
| Three-phase 200V | 0.75 | FRN0.75VG1□-2J | HD | 3.2 | 5.3 | 4 | 3 | 4.9 | 3.7 |
| | 1.5 | FRN1.5VG1□-2J | | 6.1 | 9.5 | 7.5 | 5.6 | 8.7 | 6.9 |
| | 2.2 | FRN2.2VG1□-2J | | 8.9 | 13.2 | 11 | 8.1 | 12 | 10 |
| | 3.7 | FRN3.7VG1□-2J | | 15 | 22.2 | 18.4 | 13.6 | 20 | 16.7 |
| | 5.5 | FRN5.5VG1□-2J | | 21.1 | 31.5 | 25.9 | 19 | 28.4 | 23.3 |
| | 7.5 | FRN7.5VG1□-2J | | 28.8 | 42.7 | 35.3 | 26 | 38.5 | 31.9 |
| | 11 | FRN11VG1□-2J | | 42.2 | 60.7 | 51.7 | 38 | 54.7 | 46.6 |
| | 15 | FRN15VG1□-2J | | 57.6 | 80.1 | 70.6 | 52 | 72.2 | 63.7 |
| | 18.5 | FRN18.5VG1□-2J | | 71 | 97 | 87 | 64 | 87.4 | 78.4 |
| | 22 | FRN22VG1□-2J | | 84.4 | 112 | 103 | 76 | 101 | 93.1 |
| | 30 | FRN30VG1□-2J | HD | 114 | 151 | 140 | 103 | 136 | 126 |
| | 37 | | LD | 138 | 185 | 169 | 124 | 167 | 152 |
| | | 45 | FRN37VG1□-2J | HD | 138 | 185 | 169 | 124 | 167 |
| | 55 | | FRN45VG1□-2J | LD | 167 | 225 | 205 | 150 | 203 |
| | | 75 | FRN45VG1□-2J | HD | 167 | 225 | 205 | 150 | 203 |
| | LD | | | 203 | 270 | 249 | 183 | 243 | 224 |
| | 90 | FRN55VG1□-2J | HD | 203 | 270 | 249 | 183 | 243 | 224 |
| | | | LD | 282 | - | 345 | 254 | - | 311 |
| 110 | FRN75VG1□-2J | HD | 282 | - | 345 | 254 | - | 311 | |
| | | LD | 334 | - | 409 | 301 | - | 368 | |
| 110 | FRN90VG1□-2J | HD | 334 | - | 409 | 301 | - | 368 | |
| | | LD | 410 | - | 502 | 369 | - | 452 | |

Note: □ in the inverter model represents an alphabet.



- Inverter efficiency is calculated using values suitable for each inverter model. The input route mean square (RMS) current is calculated according to the following conditions:
[22 kW or below] Power supply capacity 500 kVA, Power supply impedance 5%
[30 kW or above] Power supply capacity and power supply impedance which are calculated using values matching the inverter capacity recommended by Fuji Electric.
- The input RMS current listed in the above table will vary in inverse proportion to the power supply voltage, such as 230 VAC.

Table 8.1 Currents Flowing through Inverter (continued)

HD (High Duty) mode: Heavy duty load applications
 MD (Medium Duty) mode: Medium duty load applications
 LD (Low Duty) mode: Light duty load applications

| Power supply voltage | Nominal applied motor (kW) | Inverter type | Specifications | 50 Hz, 400 V | | | 60 Hz, 440 V | | |
|----------------------|----------------------------|----------------|----------------|-----------------------|---------|-------------------------|-----------------------|------|-------------------------|
| | | | | Input RMS current (A) | | DC link bus current (A) | Input RMS current (A) | | DC link bus current (A) |
| | | | | DC reactor (DCR) | | | DC reactor (DCR) | | |
| | | | | w/ DCR | w/o DCR | w/ DCR | w/o DCR | | |
| Three-phase 400 V | 3.7 | FRN3.7VG1□-4J | HD | 7.5 | 13 | 9.2 | 6.9 | 11.8 | 8.5 |
| | 5.5 | FRN5.5VG1□-4J | | 10.6 | 17.3 | 13 | 9.6 | 15.7 | 11.8 |
| | 7.5 | FRN7.5VG1□-4J | | 14.4 | 23.2 | 17.7 | 13 | 21 | 16 |
| | 11 | FRN11VG1□-4J | | 21.1 | 33 | 25.9 | 19 | 29.8 | 23.3 |
| | 15 | FRN15VG1□-4J | | 28.8 | 43.8 | 35.3 | 26 | 39.5 | 31.9 |
| | 18.5 | FRN18.5VG1□-4J | | 35.5 | 52.3 | 43.5 | 32 | 47.1 | 39.2 |
| | 22 | FRN22VG1□-4J | | 42.2 | 60.6 | 51.7 | 38 | 54.6 | 46.6 |
| | 30 | FRN30VG1□-4J | HD | 57 | 77.9 | 69.9 | 51.4 | 70.2 | 63 |
| | 37 | | LD | 68.5 | 94.3 | 83.9 | 61.8 | 85 | 75.7 |
| | | 45 | FRN37VG1□-4J | HD | 68.5 | 94.3 | 83.9 | 61.8 | 85 |
| | 55 | | FRN45VG1□-4J | LD | 83.2 | 114 | 102 | 75 | 103 |
| | | HD | | 83.2 | 114 | 102 | 75 | 103 | 91.9 |
| | 75 | FRN55VG1□-4J | LD | 102 | 140 | 125 | 91.9 | 126 | 113 |
| | | | HD | 102 | 140 | 125 | 91.9 | 126 | 113 |
| | 90 | FRN75VG1□-4J | LD | 138 | - | 169 | 124 | - | 152 |
| | | | HD | 138 | - | 169 | 124 | - | 152 |
| | 110 | FRN90VG1□-4J | LD | 164 | - | 201 | 148 | - | 181 |
| | | | HD | 164 | - | 201 | 148 | - | 181 |
| | 132 | FRN110VG1□-4J | MD/LD | 201 | - | 246 | 181 | - | 222 |
| | | | HD | 201 | - | 246 | 181 | - | 222 |
| | 160 | FRN132VG1□-4J | MD/LD | 238 | - | 292 | 214 | - | 263 |
| | | | HD | 238 | - | 292 | 214 | - | 263 |
| | 200 | FRN160VG1□-4J | MD/LD | 286 | - | 350 | 258 | - | 315 |
| | | | HD | 286 | - | 350 | 258 | - | 315 |
| | 220 | FRN200VG1□-4J | MD/LD | 357 | - | 437 | 321 | - | 394 |
| | | | HD | 357 | - | 437 | 321 | - | 394 |
| | 250 | FRN220VG1□-4J | MD/LD | 390 | - | 478 | 351 | - | 430 |
| | | | HD | 390 | - | 478 | 351 | - | 430 |
| 280 | FRN280VG1□-4J | MD | 443 | - | 543 | 399 | - | 489 | |
| | | LD | 500 | - | 613 | 450 | - | 552 | |
| 315 | FRN280VG1□-4J | HD | 500 | - | 613 | 450 | - | 552 | |
| | | MD | 559 | - | 685 | 503 | - | 617 | |
| 355 | | LD | 628 | - | 770 | 565 | - | 693 | |

Note: □ in the inverter model represents an alphabet.

□
 S (Basic type)


- Inverter efficiency is calculated using values suitable for each inverter model. The input route mean square (RMS) current is calculated according to the following conditions:
 [22 kW or below] Power supply capacity 500 kVA, Power supply impedance 5%
 [30 kW or above] Power supply capacity and power supply impedance which are calculated using values matching the inverter capacity recommended by Fuji Electric.
- The input RMS current listed in the above table will vary in inverse proportion to the power supply voltage, such as 380 VAC.

Table 8.1 Currents Flowing through Inverter (continued)

HD (High Duty) mode: Heavy duty load applications
 MD (Medium Duty) mode: Medium duty load applications
 LD (Low Duty) mode: Light duty load applications

| Power supply voltage | Nominal applied motor (kW) | Inverter type | Specifications | 50 Hz, 400 V | | | 60 Hz, 440 V | | |
|----------------------|----------------------------|---------------|----------------|-----------------------|---------|-------------------------|-----------------------|------|-------------------------|
| | | | | Input RMS current (A) | | DC link bus current (A) | Input RMS current (A) | | DC link bus current (A) |
| | | | | DC reactor (DCR) | | | DC reactor (DCR) | | |
| | | | | w/ DCR | w/o DCR | w/ DCR | w/o DCR | | |
| Three-phase 400 V | 315 | FRN315VG1□-4J | HD | 559 | - | 685 | 503 | 617 | |
| | 355 | | MD | 628 | | 770 | 565 | 693 | |
| | 400 | | LD | 705 | | 864 | 635 | 778 | |
| | 355 | FRN355VG1□-4J | HD | 628 | | 770 | 565 | 693 | |
| | 400 | | MD | 705 | | 864 | 635 | 778 | |
| | 450 | | LD | 789 | | 967 | 710 | 870 | |
| | 400 | FRN400VG1□-4J | HD | 705 | | 864 | 635 | 778 | |
| | 450 | | MD | 789 | | 967 | 710 | 870 | |
| | 500 | | LD | 881 | | 1080 | 793 | 972 | |
| | 630 | FRN500VG1□-4J | HD | 881 | | 1080 | 793 | 972 | |
| | | | LD | 1115 | | 1367 | 1004 | 1230 | |
| | | | HD | 1115 | | 1367 | 1004 | 1230 | |
| 710 | FRN630VG1□-4J | LD | 1256 | 1539 | 1130 | 1385 | | | |

Note: □ in the inverter model represents an alphabet.



- Inverter efficiency is calculated using values suitable for each inverter model. The input route mean square (RMS) current is calculated according to the following conditions:
 [22 kW or below] Power supply capacity 500 kVA, Power supply impedance 5%
 [30 kW or above] Power supply capacity and power supply impedance which are calculated using values matching the inverter capacity recommended by Fuji Electric.
- The input RMS current listed in the above table will vary in inverse proportion to the power supply voltage, such as 380 VAC.

8.3 Recommended Wires

The following tables list the recommended wires according to the internal temperature of your power control panel.

■ If the internal temperature of your power control panel is 50°C or below

Table 8.2 Wire Size (for main circuit power input and inverter output)

HD (High Duty) mode: Heavy duty load applications
LD (Low Duty) mode: Light duty load applications

| Power supply voltage | Nominal applied motor (kW) | Inverter type | Specifications | Recommended wires | | | | | | | | | | | | | | | | | | | | |
|----------------------|----------------------------|----------------|----------------|---|---------|---------|-------------|------------------------------|--------|---------|-------------|------------------------------|---------|-------------|------------------------------|------|-------------|------------------------------|-----|-------------|---------|------|-----|-----|
| | | | | Main circuit power inputs L1/R, L2/S, L3/T | | | | | | | | Inverter output U, V, W | | | | | | | | | | | | |
| | | | | w/ DC reactor (DCR) | | | | w/o DC reactor (DCR) | | | | HD | | | | MD | | | | LD | | | | |
| | | | | Maximum temperature (Note 1) | | | Current (A) | Maximum temperature (Note 1) | | | Current (A) | Maximum temperature (Note 1) | | Current (A) | Maximum temperature (Note 1) | | Current (A) | Maximum temperature (Note 1) | | Current (A) | | | | |
| | | | | 60°C | 75°C | 90°C | | 60°C | 75°C | 90°C | | 60°C | 75°C | 90°C | | 60°C | 75°C | 90°C | | 60°C | 75°C | 90°C | | |
| Three-phase 200V | 0.75 | FRN0.75VG1□-2J | HD | 2.0 | 2.0 | 2.0 | 3.2 | 2.0 | 2.0 | 2.0 | 5.3 | 2.0 | 2.0 | 2.0 | 5 | - | - | - | - | - | - | - | - | |
| | 1.5 | FRN1.5VG1□-2J | | 2.0 | 2.0 | 2.0 | 6.1 | 2.0 | 2.0 | 2.0 | 9.5 | 2.0 | 2.0 | 2.0 | 8 | - | - | - | - | - | - | - | - | |
| | 2.2 | FRN2.2VG1□-2J | | 2.0 | 2.0 | 2.0 | 8.9 | 2.0 | 2.0 | 2.0 | 13.2 | 2.0 | 2.0 | 2.0 | 11 | - | - | - | - | - | - | - | - | |
| | 3.7 | FRN3.7VG1□-2J | | 2.0 | 2.0 | 2.0 | 15.0 | 5.5 | 2.0 | 2.0 | 22.2 | 3.5 | 2.0 | 2.0 | 18 | - | - | - | - | - | - | - | - | |
| | 5.5 | FRN5.5VG1□-2J | | 5.5 | 2.0 | 2.0 | 21.1 | 8.0 | 3.5 | 3.5 | 31.5 | 5.5 | 3.5 | 2.0 | 27 | - | - | - | - | - | - | - | - | |
| | 7.5 | FRN7.5VG1□-2J | | 8.0 | 3.5 | 2.0 | 28.8 | 14 | 5.5 | 5.5 | 42.7 | 14 | 5.5 | 3.5 | 37 | - | - | - | - | - | - | - | - | |
| | 11 | FRN11VG1□-2J | | 14 | 5.5 | 5.5 | 42.2 | 22 | 14 | 8.0 *3) | 60.7 | 14 | 8.0 *3) | 5.5 | 49 | - | - | - | - | - | - | - | - | |
| | 15 | FRN15VG1□-2J | | 22 | 14 | 8.0 *3) | 57.6 | 38 | 22 | 14 | 80.1 | 22 | 14 | 8.0 *3) | 63 | - | - | - | - | - | - | - | - | |
| | 18.5 | FRN18.5VG1□-2J | | 38 *1) | 14 | 14 | 71.1 | 60 *2) | 22 | 14 | 97.0 | 38 *1) | 14 | 14 | 76 | - | - | - | - | - | - | - | - | |
| | 22 | FRN22VG1□-2J | | 38 *1) | 22 | 14 | 84.4 | 60 *2) | 38 *1) | 22 | 112 | 38 *1) | 22 | 14 | 90 | - | - | - | - | - | - | - | - | |
| | 30 | FRN30VG1□-2J | | HD | 60 | 38 | 22 | 114 | - | 60 | 38 | 151 | 60 | 38 | 22 | 119 | - | - | - | - | - | - | - | - |
| | LD | | | - | 38 | 38 | 138 | - | 60 | 38 | 185 | - | - | - | - | - | - | - | - | - | 38 | 38 | 146 | |
| | 37 | FRN37VG1□-2J | | HD | 100 | 60 | 38 | 167 | - | 100 | 60 | 225 | - | 60 | 38 | 180 | - | - | - | - | - | 60 | 38 | 180 |
| | LD | | | 100 | 60 | 38 | 203 | - | 100 | 100 | 270 | - | - | - | - | - | - | - | - | - | 100 | 60 | 215 | |
| | 45 | FRN45VG1□-2J | | HD | - | 100 | 60 | 203 | - | 100 | 100 | 270 | - | 100 | 60 | 215 | - | - | - | - | - | - | - | - |
| | LD | | | - | 150 *4) | 100 | 282 | - | - | - | - | - | - | - | - | - | - | - | - | - | 150 *4) | 100 | 283 | |
| | 55 | FRN55VG1□-2J | | HD | - | 150 | 100 | 282 | - | - | - | - | - | 150 | 100 | 283 | - | - | - | - | - | - | - | - |
| | LD | | | - | 150 | 100 | 334 | - | - | - | - | - | - | - | - | - | - | - | - | - | 150 | 150 | 346 | |
| 75 | FRN75VG1□-2J | HD | - | 150 | 100 | 334 | - | - | - | - | - | 150 | 150 | 346 | - | - | - | - | - | - | - | - | | |
| LD | | - | 200 | 150 | 410 | - | - | - | - | - | - | - | - | - | - | - | - | - | 200 | 150 | 415 | | | |
| 90 | FRN90VG1□-2J | HD | - | 200 | 150 | 410 | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | | |
| LD | | - | 200 | 150 | 410 | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | | | |

Note 1: Assuming the use of aerial wiring (without rack or duct): 600 V class of vinyl-insulated IV wires for 60°C, 600 V class of polyethylene-insulated HIV wires for 75°C, and 600 V cross-linked polyethylene insulated wires for 90°C.

Note 2: □ in the inverter model represents an alphabet.

□
└─ S (Basic type)

*1 Use the crimp terminal model No. 38-6 manufactured by JST Mfg. Co., Ltd., or equivalent.

*2 Use the crimp terminal model No. 60-6 manufactured by JST Mfg. Co., Ltd., or equivalent.

*3 Use the crimp terminal model No. 8-L6 manufactured by JST Mfg. Co., Ltd., or equivalent.

*4 Use CB150-10 crimp terminals designed for low voltage appliances in JEM1399.


Table 8.2 Wire Size (for DC reactor, control circuit, and inverter grounding) (continued)

HD (High Duty) mode: Heavy duty load applications
 MD (Medium Duty) mode: Medium duty load applications
 LD (Low Duty) mode: Light duty load applications

| Power supply voltage | Nominal applied motor (kW) | Inverter type | Specifications | Recommended wires (mm ²) | | | | | | | | | | | | | | |
|----------------------|----------------------------|----------------|----------------|--------------------------------------|------------|------|-------------|------------------------------|------|------|--|------|------|---|------|------|------------------------------|------|
| | | | | For DC reactor connection [P1,P(+)] | | | | For control circuit | | | Auxiliary power input for the control circuit [R0, T0] | | | Auxiliary input for fan power supply [R1, T1] | | | For inverter grounding (G) | |
| | | | | Maximum temperature (Note 1) | | | Current (A) | Maximum temperature (Note 1) | | | Maximum temperature (Note 1) | | | Maximum temperature (Note 1) | | | Maximum temperature (Note 1) | |
| | | | | 60°C | 75°C | 90°C | | 60°C | 75°C | 90°C | 60°C | 75°C | 90°C | 60°C | 75°C | 90°C | 60°C | 75°C |
| Three-phase 400 V | 3.7 | FRN3.7VG1□-4J | HD | 2.0 | 2.0 | 2.0 | 9.2 | 1.25 | 2.0 | 2.0 | 2.0 | 2.0 | 2.0 | 2.0 | 2.0 | 2.0 | 2.0 | |
| | 5.5 | FRN5.5VG1□-4J | HD | 2.0 | 2.0 | 2.0 | 13.0 | | | | | | | | | | | 2.0 |
| | 7.5 | FRN7.5VG1□-4J | HD | 3.5 | 2.0 | 2.0 | 17.7 | | | | | | | | | | | 3.5 |
| | 11 | FRN11VG1□-4J | HD | 5.5 | 3.5 | 2.0 | 25.9 | | | | | | | | | | | 5.5 |
| | 15 | FRN15VG1□-4J | HD | 14 | 5.5 | 3.5 | 35.3 | | | | | | | | | | | 14 |
| | 18.5 | FRN18.5VG1□-4J | HD | 14 | 5.5 | 5.5 | 43.5 | | | | | | | | | | | 14 |
| | 22 | FRN22VG1□-4J | HD | 22 | 8.0 *1) | 5.5 | 51.7 | | | | | | | | | | | 22 |
| | 30 | FRN30VG1□-4J | HD | 38 | 14 | 8.0 | 69.9 | | | | | | | | | | | 38 |
| | 37 | | LD | 38 | 22 | 14 | 83.9 | | | | | | | | | | | 38 |
| | 45 | FRN37VG1□-4J | HD | 60 | 22 | 22 | 102 | | | | | | | | | | | 60 |
| | 55 | | LD | | | | | | | | | | | | | | | |
| | 55 | FRN45VG1□-4J | HD | 60 | 38 | 22 | 125 | | | | | | | | | | | 60 |
| | 75 | | LD | | | | | | | | | | | | | | | |
| | 75 | FRN55VG1□-4J | HD | - | 60 | 38 | 169 | | | | | | | | | | | 100 |
| | 90 | | LD | | | | | | | | | | | | | | | |
| | 90 | FRN75VG1□-4J | HD | - | 100 | 60 | 201 | | | | | | | | | | | 100 |
| | 110 | | LD | | | | | | | | | | | | | | | |
| | 110 | FRN90VG1□-4J | MD/ | - | 100 | 60 | 246 | | | | | | | | | | | 100 |
| | 132 | | LD | | | | | | | | | | | | | | | |
| | 132 | FRN110VG1□-4J | MD/ | - | 150 | 100 | 292 | | | | | | | | | | | 150 |
| | 160 | | LD | | | | | | | | | | | | | | | |
| | 160 | FRN132VG1□-4J | MD/ | - | 150 | 150 | 350 | | | | | | | | | | | 150 |
| | 200 | | LD | | | | | | | | | | | | | | | |
| | 200 | FRN160VG1□-4J | MD/ | - | 250 | 150 | 437 | | | | | | | | | | | 250 |
| | 220 | | LD | | | | | | | | | | | | | | | |
| | 220 | FRN200VG1□-4J | MD/ | - | 250 | 200 | 478 | | | | | | | | | | | 250 |
| | 250 | | LD | | | | | | | | | | | | | | | |
| | 250 | FRN220VG1□-4J | MD | - | 325 | 250 | 543 | | | | | | | | | | | 250 |
| | 280 | | LD | | | | | | | | | | | | | | | |
| | 280 | FRN280VG1□-4J | MD | - | 2x200 | 250 | 612 | | | | | | | | | | | 250 |
| | 315 | | LD | | | | | | | | | | | | | | | |
| | 315 | FRN280VG1□-4J | MD | - | 2x200 | 325 | 685 | | | | | | | | | | | 250 |
| 355 | LD | | | | | | | | | | | | | | | | | |
| 355 | FRN315VG1□-4J | MD | - | 2x250 | 2x200 | 769 | 250 | | | | | | | | | | | |
| 400 | | LD | | | | | | | | | | | | | | | | |
| 355 | FRN315VG1□-4J | MD | - | 2x250 | 2x200 | 769 | 250 | | | | | | | | | | | |
| 400 | | LD | | | | | | | | | | | | | | | | |
| 400 | FRN355VG1□-4J | MD | - | 2x325 | 2x200 | 864 | 250 | | | | | | | | | | | |
| 450 | | LD | | | | | | | | | | | | | | | | |
| 400 | FRN355VG1□-4J | MD | - | 2x325 | 2x200 | 864 | 250 | | | | | | | | | | | |
| 450 | | LD | | | | | | | | | | | | | | | | |
| 400 | FRN400VG1□-4J | MD | - | 2x325 | 2x250 | 966 | 250 | | | | | | | | | | | |
| 500 | | LD | | | | | | | | | | | | | | | | |
| 500 | FRN500VG1□-4J | MD | - | 3x325 | 2x325 | 1079 | 250 | | | | | | | | | | | |
| 630 | | LD | | | | | | | | | | | | | | | | |
| 630 | FRN630VG1□-4J | MD | - | 3x325 | 3x325 | 1366 | 250 | | | | | | | | | | | |
| 710 | | LD | | | | | | | | | | | | | | | | |

Note 1: Assuming the use of aerial wiring (without rack or duct): 600 V class of vinyl-insulated IV wires for 60°C, 600 V class of polyethylene-insulated HIV wires for 75°C, and 600 V cross-linked polyethylene insulated wires for 90°C.

Note 2: □ in the inverter model represents an alphabet.



*1 Use the crimp terminal model No. 8-L6 manufactured by JST Mfg. Co., Ltd., or equivalent.

■ If the internal temperature of your power control panel is 40°C or below


Table 8.3 Wire Size (for main circuit power input and inverter output)

HD (High Duty) mode: Heavy duty load applications
LD (Low Duty) mode: Light duty load applications

| Power supply voltage | Nominal applied motor (kW) | Inverter type | Specifications | Recommended wires (mm ²) | | | | | | | | | | | | | | | | | | | |
|----------------------|----------------------------|----------------|----------------|---|---------|---------|-------------|------------------------------|----------------------|------|-------------|------------------------------|---------|---------------------------|-------------|------------------------------|------|------|-------------|------------------------------|------|------|-------------|
| | | | | Main circuit power input [L1/R, L2/S, L3/T] | | | | | | | | | | Inverter output [U, V, W] | | | | | | | | | |
| | | | | w/ DC reactor (DCR) | | | | | w/o DC reactor (DCR) | | | | | HD | | | MD | | | LD | | | |
| | | | | Maximum temperature (Note 1) | | | Current (A) | Maximum temperature (Note 1) | | | Current (A) | Maximum temperature (Note 1) | | | Current (A) | Maximum temperature (Note 1) | | | Current (A) | Maximum temperature (Note 1) | | | Current (A) |
| | | | | 60°C | 75°C | 90°C | | 60°C | 75°C | 90°C | | 60°C | 75°C | 90°C | | 60°C | 75°C | 90°C | | 60°C | 75°C | 90°C | |
| Three-phase 200V | 0.75 | FRN0.75VG1□-2J | HD | 2.0 | 2.0 | 2.0 | 3.2 | 2.0 | 2.0 | 2.0 | 5.3 | 2.0 | 2.0 | 2.0 | 5 | - | - | - | - | - | - | - | - |
| | 1.5 | FRN1.5VG1□-2J | | 2.0 | 2.0 | 2.0 | 6.1 | 2.0 | 2.0 | 2.0 | 9.5 | 2.0 | 2.0 | 2.0 | 8 | - | - | - | - | - | - | - | - |
| | 2.2 | FRN2.2VG1□-2J | | 2.0 | 2.0 | 2.0 | 8.9 | 2.0 | 2.0 | 2.0 | 13.2 | 2.0 | 2.0 | 2.0 | 11 | - | - | - | - | - | - | - | - |
| | 3.7 | FRN3.7VG1□-2J | | 2.0 | 2.0 | 2.0 | 15 | 3.5 | 2.0 | 2.0 | 22.2 | 2.0 | 2.0 | 2.0 | 18 | - | - | - | - | - | - | - | - |
| | 5.5 | FRN5.5VG1□-2J | HD | 2.0 | 2.0 | 2.0 | 21.1 | 5.5 | 3.5 | 2.0 | 31.5 | 3.5 | 2.0 | 2.0 | 27 | - | - | - | - | - | - | - | - |
| | 7.5 | FRN7.5VG1□-2J | HD | 3.5 | 2.0 | 2.0 | 28.8 | 8.0 | 5.5 | 3.5 | 42.7 | 5.5 | 3.5 | 3.5 | 37 | - | - | - | - | - | - | - | - |
| | 11 | FRN11VG1□-2J | HD | 8.0 *2) | 5.5 | 3.5 | 42.2 | 14 | 8.0 *2) | 5.5 | 60.7 | 8.0 *2) | 5.5 | 5.5 | 49 | - | - | - | - | - | - | - | - |
| | 15 | FRN15VG1□-2J | HD | 14 | 8.0 *2) | 5.5 | 57.6 | 22 | 14 | 14 | 80.1 | 14 | 8.0 *2) | 5.5 | 63 | - | - | - | - | - | - | - | - |
| | 18.5 | FRN18.5VG1□-2J | HD | 14 | 14 | 8.0 *2) | 71 | 38 *1) | 22 | 14 | 97.0 | 22 | 14 | 8.0 *2) | 76 | - | - | - | - | - | - | - | - |
| | 22 | FRN22VG1□-2J | HD | 22 | 14 | 14 | 84.4 | 38 *1) | 22 | 14 | 112 | 22 | 14 | 14 | 90 | - | - | - | - | - | - | - | - |
| | 30 | FRN30VG1□-2J | HD | 38 | 22 | 22 | 114 | 60 | 38 | 38 | 151 | 38 | 22 | 22 | 119 | - | - | - | - | - | - | - | - |
| | 37 | | LD | 60 | 38 | 22 | 138 | - | 60 | 38 | 185 | - | - | - | - | - | - | - | - | 60 | 38 | 22 | 146 |
| | 45 | FRN37VG1□-2J | HD | - | - | - | - | 100 | - | - | - | 60 | 38 | 22 | 146 | - | - | - | - | - | - | - | - |
| | | | LD | 60 | 38 | 38 | 167 | 100 | 60 | 60 | 225 | - | - | - | - | - | - | - | - | 100 | 60 | 38 | 180 |
| | 55 | FRN45VG1□-2J | HD | - | - | - | - | - | - | - | - | 100 | 60 | 38 | 180 | - | - | - | - | - | - | - | - |
| | | | LD | 100 | 60 | 38 | 203 | - | 100 | 60 | 270 | - | - | - | - | - | - | - | - | 100 | 60 | 60 | 215 |
| 75 | FRN55VG1□-2J | HD | - | - | - | - | - | - | - | - | 100 | 60 | 60 | 215 | - | - | - | - | - | - | - | - | |
| | | LD | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | 100 | 100 | 283 | |
| 90 | FRN75VG1□-2J | HD | 150 *3) | 100 | 100 | 282 | - | - | - | - | 150 | 100 | 100 | 283 | - | - | - | - | - | - | - | - | |
| | | LD | - | 150 | 100 | 334 | - | - | - | - | - | - | - | - | - | - | - | - | 200 | 150 | 100 | 346 | |
| 110 | FRN90VG1□-2J | LD | - | 150 | 150 | 410 | - | - | - | - | - | - | - | - | - | - | - | - | 250 | 150 | 150 | 415 | |

Note 1: Assuming the use of aerial wiring (without rack or duct): 600 V class of vinyl-insulated IV wires for 60°C, 600 V class of polyethylene-insulated HIV wires for 75°C, and 600 V cross-linked polyethylene insulated wires for 90°C.

Note 2: □ in the inverter model represents an alphabet.



*1 Use the crimp terminal model No. 38-6 manufactured by JST Mfg. Co., Ltd., or equivalent.

*2 Use the crimp terminal model No. 8-L6 manufactured by JST Mfg. Co., Ltd., or equivalent.

*3 Use CB150-10 crimp terminals designed for low voltage appliances in JEM1399.


Table 8.3 Wire Size (for main circuit power input and inverter output) (continued)

HD (High Duty) mode: Heavy duty load applications
 MD (Medium Duty) mode: Medium duty load applications
 LD (Low Duty) mode: Light duty load applications

| Power supply voltage | Nominal applied motor (kW) | Inverter type | Specifications | Recommended wires (mm ²) | | | | | | | | | | | | | | | | | | | | | |
|----------------------|----------------------------|----------------|----------------|---|-------|------|-------------|------------------------------|----------------------|------|-------------|------------------------------|-------|---------------------------|-------------|------------------------------|-------|------|-------------|------------------------------|------|-------|-------------|------|-----|
| | | | | Main circuit power input [L1/R, L2/S, L3/T] | | | | | | | | | | Inverter output [U, V, W] | | | | | | | | | | | |
| | | | | w/ DC reactor (DCR) | | | | | w/o DC reactor (DCR) | | | | | HD | | | MD | | | LD | | | | | |
| | | | | Maximum temperature (Note 1) | | | Current (A) | Maximum temperature (Note 1) | | | Current (A) | Maximum temperature (Note 1) | | | Current (A) | Maximum temperature (Note 1) | | | Current (A) | Maximum temperature (Note 1) | | | Current (A) | | |
| 60°C | 75°C | 90°C | | 60°C | 75°C | 90°C | | 60°C | 75°C | 90°C | | 60°C | 75°C | 90°C | | 60°C | 75°C | 90°C | | 60°C | 75°C | 90°C | | | |
| Three-phase 400 V | 3.7 | FRN3.7VG1□-4J | HD | 2.0 | 2.0 | 2.0 | 7.5 | 2.0 | 2.0 | 2.0 | 13.0 | 2.0 | 2.0 | 2.0 | 9 | - | - | - | - | - | - | - | - | - | |
| | 5.5 | FRN5.5VG1□-4J | HD | 2.0 | 2.0 | 2.0 | 10.6 | 2.0 | 2.0 | 2.0 | 17.3 | 2.0 | 2.0 | 2.0 | 13.5 | - | - | - | - | - | - | - | - | - | |
| | 7.5 | FRN7.5VG1□-4J | HD | 2.0 | 2.0 | 2.0 | 14.4 | 3.5 | 2.0 | 2.0 | 23.2 | 2.0 | 2.0 | 2.0 | 18.5 | - | - | - | - | - | - | - | - | - | |
| | 11 | FRN11VG1□-4J | HD | 2.0 | 2.0 | 2.0 | 21.1 | 5.5 | 3.5 | 2.0 | 33 | 3.5 | 2.0 | 2.0 | 24.5 | - | - | - | - | - | - | - | - | - | |
| | 15 | FRN15VG1□-4J | HD | 3.5 | 2.0 | 2.0 | 28.8 | 8.0 *1) | 5.5 | 3.5 | 43.8 | 5.5 | 3.5 | 2.0 | 32 | - | - | - | - | - | - | - | - | - | |
| | 18.5 | FRN18.5VG1□-4J | HD | 5.5 | 3.5 | 3.5 | 35.5 | 14 | 8.0 *1) | 5.5 | 52.3 | 5.5 | 3.5 | 3.5 | 39 | - | - | - | - | - | - | - | - | - | |
| | 22 | FRN22VG1□-4J | HD | 8.0 *1) | 5.5 | 3.5 | 42.2 | 14 | 8.0 *1) | 5.5 | 60.6 | 8.0 *1) | 5.5 | 3.5 | 45 | - | - | - | - | - | - | - | - | - | |
| | 30 | FRN30VG1□-4J | HD | 14 | 8.0 | 5.5 | 57.0 | 22 | 14 | 8.0 | 77.9 | 14 | 8.0 | 5.5 | 60 | - | - | - | - | - | - | - | - | - | |
| | 37 | FRN37VG1□-4J | LD | 14 | 14 | 8.0 | 68.5 | 38 | 14 | 14 | 94.3 | - | - | - | - | - | - | - | - | - | - | 22 | 14 | 8.0 | 75 |
| | | | HD | 14 | 14 | 8.0 | 68.5 | 38 | 14 | 14 | 94.3 | 22 | 14 | 8.0 | 75 | - | - | - | - | - | - | - | - | - | - |
| | 45 | FRN45VG1□-4J | LD | 22 | 14 | 14 | 83.2 | 38 | 22 | 22 | 114 | - | - | - | - | - | - | - | - | - | - | 22 | 14 | 14 | 91 |
| | | | HD | 22 | 14 | 14 | 83.2 | 38 | 22 | 22 | 114 | 22 | 14 | 14 | 91 | - | - | - | - | - | - | - | - | - | - |
| | 55 | FRN55VG1□-4J | LD | 38 | 22 | 14 | 102 | 60 | 38 | 22 | 140 | - | - | - | - | - | - | - | - | - | - | 38 | 22 | 14 | 112 |
| | | | HD | 38 | 22 | 14 | 102 | 60 | 38 | 22 | 140 | 38 | 22 | 14 | 112 | - | - | - | - | - | - | - | - | - | - |
| | 75 | FRN75VG1□-4J | LD | 60 | 38 | 22 | 138 | - | - | - | - | - | - | - | - | - | - | - | - | - | - | 60 | 38 | 38 | 150 |
| | | | HD | 60 | 38 | 22 | 138 | - | - | - | - | - | 60 | 38 | 38 | 150 | - | - | - | - | - | - | - | - | - |
| | 90 | FRN90VG1□-4J | LD | 60 | 38 | 38 | 164 | - | - | - | - | - | - | - | - | - | - | - | - | - | - | 60 | 60 | 38 | 176 |
| | | | HD | 60 | 38 | 38 | 164 | - | - | - | - | - | 60 | 60 | 38 | 176 | - | - | - | - | - | - | - | - | - |
| | 110 | FRN110VG1□-4J | MD/LD | 100 | 60 | 38 | 201 | - | - | - | - | - | - | - | - | 100 | 60 | 60 | 210 | - | - | 100 | 60 | 60 | 210 |
| | | | HD | 100 | 60 | 38 | 201 | - | - | - | - | - | 100 | 60 | 60 | 210 | - | - | - | - | - | - | - | - | - |
| | 132 | FRN132VG1□-4J | MD/LD | 100 | 100 | 60 | 238 | - | - | - | - | - | - | - | - | 150 | 100 | 60 | 253 | - | - | 150 | 100 | 60 | 253 |
| | | | HD | 100 | 100 | 60 | 238 | - | - | - | - | - | 150 | 100 | 60 | 253 | - | - | - | - | - | - | - | - | - |
| | 160 | FRN160VG1□-4J | MD/LD | 150 | 100 | 100 | 286 | - | - | - | - | - | - | - | - | 150 | 100 | 100 | 304 | - | - | 150 | 100 | 100 | 304 |
| | | | HD | 150 | 100 | 100 | 286 | - | - | - | - | - | 150 | 100 | 100 | 304 | - | - | - | - | - | - | - | - | - |
| | 200 | FRN200VG1□-4J | MD/LD | 200 | 150 | 100 | 357 | - | - | - | - | - | - | - | - | 200 | 150 | 100 | 377 | - | - | 200 | 150 | 100 | 377 |
| | | | HD | 200 | 150 | 100 | 357 | - | - | - | - | - | 200 | 150 | 100 | 377 | - | - | - | - | - | - | - | - | - |
| | 220 | FRN220VG1□-4J | MD/LD | 250 | 150 | 150 | 390 | - | - | - | - | - | - | - | - | 250 | 150 | 150 | 415 | - | - | 250 | 150 | 150 | 415 |
| | | | HD | 250 | 150 | 150 | 390 | - | - | - | - | - | 250 | 150 | 150 | 415 | - | - | - | - | - | - | - | - | - |
| | 250 | FRN220VG1□-4J | MD | 250 | 200 | 150 | 443 | - | - | - | - | - | - | - | - | 325 | 200 | 150 | 468 | - | - | - | - | - | |
| | 280 | FRN280VG1□-4J | LD | 325 | 200 | 150 | 500 | - | - | - | - | - | - | - | - | - | - | - | - | - | - | 325 | 250 | 200 | 520 |
| | | | HD | 325 | 200 | 150 | 500 | - | - | - | - | - | 325 | 250 | 200 | 520 | - | - | - | - | - | - | - | - | - |
| | 315 | FRN280VG1□-4J | MD | - | 250 | 200 | 559 | - | - | - | - | - | - | - | - | - | 250 | 200 | 585 | - | - | - | - | - | |
| | 355 | FRN315VG1□-4J | LD | - | 325 | 250 | 628 | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | 325 | 250 | 650 |
| | 315 | FRN315VG1□-4J | HD | - | 250 | 200 | 559 | - | - | - | - | - | 250 | 200 | 585 | - | - | - | - | - | - | - | - | - | - |
| | 355 | FRN315VG1□-4J | MD | - | 325 | 250 | 628 | - | - | - | - | - | - | - | - | - | 325 | 250 | 650 | - | - | - | - | - | |
| | 400 | FRN355VG1□-4J | LD | - | 2x150 | 250 | 705 | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | 2x200 | 325 | 740 |
| | 355 | FRN355VG1□-4J | HD | - | 325 | 250 | 628 | - | - | - | - | - | 325 | 250 | 650 | - | - | - | - | - | - | - | - | - | - |
| 400 | FRN355VG1□-4J | MD | - | 2x150 | 250 | 705 | - | - | - | - | - | - | - | - | - | 2x200 | 325 | 740 | - | - | - | - | - | | |
| 450 | FRN400VG1□-4J | LD | - | 2x200 | 325 | 789 | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | 2x200 | 2x150 | 840 | |
| 400 | FRN400VG1□-4J | HD | - | 2x150 | 250 | 705 | - | - | - | - | - | 2x200 | 325 | 740 | - | - | - | - | - | - | - | - | - | - | |
| 450 | FRN400VG1□-4J | MD | - | 2x200 | 325 | 789 | - | - | - | - | - | - | - | - | - | 2x200 | 2x150 | 840 | - | - | - | - | - | | |
| 500 | FRN500VG1□-4J | LD | - | 2x250 | 2x200 | 881 | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | 2x250 | 2x200 | 960 | |
| | | HD | - | 2x250 | 2x200 | 881 | - | - | - | - | - | 2x250 | 2x200 | 960 | - | - | - | - | - | - | - | - | - | - | |
| 630 | FRN630VG1□-4J | LD | - | 2x325 | 2x250 | 1115 | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | 3x250 | 2x250 | 1170 | |
| | | HD | - | 2x325 | 2x250 | 1115 | - | - | - | - | - | 3x250 | 2x250 | 1170 | - | - | - | - | - | - | - | - | - | - | |
| 710 | FRN630VG1□-4J | LD | - | 3x250 | 2x325 | 1256 | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | 3x325 | 2x325 | 1370 | |

Note 1: Assuming the use of aerial wiring (without rack or duct): 600 V class of vinyl-insulated IV wires for 60°C, 600 V class of polyethylene-insulated HIV wires for 75°C, and 600 V cross-linked polyethylene insulated wires for 90°C.

Note 2: □ in the inverter model represents an alphabet.



*1 Use the crimp terminal model No. 8-L6 manufactured by JST Mfg. Co., Ltd., or equivalent.

Table 8.3 Wire Size (for DC reactor, control circuit, and inverter grounding) (continued)

HD (High Duty) mode: Heavy duty load applications
 LD (Low Duty) mode: Light duty load applications

| Power supply voltage | Nominal applied motor (kW) | Inverter type | Specifications | Recommended wires (mm ²) | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
|----------------------|----------------------------|----------------|----------------|--------------------------------------|---------|---------|-------------|------------------------------|------|------|--|------|------|---|------|------|------------------------------|------|------|---|---|---|---|---|---|----------------------|--|--|--|--|--|--|--|--|--|--|--|
| | | | | For DC reactor connection [P1,P(+)] | | | | For control circuit | | | Auxiliary power input for the control circuit [R0, T0] | | | Auxiliary input for fan power supply [R1, T1] | | | For inverter grounding [G] | | | | | | | | | | | | | | | | | | | | |
| | | | | Maximum temperature (Note 1) | | | Current (A) | Maximum temperature (Note 1) | | | Maximum temperature (Note 1) | | | Maximum temperature (Note 1) | | | Maximum temperature (Note 1) | | | | | | | | | | | | | | | | | | | | |
| | | | | 60°C | 75°C | 90°C | | 60°C | 75°C | 90°C | 60°C | 75°C | 90°C | 60°C | 75°C | 90°C | 60°C | 75°C | 90°C | | | | | | | | | | | | | | | | | | |
| Three-phase 200V | 0.75 | FRN0.75VG1□-2J | HD | 2.0 | 2.0 | 2.0 | 4.0 | 1.25 | 2.0 | - | - | - | - | - | - | - | 2.0 | | | | | | | | | | | | | | | | | | | | |
| | 1.5 | FRN1.5VG1□-2J | | 2.0 | 2.0 | 2.0 | 7.5 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | 2.2 | FRN2.2VG1□-2J | | 2.0 | 2.0 | 2.0 | 11.0 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | 3.7 | FRN3.7VG1□-2J | | 2.0 | 2.0 | 2.0 | 18.4 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | 5.5 | FRN5.5VG1□-2J | | 3.5 | 2.0 | 2.0 | 25.9 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | 7.5 | FRN7.5VG1□-2J | | 5.5 | 3.5 | 3.5 | 35.3 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | 11 | FRN11VG1□-2J | | 14 | 5.5 | 5.5 | 51.7 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | 15 | FRN15VG1□-2J | | 14 | 14 | 8.0 *2) | 70.6 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | 18.5 | FRN18.5VG1□-2J | | 22 | 14 | 14 | 87.0 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | 22 | FRN22VG1□-2J | | 38 *1) | 22 | 14 | 103 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | 30 | FRN30VG1□-2J | HD | 60 | 38 | 22 | 140 | 1.25 | 2.0 | - | - | - | - | - | - | - | 2.0 | | | | | | | | | | | | | | | | | | | | |
| | 37 | | LD | 60 | 38 | 38 | 169 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | 45 | FRN37VG1□-2J | HD | 100 | 60 | 38 | 205 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | | | LD | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | 55 | FRN45VG1□-2J | HD | 150 *3) | 100 | 60 | 249 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | | | LD | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | 75 | FRN55VG1□-2J | LD | - | 150 *3) | 100 | 345 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | | | HD | 150 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | 90 | FRN75VG1□-2J | LD | - | 150 | 150 | 409 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | | | HD | - | 150 | 150 | 409 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 110 | FRN90VG1□-2J | LD | - | 200 | 150 | 502 | 1.25 | | | | | | | | | | | 2.0 | - | - | - | - | - | - | - | 2.0 (37 kW or above) | | | | | | | | | | | |
| | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |

Note 1: Assuming the use of aerial wiring (without rack or duct): 600 V class of vinyl-insulated IV wires for 60°C, 600 V class of polyethylene-insulated HIV wires for 75°C, and 600 V cross-linked polyethylene insulated wires for 90°C.

Note 2: □ in the inverter model represents an alphabet.

□ S (Basic type)

*1 Use the crimp terminal model No. 8-L6 manufactured by JST Mfg. Co., Ltd., or equivalent.

*2 Use the crimp terminal model No. 8-L6 manufactured by JST Mfg. Co., Ltd., or equivalent.

*3 Use CB150-10 crimp terminals designed for low voltage appliances in JEM1399.

Table 8.3 Wire Size (for DC reactor, control circuit, and inverter grounding) (continued)

HD (High Duty) mode: Heavy duty load applications
 MD (Medium Duty) mode: Medium duty load applications
 LD (Low Duty) mode: Light duty load applications

| Power supply voltage | Nominal applied motor (kW) | Inverter type | Specifications | Recommended wires (mm ²) | | | | | | | | | | | | | | |
|----------------------|----------------------------|----------------|----------------|--------------------------------------|-------|------|-------------|------------------------------|------|------|--|------|------|---|------|------|------------------------------|------|
| | | | | For DC reactor connection [P1,P(+)] | | | | For control circuit | | | Auxiliary power input for the control circuit [R0, T0] | | | Auxiliary input for fan power supply [R1, T1] | | | For inverter grounding (G) | |
| | | | | Maximum temperature (Note 1) | | | Current (A) | Maximum temperature (Note 1) | | | Maximum temperature (Note 1) | | | Maximum temperature (Note 1) | | | Maximum temperature (Note 1) | |
| | | | | 60°C | 75°C | 90°C | | 60°C | 75°C | 90°C | 60°C | 75°C | 90°C | 60°C | 75°C | 90°C | 60°C | 75°C |
| Three-phase 400 V | 3.7 | FRN3.7VG1□-4J | HD | 2.0 | 2.0 | 2.0 | 9.2 | 1.25 | 2.0 | 2.0 | 2.0 | 2.0 | 2.0 | 2.0 | 2.0 | 2.0 | 2.0 | |
| | 5.5 | FRN5.5VG1□-4J | HD | 2.0 | 2.0 | 2.0 | 13.0 | | | | | | | | | | | 2.0 |
| | 7.5 | FRN7.5VG1□-4J | HD | 2.0 | 2.0 | 2.0 | 17.7 | | | | | | | | | | | 3.5 |
| | 11 | FRN11VG1□-4J | HD | 3.5 | 2.0 | 2.0 | 25.9 | | | | | | | | | | | 3.5 |
| | 15 | FRN15VG1□-4J | HD | 5.5 | 3.5 | 3.5 | 35.3 | | | | | | | | | | | 5.5 |
| | 18.5 | FRN18.5VG1□-4J | HD | 8.0*1) | 5.5 | 3.5 | 43.5 | | | | | | | | | | | 5.5 |
| | 22 | FRN22VG1□-4J | HD | 14 | 5.5 | 5.5 | 51.7 | | | | | | | | | | | 8.0 |
| | 30 | FRN30VG1□-4J | HD | 14 | 14 | 8.0 | 69.9 | | | | | | | | | | | 8.0 |
| | 37 | | LD | 22 | 14 | 14 | 83.9 | | | | | | | | | | | 8.0 |
| | | 45 | FRN37VG1□-4J | HD | 38 | 22 | 14 | | | | | | | | | | | 102 |
| | LD | | | | | | | | | | | | | | | | | |
| | 55 | FRN45VG1□-4J | HD | 38 | 38 | 22 | 125 | | | | | | | | | | | 14 |
| | | LD | | | | | | | | | | | | | | | | |
| | 75 | FRN55VG1□-4J | HD | 60 | 38 | 38 | 169 | | | | | | | | | | | 14 |
| | | LD | | | | | | | | | | | | | | | | |
| | 90 | FRN75VG1□-4J | HD | 100 | 60 | 38 | 201 | | | | | | | | | | | 14 |
| | 110 | | LD | | | | | | | | | | | | | | | |
| | | 132 | FRN90VG1□-4J | MD/ LD | 150 | 100 | 60 | | | | | | | | | | | 246 |
| | HD | | | | | | | | | | | | | | | | | |
| | 160 | FRN110VG1□-4J | MD/ LD | 150 | 100 | 100 | 292 | | | | | | | | | | | 38 |
| | | HD | | | | | | | | | | | | | | | | |
| | 200 | FRN132VG1□-4J | MD/ LD | 200 | 150 | 100 | 350 | | | | | | | | | | | 38 |
| | | HD | | | | | | | | | | | | | | | | |
| | 220 | FRN160VG1□-4J | MD/ LD | 250 | 200 | 150 | 437 | | | | | | | | | | | 38 |
| | | HD | | | | | | | | | | | | | | | | |
| | 250 | FRN200VG1□-4J | MD/ LD | 325 | 200 | 150 | 478 | | | | | | | | | | | 60 |
| | | | HD | | | | | | | | | | | | | | | |
| | 280 | FRN220VG1□-4J | MD | - | 250 | 200 | 543 | | | | | | | | | | | 60 |
| | | | LD | | | | | | | | | | | | | | | |
| | 315 | FRN280VG1□-4J | HD | - | 2x150 | 250 | 685 | | | | | | | | | | | 60 |
| | | | LD | | | | | | | | | | | | | | | |
| | 355 | FRN315VG1□-4J | HD | - | 2x200 | 325 | 769 | | | | | | | | | | | 60 |
| | | | LD | | | | | | | | | | | | | | | |
| | 400 | FRN355VG1□-4J | HD | - | 2x150 | 250 | 685 | | | | | | | | | | | 60 |
| LD | | | | | | | | | | | | | | | | | | |
| 450 | FRN400VG1□-4J | MD | - | 2x200 | 325 | 769 | 60 | | | | | | | | | | | |
| | | LD | | | | | | | | | | | | | | | | |
| 500 | FRN450VG1□-4J | MD | - | 2x250 | 2x200 | 864 | 60 | | | | | | | | | | | |
| | | LD | | | | | | | | | | | | | | | | |
| 630 | FRN500VG1□-4J | MD | - | 2x250 | 2x200 | 966 | 100 | | | | | | | | | | | |
| | | LD | | | | | | | | | | | | | | | | |
| 710 | FRN630VG1□-4J | MD | - | 3x325 | 2x325 | 1366 | 100 | | | | | | | | | | | |
| | | LD | | | | | | | | | | | | | | | | |

Note 1: Assuming the use of aerial wiring (without rack or duct): 600 V class of vinyl-insulated IV wires for 60°C, 600 V class of polyethylene-insulated HIV wires for 75°C, and 600 V cross-linked polyethylene insulated wires for 90°C.

Note 2: □ in the inverter model represents an alphabet.

□ S (Basic type)

*1 Use the crimp terminal model No. 8-L6 manufactured by JST Mfg. Co., Ltd., or equivalent.

< Wire Size (for DC reactor, braking resistor) >

■ If the internal temperature of your power control panel is 50°C or below


Table 8.4 Wire Size (for braking resistor)

HD (High Duty) mode: Heavy duty load applications
LD (Low Duty) mode: Light duty load applications

| Power supply voltage | Nominal applied motor (kW) | Inverter type | Specifications | 10% ED product | | | | | | | | | | | | 20% ED product | | | | | | | | | | | | | | | | | | | | | | | | | | |
|----------------------|----------------------------|----------------|----------------|---|------------|------|-------------|------------------------------|------|------|-------------|------------------------------|------|-----------|-------------|---|------|------|-------------|------------------------------|------|---|-------------|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|
| | | | | For braking resistor connection [P(+),DB] | | | | | | | | | | | | For braking resistor connection [P(+),DB] | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | | | | HD | | | MD | | | LD | | | HD | | | MD | | | LD | | | | | | | | | | | | | | | | | | | | | | | |
| | | | | Maximum temperature (Note 1) | | | Current (A) | Maximum temperature (Note 1) | | | Current (A) | Maximum temperature (Note 1) | | | Current (A) | Maximum temperature (Note 1) | | | Current (A) | Maximum temperature (Note 1) | | | Current (A) | | | | | | | | | | | | | | | | | | | |
| 60°C | 75°C | 90°C | 60°C | 75°C | 90°C | 60°C | | 75°C | 90°C | 60°C | | 75°C | 90°C | 60°C | | 75°C | 90°C | 60°C | | 75°C | 90°C | | | | | | | | | | | | | | | | | | | | | |
| Three-phase 200V | 0.75 | FRN0.75VG1□-2J | HD | 2.0 | 2.0 | 2.0 | 1.4 | - | - | - | - | - | - | - | 2.0 | 2.0 | 2.0 | 1.9 | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | |
| | 1.5 | FRN1.5VG1□-2J | HD | 2.0 | 2.0 | 2.0 | 1.9 | - | - | - | - | - | - | - | 2.0 | 2.0 | 2.0 | 2.7 | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | |
| | 2.2 | FRN2.2VG1□-2J | HD | 2.0 | 2.0 | 2.0 | 2.3 | - | - | - | - | - | - | - | 2.0 | 2.0 | 2.0 | 3.3 | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - |
| | 3.7 | FRN3.7VG1□-2J | HD | 2.0 | 2.0 | 2.0 | 3.4 | - | - | - | - | - | - | - | 2.0 | 2.0 | 2.0 | 4.8 | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - |
| | 5.5 | FRN5.5VG1□-2J | HD | 2.0 | 2.0 | 2.0 | 5.1 | - | - | - | - | - | - | - | 2.0 | 2.0 | 2.0 | 7.2 | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - |
| | 7.5 | FRN7.5VG1□-2J | HD | 2.0 | 2.0 | 2.0 | 6.8 | - | - | - | - | - | - | - | 2.0 | 2.0 | 2.0 | 9.7 | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - |
| | 11 | FRN11VG1□-2J | HD | 2.0 | 2.0 | 2.0 | 10.2 | - | - | - | - | - | - | - | 2.0 | 2.0 | 2.0 | 14.4 | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - |
| | 15 | FRN15VG1□-2J | HD | 2.0 | 2.0 | 2.0 | 13.7 | - | - | - | - | - | - | - | 3.5 | 2.0 | 2.0 | 19.4 | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - |
| | 18.5 | FRN18.5VG1□-2J | HD | 3.5 | 2.0 | 2.0 | 17.6 | - | - | - | - | - | - | - | 5.5 | 3.5 | 2.0 | 24.8 | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - |
| | 22 | FRN22VG1□-2J | HD | 3.5 | 2.0 | 2.0 | 20.3 | - | - | - | - | - | - | - | 8.0 | 3.5 | 2.0 | 28.7 | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - |
| | 30 | FRN30VG1□-2J | HD | 8.0 | 3.5 | 2.0 | 30.0 | - | - | - | - | - | - | - | 14 | 5.5 | 3.5 | 38.7 | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - |
| | 37 | | LD | - | - | - | - | - | - | - | - | - | - | - | 8.0 | 3.5 | 2.0 | 29.8 | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | |
| | 45 | FRN37VG1□-2J | HD | 14 | 5.5 | 3.5 | 35.1 | - | - | - | - | - | - | - | 14 | 8.0 | 5.5 | 48.1 | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - |
| | | | LD | - | - | - | - | - | - | - | - | - | - | - | 8.0 | 5.5 | 3.5 | 34.6 | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | |
| | 55 | FRN45VG1□-2J | HD | 14 | 5.5 | 3.5 | 41.1 | - | - | - | - | - | - | - | 22 | 14 | 8.0 | 58.1 | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - |
| | | | LD | - | - | - | - | - | - | - | - | - | - | - | 14 | 5.5 | 3.5 | 40.6 | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - |
| | 75 | FRN55VG1□-2J | HD | 14 | 8.0 | 5.5 | 50.8 | - | - | - | - | - | - | - | 38 | 14 | 14 | 71.8 | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - |
| | | | LD | - | - | - | - | - | - | - | - | - | - | - | 22 | 8.0 | 5.5 | 53.0 | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - |
| 90 | FRN75VG1□-2J | HD | 14 | 5.5 | 3.5 | 68.5 | - | - | - | - | - | - | 22 | 8 | 5.5 | 96.8 | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | | |
| | | LD | - | - | - | - | - | - | - | - | - | - | - | 14 | 5.5 | 3.5 | 67.1 | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | |
| 110 | FRN90VG1□-2J | HD | 14 | 8 | 5.5 | 82.2 | - | - | - | - | - | - | 22 | 14 | 8 | 116 | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | | |
| | | LD | - | - | - | - | - | - | - | - | - | - | - | 14 | 8 | 5.5 | 81.2 | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | |

Note 1: Assuming the use of aerial wiring (without rack or duct): 600 V class of vinyl-insulated IV wires for 60°C, 600 V class of polyethylene-insulated HIV wires for 75°C, and 600 V cross-linked polyethylene insulated wires for 90°C.

Note 2: □ in the inverter model represents an alphabet.



Note 3: **Bolded values** (n) denote wire sizes to be applied when a braking unit (BU) or braking resistor (DBR) is connected in parallel.

Bolded values in upper position: Wire sizes per unit connected in parallel

(n) in lower position: Number of parallels. For example, (2) denotes two parallels.

When a relay terminal block is provided and branching from the terminal block to each braking unit (BU) or braking resistor (DBR) is made, the wire size between the inverter and the relay terminal block should be selected based on the current values.

The wire sizes are selected for parallel wiring, taking into account the safety coefficient.

- 2 units in parallel: Current value x 1/85%
- 3 units in parallel: Current value x 1/80%
- 4 units in parallel: Current value x 1/70%


Table 8.4 Wire Size (for braking resistor) (continued)

HD (High Duty) mode: Heavy duty load applications
 MD (Medium Duty) mode: Medium duty load applications
 LD (Low Duty) mode: Light duty load applications

| Power supply voltage | Nominal applied motor (kW) | Inverter type | Specifications | 10% ED product | | | | | | | | | | | | 20% ED product | | | | | | | | | | | |
|----------------------|----------------------------|----------------|----------------|---|-----|----------------|------------------------------|----|----------------|------------------------------|------|----------------|------------------------------|------|----------------|---|-----|----------------|------------------------------|-----|----|----|------|-----|-----|-----|------|
| | | | | For braking resistor connection [P(+),DB] | | | | | | | | | | | | For braking resistor connection [P(+),DB] | | | | | | | | | | | |
| | | | | HD | | | MD | | | LD | | | HD | | | MD | | | LD | | | | | | | | |
| | | | | Maximum temperature (Note 1) | | | Maximum temperature (Note 1) | | | Maximum temperature (Note 1) | | | Maximum temperature (Note 1) | | | Maximum temperature (Note 1) | | | Maximum temperature (Note 1) | | | | | | | | |
| 60°C 75°C 90°C | | | 60°C 75°C 90°C | | | 60°C 75°C 90°C | | | 60°C 75°C 90°C | | | 60°C 75°C 90°C | | | 60°C 75°C 90°C | | | 60°C 75°C 90°C | | | | | | | | | |
| Current (A) | | | Current (A) | | | Current (A) | | | Current (A) | | | Current (A) | | | Current (A) | | | | | | | | | | | | |
| Three-phase 400V | 3.7 | FRN3.7VG1□-4J | HD | 2.0 | 2.0 | 2.0 | 1.7 | - | - | - | - | - | - | - | - | 2.0 | 2.0 | 2.0 | 2.4 | - | - | - | - | - | - | - | - |
| | 5.5 | FRN5.5VG1□-4J | HD | 2.0 | 2.0 | 2.0 | 2.5 | - | - | - | - | - | - | - | - | 2.0 | 2.0 | 2.0 | 3.6 | - | - | - | - | - | - | - | - |
| | 7.5 | FRN7.5VG1□-4J | HD | 2.0 | 2.0 | 2.0 | 3.4 | - | - | - | - | - | - | - | - | 2.0 | 2.0 | 2.0 | 4.8 | - | - | - | - | - | - | - | - |
| | 11 | FRN11VG1□-4J | HD | 2.0 | 2.0 | 2.0 | 5.1 | - | - | - | - | - | - | - | - | 2.0 | 2.0 | 2.0 | 7.2 | - | - | - | - | - | - | - | - |
| | 15 | FRN15VG1□-4J | HD | 2.0 | 2.0 | 2.0 | 6.8 | - | - | - | - | - | - | - | - | 2.0 | 2.0 | 2.0 | 9.7 | - | - | - | - | - | - | - | - |
| | 18.5 | FRN18.5VG1□-4J | HD | 2.0 | 2.0 | 2.0 | 8.8 | - | - | - | - | - | - | - | - | 2.0 | 2.0 | 2.0 | 12.4 | - | - | - | - | - | - | - | - |
| | 22 | FRN22VG1□-4J | HD | 2.0 | 2.0 | 2.0 | 10.2 | - | - | - | - | - | - | - | - | 2.0 | 2.0 | 2.0 | 14.4 | - | - | - | - | - | - | - | - |
| | 30 | FRN30VG1□-4J | HD | 2.0 | 2.0 | 2.0 | 15.0 | - | - | - | - | - | - | - | - | 3.5 | 2.0 | 2.0 | 19.4 | - | - | - | - | - | - | - | - |
| | 37 | FRN37VG1□-4J | LD | - | - | - | - | - | - | - | - | 2.0 | 2.0 | 2.0 | 14.9 | - | - | - | - | - | - | - | - | 3.5 | 2.0 | 2.0 | 19.2 |
| | 37 | | HD | 3.5 | 2.0 | 2.0 | 17.6 | - | - | - | - | - | - | - | - | 5.5 | 3.5 | 2.0 | 24.8 | - | - | - | - | - | - | - | - |
| | 45 | FRN45VG1□-4J | LD | - | - | - | - | - | - | - | - | 3.5 | 2.0 | 2.0 | 17.3 | - | - | - | - | - | - | - | - | 5.5 | 3.5 | 2.0 | 24.5 |
| | 45 | | HD | 3.5 | 2.0 | 2.0 | 20.5 | - | - | - | - | - | - | - | - | 8.0 | 3.5 | 2.0 | 29.0 | - | - | - | - | - | - | - | - |
| | 55 | FRN55VG1□-4J | LD | - | - | - | - | - | - | - | - | 3.5 | 2.0 | 2.0 | 20.3 | - | - | - | - | - | - | - | - | 8.0 | 3.5 | 2.0 | 28.7 |
| | 55 | | HD | 5.5 | 3.5 | 2.0 | 25.2 | - | - | - | - | - | - | - | - | 14 | 5.5 | 3.5 | 35.6 | - | - | - | - | - | - | - | - |
| | 75 | FRN75VG1□-4J | LD | - | - | - | - | - | - | - | - | 5.5 | 3.5 | 2.0 | 26.3 | - | - | - | - | - | - | - | - | 14 | 5.5 | 3.5 | 37.2 |
| | 75 | | HD | 8.0 | 5.5 | 3.5 | 34.6 | - | - | - | - | - | - | - | - | 14 | 8.0 | 5.5 | 48.9 | - | - | - | - | - | - | - | - |
| | 90 | FRN90VG1□-4J | LD | - | - | - | - | - | - | - | - | 8.0 | 5.5 | 3.5 | 33.9 | - | - | - | - | - | - | - | - | 14 | 8.0 | 5.5 | 47.9 |
| | 90 | | HD | 14 | 5.5 | 3.5 | 41.6 | - | - | - | - | - | - | - | - | 22 | 14 | 8.0 | 58.8 | - | - | - | - | - | - | - | - |
| | 110 | FRN110VG1□-4J | MD | - | - | - | - | 14 | 8.0 | 5.5 | 50.8 | - | - | - | - | - | - | - | - | 38 | 14 | 14 | 71.8 | - | - | - | |
| | 110 | | LD | - | - | - | - | - | - | - | - | 14 | 5.5 | 3.5 | 41.1 | - | - | - | - | - | - | - | - | 22 | 14 | 8.0 | 58.2 |
| | 110 | FRN110VG1□-4J | HD | 14 | 8.0 | 5.5 | 50.8 | - | - | - | - | - | - | - | - | 38 | 14 | 14 | 71.8 | - | - | - | - | - | - | - | - |
| | 132 | | MD | - | - | - | - | 22 | 14 | 8.0 | 61.7 | - | - | - | - | - | - | - | - | 38 | 22 | 14 | 87.3 | - | - | - | |
| | 132 | FRN132VG1□-4J | LD | - | - | - | - | - | - | - | - | 14 | 8.0 | 5.5 | 49.7 | - | - | - | - | - | - | - | - | 38 | 14 | 14 | 70.4 |
| | 132 | | HD | 22 | 14 | 8.0 | 61.7 | - | - | - | - | - | - | - | - | 38 | 22 | 14 | 87.3 | - | - | - | - | - | - | - | - |
| | 160 | FRN160VG1□-4J | MD | - | - | - | - | 38 | 14 | 14 | 73.9 | - | - | - | - | - | - | - | - | 60 | 38 | 22 | 104 | - | - | - | |
| | 160 | | LD | - | - | - | - | - | - | - | - | 22 | 14 | 8.0 | 60.8 | - | - | - | - | - | - | - | - | 38 | 22 | 14 | 85.9 |
| | 160 | FRN160VG1□-4J | HD | 38 | 14 | 14 | 73.9 | - | - | - | - | - | - | - | - | 60 | 38 | 22 | 104 | - | - | - | - | - | - | - | - |
| | 200 | | MD | - | - | - | - | 38 | 22 | 14 | 92.6 | - | - | - | - | - | - | - | - | 100 | 38 | 22 | 131 | - | - | - | |
| 200 | FRN160VG1□-4J | LD | - | - | - | - | - | - | - | - | 38 | 14 | 14 | 73.9 | - | - | - | - | - | - | - | - | 60 | 38 | 22 | 104 | |
| 200 | | HD | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | |

Note 1: Assuming the use of aerial wiring (without rack or duct): 600 V class of vinyl-insulated IV wires for 60°C, 600 V class of polyethylene-insulated HIV wires for 75°C, and 600 V cross-linked polyethylene insulated wires for 90°C.

Note 2: □ in the inverter model represents an alphabet.



■ If the internal temperature of your power control panel is 40°C or below


Table 8.4 Wire Size (for braking resistor) (continued)

HD (High Duty) mode: Heavy duty load applications
LD (Low Duty) mode: Light duty load applications

| Power supply voltage | Nominal applied motor (kW) | Inverter type | Specifications | 10% ED product | | | | | | | | | | | | 20% ED product | | | | | | | | | | | | | | | | | | | | | | | | | | |
|----------------------|----------------------------|----------------|-----------------|---|-------------------|-------------------|------------------------------|---|----------------|------------------------------|---|----------------|------------------------------|---|----------------|---|---|------------------|------------------------------|-----------------|-------------------|------|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|
| | | | | For braking resistor connection [P(+),DB] | | | | | | | | | | | | For braking resistor connection [P(+),DB] | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | | | | HD | | | MD | | | LD | | | HD | | | MD | | | LD | | | | | | | | | | | | | | | | | | | | | | | |
| | | | | Maximum temperature (Note 1) | | | Maximum temperature (Note 1) | | | Maximum temperature (Note 1) | | | Maximum temperature (Note 1) | | | Maximum temperature (Note 1) | | | Maximum temperature (Note 1) | | | | | | | | | | | | | | | | | | | | | | | |
| 60°C 75°C 90°C | | | 60°C 75°C 90°C | | | 60°C 75°C 90°C | | | 60°C 75°C 90°C | | | 60°C 75°C 90°C | | | 60°C 75°C 90°C | | | 60°C 75°C 90°C | | | | | | | | | | | | | | | | | | | | | | | | |
| | | | Current (A) | | | Current (A) | | | Current (A) | | | Current (A) | | | Current (A) | | | Current (A) | | | | | | | | | | | | | | | | | | | | | | | | |
| Three-phase 200V | 0.75 | FRN0.75VG1□-2J | HD | 2.0 | 2.0 | 2.0 | 1.4 | - | - | - | - | - | - | - | - | - | - | 2.0 | 2.0 | 2.0 | 1.9 | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | |
| | 1.5 | FRN1.5VG1□-2J | HD | 2.0 | 2.0 | 2.0 | 1.9 | - | - | - | - | - | - | - | - | - | - | - | 2.0 | 2.0 | 2.0 | 2.7 | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | | |
| | 2.2 | FRN2.2VG1□-2J | HD | 2.0 | 2.0 | 2.0 | 2.3 | - | - | - | - | - | - | - | - | - | - | - | 2.0 | 2.0 | 2.0 | 3.3 | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | |
| | 3.7 | FRN3.7VG1□-2J | HD | 2.0 | 2.0 | 2.0 | 3.4 | - | - | - | - | - | - | - | - | - | - | - | 2.0 | 2.0 | 2.0 | 4.8 | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | |
| | 5.5 | FRN5.5VG1□-2J | HD | 2.0 | 2.0 | 2.0 | 5.1 | - | - | - | - | - | - | - | - | - | - | - | 2.0 | 2.0 | 2.0 | 7.2 | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | |
| | 7.5 | FRN7.5VG1□-2J | HD | 2.0 | 2.0 | 2.0 | 6.8 | - | - | - | - | - | - | - | - | - | - | - | 2.0 | 2.0 | 2.0 | 9.7 | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | |
| | 11 | FRN11VG1□-2J | HD | 2.0 | 2.0 | 2.0 | 10.2 | - | - | - | - | - | - | - | - | - | - | - | 2.0 | 2.0 | 2.0 | 14.4 | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | |
| | 15 | FRN15VG1□-2J | HD | 2.0 | 2.0 | 2.0 | 13.7 | - | - | - | - | - | - | - | - | - | - | - | 2.0 | 2.0 | 2.0 | 19.4 | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | |
| | 18.5 | FRN18.5VG1□-2J | HD | 2.0 | 2.0 | 2.0 | 17.6 | - | - | - | - | - | - | - | - | - | - | - | 3.5 | 2.0 | 2.0 | 24.8 | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | |
| | 22 | FRN22VG1□-2J | HD | 2.0 | 2.0 | 2.0 | 20.3 | - | - | - | - | - | - | - | - | - | - | - | 3.5 | 2.0 | 2.0 | 28.7 | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - |
| | 30 | FRN30VG1□-2J | HD | 3.5 | 3.5 | 2.0 | 30.0 | - | - | - | - | - | - | - | - | - | - | - | 5.5 | 3.5 | 3.5 | 38.7 | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | |
| | 37 | | LD | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | | |
| | 37 | FRN37VG1□-2J | HD | 5.5 | 3.5 | 3.5 | 35.1 | - | - | - | - | - | - | - | - | - | - | - | 8.0 | 5.5 | 5.5 | 48.1 | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | |
| | 45 | | LD | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | | |
| | 45 | FRN45VG1□-2J | HD | 8.0 | 5.5 | 3.5 | 41.1 | - | - | - | - | - | - | - | - | - | - | - | 14 | 8.0 | 5.5 | 58.1 | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | |
| | 55 | | LD | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | |
| | 55 | FRN55VG1□-2J | HD | 14 | 5.5 | 5.5 | 50.8 | - | - | - | - | - | - | - | - | - | - | - | 14 | 14 | 8.0 | 71.8 | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | |
| | 75 | | LD | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | |
| | 75 | FRN75VG1□-2J | HD | 8 (2) | 5.5 (2) | 3.5 (2) | 68.5 | - | - | - | - | - | - | - | - | - | - | - | 14 (2) | 8 (2) | 5.5 (2) | 96.8 | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | |
| | 90 | | LD | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | |
| 90 | FRN90VG1□-2J | HD | 8 (2) | 5.5 (2) | 5.5 (2) | 82.2 | - | - | - | - | - | - | - | - | - | - | - | 14 (2) | 8 (2) | 8 (2) | 116 | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | | |
| 110 | | LD | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | | |

Note 1: Assuming the use of aerial wiring (without rack or duct): 600 V class of vinyl-insulated IV wires for 60°C, 600 V class of polyethylene-insulated HIV wires for 75°C, and 600 V cross-linked polyethylene insulated wires for 90°C.

Note 2: □ in the inverter model represents an alphabet.



Note 3: **Bolded values** (n) denote wire sizes to be applied when a braking unit (BU) or braking resistor (DBR) is connected in parallel.

Bolded values in upper position: Wire sizes per unit connected in parallel

(n) in lower position: Number of parallels. For example, (2) denotes two parallels.

When a relay terminal block is provided and branching from the terminal block to each braking unit (BU) or braking resistor (DBR) is made, the wire size between the inverter and the relay terminal block should be selected based on the current values.

The wire sizes are selected for parallel wiring, taking into account the safety coefficient.

- 2 units in parallel: Current value x 1/85%

- 3 units in parallel: Current value x 1/80%

- 4 units in parallel: Current value x 1/70%

Table 8.4 Wire Size (for braking resistor) (continued)

HD (High Duty) mode: Heavy duty load applications
 MD (Medium Duty) mode: Medium duty load applications
 LD (Low Duty) mode: Light duty load applications

| Power supply voltage | Nominal applied motor (kW) | Inverter type | Specifications | 10% ED product | | | | | | | | | | | | 20% ED product | | | | | | | | | | | |
|----------------------|----------------------------|----------------|----------------|---|------|------|--------------|------------------------------|------|------|--------------|------------------------------|------|------|--------------|---|------|------|--------------|------------------------------|------|-----|--------------|-----|-----|------|------|
| | | | | For braking resistor connection [P(+),DB] | | | | | | | | | | | | For braking resistor connection [P(+),DB] | | | | | | | | | | | |
| | | | | HD | | | MD | | | LD | | | HD | | | MD | | | LD | | | | | | | | |
| | | | | Maximum temperature (Note 1) | | | Cur-rent (A) | Maximum temperature (Note 1) | | | Cur-rent (A) | Maximum temperature (Note 1) | | | Cur-rent (A) | Maximum temperature (Note 1) | | | Cur-rent (A) | Maximum temperature (Note 1) | | | Cur-rent (A) | | | | |
| 60°C | 75°C | 90°C | 60°C | 75°C | 90°C | 60°C | | 75°C | 90°C | 60°C | | 75°C | 90°C | 60°C | | 75°C | 90°C | 60°C | | 75°C | 90°C | | | | | | |
| Three-phase 400V | 3.7 | FRN3.7VG1□-4J | HD | 2.0 | 2.0 | 2.0 | 1.7 | - | - | - | - | - | - | - | - | 2.0 | 2.0 | 2.0 | 2.4 | - | - | - | - | - | - | - | - |
| | 5.5 | FRN5.5VG1□-4J | HD | 2.0 | 2.0 | 2.0 | 2.5 | - | - | - | - | - | - | - | - | 2.0 | 2.0 | 2.0 | 3.6 | - | - | - | - | - | - | - | - |
| | 7.5 | FRN7.5VG1□-4J | HD | 2.0 | 2.0 | 2.0 | 3.4 | - | - | - | - | - | - | - | - | 2.0 | 2.0 | 2.0 | 4.8 | - | - | - | - | - | - | - | - |
| | 11 | FRN11VG1□-4J | HD | 2.0 | 2.0 | 2.0 | 5.1 | - | - | - | - | - | - | - | - | 2.0 | 2.0 | 2.0 | 7.2 | - | - | - | - | - | - | - | - |
| | 15 | FRN15VG1□-4J | HD | 2.0 | 2.0 | 2.0 | 6.8 | - | - | - | - | - | - | - | - | 2.0 | 2.0 | 2.0 | 9.7 | - | - | - | - | - | - | - | - |
| | 18.5 | FRN18.5VG1□-4J | HD | 2.0 | 2.0 | 2.0 | 8.8 | - | - | - | - | - | - | - | - | 2.0 | 2.0 | 2.0 | 12.4 | - | - | - | - | - | - | - | - |
| | 22 | FRN22VG1□-4J | HD | 2.0 | 2.0 | 2.0 | 10.2 | - | - | - | - | - | - | - | - | 2.0 | 2.0 | 2.0 | 14.4 | - | - | - | - | - | - | - | - |
| | 30 | FRN30VG1□-4J | HD | 2.0 | 2.0 | 2.0 | 15.0 | - | - | - | - | - | - | - | - | 2.0 | 2.0 | 2.0 | 19.4 | - | - | - | - | - | - | - | - |
| | 37 | | LD | - | - | - | - | - | - | - | - | 2.0 | 2.0 | 2.0 | 14.9 | - | - | - | - | - | - | - | - | 2.0 | 2.0 | 2.0 | 19.2 |
| | 37 | FRN37VG1□-4J | HD | 2.0 | 2.0 | 2.0 | 17.6 | - | - | - | - | - | - | - | - | 3.5 | 2.0 | 2.0 | 24.8 | - | - | - | - | - | - | - | - |
| | 45 | | LD | - | - | - | - | - | - | - | - | 2.0 | 2.0 | 2.0 | 17.3 | - | - | - | - | - | - | - | - | 3.5 | 2.0 | 2.0 | 24.5 |
| | 45 | FRN45VG1□-4J | HD | 2.0 | 2.0 | 2.0 | 20.5 | - | - | - | - | - | - | - | - | 3.5 | 3.5 | 2.0 | 29.0 | - | - | - | - | - | - | - | - |
| | 55 | | LD | - | - | - | - | - | - | - | - | 2.0 | 2.0 | 2.0 | 20.3 | - | - | - | - | - | - | - | - | 3.5 | 2.0 | 2.0 | 28.7 |
| | 55 | FRN55VG1□-4J | HD | 3.5 | 2.0 | 2.0 | 25.2 | - | - | - | - | - | - | - | - | 5.5 | 3.5 | 3.5 | 35.6 | - | - | - | - | - | - | - | - |
| | 75 | | LD | - | - | - | - | - | - | - | - | 3.5 | 2.0 | 2.0 | 26.3 | - | - | - | - | - | - | - | - | 5.5 | 3.5 | 3.5 | 37.2 |
| | 75 | FRN75VG1□-4J | HD | 5.5 | 3.5 | 3.5 | 34.6 | - | - | - | - | - | - | - | - | 8.0 | 5.5 | 5.5 | 48.9 | - | - | - | - | - | - | - | - |
| | 90 | | LD | - | - | - | - | - | - | - | - | 5.5 | 3.5 | 2.0 | 33.9 | - | - | - | - | - | - | - | - | 8.0 | 5.5 | 5.5 | 47.9 |
| | 90 | FRN90VG1□-4J | HD | 8.0 | 5.5 | 3.5 | 41.6 | - | - | - | - | - | - | - | - | 14 | 8.0 | 5.5 | 58.8 | - | - | - | - | - | - | - | - |
| | 110 | | MD | - | - | - | - | 14 | 5.5 | 5.5 | 50.8 | - | - | - | - | - | - | - | - | 14 | 14 | 8.0 | 71.8 | - | - | - | - |
| | 110 | FRN110VG1□-4J | LD | - | - | - | - | - | - | - | - | 8.0 | 5.5 | 3.5 | 41.1 | - | - | - | - | - | - | - | - | 14 | 8.0 | 5.5 | 58.2 |
| | 110 | | HD | 14 | 5.5 | 5.5 | 50.8 | - | - | - | - | - | - | - | - | 14 | 14 | 8.0 | 71.8 | - | - | - | - | - | - | - | - |
| | 132 | FRN132VG1□-4J | MD | - | - | - | - | 14 | 8.0 | 5.5 | 61.7 | - | - | - | - | - | - | - | - | 22 | 14 | 14 | 87.3 | - | - | - | - |
| | 132 | | LD | - | - | - | - | - | - | - | - | 8.0 | 5.5 | 5.5 | 49.7 | - | - | - | - | - | - | - | - | 14 | 14 | 8.0 | 70.4 |
| | 132 | FRN132VG1□-4J | HD | 14 | 8.0 | 5.5 | 61.7 | - | - | - | - | - | - | - | - | 22 | 14 | 14 | 87.3 | - | - | - | - | - | - | - | - |
| 160 | MD | | - | - | - | - | 22 | 14 | 8.0 | 73.9 | - | - | - | - | - | - | - | - | 38 | 22 | 14 | 104 | - | - | - | - | |
| 160 | FRN160VG1□-4J | LD | - | - | - | - | - | - | - | - | 14 | 8.0 | 5.5 | 60.8 | - | - | - | - | - | - | - | - | 22 | 14 | 14 | 85.9 | |
| 160 | | HD | 22 | 14 | 8.0 | 73.9 | - | - | - | - | - | - | - | - | 38 | 22 | 14 | 104 | - | - | - | - | - | - | - | - | |
| 200 | FRN160VG1□-4J | MD | - | - | - | - | 22 | 14 | 14 | 92.6 | - | - | - | - | - | - | - | - | 38 | 38 | 22 | 131 | - | - | - | - | |
| 200 | | LD | - | - | - | - | - | - | - | - | 22 | 14 | 8.0 | 73.9 | - | - | - | - | - | - | - | - | 38 | 22 | 14 | 104 | |

Note 1: Assuming the use of aerial wiring (without rack or duct): 600 V class of vinyl-insulated IV wires for 60°C, 600 V class of polyethylene-insulated HIV wires for 75°C, and 600 V cross-linked polyethylene insulated wires for 90°C.

Note 2: □ in the inverter model represents an alphabet.

□
 S (Basic type)


Table 8.4 Wire Size (for braking resistor) (continued)

HD (High Duty) mode: Heavy duty load applications
 MD (Medium Duty) mode: Medium duty load applications
 LD (Low Duty) mode: Light duty load applications

| Power supply voltage | Nominal applied motor (kW) | Inverter type | Specifications | 10% ED product | | | | | | | | | 20% ED product | | | | | | | | | | | | | | | | | | | | | | | | |
|----------------------|----------------------------|---------------|------------------|---|-------------------|------|------------------|------------------------------|-------------------|------|------------------|------------------------------|---|------|-------------|------------------------------|------------------|------------------|-------------|------------------------------|------------------|------------------|------------------|------|------|------------------|------------------|------------------|-----------------|-----|---|---|---|---|---|---|---|
| | | | | For braking resistor connection [P(+),DB] | | | | | | | | | For braking resistor connection [P(+),DB] | | | | | | | | | | | | | | | | | | | | | | | | |
| | | | | HD | | | MD | | | LD | | | HD | | | MD | | | LD | | | | | | | | | | | | | | | | | | |
| | | | | Maximum temperature (Note 1) | | | Current (A) | Maximum temperature (Note 1) | | | Current (A) | Maximum temperature (Note 1) | | | Current (A) | Maximum temperature (Note 1) | | | Current (A) | Maximum temperature (Note 1) | | | Current (A) | | | | | | | | | | | | | | |
| | | | | 60°C | 75°C | 90°C | | 60°C | 75°C | 90°C | | 60°C | 75°C | 90°C | | 60°C | 75°C | 90°C | | 60°C | 75°C | 90°C | | 60°C | 75°C | 90°C | | | | | | | | | | | |
| 200 | FRN200VG1□-4J | HD | 14 (2) | 5.5 (2) | 5.5 (2) | 92.6 | - | - | - | - | - | - | - | - | - | 22 (2) | 14 (2) | 8 (2) | 131 | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - |
| 220 | | MD | - | - | - | - | 14 (2) | 8 (2) | 5.5 (2) | 102 | - | - | - | - | - | - | - | - | - | - | 22 (2) | 14 (2) | 14 (2) | 144 | - | - | - | - | - | - | - | - | - | - | - | - | - |
| 220 | | LD | - | - | - | - | - | - | - | - | 14 (2) | 5.5 (2) | 5.5 (2) | 86.8 | - | - | - | - | - | - | - | - | - | - | - | - | 22 (2) | 14 (2) | 8 (2) | 123 | - | - | - | - | - | - | - |
| 220 | FRN220VG1□-4J | HD | 14 (2) | 8 (2) | 5.5 (2) | 102 | - | - | - | - | - | - | - | - | - | 22 (2) | 14 (2) | 14 (2) | 144 | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | |
| 250 | | MD | - | - | - | - | 14 (2) | 14 (2) | 8 (2) | 120 | - | - | - | - | - | - | - | - | - | - | 38 (2) | 22 (2) | 14 (2) | 170 | - | - | - | - | - | - | - | - | - | - | - | - | - |
| 280 | | LD | - | - | - | - | - | - | - | - | 14 (2) | 8 (2) | 5.5 (2) | 102 | - | - | - | - | - | - | - | - | - | - | - | 22 (2) | 14 (2) | 14 (2) | 145 | - | - | - | - | - | - | - | - |
| 280 | FRN280VG1□-4J | HD | 22 (2) | 14 (2) | 8 (2) | 138 | - | - | - | - | - | - | - | - | - | 38 (2) | 22 (2) | 14 (2) | 195 | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | |
| 315 | | MD | - | - | - | - | 22 (2) | 14 (2) | 14 (2) | 147 | - | - | - | - | - | - | - | - | - | - | 38 (2) | 22 (2) | 22 (2) | 207 | - | - | - | - | - | - | - | - | - | - | - | - | - |
| 355 | | LD | - | - | - | - | - | - | - | - | 22 (2) | 14 (2) | 14 (2) | 139 | - | - | - | - | - | - | - | - | - | - | - | 38 (2) | 22 (2) | 22 (2) | 197 | - | - | - | - | - | - | - | - |
| 315 | FRN315VG1□-4J | HD | 22 (2) | 14 (2) | 14 (2) | 147 | - | - | - | - | - | - | - | - | - | 38 (2) | 22 (2) | 22 (2) | 207 | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | |
| 355 | | MD | - | - | - | - | 14 (3) | 14 (3) | 8 (3) | 175 | - | - | - | - | - | - | - | - | - | - | 38 (3) | 22 (3) | 14 (3) | 248 | - | - | - | - | - | - | - | - | - | - | - | - | - |
| 400 | | LD | - | - | - | - | - | - | - | - | 22 (2) | 14 (2) | 14 (2) | 148 | - | - | - | - | - | - | - | - | - | - | - | 60 (2) | 38 (2) | 22 (2) | 235 | - | - | - | - | - | - | - | - |
| 355 | FRN355VG1□-4J | HD | 14 (3) | 14 (3) | 8 (3) | 175 | - | - | - | - | - | - | - | - | - | 38 (3) | 22 (3) | 14 (3) | 248 | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | |
| 400 | | MD | - | - | - | - | 22 (3) | 14 (3) | 8 (3) | 186 | - | - | - | - | - | - | - | - | - | - | 38 (3) | 22 (3) | 14 (3) | 263 | - | - | - | - | - | - | - | - | - | - | - | - | - |
| 450 | | LD | - | - | - | - | - | - | - | - | 14 (3) | 14 (3) | 8 (3) | 177 | - | - | - | - | - | - | - | - | - | - | - | 38 (3) | 22 (3) | 14 (3) | 250 | - | - | - | - | - | - | - | - |
| 400 | FRN400VG1□-4J | HD | 22 (3) | 14 (3) | 8 (3) | 186 | - | - | - | - | - | - | - | - | - | 38 (3) | 22 (3) | 14 (3) | 263 | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | |
| 450 | | MD | - | - | - | - | 38 (3) | 14 (3) | 14 (3) | 228 | - | - | - | - | - | - | - | - | - | - | 60 (3) | 38 (3) | 22 (3) | 322 | - | - | - | - | - | - | - | - | - | - | - | - | - |
| 500 | | LD | - | - | - | - | - | - | - | - | 22 (3) | 14 (3) | 8 (3) | 186 | - | - | - | - | - | - | - | - | - | - | - | 38 (3) | 22 (3) | 14 (3) | 263 | - | - | - | - | - | - | - | - |
| 500 | FRN500VG1□-4J | HD | 22 (4) | 14 (4) | 14 (4) | 240 | - | - | - | - | - | - | - | - | - | 38 (4) | 22 (4) | 22 (4) | 340 | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | |
| 630 | | LD | - | - | - | - | - | - | - | - | 22 (4) | 14 (4) | 14 (4) | 241 | - | - | - | - | - | - | - | - | - | - | - | 38 (4) | 22 (4) | 22 (4) | 341 | - | - | - | - | - | - | - | - |
| 630 | FRN630VG1□-4J | HD | 22 (4) | 14 (4) | 14 (4) | 293 | - | - | - | - | - | - | - | - | - | 38 (4) | 22 (4) | 22 (4) | 381 | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | |
| 710 | | LD | - | - | - | - | - | - | - | - | 38 (4) | 22 (4) | 14 (4) | 278 | - | - | - | - | - | - | - | - | - | - | - | 60 (4) | 38 (4) | 22 (4) | 394 | - | - | - | - | - | - | - | - |

Note 1: Assuming the use of aerial wiring (without rack or duct): 600 V class of vinyl-insulated IV wires for 60°C, 600 V class of polyethylene-insulated HIV wires for 75°C, and 600 V cross-linked polyethylene insulated wires for 90°C.

Note 2: □ in the inverter model represents an alphabet.



Note 3: **Bolded values** (n) denote wire sizes to be applied when a braking unit (BU) or braking resistor (DBR) is connected in parallel.

Bolded values in upper position: Wire sizes per unit connected in parallel

(n) in lower position: Number of parallels. For example, (2) denotes two parallels.

When a relay terminal block is provided and branching from the terminal block to each braking unit (BU) or braking resistor (DBR) is made, the wire size between the inverter and the relay terminal block should be selected based on the current values.

The wire sizes are selected for parallel wiring, taking into account the safety coefficient.

- 2 units in parallel: Current value x 1/85%
- 3 units in parallel: Current value x 1/80%
- 4 units in parallel: Current value x 1/70%

8.4 Peripheral Equipment

8.4.1 Molded case circuit breaker or residual-current-operated protective device/earth leakage circuit breaker/magnetic contactor

8.4.1.1 Functional overview

■ MCCBs and RCDs/ELCBs*

* With overcurrent protection

Molded Case Circuit Breakers (MCCBs) are designed to protect the power circuits between the power supply and inverter's main circuit terminals ([L1/R], [L2/S] and [L3/T]) from overload or short-circuit, which in turn prevents secondary accidents caused by the broken inverter.

Residual-Current-Operated Protective Devices (RCDs)/Earth Leakage Circuit Breakers (ELCBs) function in the same way as MCCBs.

Built-in overcurrent/overload protective functions protect the inverter itself from failures related to its input/output lines.


■ MCs

An MC can be used at both the power input and output sides of the inverter. At each side, the MC works as described below. Use as needed. When inserted in the output circuit of the inverter, the MC can also switch the motor drive power supply between the inverter output and commercial power lines.




At the power supply side

Insert an MC in the power supply side of the inverter in order to:

- (1) Forcibly cut off the inverter from the power supply (generally, commercial/factory power lines) with the protective function built into the inverter, or with the external signal input.
- (2) Stop the inverter operation in an emergency when the inverter cannot interpret the stop command due to internal/external circuit failures.
- (3) Cut off the inverter from the power supply when the MCCB inserted in the power supply side cannot cut it off for maintenance or inspection purpose. For the purpose only, it is recommended that you use an MC capable of turning the MC ON/OFF manually.

 **Note** Avoid frequent ON/OFF operation of the magnetic contactor (MC) in the input circuit; otherwise, the inverter failure may result.


The frequency of the MC's ON/OFF should not be more than once per 30 minutes. To assure 10-year or longer service life of the inverter, it should not be more than once per hour.

If frequent start/stop of the motor is required, use FWD/REV terminal signals or the  /  /  keys on the inverter's keypad.

At the output side

Insert an MC in the power output side of the inverter in order to:

- (1) Prevent externally turned-around current from being applied to the inverter power output terminals ([U], [V], and [W]) unexpectedly. An MC should be used, for example, when a circuit that switches the motor driving power supply between the inverter output and commercial power lines is connected to the inverter.

 **Tip** If a magnetic contactor (MC) is inserted in the inverter's output (secondary) circuit for switching the motor to a commercial power or for any other purposes, it should be switched on and off when both the inverter and motor are completely stopped. This prevents the contact point from getting rough due to a switching arc of the MC. The MC should not be equipped with any main circuit surge killer (Fuji SZ-ZM□, etc.).

Applying a commercial power to the inverter's output circuit breaks the inverter. To avoid it, interlock the MC on the motor's commercial power line with the one in the inverter output circuit so that they are not switched ON at the same time.

- (2) Drive more than one motor selectively by a single inverter.
- (3) Selectively cut off the motor whose thermal overload relay or equivalent devices have been activated.


Driving the motor using commercial power lines


MCs can also be used to switch the power supply of the motor driven by the inverter to a commercial power supply.

Select the MC so as to satisfy the rated currents listed in Table 8.1, which are the most critical RMS currents for using the inverter. (Refer to Table 8.4) For switching the motor drive source between the inverter output and commercial power lines, use the MC of class AC3 specified by JIS C8325 in the commercial line side.


8.4.1.2 Connection example and criteria for selection of circuit breakers

Figure 8.2 shows a connection example for MCCB or RCD/ELCB (with overcurrent protection) and MC in the inverter input circuit. Table 8.5 lists the rated current for the MCCB and corresponding inverter models. Table 8.6 lists the applicable grades of RCD/ELCB sensitivity.

| |
|---|
|  WARNING |
| <p>Insert an MCCB or RCD/ELCB (with overcurrent protection) recommended for each inverter for its input circuits. Do not use an MCCB or RCD/ELCB of a higher rating than that recommended.</p> <p>Doing so could result in a fire.</p> |



Molded case circuit breaker or residual-current-operated protective device/earth leakage circuit breaker



Magnetic contactor





Figure 8.2 External Views of MCCB or RCD/ELCB and MC and Connection Example

Table 8.5 Rated Current of Molded Case Circuit Breaker (MCCB), Residual-Current-Operated Protective Device (RCD)/Earth Leakage Circuit Breaker (ELCB) and Magnetic Contactor (MC)

HD (High Duty) mode: Heavy duty load applications
 LD (Low Duty) mode: Light duty load applications

| Power supply voltage | Nominal applied motor (kW) | Inverter type | Specifications | MCCB, ELCB Rated current(A) | | Magnetic contactor (MC) | | | |
|----------------------|----------------------------|----------------|----------------|-----------------------------|---------|-------------------------|---------|--------------------|----|
| | | | | | | For input circuit | | For output circuit | |
| | | | | DC reactor (DCR) | | DC reactor (DCR) | | HD | LD |
| | | | | w/ DCR | w/o DCR | w/ DCR | w/o DCR | | |
| Three-phase 200V | 0.75 | FRN0.75VG1□-2J | HD | 5 | 10 | SC-05 | SC-05 | - | |
| | 1.5 | FRN1.5VG1□-2J | | 10 | 15 | | | | |
| | 2.2 | FRN2.2VG1□-2J | | 20 | 30 | | | | |
| | 3.7 | FRN3.7VG1□-2J | | 30 | 50 | | | | |
| | 5.5 | FRN5.5VG1□-2J | | 40 | 75 | | | | |
| | 7.5 | FRN7.5VG1□-2J | | 50 | 100 | | | | |
| | 11 | FRN11VG1□-2J | | 75 | 125 | | | | |
| | 15 | FRN15VG1□-2J | | 100 | 150 | | | | |
| | 18.5 | FRN18.5VG1□-2J | | 150 | 175 | | | | |
| | 22 | FRN22VG1□-2J | | 150 | 200 | | | | |
| | 30 | FRN30VG1□-2J | LD | 175 | 250 | SC-N5 | - | SC-N5 | |
| | 37 | FRN37VG1□-2J | | 200 | 300 | | - | SC-N7 | |
| | 45 | FRN45VG1□-2J | | 250 | 350 | | - | SC-N8 | |
| | 55 | FRN55VG1□-2J | | 350 | - | | - | SC-N10 | |
| | 75 | FRN75VG1□-2J | | 400 | - | | - | SC-N11 | |
| | 90 | FRN90VG1□-2J | | 500 | - | | - | SC-N11 | |
| | 110 | FRN90VG1□-2J | | 500 | - | | - | SC-N12 | |

Note: □ in the inverter model represents an alphabet.



- Install the MCCB or RCD/ELCB at the input side of the inverter. They cannot be installed at the output side of the inverter.
- The above table lists the rated current of MCCBs and RCD/ELCBs to be used in the power control panel with an internal temperature of lower than 50°C. The rated current is factored by a correction coefficient of 0.85 as the RCDs'/MCCBs' and ELCBs' original rated current is specified when using them in a surrounding temperature of 40°C or lower. Select an MCCB and/or RCD/ELCB suitable for the actual short-circuit breaking capacity needed for your power systems.
- For the selection of the MC type, it is assumed that the 600 V HIV (allowable surrounding temperature: 75°C) wires for the power input/output of the inverter are used. If an MC type for another class of wires is selected, the wire size suitable for the terminal size of both the inverter and the MC type should be taken into account.
- Use ELCBs with overcurrent protection.
- To protect your power systems from secondary accidents caused by the broken inverter, use an MCCB and/or RCD/ELCB with the rated current listed in the above table. Do not use an MCCB or RCD/ELCB with a rating higher than that listed.

**Table 8.5 Rated Current of Molded Case Circuit Breaker (MCCB), Residual-Current-Operated Protective Device (RCD)/Earth Leakage Circuit Breaker (ELCB) and Magnetic Contactor (MC)
(continued)**

HD (High Duty) mode: Heavy duty load applications
 MD (Medium Duty) mode: Medium duty load applications
 LD (Low Duty) mode: Light duty load applications

| Power supply voltage | Nominal applied motor (kW) | Inverter type | Specifications | MCCB, ELCB Rated current(A) | | Magnetic contactor (MC) | | | | | |
|----------------------|----------------------------|---------------|----------------|-----------------------------|---------|-------------------------|---------|--------------------|--------|-------|--------|
| | | | | DC reactor (DCR) | | For input circuit | | For output circuit | | | |
| | | | | w/ DCR | w/o DCR | w/ DCR | w/o DCR | HD | MD | LD | |
| Three-phase 400V | 3.7 | FRN3.7VG1□-4 | HD | 10 | 20 | SC-05 | SC-05 | - | - | - | |
| | 5.5 | FRN5.5VG1□-4 | | 15 | 30 | | SC-4-0 | | | | SC-05 |
| | 7.5 | FRN7.5VG1□-4 | | 20 | 40 | | SC-5-1 | | | | SC-05 |
| | 11 | FRN11VG1□-4 | | 30 | 50 | SC-5-1 | SC-4-0 | | | | |
| | 15 | FRN15VG1□-4 | | 40 | 60 | | SC-N1 | | | | SC-5-1 |
| | 18.5 | FRN18.5VG1□-4 | | 75 | 100 | SC-N1 | SC-N2 | | | | SC-N1 |
| | 22 | FRN22VG1□-4 | | | | | SC-N2S | | | | SC-N1 |
| | 30 | FRN30VG1□-4 | | 75 | 125 | SC-N2 | SC-N3 | | | | SC-N2 |
| | 37 | FRN37VG1□-4 | | LD | | 100 | SC-N2S | | | | - |
| | 45 | | | HD | 150 | | SC-N4 | | | | SC-N2S |
| | 55 | FRN45VG1□-4 | LD | 125 | | 200 | | SC-N3 | SC-N3 | SC-N3 | |
| | | | HD | | SC-N5 | | SC-N4 | | SC-N4 | | |
| | 75 | FRN55VG1□-4 | LD | 175 | - | SC-N4 | SC-N4 | SC-N5 | | | |
| | | | HD | | | | SC-N5 | SC-N5 | SC-N5 | | |
| | 90 | FRN75VG1□-4 | LD | 200 | - | SC-N7 | SC-N7 | SC-N7 | | | |
| | | | HD | | | | SC-N7 | SC-N7 | SC-N7 | | |
| | 110 | FRN90VG1□-4 | MD/LD | 250 | - | SC-N8 | - | SC-N8 | SC-N8 | | |
| | | | HD | | | | SC-N8 | SC-N8 | SC-N8 | | |
| | 132 | FRN110VG1□-4 | MD/LD | 300 | - | SC-N8 | - | SC-N8 | SC-N8 | | |
| | | | HD | | | | SC-N8 | SC-N8 | SC-N8 | | |
| | 160 | FRN132VG1□-4 | MD/LD | 350 | - | SC-N11 | - | SC-N11 | SC-N11 | | |
| | | | HD | | | | SC-N11 | SC-N11 | SC-N11 | | |
| | 200 | FRN160VG1□-4 | MD/LD | 500 | - | SC-N12 | - | SC-N12 | SC-N12 | | |
| | | | HD | | | | SC-N12 | SC-N12 | SC-N12 | | |
| | 220 | FRN200VG1□-4 | MD/LD | 500 | - | SC-N12 | SC-N12 | SC-N12 | SC-N12 | | |
| | | | HD | | | | SC-N12 | SC-N12 | SC-N12 | | |
| | 250 | FRN220VG1□-4 | MD | 600 | - | SC-N14 | - | SC-N14 | SC-N14 | | |
| | | | LD | | | | SC-N14 | SC-N14 | SC-N14 | | |
| | 280 | FRN280VG1□-4 | HD | 800 | - | SC-N14 | SC-N14 | SC-N14 | SC-N14 | | |
| | | | MD | | | | SC-N14 | SC-N14 | SC-N14 | | |
| | 315 | FRN315VG1□-4 | LD | 800 | - | SC-N14 | - | SC-N14 | SC-N14 | | |
| | | | HD | | | | SC-N14 | SC-N14 | SC-N14 | | |
| 355 | FRN355VG1□-4 | MD | 1200 | - | SC-N16 | - | SC-N14 | SC-N16 | | | |
| | | LD | | | | SC-N16 | SC-N16 | 610CM* | | | |
| 400 | FRN400VG1□-4 | HD | 1200 | - | 610CM* | - | 610CM* | 610CM* | | | |
| | | MD | | | | 610CM* | 610CM* | 610CM* | | | |
| 450 | FRN450VG1□-4 | LD | 1400 | - | 612CM* | - | - | 612CM* | | | |
| | | HD | | | | 612CM* | 612CM* | 612CM* | | | |
| 500 | FRN500VG1□-4 | MD | 1600 | - | 616CM* | - | - | 616CM* | | | |
| | | LD | | | | 616CM* | 616CM* | 616CM* | | | |

* 610CM, 612CM and 616CM: Please contact us for further informations.

Note: □ in the inverter model represents an alphabet.

□ S (Basic type)

- Install the MCCB or RCD/ELCB at the input side of the inverter. They cannot be installed at the output side of the inverter.
- The above table lists the rated current of MCCBs and RCD/ELCBs to be used in the power control panel with an internal temperature of lower than 50°C. The rated current is factored by a correction coefficient of 0.85 as the RCDs'/MCCBs' and ELCBs' original rated current is specified when using them in a surrounding temperature of 40°C or lower. Select an MCCB and/or RCD/ELCB suitable for the actual short-circuit breaking capacity needed for your power systems.
- For the selection of the MC type, it is assumed that the 600 V HIV (allowable surrounding temperature: 75°C) wires for the power input/output of the inverter are used. If an MC type for another class of wires is selected, the wire size suitable for the terminal size of both the inverter and the MC type should be taken into account.
- Use ELCBs with overcurrent protection.
- To protect your power systems from secondary accidents caused by the broken inverter, use an MCCB and/or RCD/ELCB with the rated current listed in the above table. Do not use an MCCB or RCD/ELCB with a rating higher than that listed.

Table 8.6 lists the relationship between the rated leakage current sensitivity of RCDs/ELCBs (with overcurrent protection) and wiring length of the inverter output circuits. Note that the sensitivity levels listed in the table are estimated values based on the results obtained by the test setup in the Fuji laboratory where each inverter drives a single motor.

Table 8.6 Rated Current Sensitivity of Residual-Current-Operated Protective Devices (RCDs)/Earth Leakage Circuit Breakers (ELCBs)

| Power supply voltage | Standard application motor (kW) | Wire distance/current sensitivity | | | | | |
|----------------------|---------------------------------|-----------------------------------|-------|--------|--------|-------------------|-------------------|
| | | 10 m | 30 m | 50 m | 100 m | 200 m | 300 m |
| Three-phase 200V | 0.75 | | | | | | |
| | 1.5 | | | | | | |
| | 2.2 | | 30 mA | | | | |
| | 3.7 | | | | | | |
| | 5.5 | | | | | | |
| | 7.5 | | | | 100 mA | | |
| | 11 | | | | | | |
| | 15 | | | | | | |
| | 18.5 | | | | | 200 mA | |
| | 22 | | | | | | |
| | 30 | | | | | | |
| | 37 | | | | | | |
| | 45 | | | | | | |
| | 55 | | | | | | |
| 75 | | | | | | 500 mA | |
| 90 | | | | | | | |
| 110 | | | | | | | |
| Three-phase 400V | 3.7 | | | | | | |
| | 5.5 | | | | | | |
| | 7.5 | 30 mA | | | | | |
| | 11 | | | 100 mA | | | |
| | 15 | | | | | | |
| | 18.5 | | | | | | |
| | 22 | | | | 200 mA | | |
| | 30 | | | | | | |
| | 37 | | | | | | |
| | 45 | | | | | 500 mA | |
| | 55 | | | | | | |
| | 75 | | | | | | |
| | 90 | | | | | | |
| | 110 | | | | | | |
| | 132 | | | | | | 1000 mA (Special) |
| | 160 | | | | | | |
| | 200 | | | | | | |
| | 220 | | | | | | |
| | 250 | | | | | | |
| | 280 | | | | | | |
| 315 | | | | | | | |
| 355 | | | | | | 3000 mA (Special) | |
| 400 | | | | | | | |
| 450 | | | | | | | |
| 500 | | | | | | | |
| 630 | | | | | | | |
| 710 | | | | | | | |

- Values listed above were obtained using Fuji ELCB EG or SG series applied to the test setup.
- The rated current of applicable motor rating indicates values for Fuji standard motor (4 poles, 50 Hz and 200 V three-phase).
- The leakage current is calculated based on grounding of the single wire for 200 V class delta connection and neutral grounding for 400 V class Y-connection power lines.
- Values listed above are calculated based on the static capacitance to the earth when the 600 V class of vinyl-insulated IV wires are used in a wiring through metal conduit pipes.
- Wiring length is the total length of wiring between the inverter and motor. If more than one motor is to be connected to a single inverter, the wiring length should be the total length of wiring between the inverter and motors.

8.4.2 Surge killer for L-load

A surge killer absorbs surge voltage induced by L-load of an electro magnetic switch or solenoid valve. Use of a surge killer is effective in preventing the electronic equipment, including inverters, from damage or malfunctioning caused by such surges.

Install a surge killer near the power coil of the surge source. Connected to the inverter's power source side, as shown in Figure 8.3, a surge killer absorbs the surge voltage, preventing the electronic equipment, from damage or malfunctioning. (The maximum capacity is 3.7 kW.)

Refer to the catalog "Fuji Surge Killers/Absorbers (HS118: Japanese edition only)" for details. These products are available from Fuji Electric Technica Co., Ltd.

Note: Do not use the capacitor in the inverter secondary (output) line.




Figure 8.3 Dimensions of Surge Killer and Connection Example

8.4.3 Arrester

An arrester suppresses surge currents induced by lightning invaded from the power supply lines. Common use of the grounding wire that is used for electric equipment in the panel, with the arrester, is effective in preventing electronic equipment from damage or malfunctioning caused by such surges.

Applicable arrester models are CN5132 for three-phase 200 V class series, and CN5134 for three-phase 400 V class series. (The CN5232 and CN5234 series with 20 kA of discharge withstand current rating are also available.)

Figure 8.4 shows their external dimensions and connection examples. Refer to the catalog "Fuji Surge Killers/Absorbers (HS118: Japanese edition only)" for details. These products are available from Fuji Electric Technica Co., Ltd.





Figure 8.4 Arrester Dimensions and Connection Examples

8.4.4 Surge absorber

A surge absorber absorbs surges or noises generated by a magnetic contactor (MC) or solenoid valve in the power system to effectively protect electronic equipment in the panel from malfunctions or breakdown. Installed parallel to a coil of an MC, solenoid valve, or L load, a surge absorber absorbs a surge voltage.

The type of surge absorber is S2-A-O and S1-B-O. Figure 8.5 shows their external dimensions.

The surge absorbers are available from Fuji Electric Technica Co., Ltd.



Available from Fuji Electric Technica Co., Ltd.

Figure 8.5 Surge Absorber Dimensions

8.4.5 Filter capacitor for radio noise reduction

These capacitors are effective to suppress AM radio band (less than 1 MHz) noises. Using them with Zero-phase reactors upgrades capability.

Applicable models are NFM25M315KPD1 for 200 V class series inverters and NFM60M315KPD for 400 V class. Use one of them no matter what the inverter capacity. Figure 8.6 shows their external dimensions. The surge absorbers are available from Fuji Electric Technica Co., Ltd.

Note: Do not use the capacitor in the inverter secondary (output) line.




Figure 8.6 Filtering Capacitors Dimensions

8.5 Peripheral Equipment Options

8.5.1 Braking resistors (DBRs) and braking units

8.5.1.1 Braking resistors (DBRs)

A braking resistor converts regenerative energy generated from deceleration of the motor to heat for consumption. Use of a braking resistor results in improved deceleration performance of the inverter. FRENIC-VG provides 2 types: Standard 10% ED product and 20% ED product.

📖 Refer to Chapter 9, Section 9.2 "Selecting a Braking Resistor."

(1) 10% ED product, 20% ED product

The standard model of a braking resistor integrates a facility that detects the temperature on the heat sink of the resistor and outputs a digital ON/OFF signal if the temperature exceeds the specified level (as an overheating warning signal). To ensure that the signal is recognized at one of the digital input terminals of the FRENIC-VG, assign the external alarm THR to any of terminals [X1] to [X9]. Connect the assigned terminals to terminals [1] and [2] of the braking resistor. Upon detection of the warning signal, the inverter simultaneously transfers to Alarm mode, displays alarm 0h2 on the LED monitor and shuts down its power output.




Figure 8.7 Braking Resistor (Standard Model) and Connection Example

📖 For the specifications and external dimensions of the braking units, refer to [3] and [4] in this Section.

8.5.1.2 Braking units

Add a braking unit to the braking resistor to upgrade the braking capability of inverters with the followings.

HD mode: 75 kW or above (200V series), 200 kW or above (400V series)

LD mode: 75 kW or above (200V series), 200 kW or above (400V series)

MD mode: 200 kW or above (400V series)

Inverters other than above have built-in IGBTs for the braking resistor.



Figure 8.8 Braking Unit

📖 For the specifications and external dimensions of the braking units, refer to [3] and [4] in this Section. For details, refer to the Instruction Manual (INR-HF51196).

8.5.1.3 Specifications and connection example

Table 8.7 Generated Loss in Braking Unit

| Model | Generated loss (W) | |
|----------|--------------------|---------------|
| | Standard model | With fan unit |
| BU55-2C | 50 | 150 |
| BU90-2C | 60 | 180 |
| BU220-4C | 80 | 240 |

■HD-mode Inverters

Table 8.8 (a) Braking Unit/Braking Resistor (Standard ED)

| Power supply voltage | Nominal applied motor (kW) | Inverter type | Fig | Selecting Options | | | | | Maximum braking torque (%) | | Continuous braking (converted to 150% torque value) | | Repetitive braking (at 100s interval or less) | | | | | |
|----------------------|----------------------------|----------------|----------|-------------------|--------------|------------------|--------------|----------------------|----------------------------|-------|---|------------------------------|---|-------------------|-------|------|----|------|
| | | | | Braking unit | | Braking resistor | | | Torque (N·m) | | Braking time (s) | Discharging capability (kWs) | Duty cycle (%ED) | Average loss (kW) | | | | |
| | | | | Model | Qty. (units) | Model | Qty. (units) | Resistance value (Ω) | 50 Hz | 60 Hz | | | | | | | | |
| | | | | | | | | | | | | | | | | | | |
| Three-phase 200V | 0.75 | FRN0.75VG1S-2J | A | - | - | DB2.2V-21B | 1 | 30 | 150 | 7.16 | 5.97 | 10 | 16.5 | 10 | 0.165 | | | |
| | 1.5 | FRN1.5VG1S-2J | | | | DB2.2V-21B | 1 | 30 | 150 | 14.3 | 11.9 | 10 | 16.5 | 10 | 0.165 | | | |
| | 2.2 | FRN2.2VG1S-2J | | | | DB2.2V-21B | 1 | 30 | 150 | 21.0 | 17.5 | 10 | 16.5 | 10 | 0.165 | | | |
| | 3.7 | FRN3.7VG1S-2J | | | | DB3.7V-21B | 1 | 24 | 150 | 35.3 | 29.4 | 10 | 27.8 | 10 | 0.278 | | | |
| | 5.5 | FRN5.5VG1S-2J | | | | DB5.5V-21B | 1 | 16 | 150 | 52.5 | 43.8 | 10 | 41.3 | 10 | 0.413 | | | |
| | 7.5 | FRN7.5VG1S-2J | | | | DB7.5V-21B | 1 | 12 | 150 | 71.6 | 59.7 | 10 | 56.3 | 10 | 0.563 | | | |
| | 11 | FRN11VG1S-2J | | | | DB11V-21B | 1 | 8.0 | 150 | 105 | 87.5 | 10 | 82.5 | 10 | 0.825 | | | |
| | 15 | FRN15VG1S-2J | | | | DB15V-21B | 1 | 6.0 | 150 | 143 | 119 | 10 | 113 | 10 | 1.13 | | | |
| | 18.5 | FRN18.5VG1S-2J | | | | DB18.5V-21B | 1 | 4.5 | 150 | 177 | 147 | 10 | 139 | 10 | 1.39 | | | |
| | 22 | FRN22VG1S-2J | | | | DB22V-21B | 1 | 4.0 | 150 | 210 | 175 | 10 | 165 | 10 | 1.65 | | | |
| | 30 | FRN30VG1S-2J | | | | DB30V-21B | 1 | 2.5 | 150 | 286 | 239 | 10 | 225 | 10 | 2.25 | | | |
| | 37 | FRN37VG1S-2J | | | | DB37V-21B | 1 | 2.25 | 150 | 353 | 294 | 10 | 278 | 10 | 2.78 | | | |
| | 45 | FRN45VG1S-2J | | | | DB45V-21B | 1 | 2.0 | 150 | 430 | 358 | 10 | 338 | 10 | 3.38 | | | |
| | 55 | FRN55VG1S-2J | | | | DB55V-21C | 1 | 1.6 | 150 | 525 | 438 | 10 | 413 | 10 | 4.13 | | | |
| | 75 | FRN75VG1S-2J | | | | B | BU55-2C | 2 | DB75V-21C | 1 | 2.4/2 | 150 | 716 | 597 | 10 | 563 | 10 | 5.63 |
| 90 | FRN90VG1S-2J | BU90-2C | 2 | DB90V-21C | 1 | | 2.0/2 | 150 | 859 | 716 | 10 | 675 | 10 | 6.75 | | | | |
| Three-phase 400V | 3.7 | FRN3.7VG1S-4J | A | - | - | DB3.7V-41B | 1 | 96 | 150 | 35.3 | 29.4 | 10 | 27.8 | 10 | 0.278 | | | |
| | 5.5 | FRN5.5VG1S-4J | | | | DB5.5V-41B | 1 | 64 | 150 | 52.5 | 43.8 | 10 | 41.3 | 10 | 0.413 | | | |
| | 7.5 | FRN7.5VG1S-4J | | | | DB7.5V-41B | 1 | 48 | 150 | 71.6 | 59.7 | 10 | 56.3 | 10 | 0.563 | | | |
| | 11 | FRN11VG1S-4J | | | | DB11V-41B | 1 | 32 | 150 | 105 | 87.5 | 10 | 82.5 | 10 | 0.825 | | | |
| | 15 | FRN15VG1S-4J | | | | DB15V-41B | 1 | 24 | 150 | 143 | 119 | 10 | 113 | 10 | 1.13 | | | |
| | 18.5 | FRN18.5VG1S-4J | | | | DB18.5V-41B | 1 | 18 | 150 | 177 | 147 | 10 | 139 | 10 | 1.39 | | | |
| | 22 | FRN22VG1S-4J | | | | DB22V-41B | 1 | 16 | 150 | 210 | 175 | 10 | 165 | 10 | 1.65 | | | |
| | 30 | FRN30VG1S-4J | | | | DB30V-41B | 1 | 10 | 150 | 286 | 239 | 10 | 225 | 10 | 2.25 | | | |
| | 37 | FRN37VG1S-4J | | | | DB37V-41B | 1 | 9.0 | 150 | 353 | 294 | 10 | 278 | 10 | 2.78 | | | |
| | 45 | FRN45VG1S-4J | | | | DB45V-41B | 1 | 8.0 | 150 | 430 | 358 | 10 | 338 | 10 | 3.38 | | | |
| | 55 | FRN55VG1S-4J | | | | DB55V-41C | 1 | 6.5 | 150 | 525 | 438 | 10 | 413 | 10 | 4.13 | | | |
| | 75 | FRN75VG1S-4J | | | | DB75V-41C | 1 | 4.7 | 150 | 716 | 597 | 10 | 563 | 10 | 5.63 | | | |
| | 90 | FRN90VG1S-4J | | | | DB90V-41C | 1 | 3.9 | 150 | 859 | 716 | 10 | 675 | 10 | 6.75 | | | |
| | 110 | FRN110VG1S-4J | | | | DB110V-41C | 1 | 3.2 | 150 | 1050 | 875 | 10 | 825 | 10 | 8.25 | | | |
| | 132 | FRN132VG1S-4J | | | | DB132V-41C | 1 | 2.6 | 150 | 1261 | 1050 | 10 | 990 | 10 | 9.90 | | | |
| | 160 | FRN160VG1S-4J | | | | C | | | DB160V-41C | 1 | 2.2 | 150 | 1528 | 1273 | 10 | 1200 | 10 | 12.0 |
| | 200 | FRN200VG1S-4J | | | | D | BU220-4C | 2 | DB200V-41C | 1 | 3.5/2 | 150 | 1910 | 1592 | 10 | 1500 | 10 | 15.0 |
| | 220 | FRN220VG1S-4J | | | | | BU220-4C | 2 | DB220V-41C | 1 | 3.2/2 | 150 | 2101 | 1751 | 10 | 1650 | 10 | 16.5 |
| 280 | FRN280VG1S-4J | E | BU220-4C | 2 | DB160V-41C | 2 | 2.2/2 | 150 | 2674 | 2228 | 10 | 2100 | 10 | 21.0 | | | | |
| 315 | FRN315VG1S-4J | | BU220-4C | 2 | DB160V-41C | 2 | 2.2/2 | 150 | 3008 | 2507 | 10 | 2363 | 10 | 23.6 | | | | |
| 355 | FRN355VG1S-4J | F | BU220-4C | 3 | DB132V-41C | 3 | 2.6/3 | 150 | 3390 | 2825 | 10 | 2663 | 10 | 26.6 | | | | |
| 400 | FRN400VG1S-4J | | BU220-4C | 3 | DB132V-41C | 3 | 2.6/3 | 150 | 3820 | 3183 | 10 | 3000 | 10 | 30.0 | | | | |
| 500 | FRN500VG1S-4J | G | BU220-4C | 4 | DB132V-41C | 4 | 2.6/4 | 150 | 4775 | 3979 | 10 | 3750 | 10 | 37.5 | | | | |
| 630 | FRN630VG1S-4J | | H | BU220-4C | 4 | DB160V-41C | 4 | 2.2/4 | 150 | 6016 | 5013 | 10 | 4725 | 10 | 47.3 | | | |

Note: • Refer to notes on and procedure of selection.

For DB160V-41C - DB220V-41C, two braking resistors are used per one unit.

Example) For the model: DB160V-41C, quantity: 2, four braking resistors are used.

■MD-mode Inverters

Table 8.8 (b) Braking Unit/Braking Resistor (Standard 10%ED)

| Power supply voltage | Nominal applied motor (kW) | Inverter type | Fig | Selecting Options | | | | | Maximum braking torque (%) | | | Continuous braking (converted to 150% torque value) | | Repetitive braking (at 100s interval or less) | | |
|----------------------|----------------------------|---------------|-----|-------------------|--------------|------------------|--------------|----------------------|----------------------------|-------|------------------|---|------------------|---|------|------|
| | | | | Braking unit | | Braking resistor | | | Torque (N·m) | | Braking time (s) | Discharging capacity (kWs) | Duty cycle (%ED) | Average loss (kW) | | |
| | | | | Model | Qty. (units) | Model | Qty. (units) | Resistance value (Ω) | 50 Hz | 60 Hz | | | | | | |
| | | | | | | | | | | | | | | | | |
| Three-phase 400V | 110 | FRN90VG1S-4J | A | | | DB110V-41C | 1 | 3.2 | 150 | 1050 | 875 | 10 | 825 | 10 | 8.25 | |
| | 132 | FRN110VG1S-4J | | | | DB132V-41C | 1 | 2.6 | 150 | 1261 | 1050 | 10 | 990 | 10 | 9.90 | |
| | 160 | FRN132VG1S-4J | | | | C | DB160V-41C | 1 | 2.2 | 150 | 1528 | 1273 | 10 | 1200 | 10 | 12.0 |
| | 200 | FRN160VG1S-4J | | | | | J | DB200V-41C | 1 | 3.5/2 | 150 | 1910 | 1592 | 10 | 1500 | 10 |
| | 220 | FRN200VG1S-4J | D | BU220-4C | 2 | DB220V-41C | 1 | 3.2/2 | 150 | 2101 | 1751 | 10 | 1650 | 10 | 16.5 | |
| | 250 | FRN220VG1S-4J | I | BU220-4C | 2 | DB132V-41C | 2 | 2.6/2 | 150 | 2388 | 1990 | 10 | 1875 | 10 | 18.8 | |
| | 315 | FRN280VG1S-4J | E | BU220-4C | 2 | DB160V-41C | 2 | 2.2/2 | 150 | 3008 | 2507 | 10 | 2363 | 10 | 23.6 | |
| | 355 | FRN315VG1S-4J | F | BU220-4C | 3 | DB132V-41C | 3 | 2.6/3 | 150 | 3390 | 2825 | 10 | 2663 | 10 | 26.6 | |
| | 400 | FRN355VG1S-4J | | BU220-4C | 3 | DB132V-41C | 3 | 2.6/3 | 150 | 3820 | 3183 | 10 | 3000 | 10 | 30.0 | |
| | 450 | FRN400VG1S-4J | | G | BU220-4C | 4 | DB132V-41C | 4 | 2.6/4 | 150 | 4297 | 3581 | 10 | 3375 | 10 | 33.8 |

Note: • Refer to notes on and procedure of selection.

For DB160V-41C - DB220V-41C, two braking resistors are used per one unit.

Example) For the model: DB160V-41C, quantity: 2, four braking resistors are used.

■LD-mode Inverters

Table 8.8 (c) Braking Unit/Braking Resistor (Standard 10%ED)

| Power supply voltage | Nominal applied motor (kW) | Inverter type | Fig | Selecting Options | | | | | Maximum braking torque (%) | | | Continuous braking (converted to 150% torque value) | | Repetitive braking (at 100s interval or less) | | |
|----------------------|----------------------------|---------------|----------|-------------------|--------------|------------------|--------------|----------------------|----------------------------|-------|------------------|---|------------------|---|------|------|
| | | | | Braking unit | | Braking resistor | | | Torque (N·m) | | Braking time (s) | Discharging capacity (kWs) | Duty cycle (%ED) | Average loss (kW) | | |
| | | | | Model | Qty. (units) | Model | Qty. (units) | Resistance value (Ω) | 50 Hz | 60 Hz | | | | | | |
| | | | | | | | | | | | | | | | | |
| Three-phase 200V | 37 | FRN30VG1S-2J | A | | | DB30V-21B | 1 | 2.5 | 110 | 259 | 216 | 10 | 204 | 10 | 2.25 | |
| | 45 | FRN37VG1S-2J | | | | DB37V-21B | 1 | 2.25 | 110 | 315 | 263 | 10 | 248 | 10 | 2.78 | |
| | 55 | FRN45VG1S-2J | | | | DB45V-21B | 1 | 2.0 | 110 | 385 | 321 | 10 | 303 | 10 | 3.38 | |
| | 75 | FRN55VG1S-2J | | | | DB55V-21C | 1 | 1.6 | 110 | 525 | 438 | 10 | 413 | 10 | 4.13 | |
| | 90 | FRN75VG1S-2J | B | BU55-2C | 2 | DB75V-21C | 1 | 2.4/2 | 110 | 630 | 525 | 10 | 495 | 10 | 5.63 | |
| | 110 | FRN90VG1S-2J | | BU90-2C | 2 | DB90V-21C | 1 | 2.0/2 | 110 | 770 | 642 | 10 | 605 | 10 | 6.75 | |
| Three-phase 400V | 37 | FRN30VG1S-4J | A | | | DB30V-41B | 1 | 10 | 110 | 259 | 216 | 10 | 204 | 10 | 2.25 | |
| | 45 | FRN37VG1S-4J | | | | DB37V-41B | 1 | 9.0 | 110 | 315 | 263 | 10 | 248 | 10 | 2.78 | |
| | 55 | FRN45VG1S-4J | | | | DB45V-41B | 1 | 8.0 | 110 | 385 | 321 | 10 | 303 | 10 | 3.38 | |
| | 75 | FRN55VG1S-4J | | | | DB55V-41C | 1 | 6.5 | 110 | 525 | 438 | 10 | 413 | 10 | 4.13 | |
| | 90 | FRN75VG1S-4J | | | | DB75V-41C | 1 | 4.7 | 110 | 630 | 525 | 10 | 495 | 10 | 5.63 | |
| | 110 | FRN90VG1S-4J | | | | DB90V-41C | 1 | 3.9 | 110 | 770 | 642 | 10 | 605 | 10 | 6.75 | |
| | 132 | FRN110VG1S-4J | | | | DB110V-41C | 1 | 3.2 | 110 | 924 | 770 | 10 | 726 | 10 | 8.25 | |
| | 160 | FRN132VG1S-4J | | | | DB132V-41C | 1 | 2.6 | 110 | 1120 | 934 | 10 | 880 | 10 | 9.9 | |
| | 200 | FRN160VG1S-4J | C | DB160V-41C | 1 | 2.2 | 110 | 1401 | 1167 | 10 | 1100 | 10 | 12.0 | | | |
| | 220 | FRN200VG1S-4J | | D | BU220-4C | 2 | DB200V-41C | 1 | 3.5/2 | 110 | 1541 | 1284 | 10 | 1210 | 10 | 15.0 |
| | 280 | FRN220VG1S-4J | | BU220-4C | 2 | DB220V-41C | 1 | 3.2/2 | 110 | 1961 | 1634 | 10 | 1540 | 10 | 16.5 | |
| | 355 | FRN280VG1S-4J | | E | BU220-4C | 2 | DB160V-41C | 2 | 2.2/2 | 110 | 2486 | 2072 | 10 | 1953 | 10 | 21.0 |
| | 400 | FRN315VG1S-4J | | | BU220-4C | 2 | DB160V-41C | 2 | 2.2/2 | 110 | 2801 | 2334 | 10 | 2200 | 10 | 23.6 |
| | 450 | FRN355VG1S-4J | | F | BU220-4C | 3 | DB132V-41C | 3 | 2.6/3 | 110 | 3151 | 2626 | 10 | 2475 | 10 | 26.6 |
| | 500 | FRN400VG1S-4J | | | BU220-4C | 3 | DB132V-41C | 3 | 2.6/3 | 110 | 3501 | 2918 | 10 | 2750 | 10 | 30.0 |
| 630 | FRN500VG1S-4J | G | BU220-4C | 4 | DB132V-41C | 4 | 2.6/4 | 110 | 4412 | 3677 | 10 | 3465 | 10 | 37.5 | | |
| 710 | FRN630VG1S-4J | H | BU220-4C | 4 | DB160V-41C | 4 | 2.2/4 | 110 | 4972 | 4143 | 10 | 3905 | 10 | 47.3 | | |

Note: • Refer to notes on and procedure of selection.

For DB160V-41C - DB220V-41C, two braking resistors are used per one unit.

Example) For the model: DB160V-41C, quantity: 2, four braking resistors are used.

■HD-mode Inverters

Table 8.9 (a) Braking Unit/Braking Resistor (20%ED)

| Power supply voltage | Nominal applied motor (kW) | Inverter type | Fig | Selecting Options | | | | | Maximum braking torque (%) | | Continuous braking (converted to 150% torque value) | | Repetitive braking (at 100s interval or less) | | | | | | |
|----------------------|----------------------------|----------------|---------------|-------------------|-------------|------------------|-------------|---------------------|----------------------------|-----------|---|-------------------------------|---|-------------------|-------|------|------|----|------|
| | | | | Braking unit | | Braking resistor | | | Torque (N·m) | | Braking time(s) | Discharging capability (kW/s) | Duty cycle (%ED) | Average loss (kW) | | | | | |
| | | | | Model | Qty.(units) | Model | Qty.(units) | Resistance value(Ω) | 50 Hz | 60 Hz | | | | | | | | | |
| | | | | | | | | | | | | | | | | | | | |
| Three-phase 200V | 0.75 | FRN0.75VG1S-2J | A | - | - | DB2.2V-22B | 1 | 30 | 150 | 7.16 | 5.97 | 20 | 33.0 | 20 | 0.330 | | | | |
| | 1.5 | FRN1.5VG1S-2J | | | | DB2.2V-22B | 1 | 30 | 150 | 14.3 | 11.9 | 20 | 33.0 | 20 | 0.330 | | | | |
| | 2.2 | FRN2.2VG1S-2J | | | | DB2.2V-22B | 1 | 30 | 150 | 21.0 | 17.5 | 20 | 33.0 | 20 | 0.330 | | | | |
| | 3.7 | FRN3.7VG1S-2J | | | | DB3.7V-22B | 1 | 24 | 150 | 35.3 | 29.4 | 20 | 55.5 | 20 | 0.555 | | | | |
| | 5.5 | FRN5.5VG1S-2J | | | | DB5.5V-22B | 1 | 16 | 150 | 52.5 | 43.8 | 20 | 82.5 | 20 | 0.825 | | | | |
| | 7.5 | FRN7.5VG1S-2J | | | | DB7.5V-22B | 1 | 12 | 150 | 71.6 | 59.7 | 20 | 113 | 20 | 1.13 | | | | |
| | 11 | FRN11VG1S-2J | | | | DB11V-22B | 1 | 8.0 | 150 | 105 | 87.5 | 20 | 165 | 20 | 1.65 | | | | |
| | 15 | FRN15VG1S-2J | | | | DB15V-22B | 1 | 6.0 | 150 | 143 | 119 | 20 | 225 | 20 | 2.25 | | | | |
| | 18.5 | FRN18.5VG1S-2J | | | | DB18.5V-22B | 1 | 4.5 | 150 | 177 | 147 | 20 | 278 | 20 | 2.78 | | | | |
| | 22 | FRN22VG1S-2J | | | | DB22V-22B | 1 | 4.0 | 150 | 210 | 175 | 20 | 330 | 20 | 3.30 | | | | |
| | 30 | FRN30VG1S-2J | | | | DB30V-22C | 1 | 3.0 | 150 | 286 | 239 | 20 | 450 | 20 | 4.50 | | | | |
| | 37 | FRN37VG1S-2J | | | | DB37V-22C | 1 | 2.4 | 150 | 353 | 294 | 20 | 555 | 20 | 5.55 | | | | |
| | 45 | FRN45VG1S-2J | | | | DB45V-22C | 1 | 2.0 | 150 | 430 | 358 | 20 | 675 | 20 | 6.75 | | | | |
| | 55 | FRN55VG1S-2J | | | | DB55V-22C | 1 | 1.6 | 150 | 525 | 438 | 20 | 825 | 20 | 8.25 | | | | |
| | 75 | FRN75VG1S-2J | | | | FRN75VG1S-2J | B | BU55-2C | 2 | DB37V-22C | 2 | 2.4/2 | 150 | 716 | 597 | 20 | 1125 | 20 | 11.3 |
| | 90 | FRN90VG1S-2J | | | | FRN90VG1S-2J | B | BU90-2C | 2 | DB45V-22C | 2 | 2.0/2 | 150 | 859 | 716 | 20 | 1350 | 20 | 13.5 |
| Three-phase 400V | 3.7 | FRN3.7VG1S-4J | A | - | - | DB3.7V-42B | 1 | 96 | 150 | 35.3 | 29.4 | 20 | 55.5 | 20 | 0.555 | | | | |
| | 5.5 | FRN5.5VG1S-4J | | | | DB5.5V-42B | 1 | 64 | 150 | 52.5 | 43.8 | 20 | 82.5 | 20 | 0.825 | | | | |
| | 7.5 | FRN7.5VG1S-4J | | | | DB7.5V-42B | 1 | 48 | 150 | 71.6 | 59.7 | 20 | 113 | 20 | 1.13 | | | | |
| | 11 | FRN11VG1S-4J | | | | DB11V-42B | 1 | 32 | 150 | 105 | 87.5 | 20 | 165 | 20 | 1.65 | | | | |
| | 15 | FRN15VG1S-4J | | | | DB15V-42B | 1 | 24 | 150 | 143 | 119 | 20 | 225 | 20 | 2.25 | | | | |
| | 18.5 | FRN18.5VG1S-4J | | | | DB18.5V-42B | 1 | 18 | 150 | 177 | 147 | 20 | 278 | 20 | 2.78 | | | | |
| | 22 | FRN22VG1S-4J | | | | DB22V-42B | 1 | 16 | 150 | 210 | 175 | 20 | 330 | 20 | 3.30 | | | | |
| | 30 | FRN30VG1S-4J | | | | DB30V-42C | 1 | 12 | 150 | 286 | 239 | 20 | 450 | 20 | 4.50 | | | | |
| | 37 | FRN37VG1S-4J | | | | DB37V-42C | 1 | 9.0 | 150 | 353 | 294 | 20 | 555 | 20 | 5.55 | | | | |
| | 45 | FRN45VG1S-4J | | | | DB45V-42C | 1 | 8.0 | 150 | 430 | 358 | 20 | 675 | 20 | 6.75 | | | | |
| | 55 | FRN55VG1S-4J | | | | DB55V-42C | 1 | 6.5 | 150 | 525 | 438 | 20 | 825 | 20 | 8.25 | | | | |
| | 75 | FRN75VG1S-4J | | | | DB75V-42C | 1 | 4.7 | 150 | 716 | 597 | 20 | 1125 | 20 | 11.3 | | | | |
| | 90 | FRN90VG1S-4J | | | | DB90V-42C | 1 | 3.9 | 150 | 859 | 716 | 20 | 1350 | 20 | 13.5 | | | | |
| | 110 | FRN110VG1S-4J | | | | DB110V-42C | 1 | 3.2 | 150 | 1050 | 875 | 20 | 1650 | 20 | 16.5 | | | | |
| | 132 | FRN132VG1S-4J | | | | DB132V-42C | 1 | 2.6 | 150 | 1261 | 1050 | 20 | 1980 | 20 | 19.8 | | | | |
| | 160 | FRN160VG1S-4J | | | | DB160V-42C | 1 | 2.2 | 150 | 1528 | 1273 | 20 | 2400 | 20 | 24.0 | | | | |
| | 200 | FRN200VG1S-4J | FRN200VG1S-4J | D | BU220-4C | 2 | DB200V-42C | 1 | 3.5/2 | 150 | 1910 | 1592 | 20 | 3000 | 20 | 30.0 | | | |
| | 220 | FRN220VG1S-4J | FRN220VG1S-4J | D | BU220-4C | 2 | DB220V-42C | 1 | 3.2/2 | 150 | 2101 | 1751 | 20 | 3300 | 20 | 33.0 | | | |
| | 280 | FRN280VG1S-4J | FRN280VG1S-4J | I | BU220-4C | 2 | DB160V-42C | 2 | 2.2/2 | 150 | 2674 | 2228 | 20 | 4200 | 20 | 42.0 | | | |
| | 315 | FRN315VG1S-4J | FRN315VG1S-4J | I | BU220-4C | 2 | DB160V-42C | 2 | 2.2/2 | 150 | 3008 | 2507 | 20 | 4725 | 20 | 47.3 | | | |
| 355 | FRN355VG1S-4J | FRN355VG1S-4J | F | BU220-4C | 3 | DB132V-42C | 3 | 2.6/3 | 150 | 3390 | 2825 | 20 | 5325 | 20 | 53.3 | | | | |
| 400 | FRN400VG1S-4J | FRN400VG1S-4J | F | BU220-4C | 3 | DB132V-42C | 3 | 2.6/3 | 150 | 3820 | 3183 | 20 | 6000 | 20 | 60.0 | | | | |
| 500 | FRN500VG1S-4J | FRN500VG1S-4J | G | BU220-4C | 4 | DB132V-42C | 4 | 2.6/4 | 150 | 4775 | 3979 | 20 | 7500 | 20 | 75.0 | | | | |
| 630 | FRN630VG1S-4J | FRN630VG1S-4J | G | BU220-4C | 4 | DB160V-42C | 4 | 2.2/4 | 150 | 6016 | 5013 | 20 | 9450 | 20 | 94.6 | | | | |

Note) • This option is built to order.

• The braking unit requires the fan unit (BU-F).

For DB200V-42C and DB220V-42C, two braking resistors are used per one unit.

Example) For the model: DB200V-42C, quantity: 1, two braking resistors are used.

■MD-mode Inverters

Table 8.9 (b) Braking Unit/Braking Resistor (20%ED)

| Power supply voltage | Nominal applied motor (kW) | Inverter type | Fig | Selecting Options | | | | | Maximum braking torque (%) | | | Continuous braking (converted to 150% torque value) | | Repetitive braking (at 100s interval or less) | |
|----------------------|----------------------------|---------------|-----|-------------------|--------------|------------------|--------------|---------------------|----------------------------|-------|------------------|---|------------------|---|------|
| | | | | Braking unit | | Braking resistor | | | Torque (N·m) | | Braking time (s) | Discharging capability (kW) | Duty cycle (%ED) | Average loss (kW) | |
| | | | | Model | Qty. (units) | Model | Qty. (units) | Resistance value(Ω) | 50 Hz | 60 Hz | | | | | |
| | | | | | | | | | | | | | | | |
| Three-phase 400V | 110 | FRN90VG1S-4J | A | | | DB110V-42C | 1 | 3.2 | 150 | 1050 | 875 | 20 | 1650 | 20 | 16.5 |
| | 132 | FRN110VG1S-4J | | | | DB132V-42C | 1 | 2.6 | 150 | 1261 | 1050 | 20 | 1980 | 20 | 19.8 |
| | 160 | FRN132VG1S-4J | | | | DB160V-42C | 1 | 2.2 | 150 | 1528 | 1273 | 20 | 2400 | 20 | 24.0 |
| | 200 | FRN160VG1S-4J | J | | | DB200V-42C | 1 | 3.5/2 | 150 | 1910 | 1592 | 20 | 3000 | 20 | 30.0 |
| | 220 | FRN200VG1S-4J | D | BU220-4C | 2 | DB220V-42C | 1 | 3.2/2 | 150 | 2101 | 1751 | 20 | 3300 | 20 | 33.0 |
| | 250 | FRN220VG1S-4J | I | BU220-4C | 2 | DB132V-42C | 2 | 2.6/2 | 150 | 2388 | 1990 | 20 | 3750 | 20 | 37.5 |
| | 315 | FRN280VG1S-4J | | BU220-4C | 2 | DB160V-42C | 2 | 2.2/2 | 150 | 3008 | 2507 | 20 | 4725 | 20 | 47.3 |
| | 355 | FRN315VG1S-4J | F | BU220-4C | 3 | DB132V-42C | 3 | 2.6/3 | 150 | 3390 | 2825 | 20 | 5325 | 20 | 53.3 |
| | 400 | FRN355VG1S-4J | | BU220-4C | 3 | DB132V-42C | 3 | 2.6/3 | 150 | 3820 | 3183 | 20 | 6000 | 20 | 60.0 |
| | 450 | FRN400VG1S-4J | G | BU220-4C | 4 | DB132V-42C | 4 | 2.6/4 | 150 | 4297 | 3581 | 20 | 6750 | 20 | 67.5 |

■LD-mode Inverters

Table 8.9 (c) Braking Unit/Braking Resistor (20%ED)

| Power supply voltage | Nominal applied motor (kW) | Inverter type | Fig | Selecting Options | | | | | Maximum braking torque(%) | | | Continuous braking (converted to 150% torque value) | | Repetitive braking (at 100s interval or less) | |
|----------------------|----------------------------|---------------|----------|-------------------|--------------|------------------|--------------|----------------------|---------------------------|-------|------------------|---|------------------|---|------|
| | | | | Braking unit | | Braking resistor | | | Torque (N·m) | | Braking time (s) | Discharging capability (kW) | Duty cycle (%ED) | Average loss (kW) | |
| | | | | Model | Qty. (units) | Model | Qty. (units) | Resistance value (Ω) | 50 Hz | 60 Hz | | | | | |
| | | | | | | | | | | | | | | | |
| Three-phase 200V | 37 | FRN30VG1S-2J | A | | | DB30V-22C | 1 | 3.0 | 110 | 259 | 216 | 20 | 407 | 20 | 4.50 |
| | 45 | FRN37VG1S-2J | | | | DB37V-22C | 1 | 2.4 | 110 | 315 | 263 | 20 | 495 | 20 | 5.55 |
| | 55 | FRN45VG1S-2J | | | | DB45V-22C | 1 | 2.0 | 110 | 385 | 321 | 20 | 605 | 20 | 6.75 |
| | 75 | FRN55VG1S-2J | | | | DB55V-22C | 1 | 1.6 | 110 | 525 | 438 | 20 | 825 | 20 | 8.25 |
| | 90 | FRN75VG1S-2J | B | BU55-2C | 2 | DB37V-22C | 2 | 2.4/2 | 110 | 630 | 525 | 20 | 990 | 20 | 11.3 |
| | 110 | FRN90VG1S-2J | | BU90-2C | 2 | DB45V-22C | 2 | 2.0/2 | 110 | 770 | 642 | 20 | 1210 | 20 | 13.5 |
| Three-phase 400V | 37 | FRN30VG1S-4J | A | | | DB30V-42C | 1 | 12 | 110 | 259 | 216 | 20 | 407 | 20 | 4.50 |
| | 45 | FRN37VG1S-4J | | | | DB37V-42C | 1 | 9.0 | 110 | 315 | 263 | 20 | 495 | 20 | 5.55 |
| | 55 | FRN45VG1S-4J | | | | DB45V-42C | 1 | 8.0 | 110 | 385 | 321 | 20 | 605 | 20 | 6.75 |
| | 75 | FRN55VG1S-4J | | | | DB55V-42C | 1 | 6.5 | 110 | 525 | 438 | 20 | 825 | 20 | 8.25 |
| | 90 | FRN75VG1S-4J | | | | DB75V-42C | 1 | 4.7 | 110 | 630 | 525 | 20 | 990 | 20 | 11.3 |
| | 110 | FRN90VG1S-4J | | | | DB90V-42C | 1 | 3.9 | 110 | 770 | 642 | 20 | 1210 | 20 | 13.5 |
| | 132 | FRN110VG1S-4J | | | | DB110V-42C | 1 | 3.2 | 110 | 924 | 770 | 20 | 1452 | 20 | 16.5 |
| | 160 | FRN132VG1S-4J | | | | DB132V-42C | 1 | 2.6 | 110 | 1120 | 934 | 20 | 1760 | 20 | 19.8 |
| | 200 | FRN160VG1S-4J | | | | DB160V-42C | 1 | 2.2 | 110 | 1401 | 1167 | 20 | 2200 | 20 | 24.0 |
| | 220 | FRN200VG1S-4J | D | BU220-4C | 2 | DB200V-42C | 1 | 3.5/2 | 110 | 1541 | 1284 | 20 | 2420 | 20 | 30.0 |
| | 280 | FRN220VG1S-4J | | BU220-4C | 2 | DB220V-42C | 1 | 3.2/2 | 110 | 1961 | 1634 | 20 | 3080 | 20 | 33.0 |
| | 355 | FRN280VG1S-4J | I | BU220-4C | 2 | DB160V-42C | 2 | 2.2/2 | 110 | 2486 | 2072 | 20 | 3905 | 20 | 47.3 |
| | 400 | FRN315VG1S-4J | F | BU220-4C | 3 | DB132V-42C | 3 | 2.6/3 | 110 | 2801 | 2334 | 20 | 4400 | 20 | 53.3 |
| | 450 | FRN355VG1S-4J | | BU220-4C | 3 | DB132V-42C | 3 | 2.6/3 | 110 | 3151 | 2626 | 20 | 4950 | 20 | 53.3 |
| 500 | FRN400VG1S-4J | | BU220-4C | 3 | DB132V-42C | 3 | 2.6/3 | 110 | 3501 | 2918 | 20 | 5500 | 20 | 60.0 | |
| 630 | FRN500VG1S-4J | G | BU220-4C | 4 | DB132V-42C | 4 | 2.6/4 | 110 | 4412 | 3677 | 20 | 6930 | 20 | 75.0 | |
| 710 | FRN630VG1S-4J | | BU220-4C | 4 | DB160V-42C | 4 | 2.2/4 | 110 | 4972 | 4143 | 20 | 7810 | 20 | 94.6 | |

Note) • This option is built to order.

• The braking unit requires the fan unit (BU-F).

For DB200V-42C and DB220V-42C, two braking resistors are used per one unit.

Example) For the model: DB200V-42C, quantity: 1, two braking resistors are used.

Connection examples

Figure A





Figure B




Note 1: To use the 20%ED braking resistor (DB□□□V-□2C), the braking unit requires the fan unit (BU-F).

Note 2: In Figure B, main circuit wires should be branched from inverter's P and N terminals and the wiring distances from the inverter to braking resistors (Master and slave) should be the same.

When direct branching from the inverter is not made, install a relay terminal block for branch wiring.


Figure C



Note 1: For DB160V-41C and DB200V-42C, two braking resistors are used per one unit.

Note 2: To use the 20%ED braking resistor (DB□□□V-□2C), the braking unit requires the fan unit (BU-F).

Figure D




Note 1: For DB200V-41C, DV220V-41C, DB200V-42C and DB220-42C, two braking resistors are used per one unit.

Note 2: To use the 20% ED braking resistor (DB□□□V-□2C), the braking unit requires the fan unit (BU-F).

Note 3: In Figure D, main circuit wires should be branched from inverter's P and N terminals and the wiring distances from the inverter to braking resistors (Master and slave) should be the same.


When direct branching from the inverter is not made, install a relay terminal block for branch wiring.

Figure E



- Note 1: For DB160V-41C, two braking resistors are used per one unit.
Example) For the model: DB160V-41C, quantity: 2, four braking resistors are used.
- Note 2: To use the 20% ED braking resistor (DB□□□V-□2C), the braking unit requires the fan unit (BU-F).
- Note 3: In Figure E, main circuit wires should be branched from inverter's P and N terminals and the wiring distances from the inverter to braking resistors (Master and slave) should be the same.
When direct branching from the inverter is not made, install a relay terminal block for branch wiring.


Figure F



Note 1: To use the 20% ED braking resistor (DB□□□V-□2C), the braking unit requires the fan unit (BU-F).


Note 2: In Figure F, main circuit wires should be branched by installing branch bars on inverter's P and N terminals. The wiring distances from the inverter to braking resistors (Master and slave) should be the same. When direct branching from the inverter is not made, install a relay terminal block for branch wiring.

Figure G




- Note 1: To use the 20% ED braking resistor (DB□□□V-□2C), the braking unit requires the fan unit (BU-F).
- Note 2: In Figure G, main circuit wires should be branched by installing branch bars on inverter's P and N terminals. The wiring distances from the inverter to braking resistors (Master and slave) should be the same. When direct branching from the inverter is not made, install a relay terminal block for branch wiring.

Figure H




- Note 1: For DB160V-41C, two braking resistors are used per one unit.
 Example) For the model: DB160V-41C, quantity: 4, eight braking resistors are used.
- Note 2: To use the 20% ED braking resistor (DB□□□V-□2C), the braking unit requires the fan unit (BU-F).
- Note 3: In Figure H, main circuit wires should be branched by installing branch bars on inverter's P and N terminals. The wiring distances from the inverter to braking resistors (Master and slave) should be the same. When direct branching from the inverter is not made, install a relay terminal block for branch wiring.

Figure I



- Note 1: To use the 20% ED braking resistor (DB□□□V-□2C), the braking unit requires the fan unit (BU-F).
- Note 2: In Figure I, main circuit wires should be branched from inverter's P and N terminals and the wiring distances from the inverter to braking resistors (Master and slave) should be the same.
- When direct branching from the inverter is not made, install a relay terminal block for branch wiring.


Figure J



- Note 1: For DB160V-41C and DB200V-42C, two braking resistors are used per one unit.

8.5.1.4 External dimensions

Braking resistors, 10% ED models



200V series (10% ED product)

| Model | Fig. | Dimensions (mm) | | | | | | | | Screw size | | Max. connection wire size (mm ²) *1 | Approx. weight (kg) | |
|-------------|------|-----------------|-----|-----|-----|-----|-----|-------|-----|------------|-----|---|---------------------|-------|
| | | W | W1 | H | H1 | H2 | D | D1 | C | P, DB | G | | | |
| DB2.2V-21B | A | 330 | 298 | 242 | 210 | 165 | 140 | 1.6 | 8 | M4 | M4 | 5.5/5.5 | 4 | |
| DB3.7V-21B | | 400 | 368 | 280 | 248 | 203 | | | | | | | 5 | |
| DB5.5V-21B | | 480 | 448 | 377 | 10 | M5 | | | | | | | M5 | 14/14 |
| DB7.5V-21B | | | | | | | 7 | | | | | | | |
| DB11V-21B | | 660 | 628 | 557 | 240 | M6 | M6 | 22/22 | 10 | | | | | |
| DB15V-21B | | 405 | 750 | 718 | | | | | 647 | 340 | M6 | M6 | 22/22 | 13 |
| DB18.5V-21B | | | | | 18 | | | | | | | | | |
| DB22V-21B | | | | | 22 | | | | | | | | | |
| DB30V-21B | | B | 450 | 420 | 440 | 430 | 250 | 283 | - | 12 | M10 | M6 | 100/22 | 26 |
| DB37V-21B | | | 35 | | | | | | | | | | | |
| DB45V-21B | 600 | | 570 | 33 | | | | | | | | | | |
| DB55V-21C | 700 | | 670 | 43 | | | | | | | | | | |

400V series (10% ED product)

| Model | Fig. | Dimensions (mm) | | | | | | | | Screw size | | Max. connection wire size (mm ²) *1 | Approx. weight (kg) | |
|-------------|------|-----------------|--------|--------|-----|-----|-----|-----|-------|------------|-----|---|---------------------|----|
| | | W | W1 | H | H1 | H2 | D | D1 | C | P, DB | G | | | |
| DB3.7V-41B | A | 420 | 388 | 280 | 248 | 203 | 140 | 1.6 | 8 | M4 | M4 | 5.5/5.5 | 5 | |
| DB5.5V-41B | | | | 480 | 448 | 377 | | | 10 | | | | 7 | |
| DB7.5V-41B | | | | 660 | 628 | 557 | | | 240 | | | | M5 | M5 |
| DB11V-41B | | 11 | | | | | | | | | | | | |
| DB15V-41B | | 425 | 750 | 718 | 647 | 340 | M5 | M5 | 14/14 | 14 | | | | |
| DB18.5V-41B | | | | | | | | | | 19 | | | | |
| DB22V-41B | | | | | | | | | | 21 | | | | |
| DB30V-41B | | | | | | | | | | 26 | | | | |
| DB37V-41B | | B | 550 | 520 | 440 | 430 | 250 | 283 | - | 12 | M8 | M6 | 60/22 | 26 |
| DB45V-41B | | | | | | | | | | | M10 | | | 30 |
| DB55V-41C | 650 | | 720 | 41 | | | | | | | | | | |
| DB75V-41C | | | | | 57 | | | | | | | | | |
| DB90V-41C | 750 | | 720 | 43 | | | | | | | | | | |
| DB110V-41C | | | | | 57 | | | | | | | | | |
| DB132V-41C | 600 | | 570 | 74 | | | | | | | | | | |
| DB160V-41C | | | | | 74 | | | | | | | | | |
| DB200V-41C | 725 | 695 | 50(x2) | | | | | | | | | | | |
| DB220V-41C | | | | 51(x2) | | | | | | | | | | |


*1 The max. connection wire size is expressed by: □□□ / □□□.

□□□ Max. connection wire size for P and DB terminals
 □□□ Max. connection wire size for G terminal

*2 For DB160V-41C - DB220V-41C, two resistors of the same shape are used in a pair, and enough space for them should be considered.

When this model is ordered, a set of two resistors will be shipped.

Braking resistor 20% ED product



200 V series (20% ED product)

| Model | Fig. | Dimensions (mm) | | | | | | | | Screw size | | Max. connection wire size (mm ²) *1 | Approx. weight (kg) | | | | | |
|-------------|------|-----------------|-----|-----|-----|-----|-----|-----|----|------------|----|---|---------------------|-----|-----|-----|-----|----|
| | | W | W1 | H | H1 | H2 | D | D1 | C | P, DB | G | | | | | | | |
| DB2.2V-22B | A | 400 | 368 | 280 | 248 | 203 | 140 | 1.6 | 8 | M4 | M4 | 5.5/5.5 | 5 | | | | | |
| DB3.7V-22B | | | | 480 | 448 | 377 | | | | | | | 6 | | | | | |
| DB5.5V-22B | | | | 660 | 628 | 557 | | | | | | | 7 | | | | | |
| DB7.5V-22B | | | | 660 | 628 | 557 | | | | | | | 10 | | | | | |
| DB11V-22B | | 405 | 368 | 280 | 248 | 203 | 140 | 1.6 | 8 | M5 | M5 | | 5.5/5.5 | 10 | | | | |
| DB15V-22B | | | | | | | | | | | | | | 750 | 718 | 647 | 13 | |
| DB18.5V-22B | | | | | | | | | | | | | | 750 | 718 | 647 | 240 | 22 |
| DB22V-22B | | | | | | | | | | | | | | 750 | 718 | 647 | 340 | 26 |
| DB30V-22C | B | 450 | 420 | 440 | 430 | 250 | 283 | - | 12 | M10 | M6 | 100/22 | | 41 | | | | |
| DB37V-22C | | 550 | 520 | 440 | 430 | 250 | 283 | - | 12 | M10 | M6 | | | 36 | | | | |
| DB45V-22C | | 650 | 620 | 440 | 430 | 250 | 283 | - | 12 | M10 | M6 | | | 43 | | | | |
| DB55V-22C | | 700 | 670 | 440 | 430 | 250 | 283 | - | 12 | M10 | M6 | | | 43 | | | | |


400 V series (20% ED product)

| Model | Fig. | Dimensions (mm) | | | | | | | | Screw size | | Max. connection wire size (mm ²) *1 | Approx. weight (kg) | | | | |
|---------------|------|-----------------|-----|-----|-----|-----|-----|-----|--------|------------|----|---|---------------------|--------|-----|-----|-----|
| | | W | W1 | H | H1 | H2 | D | D1 | C | P, DB | G | | | | | | |
| DB3.7V-42B | A | 420 | 388 | 480 | 448 | 377 | 140 | 1.6 | 10 | M4 | M4 | 5.5/5.5 | 8 | | | | |
| DB5.5V-42B | | | | 660 | 628 | 557 | | | | | | | 11 | | | | |
| DB7.5V-42B | | | | 660 | 628 | 557 | | | | | | | 11 | | | | |
| DB11V-42B | | | | 660 | 628 | 557 | | | | | | | 14 | | | | |
| DB15V-42B | | 420 | 388 | 480 | 448 | 377 | 140 | 1.6 | 10 | M5 | M5 | | 5.5/5.5 | 21 | | | |
| DB18.5V-42B | | | | | | | | | | | | | | 750 | 718 | 647 | 21 |
| DB22V-42B | | | | | | | | | | | | | | 750 | 718 | 647 | 240 |
| DB30V-42C | B | 600 | 570 | 440 | 430 | 250 | 283 | - | 12 | M8 | M6 | 60/22 | | 24 | | | |
| DB37V-42C | | 700 | 670 | 440 | 430 | 250 | 283 | - | 12 | | | | | 32 | | | |
| DB45V-42C | | 700 | 670 | 440 | 430 | 250 | 283 | - | 12 | | | | | 34 | | | |
| DB55V-42C | | 750 | 720 | 440 | 430 | 250 | 283 | - | 12 | M10 | M6 | | | 45 | | | |
| DB75V-42C | | 550 | 520 | 440 | 430 | 250 | 483 | - | - | M10 | M6 | | 100/22 | 68 | | | |
| DB90V-42C | | 650 | 620 | 440 | 430 | 250 | 483 | - | - | | | | | 65 | | | |
| DB110V-42C | | 700 | 670 | 440 | 430 | 250 | 483 | - | - | | | | | 82 | | | |
| DB132V-42C | | 700 | 670 | 440 | 430 | 250 | 483 | - | - | | | | | 86 | | | |
| DB160V-42C | | 700 | 670 | 440 | 430 | 250 | 483 | - | - | | | | | 100 | | | |
| *2 DB200V-42C | | 700 | 670 | 440 | 430 | 250 | 483 | - | - | | | | | 85(x2) | | | |
| *2 DB220V-42C | 700 | 670 | 440 | 430 | 250 | 483 | - | - | 83(x2) | | | | | | | | |

*1 The max. connection wire size is expressed by: □□□ / □□□.
 — Max. connection wire size for P and DB terminals
 — Max. connection wire size for G terminal

*2 For DB200V-42C and DB220V-42C, two resistors of the same shape are used in a pair, and enough space for them should be considered.
 When this model is ordered, a set of two resistors will be shipped.

Braking unit




| Voltage | Model | Dimensions (mm) | | | | | | Terminal screw | | Max. connection wire size (mm ²) | Approx. weight (kg) |
|-------------|----------|-----------------|-----|-----|-----|-----|-----|----------------|---------------|--|---------------------|
| | | W | W1 | H | H1 | H2 | D | Main terminal | Grounding (G) | | |
| 200V series | BU55-2C | 230 | 130 | 240 | 225 | 210 | 160 | M8 | M8 | 22 | 6 |
| | BU90-2C | 250 | 150 | 370 | 355 | 340 | | M8 | M8 | 38 | 9 |
| 400V series | BU220-4C | 250 | 150 | 450 | 435 | 420 | 160 | M10 | M10 | 100 | 13 |

Fan units for braking units


Using this option improves the duty cycle [%ED] of a model using the external braking unit from 10%ED to 30%ED.

■ Fan unit



| Model | Dimensions(mm) | | | |
|-------|----------------|----|----|---------------------------|
| | W1 | H1 | D1 | l (fan power supply line) |
| BU-F | 149 | 44 | 76 | 320 |

■ Braking unit + fan unit



| Voltage | Model | Dimensions(mm) | | | | | | | | |
|-------------|---------------|----------------|-----|------|-----|----|-----|-----|-----|----|
| | | W2 | W3 | W4 | H2 | H3 | H4 | D2 | D3 | D4 |
| 200V series | BU55-2C+BU-F | 230 | 135 | 47.5 | 240 | 30 | 270 | 160 | 1.2 | 64 |
| | BU90-2C+BU-F | 250 | | 57.5 | 370 | | 400 | | | |
| 400V series | BU220-4C+BU-F | 250 | 135 | 57.5 | 450 | 30 | 480 | 160 | 1.2 | 64 |

8.5.2 Power regenerative PWM converters (RHC series)

8.5.2.1 Features

■ Conforms to harmonics suppressing guideline

Since this product converts the power supply current into sine waves by PWM control to greatly reduce the harmonics current, the conversion coefficient defined in the "Guideline of Harmonics Reduction for Consumers who has High or Ultra-High Voltage Power Receiving Facilities" can be reduced to "0" (i.e., no harmonics occur) when used in combination with inverters.

■ Can reduce power supply facilities capacity

By flowing current with the same phase as the power supply phase voltage by power factor control, operation with the power factor of approximately 1 can be achieved. This results in smaller power supply transformer capacity and equipment size, compared with the standard inverter.

■ Greatly improves braking ability

In highly frequent acceleration/deceleration operation and elevator operation, regenerated energy is all returned to the power supply to save power in regeneration. Also, there will be no trouble with the power supply system because the current waveform in regeneration is sine wave.

| | |
|--------------------------------|-------------------------|
| Continuous regeneration rating | 100% |
| 1-minute regeneration rating | 150% (CT specification) |
| | 120% (VT specification) |

■ Rich protective and maintenance functionality



- Troubleshooting is made easier by the traceback (option).
 - (1) Past alarm details (for the last 10 alarms) by the segment LEDs can be retrieved. This allows for easy alarm cause analysis and measure planning.
 - (2) Upon a momentary power failure, the gate is shut down to ensure quick restart after the power comes back.
 - (3) Predictive signals for overload, fin over temperature, and life, alarms can be generated before the converter slips.

■ Networking capability

- MICREX-SX, F series, and CC-Link master devices can be (optionally) connected. RS-485 is equipped by standard.



Comparison of input current waveform
<Without PWM converter>



8.5.2.2 Specifications

(1) Standard specifications

■ 200 V series

| Item | | Standard specifications | | | | | | | | | | | |
|--------------------|--|---|---|------|------|----|----|----|----|----|-----------------|-----|-----|
| Model RHC□□□-2C | | 200 V series | | | | | | | | | | | |
| | | 7.5 | 11 | 15 | 18.5 | 22 | 30 | 37 | 45 | 55 | 75 | 90 | |
| CT application | Applicable inverter capacity (kW) | 7.5 | 11 | 15 | 18.5 | 22 | 30 | 37 | 45 | 55 | 75 | 90 | |
| | Output | Continuous capacity (kW) | 8.8 | 13 | 18 | 22 | 26 | 36 | 44 | 53 | 65 | 88 | 103 |
| | | Overload rating | 150% of continuous rating for 1 minute | | | | | | | | | | |
| | | Voltage 200V | 320-355 VDC (variable according to input power supply voltage) (*3) | | | | | | | | | | |
| | Required power supply capacity (kVA) | 9.5 | 14 | 19 | 24 | 29 | 38 | 47 | 57 | 70 | 93 | 111 | |
| Carrier frequency | | Standard 15 kHz | | | | | | | | | Standard 10 kHz | | |
| VT application | Applicable inverter capacity(kW) | 11 | 15 | 18.5 | 22 | 30 | 37 | 45 | 55 | 75 | 90 | 110 | |
| | Output | Continuous capacity (kW) | 13 | 18 | 22 | 26 | 36 | 44 | 53 | 65 | 88 | 103 | 126 |
| | | Overload rating | 120% of continuous rating for 1 minute | | | | | | | | | | |
| | | Voltage 200V | 320-355 VDC (variable according to input power supply voltage) (*3) | | | | | | | | | | |
| | Required power supply capacity (kVA) | 14 | 19 | 24 | 29 | 38 | 47 | 57 | 70 | 93 | 111 | 136 | |
| Carrier frequency | | Standard 10 kHz | | | | | | | | | Standard 6 kHz | | |
| Input power supply | Number of phases, voltage, and frequency | 3-phase 3-wire, 200-220V 50 Hz, 220-230V 50 Hz(*1), 200-230V 60 Hz | | | | | | | | | | | |
| | Voltage and frequency fluctuation | Voltage: -15 to +10%, frequency: ±5%, Voltage imbalance: within 2% (*4) | | | | | | | | | | | |

■ 400 V series

| Item | | Standard specifications | | | | | | | | | | | | | | | | | | | | | | |
|--------------------|--|---|---|------|------|----|----|----|----|----|-----|-----------------|-----|-----|-----|-----|-----|-----|-----|-----|-----|----------------|-----|-----|
| Model RHC□□□-4C | | 400V series | | | | | | | | | | | | | | | | | | | | | | |
| | | 7.5 | 11 | 15 | 18.5 | 22 | 30 | 37 | 45 | 55 | 75 | 90 | 110 | 132 | 160 | 200 | 220 | 280 | 315 | 355 | 400 | 500 | 630 | |
| CT application | Applicable inverter capacity(kW) | 7.5 | 11 | 15 | 18.5 | 22 | 30 | 37 | 45 | 55 | 75 | 90 | 110 | 132 | 160 | 200 | 220 | 280 | 315 | 355 | 400 | 500 | 630 | |
| | Output | Continuous capacity (kW) | 8.8 | 13 | 18 | 22 | 26 | 36 | 44 | 53 | 65 | 88 | 103 | 126 | 150 | 182 | 227 | 247 | 314 | 353 | 400 | 448 | 560 | 705 |
| | | Overload rating | 150% of continuous rating for 1 minute | | | | | | | | | | | | | | | | | | | | | |
| | | Voltage 400V | 640-710 VDC (variable according to input power supply voltage) (*3) | | | | | | | | | | | | | | | | | | | | | |
| | Required power supply capacity (kVA) | 9.5 | 14 | 19 | 24 | 29 | 38 | 47 | 57 | 70 | 93 | 111 | 136 | 161 | 196 | 244 | 267 | 341 | 383 | 433 | 488 | 610 | 762 | |
| Carrier frequency | | Standard 15 kHz | | | | | | | | | | Standard 10 kHz | | | | | | | | | | Standard 6 kHz | | |
| VT application | Applicable inverter capacity(kW) | 11 | 15 | 18.5 | 22 | 30 | 37 | 45 | 55 | 75 | 90 | 110 | 132 | 160 | 200 | 220 | 280 | 315 | 355 | 400 | 500 | | | |
| | Output | Continuous capacity (kW) | 13 | 18 | 22 | 26 | 36 | 44 | 53 | 65 | 88 | 103 | 126 | 150 | 182 | 227 | 247 | 314 | 353 | 400 | 448 | 560 | | |
| | | Overload rating | 120% of continuous rating for 1 minute | | | | | | | | | | | | | | | | | | | | | |
| | | Voltage 400V | 640-710 VDC (variable according to input power supply voltage) (*3) | | | | | | | | | | | | | | | | | | | | | |
| | Required power supply capacity (kVA) | 14 | 19 | 24 | 29 | 38 | 47 | 57 | 70 | 93 | 111 | 136 | 161 | 196 | 244 | 267 | 341 | 383 | 433 | 488 | 610 | | | |
| Carrier frequency | | Standard 10 kHz | | | | | | | | | | Standard 6 kHz | | | | | | | | | | | | |
| Input power supply | Number of phases, voltage, and frequency | 3-phase 3-wire, , 380-440V 50 Hz, 380-460V 60 Hz (*2) | | | | | | | | | | | | | | | | | | | | | | |
| | Voltage and frequency fluctuation | Voltage: -15 to +10%, frequency: ±5%, Voltage imbalance: within 2% (*4) | | | | | | | | | | | | | | | | | | | | | | |

(*1) 220-230V/50 Hz model can be manufactured for a separate order.

(*2) When the power supply voltage is 380-398V/50 Hz or 380-430V/60 Hz, tap switching is required inside the converter. If the power supply voltage is lower than 400V, the capacity must be reduced.

(*3) The output voltage is approximately 320/640 VDC for the power supply voltage of 200/400V, 343/686 VDC for 220/440V, and 355/710 VDC for 230/460V.

(*4) Inter-phase voltage imbalance ratio [%] = (Maximum voltage [V] - minimum voltage [V]) / 3-phase average voltage x 67

(2) Common specifications

| | Item | Specifications |
|------------|---------------------------------------|---|
| Control | Control method | AVR constant control with DC ACR minor |
| | Running/Stopping | Starts rectification when the converter is powered ON after connection. Starts boosting when it receives a run signal (terminals [RUN] and [CM] short-circuited or a run command via the communications link). After that, the converter is ready to run. |
| | Running status signal | Running, power running, regenerative operation, ready-to-run, alarm output (for any alarm), etc. |
| | CT/VT switching | CT: 150% of overload rating for 1 min VT: 120% of overload rating for 1 min (CT model only: 500 kW or above) |
| | Carrier frequency | Fixed to high carrier frequency |
| | Input power factor | 0.99 or above (at full load) (*1) |
| | Input harmonics current | Conversion coefficient can be $K_i = 0$ according to the harmonics suppressing guideline by METI. |
| | Restart after momentary power failure | Shields the gate when the voltage level reaches the undervoltage level if a momentary power failure occurs, and the converter can automatically restart after the power recovers. |
| | Power limiting control | Controls the power not to exceed the preset limit value. |
| Indication | Alarm display (Protective functions) | AC fuse blown, AC overvoltage, AC undervoltage, AC overcurrent, AC input current error, input phase loss, synchronous power supply frequency error, DC fuse blown, DC overvoltage, DC undervoltage, charge circuit fault, heat sink overheat, external alarm, converter internal overheat, overload, memory error, keypad communications error, CPU error, network device error, operation procedure error, A/D converter error, optical network error, IPM error |
| | Alarm history | Saves and displays the most recent 10 alarms. Saves and displays the detailed information of the trip cause for the previous alarm. |
| | Monitor | Displays input power, input current in RMS, input voltage in RMS, DC link bus voltage and power supply frequency. |
| | Load factor | Allows the user to measure the load factor with the keypad. |
| | Language | Allows the user to specify or refer to function codes in any of the three languages--Japanese, English or Chinese. |
| | Charging lamp | Lights when the DC link bus capacitor is charged. |

(*1) When the power supply voltage is 420V(210V) or higher and the operating load is 50% or higher, the power supply's power factor is reduced to approximately 0.095 (during regenerative operation only).

8.5.2.3 Function specifications

(1) Terminal functions

| Classification | Symbol | Name | Specifications |
|-------------------|---------------------|---|---|
| Main circuit | L1/R, L2/S, L3/T | Main circuit power inputs | Connects with the three-phase input power lines through a dedicated reactor. |
| | P(+), N(-) | Converter outputs | Connects with the power input terminals P(+) and N(-) on an inverter. |
| | E(G) | Grounding | Grounding terminal for the converter's chassis (or casing). |
| | R0, T0 | Auxiliary power input for the control circuit | For a backup of the control circuit power supply, connect the power lines same as that of the main power input. |
| Voltage detection | R1, S1, T1 | Synchronous power input for voltage detection | Voltage detection terminals for the internal control of the converter. Connect with the power supply side of the dedicated reactor or filter. |
| | R2, T2 | Inputs for control monitoring | Detection terminal for AC fuse blown. |
| Input signal | RUN | Run command | Short-circuiting terminals [RUN] and [CM] runs the converter; opening them stops the converter. |
| | RST | Reset alarm command | When the converter stops due to an alarm, removing the alarm factor and short-circuiting the terminals [RST] and [CM] cancels the protective function, restarting the converter. |
| | X1 | General-purpose transistor input | 0: Enable external alarm trip THR 1: Cancel current limiter LMT-CCL 2: 73 answerback 73ANS 3: Switch current limiter I-LIM4: Option D IOPT-DI |
| | CM | Digital input common | Common terminal for digital input signals. |
| | PLC | PLC signal power | Connects to PLC output signal power supply. (Rated voltage: 24 VDC (22 to 27 VDC)) |
| Output signal | 30A, 30B, 30C | Batch output alarm | Outputs a signal when the converter protective function acts and the converter stops in an alarm state. (Contact: 1C, on error, 30A-30C: ON) (Contact capacity: 250 VAC 50 mA max.) |
| | Y1, Y2, Y3, Y11-Y18 | General-purpose transistor output | 0: Converter running RUN 1: Converter ready to run RDY 2: Power supply current limiting IL 3: Lifetime alarm LIFE 4: Heat sink overheat early warning PRE-OH 5: Overload early warning PRE-OL 6: Power running DRV 7: Regenerating REG 8: Current limiting early warning CUR 9: Restarting after momentary power failure U-RES 10: Synchronizing power supply frequency SY-HZ 11: Alarm content 1 AL1 12: Alarm content 2 AL2 13: Alarm content 4 AL4 14: Option DO OPT-DO * Mounting the OPC-VG7-DIOA option makes 8 points of DO extended functions available. (DI functions are not available.) |
| | CME | Digital output common | |
| | Y5A, Y5C | Relay output | |
| | A01, A04, A05 | General-purpose analog output | 0: Input power PWR 1: Input current in RMS I-AC 2: Input voltage in RMS V-AC 3: DC link bus voltage V-DC 4: Power supply frequency FREQ 5: +10 V test P106: -10 V test N10 * Mounting the OPC-VG7-DIOA option makes 2 points of DO extended functions available. (DI functions are not available.) |
| | M | Analog output common | Common terminal for analog output signal. |
| | 73A, 73C | Charging resistor input relay outputs | Control output for the input relay of the external charging resistor (73). |

(2) Communications specifications

| Item | Specifications | | |
|--------------------------------|---|---|--|
| Communications specifications | General communication specifications | Monitoring the running information, running status and function code data, and controlling (selecting) the terminals [RUN], [RST] and [X1]. * Writing to function codes is not possible. | |
| | RS-485 (standard) | Communicating with a PC or PLC. (The converter supports the Fuji general-purpose inverter protocol and Modbus RTU protocol.) | |
| | T-Link (option) | Mounting the OPC-VG7-TL option enables communication with a T-Link module of MICREX-F or MICREX-SX via a T-Link network. | |
| | SX-bus (option) | Mounting the OPC-VG7-SX option enables communication with a MICREX-SX via an SX bus network. | |
| | CC-Link (option) | Mounting the OPC-VG7-CCL option enables communication with a CC-Link master. | |
| | Traceback (option) | Hardware | Mounting the OPC-RHC-TR option enables tracing back of the running status data of the converter. WPS-LD-TR software is required. |
| | | Software | Installing the WPS-RHC-TR software enables collecting of traceback data on the PC. |
| Optical communication (option) | The OPC-VG7-SI allows for load balancing control of a concurrent multi-processing system. This supports capacity of up to 2400 kW. | | |

(3) Function settings

| Function code | Name |
|---------------|--|
| F00 | Data protection |
| F01 | High frequency filter selection |
| F02 | Restart upon momentary power failure (operation selection) |
| F03 | Current rating switching |
| F04 | LED monitor, item selection |
| F05 | LCD monitor, item selection |
| F06 | LCD monitor, language selection |
| F07 | LCD monitor, contrast control |
| F08 | Carrier frequency |
| E01 | Terminal [X1] function |
| E02-13 | Terminal [Y1], [Y2], [Y3,], [Y5], [Y11] to [Y18] function |
| E14 | I/O function normal open/closed |
| E15 | RHC overload early warning level |
| E16 | Cooling fan ON/OFF control |
| E17 | Under current limiting (Hysteresis width) |
| E18-20 | A01, A04 and A05, function selection |
| E21-23 | A01, A04 and A05, gain setting |
| E24-26 | A01, A04 and A05, bias setting |
| E27 | A01, A04 and A05, filter setting |
| H01 | Station address |
| H02 | Communications error processing |
| H03 | Timer |
| H04 | Baud rate |
| H05 | Data length |
| H06 | Parity bits |
| H07 | Stop bits |
| H08 | No-response error detection time |
| H09 | Response interval |
| H10 | Protocol selection |
| H11 | TL transmission format |
| H12 | Parallel system |
| H13 | Number of slave stations in parallel system |
| H14 | Clear alarm data |
| H15,16 | Power supply current limiter (driving 1/2) |
| H17,18 | Power supply current limiter (braking 1/2) |
| H19,20 | Current limiting early warning (level/timer) |
| S01 | Operation method |
| S02,03 | Power supply current limiting (driving/braking) |
| M09 | Power supply frequency |
| M10 | Input power |
| M11 | Input current in RMS |
| M12 | Input voltage in RMS |
| M13 | Run command |
| M14 | Running status |
| M15 | Output terminals [Y1] to [Y18] |

(4) Protective functions

| Item | Indication | Protective specifications | Remarks |
|-----------------------------------|------------|--|---|
| AC fuse blown | ACF | Stops the converter output if the AC fuse (R-/T-phase only) is blown. | |
| AC overvoltage | AOV | Stops the converter output upon detection of an AC overvoltage condition. | |
| AC undervoltage | ALV | Stops the converter output upon detection of an AC undervoltage condition. | |
| AC overcurrent | AOC | Stops the converter output if the peak value of the input current exceeds the overcurrent level. | |
| AC input current error | ACE | Stops the converter output upon detection of the excessive deviation of the AC reactor from the AC input. | |
| Input phase loss | LPV | Stops the converter output upon detection of an input phase loss. | |
| Synchronous power frequency error | FrE | After the MC for charging circuit (73) is turned on, the converter checks the power frequency. If it detects a power frequency error, this function stops the converter output. An error during converter running (e.g., momentary power failure) triggers no alarm. | |
| DC fuse blown | dCF | Stops the converter output if the DC fuse (P side) is blown. | 18.5 kW or above |
| DC overvoltage | dOV | Stops the converter output upon detection of a DC overvoltage condition. If a power failure continues for a long time and the control power source is shut down, this alarm is automatically reset. | 200 V class series: 400 V \pm 3 V 400 V class series: 800 V \pm 5 V |
| DC undervoltage | dLV | Stops the converter output upon detection of a DC undervoltage condition. If a power failure continues for a long time and the control power source is shut down, this alarm is automatically reset. | 200 V class series: Stops at 185 V, restarts at 208 V. 400V class series: Stops at 371V, restarts at 417V. |
| Charging circuit fault | PbF | Stops the converter output upon detection of a heat sink overheat. | Condition: 73ANS (Answerback from 73) is assigned to terminal [X1]. |
| Heat sink overheat | OH1 | Stops the converter output upon detection of an internal overheat of the converter. | |
| External alarm | OH2 | Stops the converter output upon receipt of an external signal THR. | THR (Enable external alarm trip) is assigned to terminal [X1]. |
| Converter internal overheat | OH3 | Stops the converter output with the inverse-time characteristics due to the input current. | |
| Converter overload | OLU | Stops the converter output upon detection of a heat sink overheat. | Activate at 105%, 150% for 1 min |
| Memory error | Er1 | Stops the converter output if a data writing error or any other memory error occurs (when the checksums of the EEPROM and RAM do not match). | |
| Keypad communications error | Er2 | Displays $\mathcal{E}r2$ upon detection of a wire break in initial communication with the keypad. This does not affect the converter operation. | |
| CPU error | Er3 | Activated if a CPU error occurs. | |
| Network device error | Er4 | Stops the converter output if a fatal error (including no power supply connection) occurs in the master unit in the network. | Applies to T-Link, SX-bus, and CC-Link devices. |
| Operation procedure error | Er6 | Stops the converter output upon detection of an error in the operation procedure. | |
| A/D converter error | Er8 | Stops the converter output upon detection of a failure in the A/D converter circuit. | |
| Optical network error | Erb | Stops the converter output upon detection of an optical cable break or a fatal error in the optical option. | |
| IPM error | IPE | Activated when the IPM's self-diagnosis function works due to an overcurrent or overheat. | 15 kW or below |

(5) Required structure and environment

| Item | Required structure, environment and standards | | Remarks |
|-------------|---|---|---------|
| Structure | Structure | Mounting in a panel or mounting for external cooling | |
| | Enclosure | IP00 | |
| | Cooling system | Forced air cooling | |
| | Installation | Vertical installation | |
| | Coating color | Munsell 5Y3/0.5, eggshell | |
| | Maintainability | Structure designed for easy parts replacement | |
| Environment | Site location | Shall be free from corrosive gases, flammable gases, dusts, and direct sunlight. | |
| | Surrounding temperature | -10 to 50°C | |
| | Relative humidity | 5 to 95% RH (No condensation) | |
| | Altitude | 3,000 m max. (For use in an altitude between 1,001 m to 3,000 m, the output current should be derated.) | |
| | Vibration | 2 to 9 Hz: Amplitude = 3 mm, 9 to 20 Hz: 9.8 m/s^2 , 20 to 55 Hz: 2 m/s^2 (9 to 55 Hz: 2 m/s^2 for 90 kW or above), 55 to 200 Hz: 1 m/s^2 | |
| | Storage temperature | -20 to 55°C | |
| | Storage humidity | 5 to 95% RH | |

8.5.2.4 Converter configuration

(1) CT mode

| Power supply voltage | Applicable motor [kW] | PWM converter type | Charging circuit contactor | | Power supply contactor | | Charging circuit box (*1) | | | | | | Boosting reactor | | Filtering resistor | | Filtering reactor | | Filtering capacitor | | Filter circuit contactor | | |
|----------------------|-----------------------|--------------------|----------------------------|--------|------------------------|---------|---------------------------|--------------|-------------------------|--------------|----------------|----------|------------------|----------------------------|----------------------------|-----------|-------------------|----------|---------------------|-----------------------|--------------------------|------|--|
| | | | (73) | Qty. | (52) | Qty. | (CU) | Qty. | (R0) | Qty. | (F) | Qty. | (Lr) | Qty. | (Lf) | Qty. | (Ld) | Qty. | (Cf) | Qty. | (6F) | Qty. | |
| | | | | | | | | | | | | | | | | | | | | | | | |
| 200V series | 7.5 | RHC7.5-2C | SC-5-1 | 1 | | | CU7.5-2C | 1 | (80W 7.5Ω) | (3) | (CR2LS-50/UL) | (2) | LR2-7.5C | 1 | GRZG80 0.42Ω | 3 | LFC2-7.5C | 1 | CF2-7.5C | 1 | | | |
| | 11 | RHC11-2C | SC-N1 | 1 | | | CU11-2C | 1 | (HF5C5504) | | (CR2LS-75/UL) | (2) | LR2-15C | 1 | GRZG150 0.20Ω | 3 | LFC2-15C | 1 | CF2-15C | 1 | | | |
| | 15 | RHC15-2C | SC-N2 | 1 | | | CU15-2C | 1 | | | (CR2LS-100/UL) | (2) | | | | | | | | | | | |
| | 18.5 | RHC18.5-2C | SC-N3 | 1 | | | CU18.5-2C | 1 | (GRZG120 2Ω) | (3) | | | LR2-22C | 1 | GRZG200 0.13Ω | 3 | LFC2-22C | 1 | CF2-22C | 1 | | | |
| | 22 | RHC22-2C | | | | | CU22-2C | 1 | | | (CR2L-150/UL) | (2) | | | | | | | | | | | |
| | 30 | RHC30-2C | SC-N4 | 1 | | | CU30-2C | 1 | | | (CR2L-200/UL) | (2) | LR2-37C | 1 | GRZG400 0.1Ω | 3 | LFC2-37C | 1 | CF2-37C | 1 | | | |
| | 37 | RHC37-2C | SC-N5 | 1 | | | CU45-2C | 1 | | | (CR2L-260/UL) | (2) | | | | | | | | | | | |
| | 45 | RHC45-2C | SC-N7 | 1 | | | | | | | | | LR2-55C | 1 | | | | LFC2-55C | 1 | CF2-55C | 1 | | |
| | 55 | RHC55-2C | SC-N8 | 1 | | | CU55-2C | 1 | | | (CR2L-400/UL) | (2) | | | | | | | | | | | |
| | 75 | RHC75-2C | SC-N11 | 1 | | | CU75-2C | 1 | | | | | LR2-75C | 1 | | | | LFC2-75C | 1 | CF2-75C | 1 | | |
| 90 | RHC90-2C | | | | | CU90-2C | 1 | (GRZG400 1Ω) | (3) | (A50P600-4) | (2) | LR2-110C | 1 | GRZG400 0.12Ω [2 parallel] | 6 | LFC2-110C | 1 | CF2-110C | 1 | | | | |
| 400V series | 7.5 | RHC7.5-4C | SC-05 | 1 | | | CU7.5-4C | 1 | (TK50B 30Ω) | (3) | (CR6L-30/UL) | (2) | LR4-7.5C | 1 | GRZG80 1.74Ω | 3 | LFC4-7.5C | 1 | CF4-7.5C | 1 | | | |
| | 11 | RHC11-4C | SC-4-0 | 1 | | | CU15-4C | 1 | (HF5B0416) | | (CR6L-50/UL) | (2) | LR4-15C | 1 | GRZG150 0.79Ω | 3 | LFC4-15C | 1 | CF4-15C | 1 | | | |
| | 15 | RHC15-4C | SC-5-1 | 1 | | | | | | | | | | | | | | | | | | | |
| | 18.5 | RHC18.5-4C | SC-N1 | 1 | | | CU18.5-4C | 1 | (80W 7.5Ω) | (3) | | | LR4-22C | 1 | GRZG200 0.53Ω | 3 | LFC4-22C | 1 | CF4-22C | 1 | | | |
| | 22 | RHC22-4C | | | | | CU22-4C | 1 | (HF5C5504) | | (CR6L-75/UL) | (2) | | | | | | | | | | | |
| | 30 | RHC30-4C | SC-N2 | 1 | | | CU30-4C | 1 | | | (CR6L-100/UL) | (2) | LR4-37C | 1 | GRZG400 0.38Ω | 3 | LFC4-37C | 1 | CF4-37C | 1 | | | |
| | 37 | RHC37-4C | SC-N2S | 1 | | | CU45-4C | 1 | | | (CR6L-150/UL) | (2) | | | | | | | | | | | |
| | 45 | RHC45-4C | SC-N3 | 1 | | | | | | | | | LR4-55C | 1 | GRZG400 0.26Ω | 3 | LFC4-55C | 1 | CF4-55C | 1 | | | |
| | 55 | RHC55-4C | SC-N4 | 1 | | | CU55-4C | 1 | | | (CR6L-200/UL) | (2) | | | | | | | | | | | |
| | 75 | RHC75-4C | SC-N5 | 1 | | | CU75-4C | 1 | | | | | LR4-75C | 1 | GRZG400 0.38Ω | 3 | LFC4-75C | 1 | CF4-75C | 1 | | | |
| | 90 | RHC90-4C | SC-N7 | 1 | | | CU90-4C | 1 | | | (CR6L-300/UL) | (2) | LR4-110C | 1 | GRZG400 0.53Ω [2 parallel] | 6 | LFC4-110C | 1 | CF4-110C | 1 | | | |
| | 110 | RHC110-4C | SC-N8 | 1 | | | CU110-4C | 1 | (GRZG120 2Ω) | (3) | | | | | | | | | | | | | |
| | 132 | RHC132-4C | | | | | CU132-4C | 1 | | | (A50P400-4) | (2) | LR4-160C | 1 | RF4-160C | 1 | LFC4-160C | 1 | CF4-160C | 1 | | | |
| | 160 | RHC160-4C | SC-N11 | 1 | | | CU160-4C | 1 | | | (A50P600-4) | (2) | | | | | | | | | | | |
| | 200 | RHC200-4C | SC-N12 | 1 | | | CU200-4C | 1 | (GRZG400 1Ω) | (3) | | | LR4-220C | 1 | RF4-220C | 1 | LFC4-220C | 1 | CF4-220C | 1 | | | |
| | 220 | RHC220-4C | | | | | CU220-4C | 1 | | | (A70QS800-4) | (2) | | | | | | | | | | | |
| | 280 | RHC280-4C | SC-N3 | 1 | SC-N14 | 1 | | | GRZG400 1Ω [2 parallel] | 6 | A70QS800-4 | 2 | LR4-280C | 1 | RF4-280C | 1 | LFC4-280C | 1 | CF4-280C | 1 | SC-N4 | 1 | |
| 315 | RHC315-4C | | | | | | | | | A70P1600-4TA | 2 | LR4-315C | 1 | RR4-315C | 1 | LFC4-315C | 1 | CF4-315C | 1 | | | | |
| 355 | RHC355-4C | | | | | | | | | | | LR4-355C | 1 | RR4-355C | 1 | LFC4-355C | 1 | CF4-355C | 1 | | | | |
| 400 | RHC400-4C | | | SC-N16 | 1 | | | | | | | LR4-400C | 1 | RR4-400C | 1 | LFC4-400C | 1 | CF4-400C | 1 | | | | |
| 500 | RHC500-4C | | | SC-N11 | 3 | | | | | | | LR4-500C | 1 | RR4-500C | 1 | LFC4-500C | 1 | CF4-500C | 1 | SC-N4 ^{(*)2} | SC-N7 ^{(*)3} | | |
| 630 | RHC630-4C | | | SC-N12 | 3 | | | | | A70P2000-4T | 2 | LR4-630C | 1 | RR4-630C | 1 | LFC4-630C | 1 | CF4-630C | 1 | SC-N7 ^{(*)2} | SC-N7 ^{(*)3} | | |

(*1) The charging box (CU) contains a combination of a charging resistor (R0) and a fuse (F). If no CU is used, it is necessary to prepare the charging resistor (R0) and fuse (F) at your end.

(*2) The filtering capacitor consists of two pieces of capacitors. For an order of quantity "1," two pieces of capacitors are to be delivered.

(*3) When changing the carrier frequency from the factory default, it is necessary to change the filtering circuit contactor (6F). For details, refer to the PWM Converter Instruction Manual.

(2) VT mode

| Power supply voltage | Applicable motor [kW] | PWM converter type | Charging circuit contactor | | Power supply contactor | | Charging circuit box (*1) | | | | | | Boosting reactor | | Filtering resistor | | Filtering reactor | | Filtering capacitor | | Filter circuit contactor | |
|----------------------|-----------------------|--------------------|----------------------------|--------|------------------------|------------------------------|------------------------------|--------------|---------------------------|---------------|----------------|--------------------------|------------------|---------------|-------------------------------|----------|-------------------|----------------|---------------------|----------------|--------------------------|---------------|
| | | | (73) | Qty. | (52) | Qty. | (CU) | Qty. | Charger resistor | | Fuse | | (Lr) | Qty. | (Lf) | Qty. | (Lf) | Qty. | (Cf) | Qty. | (6F) | Qty. |
| | | | | | | | | | (R0) | Qty. | (F) | Qty. | | | | | | | | | | |
| 200V series | 11 | RHC7.5-2C | SC-N1 | 1 | - | - | CU7.5-2C | 1 | (80W 7.5Ω) (HF5C5504) | (3) | (CR2LS-50/UL) | (2) | LR2-15C | 1 | GRZG150 0.2Ω | 3 | LFC2-15C | 1 | CF2-15C | 1 | - | - |
| | 15 | RHC11-2C | SC-N2 | 1 | | | CU11-2C | 1 | | (CR2LS-75/UL) | (2) | LR2-22C | 1 | GRZG200 0.13Ω | | 3 | LFC2-22C | 1 | CF2-22C | 1 | | |
| | 18.5 | RHC15-2C | SC-N3 | 1 | | | CU15-2C | 1 | (GRZG120 2Ω) | (3) | (CR2L-100/UL) | (2) | LR2-22C | 1 | GRZG200 0.13Ω | 3 | LFC2-22C | 1 | CF2-22C | 1 | | |
| | 22 | RHC18.5-2C | SC-N4 | 1 | | | CU18.5-2C | 1 | | | | | | | | | | | | | | |
| | 30 | RHC22-2C | SC-N4 | 1 | | | CU22-2C | 1 | (80W 7.5Ω) (HF5C5504) | (3) | (CR2L-150/UL) | (2) | LR2-37C | 1 | GRZG400 0.1Ω | 3 | LFC2-37C | 1 | CF2-37C | 1 | | |
| | 37 | RHC30-2C | SC-N5 | 1 | | | CU30-2C | 1 | | | (CR2L-200/UL) | (2) | LR2-55C | 1 | | | LFC2-55C | 1 | CF2-55C | 1 | | |
| | 45 | RHC37-2C | SC-N7 | 1 | | | CU45-2C | 1 | (GRZG400 1Ω) | (3) | (A50P600-4) | (2) | LR2-110C | 1 | GRZG400 0.12Ω [2 parallel] | 6 | LFC2-110C | 1 | CF2-110C | 1 | | |
| | 55 | RHC45-2C | SC-N8 | 1 | | | CU55-2C | 1 | | | | | | | | | | | | | | |
| | 75 | RHC55-2C | SC-N11 | 1 | | | CU75-2C | 1 | (TK50B 30Ω) (HF5B0416) | (3) | (CR6L-30/UL) | (2) | LR4-15C | 1 | GRZG150 0.79Ω | 3 | LFC4-15C | 1 | CF4-15C | 1 | | |
| | 90 | RHC75-2C | SC-N12 | 1 | | | CU90-2C | 1 | | | | | | | | | | | | | | |
| | 400V series | 11 | RHC7.5-4C | SC-4-0 | | | 1 | - | - | CU7.5-4C | 1 | (80W 7.5Ω) (HF5C5504) | (3) | (CR6L-75/UL) | (2) | LR4-37C | 1 | GRZG400 0.38Ω | 3 | LFC4-37C | | |
| 15 | | RHC11-4C | SC-5-1 | 1 | CU15-4C | 1 | (CR6L-100/UL) | | | (2) | LR4-55C | | | | | | | | | | 1 | GRZG400 0.26Ω |
| 18.5 | | RHC15-4C | SC-N1 | 1 | CU18.5-4C | 1 | (80W 7.5Ω) (HF5C5504) | | | (3) | (CR6L-200/UL) | (2) | LR4-75C | 1 | GRZG400 0.38Ω | 3 | LFC4-75C | 1 | CF4-75C | 1 | | |
| 22 | | RHC18.5-4C | SC-N2 | 1 | CU22-4C | 1 | | | | | | | | | | | | | | | (CR6L-300/UL) | (2) |
| 30 | | RHC22-4C | SC-N2 | 1 | CU30-4C | 1 | (GRZG120 2Ω) | | | (3) | (A50P400-4) | (2) | LR4-160C | 1 | RF4-160C | 1 | LFC4-160C | 1 | CF4-160C | 1 | | |
| 37 | | RHC30-4C | SC-N2S | 1 | CU45-4C | 1 | | | | | | | | | | | | | | | (A50P600-4) | (2) |
| 45 | | RHC37-4C | SC-N3 | 1 | CU55-4C | 1 | (GRZG400 1Ω) | | | (3) | (A70QS800-4) | (2) | LR4-280C | 1 | RF4-280C | 1 | LFC4-280C | 1 | CF4-280C | 1 | | |
| 55 | | RHC45-4C | SC-N4 | 1 | CU75-4C | 1 | | | | | | | | | | | | | | | (A70P1600-4TA) | 2 |
| 75 | | RHC55-4C | SC-N5 | 1 | CU90-4C | 1 | (GRZG400 1Ω) [2 parallel] | | | (3) | (A70P1600-4TA) | 2 | LR4-355C | 1 | RR4-355C | 1 | LFC4-355C | 1 | CF4-355C | 1 | | |
| 90 | | RHC75-4C | SC-N7 | 1 | CU110-4C | 1 | | | | | | | | | | | | | | | (A70P1600-4TA) | 2 |
| 110 | | RHC90-4C | SC-N8 | 1 | CU132-4C | 1 | (GRZG400 1Ω) | | | (3) | (A70QS800-4) | (2) | LR4-500C | 1 | RR4-400C | 1 | LFC4-500C | 1 | CF4-500C | 1 | SC-N4SF | 1 |
| 132 | | RHC110-4C | SC-N8 | 1 | CU160-4C | 1 | | | | | | | | | | | | | | | | |
| 160 | | RHC132-4C | SC-N11 | 1 | CU200-4C | 1 | (GRZG400 1Ω) [2 parallel] | | | (3) | (A70QS800-4) | (2) | LR4-280C | 1 | RF4-280C | 1 | LFC4-280C | 1 | CF4-280C | 1 | | |
| 200 | | RHC160-4C | SC-N12 | 1 | CU220-4C | 1 | | | | | | | | | | | | | | | (A70QS800-4) | (2) |
| 220 | | RHC200-4C | SC-N14 | 1 | CU220-4C | 1 | (GRZG400 1Ω) [2 parallel] | | | (3) | (A70QS800-4) | (2) | LR4-280C | 1 | RF4-280C | 1 | LFC4-280C | 1 | CF4-280C | 1 | | |
| 280 | | RHC220-4C | SC-N14 | 1 | CU220-4C | 1 | | | | | | | | | | | | | | | (A70QS800-4) | (2) |
| 315 | RHC280-4C | SC-N3 | 1 | SC-N14 | 1 | (GRZG400 1Ω) [2 parallel] | (3) | (A70QS800-4) | 2 | LR4-315C | 1 | RR4-315C | 1 | LFC4-315C | 1 | CF4-315C | 1 | SC-N4 | 1 | | | |
| 355 | RHC315-4C | SC-N16 | 1 | SC-N16 | 1 | | | | | | | | | | | | | | | (A70P1600-4TA) | 2 | LR4-355C |
| 400 | RHC355-4C | SC-N11 | 3 | SC-N11 | 3 | (GRZG400 1Ω) [2 parallel] | (3) | (A70QS800-4) | 2 | LR4-400C | 1 | RR4-400C | 1 | LFC4-400C | 1 | CF4-400C | 1 | | | | | |
| 500 | RHC400-4C | SC-N11 | 3 | SC-N11 | 3 | | | | | | | | | | | | | (A70P1600-4TA) | 2 | LR4-500C | 1 | RR4-400C |


(*1) The charging box (CU) contains a combination of a charging resistor (R0) and a fuse (F). If no CU is used, it is necessary to prepare the charging resistor (R0) and fuse (F) at your end.

(*2) The filtering capacitor consists of two pieces of capacitors. For an order of quantity "1," two pieces of capacitors are to be delivered.


8.5.2.5 Basic connection diagrams

■RHC7.5-2C to RHC90-2C (Applicable inverters: FRN0.75VG1S-2J to FRN90VG1S-2J)

■RHC7.5-4C to RHC220-4C (Applicable inverters: FRN3.7VG1S-4J to FRN220VG1S-4J)



| Symbol | Part name |
|--------|---|
| Lr | Boosting reactor |
| Lf | Filtering reactor |
| Cf | Filtering capacitor |
| Rf | Filtering resistor |
| R0 | Charger resistor |
| F | AC fuse |
| 73 | Magnetic contactor for charging circuit |



(*1) For the 400 V class power supply, connect a stepdown transformer to limit the voltage of the sequence circuit to 220 V or below.

Be sure to connect the auxiliary power input terminals R0 and T0 of the PWM converter to the main power input lines via B contacts of magnetic contactors of the charging circuit (73 or MC). Note that when applied to an ungrounded power supply, an insulated transformer is required. For the details, refer to the "PWM Converter Instruction Manual" (INR-HF51746□).

(*2) For FRN37VG1S-2J or FRN75VG1S-2J, be sure to connect the fan power input terminals R1 and T1 of the inverter to the main power input lines without going through the MC's B contacts or 73.

(*3) For the fan power supply switching connectors, change "CN R" to the NC side and "CN W" to the FAN side.


(*4) Construct a sequence in which a run command is given to the inverter after the PWM converter becomes ready to run.

(*5) Assign the external alarm THR to any of terminals [X1] to [X9] on the inverter.

(*6) Wiring for terminals L1/R, L2/S, L3/T, R2, T2, R1, S1, and T1 should match with the phase sequence.

(*7) Remove the short-circuit bar or DC reactor connected to the P1, P(+) terminal of the inverter unit.

■RHC280-4C to RHC400-4C (Applicable inverters: FRN280VG1S-4J to FRN630VG1S-4J)



- (*1) Connect a stepdown transformer to limit the voltage of the sequence circuit to 220 V or below.
- (*2) Be sure to connect the auxiliary power input terminals R0 and T0 of the PWM converter to the main power input lines via B contacts of magnetic contactors of the power supply circuit (52). Note that when applied to an ungrounded power supply, an insulated transformer is required. For the details, refer to the "PWM Converter Instruction Manual" (INR-HF51746□).
- (*3) Be sure to connect the fan power input terminals R1 and T1 of the inverter to the main power input lines without going through the MC's B contacts or 73.
- (*4) For the fan power supply switching connectors, change "CN R" to the NC side and "CN W" to the FAN side.
- (*5) Construct a sequence in which a run command is given to the inverter after the PWM converter becomes ready to run.
- (*6) Set the timer 52T at 1 sec.
- (*7) Assign the external alarm THR to any of terminals [X1] to [X9] on the inverter.
- (*8) Wiring for terminals L1/R, L2/S, L3/T, R2, T2, R1, S1, and T1 should match with the phase sequence.
- (*9) Remove the short-circuit bar or DC reactor connected to the P1, P(+) terminal of the inverter unit.

8.5.2.6 External dimensions

<PWM converter>

Figure A




Figure B




Figure C





Figure D



| PWM converter type | | Fig | Dimensions(mm) | | | | | | | | | Approx. weight (kg) |
|--------------------|------------|-----|----------------|------|------|------|-------|-----|----|----|-----|---------------------|
| | | | W | W1 | H | H1 | D | D1 | n | B | C | |
| 200V series | RHC7.5-2C | A | 250 | 226 | 380 | 358 | 245 | 125 | 2 | 10 | 10 | 12.5 |
| | RHC11-2C | | | | | | | | | | | |
| | RHC15-2C | | | | | | | | | | | |
| | RHC18.5-2C | B | 340 | 240 | 480 | 460 | 255 | 145 | 2 | 10 | 10 | 24 |
| | RHC22-2C | | | | | | | | | | | |
| | RHC30-2C | B | 340 | 240 | 550 | 530 | 255 | 145 | 2 | 10 | 10 | 29 |
| | RHC37-2C | B | 375 | 275 | 615 | 595 | 270 | 145 | 2 | 10 | 10 | 36 |
| | RHC45-2C | B | 375 | 275 | 740 | 720 | 270 | 145 | 2 | 10 | 10 | 42 |
| | RHC55-2C | B | 375 | 275 | 740 | 720 | 270 | 145 | 2 | 10 | 10 | 44 |
| RHC75-2C | C | 530 | 430 | 750 | 720 | 285 | 145 | 2 | 15 | 15 | 70 | |
| RHC90-2C | C | 680 | 580 | 880 | 850 | 360 | 220 | 3 | 15 | 15 | 115 | |
| 400V series | RHC7.5-4C | A | 250 | 226 | 380 | 358 | 245 | 125 | 2 | 10 | 10 | 12.5 |
| | RHC11-4C | | | | | | | | | | | |
| | RHC15-4C | | | | | | | | | | | |
| | RHC18.5-4C | B | 340 | 240 | 480 | 460 | 255 | 145 | 2 | 10 | 10 | 24 |
| | RHC22-4C | | | | | | | | | | | |
| | RHC30-4C | B | 340 | 240 | 550 | 530 | 255 | 145 | 2 | 10 | 10 | 29 |
| | RHC37-4C | B | 375 | 275 | 550 | 530 | 270 | 145 | 2 | 10 | 10 | 34 |
| | RHC45-4C | B | 375 | 275 | 675 | 655 | 270 | 145 | 2 | 10 | 10 | 38 |
| | RHC55-4C | B | 375 | 275 | 675 | 655 | 270 | 145 | 2 | 10 | 10 | 39 |
| | RHC75-4C | B | 375 | 275 | 740 | 720 | 270 | 145 | 2 | 10 | 10 | 48 |
| | RHC90-4C | C | 530 | 430 | 740 | 710 | 315 | 175 | 2 | 15 | 15 | 70 |
| | RHC110-4C | | | | | | | | | | | |
| | RHC132-4C | C | 530 | 430 | 1000 | 970 | 360 | 220 | 2 | 15 | 15 | 100 |
| | RHC160-4C | | | | | | | | | | | |
| | RHC200-4C | C | 680 | 580 | 1000 | 970 | 360 | 220 | 3 | 15 | 15 | 140 |
| | RHC220-4C | | | | | | | | | | | |
| | RHC280-4C | C | 680 | 580 | 1400 | 1370 | 450 | 285 | 3 | 15 | 15 | 320 |
| | RHC315-4C | | | | | | | | | | | |
| RHC355-4C | C | 880 | 780 | 1400 | 1370 | 450 | 285 | 4 | 15 | 15 | 410 | |
| RHC400-4C | | | | | | | | | | | | |
| RHC500-4C | D | 999 | 900 | 1550 | 1520 | 500 | 313.2 | 4 | 15 | 15 | 525 | |
| RHC630-4C | | | | | | | | | | | | |

< Boosting reactor >

Figure A




Figure B




Figure C





Figure D



| Boosting reactor model | Fig | Dimensions(mm) | | | | | | | | | Approx. weight (kg) |
|------------------------|----------|----------------|-----|-----|-----|-----|-----|-----|-------|-----|---------------------|
| | | W | W1 | H | D | D1 | D2 | K | M | | |
| 200 V Series | LR2-7.5C | A | 180 | 75 | 205 | 105 | 85 | 95 | 7 | M5 | 12 |
| | LR2-15C | B | 195 | 75 | 215 | 131 | 110 | 130 | 7 | M8 | 18 |
| | LR2-22C | C | 240 | 80 | 340 | 215 | 180 | 145 | 10 | M8 | 33 |
| | LR2-37C | C | 285 | 95 | 420 | 240 | 205 | 150 | 12 | M10 | 50 |
| | LR2-55C | C | 285 | 95 | 420 | 250 | 215 | 160 | 12 | M12 | 58 |
| | LR2-75C | C | 330 | 110 | 440 | 255 | 220 | 165 | 12 | M12 | 70 |
| | LR2-110C | C | 345 | 115 | 500 | 280 | 245 | 185 | 12 | M12 | 100 |
| 400 V Series | LR4-7.5C | B | 180 | 75 | 205 | 105 | 85 | 90 | 7 | M4 | 12 |
| | LR4-15C | A | 195 | 75 | 215 | 131 | 110 | 120 | 7 | M5 | 18 |
| | LR4-22C | C | 240 | 80 | 340 | 215 | 180 | 120 | 10 | M6 | 33 |
| | LR4-37C | C | 285 | 95 | 405 | 240 | 205 | 130 | 12 | M8 | 50 |
| | LR4-55C | C | 285 | 95 | 415 | 250 | 215 | 145 | 12 | M10 | 58 |
| | LR4-75C | C | 330 | 110 | 440 | 255 | 220 | 150 | 12 | M10 | 70 |
| | LR4-110C | C | 345 | 115 | 490 | 280 | 245 | 170 | 12 | M12 | 100 |
| | LR4-160C | C | 380 | 125 | 550 | 300 | 260 | 185 | 15 | M12 | 140 |
| | LR4-220C | C | 450 | 150 | 620 | 330 | 290 | 230 | 15 | M12 | 200 |
| | LR4-280C | C | 480 | 160 | 740 | 330 | 290 | 240 | 15 | M16 | 250 |
| | LR4-315C | C | 480 | 160 | 760 | 340 | 300 | 250 | 15 | M16 | 270 |
| | LR4-355C | C | 480 | 160 | 830 | 355 | 315 | 255 | 15 | M16 | 310 |
| | LR4-400C | C | 480 | 160 | 890 | 380 | 330 | 260 | 19 | M16 | 340 |
| | LR4-500C | C | 525 | 175 | 960 | 410 | 360 | 290 | 19 | M16 | 420 |
| LR4-630C | D | 600 | 200 | 64 | 440 | 390 | 290 | 19 | 4×M12 | 450 | |

Note 1: CF4-500C to CF4-630C require two capacitors. (Figures above are for one capacitor.)

< Filtering reactor >

Figure A




Figure B




Figure C




Figure D





Figure E



| Filtering reactor model | | Fig | Dimensions(mm) | | | | | | | | Approx. weight (kg) |
|-------------------------|-----------|-----|----------------|-----|-----|-----|-----|-----|-------|-----|---------------------|
| | | | W | W1 | H | D | D1 | D2 | K | M | |
| 200V series | LFC2-7.5C | B | 125 | 40 | 100 | 85 | 67 | 85 | 6 | M5 | 2.2 |
| | LFC2-15C | B | 125 | 40 | 100 | 93 | 75 | 90 | 6 | M8 | 2.5 |
| | LFC2-22C | B | 125 | 40 | 100 | 93 | 75 | 105 | 6 | M8 | 3.0 |
| | LFC2-37C | B | 150 | 60 | 115 | 103 | 85 | 125 | 6 | M10 | 5.0 |
| | LFC2-55C | B | 175 | 60 | 145 | 110 | 90 | 140 | 6 | M12 | 8.0 |
| | LFC2-75C | B | 195 | 80 | 200 | 120 | 100 | 150 | 7 | M12 | 13 |
| | LFC2-110C | C | 255 | 85 | 230 | 118 | 95 | 165 | 7 | M12 | 20 |
| 400V series | LFC4-7.5C | A | 125 | 40 | 100 | 85 | 67 | 75 | 6 | M4 | 2.2 |
| | LFC4-15C | A | 125 | 40 | 100 | 93 | 75 | 90 | 6 | M5 | 2.5 |
| | LFC4-22C | A | 125 | 40 | 100 | 93 | 75 | 95 | 6 | M6 | 3.0 |
| | LFC4-37C | B | 150 | 60 | 115 | 108 | 90 | 110 | 6 | M8 | 5.0 |
| | LFC4-55C | B | 175 | 60 | 145 | 110 | 90 | 120 | 6 | M10 | 8.0 |
| | LFC4-75C | B | 195 | 80 | 200 | 113 | 93 | 130 | 7 | M10 | 12 |
| | LFC4-110C | C | 255 | 85 | 220 | 113 | 90 | 145 | 7 | M12 | 19 |
| | LFC4-160C | C | 255 | 85 | 245 | 137 | 110 | 150 | 7 | M12 | 22 |
| | LFC4-220C | D | 300 | 100 | 320 | 210 | 180 | 170 | 10 | M12 | 35 |
| | LFC4-280C | D | 330 | 110 | 320 | 230 | 195 | 195 | 12 | M16 | 43 |
| | LFC4-315C | D | 315 | 105 | 365 | 230 | 195 | 200 | 12 | M16 | 48 |
| | LFC4-355C | D | 315 | 105 | 395 | 235 | 200 | 210 | 12 | M16 | 53 |
| | LFC4-400C | D | 345 | 115 | 420 | 235 | 200 | 235 | 12 | M16 | 60 |
| | LFC4-500C | D | 345 | 115 | 480 | 240 | 205 | 240 | 12 | M16 | 72 |
| LFC4-630C | E | 435 | 145 | 550 | 295 | 255 | 205 | 15 | 4×M12 | 175 | |

<Filtering capacitor>

Figure A





Figure B



| Filtering capacitor model | Fig | Dimensions(mm) | | | | | | | | | | Approx. weight (kg) |
|---------------------------|----------|----------------|-----|-----|-----|-----|-----|----|-------------------|-------------------|------|---------------------|
| | | W | W1 | H | H1 | D | D1 | E | F | J | | |
| 200V series | CF2-7.5C | A | 165 | 150 | 185 | - | 70 | 40 | 30 | 7 | M5 | 1.9 |
| | CF2-15C | A | 205 | 190 | 245 | - | 70 | 40 | 30 | 7 | M5 | 3.5 |
| | CF2-22C | A | 280 | 265 | 215 | - | 90 | 55 | 30 | 7 | M5 | 5.5 |
| | CF2-37C | A | 280 | 265 | 235 | - | 90 | 55 | 30 | 7 | M5 | 6.0 |
| | CF2-55C | A | 280 | 265 | 340 | - | 90 | 55 | 80 | 7 | M6 | 8.5 |
| | CF2-75C | A | 280 | 265 | 235 | - | 90 | 55 | 30 | 7 | M5 | 6.0 |
| | CF2-110C | A | 280 | 265 | 340 | - | 90 | 55 | 80 | 7 | M8 | 8.5 |
| 400V series | CF4-7.5C | A | 165 | 150 | 135 | - | 70 | 40 | 30 | 7 | M5 | 1.3 |
| | CF4-15C | A | 165 | 150 | 215 | - | 70 | 40 | 30 | 7 | M5 | 2.3 |
| | CF4-22C | A | 205 | 190 | 185 | - | 70 | 40 | 30 | 7 | M5 | 2.5 |
| | CF4-37C | A | 205 | 190 | 205 | - | 70 | 40 | 30 | 7 | M5 | 2.9 |
| | CF4-55C | A | 205 | 190 | 245 | - | 70 | 40 | 30 | 7 | M5 | 3.5 |
| | CF4-75C | A | 205 | 190 | 205 | - | 70 | 40 | 30 | 7 | M5 | 2.9 |
| | CF4-110C | A | 205 | 190 | 245 | - | 70 | 40 | 30 | 7 | M5 | 3.5 |
| | CF4-160C | A | 280 | 265 | 260 | - | 90 | 55 | 80 | 7 | M6 | 6.0 |
| | CF4-220C | B | 435 | 400 | 310 | 125 | 100 | - | 80 | 15x20 length hole | M12 | 13.0 |
| | CF4-280C | B | 435 | 400 | 350 | 165 | 100 | - | 80 | 15x20 length hole | M12 | 15.0 |
| | CF4-315C | B | 435 | 400 | 460 | 275 | 100 | - | 80 | 15x20 length hole | M12 | 20.0 |
| | CF4-355C | B | 435 | 400 | 520 | 335 | 100 | - | 80 | 15x20 length hole | M12 | 23.0 |
| | CF4-400C | B | 435 | 400 | 610 | 425 | 100 | - | 80 | 15x20 length hole | M12 | 27.0 |
| | CF4-500C | B | 435 | 400 | 310 | 125 | 100 | - | 80 | 15x20 length hole | M12 | 13.0 |
| CF4-630C | B | 435 | 400 | 460 | 275 | 100 | - | 80 | 15x20 length hole | M12 | 20.0 | |

< Filtering resistor >

Figure A




Figure B





Figure C



| Filtering resistor model | Fig | Dimensions(mm) | | | | | | | | | Approx. weight (kg) | |
|--------------------------|---------------|----------------|-----|-----|-----|-----|----|-----|-----|-----|---------------------|------|
| | | W | W1 | W2 | H1 | H2 | D | D1 | D2 | C | | |
| 200V series | GRZG80 0.42Ω | A | 167 | 148 | 115 | 22 | 32 | 33 | 26 | 6 | 5.5 | 0.19 |
| | GRZG150 0.2Ω | A | 247 | 228 | 195 | 22 | 40 | 33 | 26 | 6 | 8.2 | 0.30 |
| | GRZG200 0.13Ω | A | 306 | 287 | 254 | 22 | 40 | 33 | 26 | 6 | 8.2 | 0.35 |
| | GRZG400 0.1Ω | A | 411 | 385 | 330 | 40 | 46 | 47 | 40 | 9.5 | 8.2 | 0.85 |
| | GRZG400 0.12Ω | A | 411 | 385 | 330 | 40 | 46 | 47 | 40 | 9.5 | 8.2 | 0.85 |
| 400V series | GRZG80 1.74Ω | A | 167 | 148 | 115 | 22 | 32 | 33 | 26 | 6 | 5.5 | 0.19 |
| | GRZG150 0.79Ω | A | 247 | 228 | 195 | 22 | 32 | 33 | 26 | 6 | 5.5 | 0.3 |
| | GRZG200 0.53Ω | A | 306 | 287 | 254 | 22 | 32 | 33 | 26 | 6 | 5.5 | 0.35 |
| | GRZG400 0.38Ω | A | 411 | 385 | 330 | 40 | 46 | 47 | 40 | 9.5 | 8.2 | 0.85 |
| | GRZG400 0.26Ω | A | 411 | 385 | 330 | 40 | 46 | 47 | 40 | 9.5 | 8.2 | 0.85 |
| | GRZG400 0.53Ω | A | 411 | 385 | 330 | 40 | 46 | 47 | 40 | 9.5 | 8.2 | 0.85 |
| | RF4-160C | B | 400 | 370 | - | 240 | 55 | 470 | 460 | 320 | - | 22 |
| | RF4-220C | | 25 | | | | | | | | | |
| | RF4-280C | C | 655 | 625 | - | 240 | 55 | 470 | 460 | 320 | - | 31 |
| | RF4-315C | | 35 | | | | | | | | | |
| | RF4-355C | | 36 | | | | | | | | | |
| | RF4-400C | | 38 | | | | | | | | | |
| | RF4-500C | | 41 | | | | | | | | | |
| RF4-630C | 70 | | | | | | | | | | | |


< Charging box >

The charging box contains a combination of a charging resistor and a fuse, which is essential in the configuration of the RHC-C series of PWM converters. Using this charging box eases mounting and wiring jobs.

■ Capacity range

200 V series: 7.5 kW to 90 kW in 10 types, 400 V series: 7.5 kW to 220 kW in 14 types, Total 24 types

As for 400 V class series with a capacity of 280 to 400 kW, the charging resistor and the fuse are separately provided as before.



| Fuse model | | Dimensions(mm) | | | | | | | | | | Mounting bolt | Approx. weight (kg) |
|-------------|-----------|----------------|-----|-----|-----|-----|-----|----|-----|-----|----|---------------|---------------------|
| | | W | W1 | H | H1 | H2 | H3 | 4 | D | D1 | C | | |
| 200V series | CU7.5-2C | 270 | 170 | 300 | 285 | 270 | 7.5 | 15 | 100 | 2.4 | 6 | M5 | 6 |
| | CU11-2C | | | | | | | | | | | | |
| | CU15-2C | | | | | | | | | | | | |
| | CU18.5-2C | | | | | | | | | | | | |
| | CU22-2C | | | | | | | | | | | | |
| | CU30-2C | 300 | 200 | 310 | 295 | 280 | 7.5 | 15 | 110 | 2.4 | 6 | M5 | 7 |
| | CU45-2C | 330 | 230 | 310 | 295 | 280 | 7.5 | 15 | 130 | 2.4 | 6 | M5 | 8 |
| | CU55-2C | 430 | 330 | 560 | 536 | 510 | 12 | 25 | 150 | 3.2 | 10 | M8 | 17 |
| | CU75-2C | | | | | | | | | | | | 20 |
| | CU90-2C | | | | | | | | | | | | |
| 400V series | CU7.5-4C | 270 | 170 | 300 | 285 | 270 | 7.5 | 15 | 100 | 2.4 | 6 | M5 | 5.5 |
| | CU15-4C | | | | | | | | | | | | 6 |
| | CU18.5-4C | | | | | | | | | | | | |
| | CU22-4C | | | | | | | | | | | | |
| | CU30-4C | 300 | 200 | 310 | 295 | 280 | 7.5 | 15 | 110 | 2.4 | 6 | M5 | 7 |
| | CU45-4C | 330 | 230 | 310 | 295 | 280 | 7.5 | 15 | 130 | 2.4 | 6 | M5 | 8 |
| | CU55-4C | | | | | | | | | | | | |
| | CU75-4C | | | | | | | | | | | | |
| | CU90-4C | 430 | 330 | 560 | 536 | 510 | 12 | 25 | 150 | 3.2 | 10 | M8 | 18 |
| | CU110-4C | | | | | | | | | | | | 20 |
| | CU132-4C | | | | | | | | | | | | |
| | CU160-4C | | | | | | | | | | | | |
| | CU200-4C | | | | | | | | | | | | |
| | CU220-4C | | | | | | | | | | | | |

<Charger resistor>

Figure A




Figure B





Figure C



| Charger resistor model | Fig | Dimensions(mm) | | | | | | | | | Approx. weight (kg) |
|------------------------|-----|----------------|-----|-----|----|----|----|----|-----|-----|---------------------|
| | | W | W1 | W2 | H1 | H2 | D | D1 | D2 | C | |
| GRZG120 2Ω | A | 217 | 198 | 165 | 22 | 32 | 33 | 22 | 6 | 5.5 | 0.25 |
| GRZG400 1Ω | A | 411 | 385 | 330 | 40 | 39 | 47 | 40 | 9.5 | 5.5 | 0.85 |
| TK50B 30ΩJ (HF5B0416) | B | - | - | - | - | - | - | - | - | - | 0.15 |
| 80W 7.5Ω (HF5C5504) | C | - | - | - | - | - | - | - | - | - | 0.19 |

<fuse>

Figure A




Figure B






Figure C



Side view of A70P1600-4TA



Side view of A70P2000-4

| Fuse model | | Fig | Dimensions(mm) | | | | | | | | Approx. weight (kg) |
|-------------|--------------|-------|----------------|-------|------|------|------|------|-----------|-----------|---------------------|
| | | | W | W1 | W2 | H | D | D1 | G | E | |
| 200V series | CR2LS-50/UL | A | 56 | 42 | 26 | 18.5 | 17.5 | 12 | 2 | 6.5x8.5 | 0.03 |
| | CR2LS-75/UL | | | | | | | | | | |
| | CR2LS-100/UL | | | | | | | | | | |
| | CR2L-150/UL | A | 80 | 58 | 29.5 | 30.5 | 27 | 20 | 3 | 9x11 | 0.10 |
| | CR2L-200/UL | A | 85 | 60 | 30 | 33.5 | 30 | 25 | 3.2 | 11x13 | 0.13 |
| | CR2L-260/UL | A | 95 | 70 | 31 | 42 | 37 | 30 | 4 | 11x13 | 0.22 |
| | CR2L-400/UL | | | | | | | | | | |
| A50P600-4 | B | 113.5 | 81.75 | 56.4 | - | 50.8 | 38.1 | 6.4 | 10.3x18.2 | 0.60 | |
| 400V series | CR6L-30/UL | A | 76 | 62 | 47 | 18.5 | 17.5 | 12 | 2 | 6.5x8.5 | 0.04 |
| | CR6L-50/UL | | | | | | | | | | |
| | CR6L-75/UL | A | 95 | 70 | 40 | 34 | 30 | 25 | 3.2 | 11x13 | 0.15 |
| | CR6L-100/U | | | | | | | | | | |
| | CR6L-150/UL | | | | | | | | | | |
| | CR6L-200/UL | A | 107 | 82 | 43 | 42 | 37 | 30 | 4 | 11x13 | 0.25 |
| | CR6L-300/UL | | | | | | | | | | |
| | A50P400-4 | B | 110 | 78.6 | 53.1 | - | 38.1 | 25.4 | 6.4 | 10.3x18.4 | 0.30 |
| | A50P600-4 | B | 113.5 | 81.75 | 56.4 | - | 50.8 | 38.1 | 6.4 | 10.3x18.2 | 0.60 |
| | A70QS800-4 | B | 180.2 | 129.4 | 72.2 | - | 63.5 | 50.8 | 9.5 | 13.5x18.3 | 1.1 |
| A70P1600-4T | C | - | - | - | - | - | - | - | - | - | 8.0 |
| A70P2000-4 | C | - | - | - | - | - | - | - | - | - | 8.0 |

8.5.2.7 Generated loss

(1) In CT mode

| Main unit | | Boosting reactor | | Filtering reactor | | < Filtering resistor > | | |
|------------|--------------------|------------------|--------------------|-------------------|--------------------|-------------------------------|------|--------------------|
| Model | Generated loss (W) | Model | Generated loss (W) | Model | Generated loss (W) | Model | Qty. | Generated loss (W) |
| RHC7.5-2C | 400 | LR2-7.5C | 95 | LFC2-7.5C | 10 | GRZG80 0.42Ω | 3 | 16 |
| RHC11-2C | 500 | LR2-15C | 150 | LFC2-15C | 19 | GRZG150 0.2Ω | 3 | 48 |
| RHC15-2C | 650 | | | | | | | |
| RHC18.5-2C | 700 | LR2-22C | 230 | LFC2-22C | 26 | GRZG200 0.13Ω | 3 | 68 |
| RHC22-2C | 800 | | | | | | | |
| RHC30-2C | 1000 | LR2-37C | 330 | LFC2-37C | 32 | GRZG400 0.1Ω | 3 | 107 |
| RHC37-2C | 1350 | | | | | | | |
| RHC45-2C | 1500 | LR2-55C | 450 | LFC2-55C | 43 | GRZG400 0.1Ω | 3 | 240 |
| RHC55-2C | 1750 | | | | | | | |
| RHC75-2C | 2050 | LR2-75C | 520 | LFC2-75C | 74 | GRZG400 0.1Ω | 3 | 137 |
| RHC90-2C | 2450 | LR2-110C | 720 | LFC2-110C | 115 | GRZG400 0.12Ω (2 parallel) | 6 | 374 |
| RHC7.5-4C | 400 | LR4-7.5C | 90 | LFC4-7.5C | 9 | GRZG80 1.74Ω | 3 | 15 |
| RHC11-4C | 500 | LR4-15C | 160 | LFC4-15C | 20 | GRZG150 0.79Ω | 3 | 48 |
| RHC15-4C | 600 | | | | | | | |
| RHC18.5-4C | 650 | LR4-22C | 230 | LFC4-22C | 22 | GRZG200 0.53Ω | 3 | 70 |
| RHC22-4C | 900 | | | | | | | |
| RHC30-4C | 1200 | LR4-37C | 350 | LFC4-37C | 36 | GRZG400 0.38Ω | 3 | 86 |
| RHC37-4C | 1550 | | | | | | | |
| RHC45-4C | 1800 | LR4-55C | 490 | LFC4-55C | 43 | GRZG400 0.26Ω | 3 | 130 |
| RHC55-4C | 2050 | | | | | | | |
| RHC75-4C | 2150 | LR4-75C | 520 | LFC4-75C | 78 | GRZG400 0.38Ω | 3 | 112 |
| RHC90-4C | 2600 | LR4-110C | 710 | LFC4-110C | 90 | GRZG400 0.53Ω (2 parallel) | 6 | 405 |
| RHC110-4C | 3050 | | | | | | | |
| RHC132-4C | 3500 | LR4-160C | 1000 | LFC4-160C | 160 | RF4-160C | 1 | 568 |
| RHC160-4C | 4150 | | | | | | | |
| RHC200-4C | 5100 | LR4-220C | 1240 | LFC4-220C | 200 | RF4-220C | 1 | 751 |
| RHC220-4C | 5600 | | | | | | | |
| RHC280-4C | 7100 | LR4-280C | 1430 | LFC4-280C | 220 | RF4-280C | 1 | 1027 |
| RHC315-4C | 8000 | LR4-315C | 1660 | LFC4-315C | 260 | RF4-315C | 1 | 1154 |
| RHC355-4C | 8900 | LR4-355C | 1910 | LFC4-355C | 300 | RF4-355C | 1 | 1286 |
| RHC400-4C | 10100 | LR4-400C | 2160 | LFC4-400C | 350 | RF4-400C | 1 | 1454 |
| RHC500-4C | 10000 | LR4-500C | 2470 | LFC4-500C | 450 | RF4-500C | 1 | 5463 |
| RHC630-4C | 12400 | LR4-630C | 2300 | LFC4-630C | 510 | RF4-630C | 1 | 4722 |

(2) In VT mode

| Main unit | | Boosting reactor | | Filtering reactor | | < Filtering resistor > | | |
|------------|--------------------|------------------|--------------------|-------------------|--------------------|-------------------------------|------|--------------------|
| Model | Generated loss (W) | Model | Generated loss (W) | Model | Generated loss (W) | Model | Qty. | Generated loss (W) |
| RHC7.5-2C | 450 | LR2-15C | 150 | LFC2-15C | 19 | GRZG150 0.2Ω | 3 | 48 |
| RHC11-2C | 550 | | | | | | | |
| RHC15-2C | 650 | | | | | | | |
| RHC18.5-2C | 750 | LR2-22C | 230 | LFC2-22C | 26 | GRZG200 0.13Ω | 3 | 68 |
| RHC22-2C | 850 | | | | | | | |
| RHC30-2C | 1200 | LR2-37C | 330 | LFC2-37C | 32 | GRZG400 0.1Ω | 3 | 107 |
| RHC37-2C | 1500 | | | | | | | |
| RHC45-2C | 1600 | LR2-55C | 450 | LFC2-55C | 43 | GRZG400 0.1Ω | 3 | 240 |
| RHC55-2C | 2100 | | | | | | | |
| RHC75-2C | 2300 | LR2-110C | 720 | LFC2-110C | 115 | GRZG400 0.12Ω (2 parallel) | 6 | 374 |
| RHC90-2C | 2650 | | | | | | | |
| RHC7.5-4C | 400 | LR4-15C | 160 | LFC4-15C | 20 | GRZG150 0.79Ω | 3 | 48 |
| RHC11-4C | 500 | | | | | | | |
| RHC15-4C | 600 | LR4-22C | 230 | LFC4-22C | 22 | GRZG200 0.53Ω | 3 | 70 |
| RHC18.5-4C | 600 | | | | | | | |
| RHC22-4C | 950 | LR4-37C | 350 | LFC4-37C | 36 | GRZG400 0.38Ω | 3 | 86 |
| RHC30-4C | 1200 | | | | | | | |
| RHC37-4C | 1450 | LR4-55C | 490 | LFC4-55C | 43 | GRZG400 0.26Ω | 3 | 130 |
| RHC45-4C | 1750 | | | | | | | |
| RHC55-4C | 2250 | LR4-75C | 520 | LFC4-75C | 78 | GRZG400 0.38Ω | 3 | 112 |
| RHC75-4C | 1950 | | | | | | | |
| RHC90-4C | 2400 | LR4-110C | 710 | LFC4-110C | 90 | GRZG400 0.53Ω (2 parallel) | 6 | 405 |
| RHC110-4C | 2900 | | | | | | | |
| RHC132-4C | 3250 | LR4-160C | 1000 | LFC4-160C | 160 | RF4-160C | 1 | 568 |
| RHC160-4C | 4100 | | | | | | | |
| RHC200-4C | 4400 | LR4-220C | 1240 | LFC4-220C | 200 | RF4-220C | 1 | 751 |
| RHC220-4C | 5600 | | | | | | | |
| RHC280-4C | 6250 | LR4-315C | 1660 | LFC4-315C | 260 | RF4-315C | 1 | 1154 |
| RHC315-4C | 7000 | | | | | | | |
| RHC355-4C | 8050 | LR4-400C | 2160 | LFC4-400C | 350 | RF4-400C | 1 | 1454 |
| RHC400-4C | 8950 | | | | | | | |
| | | LR4-500C | 2470 | LFC4-500C | 450 | RF4-500C | 1 | 1821 |

* The generated loss for the filtering resistor above represent the value for all quantities.

8.5.3 DC reactor (DCR)

A DCR is mainly used for power supply matching and for input power factor correction (for reducing harmonic components).

For power supply matching

- Use a DCR when the capacity of a power supply transformer exceeds 500 kVA and is 10 times or more the rated inverter capacity. In this case, the percent reactance of the power supply decreases, and harmonic components and their peak value increase. These factors may break rectifiers or capacitors in the converter section of inverter, or decrease the capacitance of the capacitor (which can shorten the inverter's service life).
- Also use a DCR when there are thyristor-driven loads or when phase-advancing capacitors are being turned ON/OFF.
- Use a DCR when the interphase voltage unbalance ratio of the inverter power supply exceeds 2%.

$$\text{Interphase voltage unbalance (\%)} = \frac{\text{Max. voltage (V)} - \text{Min. voltage (V)}}{\text{Three - phase average voltage (V)}} \times 67$$

For input power factor correction (for suppressing harmonics)

Generally a capacitor is used to improve the power factor of the load, however, it cannot be used in a system that includes an inverter. Using a DCR increases the reactance of inverter's power supply so as to decrease harmonic components on the power supply lines and improve the power factor of inverter. Using a DCR improves the input power factor to approximately 86% to 95%.

Note <HD class product: 55 kW or lower, LD class product: 45 kW or lower>

- At the time of shipping, a jumper bar is connected across terminals P1 and P (+) on the terminal block. Remove the jumper bar when connecting a DCR.
- If a DCR is not going to be used, do not remove the jumper bar.

<HD class product: 75 kW or higher, LD class product: 55 kW or higher, MD class product >

- At the time of shipping, a jumper bar is not connected across terminals P1 and P (+) on the terminal block. Be sure to connect the (supplied) DC reactor.




Figure 8.9 External View of a DC Reactor (DCR) and Connection Example

Table 8.10 DC reactor (DCR)

| Power supply voltage | Nominal applicable motor (kW) | Inverter type | Specifications | Reactor model | Rated current (A) | Inductance (mH) | Generated loss (W) |
|----------------------|-------------------------------|----------------|----------------|---------------|-------------------|-----------------|--------------------|
| Three-phase 200V | 0.75 | FRN0.75VG1□-2J | HD | DCR2-0.75 | 5 | 7 | 2.8 |
| | 1.5 | FRN1.5VG1□-2J | | DCR2-1.5 | 8 | 4 | 4.6 |
| | 2.2 | FRN2.2VG1□-2J | | DCR2-2.2 | 11 | 3 | 6.7 |
| | 3.7 | FRN3.7VG1□-2J | | DCR2-3.7 | 18 | 1.7 | 8.8 |
| | 5.5 | FRN5.5VG1□-2J | | DCR2-5.5 | 25 | 1.2 | 14 |
| | 7.5 | FRN7.5VG1□-2J | | DCR2-7.5 | 34 | 0.8 | 16 |
| | 11 | FRN11VG1□-2J | | DCR2-11 | 50 | 0.6 | 27 |
| | 15 | FRN15VG1□-2J | | DCR2-15 | 67 | 0.4 | 27 |
| | 18.5 | FRN18.5VG1□-2J | | DCR2-18.5 | 81 | 0.35 | 29 |
| | 22 | FRN22VG1□-2J | | DCR2-22A | 98 | 0.3 | 38 |
| | 30 | FRN30VG1□-2J | HD | DCR2-30B | 136 | 0.23 | 37 |
| | 37 | | LD | DCR2-37B | 167 | 0.19 | 47 |
| | | FRN37VG1□-2J | HD | DCR2-37B | 167 | 0.19 | 47 |
| | | | LD | DCR2-37C | 175 | 0.119 | 63 |
| | | 45 | FRN45VG1□-2J | LD | DCR2-45B | 203 | 0.16 |
| | HD | | | DCR2-45C | 213 | 0.1 | 68 |
| | FRN55VG1□-2J | | LD | DCR2-45B | 203 | 0.16 | 52 |
| | | | HD | DCR2-45C | 213 | 0.1 | 68 |
| | 55 | FRN55VG1□-2J | LD | DCR2-55B | 244 | 0.13 | 55 |
| | | | HD | DCR2-55C | 256 | 0.08 | 75 |
| | | FRN75VG1□-2J | HD | DCR2-55B | 244 | 0.13 | 55 |
| | | | LD | DCR2-55C | 256 | 0.08 | 75 |
| | 75 | FRN75VG1□-2J | LD | DCR2-75C | 358 | 0.05 | 96 |
| | 90 | | HD | DCR2-90C | 431 | 0.042 | 100 |
| | | 110 | FRN90VG1□-2J | LD | DCR2-110C | 552 | 0.034 |

Note 1: Generated losses listed in the above table are approximate values that are calculated according to the following conditions:

- The power supply is three-phase 200 V/400 V 50 Hz with 0% interphase voltage unbalance ratio.
- The power supply capacity uses the larger of either 500 kVA or 10 times the rated capacity of the inverter.
- The motor is a 4-pole standard model at full load (100%).
- An AC reactor (ACR) is not connected.

Note 2: □ in the inverter model represents an alphabet.

□
└─ S (Basic type)

Table 8.10 DC reactor (DCR) (continued)

| Power supply voltage | Nominal applied motor (kW) | Inverter type | Specifi-cations | Reactor model | Rated current (A) | Inductance (mH) | Generated loss (W) |
|----------------------|----------------------------|----------------|-----------------|---------------|-------------------|-----------------|--------------------|
| Three-phase 400 V | 3.7 | FRN3.7VG1□-4J | HD | DCR4-3.7 | 9 | 7 | 8.1 |
| | 5.5 | FRN5.5VG1□-4J | | DCR4-5.5 | 13 | 4 | 10 |
| | 7.5 | FRN7.5VG1□-4J | | DCR4-7.5 | 18 | 3.5 | 15 |
| | 11 | FRN11VG1□-4J | | DCR4-11 | 25 | 2.2 | 21 |
| | 15 | FRN15VG1□-4J | | DCR4-15 | 34 | 1.8 | 28 |
| | 18.5 | FRN18.5VG1□-4J | | DCR4-18.5 | 41 | 1.4 | 29 |
| | 22 | FRN22VG1□-4J | | DCR4-22A | 49 | 1.2 | 35 |
| | 30 | FRN22VG1□-4J | | DCR4-30B | 71 | 0.86 | 35 |
| | 37 | FRN30VG1□-4J | LD | DCR4-37B | 88 | 0.70 | 40 |
| | | | | DCR4-37C | 88 | 0.483 | 63 |
| | 45 | FRN37VG1□-4J | HD | DCR4-37B | 88 | 0.70 | 40 |
| | | | | DCR4-37C | 88 | 0.483 | 63 |
| | | | LD | DCR4-45B | 107 | 0.58 | 44 |
| | | | | DCR4-45C | 107 | 0.4 | 69 |
| | 55 | FRN45VG1□-4J | HD | DCR4-45B | 107 | 0.58 | 44 |
| | | | | DCR4-45C | 107 | 0.4 | 69 |
| | | | LD | DCR4-55B | 131 | 0.47 | 55 |
| | | | | DCR4-55C | 131 | 0.324 | 78 |
| | 75 | FRN55VG1□-4J | HD | DCR4-55B | 131 | 0.47 | 55 |
| | | | LD | DCR4-55C | 131 | 0.324 | 78 |
| | 90 | FRN75VG1□-4J | HD | DCR4-75C | 178 | 0.23 | 97 |
| | | | LD | DCR4-75C | 178 | 0.23 | 97 |
| | 110 | FRN90VG1□-4J | HD | DCR4-90C | 214 | 0.2 | 111 |
| | | | MD/LD | DCR4-110C | 261 | 0.166 | 122 |
| | 132 | FRN110VG1□-4J | HD | | | | |
| | | | MD/LD | | | | |
| | 160 | FRN132VG1□-4J | MD/LD | DCR4-160C | 380 | 0.122 | 185 |
| | | | HD | | | | |
| | 200 | FRN160VG1□-4J | MD/LD | DCR4-200C | 475 | 0.098 | 218 |
| | | | HD | | | | |
| | 220 | FRN200VG1□-4J | MD/LD | DCR4-220C | 524 | 0.087 | 231 |
| | | | HD | | | | |
| | 250 | FRN220VG1□-4J | MD | DCR4-250C | 589 | 0.077 | 249 |
| | | | LD | | | | |
| | 280 | FRN220VG1□-4J | HD | DCR4-280C | 649 | 0.069 | 270 |
| | | | MD | | | | |
| | 315 | FRN280VG1□-4J | MD | DCR4-315C | 739 | 0.061 | 285 |
| | 355 | FRN315VG1□-4J | LD | DCR4-355C | 833 | 0.054 | 308 |
| | | | HD | DCR4-315C | 739 | 0.061 | 285 |
| | | | MD | DCR4-355C | 833 | 0.054 | 308 |
| | 400 | FRN315VG1□-4J | LD | DCR4-400C | 938 | 0.048 | 323 |
| | 355 | | HD | DCR4-355C | 833 | 0.054 | 308 |
| 400 | MD | | DCR4-400C | 938 | 0.048 | 323 | |
| 450 | FRN355VG1□-4J | LD | DCR4-450C | 1056 | 0.043 | 338 | |
| | | HD | DCR4-400C | 938 | 0.048 | 323 | |
| | | MD | DCR4-450C | 1056 | 0.043 | 338 | |
| 500 | FRN400VG1□-4J | LD | DCR4-500C | 1173 | 0.039 | 384 | |
| | | HD | | | | | |
| 630 | FRN500VG1□-4J | LD | DCR4-630C | 1477 | 0.031 | 620 | |
| | | HD | | | | | |
| 710 | FRN630VG1□-4J | LD | DCR4-710C | 1666 | 0.028 | 600 | |

Note 1: □ in the inverter model represents an alphabet.

□
└─ S (Basic type)

Note 2: Generated losses listed in the above table are approximate values that are calculated according to the following conditions:

- The power supply is three-phase 200 V/400 V 50 Hz with 0% interphase voltage unbalance ratio.
- The power supply capacity uses the larger of either 500 kVA or 10 times the rated capacity of the inverter.
- The motor is a 4-pole standard model at full load (100%).
- An AC reactor (ACR) is not connected.




Table 8.11 DC Reactors (DCRs) External Dimensions

| Power supply voltage | Nominal applied motor (kW) | Inverter type | Specifications | Reactor model | Dimensions | | | | | | | | Approx. weight (kg) | | |
|----------------------|----------------------------|----------------|----------------|---------------|------------|-----|-----|-----|-----|-----------|-----------|--------|---------------------|-----|-----|
| | | | | | Fig | W | W1 | D | D1 | D2 | G | H | | H1 | J |
| Three-phase 200V | 0.75 | FRN0.75VG1□-2J | HD | DCR2-0.75 | A | 66 | 56 | 90 | 72 | 20 | M4(5.2×8) | 94 | - | M4 | 1.4 |
| | 1.5 | FRN1.5VG1□-2J | | DCR2-1.5 | 66 | 56 | 90 | 72 | 20 | M4(5.2×8) | 94 | - | M4 | 1.6 | |
| | 2.2 | FRN2.2VG1□-2J | | DCR2-2.2 | 86 | 71 | 100 | 80 | 10 | M5(6×9) | 110 | - | M4 | 1.8 | |
| | 3.7 | FRN3.7VG1□-2J | | DCR2-3.7 | 86 | 71 | 100 | 80 | 20 | M5(6×9) | 110 | - | M4 | 2.6 | |
| | 5.5 | FRN5.5VG1□-2J | | DCR2-5.5 | 111 | 95 | 100 | 80 | 20 | M6(7×11) | 130 | - | M5 | 3.6 | |
| | 7.5 | FRN7.5VG1□-2J | | DCR2-7.5 | 111 | 95 | 100 | 80 | 23 | M6(7×11) | 130 | - | M5 | 3.8 | |
| | 11 | FRN11VG1□-2J | | DCR2-11 | 111 | 95 | 100 | 80 | 24 | M6(7×11) | 137 | - | M6 | 4.3 | |
| | 15 | FRN15VG1□-2J | | DCR2-15 | 146 | 124 | 120 | 96 | 15 | M6(7×11) | 180 | - | M8 | 5.9 | |
| | 18.5 | FRN18.5VG1□-2J | | DCR2-18.5 | 146 | 124 | 120 | 96 | 25 | M6(7×11) | 180 | - | M8 | 7.4 | |
| | 22 | FRN22VG1□-2J | | DCR2-22A | 146 | 124 | 120 | 96 | 25 | M6(7×11) | 180 | - | M8 | 7.5 | |
| | 30 | FRN30VG1□-2J | | HD | DCR2-30B | B | 152 | 90 | 156 | 116 | 115 | M6(Φ8) | 130 | 190 | M10 |
| | 37 | | LD | DCR2-37B | B | 171 | 110 | 151 | 110 | 115 | M6(Φ8) | 150 | 200 | M10 | 14 |
| | | | DCR2-37C | C | 210 | 185 | 101 | 81 | 125 | M6(7×13) | 125 | - | M10 | 7.4 | |
| | 45 | FRN37VG1□-2J | HD | DCR2-37B | B | 171 | 110 | 151 | 110 | 115 | M6(Φ8) | 150 | 200 | M10 | 14 |
| | | | LD | DCR2-45B | B | 171 | 110 | 166 | 125 | 120 | M6(Φ8) | 150 | 200 | M10 | 16 |
| | 55 | FRN45VG1□-2J | HD | DCR2-45C | C | 210 | 185 | 106 | 86 | 135 | M6(7×13) | 125 | - | M12 | 8.4 |
| | | | LD | DCR2-45B | B | 171 | 110 | 166 | 125 | 120 | M6(Φ8) | 150 | 200 | M10 | 16 |
| | 75 | FRN55VG1□-2J | HD | DCR2-55C | C | 210 | 185 | 106 | 86 | 135 | M6(7×13) | 125 | - | M12 | 8.4 |
| | | | LD | DCR2-55B | D | 190 | 160 | 131 | 90 | 100 | M6(Φ8) | 210 | 250 | M12 | 16 |
| | 90 | FRN75VG1□-2J | HD | DCR2-55C | D | 255 | 225 | 96 | 76 | 140 | M6(7×13) | 145 | - | M12 | 11 |
| | | | LD | DCR2-75C | C | 255 | 225 | 106 | 86 | 145 | M6(7×13) | 145 | - | M12 | 12 |
| | 110 | FRN90VG1□-2J | HD | DCR2-90C | C | 255 | 225 | 116 | 96 | 155 | M6(7×13) | 145 | - | M12 | 14 |
| | | | LD | DCR2-110C | C | 300 | 265 | 116 | 90 | 185 | M8(10×18) | 160 | - | M12 | 17 |

Note : □ in the inverter model represents an alphabet.

□
└─ S (Basic type)

Table 8.11 DC Reactors (DCRs) External Dimensions (continued)

| Power supply voltage | Nominal applied motor (kW) | Inverter type | Specifications | Reactor model | Dimensions | | | | | | | | | Approx. weight (kg) | |
|----------------------|----------------------------|----------------|----------------|---------------|------------|-----|-----|-----|-----|------------|------------|-----|-------|---------------------|-----|
| | | | | | Fig | W | W1 | D | D1 | D2 | G | H | H1 | | J |
| Three-phase 400V | 3.7 | FRN3.7VG1□-4J | HD | DCR4-3.7 | A | 86 | 71 | 100 | 80 | 20 | M5(6×9) | 110 | - | M4 | 2.6 |
| | 5.5 | FRN5.5VG1□-4J | | DCR4-5.5 | | 86 | 71 | 100 | 80 | 20 | M5(6×9) | 110 | - | M4 | 2.6 |
| | 7.5 | FRN7.5VG1□-4J | | DCR4-7.5 | | 111 | 95 | 100 | 80 | 24 | M6(7×11) | 130 | - | M5 | 4.2 |
| | 11 | FRN11VG1□-4J | | DCR4-11 | | 111 | 95 | 100 | 80 | 24 | M6(7×11) | 130 | - | M5 | 4.3 |
| | 15 | FRN15VG1□-4J | | DCR4-15 | | 146 | 124 | 120 | 96 | 15 | M6(7×11) | 168 | - | M5 | 5.9 |
| | 18.5 | FRN18.5VG1□-4J | | DCR4-18.5 | | 146 | 124 | 120 | 96 | 25 | M6(7×11) | 171 | - | M6 | 7.2 |
| | 22 | FRN22VG1□-4J | | DCR4-22A | | 146 | 124 | 120 | 96 | 25 | M6(7×11) | 171 | - | M6 | 7.2 |
| | 30 | FRN30VG1□-4J | | DCR4-30B | | 152 | 90 | 157 | 115 | 100 | M6(Φ8) | 130 | 190 | M8 | 13 |
| | 37 | | LD | DCR4-37B | B | 171 | 110 | 150 | 110 | 100 | M6(Φ8) | 150 | 200 | M8 | 15 |
| | | DCR4-37C | | C | 210 | 185 | 101 | 81 | 105 | M6(7×13) | 125 | - | M8 | 7.4 | |
| | | HD | DCR4-37B | B | 171 | 110 | 150 | 110 | 100 | M6(Φ8) | 150 | 200 | M8 | 15 | |
| | | | DCR4-37C | C | 210 | 185 | 101 | 81 | 105 | M6(7×13) | 125 | - | M8 | 7.4 | |
| | 45 | FRN37VG1□-4J | LD | DCR4-45B | B | 171 | 110 | 165 | 125 | 110 | M6(Φ8) | 150 | 210 | M8 | 18 |
| | | | | DCR4-45C | C | 210 | 185 | 106 | 86 | 120 | M6(7×13) | 125 | - | M8 | 8.4 |
| | | HD | DCR4-45B | B | 171 | 110 | 165 | 125 | 110 | M6(Φ8) | 150 | 210 | M8 | 18 | |
| | | | DCR4-45C | C | 210 | 185 | 106 | 86 | 120 | M6(7×13) | 125 | - | M8 | 8.4 | |
| | 55 | FRN45VG1□-4J | LD | DCR4-55B | B | 171 | 110 | 170 | 130 | 110 | M6(Φ8) | 150 | 210 | M8 | 20 |
| | | | | DCR4-55C | C | 255 | 225 | 96 | 76 | 120 | M6(7×13) | 145 | - | M10 | 11 |
| | | HD | DCR4-55B | B | 171 | 110 | 170 | 130 | 110 | M6(Φ8) | 150 | 210 | M8 | 20 | |
| | | | DCR4-55C | | 255 | 225 | 96 | 76 | 120 | M6(7×13) | 145 | - | M10 | 11 | |
| | 75 | FRN75VG1□-4J | LD | DCR4-75C | | 255 | 225 | 106 | 86 | 125 | M6(7×13) | 145 | - | M10 | 13 |
| | | | HD | DCR4-75C | | 255 | 225 | 106 | 86 | 125 | M6(7×13) | 145 | - | M10 | 13 |
| | 90 | FRN90VG1□-4J | LD | DCR4-90C | | 255 | 225 | 116 | 96 | 140 | M6(7×13) | 145 | - | M12 | 15 |
| | | | HD | | | | | | | | | | | | |
| | 110 | FRN110VG1□-4J | MD/LD | DCR4-110C | | 300 | 265 | 116 | 90 | 175 | M8(10×18) | 155 | - | M12 | 19 |
| | | | HD | | | | | | | | | | | | |
| | 132 | FRN132VG1□-4J | MD/LD | DCR4-132C | | 300 | 265 | 126 | 100 | 180 | M8(10×18) | 160 | - | M12 | 22 |
| | | | HD | | | | | | | | | | | | |
| | 160 | FRN160VG1□-4J | MD/LD | DCR4-160C | C | 350 | 310 | 131 | 103 | 180 | M10(12×22) | 190 | - | M12 | 26 |
| | | | HD | | | | | | | | | | | | |
| | 200 | FRN200VG1□-4J | MD/LD | DCR4-200C | | 350 | 310 | 141 | 113 | 185 | M10(12×22) | 190 | - | M12 | 30 |
| | | | HD | | | | | | | | | | | | |
| | 220 | FRN220VG1□-4J | MD/LD | DCR4-220C | | 350 | 310 | 146 | 118 | 200 | M10(12×22) | 190 | - | M12 | 33 |
| | | | HD | | | | | | | | | | | | |
| | 250 | FRN250VG1□-4J | MD | DCR4-250C | | 350 | 310 | 161 | 133 | 210 | M10(12×22) | 190 | - | M12 | 35 |
| | | | LD | | | | | | | | | | | | |
| | 280 | FRN280VG1□-4J | HD | DCR4-280C | | 350 | 310 | 161 | 133 | 210 | M10(12×22) | 190 | - | M16 | 37 |
| | | | MD | DCR4-315C | | 400 | 345 | 146 | 118 | 200 | M10(12×22) | 225 | - | M16 | 40 |
| | 355 | FRN355VG1□-4J | LD | DCR4-355C | E | 400 | 345 | 156 | 128 | 200 | M10(12×22) | 225 | - | 4×M12 | 49 |
| | 315 | FRN315VG1□-4J | HD | DCR4-315C | C | 400 | 345 | 146 | 118 | 200 | M10(12×22) | 225 | - | M16 | 40 |
| | 355 | FRN355VG1□-4J | MD | DCR4-355C | | 400 | 345 | 156 | 128 | 200 | M10(12×22) | 225 | - | 4×M12 | 49 |
| | 400 | FRN400VG1□-4J | LD | DCR4-400C | | 445 | 385 | 145 | 117 | 213 | M10(12×22) | 245 | - | 4×M12 | 52 |
| | 355 | FRN355VG1□-4J | HD | DCR4-355C | | 400 | 345 | 156 | 128 | 200 | M10(12×22) | 225 | - | 4×M12 | 49 |
| | 400 | FRN400VG1□-4J | MD | DCR4-400C | | 445 | 385 | 145 | 117 | 213 | M10(12×22) | 245 | - | 4×M12 | 52 |
| | 450 | FRN450VG1□-4J | LD | DCR4-450C | E | 440 | 385 | 150 | 122 | 215 | M10(12×22) | 245 | - | 4×M12 | 62 |
| 400 | FRN400VG1□-4J | HD | DCR4-400C | | 445 | 385 | 145 | 117 | 213 | M10(12×22) | 245 | - | 4×M12 | 52 | |
| 450 | FRN450VG1□-4J | MD | DCR4-450C | | 440 | 385 | 150 | 122 | 215 | M10(12×22) | 245 | - | 4×M12 | 62 | |
| 500 | FRN500VG1□-4J | LD | DCR4-500C | | 445 | 390 | 165 | 137 | 220 | M10(12×22) | 245 | - | 4×M12 | 72 | |
| | | HD | | | | | | | | | | | | | |
| 630 | FRN630VG1□-4J | LD | DCR-630C | F | 285 | 145 | 203 | 170 | 195 | M12(14×20) | 480 | - | 2×M12 | 75 | |
| 710 | FRN710VG1□-4J | LD | DCR-710C | | 340 | 160 | 295 | 255 | 225 | M12(Φ15) | 480 | - | 4×M12 | 95 | |

Note: □ in the inverter model represents an alphabet.


□
└─ S (Basic type)

8.5.4 AC reactor (ACR)

Use an ACR when the converter part of the inverter should supply very stable DC power, for example, in DC link bus operation (shared PN operation). Generally, ACRs are used for correction of voltage waveform and power factor or for power supply matching, but not for suppressing harmonic components in the power lines. For suppressing harmonic components, use a DCR.

■ For power supply matching


- Also use a DCR when there are thyristor-driven loads or when phase-advancing capacitors are being turned ON/OFF.



- Use a DCR when the interphase voltage unbalance ratio of the inverter power supply exceeds 2%.

$$\text{Interphase voltage unbalance (\%)} = \frac{\text{Max. voltage (V)} - \text{Min. voltage (V)}}{\text{Three - phase average voltage (V)}} \times 67$$

- When connecting multiple inverters to DC mother line



Note 1) Be sure to connect the AC reactor when connecting to the DC mother line.

Note 2) When connecting to the DC mother line, use inverters of the same model and capacity.




Figure 8.10 External View of AC Reactor (ACR) and Connection Example

Table 8.12 AC Reactor (ACR)

| Power supply voltage | Nominal applied motor (kW) | Inverter type | Specifications | Reactor model | Rated current (A) | Reactance (mΩ/phase) | | Winding resistor (mΩ) | Generated loss (W) |
|----------------------|----------------------------|----------------|----------------|---------------|-------------------|----------------------|-------|-----------------------|--------------------|
| | | | | | | 50 Hz | 60 Hz | | |
| Three-phase 200V | 0.75 | FRN0.75VG1□-2J | HD | ACR2-0.75A | 5 | 493 | 592 | - | 12 |
| | 1.5 | FRN1.5VG1□-2J | | ACR2-1.5A | 8 | 295 | 354 | - | 14 |
| | 2.2 | FRN2.2VG1□-2J | | ACR2-2.2A | 11 | 213 | 256 | - | 16 |
| | 3.7 | FRN3.7VG1□-2J | | ACR2-3.7A | 17 | 218 | 153 | - | 23 |
| | 5.5 | FRN5.5VG1□-2J | | ACR2-5.5A | 25 | 87.7 | 105 | - | 27 |
| | 7.5 | FRN7.5VG1□-2J | | ACR2-7.5A | 33 | 65 | 78 | - | 30 |
| | 11 | FRN11VG1□-2J | | ACR2-11A | 46 | 45.5 | 54.7 | - | 37 |
| | 15 | FRN15VG1□-2J | | ACR2-15A | 59 | 34.8 | 41.8 | - | 43 |
| | 18.5 | FRN18.5VG1□-2J | | ACR2-18.5A | 74 | 28.6 | 34.3 | - | 51 |
| | 22 | FRN22VG1□-2J | | ACR2-22A | 87 | 24 | 28.8 | - | 57 |
| | 30 | FRN30VG1□-2J | HD | ACR2-37 | 200 | 10.8 | 13 | 0.5 | 28.6 |
| | 37 | | LD | ACR2-37 | 200 | 10.8 | 13 | 0.5 | 40.8 |
| | 45 | FRN45VG1□-2J | HD | ACR2-55 | 270 | 7.5 | 9 | 0.375 | 47.1 |
| | 55 | | LD | | | | | | |
| | 75 | FRN55VG1□-2J | HD | ACR2-55 | 270 | 7.5 | 9 | 0.375 | 66.1 |
| | 90 | | LD | | | | | | |
| | 90 | FRN75VG1□-2J | HD | ACR2-75 | 390 | 5.45 | 6.54 | 0.25 | 55.1 |
| | | | LD | | | | | | |
| | 110 | FRN90VG1□-2J | HD | ACR2-90 | 450 | 4.73 | 5.67 | 0.198 | 61.5 |
| | | | LD | | | | | | |

Note 1: □ in the inverter model represents an alphabet.

□ S (Basic type)

Note 2: Generated losses listed in the above table are approximate values that are calculated according to the following conditions:

- The power supply is three-phase 200 V/400 V 50 Hz with 0% interphase voltage unbalance ratio.
- The power supply capacity uses the larger of either 500 kVA or 10 times the rated capacity of the inverter.
- The motor is a 4-pole standard model at full load (100%).

Table 8.12 AC Reactor (ACR) (continued)

| Power supply voltage | Nominal applied motor (kW) | Inverter type | Specifications | Reactor model | Rated current(A) | Reactance (mΩ/phase) | | Winding resistor (mΩ) | Generated loss (W) |
|----------------------|----------------------------|----------------|----------------|---------------|------------------|----------------------|--------|-----------------------|--------------------|
| | | | | | | 50 Hz | 60 Hz | | |
| Three-phase 400V | 3.7 | FRN3.7VG1□-4J | HD | ACR4-3.7A | 9 | 512 | 615 | - | 17 |
| | 5.5 | FRN5.5VG1□-4J | | ACR4-5.5A | 13 | 349 | 418 | - | 22 |
| | 7.5 | FRN7.5VG1□-4J | | ACR4-7.5A | 18 | 256 | 307 | - | 27 |
| | 11 | FRN11VG1□-4J | | ACR4-11A | 24 | 183 | 219 | - | 40 |
| | 15 | FRN15VG1□-4J | | ACR4-15A | 30 | 139 | 167 | - | 46 |
| | 18.5 | FRN18.5VG1□-4J | | ACR4-18.5A | 39 | 114 | 137 | - | 57 |
| | 22 | FRN22VG1□-4J | | ACR4-22A | 45 | 95.8 | 115 | - | 62 |
| | 30 | FRN30VG1□-4J | HD | ACR4-37 | 100 | 41.7 | 50 | 2.73 | 38.9 |
| | 37 | | LD | ACR4-37 | 100 | 41.7 | 50 | 2.73 | 55.7 |
| | | HD | | | | | | | |
| | 45 | FRN37VG1□-4J | LD | ACR4-55 | 135 | 30.8 | 37 | 1.61 | 50.2 |
| | | | HD | | | | | | |
| | 55 | FRN45VG1□-4J | LD | ACR4-55 | 135 | 30.8 | 37 | 1.61 | 70.7 |
| | | | HD | | | | | | |
| | 75 | FRN55VG1□-4J | LD | ACR4-75 * | 160 | 25.8 | 31 | 1.16 | 65.3 |
| | | | HD | | | | | | |
| | 90 | FRN75VG1□-4J | LD | ACR4-110 | 250 | 16.7 | 20 | 0.523 | 42.2 |
| | | | HD | | | | | | |
| | 110 | FRN90VG1□-4J | MD/LD | ACR4-110 | 250 | 16.7 | 20 | 0.523 | 60.3 |
| | | | HD | | | | | | |
| | 132 | FRN110VG1□-4J | MD/LD | ACR4-132 * | 270 | 20.8 | 25 | 0.741 | 119 |
| | | | HD | | | | | | |
| | 160 | FRN132VG1□-4J | MD/LD | ACR4-220 | 561 | 10 | 12 | 0.236 | 56.4 |
| | | | HD | | | | | | |
| | 200 | FRN160VG1□-4J | MD/LD | ACR4-220 | 561 | 10 | 12 | 0.236 | 90.4 |
| | | | HD | | | | | | |
| | 220 | FRN200VG1□-4J | MD/LD | ACR4-220 | 561 | 10 | 12 | 0.236 | 107 |
| | | | HD | | | | | | |
| | 250 | FRN220VG1□-4J | MD | ACR4-280 | 825 | 6.67 | 8 | 0.144 | 96.4 |
| | | | LD | | | | | | |
| | 280 | FRN280VG1□-4J | HD | ACR4-355 | 825 | 6.67 | 8 | 0.144 | 108 |
| | | | MD | | | | | | |
| | 315 | FRN315VG1□-4J | LD | ACR4-355 | 825 | 6.67 | 8 | 0.144 | 194 |
| | 355 | | HD | | | | | | 245 |
| | 315 | FRN315VG1□-4J | MD | ACR4-355 | 825 | 6.67 | 8 | 0.144 | 194 |
| | | | LD | | | | | | 245 |
| | 400 | FRN355VG1□-4J | HD | ACR4-450 | 950 | 6.67 | 8 | 0.136 | 380 |
| | | | LD | | | | | | 473 |
| | 450 | FRN355VG1□-4J | HD | ACR4-355 * | 825 | 6.67 | 8 | 0.144 | 245 |
| | | | MD | | | | | | 380 |
| | 450 | FRN355VG1□-4J | LD | ACR4-450 | 950 | 6.67 | 8 | 0.136 | 473 |
| | | | HD | | | | | | 380 |
| 450 | FRN400VG1□-4J | MD | ACR4-450 | 950 | 6.67 | 8 | 0.136 | 473 | |
| | | LD | | | | | | | |
| 500 | FRN500VG1□-4J | HD | ACR4-530 | 1100 | 5.75 | 6.9 | 0.0824 | 340 | |
| | | LD | | | | | | | |
| 630 | FRN630VG1□-4J | HD | ACR4-630 | 1300 | 4.87 | 5.84 | 0.0713 | 422 | |
| | | LD | | | | | | | |
| 710 | FRN630VG1□-4J | LD | - | - | - | - | - | - | |

* Cool the fan (for 3m/s or more).

Note 1: □ in the inverter model represents an alphabet.

□
└─ S (Basic type)

Note 2: Generated losses listed in the above table are approximate values that are calculated according to the following conditions:

- The power supply is three-phase 200 V/400 V 50 Hz with 0% interphase voltage unbalance ratio.
- The power supply capacity uses the larger of either 500 kVA or 10 times the rated capacity of the inverter.
- The motor is a 4-pole standard model at full load (100%).




Table 8.13 AC Reactors (ACRs) External Dimensions

| Power supply voltage | Nominal applied motor (kW) | Inverter type | Specifications | Reactor model | Dimensions (mm) | | | | | | | | Approx. weight (kg) | |
|----------------------|----------------------------|----------------|----------------|---------------|-----------------|-----|-----|-----|-----|-----|------------|-----|---------------------|-----|
| | | | | | Fig | W | W1 | D | D1 | D2 | G | H | | J |
| Three-phase 200V | 0.75 | FRN0.75VG1□-2J | HD | ACR2-0.75A | A | 120 | 40 | 100 | 75 | 20 | M5(6×10) | 115 | M4 | 1.9 |
| | 1.5 | FRN1.5VG1□-2J | | ACR2-1.5A | | 120 | 40 | 100 | 75 | 20 | M5(6×10) | 115 | M4 | 2.0 |
| | 2.2 | FRN2.2VG1□-2J | | ACR2-2.2A | | 120 | 40 | 100 | 75 | 20 | M5(6×10) | 115 | M4 | 2.0 |
| | 3.7 | FRN3.7VG1□-2J | | ACR2-3.7A | | 125 | 40 | 100 | 75 | 25 | M5(6×10) | 125 | M4 | 2.4 |
| | 5.5 | FRN5.5VG1□-2J | | ACR2-5.5A | | 125 | 40 | 115 | 90 | 25 | M5(6×10) | 125 | M4 | 3.1 |
| | 7.5 | FRN7.5VG1□-2J | | ACR2-7.5A | | 125 | 40 | 115 | 90 | 106 | M5(6×10) | 95 | M5 | 3.1 |
| | 11 | FRN11VG1□-2J | | ACR2-11A | | 125 | 40 | 125 | 100 | 106 | M5(6×10) | 95 | M6 | 3.7 |
| | 15 | FRN15VG1□-2J | | ACR2-15A | | 180 | 60 | 110 | 85 | 106 | M6(7×11) | 115 | M6 | 4.8 |
| | 18.5 | FRN18.5VG1□-2J | | ACR2-18.5A | | 180 | 60 | 110 | 85 | 109 | M6(7×11) | 115 | M6 | 5.1 |
| | 22 | FRN22VG1□-2J | | ACR2-22A | | 180 | 60 | 110 | 85 | 109 | M6(7×11) | 115 | M6 | 5.1 |
| | 30 | FRN30VG1□-2J | HD | ACR2-37 | B | 190 | 60 | 120 | 90 | 172 | M6(7×11) | 190 | M8 | 11 |
| | 37 | | LD | ACR2-37 | | 190 | 60 | 120 | 90 | 172 | M6(7×11) | 190 | M8 | 11 |
| | 45 | FRN45VG1□-2J | HD | ACR2-55 | C | 190 | 60 | 120 | 90 | 200 | M6(7×11) | 190 | M12 | 13 |
| | 55 | | LD | | | | | | | | | | | |
| | 75 | FRN55VG1□-2J | HD | ACR2-75 | C | 250 | 100 | 120 | 90 | 200 | M8(9×14) | 250 | M12 | 25 |
| | 90 | | LD | | | | | | | | | | | |
| | 90 | FRN90VG1□-2J | HD | ACR2-90 | C | 285 | 190 | 158 | 120 | 190 | M10(12×20) | 210 | M12 | 26 |
| | 110 | | LD | | | | | | | | | | | |


Table 8.13 AC Reactors (ACRs) External Dimensions (continued)

| Power supply voltage | Nominal applied motor (kW) | Inverter type | Specifications | Reactor model | Dimensions (mm) | | | | | | | | | Approx. weight (kg) |
|----------------------|----------------------------|----------------|----------------|---------------|-----------------|-----|-----|-----|-----|------------|------------|-------|-------|---------------------|
| | | | | | Fig | W | W1 | D | D1 | D2 | G | H | J | |
| Three-phase 400V | 3.7 | FRN3.7VG1□-4J | HD | ACR4-3.7A | B | 125 | 40 | 100 | 75 | 106 | M5(6×10) | 95 | M4 | 2.4 |
| | 5.5 | FRN5.5VG1□-4J | | ACR4-5.5A | | 125 | 40 | 115 | 90 | 106 | M5(6×10) | 95 | M5 | 3.1 |
| | 7.5 | FRN7.5VG1□-4J | | ACR4-7.5A | | 125 | 40 | 115 | 90 | 106 | M5(6×10) | 95 | M5 | 3.7 |
| | 11 | FRN11VG1□-4J | | ACR4-11A | | 180 | 60 | 110 | 85 | 106 | M6(7×11) | 115 | M6 | 4.3 |
| | 15 | FRN15VG1□-4J | | ACR4-15A | | 180 | 60 | 110 | 85 | 106 | M6(7×11) | 137 | M6 | 5.4 |
| | 18.5 | FRN18.5VG1□-4J | | ACR4-18.5A | | 180 | 60 | 110 | 85 | 106 | M6(7×11) | 137 | M6 | 5.7 |
| | 22 | FRN22VG1□-4J | | ACR4-22A | | 180 | 60 | 110 | 85 | 106 | M6(7×11) | 137 | M6 | 5.9 |
| | 30 | FRN30VG1□-4J | HD | ACR4-37 | B | 190 | 60 | 120 | 90 | 172 | M6(7×11) | 190 | M8 | 12 |
| | 37 | | LD | | | | | | | | | | | |
| | 45 | FRN37VG1□-4J | HD | ACR4-55 | C | 190 | 60 | 120 | 90 | 200 | M6(7×11) | 190 | M10 | 14 |
| | | | LD | | | | | | | | | | | |
| | 55 | FRN45VG1□-4J | HD | ACR4-55 | C | 190 | 60 | 120 | 90 | 200 | M6(7×11) | 190 | M10 | 14 |
| | | | LD | | | | | | | | | | | |
| | 75 | FRN55VG1□-4J | HD | ACR4-75 | C | 190 | 60 | 126 | 90 | 157 | M6(7×10) | 190 | M10 | 16 |
| | | | LD | | | | | | | | | | | |
| | 90 | FRN75VG1□-4J | HD | ACR4-110 | C | 250 | 100 | 136 | 105 | 202 | M8(9.5×18) | 245 | M12 | 24 |
| | | | LD | | | | | | | | | | | |
| | 110 | FRN90VG1□-4J | MD/LD | ACR4-110 | C | 250 | 100 | 136 | 105 | 202 | M8(9.5×18) | 245 | M12 | 24 |
| | | | HD | | | | | | | | | | | |
| | 132 | FRN110VG1□-4J | MD/LD | ACR4-132 | C | 250 | 100 | 146 | 115 | 207 | M8(10×16) | 250 | M12 | 32 |
| | | | HD | | | | | | | | | | | |
| | 160 | FRN132VG1□-4J | MD/LD | ACR4-220 | C | 320 | 120 | 150 | 110 | 240 | M10(12×20) | 300 | M12 | 40 |
| | | | HD | | | | | | | | | | | |
| | 200 | FRN160VG1□-4J | MD/LD | ACR4-220 | C | 320 | 120 | 150 | 110 | 240 | M10(12×20) | 300 | M12 | 40 |
| | | | HD | | | | | | | | | | | |
| | 220 | FRN200VG1□-4J | MD/LD | ACR4-220 | C | 320 | 120 | 150 | 110 | 240 | M10(12×20) | 300 | M12 | 40 |
| | | | HD | | | | | | | | | | | |
| | 250 | FRN220VG1□-4J | MD | ACR4-280 | C | 380 | 130 | 150 | 110 | 260 | M10(12×20) | 300 | M12 | 52 |
| | | | LD | | | | | | | | | | | |
| | 280 | FRN280VG1□-4J | MD | ACR4-355 | C | 380 | 130 | 150 | 110 | 260 | M10(12×20) | 300 | M12 | 52 |
| | | | LD | | | | | | | | | | | |
| | 315 | FRN315VG1□-4J | HD | ACR4-355 | C | 380 | 130 | 150 | 110 | 260 | M10(12×20) | 300 | M12 | 52 |
| | | | MD | | | | | | | | | | | |
| | 355 | FRN355VG1□-4J | HD | ACR4-450 | D | 460 | 155 | 290 | 230 | 200 | M12(Φ15) | 490 | 4×M12 | 95 |
| | | | LD | | | | | | | | | | | |
| 400 | FRN355VG1□-4J | MD | ACR4-450 | D | 460 | 155 | 290 | 230 | 200 | M12(Φ15) | 490 | 4×M12 | 95 | |
| | | LD | | | | | | | | | | | | |
| 450 | FRN400VG1□-4J | HD | ACR4-450 | E | 460 | 155 | 290 | 230 | 200 | M12(Φ15) | 490 | 4×M12 | 95 | |
| | | MD | | | | | | | | | | | | |
| 500 | FRN400VG1□-4J | LD | ACR4-530 | E | 480 | 155 | 420 | 370 | - | M12(15×25) | 380 | 4×M12 | 100 | |
| | | HD | | | | | | | | | | | | |
| 630 | FRN500VG1□-4J | LD | ACR4-630 | E | 510 | 170 | 420 | 370 | - | M12(15×25) | 390 | 4×M12 | 110 | |
| | | HD | | | | | | | | | | | | |
| 710 | FRN630VG1□-4J | LD | - | - | - | - | - | - | - | - | - | - | - | |

8.5.5 Surge suppression unit (SSU)




If the drive wire for the motor is long, an extremely low surge voltage (micro surge) occurs at the wire end connected to the motor. Surge voltage causes motor degradation, insulation breakdown, or increased noises. The surge suppression unit (SSU) suppresses the surge voltage. It features the connectivity for all motor capacities and easy wiring work.



External dimensions


For 50 m : SSU 50TA-NS

For 100 m : SSU 100TA-NS




Effect of surge suppression unit (voltage waveform between motor wires)

- Motor/inverter capacity: 3.7 kW
- Operation status: No load
- Wire length: 50 m
- Power supply voltage: 3-phase 400 V



- Motor/inverter capacity: 75 kW
- Operation status: No load
- Wire length: 100 m
- Power supply voltage: 3-phase 400 V



Basic specifications

| Item | Specifications | |
|--------------------------|---|--------------|
| Model | SSU 50TA-NS | SSU 100TA-NS |
| Applicable wire length | Up to 50 m | Up to 100 m |
| Power supply voltage | 200V system, 400V system, PWM converter are applicable. | |
| Inverter capacity | Up to 75 kW | |
| Output frequency | Up to 400 Hz | |
| Carrier frequency | Up to 15 kHz (not available for 16 kHz) | |
| Protective structure | IP20 | |
| Installation environment | Ambient temperature: -20 to 40°C, ambient humidity: 85%RH or lower, vibration: 0.7G or less, installation site: level | |
| Insulation voltage | 2500 V AC, 1 min | |

8.5.6 Output circuit filter (OFL)

- (1) The output circuit filter (OFL) is an LC filter to be used at the output side of the inverter for the following purposes:
 - Protecting the motor from insulation damage that could be caused by micro surge voltage from inverters.
 - Suppressing leakage current (in-line leakage current) in long-distance wiring.
 - Suppressing induction noise from the inverter output lines

The OFL is effective for suppression of surge and in-line leakage current in long-distance wiring such as in plant facilities.
 - (2) An OFL to be used for motors of 30 kW or above is divided into a reactor and capacitor unit. Use them in combination.
 - (3) For wiring of 50 m or more, it is recommended that an OFL be used.
- 📖 For details on the product, refer to the Output Circuit Filter (OFL-A) Instruction Manual:
- For OFL-22-4A or lower capacity, refer to INR-SI47-0547□.
 - For OFL-30-4A or higher capacity, refer to INR-HF52131□.




Figure 8.11 External View of Output Circuit Filter (OFL) and Connection Examples

Table 8.14 (a) Specifications of Output Circuit Filter (OFL)

| | | | | |
|--|-----------------------|--|---------------------|--|
| Environment | Site location | <ul style="list-style-type: none"> • Indoors (There must be no corrosive gas, flammable gas, dust, and oil mist.) Pollution degree 2: IEC60664-1 • Must not be exposed to direct sunlight. | | |
| | Operating temperature | -10 to +50°C | Storage temperature | -25 to +65°C (30 °C or lower in the case of storage for long period of time) |
| | Ambient humidity | 5 to 95% Rh (No dew condensation) | Storage humidity | 5 to 95% Rh (No dew condensation) |
| | Altitude | 1000 m or less | | |
| Max. output wiring length | | 400 m or less | | |
| Dielectric strength voltage, Insulation resistance | | 2500 VAC/min., 1 MΩ or more (500 VDC Megger) | | |

- Note**
- 1) The OFL-30-4A or higher models are delivered in sets with a reactor and a capacitor unit.
 - 2) The OFL-30-4A or higher models generate heat from the resistors in the capacitor unit when the inverter is running. Mount the OFL not inside the cabinet but on top of the cabinet.
 - 3) Under vector control, if an OFL is used in long-distance wiring, the inverter may not control the motor normally due to the inductance of the OFL or wiring, causing current vibration or torque shortage. To prevent such problems, select an installation location of the motor to keep the wiring distance between the inverter and motor within 100 m (as a guide) even if an OFL is used.
 - 4) Under vector control, only OFL models having a suffix "A" (listed in Table 8.14 (b)) can be used. Other models without suffix "A" cannot be used.

Table 8.14 (b) Specifications of Output Circuit Filter (OFL)

OFL-□□□-4A

| Power supply voltage | Nominal applied motor (kW) | Inverter type | Specifications | Filter model | Rated current (A) | Overload resistance | Inverter input power supply voltage | Carrier frequency tolerance (kHz) | Maximum output frequency (Hz) | Generated loss (W) | |
|----------------------|----------------------------|----------------|----------------|--------------|-------------------|--|-------------------------------------|-----------------------------------|-------------------------------|--------------------|-----|
| Three-phase 400V | 3.7 | FRN3.7VG1□-4J | HD | OFL-3.7-4A | 9 | HD model 150%-1 min 200%-3 s MD model 150%-1 min LD model 120%-1 min | Three-phase 380-480V 50/60 Hz | 2-15 kHz | 400 Hz | 210 | |
| | 5.5 | FRN5.5VG1□-4J | | OFL-7.5-4A | 18 | | | | | 190 | |
| | 7.5 | FRN7.5VG1□-4J | | OFL-15-4A | 30 | | | | | 320 | |
| | 11 | FRN11VG1□-4J | | OFL-22-4A | 45 | | | | | 350 | |
| | 15 | FRN15VG1□-4J | | HD | OFL-30-4A | | | | | 60 | 570 |
| | 18.5 | FRN18.5VG1□-4J | | LD | OFL-37-4A | | | | | 75 | 610 |
| | 22 | FRN22VG1□-4J | HD | OFL-45-4A | 91 | | | 810 | | | |
| | 30 | FRN30VG1□-4J | LD | OFL-55-4A | 112 | | | 910 | | | |
| | 37 | FRN37VG1□-4J | HD | OFL-75-4A | 150 | | | 1200 | | | |
| | 45 | FRN45VG1□-4J | LD | OFL-90-4A | 176 | | | 1360 | | | |
| | 55 | FRN55VG1□-4J | HD | OFL-110-4A | 210 | | | 1410 | | | |
| | 75 | FRN75VG1□-4J | LD | OFL-132-4A | 253 | | | 1800 | | | |
| | 90 | FRN90VG1□-4J | MD/LD | OFL-160-4A | 304 | | | 2210 | | | |
| | 110 | FRN110VG1□-4J | HD | OFL-200-4A | 377 | | | 2520 | | | |
| | 132 | FRN132VG1□-4J | MD/LD | OFL-220-4A | 415 | | | 2590 | | | |
| | 160 | FRN160VG1□-4J | HD | OFL-280-4A | 520 | | | 3570 | | | |
| | 200 | FRN200VG1□-4J | LD | OFL-315-4A | 585 | | | 3290 | | | |
| | 220 | FRN220VG1□-4J | MD | OFL-355-4A | 650 | | | 3320 | | | |
| | 250 | FRN250VG1□-4J | LD | OFL-315-4A | 585 | | | 3290 | | | |
| | 280 | FRN280VG1□-4J | MD | OFL-355-4A | 650 | | | 3320 | | | |
| | 315 | FRN315VG1□-4J | LD | OFL-400-4A | 740 | | | 3390 | | | |
| | 355 | FRN355VG1□-4J | HD | OFL-355-4A | 650 | | | 3320 | | | |
| | 400 | FRN400VG1□-4J | MD | OFL-400-4A | 740 | | | 3390 | | | |
| | 450 | FRN450VG1□-4J | LD | OFL-450-4A | 840 | | | 3390 | | | |
| | 500 | FRN500VG1□-4J | HD | OFL-400-4A | 740 | | | 3390 | | | |
| | 630 | FRN630VG1□-4J | MD | OFL-450-4A | 840 | | | 3390 | | | |
| | | | LD | OFL-500-4A | 960 | | | 4250 | | | |
| | | | HD | OFL-630-4A | 1170 | | | 4700 | | | |

Note : □ in the inverter model replaces an alphabet.

□
└ S (Basic type)

Table 8.15 Output Circuit Filter (OFL) Dimensions

| Power supply voltage | Nominal applied motor (kW) | Inverter type | Specifications | Filter type | Fig | Dimensions(mm) | | | | | | | | | Approx. weight (kg) | | |
|----------------------|----------------------------|----------------|----------------|-------------|-----------|----------------|-----|-----|-----|-----|-----|-----|-------------------|------------------|---------------------|------------------|----|
| | | | | | | A | B | C | D | E | F | G | Grounding screw H | Terminal screw J | | Mounting screw K | |
| Three-phase 400V | 3.7 | FRN3.7VG1□-4J | HD | OFL-3.7-4A | A | 220 | 225 | 220 | 200 | 115 | - | - | M4 | M4 | M5 | 14 | |
| | 5.5 | FRN5.5VG1□-4J | | OFL-7.5-4A | | 290 | 290 | 230 | 260 | 160 | - | - | M5 | M5 | M6 | 22 | |
| | 7.5 | FRN7.5VG1□-4J | | OFL-15-4A | B | 330 | 275 | 310 | 300 | 145 | - | - | M6 | M6 | M8 | 35 | |
| | 11 | FRN11VG1□-4J | | OFL-22-4A | | 330 | 300 | 330 | 300 | 170 | - | - | M6 | M6 | M8 | 45 | |
| | 15 | FRN15VG1□-4J | | HD | OFL-30-4A | C/F | 210 | 175 | 210 | 70 | 140 | 90 | 160 | - | M5 | M6 | 12 |
| | 18.5 | FRN18.5VG1□-4J | | LD | OFL-37-4A | | 220 | 190 | 220 | 75 | 150 | 95 | 160 | - | M5 | M6 | 15 |
| | 22 | FRN22VG1□-4J | HD | OFL-45-4A | D/F | 220 | 195 | 265 | 70 | 155 | 140 | 160 | - | M6 | M8 | 17 | |
| | 30 | FRN30VG1□-4J | LD | OFL-55-4A | | 260 | 200 | 275 | 85 | 160 | 150 | 160 | - | M6 | M8 | 22 | |
| | 37 | FRN37VG1□-4J | HD | OFL-75-4A | | 260 | 210 | 290 | 85 | 170 | 150 | 233 | - | M8 | M10 | 25 | |
| | 45 | FRN45VG1□-4J | LD | OFL-90-4A | | 260 | 210 | 290 | 85 | 170 | 155 | 233 | - | M8 | M10 | 28 | |
| | 55 | FRN55VG1□-4J | HD | OFL-110-4A | | 300 | 230 | 330 | 100 | 190 | 170 | 233 | - | M8 | M10 | 38 | |
| | 75 | FRN75VG1□-4J | LD | OFL-132-4A | | 300 | 240 | 340 | 100 | 200 | 170 | 233 | - | M10 | M10 | 42 | |
| | 90 | FRN90VG1□-4J | HD | OFL-160-4A | | 300 | 240 | 340 | 100 | 200 | 180 | 233 | - | M10 | M10 | 48 | |
| | 110 | FRN110VG1□-4J | MD/LD | OFL-200-4A | | 320 | 270 | 350 | 105 | 220 | 190 | 333 | - | M10 | M12 | 60 | |
| | 132 | FRN132VG1□-4J | HD | OFL-220-4A | | 340 | 300 | 390 | 115 | 250 | 190 | 333 | - | M10 | M12 | 70 | |
| | 160 | FRN160VG1□-4J | MD/LD | OFL-280-4A | | 350 | 300 | 430 | 115 | 250 | 200 | 333 | - | M10 | M12 | 78 | |
| | 200 | FRN200VG1□-4J | HD | OFL-315-4A | E/G | 440 | 275 | 450 | 150 | 230 | 170 | - | - | M12 | M12 | 90 | |
| | 220 | FRN220VG1□-4J | LD | OFL-355-4A | | 440 | 290 | 480 | 150 | 245 | 175 | - | - | M12 | M12 | 100 | |
| | 250 | FRN250VG1□-4J | MD | OFL-315-4A | | 440 | 275 | 450 | 150 | 230 | 170 | - | - | M12 | M12 | 90 | |
| | 280 | FRN280VG1□-4J | HD | OFL-355-4A | | 440 | 290 | 480 | 150 | 245 | 175 | - | - | M12 | M12 | 100 | |
| | 315 | FRN315VG1□-4J | LD | OFL-400-4A | | 440 | 295 | 510 | 150 | 240 | 175 | - | - | M12 | M12 | 110 | |
| | 355 | FRN355VG1□-4J | MD | OFL-355-4A | | 440 | 290 | 480 | 150 | 245 | 175 | - | - | M12 | M12 | 100 | |
| | 400 | FRN400VG1□-4J | HD | OFL-400-4A | | 440 | 295 | 510 | 150 | 240 | 175 | - | - | M12 | M12 | 110 | |
| | 450 | FRN450VG1□-4J | LD | OFL-450-4A | | 440 | 325 | 470 | 150 | 270 | 195 | - | - | M12 | M12 | 125 | |
| | 500 | FRN500VG1□-4J | MD | OFL-400-4A | | 440 | 295 | 510 | 150 | 240 | 175 | - | - | M12 | M12 | 110 | |
| | 630 | FRN630VG1□-4J | HD | OFL-450-4A | | 440 | 325 | 470 | 150 | 270 | 195 | - | - | M12 | M12 | 125 | |
| | | | LD | OFL-500-4A | | 440 | 335 | 500 | 150 | 280 | 210 | - | - | M12 | M12 | 145 | |
| | | | HD | OFL-630-4A | | 480 | 355 | 560 | 150 | 280 | 245 | - | - | M12 | M12 | 170 | |

Note that the OFL-***-4A models have no restrictions on carrier frequency.

OFL-□□□-4A

■ Filter (for 22 kW or below)

Figure A





Figure B



■ Reactor (for 30 kW or above)

Figure C




Figure D





Figure E



■ Resistor and Capacitor (for 30 kW or above)

Figure F





Figure G



8.5.7 Radio noise reducing zero phase reactor (ACL)

An ACL is used to reduce radio frequency noise emitted by the inverter.

An ACL suppresses the outflow of high frequency harmonics caused by switching operation for the power supply lines inside the inverter. Pass the power supply lines together through the ACL.

If wiring length between the inverter and motor is less than 20 m, insert an ACL to the power supply lines; if it is more than 20 m, insert it to the power output lines of the inverter.

Wire size is determined depending upon the ACL size (I.D.) and installation requirements.




Figure 8.12 Dimensions of Zero-phase Reactor for Reducing Radio Noise (ACL) and Connection Example

Table 8.16 Zero-phase Reactors for Reducing Radio Noise (ACL)

| Zero-phase reactor type | Installation requirements | | Wire size (mm ²) |
|-------------------------|---------------------------|-----------------|---|
| | Qty. | Number of turns | |
| ACL-40B | 1 | 4 | 2.0, 3.5, 5.5 |
| | 2 | 2 | 8, 14 |
| ACL-74B | 1 | 4 | 8, 14 |
| | 2 | 2 | 22, 38, 60, 5.5×2, 8×2, 14×2, 22×2 |
| | 4 | 1 | 100, 150, 200, 250, 325, 38×2, 60×2, 100×2, 150×2 |
| F200160 | 4 | 1 | 200×2, 250×2, 325×2, 325×3 |
| F200160PB | 4 | 1 | 200×2, 250×2, 325×2, 325×3 |


The selected wires are for use with 3-phase input/output lines (3 wires).

Note: Use the insulated wire of 75°C, 600 V, HIV-insulated.

8.5.8 External cooling attachment

This attachment is used to allow the inverter cooling fins to protrude out of the panel.


■PBVG7-7.5(FRN0.75VG1S-2J to FRN7.5VG1S-2J,FRN3.7VG1S-4J to FRN7.5VG1S-4J)



Unit : [mm]

Figure 8.13 External Cooling Attachment External Dimensions

■PB-F1-30(FRN11VG1S-2J to FRN22VG1S-2J,FRN11VG1S-4J to FRN22VG1S-4J)



Unit : mm

Figure 8.13 External Cooling Attachment External Dimensions (continued)

8.6 Battery

8.6.1 Overview of battery

Used to retain the trace back memory and calendar when the inverter is not powered.

- 22 kW or lower: Option
- 30 kW or higher: Included as standard

| | |
|------------------|---|
| Model | OPK-BP |
| Voltage/capacity | 3.6 V/1100 mAh |
| Type | Lithium Thionyl Chloride(Li-SOCl ₂) battery |
| Life | 5 years (with ambient temperature of 60°C and inverter powered off) |




Figure 8.14 Overview of Battery

⚠ WARNING

Safety Precautions

This battery contains lithium (dangerous substance) and thionyl chloride (very dangerous substance) to provide high energy. If you use it in a wrong way, the battery may be deformed, liquid inside the battery may leak, or heat generation, explosion, fire, and/or stimulative/corrosive gas generation may occur, resulting in a injury or device failure. Be sure to observe the following precautions:

- Do not swallow the battery.
- Do not apply excessive force to the positive terminal.
- Do not drop the battery.
- Do not short-circuit the battery.
- Do not charge the battery.
- Do not force the battery to discharge.
- Do not heat the battery.
- Do not throw the battery into fire.
- Do not disassemble the battery.
- Do not deform the battery.
- Insert the battery into the inverter in the correct direction.
- Do not allow liquid from the battery to touch your skin.
- Do not leave a damaged battery in the inverter.

⚠ CAUTION

Keep the battery where it is not exposed to the direct sunlight, high temperature/humidity, and/or rain drop.

This battery belongs to the "primary battery class", which must be discarded in accordance with the defined method (law).

8.6.2 Installing battery

⚠ CAUTION



Be sure to operate the inverter with the battery installed.

Afire or an accident might occur.

Refer to "3.4.4.12 Setting Date/Time" for how to adjust the clock.

8.6.2.1 Installing battery (for 22 kW or lower)

- ① Remove the outer cover.



- ② Install the battery as shown in the figure.

- ③ Connect the battery cable to the connector CN7 on the control printed board.








Figure 8.15 Battery Installed (22 kW or lower)

8.6.2.2 Installing battery (for 30 kW or higher)

① Remove the front cover.
Open the touch panel case and disconnect the connectors CN5 and CN8 from the control printed board.

② Remove the touch panel case.



③ Install the battery as shown in the figure.

④ Connect the battery cable to the connector CN7 on the control printed board.







Figure 8.16 Battery Installed (30 kW or higher)

8.6.3 Replacing battery

Reverse the installation procedure to remove the battery, and then install the new battery.

| |
|--|
|  CAUTION |
| Be sure to operate the inverter with the battery installed. A fire or an accident might occur. |

Refer to "3.4.4.12 Setting Date/Time" for how to adjust the clock.

8.6.4 About marine or air transport of a lithium-metal battery

When transporting a lithium-metal battery by itself, by packing it in a package of the inverter, or by incorporating it in the inverter, observe the following notes.

(1) To transport a lithium-metal battery incorporated in the inverter

When transporting a panel holding five or more inverters with a built-in battery, it is necessary to attach the label shown in Figure 8.17 and prepare the transportation documents.

(2) To transport a lithium-metal battery packed with the inverter

It is necessary to attach the label shown in Figure 8.17 and issue a drop test certificate together with the transportation documents.

To transport a lithium-metal battery by air, the number of batteries that can be contained in a package of the inverter is limited to the number of batteries required for device operation plus 2 batteries.



Figure 8.17 Label to be Attached to Outer Wrapping

For details, contact your shipping company.

8.7 PG Amplifier (Isolated Signal Conditioner)

When the inverter cannot detect the motor speed normally due to distorted PG waveforms resulting from the long-distance wiring to the motor speed detection pulse generator (PG), the PG amplifier is used to shape or amplify PG waveforms.

8.7.1 Recommended Pulse Amplifier Models

- SHP-115150 (Heidenhain product)
- SHC-215150 (Same as above)

The difference in the above products is only in the control power supply specifications of the PG amplifier.

The PG voltage of the standard vector motor type is 15 V.

Contact us when purchasing these products.

Type description

SHP-□□□□□□

- Power supply voltage
 - 1: 100-110 VAC, 50/60 Hz
 - 2: 200-220 VAC, 50/60 Hz
- Detector power supply
 - 05: 5 VDC
 - 10: ± 5 VDC
 - 12: 12 VDC
 - 15: 15 VDC
- Output voltage
 - 12: 12 VDC
 - 15: 15 VDC
- External power supply
 - 0: None
 - 1: Available (same as output voltage)

8.7.2 Specifications and description of terminals

Specifications

| Item | Specifications | | | | | | | | | | | | | | | |
|--|---|------------|---------|---------|-----------|-------------|------------|-----------|------------|------------|-----------|-----------|----------|-----------|-----------|----------|
| Maximum input frequency | 100 kHz | | | | | | | | | | | | | | | |
| Isolation between input and output signals | Isolator using photocoupler | | | | | | | | | | | | | | | |
| Input interface | Voltage input (Input impedance: 500 k Ω) | | | | | | | | | | | | | | | |
| Signal level | <table border="1"> <thead> <tr> <th></th> <th>H level</th> <th>L level</th> </tr> </thead> <tbody> <tr> <td>SHP-□05□□</td> <td>3.5 to 18 V</td> <td>0 to 0.8 V</td> </tr> <tr> <td>SHP-□10□□</td> <td>3.5 to 6 V</td> <td>-1 to -6 V</td> </tr> <tr> <td>SHP-□12□□</td> <td>8 to 18 V</td> <td>0 to 1 V</td> </tr> <tr> <td>SHP-□15□□</td> <td>8 to 18 V</td> <td>0 to 1 V</td> </tr> </tbody> </table> | | H level | L level | SHP-□05□□ | 3.5 to 18 V | 0 to 0.8 V | SHP-□10□□ | 3.5 to 6 V | -1 to -6 V | SHP-□12□□ | 8 to 18 V | 0 to 1 V | SHP-□15□□ | 8 to 18 V | 0 to 1 V |
| | H level | L level | | | | | | | | | | | | | | |
| SHP-□05□□ | 3.5 to 18 V | 0 to 0.8 V | | | | | | | | | | | | | | |
| SHP-□10□□ | 3.5 to 6 V | -1 to -6 V | | | | | | | | | | | | | | |
| SHP-□12□□ | 8 to 18 V | 0 to 1 V | | | | | | | | | | | | | | |
| SHP-□15□□ | 8 to 18 V | 0 to 1 V | | | | | | | | | | | | | | |
| Phase of input and output signals | Same phase | | | | | | | | | | | | | | | |
| Delay between input and output signals | 500 nS | | | | | | | | | | | | | | | |
| Output interface | Complementary (Loading impedance: Min. 500 Ω) | | | | | | | | | | | | | | | |
| Signal level | H = 10 V or more, L = 1 V or below (Loading impedance: 10 k Ω) | | | | | | | | | | | | | | | |
| External power supply for PG* | 5, 12, 15 VDC | | | | | | | | | | | | | | | |
| Control power supply* | 100-110 VAC, 200-220 VAC, 50/60 Hz | | | | | | | | | | | | | | | |
| Dielectric strength | 1500 VAC/1 minute (between input and output terminals, between power terminal and casing) | | | | | | | | | | | | | | | |
| Insulation resistance | Min. 100 M Ω (500 VDC, all terminals -casing) | | | | | | | | | | | | | | | |
| Operating temperature, humidity | 0 to 50°C, 35 to 85% Rh (no dew condensation) | | | | | | | | | | | | | | | |
| Storage temperature, humidity | -10 to 60°C, 35 to 85% Rh (no dew condensation) | | | | | | | | | | | | | | | |
| Power consumption | Approximately 7 VA | | | | | | | | | | | | | | | |

*These specifications are model-dependent.

Description of terminals

| Terminal No. | Terminal description |
|--------------|---|
| 1 | N.C. |
| 2 | N.C. |
| 3 | A phase input (+ side) |
| 4 | A phase input (- side, common side) |
| 5 | B phase input (+ side) |
| 6 | B phase input (- side, common side) |
| 7 | PG power supply (+ side) |
| 8 | PG power supply (common side) |
| 9 | -5V terminal |
| 11 | A phase output (+ side) |
| 12 | A phase output (- side, common side) |
| 13 | B phase output (+ side) |
| 14 | B phase output (- side, common side) |
| 15 | External power supply (+ side) |
| 16 | External power supply (- side, common side) |
| 17 | Ground terminal |
| 18 | AC power supply input |
| 19 | |

8.7.3 Notes for connection and use

8.7.3.1 Connection diagram

Make wiring as shown in Figure 8.18.




Figure 8.18 Connection Diagram

Connect the grounding terminal of the PG amplifier to the same ground section as the inverter. (When the PG amplifier is stored inside a cabinet, connect the grounding terminal to the common ground bus.)

For the pulse signals, use shielded lines between the motor and PG amplifier, and between the PG amplifier and the inverter.

- Inside cabinet: MVVS-3 core of 0.3 mm² or more
- Outside cabinet: CVVS-4 core of 2 mm² or more

Connect the shield layer of the shielded wires between the motor and PG amplifier to the SS (E) terminal dedicated for motor signals.

8.7.3.2 Notes for use

Using the PG amplifier causes the following problems for the inverter. For the solution of the problems, change the settings of function codes H104 and E45.

- (1) Connection of the PG amplifier brings the inverter terminal [PGP] to an open state, resulting in a wire break alarm of the PG power line ($F73$). Disable the power wire break alarm function by changing the setting of H104 (Protective/maintenance function selection 2).
- (2) The PG signal wire break alarm function cannot be enabled since the recommended PG amplifier has no wire break detection function and the inverter terminals [PA], [PB] and [PGM] are connected with the PG amplifier. Instead of the disabled PG wire break alarm functions, therefore, enable the speed agreement alarm function ($E75$) by changing the setting of E45 (Speed disagreement alarm).

For the function code settings, refer to Chapter 4, Section 4.3 "Details of Function Codes."

8.7.4 External dimensions




Figure 8.19 Outside Drawing

- Steel closed box (IP20 equivalent)
- Paint color: Cream color (Munsell 5Y7/1)
- Approx. mass: 1 kg
- Install the PG amplifier 10 mm away from instruments such as control relays and construction parts, and more than 100 mm away from main circuit instruments and wiring.

Chapter 9

SELECTING OPTIMAL MOTOR AND INVERTER CAPACITIES

This chapter provides you with information about the inverter output torque characteristics, selection procedure, and equations for calculating capacities to help you select optimal motor and inverter models. It also helps you select braking resistors and inverter mode (HD, MD, or LD).

Contents

| | | |
|---------|---|------|
| 9.1 | Selecting Motor and Inverter Capacities | 9-1 |
| 9.1.1 | Motor output torque characteristics..... | 9-1 |
| 9.1.2 | Selection procedure..... | 9-3 |
| 9.1.3 | Equations for selections | 9-7 |
| 9.1.3.1 | Load torque during constant speed running | 9-7 |
| [1] | General equation | 9-7 |
| [2] | Obtaining the required force F | 9-7 |
| 9.1.3.2 | Acceleration and deceleration time calculation..... | 9-9 |
| [1] | Calculation of moment of inertia..... | 9-9 |
| [2] | Calculation of the acceleration time..... | 9-11 |
| [3] | Calculation of the deceleration time..... | 9-12 |
| [4] | Calculating non-linear acceleration/deceleration time | 9-12 |
| 9.1.3.3 | Heat energy calculation of braking resistor | 9-14 |
| [1] | Calculation of regenerative energy..... | 9-14 |
| 9.1.3.4 | Calculating the RMS rating of the motor | 9-15 |
| 9.2 | Selecting a Braking Resistor | 9-16 |
| 9.2.1 | Selection procedure..... | 9-16 |
| 9.2.2 | Notes on selection | 9-16 |
| 9.3 | Selecting an Inverter Drive Mode (HD/MD/LD)..... | 9-17 |
| 9.3.1 | Precaution in making the selection..... | 9-17 |
| 9.3.2 | Guideline for selecting inverter drive mode and capacity..... | 9-18 |

9.1 Selecting Motor and Inverter Capacities

First select a motor and then inverter as follows:

- (1) Key point for selecting a motor: Determine what kind of load machine is to be used, calculate its moment of inertia, and then select the appropriate motor capacity.
- (2) Key point for selecting an inverter: Taking into account the operation requirements (e.g., acceleration time, deceleration time, and frequency in operation) of the load machine to be driven by the motor selected in (1) above, calculate the acceleration/deceleration/braking torque.

This section describes the selection procedure for (1) and (2) above. First, it explains the output torque characteristics obtained by using the motor driven by the FRENIC-VG.

9.1.1 Motor output torque characteristics

Figure 9.1 shows the output torque characteristics of motors exclusive to the FRENIC-VG. The output torque is classified into the following quadrants by speed and torque-applied direction.

(Speed)(Torque)

- First quadrant: + + Driving in forward rotation
- Second quadrant: - + Braking in reverse rotation
- Third quadrant: - - Driving in reverse rotation
- Fourth quadrant: + - Braking in forward rotation

In the figure below, the speed rate (%) is expressed assuming the base speed as 100%, and the torque rate (%), assuming the continuous rated torque as 100%.




Figure 9.1 Output Torque Characteristics (HD mode)

(1) Allowable continuous driving torque (Curve (a) in the 1st and 3rd quadrants)

Curve (a) shows the output torque available continuously in the driving mode. In the domain below the base speed (100%) in the speed control range (0 to 200%), the rated output torque (100%) is obtained. In the domain above the base speed (100%), the constant output is obtained so that the output torque is in inverse proportion to the speed.

In particular, at very low speeds below the speed control range, due to the restriction on the inverter internal temperature rise, the allowable torque drops to 80% for the converted inverter output frequency of less than 1 Hz. It is necessary to take the torque loss into account.

(2) Maximum driving torque in a short time (Curve (b) in the 1st and 3rd quadrants)

Curve (b) shows the output torque allowed for a short time (60 seconds) in the driving mode. In general, this torque applies to acceleration and deceleration. The torque is 150% of the rated continuous torque.

In particular, at very low speeds below the speed control range, due to the restriction on the inverter internal temperature rise, the allowable torque drops to 100% for the converted inverter output frequency of less than 0.1 Hz.

(3) Starting torque (Around speed zero (0) in the 1st and 3rd quadrants)


The torque at around the speed zero (0) applies as starting torque. Although the continuous output torque is 80%, the starting torque becomes as high as 150% because the curve passes the very low speed range in a short period (30 seconds or less).

(4) Braking torque (2nd and 4th quadrants)

The 2nd and 4th quadrants are the braking mode range. Curve (c) shows the braking torque available in the rated continuous current range of the inverter; curve (d) is the braking torque available for 60-second rated current. In the very low speed range, the torque drops to 80% just as in the driving mode.

The time rating of the braking torque is dominantly determined by another condition--the energy processing time rating of an optional braking resistor or braking unit since the kinetic energy of mechanical load is regenerated in the braking mode.

For the time rating of the braking resistor, this manual and the associated catalogs list the allowable values (kW) in terms of the average discharging loss and the allowable values (kWs) in terms of the discharging capability that can be discharged at one time.

 For braking-related values to be applied to the standard combination of the inverter and braking resistor or braking unit, refer to Chapter 8, Section 8.5.1.1 "Braking resistors (DBRs) and braking units."

9.1.2 Selection procedure

Figure 9.2 shows the general selection procedure for optimal inverters. Items numbered (1) through (5) are described on the following pages.

You may easily select inverter capacity if there are no restrictions on acceleration and deceleration times. If "there are any restrictions on acceleration or deceleration time" or "acceleration and deceleration are frequent," then the selection procedure is more complex.




Figure 9.2 Selection Procedure

- (1) Calculating the load torque during constant speed running (For detailed calculation, refer to Section 9.1.3.1)

The "load torque during constant speed running" refers to the torque required for rotating the load at the constant speed and converted to motor shaft. It can be calculated in consideration of the reducer rate (η_G).

Driving mode

"Load torque during constant speed running" = Actual load torque (τ_L) \div Reducer rate (η_G)

Braking mode

"Load torque during constant speed running" = Actual load torque (τ_L) \times Reducer rate (η_G)

The above calculation is requisite for selecting capacities for all loads.

First calculate the load torque of the motor during constant speed running and then select a tentative capacity so that the continuous rated torque of the motor during constant speed running becomes higher than the load torque. To perform capacity selection efficiently, it is necessary to match the rated speeds (base speeds) of the motor and load each other. To do this, select an appropriate reducer (mechanical transmission) ratio and the number of motor poles.

If there is no restriction on acceleration or deceleration time and the load is not a lift load, the tentative capacity can apply as a defined capacity.

- (2) Calculating the acceleration time (For detailed calculation, refer to Section 9.1.3.2)

When there are some specified requirements for the acceleration time, calculate it according to the following procedure:

- 1) Calculate the moment of inertia for the load and motor

If the moment of inertia is large, the motor cannot accelerate easily, requiring longer acceleration time. Calculate the moment of inertia for the load, referring to Section 9.1.3.2, "Acceleration and deceleration time calculation." For the motor, refer to the related motor catalogs.

- 2) Calculate the minimum acceleration torque (See Figure 9.3)

The acceleration torque is the difference between the "motor output torque allowed for one minute" explained in Section 9.1.1 (2) and the "load torque during constant speed running" calculated in the above (1). Calculate the minimum acceleration torque for the whole range of speed.

At speeds higher than the motor rated speed, the output torque drops in inverse proportion to the speed.

- 3) Calculate the acceleration time

Assign the value calculated above to the equation (9.15) in Section 9.1.3.2, "Acceleration and deceleration time calculation" to calculate the acceleration time. If the calculated acceleration time is longer than the expected time, select the inverter and motor having one class larger capacity and calculate it again.




Figure 9.3 Example Study of Minimum Acceleration Torque

(3) Deceleration time (For detailed calculation, refer to Section 9.1.3.2)

To calculate the deceleration time, check the motor deceleration torque characteristics for the whole range of speed in the same way as for the acceleration time.

1) Calculate the moment of inertia for the load and motor

Same as for the acceleration time. If the moment of inertia is large, the deceleration time increases.

2) Calculate the minimum deceleration torque (See Figures 9.4 and 9.5.)

If the load torque is a positive value, Figure 9.4 applies.

If the load is a braking load of a lift, etc. and the load torque is a negative value, Figure 9.5 applies. In this case, be careful with the minimum value of the braking torque that decreases due to energy regeneration.

3) Calculate the deceleration time

Assign the value calculated above to the equation (9.16) to calculate the deceleration time in the same way as for the acceleration time. If the calculated deceleration time is longer than the requested time, select the inverter and motor having one class larger capacity and calculate it again.




Figure 9.4 Example Study of Minimum Deceleration Torque (1)




Figure 9.5 Example Study of Minimum Deceleration Torque (2)

(4) Braking resistor rating (For detailed calculation, refer to Section 9.1.3.3)

Braking resistor rating is classified into two types according to the braking periodic duty cycle.

1) When the periodic duty cycle is 100 sec or less:

Calculate the average loss to determine rated values.

2) When the periodic duty cycle exceeds 100 sec:

The allowable braking energy depends on the maximum regenerative braking capacity. The allowable values are listed in Chapter 8, Section 8.5.1.1 "Braking resistors (DBRs) and braking units."

(5) Motor RMS current (For detailed calculation, refer to Section 9.1.3.4)

In metal processing machine and materials handling machines requiring positioning control, highly frequent running for a short time is repeated. In this case, calculate the maximum equivalent RMS current value (effective value of current) not to exceed the allowable value (rated current) for the motor.

(6) Notes for examining inverter capacity

- When selecting an inverter for driving a FRENIC-VG dedicated motor, ensure that the root mean square of the motor torque is lower than 100% of the rated torque.
- When selecting a general-purpose motor, ensure that the root mean square of the motor current is lower than the motor rated current for effective motor cooling. In this case, select an inverter so that the root mean square of the current is lower than the inverter rated current.

9.1.3 Equations for selections

9.1.3.1 Load torque during constant speed running

[1] General equation

The frictional force acting on a horizontally moved load must be calculated. Calculation for driving a load along a straight line with the motor is shown below.

Where the force to move a load linearly at constant speed v (m/s) is F (N) and the motor speed for driving this is N_M (r/min), the required motor output torque τ_M (N·m) is as follows:

$$\tau_M = \frac{60 \cdot v}{2 \pi \cdot N_M} \cdot \frac{F}{\eta_G} \quad (\text{N} \cdot \text{m}) \quad (9.1)$$

where, η_G is Reduction-gear efficiency.

When the inverter brakes the motor, efficiency works inversely, so the required motor torque should be calculated as follows:

$$\tau_M = \frac{60 \cdot v}{2 \pi \cdot N_M} \cdot F \cdot \eta_G \quad (\text{N} \cdot \text{m}) \quad (9.2)$$

$(60 \cdot v) / (2\pi \cdot N_M)$ in the above equation is an equivalent turning radius corresponding to speed v (m/s) around the motor shaft.

The value F (N) in the above equations depends on the load type.

[2] Obtaining the required force F

■ Moving a load horizontally

A simplified mechanical configuration is assumed as shown in Figure 9.6. If the mass of the carrier table is W_0 (kg), the load is W (kg), and the friction coefficient of the ball screw is μ , then the friction force F (N) is expressed as follows, which is equal to a required force for driving the load:

$$F = (W_0 + W) \cdot g \cdot \mu \quad (\text{N}) \quad (9.3)$$

where, g is the gravity acceleration (≈ 9.8 (m/s²)).

Then, the driving torque around the motor shaft is expressed as follows:

$$\tau_M = \frac{60 \cdot v}{2 \pi \cdot N_M} \cdot \frac{(W_0 + W) \cdot g \cdot \mu}{\eta_G} \quad (\text{N} \cdot \text{m}) \quad (9.4)$$




Figure 9.6 Moving a Load Horizontally

■ Vertical Lift Load

A simplified mechanical configuration is assumed as shown in Figure 9.7. If the mass of the cage is W_0 (kg), the load is W (kg), and the balance weight is W_B (kg), then the forces F (N) required for lifting the load up and down are expressed as follows:

$$F = (W_0 + W - W_B) \cdot g \text{ (N)} \quad \text{(For lifting up)} \quad (9.5)$$

$$F = (W_0 - W - W_B) \cdot g \text{ (N)} \quad \text{(For lifting down)} \quad (9.6)$$

Assuming the maximum load is W_{\max} , the mass of the balance weight W_B (kg) is generally obtained with the expression $W_B = W_0 + W_{\max} / 2$. Depending on the mass of load W (kg), the values of F (N) may be negative in both cases of lifting up and down, which means the lift is in braking mode. So, be careful in motor and inverter selection.

For calculation of the required output torque τ around the motor shaft, apply the expression (9.1) or (9.2) depending on the driving or braking mode of the lift, that is, apply the expression (9.1) if the value of F (N) is positive, and the (9.2) if negative.




Figure 9.7 Vertical Lift Load

■ Inclined Lift Load

Although the mechanical configuration of an inclined lift load is similar to that of a vertical lift load, unignorable friction force in the inclined lift makes a difference; in an inclined lift load, there is a distinct difference between the expression to calculate the lift force F (N) for lifting up and that for lifting down.

If the incline angle is θ , and the friction coefficient is μ , as shown in the Figure 9.8, the driving force F (N) is expressed as follows:

$$F = ((W_0 + W) (\sin\theta + \mu \cdot \cos\theta) - W_B) \cdot g \text{ (N)} \quad \text{(For lifting up)} \quad (9.7)$$

$$F = ((W_B - (W_0 + W) (\sin\theta + \mu \cdot \cos\theta)) \cdot g \text{ (N)} \quad \text{(For lifting down)} \quad (9.8)$$

The braking mode applies to both lifting up and down as in the vertical lift load. And the calculation of the required output torque τ around the motor shaft is the same as in the vertical lift load; apply the expression (9.1) if the value of F (N) is positive, and the (9.2) if negative.




Figure 9.8 Inclined Lift Load

9.1.3.2 Acceleration and deceleration time calculation

When an object whose moment of inertia is J ($\text{kg}\cdot\text{m}^2$) rotates at the speed N (r/min), it has the following kinetic energy:

$$E = \frac{J}{2} \cdot \left(\frac{2\pi \cdot N}{60} \right)^2 \quad (\text{J}) \quad (9.9)$$

To accelerate the above rotational object, the kinetic energy will be increased; to decelerate the object, the kinetic energy must be discharged. The torque required for acceleration and deceleration can be expressed as follows:

$$\tau = J \cdot \frac{2\pi}{60} \left(\frac{dN}{dt} \right) \quad (\text{N}\cdot\text{m}) \quad (9.10)$$

This way, the mechanical moment of inertia is an important element in the acceleration and deceleration. First, calculation method of moment of inertia is described, then those for acceleration and deceleration time are explained.

[1] Calculation of moment of inertia

For an object that rotates around the shaft, virtually divide the object into small segments and square the distance from the shaft to each segment. Then, sum the squares of the distances and the masses of the segments to calculate the moment of inertia.

$$J = \sum (W_i \cdot r_i^2) \quad (\text{kg}\cdot\text{m}^2) \quad (9.11)$$

The following describes equations to calculate moment of inertia having different shaped loads or load systems.

(1) Hollow cylinder and solid cylinder

The common shape of a rotating body is hollow cylinder. The moment of inertia J ($\text{kg}\cdot\text{m}^2$) around the hollow cylinder center axis can be calculated as follows, where the outer and inner diameters are D_1 and D_2 [m] and total mass is W [kg] in Figure 9.9.

$$J = \frac{W \cdot (D_1^2 + D_2^2)}{8} \quad (\text{kg}\cdot\text{m}^2) \quad (9.12)$$

For a similar shape, a solid cylinder, calculate the moment of inertia as D_2 is 0.


















Figure 9.9 Hollow Cylinder

(2) For a general rotating body

Table 9.1 lists the calculation equations of moment of inertia of various rotating bodies including the above cylindrical rotating body.

Table 9.1 Moment of Inertia of Various Rotating Bodies

| Shape | Mass: W (kg) | Shape | Mass: W (kg) |
|--|--|--|--|
| | Moment of inertia: J (kg·m ²) | | Moment of inertia: J (kg·m ²) |
| Hollow cylinder  | $W = \frac{\pi}{4} \cdot (D_1^2 - D_2^2) \cdot L \cdot \rho$ $J = \frac{1}{8} \cdot W \cdot (D_1^2 + D_2^2)$ | Rectangular prism  | $W = A \cdot B \cdot L \cdot \rho$ $J_a = \frac{1}{12} \cdot W \cdot (L^2 + A^2)$ $J_b = \frac{1}{12} \cdot W \cdot (L^2 + \frac{1}{4} \cdot A^2)$ $J_c \approx W \cdot (L_0^2 + L_0 \cdot L + \frac{1}{3} \cdot L^2)$ |
| Sphere  | $W = \frac{\pi}{6} \cdot D^3 \cdot \rho$ $J = \frac{1}{10} \cdot W \cdot D^2$ | Cone  | $W = \frac{\pi}{4} \cdot D^2 \cdot L \cdot \rho$ $J = \frac{3}{40} \cdot W \cdot D^2$ |
| Cone  | $W = \frac{\pi}{12} \cdot D^2 \cdot L \cdot \rho$ $J = \frac{3}{40} \cdot W \cdot D^2$ | Rectangular prism  | $W = A \cdot B \cdot L \cdot \rho$ $J = \frac{1}{12} \cdot W \cdot (A^2 + B^2)$ |
| Rectangular prism  | $W = A \cdot B \cdot L \cdot \rho$ $J = \frac{1}{12} \cdot W \cdot (A^2 + B^2)$ | Square cone (Pyramid, rectangular base)  | $W = \frac{\pi}{4} \cdot D^2 \cdot L \cdot \rho$ $J_a = \frac{1}{12} \cdot W \cdot (L^2 + \frac{3}{4} \cdot D^2)$ $J_b = \frac{1}{3} \cdot W \cdot (L^2 + \frac{3}{16} \cdot D^2)$ $J_c \approx W \cdot (L_0^2 + L_0 \cdot L + \frac{1}{3} \cdot L^2)$ |
| Square cone (Pyramid, rectangular base)  | $W = \frac{1}{3} \cdot A \cdot B \cdot L \cdot \rho$ $J = \frac{1}{20} \cdot W \cdot (A^2 + B^2)$ | Triangular prism  | $W = \frac{1}{3} \cdot A \cdot B \cdot L \cdot \rho$ $J_b = \frac{1}{10} \cdot W \cdot (L^2 + \frac{1}{4} \cdot A^2)$ $J_c \approx W \cdot (L_0^2 + \frac{3}{2} \cdot L_0 \cdot L + \frac{3}{5} \cdot L^2)$ |
| Triangular prism  | $W = \frac{\sqrt{3}}{4} \cdot A^2 \cdot L \cdot \rho$ $J = \frac{1}{3} \cdot W \cdot A^2$ | Tetrahedron with an equilateral triangular base  | $W = \frac{\pi}{12} \cdot D^2 \cdot L \cdot \rho$ $J_b = \frac{1}{10} \cdot W \cdot (L^2 + \frac{3}{8} \cdot D^2)$ $J_c \approx W \cdot (L_0^2 + \frac{3}{2} \cdot L_0 \cdot L + \frac{3}{5} \cdot L^2)$ |
| Tetrahedron with an equilateral triangular base  | $W = \frac{\sqrt{3}}{12} \cdot A^2 \cdot L \cdot \rho$ $J = \frac{1}{5} \cdot W \cdot A^2$ | Cone  | $W = \frac{\pi}{12} \cdot D^2 \cdot L \cdot \rho$ $J_b = \frac{1}{10} \cdot W \cdot (L^2 + \frac{3}{8} \cdot D^2)$ $J_c \approx W \cdot (L_0^2 + \frac{3}{2} \cdot L_0 \cdot L + \frac{3}{5} \cdot L^2)$ |

Main metal density (at 20°C) ρ(kg/m³) Iron: 7860, Copper: 8940, Aluminum: 2700

(3) For a load running horizontally

Assume a carrier table driven by a motor as shown in Figure 9.6. If the table speed is v (m/s) when the motor speed is N_M (r/min), then an equivalent distance from the shaft is equal to $60 \cdot v / (2\pi \cdot N_M)$ (m). The moment of inertia of the table and load to the shaft is calculated as follows:

$$J = \left(\frac{60 \cdot v}{2 \pi \cdot N_M} \right)^2 \cdot (W_0 + W) \quad (\text{kg} \cdot \text{m}^2) \quad (9.13)$$

(4) For a vertical or inclined lift load

The moment of inertia J ($\text{kg} \cdot \text{m}^2$) of the loads connected with a rope as shown in Figures 9.7 and 9.8 is calculated with the following equation using the mass of all moving objects, although the motion directions of those loads are different.

$$J = \left(\frac{60 \cdot v}{2 \pi \cdot N_M} \right)^2 \cdot (W_0 + W + W_B) \quad (\text{kg} \cdot \text{m}^2) \quad (9.14)$$

[2] Calculation of the acceleration time

Figure 9.10 shows a general load model. Assume that a motor drives a load via a reduction-gear with efficiency η_G . The time required to accelerate this load in stop state to a speed of N_M (r/min) is calculated with the following equation:

$$t_{\text{acc}} = \frac{J_1 + J_2/\eta_G}{\tau_M - \tau_L/\eta_G} \cdot \frac{2\pi \cdot (N_M - 0)}{60} \quad (\text{s}) \quad (9.15)$$

where,

- J_1 : Motor shaft moment of inertia ($\text{kg} \cdot \text{m}^2$)
- J_2 : Load shaft moment of inertia converted to motor shaft ($\text{kg} \cdot \text{m}^2$)
- τ_M : Minimum motor output torque in driving motor ($\text{N} \cdot \text{m}$)
- τ_L : Maximum load torque converted to motor shaft ($\text{N} \cdot \text{m}$)
- η_G : Reduction-gear efficiency.

As clarified in the above equation, the equivalent moment of inertia becomes $(J_1 + J_2/\eta_G)$ by considering the reduction-gear efficiency.




Figure 9.10 Load Model Including Reduction-gear

[3] Calculation of the deceleration time

In a load system shown in Figure 9.10, the time needed to stop the motor rotating at a speed of N_M (r/min) is calculated with the following equation:

$$t_{DEC} = \frac{J_1 + J_2 \cdot \eta_G}{\tau_M - \tau_L \cdot \eta_G} \cdot \frac{2\pi \cdot (0 - N_M)}{60} \quad (s) \quad (9.16)$$

where,

J_1 : Motor shaft moment of inertia ($\text{kg} \cdot \text{m}^2$)


J_2 : Load shaft moment of inertia converted to motor shaft ($\text{kg} \cdot \text{m}^2$)

τ_M : Minimum motor output torque in braking (or decelerating) motor ($\text{N} \cdot \text{m}$)

τ_L : Maximum load torque converted to motor shaft ($\text{N} \cdot \text{m}$)

η_G : Reduction-gear efficiency

In the above equation, generally output torque τ_M is negative and load torque τ_L is positive. So, deceleration time becomes shorter. However, in the case of a lift load, τ_L may become a negative value in the braking mode so that the deceleration time becomes longer.

 For lift applications, calculate the deceleration time using the negative value of τ_L (maximum load torque converted to motor shaft).

[4] Calculating non-linear acceleration/deceleration time

In applications requiring frequent acceleration/deceleration, the inverter can accelerate/decelerate the motor in the shortest time utilizing all torque margins. The inverter in a vector control mode can easily perform this type of operation.




Figure 9.11 An Example of Driving Characteristics with a Constant Output Range

In this case, the acceleration/deceleration vs. speed curve will form a non-linear figure, and the acceleration/deceleration time cannot be calculated by a single expression.

Generally, the acceleration/deceleration time is obtained by calculating the acceleration/deceleration time of ΔN that is a difference of speed N broken into small parts, and then integrating it to obtain the total acceleration/deceleration time from start to end. Because the smaller ΔN provides higher accuracy, this numerical calculation needs an aid of a computer program.

The following is a guide for the numerical calculation method using a computer program.

Figure 9.11 illustrates an example of driving characteristics with a constant output range. In the figure, the range under N_0 is of constant torque characteristics, and the range between N_0 and N_1 is of a constant output with the non-linear acceleration/deceleration characteristics.

[4-1] Calculating non-linear acceleration time

The expression (9.17) gives an acceleration time Δt_{ACC} within a ΔN speed thread.

$$\Delta t_{ACC} = \frac{J_1 + J_2 / \eta_G}{\tau_M - \tau_L / \eta_G} \cdot \frac{2\pi \cdot \Delta N}{60} \quad (s) \quad (9.17)$$

Before proceeding this calculation, obtain the motor shaft moment of inertia J_1 , the load shaft moment of inertia converted to motor shaft J_2 , maximum load torque converted to motor shaft τ_L , and the reduction-gear efficiency η_G . Apply the maximum motor output torque τ_M according to an actual speed thread ΔN as follows.

[τ_M in $N \leq N_0$] Constant output torque range

$$\tau_M = \frac{60 \cdot P_O}{2\pi \cdot N_0} \quad (N \cdot m) \quad (9.18)$$

[τ_M in $N_0 \leq N \leq N_1$] Constant output power range
(The motor output torque is inversely proportional to the motor speed)

$$\tau_M = \frac{60 \cdot P_O}{2\pi \cdot N} \quad (N \cdot m) \quad (9.19)$$

If the result obtained by the above calculation does not satisfy the target value, select an inverter with one rank higher capacity.

[4-2] Calculating non-linear deceleration time

Use the following expression to obtain the non-linear deceleration time as well as for the acceleration time shown in [4-1].

$$\Delta t_{DEC} = \frac{J_1 + J_2 \cdot \eta_G}{\tau_M - \tau_L \cdot \eta_G} \cdot \frac{2\pi \cdot \Delta N}{60} \quad (s) \quad (9.20)$$

In this expression, both τ_M , and ΔN are generally negative values so that the load torque τ_L serves to assist the deceleration operation. For a lift load, however, the load torque τ_L is a negative value in some modes. In this case, the τ_M , and τ_L will take polarity opposite to each other and the τ_L will serve to prevent the deceleration operation of the lift.

9.1.3.3 Heat energy calculation of braking resistor

If the inverter brakes the motor, the kinetic energy of mechanical load is converted to electric energy to be regenerated into the inverter circuit. This regenerative energy is generally consumed in so-called braking resistors as heat. The following explains the braking resistor rating.

[1] Calculation of regenerative energy

In the inverter operation, the regenerative energy sources include the kinetic energy of a moving object and the potential energy of a lift.

(1) Kinetic energy of a moving object

When an object with moment of inertia J ($\text{kg}\cdot\text{m}^2$) rotates at a speed N_2 (r/min), its kinetic energy is as follows:

$$E = \frac{J}{2} \cdot \left(\frac{2\pi \cdot N_2}{60} \right)^2 \quad (J = \text{Ws}) \quad (9.21)$$

$$\approx \frac{1}{182.4} \cdot J \cdot N_2^2 \quad (J) \quad (9.21)'$$

When this object is decelerated to a speed N_1 (r/min), the output energy is as follows:

$$E = \frac{J}{2} \cdot \left[\left(\frac{2\pi \cdot N_2}{60} \right)^2 - \left(\frac{2\pi \cdot N_1}{60} \right)^2 \right] \quad (J) \quad (9.22)$$

$$\approx \frac{1}{182.4} \cdot J \cdot (N_2^2 - N_1^2) \quad (J) \quad (9.22)'$$

The energy regenerated to the inverter as shown in Figure 9.11 is calculated from the reduction-gear efficiency η_G and motor efficiency η_M as follows:

$$E \approx \frac{1}{182.4} \cdot (J_1 + J_2 \cdot \eta_G) \cdot \eta_M \cdot (N_2^2 - N_1^2) \quad (J) \quad (9.23)$$

(2) Potential energy of a lift

When an object whose mass is W (kg) falls from the height h_2 (m) to the height h_1 (m), the output energy is as follows:

$$E = W \cdot g \cdot (h_2 - h_1) \quad (J = \text{Ws}) \quad (9.24)$$
$$g \approx 9.8065 \text{ (m/s}^2\text{)}$$

The energy regenerated to the inverter is calculated from the reduction-gear efficiency η_G and motor efficiency η_M as follows:

$$E = W \cdot g \cdot (h_2 - h_1) \cdot \eta_G \cdot \eta_M \quad (J) \quad (9.25)$$

9.1.3.4 Calculating the RMS rating of the motor

In the case of a load which is repeatedly and very frequently driven by a motor, the motor current fluctuates largely and enters the short-time rating range of the motor repeatedly. Therefore, you have to review the allowable thermal rating of the motor. The heat value is assumed to be approximately proportional to the square of the motor current. The temperature of the forced cooling fan type of FRENIC-VG dedicated motors rises in proportion to the heat value.

If an inverter drives a motor in duty cycles that are much shorter than the thermal time constant of the motor, calculate the "equivalent RMS current" as mentioned below, and select the motor so that this RMS current will not exceed the rated current of the motor.




Figure 9.12 Sample of the Repetitive Operation

First, calculate the required torque of each part based on the speed pattern. Then using the torque-current curve of the motor, convert the torque to the motor current. The "equivalent RMS current, I_{eq} " can be finally calculated by the following equation:

$$I_{eq} = \sqrt{\frac{I_1^2 \cdot t_1 + I_2^2 \cdot t_2 + I_3^2 \cdot t_3 + I_4^2 \cdot t_4 + I_5^2 \cdot t_5}{t_1 + t_2 + t_3 + t_4 + t_5 + t_6}} \quad (A) \quad (9.26)$$

The torque-current curve for the dedicated motor is not available for actual calculation. Therefore, calculate the motor current I from the load torque τ_1 using the following equation (9.27). Then, calculate the equivalent current I_{eq} :

$$I = \sqrt{\left(\frac{\tau_1}{100} \times I_{t100}\right)^2 + I_{m100}^2} \quad (A) \quad (9.27)$$

Where, τ_1 is the load torque (%), I_{t100} is the torque current (P09; M1 torque current), and I_{m100} is exciting current (P08; M1 exciting current).

- For the function code data of P08 and P09, refer to Chapter 12 "Replacement Information."
- When using the 2nd motor, refer to the torque current and exciting current of A codes instead of those of P codes.

9.2 Selecting a Braking Resistor

9.2.1 Selection procedure

Depending on the cyclic period, the following requirements must be satisfied.

- ① If the cyclic period is 100 s or less: Requirements 1) and 3) below
 - ② If the cyclic period exceeds 100 s: Requirements 1) and 2) below
- 1) The maximum braking torque should not exceed values listed in the tables given in Chapter 8, Section 8.5.1 "Braking resistors (DBRs) and braking units." To use the maximum braking torque exceeding values in those tables, select the braking resistor having one class larger capacity.
 - 2) The discharge energy for a single braking action should not exceed the discharging capability (kW) listed in the tables given in Chapter 8, Section 8.5.1 "Braking resistors (DBRs) and braking units." For detailed calculation, refer to Section 9.1.3.3 "Heat energy calculation of braking resistor."
 - 3) The average loss that is calculated by dividing the discharge energy by the cyclic period must not exceed the average allowable loss (kW) listed in the tables given in Chapter 8, Section 8.5.1 "Braking resistors (DBRs) and braking units."

9.2.2 Notes on selection

The braking time T_1 , cyclic period T_0 , and duty cycle %ED are converted under deceleration braking conditions based on the rated torque as shown below. However, you do not need to consider these values when selecting the braking resistor capacity.




Figure 9.13 Duty Cycle

$$\text{Duty cycle \%ED} = \frac{T_1}{T_0} \times 100 (\%)$$

9.3 Selecting an Inverter Drive Mode (HD/MD/LD)

9.3.1 Precaution in making the selection

The FRENIC-VG series of inverters is available in three different drive modes--HD (High Duty: for heavy duty load applications), MD (Medium Duty: for medium duty load applications), and LD (Low Duty: for light duty load applications), which can be switched on site. The HD mode can drive a motor with the same capacity as the inverter; the MD mode, with one rank higher capacity than the inverter; the LD mode, with one or two ranks higher capacity than the inverter.

The LD mode is available in inverters of 30 kW or above, and the MD mode, in the 400 V class series of inverters of 90 to 400 kW.

Select the inverter drive mode appropriate to the user application, considering the motor capacity, overload characteristics, and HD/MD/LD mode referring to Section 9.3.2 "Guideline for selecting inverter drive mode and capacity."

HD mode designed for heavy duty load applications

Apply to general-purpose equipment where the inverter's load current in normal operations is less than the rated current of the HD-mode inverter, and the load current in overcurrent operation is less than 150% of the rated current of the HD-mode inverter for 1 minute and 200% for 3 seconds.

The rated current of the HD mode inverter is based on a motor with the same capacity as the inverter. Inverter running with the intermittent load rating is also possible as described below.

Intermittent load rating in the HD mode

Satisfying the following conditions enables inverter running with overload torque 164 to 200% (depending upon the capacity) for 10 seconds or below.

- 1) The root-mean-square current in cycle operation is 80% or less of the inverter rated current.
- 2) The carrier frequency is 10 or 6 kHz (depending upon the capacity) or below.

MD mode designed for medium duty load applications

Apply to equipment where the inverter's load current in normal operations is less than the rated current of the MD-mode inverter, and the load current in overcurrent operation is less than 150% of the rated current of the MD-mode inverter for 1 minute.

The rated current of the MD-mode inverter is based on a motor with one rank higher capacity than the inverter.

LD mode designed for light duty load applications

Apply to variable load equipment such as fans, pumps, and centrifugal machines where the inverter's load current in normal operations is less than the rated current of the LD-mode inverter, and the load current in overcurrent operation is less than 120% of the rated current of the LD-mode inverter for 1 minute.

The rated current of the LD-mode inverter is based on a motor with one or two ranks higher capacity than the inverter.

Replacement information for replacing the FRENIC5000VG7S (HT mode) with the FRENIC-VG series

The FRENIC-VG does not support the HT mode. When replacing the HT-mode FRENIC5000VG7S with the FRENIC-VG, therefore, use the inverter with one rank higher capacity.

9.3.2 Guideline for selecting inverter drive mode and capacity

Table 9.2 lists the differences between HD, MD, and LD modes.

If MD-/LD-mode inverters of 30 kW or above satisfy the requirements of the overload capability and functionality in your application, you can select the inverter with one or two ranks lower capacity than that of the motor rating.

Table 9.2 Differences between HD, MD, and LD modes

| Function | | HD mode | MD mode | LD mode | Remarks |
|--|-------|--|--|---|--|
| Application | | Heavy duty load | Medium duty load | Light duty load | — |
| Capacity range | 200 V | All capacities | Not available | 30 to 90 kW (corresponding to 37-110 kW motors) | |
| | 400 V | All capacities | 90 to 400 kW (corresponding to 110 to 450 kW motors) | 30 to 630 kW (corresponding to 37 to 710 kW motors) | |
| Function code data setting (Switching between HD, MD, and LD modes) | | F80 = 0, (Factory default) | F80 = 3 | F80 = 1 | — |
| Continuous current rating level (inverter rated current level) | | Rated current based on a motor with the <u>same</u> capacity as the inverter. | Rated current based on a motor with <u>one rank higher</u> capacity than the inverter. | Rated current based on a motor with <u>one or two ranks higher</u> capacity than the inverter. | The MD-/LD-mode inverter brings out the continuous current rating level which enables the inverter to drive a motor with one or two ranks higher capacity, but its overload capability (%) against the continuous current level decreases. For the rated current level, refer to Chapter 2 "SPECIFICATIONS." |
| Overload capability | | 150% for 1 min. 200% for 3 s, relative to the rated current of HD-mode inverters | 150% for 1 min. relative to the rated current of MD-mode inverters | 120% for 1 min. relative to the rated current of LD-mode inverters | |
| Motor sound (Carrier frequency) | | Setting range: 2 to 15 kHz (0.75 to 55 kW) 2 to 10 kHz (75 to 400 kW) 2 to 5 kHz (500, 630 kW) | Setting range: 2 to 4 kHz (90 to 400 kW) | Setting range: 2 to 10 kHz (30 to 55 kW) 2 to 5 kHz (75 to 500 kW) 2 kHz (630 kW) | In the MD/LD mode, a value out of the range, if specified, automatically changes to the maximum value allowable in the MD/LD mode. |

The MD-/LD-mode inverters have no restrictions on the output frequency range.

The MD-/LD-mode inverters have no restrictions on the setting range of function codes whose data (e.g., DC braking level) is based on the rated current.

A DC reactor (DCR) is provided as standard for the FRENIC-VG of 75 kW or above. To use the inverter in the MD or LD mode, specify the MD-/LD-mode inverter when placing an order, and the FRENIC-VG comes with the DCR suitable for the motor capacity to be applied in the MD or LD mode. If the MD-/LD-mode inverter is not specified, the FRENIC-VG comes with the DCR suitable for the motor capacity to be applied in the HD mode. Applying the DCR to be applied in the HD mode to the MD-/LD-mode inverters may flow the current exceeding the DCR rated current.

If an order for the LD-mode inverter of 55 kW is placed, the inverter comes with the DCR suitable for 75 kW as standard.

Each rated current in the HD, MD and LD modes is used as a base for displaying or specifying the electric current data in percent (%) of the rated current with function codes or for outputting or displaying it by analog output or communications monitor.

Chapter 10 ABOUT MOTORS

This chapter details vector motors that can be connected to the FRENIC-VG series of inverters.

Contents

| | |
|---|------|
| 10.1 Vibration and Noise | 10-1 |
| 10.2 Acceleration Vibration Value | 10-2 |
| 10.3 Allowable Radial Load at Motor Shaft Extension | 10-3 |
| 10.4 Allowable Thrust Load | 10-5 |
| 10.5 List of Special Combinations | 10-6 |
| 10.5.1 Combination list of 380V series | 10-6 |
| 10.5.2 Combination list of low base speed series | 10-7 |

10.1 Vibration and Noise

For the specifications and the external dimensions of the dedicated motors, refer to Chapter 2, Section 2.4 "Dedicated Motor Specifications."

| Dedicated applicable motor (kW) | No. of poles | Motor type | Vibration level (μm) | | Noise level (dB (A)) *3 | |
|---------------------------------|--------------|------------|-----------------------------------|-----------------------------|-------------------------|--------------------------|
| | | MVK__ | Base speed 1500 r/min | Maximum speed *2 3600 r/min | Base speed 1500 r/min | Maximum speed 3600 r/min |
| 0.75 | 4 | 8095A | Max. 5 | Max. 7 | 56 | 60 |
| 1.5 | | 8097A | | | | |
| 2.2 | | 8107A | | | | |
| 3.7 | | 8115A | | | | |
| 5.5 | | 8133A | | | | |
| 7.5 | | 8135A | | | | |
| 11 | | 8165A | | | | |
| 15 | | 8167A | | | | |
| 18.5 | | 8184A | | | | |
| 22 | | 8185A | | | | |
| 30 | | 8187A | Max. 7 | 71 | 73 | |
| 37 | | 8207A | | | | |
| 45 | | 8208A | Max. 5 | Max. 7 | 71 | 73 |
| 55 | | 9224A | *1 | Max. 15 | *1 | *1 |
| 75 | | 9254A | | | | |
| 90 | | 9256A | | | | |
| 110 | | 9284A | | | | |
| 132 | | 9286A | | | | |
| 160 | | 528KA | | | | |
| 200 | | 528LA | | | | |
| 220 | 531FA | | | | | |
| 250 | 531GA | | | | | |
| 280 | 531HA | | | | | |
| 300 | 535GA | | | | | |
| 315 | 535GA | | | | | |
| 355 | 535HA | | | | | |
| 400 | 535JA | | | | | |

*1 Contact your Fuji Electric representative for individual values.

*2 3000 r/min for 30 to 45 kW, 2400 r/min for 55 to 75 kW, 2000 r/min for 90 to 220 kW

*3 Values measured 1 m away from the motor to the direction of the terminal box


10.2 Acceleration Vibration Value

| Dedicated applicable motor (kW) | No. of poles | Motor type | Acceleration vibration value, acceptable (m/s ²) |
|---------------------------------|--------------|------------|--|
| | | MVK__ | |
| 0.75 | 4 | 8095A | Max. 7 |
| 1.5 | | 8097A | |
| 2.2 | | 8107A | |
| 3.7 | | 8115A | |
| 5.5 | | 8133A | |
| 7.5 | | 8135A | |
| 11 | | 8165A | |
| 15 | | 8167A | |
| 18.5 | | 8184A | |
| 22 | | 8185A | |
| 30 | | 8187A | |
| 37 | | 8207A | |
| 45 | | 8208A | |
| 55 | | 9224A | |
| 75 | | 9254A | |
| 90 | | 9256A | |
| 110 | | 9284A | |
| 132 | | 9286A | |
| 160 | | 528KA | |
| 200 | | 528LA | |
| 220 | | 531FA | |
| 250 | | 531GA | |
| 280 | | 531HA | |
| 300 | | 535GA | |
| 315 | 535GA | | |
| 355 | 535HA | | |
| 400 | 535JA | | |


Note: If the actual vibration exceeds values listed above, any separate anti-vibration measure is required.


10.3 Allowable Radial Load at Motor Shaft Extension

[Loaded point]



The maximum allowable value of radial load applied by the belt is shown in the figures below. The data is classified by the frame number and the rotation speed. If the point which is decided by the radial load FA (kN) acting on the motor shaft and the length L (mm) from the stepped joint at shaft end to the center of the pulley (the distance to the FA load points) is within a curve, the motor can be operated by that pulley. Refer to the technical leaflet of the induction motor for the details.





Note: Contact your Fuji Electric representative individually for motors whose frame number exceeds 200L (55 kW or above).

10.4 Allowable Thrust Load

Unit: kN (kgf)

| Frame number | Type MVK | Horizontal use IM B3(F11), IM B5(L51) | | | | | | Vertical use IM V5(F12), IM V1(L52) | | | | | | Vertical use IM V6(F13), IM V3(L53) | | | | | |
|---|--|---------------------------------------|--------------|--------------|-------------------------|--------------|--------------|-------------------------------------|--------------|--------------|-------------------------|--------------|----------------|-------------------------------------|--------------|--------------|-------------------------|--------------|----------------|
| | | Direction of thrust: FS | | | Direction of thrust: FU | | | Direction of thrust: FS | | | Direction of thrust: FU | | | Direction of thrust: FS | | | Direction of thrust: FU | | |
| | | 2 poles | 4 poles | 6 poles | 2 poles | 4 poles | 6 poles | 2 poles | 4 poles | 6 poles | 2 poles | 4 poles | 6 poles | 2 poles | 4 poles | 6 poles | 2 poles | 4 poles | 6 poles |
| 90L | 8095A 8097A | 0.3 (30) | 0.45 (45) | 0.55 (55) | 0.4 (40) | 0.6 (60) | 0.7 (70) | 0.25 (25) | 0.4 (40) | 0.5 (50) | 0.45 (45) | 0.65 (65) | 0.75 (75) | 0.4 (40) | 0.55 (55) | 0.65 (65) | 0.3 (30) | 0.5 (50) | 0.6 (60) |
| 100L | 8107A | — | 0.65 (65) | 0.8 (80) | — | 0.55 (55) | 0.65 (65) | — | 0.6 (60) | 0.7 (70) | — | 0.6 (60) | 0.6 (60) | — | 0.5 (50) | 0.6 (60) | — | 0.75 (75) | 0.85 (85) |
| 112M | 8115A | 0.65 (65) | 0.9 (90) | 1.1 (110) | 0.6 (60) | 0.75 (75) | 0.95 (95) | 0.6 (60) | 0.8 (80) | 1 (100) | 0.65 (65) | 0.85 (85) | 1 (100) | 0.55 (55) | 0.7 (70) | 0.85 (85) | 0.75 (75) | 1 (100) | 1.2 (120) |
| 132S | 8133A | 1 (100) | 1.4 (140) | 1.7 (170) | 0.75 (75) | 1 (100) | 1.2 (120) | 1 (100) | 1.3 (130) | 1.7 (170) | 0.9 (90) | 1.1 (110) | 1.4 (140) | 0.65 (65) | 0.9 (90) | 1.1 (110) | 1.2 (120) | 1.5 (150) | 1.9 (190) |
| 132M | 8135A | — | | | — | | | | | — | | | | — | | — | — | | |
| 160M | 8165A | 1.3 (130) | 1.8 (180) | 2.2 (220) | 1.2 (120) | 1.5 (150) | 1.9 (190) | 1.1 (110) | 1.6 (160) | 2 (200) | 1.5 (150) | 1.8 (180) | 2.2 (220) | 1 (100) | 1.4 (140) | 1.7 (170) | 1.6 (160) | 2.1 (210) | 2.5 (250) |
| 160L | 8167A | | 1.7 (170) | 2.1 (210) | | | | | 1.8 (180) | 1.5 (150) | | | | | 1.8 (180) | 1.3 (130) | | | |
| 180M | 8184A 8185A | 2 (200) | 2.7 (280) | 3.3 (340) | 1.9 (190) | 2.3 (230) | 2.8 (290) | 1.8 (180) | 2.3 (230) | 2.9 (300) | 2.2 (220) | 2.7 (280) | 3.4 (350) | 1.6 (160) | 2 (200) | 2.6 (270) | 2.4 (240) | 3.2 (330) | 3.9 (400) |
| 180L | 8187A | | | | | | | | | | | | | | | | | | |
| 200L | 8207A | 1.9 (190) | 3.8 (390) | 4.5 (460) | 2 (200) | 3.2 (330) | 3.7 (380) | 1.5 (150) | 3.2 (330) | 3.8 (390) | 2.6 (270) | 4 (410) | 4.8 (490) | 1.6 (160) | 2.7 (280) | 3 (310) | 2.5 (250) | 4.6 (470) | 5.6 (570) |
| | 8208A | 1.2 (120) | 5.4 (550) | 6.5 (-) | 1.2 (120) | 5.4 (550) | 6.5 (-) | 0.4 (40) | 4.4 (445) | 5.3 (-) | 2.3 (230) | 6.9 (700) | 8.2 (-) | | 0.4 (40) | 4.4 (445) | 5.3 (-) | 2.3 (230) | 6.9 (700) |
| 225S | 9224A | 1.1 (110) | 5.2 (535) | 6.2 (630) | 1.1 (110) | 5.2 (535) | 6.2 (630) | 0.3 (30) | 4.1 (415) | 4.8 (490) | — | — | — | 0.3 (30) | 4.1 (415) | 4.8 (490) | — | — | — |
| 250S | 9254A | 1 (100) | 6.4 (650) | 7.6 (770) | 1 (100) | 6.4 (650) | 7.6 (770) | — | 4.9 (500) | 5.6 (570) | — | 8.4 (860) | 10.3 (1050) | — | 4.9 (500) | 5.6 (570) | — | 8.4 (860) | 10.3 (1050) |
| 250M | 9256A | 0.9 (90) | 6.2 (630) | 7.3 (740) | 0.9 (90) | 6.2 (630) | 7.3 (740) | — | 4.5 (460) | 5.1 (520) | — | 8.5 (870) | 10.4 (1060) | — | 4.5 (460) | 5.1 (520) | — | 8.5 (870) | 10.4 (1060) |
| 280S | 9284A | 0.8 (80) | 5.9 (600) | 6.9 (700) | 0.8 (80) | 5.9 (600) | 6.9 (700) | — | 3.7 (380) | 4.2 (430) | — | 9.2 (940) | 10.8 (1100) | — | 3.7 (380) | 4.2 (430) | — | 9.2 (940) | 10.8 (1100) |
| 280M | 9286A | 0.7 (70) | 5.7 (580) | 6.7 (680) | 0.7 (70) | 5.7 (580) | 6.7 (680) | — | 3.1 (320) | 3.8 (390) | — | 9.3 (950) | 10.9 (1110) | — | 3.1 (320) | 3.8 (390) | — | 9.3 (950) | 10.9 (1110) |
| — | 528KA 528LA 531FA 531GA 531HA 535GA 535HA 535JA | *Contact Fuji individually | | | | | | *Contact Fuji individually | | | | | | *Contact Fuji individually | | | | | |
| Mounting method and the direction of thrust | | | | | | | | | | | | | | | | | | | |

Note 1: The above-mentioned figures whose frame number is 250S or above show the allowable thrust (axial) load of the motor for direct connection.

Note 2: The above-mentioned allowable thrust (axial) load is calculated on the assumption that the motor would bear the radial load through the normal sized half-coupling.

10.5 List of Special Combinations

10.5.1 Combination list of 380V series

| Type | | 4-pole non-standard special motor | | | 4-pole standard motor | | |
|----------------------|------|-----------------------------------|---------------|-------------------------|---|----------------|--------------------------------------|
| Base speed (r/min) | | 1500 | | | Base speed: 1,500 (r/min), Max. speed: 1,500 (r/min) | | |
| Max. load torque (%) | | 150 | | | 150 | | |
| Model and item | | Model | | Max. speed Nmax (r/min) | Model | | Potential max. speed Nmax (r/min) *2 |
| | | Motor | Inverter | | Motor | Inverter | |
| Output (kW) | 3.7 | MVK8115A | FRN3.7VG1S-4J | 3600 | MVK8115A | FRN3.7VG1S-4J | 3300 |
| | 5.5 | MVK8133A | FRN5.5VG1S-4J | | MVK8133A | FRN5.5VG1S-4J | 3400 |
| | 7.5 | MVK8135A | FRN7.5VG1S-4J | | MVK8135A | FRN7.5VG1S-4J | 2150 |
| | 11 | MVK8165A | FRN11VG1S-4J | | MVK8165A | FRN11VG1S-4J | 1600 |
| | 15 | MVK8167A | FRN15VG1S-4J | | MVK8167A | FRN15VG1S-4J | 3200 |
| | 18.5 | MVK8184A | FRN22VG1S-4J | | MVK8184A | FRN18.5VG1S-4J | 2750 |
| | 22 | MVK8185A | FRN30VG1S-4J | | MVK8185A | FRN22VG1S-4J | 2000 |
| | 30 | MVK8187A | FRN37VG1S-4J | | MVK8187A | FRN30VG1S-4J | 2200 |
| | 37 | MVK8207A | FRN45VG1S-4J | | MVK8207A | FRN37VG1S-4J | 1600 |
| | 45 | MVK8208A | FRN55VG1S-4J | MVK8208A | FRN45VG1S-4J | 2100 | |
| | 55 | MVK9224A | FRN75VG1S-4J | 2400 | MVK9224A | FRN55VG1S-4J | 1600 |
| | 75 | MVK9254A | FRN90VG1S-4J | | MVK9254A | FRN75VG1S-4J | 2000 |
| | 90 | MVK9256A | FRN110VG1S-4J | 2000 | MVK9256A | FRN90VG1S-4J | 2000 |
| | 110 | MVK9284A | FRN132VG1S-4J | | MVK9284A | FRN110VG1S-4J | 2000 |
| | 132 | MVK9286A *1 | FRN160VG1S-4J | | MVK9286A | FRN132VG1S-4J | 1500 |
| | 160 | MVK528KA *1 | FRN200VG1S-4J | | MVK528KA | FRN160VG1S-4J | 1500 |
| | 200 | MVK528LA *1 | FRN220VG1S-4J | | MVK528LA | FRN200VG1S-4J | 1500 |
| | 220 | MVK531FA *1 | FRN280VG1S-4J | | MVK531FA | FRN220VG1S-4J | 1500 |

*1 The electric characteristics of the motor are the same as those of the standard motor. The frame size of the inverter is one frame larger.

*2 The maximum speed at which the 150% overload rating torque is obtained with 380 V input is specified. If a 150% overload constant is necessary at a larger speed, select the inverter of a larger capacity.

10.5.2 Combination list of low base speed series

200V class

| No. of poles, standard/ non-standard | | 6-pole non-standard special motor | | | | | | 4-pole standard motor | |
|--------------------------------------|------|-----------------------------------|--------------------------|----------------------------|--------------------------|--------------------------|----------------------------|--------------------------|----------------------------|
| Base speed | | 500 (r/min) | 650 (r/min) | 750 (r/min) | 850 (r/min) | 1,000 (r/min) | | 1,000 (r/min) | |
| Max. speed | | 2,000 (r/min) | 2,000 (r/min) | 1,800 (r/min) | 1,700 (r/min) | 2,000 (r/min) | 2,400 (r/min) | 3,000 (r/min) | 3,600 (r/min) |
| Output (kW) | 0.75 | MVK8115A FRN1.5VG1S-2J | | MVK8107A FRN1.5VG1S-2J | | | MVK8097A FRN0.75VG1S-2J | | MVK8097A FRN1.5VG1S-2J |
| | 1.5 | MVK8133A FRN3.7VG1S-2J | | MVK8115A FRN2.2VG1S-2J | | | MVK8107A FRN2.2VG1S-2J | | MVK8107A FRN2.2VG1S-2J |
| | 2.2 | MVK8135A FRN3.7VG1S-2J | | MVK8133A FRN3.7VG1S-2J | | | MVK8115A FRN3.7VG1S-2J | | MVK8115A FRN3.7VG1S-2J |
| | 3.7 | MVK8165A FRN5.5VG1S-2J | | MVK8135A FRN5.5VG1S-2J | | | MVK8133A FRN5.5VG1S-2J | | MVK8133A FRN5.5VG1S-2J |
| | 5.5 | MVK8167A FRN7.5VG1S-2J | | MVK8165A FRN7.5VG1S-2J | | | MVK8135A FRN7.5VG1S-2J | | MVK8135A FRN7.5VG1S-2J |
| | 7.5 | MVK8185A FRN11VG1S-2J | | MVK8167A FRN11VG1S-2J | | | MVK8165A FRN7.5VG1S-2J | | MVK8165A FRN11VG1S-2J |
| | 11 | MVK8187A FRN15VG1S-2J | | MVK8184A FRN15VG1S-2J | | | MVK8167A FRN15VG1S-2J | | MVK8184A FRN18.5VG1S-2J |
| | 15 | MVK8207A FRN22VG1S-2J | | MVK8185A FRN18.5VG1S-2J | | | MVK8184A FRN18.5VG1S-2J | | MVK8185A FRN22VG1S-2J |
| | 18.5 | MVK9256A FRN30VG1S-2J | MVK9221A FRN30VG1S-2J | MVK8187A FRN22VG1S-2J | | | MVK8185A FRN22VG1S-2J | | MVK8187A FRN30VG1S-2J |
| | 22 | MVK9284A FRN37VG1S-2J | MVK9250A FRN37VG1S-2J | MVK8207A FRN30VG1S-2J | | MVK8187A FRN30VG1S-2J | | MVK8207A FRN37VG1S-2J | |
| | 30 | MVK9284A FRN45VG1S-2J | MVK9256A FRN45VG1S-2J | | MVK9221A FRN37VG1S-2J | MVK8207A FRN37VG1S-2J | | MVK8208A FRN45VG1S-2J | |
| | 37 | MVK9286A FRN55VG1S-2J | MVK9284A FRN55VG1S-2J | | MVK9224A FRN45VG1S-2J | MVK9221A FRN45VG1S-2J | | | |
| | 45 | MVK528KA FRN75VG1S-2J | MVK9284A FRN75VG1S-2J | | MVK9250A FRN55VG1S-2J | MVK9224A FRN55VG1S-2J | | | |
| | 55 | MVK528LA FRN90VG1S-2J | MVK9286A FRN75VG1S-2J | | MVK9256A FRN75VG1S-2J | MVK9250A FRN75VG1S-2J | | | |
| 75 | | MVK528LA FRN90VG1S-2J | | MVK9284A FRN90VG1S-2J | MVK9256A FRN90VG1S-2J | | | | |

400V class

| No. of poles, standard/ non-standard | | 6-pole non-standard special motor | | | | | | 4-pole standard motor | |
|--------------------------------------|------|-----------------------------------|---------------------------|----------------------------|---------------------------|---------------------------|----------------------------|--------------------------|----------------------------|
| Base speed | | 500 (r/min) | 650 (r/min) | 750 (r/min) | 850 (r/min) | 1,000 (r/min) | | 1,000 (r/min) | |
| Max. speed | | 2,000 (r/min) | 2,000 (r/min) | 1,800 (r/min) | 1,700 (r/min) | 2,000 (r/min) | 2,400 (r/min) | 3,000 (r/min) | 3,600 (r/min) |
| Output(kW) | 0.75 | MVK8115A FRN3.7VG1S-4J | | MVK8107A FRN3.7VG1S-4J | | | MVK8097A FRN3.7VG1S-4J | | MVK8097A FRN1.5VG1S-4J |
| | 1.5 | MVK8133A FRN3.7VG1S-4J | | MVK8115A FRN3.7VG1S-4J | | | MVK8107A FRN3.7VG1S-4J | | MVK8107A FRN2.2VG1S-4J |
| | 2.2 | MVK8135A FRN3.7VG1S-4J | | MVK8133A FRN3.7VG1S-4J | | | MVK8115A FRN3.7VG1S-4J | | MVK8115A FRN3.7VG1S-4J |
| | 3.7 | MVK8165A FRN5.5VG1S-4J | | MVK8135A FRN5.5VG1S-4J | | | MVK8133A FRN5.5VG1S-4J | | MVK8133A FRN5.5VG1S-4J |
| | 5.5 | MVK8167A FRN7.5VG1S-4J | | MVK8165A FRN7.5VG1S-4J | | | MVK8135A FRN7.5VG1S-4J | | MVK8135A FRN7.5VG1S-4J |
| | 7.5 | MVK8185A FRN11VG1S-4J | | MVK8167 FRN11VG1S-4J | | | MVK8165A FRN7.5VG1S-4J | | MVK8165A FRN11VG1S-4J |
| | 11 | MVK8187A FRN15VG1S-4J | | MVK8184 FRN15VG1S-4J | | | MVK8167A FRN11VG1S-4J | | MVK8184A FRN18.5VG1S-4J |
| | 15 | MVK8207A FRN22VG1S-4J | | MVK8185A FRN18.5VG1S-4J | | | MVK8184A FRN18.5VG1S-4J | | MVK8185A FRN22VG1S-4J |
| | 18.5 | MVK9256A FRN30VG1S-4J | MVK9221A FRN30VG1S-4J | MVK8187A FRN22VG1S-4J | | | MVK8185A FRN22VG1S-4J | | MVK8187A FRN30VG1S-4J |
| | 22 | MVK9284A FRN37VG1S-4J | MVK9250A FRN30VG1S-4J | MVK8207A FRN30VG1S-4J | | | MVK8187A FRN30VG1S-4J | | MVK8207A FRN37VG1S-4J |
| | 30 | MVK9284A FRN45VG1S-4J | MVK9256A FRN37VG1S-4J | | MVK9221A FRN37VG1S-4J | MVK8207A FRN37VG1S-4J | | MVK8208A FRN45VG1S-4J | |
| | 37 | MVK9286A FRN55VG1S-4J | MVK9284A FRN45VG1S-4J | | MVK9224A FRN45VG1S-4J | MVK9221A FRN45VG1S-4J | | | |
| | 45 | MVK528KA FRN75VG1S-4J | MVK9284A FRN55VG1S-4J | | MVK9250A FRN55VG1S-4J | MVK9224A FRN55VG1S-4J | | | |
| | 55 | MVK528LA FRN75VG1S-4J | MVK9286A FRN75VG1S-4J | | MVK9256A FRN75VG1S-4J | MVK9250A FRN75VG1S-4J | | | |
| | 75 | MVK531GA FRN110VG1S-4J | MVK528LA FRN90VG1S-4J | | MVK9284A FRN90VG1S-4J | MVK9256A FRN90VG1S-4J | | | |
| | 90 | MVK531HA FR132VG1S-4J | MVK531GA FRN110VG1S-4J | | MVK9286A FRN110VG1S-4J | MVK9284A FRN110VG1S-4J | | | |
| | 110 | | MVK531HA FRN132VG1S-4J | | MVK528KA FRN132VG1S-4J | MVK9286A FRN132VG1S-4J | | | |
| | 132 | | MVK531HA FRN200VG1S-4J | | MVK528LA FRN160VG1S-4J | MVK528KA FRN160VG1S-4J | | | |
| 160 | | | | | MVK528LA FRN200VG1S-4J | | | | |
| 200 | | | | | *1 | | | | |

*1 Contact your Fuji Electric representative.

Chapter 11


OPERATION DATA

This chapter provides the characteristics data of the FRENIC-VG series of inverters running.

Contents


| | |
|--|------|
| 11.1 Frequency Response Characteristics | 11-1 |
| 11.2 Rotational Fluctuation Measurement Sample | 11-1 |
| 11.3 Current Distortion Characteristics..... | 11-2 |
| 11.4 Torque Ripple..... | 11-2 |
| 11.5 Impact Load Characteristics..... | 11-3 |
| 11.6 Speed-torque Characteristics (Vector control with speed sensor) | 11-3 |
| 11.7 Torque Control Accuracy (Vector control with speed sensor)..... | 11-4 |
| 11.8 Deceleration/Acceleration via Zero Speed (Vector control with speed sensor) | 11-4 |

11.1 Frequency Response Characteristics



Inverter: FRN7.5VG1S-2J


11.2 Rotational Fluctuation Measurement Sample




Inverter: FRN37VG1S-4J
 Motor: MVK8207A, 37 kW, 1500/3000 r/min
 Test condition: Motor alone

11.3 Current Distortion Characteristics

Conventional models (FRENIC5000VG7S)



FRENIC-VG



Inverter: FRN7.5VG1S-2J


Test condition: Motor alone

11.4 Torque Ripple

Conventional models (FRENIC5000VG7S)



FRENIC-VG



Torque ripple components P-P 100%: Rated torque


| | 1 time | 2 times | 6 times |
|--------------------------------------|--------|---------|---------|
| FRENIC-VG | 0.068% | 0.307% | 0.907% |
| Conventional models (FRENIC5000VG7S) | 0.720% | 0.364% | 0.911% |

Inverter: FRN37VG1S-2J

Motor: MVK6207A-C, 37 kW, 1500/3000 rpm


Test condition: Motor constraint

11.5 Impact Load Characteristics




Inverter: FRN37VG1S-4J
 Motor: MVK8207A, 37 kW, 1500/3000 r/min
 Test condition: Running at 500 r/min

11.6 Speed-torque Characteristics (Vector control with speed sensor)



Inverter: FRN37VG1S-4J
 Motor: MVK8207A, 37 kW, 1500/3000 r/min


11.7 Torque Control Accuracy (Vector control with speed sensor)



Inverter: FRN37VG1S-4J

Motor: MVK8207A, 37 kW, 1500/3000 r/min

11.8 Deceleration/Acceleration via Zero Speed (Vector control with speed sensor)



Inverter: FRN37VG1S-4J

Motor: MVK8207A, 37 kW, 1500/3000 r/min

FRENIC-VG 12

Chapter 12 REPLACEMENT DATA

When replacing the former inverters (VG3, VG5S, and VG7S) with FRENIC-VG, refer to the replacement data given in this chapter.

Contents

| | | |
|--------|-------------------------------------|-------|
| 12.1 | Classification of Replacement..... | 12-1 |
| 12.2 | External Dimensions Comparison..... | 12-2 |
| 12.2.1 | Replacing VG7S..... | 12-2 |
| 12.2.2 | Replacing VG5S..... | 12-4 |
| 12.2.3 | Replacing VG3..... | 12-5 |
| 12.3 | Terminal Size..... | 12-6 |
| 12.3.1 | Replacing VG7S..... | 12-6 |
| 12.3.2 | Replacing VG5S..... | 12-8 |
| 12.3.3 | Replacing VG3..... | 12-10 |
| 12.4 | Terminal Symbols..... | 12-12 |
| 12.4.1 | Replacing VG7S..... | 12-12 |
| 12.4.2 | Replacing VG5S..... | 12-13 |
| 12.4.3 | Replacing VG3..... | 12-16 |
| 12.5 | Function Codes..... | 12-19 |
| 12.5.1 | Replacing VG7S..... | 12-19 |
| 12.5.2 | Replacing VG5S..... | 12-22 |
| 12.5.3 | Replacing VG3..... | 12-27 |
| 12.6 | Motor Parameters..... | 12-32 |
| 12.6.1 | Replacing VG7S..... | 12-32 |
| 12.6.2 | Replacing VG5S..... | 12-35 |
| 12.6.3 | Replacing VG3..... | 12-37 |
| 12.7 | Protective Functions..... | 12-39 |
| 12.7.1 | Replacing VG7S..... | 12-39 |
| 12.7.2 | Replacing VG5S..... | 12-40 |
| 12.7.3 | Replacing VG3..... | 12-41 |
| 12.8 | Options..... | 12-42 |
| 12.8.1 | Replacing VG7S..... | 12-42 |
| 12.8.2 | Replacing VG5S..... | 12-43 |
| 12.8.3 | Replacing VG3..... | 12-44 |

12.1 Classification of Replacement

| | Inverter | Motor | Possibility |
|--|--------------------------|-----------------------------------|---------------------|
| A: Both inverter and motor are replaced. | VG3/VG3N ⇒ FRENIC-VG | VG3 ⇒ FRENIC-VG | Possible |
| | VG5S/VG5N ⇒ FRENIC-VG | VG5 ⇒ FRENIC-VG (Same product) | Possible |
| | VG7 ⇒ FRENIC-VG | VG7 ⇒ FRENIC-VG (Same product) | Possible |
| B: Only the inverter is replaced. | VG3/VG3N ⇒ FRENIC-VG | VG3 | Possible (Note 1) |
| | VG5S/VG5N ⇒ FRENIC-VG | VG5 | Possible |
| | VG7 ⇒ FRENIC-VG | VG7 | Possible |
| C: Only the motor is replaced. | VG3 | VG3 ⇒ FRENIC-VG | Impossible (Note 2) |
| | VG5 | VG5 ⇒ FRENIC-VG (Same product) | Possible |
| | VG7 | VG7 ⇒ FRENIC-VG | Possible |

Note 1: The rated current of VG and VG3 is bigger than that of VG5, VG7. For this reason, the inverter in one-rank upper grade is required if only the inverter is changed from VG or VG3.

Note 2: For VG and VG3, the maximum output voltage, to which the stable current control is possible, is lower than that of VG5 and VG7. Therefore, if these inverters are combined with VG5 or VG7 motors, the characteristics (torque accuracy or motor wov) at around the base speed or at higher speed will deteriorate.




Note 3: When substituting from FRENIC5000VG (old model of VG3), contact us.

12.2 External Dimensions Comparison

12.2.1 Replacing VG7S

200V series

| Capacity (kW) | FRENIC5000 VG7S | | | | | | FRENIC-VG | | | | | | | |
|------------------|---------------------|--------|--------|-------------------------|---------|-----------------|-----------------|---------------------|--------|--------|-------------------------|---------|-----------------|-----------------|
| | External dimensions | | | Installation dimensions | | Mounting method | Rough mass (kg) | External dimensions | | | Installation dimensions | | Mounting method | Rough mass (kg) |
| | W (mm) | H (mm) | D (mm) | W1 (mm) | H1 (mm) | | | W (mm) | H (mm) | D (mm) | W1 (mm) | H1 (mm) | | |
| 0.75 | 205 | 300 | 245 | 181 | 278 | Wall type | 8 | 205 | 300 | 245 | 181 | 278 | Wall type | 6 |
| 1.5 | | | | | | | | | | | | | | |
| 2.2 | | | | | | | | | | | | | | |
| 3.7 | | | | | | | | | | | | | | |
| 5.5 | | | | | | | | | | | | | | |
| 7.5 | | | | | | | | | | | | | | |
| 11 | 250 | 380 | | 226 | 358 | | 12.5 | 250 | 400 | | 226 | 378 | | 10 |
| 15 | | | | 240 | 460 | | 25 | | 400 | | 378 | | | |
| 18.5 | 340 | 480 | 255 | 240 | 460 | | 25 | 320 | 550 | 255 | 240 | 530 | | 10.5 |
| 22 | | | | 240 | 460 | | 30 | | | | | | | |
| 30 | 375 | 550 | 255 | 240 | 530 | | 30 | 355 | 740 | 270 | 275 | 595 | | 25 |
| 37 | | | | | | | 37 | | | | | | | 615 |
| 45 | 375 | 740 | 270 | 275 | 720 | | 46 | 530 | 750 | 285 | 430 | 720 | | 42 |
| 55 | | | | | | | 48 | | | | | | | 43 |
| 75 | 530 | 750 | 285 | 430 | 720 | | 70 | 530 | 750 | 285 | 430 | 720 | | 62 |
| 90 | 680 | 880 | 360 | 580 | 850 | 115 | 680 | 880 | 360 | 580 | 850 | 105 | | |

-  Larger than VG7
-  An adapter is required for replacement.
-  The control panel containing VG3 should be modified.

400V series

| Capacity (kW) | FRENIC5000 VG7S | | | | | Mounting method | Rough mass (kg) | FRENIC-VG | | | | | Mounting method | Rough mass (kg) | | | | | | | | | | | | |
|---------------|---------------------|--------|--------|-------------------------|---------|-----------------|-----------------|---------------------|--------|--------|-------------------------|---------|-----------------|-----------------|-----|------|------|-----|------|------|------|------|------|-----|------|------|
| | External dimensions | | | Installation dimensions | | | | External dimensions | | | Installation dimensions | | | | | | | | | | | | | | | |
| | W (mm) | H (mm) | D (mm) | W1 (mm) | H1 (mm) | | | W (mm) | H (mm) | D (mm) | W1 (mm) | H1 (mm) | | | | | | | | | | | | | | |
| 3.7 | 205 | 300 | 245 | 181 | 278 | Wall type | 8 | 205 | 300 | 245 | 181 | 278 | Wall type | 6 | | | | | | | | | | | | |
| 5.5 | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 7.5 | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 11 | 250 | 380 | 245 | 226 | 358 | | 12.5 | 250 | 400 | 245 | 226 | 378 | | 10 | | | | | | | | | | | | |
| 15 | | | | 240 | 460 | | | | | | | | | | 226 | 378 | | | | | | | | | | |
| 18.5 | 340 | 480 | 255 | 240 | 460 | | 25 | 320 | 550 | 255 | 240 | 530 | | | 25 | | | | | | | | | | | |
| 22 | | | | | | | | | | | | | | | | 275 | 530 | 25 | 26 | | | | | | | |
| 30 | 375 | 675 | 270 | 275 | 530 | | 40 | 355 | 675 | 270 | 275 | 655 | | | 31 | | | | | | | | | | | |
| 37 | | | | 275 | 655 | | | | | | | | | | | 41 | 720 | 42 | | | | | | | | |
| 45 | | | | 275 | 720 | | | | | | | | | | | | | | | | | | | | | |
| 55 | 530 | 740 | 315 | 430 | 710 | | 72 | 530 | 740 | 315 | 430 | 710 | | | 62 | | | | | | | | | | | |
| 75 | | | | | | | | | | | | | | | | 1000 | 360 | 580 | 970 | 100 | 680 | 1000 | 360 | 580 | 970 | 94 |
| 90 | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 110 | 680 | 1000 | 360 | 580 | 970 | | 150 | - | - | - | - | - | | 140 | | | | | | | | | | | | |
| 132 | | | | | | | | | | | | | | | 880 | 1400 | 450 | 780 | 1370 | 320 | 680 | 1400 | 440 | 580 | 1370 | 245 |
| 160 | 1000 | 1550 | 500 | 900 | 1520 | | 410 | 880 | 1400 | 440 | 780 | 1370 | | 330 | | | | | | | | | | | | |
| 200 | | | | | | | | | | | | | | | 525 | 1000 | 1550 | 500 | 900 | 1520 | 525 | 1000 | 1550 | 500 | 900 | 1520 |
| 220 | 630 | 1550 | 500 | 900 | 1520 | | 525 | 1000 | 1550 | 500 | 900 | 1520 | | 555 | | | | | | | | | | | | |
| 250 | | | | | | | | | | | | | | | 630 | 1550 | 500 | 900 | 1520 | 525 | 1000 | 1550 | 500 | 900 | 1520 | 555 |
| 280 | 630 | 1550 | 500 | 900 | 1520 | | 525 | 1000 | 1550 | 500 | 900 | 1520 | | 555 | | | | | | | | | | | | |
| 315 | | | | | | | | | | | | | | | 630 | 1550 | 500 | 900 | 1520 | 525 | 1000 | 1550 | 500 | 900 | 1520 | 555 |
| 355 | 630 | 1550 | 500 | 900 | 1520 | | 525 | 1000 | 1550 | 500 | 900 | 1520 | | 555 | | | | | | | | | | | | |
| 400 | | | | | | | | | | | | | | | 630 | 1550 | 500 | 900 | 1520 | 525 | 1000 | 1550 | 500 | 900 | 1520 | 555 |
| 500 | 630 | 1550 | 500 | 900 | 1520 | | 525 | 1000 | 1550 | 500 | 900 | 1520 | | 555 | | | | | | | | | | | | |
| 630 | | | | | | | | | | | | | | | 630 | 1550 | 500 | 900 | 1520 | 525 | 1000 | 1550 | 500 | 900 | 1520 | 555 |

- Larger than VG7
- An adapter is required for replacement.
- The control panel containing VG3 should be modified.

12.2.2 Replacing VG5S

200V series

| Capacity (kW) | FRENIC5000 VG5S | | | | | | FRENIC-VG | | | | | | | | | | | | |
|------------------|---------------------|--------|--------|-------------------------|---------|-----------------|-----------------|---------------------|--------|--------|-------------------------|---------|-----------------|-----------------|-----|-----|-----|-----|-----|
| | External dimensions | | | Installation dimensions | | Mounting method | Rough mass (kg) | External dimensions | | | Installation dimensions | | Mounting method | Rough mass (kg) | | | | | |
| | W (mm) | H (mm) | D (mm) | W1 (mm) | H1 (mm) | | | W (mm) | H (mm) | D (mm) | W1 (mm) | H1 (mm) | | | | | | | |
| 0.75 | 205 | 350 | 245 | 183 | 328 | Wall type | 10 | 205 | 300 | 245 | 181 | 278 | Wall type | 6 | | | | | |
| 1.5 | | | | | | | 10 | | | | | | | | | | | | |
| 2.2 | | | | | | | 10 | | | | | | | | | | | | |
| 3.7 | | | | | | | 10 | | | | | | | | | | | | |
| 5.5 | | | | | | | 11 | | | | | | | | | | | | |
| 7.5 | | | | | | | 11 | | | | | | | | | | | | |
| 11 | 255 | 440 | 255 | 233 | 418 | | 17 | 250 | 400 | 226 | 378 | 10 | | | | | | | |
| 15 | 320 | 480 | | 298 | 458 | | 25 | | | | | | | | | | | | |
| 18.5 | | | | | | | 25 | | | | | | | | | | | | |
| 22 | | | | | | | 25 | | | | | | | | | | | | |
| 30 | | | | | | | 340 | | | | | | | 550 | 240 | 530 | 36 | 320 | 550 |
| 37 | 375 | 615 | | 255 | 275 | | 595 | | | | | | | 45 | 355 | 615 | 275 | 595 | 32 |
| 45 | | 750 | 275 | | 730 | 58 | 740 | 270 | 275 | 720 | 42 | | | | | | | | |
| 55 | | | 270 | | 430 | 720 | | | | | 60 | 720 | 43 | | | | | | |
| 75 | 530 | 750 | 285 | 430 | 720 | 76 | 530 | 750 | 285 | 430 | 720 | 62 | | | | | | | |
| 90 | | | | | | 680 | 880 | 360 | 580 | 860 | Floor type | 141 | 680 | 880 | 360 | 580 | 850 | 105 | |

400V series

| Capacity (kW) | FRENIC5000 VG5S | | | | | | FRENIC-VG | | | | | | | | | | | | |
|------------------|---------------------|--------|--------|-------------------------|---------|-----------------|-----------------|---------------------|--------|--------|-------------------------|---------|-----------------|-----------------|-----|------|-----|-----|----|
| | External dimensions | | | Installation dimensions | | Mounting method | Rough mass (kg) | External dimensions | | | Installation dimensions | | Mounting method | Rough mass (kg) | | | | | |
| | W (mm) | H (mm) | D (mm) | W1 (mm) | H1 (mm) | | | W (mm) | H (mm) | D (mm) | W1 (mm) | H1 (mm) | | | | | | | |
| 3.7 | 205 | 350 | 245 | 183 | 328 | Wall type | 10 | 205 | 300 | 245 | 181 | 278 | Wall type | 6 | | | | | |
| 5.5 | | | | | | | 11 | | | | | | | | | | | | |
| 7.5 | | | | | | | 11 | | | | | | | | | | | | |
| 11 | 255 | 440 | 255 | 233 | 418 | | 17 | 250 | 400 | 226 | 378 | 10 | | | | | | | |
| 15 | | | | 320 | 480 | | 298 | | | | | | | 458 | 25 | | | | |
| 18.5 | | | | | | | | | | | | | | | 25 | | | | |
| 22 | | | | | | | | | | | | | | | 25 | | | | |
| 30 | 340 | 550 | 255 | 240 | 530 | | 35 | 320 | 550 | 255 | 240 | 530 | | 25 | | | | | |
| 37 | 375 | 675 | | 275 | 530 | | 36 | 355 | 615 | 270 | 275 | 595 | | 26 | | | | | |
| 45 | 375 | | | 430 | 645 | | 43 | | | | | 740 | | 315 | 430 | 655 | 31 | | |
| 55 | | | | 430 | 710 | | 53 | | | | | | | | | 655 | 33 | | |
| 75 | 530 | 740 | | 270 | 430 | | 710 | 60 | 530 | 740 | 315 | 430 | | 710 | 42 | | | | |
| 90 | | | | | | 86 | | 710 | | | | | 62 | | | | | | |
| 110 | | | 1000 | | | 360 | | 430 | | | | | 970 | | 116 | 1000 | 360 | 970 | 64 |
| 132 | | | | | | | | | | | | | | | 121 | | | | 94 |
| 160 | 680 | 1000 | 360 | 580 | 980 | 173 | 680 | 1000 | 360 | 580 | 980 | 98 | | | | | | | |
| 200 | | | | | | 173 | | | | | | 130 | | | | | | | |
| 220 | | | | | | Floor type | | | | | | 173 | 140 | | | | | | |

- Larger than VG5
- An adapter is required for replacement.
- The control panel containing VG3 should be modified.

12.2.3 Replacing VG3

200V series

| Capacity (kW) | FRENIC5000 VG3 | | | | | | FRENIC-VG | | | | | | | |
|---------------|---------------------|--------|--------|-------------------------|---------|-----------------|-----------------|---------------------|--------|--------|-------------------------|---------|-----------------|-----------------|
| | External dimensions | | | Installation dimensions | | Mounting method | Rough mass (kg) | External dimensions | | | Installation dimensions | | Mounting method | Rough mass (kg) |
| | W (mm) | H (mm) | D (mm) | W1 (mm) | H1 (mm) | | | W (mm) | H (mm) | D (mm) | W1 (mm) | H1 (mm) | | |
| 0.75 | 255 | 440 | 255 | 155 | 425 | Wall type | 14 | 205 | 300 | 245 | 181 | 278 | Wall type | 6 |
| 1.5 | | | | | | | | | | | | | | |
| 2.2 | | | | | | | | | | | | | | |
| 3.7 | | | | | | | | | | | | | | |
| 5.5 | | | | | | | | | | | | | | |
| 7.5 | 280 | 480 | 180 | 465 | 20 | | | | | | | | | |
| 11 | 320 | 480 | 220 | 460 | 24 | | | | | | | | | |
| 15 | | 520 | 220 | 500 | 27 | | | | | | | | | |
| 18.5 | 340 | 550 | 240 | 530 | 30 | | | | | | | | | |
| 22 | | | 275 | 596 | 40 | | | | | | | | | |
| 30 | 375 | 615 | 290 | 775 | 53 | 355 | 615 | 270 | 275 | 595 | | | | |
| 37 | 390 | 800 | 440 | 720 | 70 | 720 | | | | | | | | |
| 45 | | | 750 | 270 | 440 | | 720 | | | | | | | |
| 55 | 540 | 750 | 270 | 440 | 720 | 70 | 720 | | | | | | | |
| 75 | 850 | 880 | - | 750 | 855 | Floor type | 130 | 530 | 750 | 285 | 430 | 62 | | |
| 90 | - | - | - | - | - | - | - | 680 | 880 | 360 | 580 | 850 | 105 | |

400V series

| Capacity (kW) | FRENIC5000 VG3 | | | | | | FRENIC-VG | | | | | | | | | |
|---------------|---------------------|--------|--------|-------------------------|---------|-----------------|-----------------|---------------------|--------|--------|-------------------------|---------|-----------------|-----------------|-----|----|
| | External dimensions | | | Installation dimensions | | Mounting method | Rough mass (kg) | External dimensions | | | Installation dimensions | | Mounting method | Rough mass (kg) | | |
| | W (mm) | H (mm) | D (mm) | W1 (mm) | H1 (mm) | | | W (mm) | H (mm) | D (mm) | W1 (mm) | H1 (mm) | | | | |
| 3.7 | 280 | 440 | 255 | 180 | 425 | Wall type | 20 | 205 | 300 | 245 | 181 | 278 | Wall type | 6 | | |
| 5.5 | | 480 | | | | | | | | | | | | | 465 | 22 |
| 7.5 | | 220 | | | | | | | | | | | | | 500 | 27 |
| 11 | 320 | 520 | 240 | 530 | 30 | | | | | | | | | | | |
| 15 | | | 240 | 530 | 30 | | | | | | | | | | | |
| 18.5 | 340 | 550 | 275 | 596 | 35 | | 720 | | | | | | | | | |
| 22 | | | 275 | 596 | 35 | | | | | | | | | | | |
| 30 | 375 | 615 | 290 | 775 | 43 | | 320 | 550 | 255 | 240 | 530 | | | | | |
| 37 | | 675 | 270 | 275 | 595 | | | | | | | | | | | |
| 45 | 530 | 880 | 325 | 430 | 850 | | 85 | 355 | 615 | 270 | 275 | 595 | | | | |
| 55 | | | | | | 675 | 270 | 275 | 655 | | | | | | | |
| 75 | 530 | 880 | 325 | 430 | 850 | 95 | 740 | 315 | 430 | 710 | | | | | | |
| 90 | | | | | | 105 | | | | | | | | | | |
| 110 | 680 | 1050 | - | 580 | 1025 | Floor type | 135 | 530 | 1000 | 360 | 970 | | | | | |
| 132 | | | - | 750 | 170 | | | | | | | | | | | |
| 160 | 850 | 1050 | - | 750 | 1025 | Floor type | 170 | 680 | 1000 | 360 | 580 | | | | | |
| 200 | | | - | - | - | - | | | | | | | | | | |
| 220 | - | - | - | - | - | - | - | 680 | 1000 | 360 | 580 | 970 | | | | |

- Larger than VG3
- An adapter is required for replacement.
- The control panel containing VG3 should be modified.

12.3 Terminal Size

12.3.1 Replacing VG7S

Main circuit terminal (200V series)

| Capacity (kW) | FRENIC5000 VG7S | | | | | FRENIC-VG | | | | |
|------------------|-------------------------------|----------------------------------|-------------------|-----------|----------------|-------------------------------|----------------------------------|-------------------|-----------|----------------|
| | Terminal size and arrangement | | | | | Terminal size and arrangement | | | | |
| | Input LI/R, L2/S, L3/T | DC link DB, P1, P(+), N(-) | Output U, V, W | GRD* G | APS* R0, T0 | Input LI/R, L2/S, L3/T | DC link DB, P1, P(+), N(-) | Output U, V, W | GRD* G | APS* R0, T0 |
| 0.75 | M5 | M5 | M5 | M5 | M4 | M5 | M5 | M5 | M5 | M3.5 |
| 1.5 | | | | | | | | | | |
| 2.2 | | | | | | | | | | |
| 3.7 | | | | | | | | | | |
| 5.5 | M5 | M5 | M5 | M5 | | M6 | M6 | M6 | M6 | |
| 7.5 | | | | | | | | | | |
| 11 | M6 | M6 | M6 | M6 | | M6 | M6 | M6 | M6 | |
| 15 | | | | | | | | | | |
| 18.5 | | | | | | | | | | |
| 22 | | | | | | | | | | |
| | LI/R, L2/S, L3/T | P1, P(+), DB, N(-) | U, V, W | G | R0, T0 | LI/R, L2/S, L3/T | DB, P1, P(+), N(-) | U, V, W | G | R0, T0 |
| 30 | M10 | M10 | M10 | M8 | M4 | M10 | M10 | M10 | M8 | M3.5 |
| 37 | | | | | | | | | | |
| 45 | | | | | | | | | | |
| 55 | | | | | | | | | | |
| | LI/R, L2/S, L3/T | P1, P(+), N(-) | U, V, W | G | R0, T0 | LI/R, L2/S, L3/T | P1, P(+), N(-) | U, V, W | G | R0, T0 |
| 75 | M12 | M12 | M12 | M10 | M4 | M12 | M12 | M12 | M10 | M3.5 |
| 90 | | | | | | | | | | |

*GRD: Ground

*APS: Auxiliary power supply

Replacing

Main circuit terminal (400V series)

| Capacity (kW) | FRENIC5000 VG7S | | | | | FRENIC-VG | | | | | |
|---------------|-------------------------------|----------------------------------|-------------------|-----------|----------------|-------------------------------|----------------------------------|-------------------|-----------|----------------|------|
| | Terminal size and arrangement | | | | | Terminal size and arrangement | | | | | |
| | Input L1/R, L2/S, L3/T | DC link DB, P1, P(+), N(-) | Output U, V, W | GRD* G | APS* R0, T0 | Input L1/R, L2/S, L3/T | DC link DB, P1, P(+), N(-) | Output U, V, W | GRD* G | APS* R0, T0 | |
| 3.7 | M5 | M5 | M5 | M5 | M4 | M5 | M5 | M5 | M5 | M3.5 | |
| 5.5 | | | | | | | | | | | |
| 7.5 | | | | | | | | | | | |
| 11 | M6 | M6 | M6 | M6 | | M6 | M6 | M6 | M6 | | |
| 15 | | | | | | | | | | | |
| 18.5 | | | | | | | | | | | |
| 22 | | | | | | | | | | | |
| | R, S, T | P1, P(+), DB, N(-) | U, V, W | E(G) | R0, T0 | L1/R, L2/S, L3/T | DB, P1, P(+), N(-) | U, V, W | G | R0, T0 | |
| 30 | M8 | M8 | M8 | M8 | M4 | M8 | M8 | M8 | M8 | M3.5 | |
| 37 | | | | | | | | | | | |
| 45 | | | | | | | | | | | |
| 55 | | | | | | | | | | | |
| 75 | M10 | M10 | M10 | M10 | | M10 | M10 | M10 | M8 | | M3.5 |
| 90 | | | | | | | | | | | |
| 110 | | | | | | | | | | | |
| | L1/R, L2/S, L3/T | P1, P(+), N(-) | U, V, W | G | R0, T0 | L1/R, L2/S, L3/T | DB, P1, P(+), N(-) | U, V, W | G | R0, T0 | |
| 132 | M12 | M12 | M12 | M10 | M4 | M12 | M12 | M12 | M10 | M3.5 | |
| 160 | | | | | | | | | | | |
| | L1/R, L2/S, L3/T | P1, P(+), N(-) | U, V, W | G | R0, T0 | L1/R, L2/S, L3/T | P1, P(+), N(-) | U, V, W | G | R0, T0 | |
| 200 | M12 | M12 | M12 | M10 | M4 | M12 | M12 | M12 | M10 | M3.5 | |
| 220 | | | | | | | | | | | |
| 250 | | | | | | | | | | | |
| 280 | | | | | | | | | | | |
| 315 | | | | | | | | | | | |
| 355 | | | | | | | | | | | |
| 400 | | | | | | | | | | | |
| 500 | | | | | | | | | | | |
| 630 | | | | | | | | | | | |

*GRD: Ground

*APS: Auxiliary power supply

12.3.2 Replacing VG5S

Main circuit terminal (200V series)

| Capacity (kW) | FRENIC5000 VG5S | | | | | FRENIC-VG | | | | | | | | | | | | | | |
|------------------|-------------------------------|----------------------------------|-------------------|--------------|----------------|-------------------------------|----------------------------------|-------------------|-----------|---------------------|------|-------------------|---------|------|--------|------|-----------------------|---------|----|--------|
| | Terminal size and arrangement | | | | | Terminal size and arrangement | | | | | | | | | | | | | | |
| | Input R, S, T | DC link P1, P(+), DB, N(-) | Output U, V, W | GRD* E(G) | APS* R0, T0 | Input LI/R, L2/S, L3/T | DC link DB, P1, P(+), N(-) | Output U, V, W | GRD* G | APS* R0, T0 | | | | | | | | | | |
| 0.75 | M5 | M5 | M5 | M5 | M4 | M5 | M5 | M5 | M5 | M3.5 | | | | | | | | | | |
| 1.5 | | | | | | | | | | | | | | | | | | | | |
| 2.2 | | | | | | | | | | | | | | | | | | | | |
| 3.7 | | | | | | | | | | | | | | | | | | | | |
| 5.5 | | | | | | | | | | | | | | | | | | | | |
| 7.5 | | | | | | | | | | | | | | | | | | | | |
| 11 | M6 | M6 | M6 | M6 | | M6 | M6 | M6 | M6 | | M3.5 | | | | | | | | | |
| 15 | | | | | | | | | | | | | | | | | | | | |
| 18.5 | M8 | M8 | M8 | M8 | | | | | | | | M6 | M6 | M6 | M6 | M3.5 | | | | |
| 22 | | | | | | | | | | | | | | | | | | | | |
| | R, S, T | P1, P(+), DB, N(-) | U, V, W | E(G) | R0, T0 | | | | | LI/R, L2/S, L3/T | | | | | | | DB, P1, P(+), N(-) | U, V, W | G | R0, T0 |
| 30 | M8 | M8 | M8 | M8 | M4 | | | | | M8 | | | | | | | M8 | M8 | M8 | M3.5 |
| 37 | | | | | | | | | | | | | | | | | | | | |
| 45 | M10 | M10 | M10 | | | M8 | M4 | M10 | M10 | M10 | | | | | | | M8 | M3.5 | | |
| 55 | | | | | | | | | | | | | | | | | | | | |
| | R, S, T | P1, P(+), N(-) | U, V, W | | | | | E(G) | R0, T0 | LI/R, L2/S, L3/T | | P1, P(+), N(-) | U, V, W | G | R0, T0 | | | | | |
| 75 | M10 | M10 | M10 | | | | | M8 | M4 | M12 | M12 | M12 | M10 | M3.5 | | | | | | |
| 90 | M12 | M12 | M12 | M10 | | | | | | | | | | | | | | | | |

*GRD: Ground

*APS: Auxiliary power supply

Main circuit terminal (400V series)

| Capacity (kW) | FRENIC5000 VG5S | | | | | FRENIC-VG | | | | |
|---------------|-------------------------------|----------------------------------|-------------------|--------------|----------------|-------------------------------|----------------------------------|-------------------|-----------|----------------|
| | Terminal size and arrangement | | | | | Terminal size and arrangement | | | | |
| | Input R, S, T | DC link P1, P(+), DB, N(-) | Output U, V, W | GRD* E(G) | APS* R0, T0 | Input L1/R, L2/S, L3/T | DC link DB, P1, P(+), N(-) | Output U, V, W | GRD* G | APS* R0, T0 |
| 3.7 | M5 | M5 | M5 | M5 | M4 | M5 | M5 | M5 | M5 | M3.5 |
| 5.5 | | | | | | | | | | |
| 7.5 | | | | | | | | | | |
| 11 | M6 | M6 | M6 | M6 | | M6 | M6 | M6 | M6 | |
| 15 | | | | | | | | | | |
| 18.5 | M8 | M8 | M8 | M8 | | M8 | M8 | M8 | M8 | |
| 22 | | | | | | | | | | |
| | R, S, T | P1, P(+), DB, N(-) | U, V, W | E(G) | R0, T0 | L1/R, L2/S, L3/T | DB, P1, P(+), N(-) | U, V, W | G | R0, T0 |
| 30 | M8 | M8 | M8 | M8 | M4 | M8 | M8 | M8 | M8 | M3.5 |
| 37 | | | | | | | | | | |
| 45 | | | | | | | | | | |
| 55 | | | | | | | | | | |
| | R, S, T | DB, P1, P(+), N(-) | U, V, W | E(G) | R0, T0 | L1/R, L2/S, L3/T | DB, P1, P(+), N(-) | U, V, W | G | R0, T0 |
| 75 | M10 | M10 | M10 | M8 | M4 | M10 | M10 | M10 | M8 | M3.5 |
| 90 | | | | | | | | | | |
| 110 | | M10 (No DB terminal) | | | | | | | | |
| 132 | | | | | | | | | | |
| 160 | M12 | M12 (No DB terminal) | M12 | M10 | M12 | M12 | M12 | M12 | M10 | |
| | R, S, T | P1, P(+), N(-) | U, V, W | E(G) | R0, T0 | L1/R, L2/S, L3/T | P1, P(+), N(-) | U, V, W | G | R0, T0 |
| 200 | M12 | M12 | M12 | M10 | M4 | M12 | M12 | M12 | M10 | M3.5 |
| 220 | | | | | | | | | | |

*GRD: Ground

*APS: Auxiliary power supply

Control circuit terminal (Common to 200V series and 400V series)

| FRENIC5000 VG5S | FRENIC-VG |
|-----------------------------|-----------------------------|
| Common to all capacities M3 | Common to all capacities M3 |

12.3.3 Replacing VG3

Main circuit terminal (200V series)

| Capacity (kW) | FRENIC5000 VG3 | | | | | FRENIC-VG | | | | |
|------------------|----------------------------------|-------------------|---------------------|--------------|----------------|-------------------------------|----------------------------------|-------------------|-----------|----------------|
| | Terminal size and arrangement | | | | | Terminal size and arrangement | | | | |
| | Input R, S, T | Output U, V, W | DC link DB, P | GRD* E(G) | APS* R0, T0 | Input L1/R, L2/S, L3/T | DC link DB, P1, P(+), N(-) | Output U, V, W | GRD* G | APS* R0, T0 |
| 0.75 | M5 | M5 | M5 | M5 | M4 | M5 | M5 | M5 | M5 | M3.5 |
| 1.5 | | | | | | | | | | |
| 2.2 | | | | | | | | | | |
| 3.7 | | | | | | | | | | |
| 5.5 | | | | | | | | | | |
| 7.5 | | | | | | | | | | |
| 11 | M6 | M6 | M6 | M6 | M6 | M6 | M6 | M6 | M6 | |
| 15 | M8 | M8 | M8 | | | | | | | |
| 18.5 | M8 | M8 | M8 | | | | | | | |
| 22 | R, S, T | U, V, W | DB, P1, P | E(G) | R0, T0 | | | | | |
| | M8 | M8 | M8 | M6 | M4 | M6 | M6 | M6 | M6 | M3.5 |
| | R, S, T | U, V, W | DB, P1, P | E(G) | R0, T0 | L1/R, L2/S, L3/T | DB, P1, P(+), N(-) | U, V, W | G | R0, T0 |
| 30 | M8 | M8 | M8 | M8 | M4 | M8 | M8 | M8 | M8 | M3.5 |
| 37 | M10 | M10 | M10 | | | | | | | |
| 45 | | | | | | | | | | |
| 55 | | | | | | | | | | |
| | Input/Output R, U, S, V, T, W | | DC link N, P1, P | GRD* E(G) | APS* R0, T0 | Input L1/R, L2/S, L3/T | DC link P1, P(+), N(-) | Output U, V, W | GRD* G | APS* R0, T0 |
| 75 | M12 | M12 | M12 | M10 | M4 | M12 | M12 | M12 | M10 | M3.5 |
| 90 | | | | | | | | | | |

*GRD: Ground

*APS: Auxiliary power supply

Main circuit terminal (400V series)

| Capacity (kW) | FRENIC5000 VG3 | | | | | FRENIC-VG | | | | |
|---------------|----------------------------------|-----------------------|---------------------|--------------|----------------|-------------------------------|----------------------------------|-------------------|-----------|----------------|
| | Terminal size and arrangement | | | | | Terminal size and arrangement | | | | |
| | Input R, S, T | Output U, V, W | DC link DB, P | GRD* E(G) | APS* R0, T0 | Input L1/R, L2/S, L3/T | DC link DB, P1, P(+), N(-) | Output U, V, W | GRD* G | APS* R0, T0 |
| 3.7 | M4 | M4 | M4 | M4 | M4 | M5 | M5 | M5 | M5 | M3.5 |
| 5.5 | | | | | | | | | | |
| 7.5 | M5 | M5 | M5 | M5 | | M6 | M6 | M6 | M6 | |
| 11 | | | | | | | | | | |
| 15 | | | | | | | | | | |
| 18.5 | M6 | M6 | M6 | M6 | | | | | | |
| 22 | R, S, T | U, V, W | DB, P1, P | E(G) | R0, T0 | | | | | |
| | M6 | M6 | M6 | M6 | M4 | M6 | M6 | M6 | M6 | M3.5 |
| | R, S, T | P1, P(+), DB, N(-) | U, V, W | E(G) | R0, T0 | L1/R, L2/S, L3/T | DB, P1, P(+), N(-) | U, V, W | G | R0, T0 |
| 30 | M8 | M8 | M8 | M8 | M4 | M8 | M8 | M8 | M8 | M3.5 |
| 37 | | | | | | | | | | |
| 45 | | | | | | | | | | |
| 55 | | | | | | | | | | |
| 75 | M10 | M10 | M10 | | | M10 | M10 | M10 | M10 | |
| 90 | | | | | | | | | | |
| 110 | | | | | | | | | | |
| | Input/Output R, U, S, V, T, W | | DC link N, P1, P | GRD* E(G) | APS* R0, T0 | L1/R, L2/S, L3/T | DB, P1, P(+), N(-) | U, V, W | G | R0, T0 |
| 132 | M12 | | M12 | M10 | M4 | M12 | M12 | M12 | M10 | M3.5 |
| 160 | | | | | | | | | | |
| 200 | | | | | | | M12 (No DB terminal) | | | |
| 220 | - | - | | - | - | | | | | |

*GRD: Ground

*APS: Auxiliary power supply

Control circuit terminal (Common to 200V series and 400V series)

| FRENIC5000 VG3 | FRENIC-VG |
|-----------------------------|-----------------------------|
| Common to all capacities M3 | Common to all capacities M3 |

12.4 Terminal Symbols

12.4.1 Replacing VG7S

Since the terminal symbols for FRENIC-VG are the same as those for VG7S (excepting for I/O of RS-485 communications), the same connections as the terminal connections of VG7S are available.

| Category | FRENIC5000 VG7S | | FRENIC-VG | |
|----------------|--------------------------------------|---|-----------------|------------------------------|
| | Terminal symbol | Terminal name | Terminal symbol | Terminal name |
| Communications | RX(+), RX(-), TX(+), TX(-), SD | I/O of RS-485 communications (Dedicated connector) | DX(+), DX(-) | I/O of RS-485 communications |

12.4.2 Replacing VG5S

| Category | FRENIC5000 VG5S | | FRENIC-VG | |
|---------------|-------------------------------|---------------------------------------|---------------------------------|---------------------------------------|
| | Terminal symbol | Terminal name | Terminal symbol | Terminal name |
| Main circuit | R, S, T | Power input | L1/R, L2/S, L3/T | Power input |
| | U, V, W | Inverter output | U, V, W | Inverter output |
| | P1, P(+) | Connects a DC REACTOR | P1, P(+) | Connects a DC REACTOR |
| | P(+), N(-) | Connects a braking unit | P(+), N(-) | Connects a braking unit |
| | P(+), DB | Connects an external braking resistor | P(+), DB | Connects an external braking resistor |
| | E(G) | To ground the inverter | G | To ground the inverter |
| | R0, T0 | Auxiliary control power supply | R0, T0 | Auxiliary control power supply |
| Analog input | 13 | Power supply for potentiometer | 13 | Power supply for potentiometer |
| | 12 | Voltage input for speed setting | 12 | Voltage input for speed setting |
| | 11 | Analog input common | 11 | Analog input common |
| | Ai1 | Analog input 1 | Ai1 | Analog input 1 |
| | Ai2 | Analog input 2 | Ai2 | Analog input 2 |
| | [AOFF] | Input signal off | [OFF] | Input signal off |
| | [AAS1] | Auxiliary speed setting 1 | [AUX-N1] | Auxiliary speed setting 1 |
| | [AAS2] | Auxiliary speed setting 2 | [AUX-N2] | Auxiliary speed setting 2 |
| | [ATL1] | Torque limiter (level 1) | [TL-REF1] | Torque limiter (level 1) |
| | [ATL2] | Torque limiter (level 2) | [TL-REF2] | Torque limiter (level 2) |
| | [ATBS] | Torque bias | [TB-REF] | Torque bias |
| | [ATS] | Torque command (before limit) | [T-REF] | Torque command (before limit) |
| | [ATCS] | Torque current command | [IT-REF] | Torque current command |
| | [AJSS1] | Creep speed 1 | [CRP-N1] | Creep speed 1 |
| | [AJSS2] | Creep speed 2 | [CRP-N2] | Creep speed 2 |
| | [AFLUX] | Magnetic-flux command | [MF-REF] | Magnetic-flux command |
| | [ASFB] | Speed feedback | [LINE-N] | Line speed detection |
| | [AMTMP] | Motor temperature | [M-TMP] | Motor temperature |
| | [ASOR] | Speed override | [N-OR] | Speed override |
| | M | Analog input common | M | Analog input common |
| Digital input | FWD | Forward operation · stop command | FWD | Forward operation · stop command |
| | REV | Reverse operation · stop command | REV | Reverse operation · stop command |
| | X1 | Digital input 1 | X1 | Digital input 1 |
| | X2 | Digital input 2 | X2 | Digital input 2 |
| | X3 | Digital input 3 | X3 | Digital input 3 |
| | X4 | Digital input 4 | X4 | Digital input 4 |
| | X5 | Digital input 5 | X5 | Digital input 5 |
| | | | X6 | Digital input 6 |
| | | | X7 | Digital input 7 |
| | | | X8 | Digital input 8 |
| | | | X9 | Digital input 9 |
| | [COPC] | Operation command switch over | | |
| | [CSRМ] | Speed setting value switch over | [N2/N1] | Speed setting N2/N1 |
| | [CMCS] | Coast-to-stop command | [BX] | Coast-to-stop command |
| | [CPEX] | Pre-exciting command | [EXITE] | Pre-exciting command |
| | [CHLD] | Operation signal hold | [HLD] | Operation signal hold |
| | [CSR1] | Multistep speed selection 1 | [SS1] | Multistep speed selection 1 |
| [CSR2] | Multistep speed selection 2 | [SS2] | Multistep speed selection 2 | |
| [CSR4] | Multistep speed selection 4 | [SS4] | Multistep speed selection 4 | |
| [CUP] | ACC command in UP/DOWN setter | [UP] | UP command in UP/DOWN setting | |
| [CDOWN] | DEC command in UP/DOWN setter | [DOWN] | DOWN command in UP/DOWN setting | |

| Category | FRENIC5000 VG5S | | FRENIC-VG | |
|---------------|---|--------------------------------------|-----------------|--|
| | Terminal symbol | Terminal name | Terminal symbol | Terminal name |
| Digital input | [CCLR] | Zero clear command in UP/DOWN setter | [CLR] | ACC/DEC zero clear command |
| | [CJSC] | Creep switch | [CRP-N2/N1] | Creep speed switching in UP/DOWN setting |
| | [CSUC] | ACC/DEC · UP/DOWN switch | [N2/N1] | Speed setting N2/N1 |
| | [CSRL] | Speed reference limiter | [N-LIM] | Speed command cancel |
| | [CSTC] | Speed control/Torque limiter switch | [H41-CCL] | H41[torque command] cancel |
| | [CTL] | Torque limiter | [F40-CC1] | F40 [torque limiter mode] cancel |
| | [CADT] | ACC/DEC time selection | [RT1][RT2] | ASR, ACC/DEC selection |
| | [CADB] | ACC/DEC time bypass | [BPS] | Bypass |
| | [CTB1] | Torque bias command 1 | [TB1] | Torque bias command 1 |
| | [CTB2] | Torque bias command 2 | [TB2] | Torque bias command 2 |
| | [CDRP] | Droop function | [DROOP] | Droop selection |
| | [CPI] | ASR PI switch | [RT1][RT2] | ASR, ACC/DEC selection |
| | [CPPI] | ASR P/PI switch | [RT1][RT2] | ASR, ACC/DEC selection |
| | [CAI1Z] | Ai1-ACC/DEC zero hold | [ZH-Ai1] | Ai1 zero hold |
| | [CAI2Z] | Ai2-ACC/DEC zero hold | [ZH-Ai2] | Ai2 zero hold |
| | [CSAD] | Analog/Digital switch (speed) | [N2/N1] | Speed setting N2/N1 |
| | [CTAD] | Analog/Digital switch (torque) | [H41-CCL] | H41[torque command]cancel |
| | [CDILS] | Di card input latch signal (speed) | [DIA] | DiA card input latch signal |
| | [CDILT] | Di card input latch signal (torque) | [DIB] | DiB card input latch signal |
| | [CTEN] | T-Link enable | [LE], [WE-LK] | Operation selection through link, Write enable command through link |
| | [CTDI] | DI command for transmission | [U-DI] | Universal DI |
| | [CREN] | RS485 enable | [LE], [WE-LK] | Operation selection through link, Write enable command through link |
| | RST | Alarm reset | [RST] | Alarm reset |
| | THR | External alarm | [THR] | External alarm |
| | - | | PLC | PLC signal power supply |
| | CM | Digital input common | CM | Digital input common |
| Analog output | Ao1 | Analog output 1 | Ao1 | Analog output 1 |
| | Ao2 | Analog output 2 | Ao2 | Analog output 2 |
| | Ao3 | Analog output 3 | Ao3 | Analog output 3 |
| | [BSM1] | Speedometer (one-way deflection) | [N-FB1+] | Speed detection (Speedometer, one-way deflection) |
| | [BSM2] | Speedometer (two-way deflection) | [N-FB1±] | Speed detection (Speedometer, two-way deflection) |
| | [BSR0] | Speed setting 0 | [N-REF2] | Speed setting 2 (before ACC/DEC calculation) |
| | [BSR1] | Speed setting 1 | [N-REF4] | Speed setting 4 (ASR input) |
| | [BSR2] | Speed setting 2 | [N-REF4] | Speed setting 4 (ASR input) |
| | [BSR] | Speed setting | [N-REF4] | Speed setting 4 (ASR input) |
| | [BSFB] | Speed feedback | [N-FB2±] | Speed detection (ASR input) |
| | [BTC1] | Torque ammeter (two-way deflection) | [IT-REF±] | Torque current command (torque ammeter, two-way deflection) |
| | [BTC2] | Torque ammeter (one-way deflection) | [IT-REF+] | Torque current command (torque ammeter, one-way deflection) |
| | [BTM1] | Torque meter (two-way deflection) | [T-REF±] | Torque command (torque meter, two-way deflection) |
| | [BTM2] | Torque meter (one-way deflection) | [T-REF+] | Torque command (torque meter, one-way deflection) |
| | [BTR] | Torque command output | [T-REF±] | Torque command (torque meter, two-way deflection) |
| [BMC] | Effective detected value of motor current | [I-AC] | Motor current | |

| Category | FRENIC5000 VG5S | | FRENIC-VG | | |
|-----------------------|-----------------|---|----------------------------|---|----------------------------|
| | Terminal symbol | Terminal name | Terminal symbol | Terminal name | |
| Analog output | [BMV] | Effective detected value of motor voltage | [V-AC] | Motor voltage | |
| | [BMTMP] | Motor temperature detected value | [TMP-M] | Motor temperature | |
| | [BVDC] | Main circuit DC voltage | [V-DC] | DC link circuit voltage | |
| | M | Analog output common | M | Analog output common | |
| Transistor output | Y1 | Digital output 1 | Y1 | Digital output 1 | |
| | Y2 | Digital output 2 | Y2 | Digital output 2 | |
| | Y3 | Digital output 3 | Y3 | Digital output 3 | |
| | – | | Y4 | Digital output 4 | |
| | [DVDC] | Establishment of main circuit DC voltage | [RDY] | Ready for operation | |
| | [DRUN] | Running | [RUN] | Running | |
| | [DACC] | Accelerating | [U-ACC] | Accelerating | |
| | [DDEC] | Decelerating | [U-DEC] | Decelerating | |
| | [DNZS] | Speed existence | [N-EX] | Speed existence | |
| | [DSAR] | Arrival at the preset speed | [N-AR] | Arrival at the preset speed | |
| | [DSAG] | Speed agreement | [N-AG1] | Speed agreement | |
| | [DSD1] | Speed detection | [N-DT1] | Speed detection 1 | |
| | [DSD2] | Speed detection | [N-DT2] | Speed detection 2 | |
| | [DSD3] | Speed detection | [N-DT3] | Speed detection 3 | |
| | [DTLM] | Torque limiting | [TL] | Torque limiting | |
| | [DTD] | Torque detection | [T-DT1] | Torque detection | |
| | [DOL] | Inverter overload early warning | [INV-OL] | Inverter overload early warning | |
| | [DMOH] | Motor temperature overheat early warning | [M-OH] | Motor temperature overheat early warning | |
| | [DMOL] | Motor overload early warning | [M-OL] | Motor overload early warning | |
| | [DBRS] | Brake release signal | [BRK] | Brake release signal | |
| | [DBRK] | Braking | [B/D] | Torque polarity detection | |
| | [DTDO] | DO for transmission | [U-DO] | Universal DO | |
| | [DTER] | Transmission error | [LK-ERR] | Transmission error | |
| | [DSYN] | Synchronizing | [SY-C] | Synchronization control completion | |
| | | CME | Digital output common | CMY | Digital output common |
| | Relay output | RYA, RYC | Relay output | Y5A, Y5C | Relay output |
| | | 30A, 30B, 30C | Alarm output for any fault | 30A, 30B, 30C | Alarm output for any fault |
| Communication | DXA, DXB | RS-485 communication input/output | DX(+),DX(-) | RS-485 communication input/output | |
| Speed detection | PA, PB | Encoder A- and B-phase signals | PA, PB | Pulse generator 2-phase signal inputs | |
| | PGP, PGM | Encoder power supply | PGP, PGM | Pulse generator power supply | |
| | FA, FB | Encoder A- and B-phase outputs | FA, FB | Pulse generator outputs | |
| | CM | Common to encoder outputs | CM | Common to pulse generator outputs | |
| Temperature detection | TH1 | Connects a motor thermistor | TH1 | Connects a motor thermistor (Motor temperature can be detected with NTC, PTC thermistors) | |
| | THC | Common to motor thermistor | THC | Common to motor thermistor | |
| Option power supply | P24 | Power supply to option (□24V) | – | Utilize the power supply on the market. | |
| | M24 | Common terminal to □24V | – | | |
| | P15 | Power supply for option (+15V) | – | | |
| | (M) | Common terminal to ±15V | – | | |
| | N15 | Power supply to option (-15V) | – | | |

12.4.3 Replacing VG3

| Category | FRENIC5000 VG3 | | FRENIC-VG | |
|---------------|---|--|-------------------------------------|---------------------------------------|
| | Terminal symbol | Terminal name | Terminal symbol | Terminal name |
| Main circuit | R, S, T | Power input | L1/R, L2/S, L3/T | Power input |
| | U, V, W | Inverter output | U, V, W | Inverter output |
| | P, DB | Connects an external braking resistor | P(+), DB | Connects an external braking resistor |
| | P, N | Connects a braking unit | P(+), N(-) | Connects a braking unit |
| | P, P1 | Connects a DC REACTOR | P(+), P1 | Connects a DC REACTOR |
| | P, N1 | Connects a backup condenser | P(+), N(-) | Connects a backup condenser |
| | E(G) | To ground the inverter | G | To ground the inverter |
| | R0, T0 | Auxiliary control power supply | R0, T0 | Auxiliary control power supply |
| Analog input | 11 | Common to analog input | 11 | Common to analog input |
| | 13 | Power supply for potentiometer | 13 | Power supply for potentiometer |
| | 12 | Speed setting voltage input | 12 | Speed setting voltage input |
| | M | Common to analog input | M | Common to analog input |
| | Ai1 | Analog input 1 | Ai1 | Analog input 1 |
| | Ai2 | Analog input 2 | Ai2 | Analog input 2 |
| | [AV2] | Auxiliary speed setting 2 | [AUX-N1] | Auxiliary speed setting 1 |
| | [AV3] | Auxiliary speed setting 3 | [AUX-N2] | Auxiliary speed setting 2 |
| | [ATL1] | Torque limiter value 1 / Torque bias command value 1 | [TL-REF1] | Torque limiter (level 1) |
| | [ATL2] | Torque limiter value 2 / Torque bias command value 2 | [TL-REF2] | Torque limiter (level 2) |
| | [ATL3] | Torque limiter value 3 / Torque bias command value 3 | – | – |
| | [ATL4] | Torque limiter value 4 | – | – |
| | [ATIN] | Torque command input | [T-REF] | Torque command (before limit) |
| | [ATR] | Torque command | | |
| | [AFAI] | Magnetic-flux command input | [MF-REF] | Magnetic-flux command |
| | [ANFI] | Speed feedback input | [LINE-N] | Speed override |
| | [ANJF] | Creep setting value in UP/DOWN setter | [CRP-N1] | Creep speed 1 |
| | | | [CRP-N2] | Creep speed 2 |
| | [ATM] | Motor temperature input | [M-TMP] | Motor temperature |
| V1 | Voltage input for auxiliary speed setting | [AUX-N1] | Auxiliary speed setting 1 | |
| Digital input | CM | Digital input common | CM | Digital input common |
| | FWD | Forward operation · stop command | FWD | Forward operation · stop command |
| | REV | Reverse operation · stop command | REV | Reverse operation · stop command |
| | X1 | Digital input 1 | X1 | Digital input 1 |
| | X2 | Digital input 2 | X2 | Digital input 2 |
| | X3 | Digital input 3 | X3 | Digital input 3 |
| | X4 | Digital input 4 | X4 | Digital input 4 |
| | X5 | Digital input 5 | X5 | Digital input 5 |
| | | | X6 | Digital input 6 |
| | | | X7 | Digital input 7 |
| | | | X8 | Digital input 8 |
| | | | X9 | Digital input 9 |
| | [CNR1] | Multistep speed setting selection 1 | [SS1] | Multistep speed setting selection 1 |
| [CNR2] | Multistep speed setting selection 2 | [SS2] | Multistep speed setting selection 2 | |
| [CNR4] | Multistep speed setting selection 4 | [SS4] | Multistep speed setting selection 4 | |

| Category | FRENIC5000 VG3 | | FRENIC-VG | | |
|---------------|-------------------------|--|--|--|-----------------|
| | Terminal symbol | Terminal name | Terminal symbol | Terminal name | |
| Digital input | [CUP] | ACC command in UP/DOWN setter | [UP] | UP command in UP/DOWN setting | |
| | [CDWN] | DEC command in UP/DOWN setter | [DOWN] | DOWN command in UP/DOWN setting | |
| | [CCLR] | Clear command in UP/DOWN setter | [CLR] | ACC/DEC zero clear command | |
| | [CBSS] | Soft start · stop bypass | [BPS] | Bypass | |
| | [CRT] | Soft start · stop time switch | [RT1] | ASR,ACC/DEC selection | |
| | [CNL] | Reverse rotation lock command | H08 | Reverse rotation lock | |
| | [CPI] | ASR PI switch | [RT1][RT2] | ASR,ACC/DEC selection | |
| | [CPPI] | ASR P/PI switch | [RT1][RT2] | ASR,ACC/DEC selection | |
| | [CSTC] | Speed control/Torque control switch | [H41-CCL] | H41 [Torque command] cancel | |
| | [CDRP] | Droop function | [DROOP] | Droop selection | |
| | [CTL] | Torque limiter | [F40-CCL] | F40 (Torque limiter mode) cancel | |
| | [CTB1] | Torque bias command 1 | [TB1] | Torque bias command 1 | |
| | [CTB2] | Torque bias command 2 | [TB2] | Torque bias command 2 | |
| | [CPOS] | Simplified position control command | – | – | |
| | RST | Alarm reset | [RST] | Alarm reset | |
| | THR | External alarm | [THR] | External alarm | |
| | EXT | Pre-exciting command | [EXITE] | Pre-exciting command | |
| | – | | PLC | PLC signal power supply | |
| | Analog output | Ao | Analog output | Ao1 | Analog output 1 |
| | | | | Ao2 | Analog output 2 |
| | | | Ao3 | Analog output 3 | |
| [BNF0] | | Speed feedback output 0 | [N-FB1+] | Speedometer one-way deflection | |
| [BNR0] | | Speed setting 0 | [N-REF2] | Speed setting 2 | |
| [BNR1] | | Speed setting 1 | [N-REF4] | Speed setting 4 | |
| [BNR2] | | Speed setting 2 | [N-REF4] | Speed setting 4 | |
| [BT0] | | Torque command output 0 | [T-REF±] | Torque meter two-way deflection | |
| [BT1] | | Torque command output 1 | [T-REF±] | Torque meter two-way deflection | |
| [BIT] | | Torque current command | [IT-REF±] | Torque ammeter two-way deflection | |
| [BNR] | | Speed setting | [N-REF4] | Speed setting 4 | |
| [BNA] | | Speed feedback | [N-FB2±] | Speed detection | |
| [BNAB] | | Speed feedback absolute value | [N-FB1+] | Speedometer one-way deflection | |
| [BTAB] | | Torque command output absolute value | [T-REF+] | Torque meter one-way deflection | |
| [BITAB] | | Torque current command output absolute value | [IT-REF+] | Torque ammeter one-way deflection | |
| [BIM] | | Motor current detected value | [I-AC] | Motor current | |
| LM | | For load meter | [IT-REF±] | Torque current command (torque ammeter two-way deflection) | |
| | | | [IT-REF+] | Torque current command (torque ammeter one-way deflection) | |
| | | | [T-REF±] | Torque command (torque meter two-way deflection) | |
| | | | [T-REF+] | Torque command (torque meter one-way deflection) | |
| SM | For speedometer | [N-FB1+] | Speed detection (speedometer one-way deflection) | | |
| | | [N-FB1±] | Speed detection (speedometer two-way deflection) | | |
| M | Common to analog output | M | Common to analog output | | |

| Category | FRENIC5000 VG3 | | FRENIC-VG | |
|-----------------------|-----------------|--|-----------------|---|
| | Terminal symbol | Terminal name | Terminal symbol | Terminal name |
| Transistor output | Y1 | Digital output 1 | Y1 | Digital output 1 |
| | Y2 | Digital output 2 | Y2 | Digital output 2 |
| | Y3 | Digital output 3 | Y3 | Digital output 3 |
| | – | | Y4 | Digital output 4 |
| | [DUV] | Establishment of link voltage (undervoltage) | [RDY] | Ready for operation |
| | [DZS] | Speed existence (zero speed) | [N-EX] | Speed existence |
| Transistor output | [DSAR] | Arrival at the preset speed | [N-AR] | Arrival at the preset speed |
| | [DSAG] | Speed agreement | [N-AG] | Speed agreement |
| | [DSDA] | Arbitrary speed (absolute value) | [N-DT1] | Speed detection 1 |
| | [DSDP] | Arbitrary speed (with polarity) | [N-DT2] | Speed detection 2 |
| | [DTLM] | Torque limiting | [TL] | Torque limiting |
| | [DTDT] | Torque detection | [T-DT1] | Torque detection 1 |
| | [DAX] | Inverter running | [RUN] | Inverter running |
| | [DACC] | Accelerating | [U-ACC] | Accelerating |
| | [DDEC] | Decelerating | [U-DEC] | Decelerating |
| | [DOL] | Inverter overload early warning | [INV-OL] | Inverter overload early warning |
| | [DOLM] | Motor temperature overheat early warning | [M-OH] | Motor temperature overheat early warning |
| | [DTY4] | Transmission data Y4 | [U-DO] | Universal DO |
| | [DTY5] | Transmission data Y5 | | |
| | [DTFT] | Transmission data error | [LK-ERR] | Transmission error |
| | CME | Digital output common | CMY | Digital output common |
| Relay output | RYA, RYC | Relay output | Y5A, Y5C | Relay output |
| | 30A, 30B, 30C | Alarm output for any fault | 30A, 30B, 30C | Alarm output for any fault |
| | RYA, RYC | Relay output | Y5A, Y5C | Relay output |
| | 30A, 30B, 30C | Alarm output for any fault | 30A, 30B, 30C | Alarm output for any fault |
| Speed detection | PA, PB | Pulse encoder phase signals | PA, PB | Pulse generator 2-phase signal inputs |
| | PGP, PGM | Pulse encoder power supply | PGP, PGM | Pulse generator power supply |
| Temperature detection | THT | Connects motor thermistor | TH1 | Connects motor thermistor (Motor temperature can be detected with the NTC and the PTC thermistors). |
| | THC | Common to motor thermistor | THC | Common to motor thermistor |
| Option power supply | P24 | Power supply for option (+24V) | – | Please utilize the power supply on the market. |
| | M24 | For +24V common | – | |
| | P15 | Power supply for option (+15V) | – | |
| | (M) | For ±15V common | – | |
| | N15 | Power supply for option (□15V) | – | |

12.5 Function Codes

12.5.1 Replacing VG7S

Since the FRENIC-VG's function codes are compatible with the VG7S's ones, the function code values for the VG7S can apply to the same function codes of the FRENIC-VG.

Function codes newly added to the FRENIC-VG are VG7S compatible by default, so no setting modification is required. Note that the functions listed below are assigned to different function codes.

- 3rd motor parameters exclusive to V/f control
(For the function code settings, refer to Chapter 4.)

| FRENIC5000 VG7S | | FRENIC-VG | |
|-----------------|---|----------------|---|
| Function Codes | Name | Function Codes | Name |
| - | - | A101 | M3 control system (*1) |
| A35 | M3 motor rated capacity | A102 | M3 motor rated capacity |
| A36 | M3 motor rated current | A103 | M3 motor rated current |
| A37 | M3 rated voltage | A104 | M3 rated voltage |
| A38 | M3 highest output voltage | A153 | M3 highest output voltage |
| A39 | M3 rated speed | A105 | M3 rated speed |
| A40 | M3 maximum speed | A106 | M3 maximum speed |
| A41 | M3 motor pole | A107 | M3 motor pole |
| A42 | M3 %R1 | A108 | M3 %R1 |
| A43 | M3 %X | A109 | M3 %X |
| A44 | M3 exciting current | A110 | M3 exciting current |
| A45 | M3 slip compensation amount | A154 | M3 slip compensation amount |
| A46 | M3 torque boost (*2) | A155 | M3 torque boost (*2) |
| A47 | M3 thermistor selection | A131 | M3 thermistor selection |
| A48 | M3 electronic thermal (operation selection) | A132 | M3 electronic thermal (operation selection) |
| A49 | M3 electronic thermal (operation level) | A133 | M3 electronic thermal (operation level) |
| A50 | M3 electronic thermal (thermal time constant) | A134 | M3 electronic thermal (thermal time constant) |

(*1) The V/f control is performed when the function code A101 is set to "5."

(*2) When the inverter capacity is 22 kW or less with the torque boost set to 2.0 to 20.0, make the settings according to the conversion table below.

Torque boost conversion table (22 kW or below)

| FRENIC5000 VG7S A46 | FRENIC-VG P35, A55, A155 | Remarks |
|---|---|---|
| 2.0 | 2.0 | Use the following expression for conversion. * Expression When the A46 data of VG7S is 2.0 to 20.0, VG setting (P35, A55, A155) = $(100 \times [\text{A46 data of VG7S}] + 200) \div 200$ |
| 4.0 | 3.0 | |
| 6.0 | 4.0 | |
| 8.0 | 5.0 | |
| 10.0 | 6.0 | |
| 12.0 | 7.0 | |
| 14.0 | 8.0 | |
| 16.0 | 9.0 | |
| 18.0 | 10.0 | |
| 20.0 (Equivalent to 10% of rated voltage) | 11.0 (Equivalent to 10% of rated voltage) | |

■ ASR1-I (Integral constant)

The definition for the ASR-P control (Integration cancel) differs as shown below.

| FRENIC5000 VG7S | | FRENIC-VG | |
|-----------------|---|---------------|--|
| Function code | Data setting range | Function code | Data setting range |
| F62 | 0.000 to 1.000 s When F62 = 1.000, P control is enabled. | F62 | 0.000 to 10.000 s When F62 = 0.000, P control is enabled. |

■ M1 magnetic pole position offset (exclusive to PMSM)

The definition of function code o10 (M1 magnetic pole position offset) differs as shown below.

Convert the offset, referring to the example given below.

Conversion example

When VG7S function code o10 = 3A7Fh

① From hexadecimal to decimal form: 3A7F (hex.) → 14975 (decimal)

② Conversion for FRENIC-VG: $360^\circ \times 14975/65535 = 82.3^\circ$ (Rounded to one decimal place)

| FRENIC5000 VG7S | | FRENIC-VG | |
|-----------------|-----------------------------------|---------------|---|
| Function code | Data setting range | Function code | Data setting range |
| o10 | 0000 to FFFF (0° to 360°, CCW) | o10 | 0.0 to 359.9 (Unit: degree (°), CCW) |

■ Multiplex system station address setting

While the VG7S uses the hardware switch (SW1) provided on the option card OPC-VG7-SI to set the multiplex system station address, the FRENIC-VG uses function code o50 as shown below.

| FRENIC5000 VG7S | | FRENIC-VG | |
|-------------------------|---|-------------------------|----------------------------|
| Station address setting | Data setting range | Station address setting | Data setting range |
| OPC-VG7-SI SW1 | 0: Master 1 to 5: Slave 6 to 9: Disable | Function code o50 | 0: Master 1 to 5: Slave |

■ PG wire break alarm activation

The FRENIC-VG causes an alarm \overline{PG} if the PG power wire breaks. When an isolated signal conditioner is used in the PG wiring, disable the alarm activation function. (Refer to Chapter 8, Section 8.7 "PG Amplifier (Isolated signal conditioner).")

| FRENIC5000 VG7S | | FRENIC-VG | |
|-----------------|--------------------|---|-------------------------|
| Activation | Data setting range | Activation | Data setting range |
| - | - | Function code H104: thousand's digit | 0: Disable 1: Enable |

■ M1-M3 PTC Activation Level



The PTC detection internal circuit of the FRENIC-VG differs from that of the VG7S; therefore, the definition of function code E32 (M1-M3 PTC activation level) also differs.

To connect the PTC used in the VG7S to the FRENIC-VG, convert the activation level, referring to the example given below.

Conversion example

When VG7S function code E32 = 3.00 (V)

Conversion for FRENIC-VG: $3.00 \times 5/9 = 1.68$ (Rounded to two decimal places)



Set R_p under the following condition.

$$R_{p1} < R_p < R_{p2}$$

To determine R_p easily, use the following expression.

$$R_p (\Omega) = (R_{p1} + R_{p2}) / 2$$

12.5.2 Replacing VG5S

| FRENIC5000 VG5S | | FRENIC-VG | |
|-----------------|--|----------------|---|
| Function Codes | Name | Function Codes | Name |
| 01 | Speed setting | F01 | Speed setting N1 |
| 02 | Operation method | F02 | Operation method |
| 03 | Max. speed | F03 | M1 max. speed |
| 04 | Acceleration time 1 | F07 | Acceleration time 1 |
| 05 | Deceleration time 1 | F08 | Deceleration time 1 |
| 06 | S-curve acceleration/deceleration 1 | F67 to F70 | S-curve acceleration/deceleration 1 |
| 07 | Multistep speed 1 | C05 | Multistep speed 1 |
| 08 | Multistep speed 2 | C06 | Multistep speed 2 |
| 09 | Multistep speed 3 | C07 | Multistep speed 3 |
| 10 | Multistep speed 4 | C08 | Multistep speed 4 |
| 11 | Multistep speed 5 | C09 | Multistep speed 5 |
| 11 | Multistep speed 6 / Creep speed 1 | C09 | Multistep speed 6 / Creep speed 1 |
| 12 | Multistep speed 7 / Creep speed 2 | C10/C18 | Multistep speed 7 / Creep speed 2 |
| 13 | | C11/C19 | |
| 14 | ASR1 (P gain) | F61 | ASR1-P(Gain) |
| 15 | (I gain) | F62 | ASR1-I (Constant of integration) |
| 16 | Constant on filtering (Speed setting) | F64 | ASR1 input filter |
| 17 | (Speed detection) | F65 | ASR1 detection filter |
| 18 | Torque limiter (Method selection) | F40,41 | Torque limiter mode |
| 19 | (Limiter value selection) | F42,43 | Torque limiter value selection |
| 20 | Torque limiter (Level 1) | F44 | Torque limiter (Level 1) |
| 21 | (Level 2) | F45 | (Level 2) |
| 22 | Motor electronic thermal (Select) | F10 | M1 motor electronic thermal (Select) |
| 23 | (Level) | F11 | (Level) |
| 24 | Restart after momentary power failure | F14 | Restart after momentary power failure (Operation selection) |
| 25 | DC brake (Time) | F22 | DC brake (Braking time) |
| 26 | (Level) | F21 | (Operation level) |
| 27 | Pre-excitation (Time) | F74 | Pre-excitation time |
| 30 | Function block (31-44) selection | – | |
| 31 | Droop control | H28 | Droop control |
| 32 | Filtering time constant (ASR output) | F66 | ASR1 output filter |
| 33 | Acceleration time 2 | C46 | Acceleration time 2 |
| 34 | Deceleration time 2 | C47 | Deceleration time 2 |
| 35 | S-curve acceleration/deceleration 2 | C48, C49 | S-curve acceleration/deceleration 2 |
| 36 | Ratio setting | F17 | Gain (Speed setting signal 12) |
| 37 | ASR2 (P gain) | C40 | ASR2-P (Gain) |
| 38 | (I gain) | C41 | ASR2-I (Constant of integration) |
| 39 | ASR1, 2 switching characteristic | C70 | ASR switching time |
| 40 | Torque bias (Level 1) | F47 | Torque bias T1 |
| 41 | (Level 2) | F48 | Torque bias T2 |
| 42 | Selection between torque control and torque current control (Select) | H41, H42 | Torque command and torque current command selection |
| 43 | Magnetic-flux command (Select) | H43 | Magnetic-flux command selection |
| 44 | Magnetic-flux command at light load | F73 | Magnetic-flux level at light load |
| 50 | Function block (51-55) selection | – | |
| 51 | ASR tuning (Action selection) | H46 | Observer type selection |
| 52 | (Operation selection) | H01 | Tuning operation selection |

| FRENIC5000 VG5S | | FRENIC-VG | |
|-----------------|---|----------------|---|
| Function Codes | Name | Function Codes | Name |
| 53 | Observer data (Compensation gain) (Integration time) (Load inertia) | H47, H48 | Observer settings (Compensation gain) (Integration time) (Load inertia) |
| 54 | | H49, H50 | |
| 55 | | H51, H52 | |
| 60 | Function block (61-74) selection | – | |
| 61 | Motor overheat protection (temp.) | E30 | Motor overheat protection (temp.) |
| 62 | Motor overheat early warning (temp.) | E31 | Motor overheat early warning (temp.) |
| 63 | Inverter overload early warning (Level) | E33 | Inverter overload early warning |
| 64 | Motor overload early warning (Level) | E34 | Motor overload early warning |
| 65 | Zero speed detection (Level) | F37 | Stop speed |
| 66 | Speed detection (Level 1) (Level 2) (Level 3) | E39 | Speed detection level 1 |
| 67 | | E40 | Speed detection level 2 |
| 68 | | E41 | Speed detection level 3 |
| 69 | Speed detection method | E38 | Speed detection method |
| 70 | Speed equivalence (Detection range) | E42 | Speed equivalence (Detection range) |
| 71 | Speed agreement (Detection range) (Off delay timer) | E43 | Speed agreement (Detection range) (Off delay timer) |
| 72 | | E44 | |
| 73 | Torque detection (Level) | E46 | Torque detection level 1 |
| 74 | Timer for continuous operation | F39 | Stop speed (Zero speed holding time) |
| 80 | Function block (81-101) selection | – | |
| 81 | Auto-restart (Times) (Interval) | H04 | Auto-restart (Times) (Interval) |
| 82 | | H05 | |
| 83 | Speed bias setting | F18 | Bias (Speed setting signal 12) |
| 84 | Speed limiter (Method selection) | F76 | Speed limiter (Method selection) |
| 85 | Speed limiter (Level 1) (Level 2) | F77 | Speed limiter level 1 |
| 86 | | F78 | Speed limiter level 2 |
| 87 | Creep selection (Setting selection) | C73 | Creep speed switching (on UP/DOWN control) |
| 88 | Operation method changeover switch | – | Function selection Di [IVS] |
| 89 | Speed feedback (Signal selection) | H53 | Line speed feedback selection |
| 90 | Suppressing function | H57 | Overvoltage suppressing function |
| 91 | Operation method selection | H11 | Automatic operation OFF function |
| 92 | Torque command monitor | F51 | Torque command monitor (Polarity selection) |
| 93 | Language | F58 | LCD monitor (Language selection) |
| 94 | LCD brightness adjustment | F59 | LCD monitor (Contrast adjustment) |
| 95 | LED monitor selection | F55 | LED monitor (Display selection) |
| 96 | Display of load speed (Coefficient 1) (Coefficient 2) | F52 | LED monitor (Display coefficient A) |
| 97 | | F53 | LED monitor (Display coefficient B) |
| 98 | LCD monitor selection | F57 | LCD monitor (Display selection) |
| 99 | Motor sound selection | F26 | Motor sound (Carrier freq.) |
| 100 | Data initialization | H03 | Data initialization |
| 101 | All save | H02 | All save |
| 110 | Function block (111-134) selection | – | |
| 111 | Selection of X1 to X5 (X1, X2) (X3, X4) (X5) | E01, E02 | Selection of X1 function, Selection of X2 function |
| 112 | | E03, E04 | Selection of X3 function, Selection of X4 function |
| 113 | | E05 | X5 function selection |
| 114 | Timer for multistep speed reference agreement | C20 | Timer for multistep speed reference agreement |
| 115 | Y1 to Y3, RY function selection (Y1, Y2) (Y3, RY) | E15, E16 | Y1 function selection, Y2 function selection |
| 116 | | E17, E19 | Y3 function selection, Y5 function selection |

| FRENIC5000 VG5S | | | FRENIC-VG | |
|-----------------|---|------------------------------------|----------------|---|
| Function Codes | Name | | Function Codes | Name |
| 117 | Ai1, Ai2 function selection | | E49, E50 | Ai1 function selection, Ai2 function selection |
| 118 | Increment/decrement limiter | (Ai1) | E65 | Increment/decrement limiter (Ai1) |
| 119 | | (Ai2) | E66 | Increment/decrement limiter (Ai2) |
| 120 | Offset setting | (12) | F18 | Bias (Speed setting signal 12) |
| 121 | | (Ai1) | E57 | Ai1 bias setting |
| 122 | | (Ai2) | E58 | Ai2 bias setting |
| 123 | Gain setting | (12) | F17 | Gain (Speed setting signal 12) |
| 124 | | (Ai1) | E53 | Ai1 gain setting |
| 125 | | (Ai2) | E54 | Ai2 gain setting |
| 126 | AO1 to AO3 function selection | | E69 to E71 | AO1 function selection, AO2 function selection, AO3 function selection |
| 127 | Bias adjustment | (AO1) | E79 | AO1 bias setting |
| 128 | | (AO2) | E80 | AO2 bias setting |
| 129 | | (AO3) | E81 | AO3 bias setting |
| 130 | Gain adjustment | (AO1) | E74 | AO1 gain setting |
| 131 | | (AO2) | E75 | AO2 gain setting |
| 132 | | (AO3) | E76 | AO3 gain setting |
| 133 | Filter selection | (AO1, AO2, AO3) | E84 | AO1-5 filter setting |
| 140 | Function block (140-169) selection | | – | |
| 141 | Operation command selection | | H30 | Serial link |
| 142 | Control input through transmission | | S06 | Operation method 1(through communication) |
| 143 | Speed command through transmission | | S01 | Speed command |
| 144 | Action on T-Link error | (Mode) | o30 | T-Link option setting (Action on transmission error) |
| 145 | | (Action time) | o31 | |
| 146 | Standard built-in RS-485 address | | H31 | RS-485 (Station address) |
| 147 | Action on RS-485 error | (Mode) | H32 | Action on RS-485 error Operation (Mode select on error) (Timer operating time) (No response error detection time) (Response interval) |
| 148 | | (Action time) | H33 | |
| 149 | | (No response error detection time) | H38 | |
| 150 | | (Response interval) | H39 | |
| 151 | X11 to X14 function selection | (X11, X12) | E10, E11 | X11 function selection, X12 function selection |
| 152 | | (X13, X14) | E12, E13 | X13 function selection, X14 function selection |
| 153 | Y11 to Y13 function selection | (Y11, Y12) | E20, E21 | Y11 function selection, Y12 function selection |
| 154 | | (Y13) | E22 | Y13 function selection |
| 155 | Function selection of OPCII-VG5-DI BCD input speed | | o01, o02 | DIA function selection, DIB function selection |
| 156 | | | o03, o04 | DIA BCD input setting, DIB BCD input setting |
| 157 | Command pulse correction 1 | | o14 | Command pulse correction 1 |
| 158 | Command pulse correction 2 | | o15 | Command pulse correction 2 |
| 159 | APR gain | | o16 | APR gain |
| 160 | F/F gain | | o17 | F/F gain |
| 161 | Deviation excess range | | o18 | Deviation excess range |
| 162 | Deviation zero range | | o19 | Deviation zero range |
| 170 | Function block (171-197) selection | | – | |
| 171 | Motor selection (*1) | | P02 | M1 motor selection |
| 172 | PG pulse number | | P28 | M1-PG pulse number |
| 173 | NTC thermistor selection | | P30 | M1 thermistor selection |





| FRENIC5000 VG5S | | | FRENIC-VG | | |
|-----------------|-------------------------------------|-------------------------------------|----------------|--------------------------------------|-----------------|
| Function Codes | Name | | Function Codes | Name | |
| 174 | Motor ratings | (Capacity) | P03 | M1 rated capacity | |
| 175 | | (Voltage) | F05 | M1 rated voltage | |
| 176 | | (Current) | P04 | M1 rated current | |
| 177 | | (Base speed) | F04 | M1 rated speed | |
| 178 | | (No. of pole) | P05 | M1 number of pole | |
| 179 | Overload capability | | – | | |
| 180 | Auto-tuning of motor characteristic | | – | | |
| 181 | (Protection) | (Operation) | H01 | Tuning operation selection | |
| 182 | Motor characteristic | (%R1) | P06 | M1-%R1 | |
| 183 | | (%X) | P07 | M1-%X | |
| 184 | | (Exciting current) | P08 | M1 exciting current | |
| 185 | | (Torque current) | P09 | M1 torque current | |
| 186 | | (Slip on driving) | P10 | M1 slip on driving | |
| 187 | | (Slip on braking) | P11 | M1 slip on braking | |
| 188 | | (Iron loss coefficient 1) | P12 | M1 iron loss coefficient 1 | |
| 189 | | (Iron loss coefficient 2) | P13 | M1 iron loss coefficient 2 | |
| 190 | | (Iron loss coefficient 3) | P14 | M1 iron loss coefficient 3 | |
| 191 | | (Magnetic saturation coefficient 1) | P15 | M1 magnetic saturation coefficient 1 | |
| 192 | | (Magnetic saturation coefficient 2) | P16 | M1 magnetic saturation coefficient 2 | |
| 193 | | (Magnetic saturation coefficient 3) | P17 | M1 magnetic saturation coefficient 3 | |
| 194 | | (Magnetic saturation coefficient 4) | P18 | M1 magnetic saturation coefficient 4 | |
| 195 | | (Magnetic saturation coefficient 5) | P19 | M1 magnetic saturation coefficient 5 | |
| 196 | | (Secondary time constant) | P20 | M1 secondary time constant | |
| 197 | | (Induced voltage coefficient) | P21 | M1 induced voltage coefficient | |
| 200 | | Data protection | | F00 | Data protection |

(*1) If "other" is specified in VG5 motor selection [171], calculate with the following formula.

| VG1 Function Codes | Name | Conversion formula |
|--------------------|----------------------|--|
| P06 | M1-%R1 | <ul style="list-style-type: none"> For 200V system $[182] \times 135 \div [175] \times \sqrt{3}$ For 400V system $[182] \times 270 \div [175] \times \sqrt{3}$ |
| P07 | M1-%X | <ul style="list-style-type: none"> For 200 V system $[183] \times 135 \div [175] \times \sqrt{3} \times \text{fbase} \div 50$ $(\text{fbase} = [177] \times [178] \div 120)$ For 400 V system $[183] \times 270 \div [175] \times \sqrt{3} \times \text{fbase} \div 50$ $(\text{fbase} = [177] \times [178] \div 120)$ |
| P08 | M1 exciting current | $[184] \div \sqrt{2}$ |
| P09 | M1 torque current | $[185] \div \sqrt{2}$ |
| P21 | M1 inductive voltage | $[197] \times \text{fbase} \div 50 \times \sqrt{3} \div \sqrt{2}$ $(\text{fbase} = [177] \times [178] \div 120)$ |

Function codes for VG5 are put in brackets.

(*2) If the inverter is broken, and the motor constant cannot be confirmed, notify our sales office of the following contents.

| | Item | Details |
|----------|--|--|
| Inverter | <ul style="list-style-type: none"> ▪ TYPE ▪ SER. No. | Notify us of the descriptive contents of the name plate.  |
| | ROM No | ROM seal are affixed to the CUP board of the control PCB.  |
| | <ul style="list-style-type: none"> ▪ System code (VG5□-□□□□-□□) 2 digits at the end = 00 (standard item) 01 to 99 (special item) | The system code seal is affixed to the back face of the control terminal block. (See the photo below)  |
| Motor | <ul style="list-style-type: none"> ▪ Product model (TYPE) ▪ Number of poles (POLES) ▪ Capacity (OUTPUT) ▪ Frequency (Hz) ▪ Voltage (VOLT) ▪ Current (AMP) ▪ Number of revolutions (RPM) ▪ Production No. (SER No.) | Notify us of the descriptive contents of the name plate.  |
| | Outline drawing | |

12.5.3 Replacing VG3

| FRENIC5000 VG3 | | FRENIC-VG | |
|----------------|--|--------------------------|--|
| Function Codes | Name | Function Codes | Name |
| 01 | Motor rotating speed detection value display | – | LED MONITOR |
| 02 | Motor rotating speed setting value display | – | LED MONITOR |
| 03 | Load speed detection value display | – | LED MONITOR |
| 04 | Torque current reference value display | – | LED MONITOR |
| 05 | Torque reference value display | – | LED MONITOR |
| 06 | Motor output display | – | LED MONITOR |
| 07 | Inverter output current display | – | LED MONITOR |
| 08 | Motor temperature display | – | LED MONITOR |
| 09 | Input signal (1) display | – | LCD monitor |
| 0A | Input signal (2) display | – | LCD monitor |
| 0B | Output signal display | – | LCD monitor |
| 0C | Operation mode display | – | LCD monitor |
| 0D | Soft switch (1) display | – | LCD monitor |
| 0E | Soft switch (2) display | – | LCD monitor |
| 0F | Magnetic-flux quantity | – | LED MONITOR |
| 10 | Protection of setting data (11-3F) | – | |
| 11 | Acceleration time 1 | F07 | Acceleration time 1 |
| 12 | Deceleration time 1 | F08 | Deceleration time 1 |
| 13 | S-curve applied range | F67 F68 F69 F70 | S-curve acceleration start side 1 S-curve acceleration end side 1 S-curve deceleration start side 1 S-curve deceleration end side 1 |
| 14 | Multistep speed setting value 1 | C05 | Multistep speed 1 |
| 15 | Multistep speed setting value 2 | C06 | Multistep speed 2 |
| 16 | Multistep speed setting value 3 | C07 | Multistep speed 3 |
| 17 | Multistep speed setting value 4 | C08 | Multistep speed 4 |
| 18 | Multistep speed setting value 5 | C09 | Multistep speed 5 |
| 19 | Acceleration time 2 | C46 | Acceleration time 2 |
| 1A | Deceleration time 2 | C47 | Deceleration time 2 |
| 1B | Speed reference input gain | F17 | Gain (Speed setting signal 12) |
| 20 | ASR P (1) | F61 | ASR1 P |
| 21 | ASR I (1) | F62 | ASR1 I |
| 22 | Speed setting constant on filtering (1) | F64 | ASR1 input filter |
| 23 | Speed detection constant on filtering (1) | F65 | ASR1 detection filter |
| 24 | ASR P (2) | C40 | ASR2 P |
| 25 | ASR I (2) | C41 | ASR2 I |
| 26 | Speed setting constant on filtering (2) | C43 | ASR2 input filter |
| 27 | Speed detection constant on filtering (2) | C44 | ASR2 detection filter |
| 28 | Droop quantity | H28 | Droop control |
| 29 | ASR time constant of P changeover switch | C70 | ASR switching time |
| 2A | Torque limiter value 1/Torque bias command value 1 | F44 | Torque limiter value (Level 1) |
| 2B | Torque limiter value 2/Torque bias command value 2 | F45 | Torque limiter value (Level 2) |
| 2C | Torque limiter value 3/Torque bias command value 3 | – | |
| 2D | Torque limiter value 4 | – | |
| 2E | Magnetic-flux command level | H44 | Magnetic-flux command value |
| 2F | Magnetic-flux command level at light load | F73 | Magnetic-flux level at light load |
| 30 | Zero speed detection level | F37 | Stop speed |
| 31 | Arbitrary speed detection level | E39 | Speed detection level 1 |





| FRENIC5000 VG3 | | FRENIC-VG | |
|----------------|--|----------------|---|
| Function Codes | Name | Function Codes | Name |
| | (Absolute value) | | |
| 32 | Arbitrary speed detection level (With polarity) | E40 | Speed detection level 2 |
| 33 | Speed equivalence detection level | E42 | Speed equivalence |
| 34 | Speed agreement detection level | E43 | Speed agreement |
| 35 | Torque detection level | E46 | Torque detection level 1 |
| 36 | Overload early warning detection level | E33 | Inverter overload early warning |
| 37 | Motor overheat early warning detection level | E31 | Motor overheat early warning |
| 38 | Output calibration coefficient of load meter | – | Adjustment is possible through E69 to 71, by allocating the torque meter into AO1 to 3. |
| 39 | Output calibration coefficient of speedometer | – | Adjustment is possible through E69 to 71, by allocating the speedometer into AO1 to 3. |
| 3A | Stop position by the simplified position control | – | |
| 40 | First fault | – | LED MONITOR |
| 41 | Second fault | – | LED MONITOR |
| 42 | Fault condition | – | LCD MONITOR |
| 43 | Speed setting value at the occurrence of fault. | – | LCD MONITOR |
| 44 | Speed detection value at the occurrence of fault. | – | LCD MONITOR |
| 45 | Torque current reference value at the occurrence of fault. | – | LCD MONITOR |
| 46 | Motor current value (U-phase) at the occurrence of fault. | – | LCD MONITOR |
| 47 | Motor current value (W-phase) at the occurrence of fault. | – | LCD MONITOR |
| 48 | Operation mode (LED display) at the occurrence of fault. | – | LCD MONITOR |
| 49 | Operation mode (HEX display) at the occurrence of fault. | – | LCD MONITOR |
| 4A | Soft switch 1 (LED display) at the occurrence of fault. | – | LCD MONITOR |
| 4B | Soft switch 2 (LED display) at the occurrence of fault. | – | LCD MONITOR |
| 4C | Soft switch (HEX display) at the occurrence of fault. | – | LCD MONITOR |
| 4D | Last fault (First fault) | – | LCD MONITOR |
| 4E | Fault before last (First fault) | – | LCD MONITOR |
| 4F | Fault before and before last (First fault) | – | LCD MONITOR |
| 50 | Protection of setting data (51-8F) | – | |
| 51 | Max. speed of motor | F03 | M1 max. speed |
| 52 | Base speed of motor | F04 | M1 rated speed |
| 53 | DC brake using/not using. | F22 | DC brake (Braking time) |
| 54 | | | |
| 55 | DC braking time | F22 | DC brake (Braking time) |
| 56 | | | |
| 57 | Speed setting limiter value (Upper limit) | F77 | Speed limiter level 1 |
| 58 | Definition of the operation method (1) | – | |
| 59 | Definition of the operation method (2) | H11 | Automatic operation OFF function |
| 5A | Definition of the Speed setting method (1) | F01 | Speed setting N1 |
| 5B | Definition of forward · reverse command | – | Possible through function selection DI [IVS]. |
| 5C | Calibration coefficient of load speed | F52,53 | LED monitor (Display coefficient) |

| FRENIC5000 VG3 | | FRENIC-VG | |
|----------------|---|----------------|--|
| Function Codes | Name | Function Codes | Name |
| 5D | Definition of the speed detection area | H53 | Line speed feedback selection |
| 5E | Definition of the Speed setting method (2) | C25 | Speed setting N2 |
| 5F | Creep setting of U/D setter | C73 | Creep speed switching |
| 60 | Definition of the torque limiter method | F40 | Torque limiter mode |
| 61 | Definition of the torque limiter value 1/Torque bias reference value 1. | F42 | Torque limiter value (Level 1) selection |
| 62 | Definition of the torque limiter value 2/Torque bias reference value 2. | F43 | Torque limiter value (Level 2) selection |
| 63 | Definition of the torque limiter value 3/Torque bias reference value 3. | – | |
| 64 | Definition of the torque limiter value 4. | – | |
| 65 | In use/not in use of external Ai for the torque reference. | H41 | Torque reference selection |
| 66 | Definition of the magnetic-flux reference value. | H43 | Magnetic-flux command selection |
| 70 | LM terminal definition | – | Possible through function selection from AO1 to 3. |
| 71 | SM terminal definition | – | Possible through function selection from AO1 to 3. |
| 72 | DI definition (X1 to X4, X6, X7) | E01 to E04 | X1 to X4 function selection |
| 73 | DI definition (X5) | E05 | X5 function selection |
| 74 | DO definition (Y1 to Y5) | E15 to E18 | Y1 to Y4 function selection |
| 75 | DO definition (RY) | E19 | Y5 function selection |
| 76 | AI definition (Ai1) | E49 | Ai1 function selection |
| 77 | AI definition (Ai2) | E50 | Ai2 function selection |
| 78 | AO definition (AO1) | E69 | AO1 function selection |
| 79 | AO definition (AO2, AO3) | E70, E71 | AO2, AO3 function selection |
| 7A | No. of motor poles, specification for the pulse generator | P28 | No. of PG pulses |
| 7B | V1 enabled/disabled | – | Possible through function selection Ai [OFF]. |
| 80 | Calibration coefficient of BCD input for speed setting | o03, o04 | DI BCD input setting. |
| 81 | Definition of the initial setting value of UP/DOWN setter. | F01, C25 | Speed setting N1, N2 |
| 82 | Enabled/disabled of transmission data | H30 | Serial link |
| 83 | Transmission ID code | – | |
| 84 | | | |
| 85 | AO adjustment | – | Possible through AO function selection [P10], [N10]. |
| 86 | AI1 filter | E61 | Ai1 filter |
| 87 | AI2 filter | E62 | Ai2 filter |
| 88 | 12 offset adjustment value | – | |
| 89 | 12 gain adjustment value | F17 | Gain (Speed setting signal 12) |
| 8A | V1 offset adjustment value | – | |
| 8B | V1 gain adjustment value | – | |
| 8C | AI1 offset adjustment value | E57 | AI1 bias setting |
| 8D | AI1 gain adjustment value | E53 | AI1 gain setting |
| 8E | AI2 offset adjustment value | E58 | AI2 bias setting |
| 8F | AI2 gain adjustment value | E54 | AI2 gain setting |
| 90 | Display of the transmitted and written DI data | S06 | Operation method 1 |
| 91 | Transmission speed setting mode selection | H30 | Serial link |
| 92 | Transmission speed setting | S01 | Speed command |

| FRENIC5000 VG3 | | FRENIC-VG | |
|------------------|---|----------------|--------------------------|
| Function Codes | Name | Function Codes | Name |
| 93 | Transmission speed setting bias | – | |
| 94 | Transmission torque command mode selection | H41 | Torque command selection |
| 95 | Transmission torque command | S02 | Torque command |
| 96 | General purpose DO | S07 | Universal DO |
| 97 | Trace data mode | – | |
| 98, 99 | | | |
| 9A | Confirmation of data saving condition | – | |
| 9B | ALL SAVE function | H02 | All save |
| For manufacturer | Motor constant setting value (non-disclosure) | P01 to P30 | Motor code (*1) |

(*1) Using "Excepting V63 standard motor" requires the confirmation of the motor constant.

Notify our sales office of the following contents.

| | Item | Details |
|----------|--|---|
| Inverter | <ul style="list-style-type: none"> ▪ TYPE ▪ SER. No. | Notify us of the descriptive contents of the name plate.  |
| | ROM No | ROM seal are affixed to the IC2 and IC3 of the control PCB.  |
| | <ul style="list-style-type: none"> ▪ System code (VG3□-□□□□-□□) 2 digits at the end = 00 (standard item) 01 to 99 (special item) | The system code seal is affixed to the back face of the control terminal block. (See the photo below)  |
| Motor | <ul style="list-style-type: none"> ▪ Product model (TYPE) ▪ Number of poles (POLES) ▪ Capacity (OUTPUT) ▪ Frequency (Hz) ▪ Voltage (VOLT) ▪ Current (AMP) ▪ Number of revolutions (RPM) ▪ Production No. (SER No.) | Notify us of the descriptive contents of the name plate.  |
| | Outline drawing | |

12.6 Motor Parameters

12.6.1 Replacing VG7S

200V series

| Motor specification | | VG7S code No. | | Motor parameters | | | | | | | | | | | | | | | | | | | | | | | | |
|---------------------|--------------|--------------------------|---------------------|-------------------|---------------------|-------------------|--------------|------|-------|--------------------------|--------------------|----------------------|----------------------|---------------------------|---------------------------|---------------------------|-------------------------------------|-------------------------------------|-------------------------------------|-------------------------------------|-------------------------------------|-----------------------------|-------------------------------|---------------------------|---------------------------|---------------------------|---|--------------|
| | | Speed (Rated/Max)(r/min) | Voltage[V] | F03 | F04 | F05 | P03 | P04 | P05 | P06 | P07 | P08 | P09 | P10 | P11 | P12 | P13 | P14 | P15 | P16 | P17 | P18 | P19 | P20 | P21 | P22 | P23 | P24 |
| Type | Capacity[kW] | No. of poles | Rated speed [r/min] | Rated voltage [V] | Rated capacity [kW] | Rated current [A] | No. of poles | %R | %X | Pre-exciting current [A] | Torque current [A] | Slip on driving [Hz] | Slip On braking [Hz] | Iron loss co-effic. 1 [%] | Iron loss co-effic. 2 [%] | Iron loss co-effic. 3 [%] | Magnetic saturation co-effic. 1 [%] | Magnetic saturation co-effic. 2 [%] | Magnetic saturation co-effic. 3 [%] | Magnetic saturation co-effic. 4 [%] | Magnetic saturation co-effic. 5 [%] | Secondary time constant [s] | Induced voltage co-effic. [V] | R2 correction co-effic. 1 | R2 correction co-effic. 2 | R2 correction co-effic. 3 | Pre-exciting current correction co-effic. | Load inertia |
| MV/K6096 | 0.75 | 4 | 1500 | 188 | 0.75 | 4.3 | 4 | 4.34 | 9.07 | 3.21 | 2.92 | 1.320 | 1.185 | 7.60 | 7.60 | 10.00 | 93.0 | 85.8 | 72.6 | 60.0 | 47.6 | 0.108 | 149 | 1.360 | 1.480 | 1.000 | 0.000 | 0.009 |
| MV/K6095A | 0.75 | 4 | 1500 | 188 | 0.75 | 4.3 | 4 | 4.34 | 9.07 | 3.21 | 2.92 | 1.320 | 1.185 | 7.60 | 7.60 | 10.00 | 93.0 | 85.8 | 72.6 | 60.0 | 47.6 | 0.108 | 149 | 1.360 | 1.480 | 1.000 | 0.000 | 0.009 |
| MV/K6097 | 1.5 | 4 | 1500 | 188 | 1.5 | 7.0 | 4 | 7.06 | 14.76 | 3.21 | 5.83 | 2.640 | 2.370 | 3.80 | 3.80 | 5.00 | 93.0 | 85.8 | 72.6 | 60.0 | 47.6 | 0.108 | 149 | 1.360 | 1.480 | 1.000 | 0.000 | 0.009 |
| MV/K8097A | 1.5 | 4 | 1500 | 188 | 1.5 | 7.0 | 4 | 7.06 | 14.76 | 3.21 | 5.83 | 2.640 | 2.370 | 3.80 | 3.80 | 5.00 | 93.0 | 85.8 | 72.6 | 60.0 | 47.6 | 0.108 | 149 | 1.360 | 1.480 | 1.000 | 0.000 | 0.009 |
| MV/K6107 | 2.2 | 4 | 1500 | 188 | 2.2 | 11 | 4 | 8.27 | 12.95 | 3.81 | 9.75 | 2.622 | 3.059 | 3.00 | 4.00 | 1.00 | 85.2 | 73.7 | 59.1 | 47.6 | 37.4 | 0.051 | 140 | 2.530 | 1.133 | 1.000 | 0.000 | 0.009 |
| MV/K8107A | 2.2 | 4 | 1500 | 188 | 2.2 | 11 | 4 | 8.27 | 12.95 | 3.81 | 9.75 | 2.622 | 3.059 | 3.00 | 4.00 | 1.00 | 85.2 | 73.7 | 59.1 | 47.6 | 37.4 | 0.051 | 140 | 2.530 | 1.133 | 1.000 | 0.000 | 0.009 |
| MV/K6115 | 3.7 | 4 | 1500 | 188 | 3.7 | 18 | 4 | 6.86 | 12.69 | 8.11 | 15.69 | 2.500 | 2.370 | 3.00 | 2.95 | 2.50 | 88.4 | 80.1 | 66.4 | 54.1 | 43.0 | 0.084 | 146 | 0.899 | 1.320 | 1.000 | 0.022 | 0.016 |
| MV/K8115A | 3.7 | 4 | 1500 | 188 | 3.7 | 18 | 4 | 6.86 | 12.69 | 8.11 | 15.69 | 2.500 | 2.370 | 3.00 | 2.95 | 2.50 | 88.4 | 80.1 | 66.4 | 54.1 | 43.0 | 0.084 | 146 | 0.899 | 1.320 | 1.000 | 0.022 | 0.016 |
| MV/K6133 | 5.5 | 4 | 1500 | 188 | 5.5 | 30 | 4 | 6.05 | 13.44 | 12.98 | 21.92 | 1.490 | 1.440 | 3.00 | 2.50 | 3.00 | 88.3 | 79.5 | 66.0 | 54.1 | 43.0 | 0.090 | 149 | 1.925 | 1.985 | 1.000 | 0.026 | 0.030 |
| MV/K8133A | 5.5 | 4 | 1500 | 188 | 5.5 | 30 | 4 | 6.05 | 13.44 | 12.98 | 21.92 | 1.490 | 1.440 | 3.00 | 2.50 | 3.00 | 88.3 | 79.5 | 66.0 | 54.1 | 43.0 | 0.090 | 149 | 1.925 | 1.985 | 1.000 | 0.026 | 0.030 |
| MV/K6135 | 7.5 | 4 | 1500 | 188 | 7.5 | 37 | 4 | 6.70 | 12.45 | 15.62 | 30.66 | 1.771 | 1.871 | 2.32 | 1.76 | 3.00 | 85.3 | 70.7 | 53.8 | 43.7 | 34.4 | 0.070 | 155 | 0.900 | 0.900 | 1.000 | 0.000 | 0.038 |
| MV/K8135A | 7.5 | 4 | 1500 | 188 | 7.5 | 37 | 4 | 6.70 | 12.45 | 15.62 | 30.66 | 1.771 | 1.871 | 2.32 | 1.76 | 3.00 | 85.3 | 70.7 | 53.8 | 43.7 | 34.4 | 0.070 | 155 | 0.900 | 0.900 | 1.000 | 0.000 | 0.038 |
| MV/K6165 | 11 | 4 | 1500 | 188 | 11 | 50 | 4 | 4.26 | 11.64 | 24.79 | 40.30 | 0.988 | 0.824 | 4.53 | 1.88 | 0.22 | 84.9 | 75.0 | 61.6 | 50.0 | 39.4 | 0.087 | 175 | 0.900 | 2.343 | 1.000 | 0.000 | 0.085 |
| MV/K8165A | 11 | 4 | 1500 | 188 | 11 | 50 | 4 | 4.26 | 11.64 | 24.79 | 40.30 | 0.988 | 0.824 | 4.53 | 1.88 | 0.22 | 84.9 | 75.0 | 61.6 | 50.0 | 39.4 | 0.087 | 175 | 0.900 | 2.343 | 1.000 | 0.000 | 0.085 |
| MV/K6167 | 15 | 4 | 1500 | 188 | 15 | 65 | 4 | 4.47 | 12.25 | 26.99 | 53.96 | 1.067 | 1.067 | 0.00 | 1.50 | 1.00 | 88.7 | 80.7 | 67.2 | 55.2 | 44.0 | 0.133 | 160 | 1.689 | 1.689 | 1.000 | 0.000 | 0.120 |
| MV/K8167A | 15 | 4 | 1500 | 188 | 15 | 65 | 4 | 4.47 | 12.25 | 26.99 | 53.96 | 1.067 | 1.067 | 0.00 | 1.50 | 1.00 | 88.7 | 80.7 | 67.2 | 55.2 | 44.0 | 0.133 | 160 | 1.689 | 1.689 | 1.000 | 0.000 | 0.120 |
| MV/K6184 | 18.5 | 4 | 1500 | 188 | 18.5 | 74 | 4 | 3.22 | 10.68 | 30.58 | 72.83 | 0.934 | 0.931 | 3.50 | 0.50 | 0.50 | 90.7 | 83.2 | 69.5 | 56.8 | 44.4 | 0.240 | 160 | 1.465 | 1.803 | 1.000 | 0.097 | 0.210 |
| MV/K8184A | 18.5 | 4 | 1500 | 188 | 18.5 | 74 | 4 | 3.22 | 10.68 | 30.58 | 72.83 | 0.934 | 0.931 | 3.50 | 0.50 | 0.50 | 90.7 | 83.2 | 69.5 | 56.8 | 44.4 | 0.240 | 160 | 1.465 | 1.803 | 1.000 | 0.097 | 0.210 |
| MV/K6185 | 22 | 4 | 1500 | 188 | 22 | 90 | 4 | 3.59 | 11.78 | 34.17 | 83.43 | 0.606 | 0.855 | 1.30 | 0.77 | 2.00 | 91.1 | 83.2 | 69.1 | 56.8 | 44.6 | 0.387 | 160 | 4.000 | 2.200 | 1.000 | 0.089 | 0.230 |
| MV/K8185A | 22 | 4 | 1500 | 188 | 22 | 90 | 4 | 3.59 | 11.78 | 34.17 | 83.43 | 0.606 | 0.855 | 1.30 | 0.77 | 2.00 | 91.1 | 83.2 | 69.1 | 56.8 | 44.6 | 0.387 | 160 | 4.000 | 2.200 | 1.000 | 0.089 | 0.230 |
| MV/K6206 | 30 | 4 | 1500 | 188 | 30 | 116 | 4 | 2.53 | 12.13 | 53.42 | 108.1 | 0.606 | 0.648 | 2.50 | 3.50 | 5.00 | 84.4 | 74.0 | 59.5 | 48.9 | 38.0 | 0.173 | 166 | 2.268 | 2.078 | 1.000 | 0.000 | 0.340 |
| MV/K8187A | 30 | 4 | 1500 | 188 | 30 | 116 | 4 | 2.43 | 12.32 | 39.95 | 106.0 | 0.915 | 1.015 | 3.00 | 0.00 | 0.00 | 88.2 | 81.9 | 70.1 | 58.4 | 46.7 | 0.385 | 166 | 1.818 | 1.737 | 1.000 | 0.000 | 0.340 |
| MV/K6207 | 37 | 4 | 1500 | 188 | 37 | 143 | 4 | 2.47 | 14.69 | 60.09 | 133.2 | 0.497 | 0.536 | 1.80 | 3.00 | 5.00 | 85.4 | 75.7 | 62.3 | 50.5 | 39.9 | 0.184 | 168 | 3.200 | 2.560 | 1.000 | 0.180 | 0.410 |
| MV/K8207A | 37 | 4 | 1500 | 188 | 37 | 143 | 4 | 2.47 | 14.69 | 60.09 | 133.2 | 0.497 | 0.536 | 1.80 | 3.00 | 5.00 | 85.4 | 75.7 | 62.3 | 50.5 | 39.9 | 0.184 | 168 | 3.200 | 2.560 | 1.000 | 0.180 | 0.410 |
| MV/K6208 | 45 | 4 | 1500 | 188 | 45 | 170 | 4 | 2.73 | 15.26 | 56.71 | 169.7 | 0.947 | 0.901 | 1.00 | 0.00 | 0.15 | 89.2 | 81.6 | 67.6 | 56.2 | 43.4 | 0.295 | 164 | 1.229 | 1.813 | 1.000 | 0.178 | 0.470 |
| MV/K8208A | 45 | 4 | 1500 | 188 | 45 | 170 | 4 | 2.73 | 15.26 | 56.71 | 169.7 | 0.947 | 0.901 | 1.00 | 0.00 | 0.15 | 89.2 | 81.6 | 67.6 | 56.2 | 43.4 | 0.295 | 164 | 1.229 | 1.813 | 1.000 | 0.178 | 0.470 |
| MV/K9250 | 55 | 4 | 1500 | 185 | 55 | 216 | 4 | 2.08 | 12.36 | 66.22 | 197.9 | 0.621 | 0.595 | 3.00 | 0.83 | 0.21 | 91.5 | 83.8 | 70.6 | 57.8 | 45.6 | 0.413 | 168 | 1.615 | 1.753 | 1.000 | 0.000 | 0.800 |
| MV/K9224A | 55 | 4 | 1500 | 180 | 55 | 225 | 4 | 2.04 | 14.42 | 72.66 | 202.3 | 0.742 | 0.742 | 3.00 | 0.00 | 0.00 | 89.3 | 83.3 | 71.4 | 59.5 | 47.6 | 0.544 | 167 | 1.000 | 1.000 | 1.000 | 0.000 | 0.530 |
| MV/K9252 | 75 | 4 | 1500 | 183 | 75 | 276 | 4 | 1.70 | 15.29 | 99.34 | 261.6 | 0.638 | 0.665 | 2.00 | 2.00 | 0.00 | 90.4 | 83.0 | 68.4 | 57.4 | 46.4 | 0.409 | 165 | 1.856 | 1.785 | 1.000 | 0.091 | 0.950 |
| MV/K9254A | 75 | 4 | 1500 | 183 | 75 | 299 | 4 | 2.00 | 16.41 | 89.26 | 272.1 | 0.597 | 0.647 | 3.00 | 0.00 | 0.00 | 89.3 | 83.3 | 71.4 | 59.5 | 47.6 | 0.555 | 163 | 1.849 | 1.784 | 1.000 | 0.000 | 0.880 |
| MV/K9280 | 90 | 4 | 1500 | 183 | 90 | 345 | 4 | 2.28 | 20.12 | 89.3 | 332.3 | 0.669 | 0.546 | 0.00 | 5.00 | 0.00 | 91.1 | 85.1 | 70.9 | 59.2 | 48.7 | 0.490 | 181 | 1.331 | 1.428 | 1.000 | 0.000 | 1.370 |
| MV/K9256A | 90 | 4 | 1500 | 185 | 90 | 362 | 4 | 1.72 | 14.10 | 124.40 | 321.7 | 0.680 | 0.680 | 3.00 | 0.00 | 0.00 | 89.3 | 83.3 | 71.4 | 59.5 | 47.6 | 0.549 | 172 | 1.000 | 1.000 | 1.000 | 0.000 | 1.030 |

*co-effic. coefficient

Note : The above table shows the setting values of FRENIC-VG.

400 V series (1)

| Motor specification | | Motor parameters | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
|---------------------|--------------|------------------|--------------------|--------------------|---------------------------|------------|------------|--------------------|---------------------|-------------------|---------------------|-------------------|--------------|--------|-------|--------------------------|--------------------|----------------------|----------------------|--------------------------------------|--------------------------------------|--------------------------------------|--|--|--|--|--|-----------------------------|--|--------------------------------------|--------------------------------------|--------------------------------------|--|--------------|--|--|--|--|
| | | F03 | F04 | F05 | F06 | F07 | F08 | F09 | F10 | F11 | F12 | F13 | F14 | F15 | F16 | F17 | F18 | F19 | F20 | F21 | F22 | F23 | F24 | F25 | H51 | | | | | | | | | | | | | |
| Type | Capacity[kW] | No. of poles | VG7S code No. | | Speed (Rated/Max) [r/min] | Voltage[V] | Current[A] | Max. speed [r/min] | Rated speed [r/min] | Rated voltage [V] | Rated capacity [kW] | Rated current [A] | No. of poles | [%] R1 | [%] X | Pre-exciting current [A] | Torque current [A] | Slip On driving [Hz] | Slip On braking [Hz] | Iron loss co-ef [*] , 1 [%] | Iron loss co-ef [*] , 2 [%] | Iron loss co-ef [*] , 3 [%] | Magnetic saturation co-ef [*] , 1 [%] | Magnetic saturation co-ef [*] , 2 [%] | Magnetic saturation co-ef [*] , 3 [%] | Magnetic saturation co-ef [*] , 4 [%] | Magnetic saturation co-ef [*] , 5 [%] | Secondary time constant [s] | Induced voltage co-ef [*] , [V] | R2 correction co-ef [*] , 1 | R2 correction co-ef [*] , 2 | R2 correction co-ef [*] , 3 | Pre-exciting current correction co-ef [*] , | Load inertia | | | | |
| | | | FRENIC-VG code No. | FRENIC-VG code No. | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| MVK6115 | 3.7 | 4 | 1500/3600 | 376 | 9 | 3.7 | 1500 | 1500 | 376 | 3.7 | 9 | 4 | 6.86 | 13.94 | 3.93 | 7.78 | 2.510 | 2.340 | 2.35 | 2.55 | 1.20 | 90.5 | 82.4 | 68.7 | 57.0 | 45.3 | 0.104 | 294 | 0.880 | 1.440 | 1.000 | 0.028 | 0.016 | | | | | |
| M8115A | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| MVK6133 | 5.5 | 4 | 1500/3600 | 376 | 15 | 5.5 | 1500 | 1500 | 376 | 5.5 | 15 | 4 | 5.50 | 12.78 | 7.15 | 10.74 | 1.311 | 1.370 | 2.00 | 5.00 | 7.00 | 88.0 | 79.2 | 65.6 | 53.6 | 42.2 | 0.078 | 299 | 2.361 | 1.985 | 1.000 | 0.019 | 0.030 | | | | | |
| MVK6133A | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| MVK6135 | 7.5 | 4 | 1500/3600 | 376 | 18.5 | 7.5 | 1500 | 1500 | 376 | 7.5 | 18.5 | 4 | 4.37 | 13.72 | 7.81 | 15.33 | 1.465 | 1.686 | 7.61 | 2.00 | 1.00 | 85.9 | 76.9 | 63.4 | 51.6 | 40.5 | 0.064 | 310 | 1.607 | 1.427 | 1.000 | 0.000 | 0.037 | | | | | |
| MVK6135A | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| MVK6165 | 11 | 4 | 1500/3600 | 376 | 25.0 | 11 | 1500 | 1500 | 376 | 11 | 25 | 4 | 4.27 | 11.67 | 12.39 | 20.15 | 0.988 | 0.824 | 4.53 | 1.88 | 0.22 | 84.9 | 75.0 | 61.6 | 50.0 | 39.4 | 0.087 | 348 | 0.910 | 2.343 | 1.000 | 0.000 | 0.085 | | | | | |
| MVK6165A | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| MVK6167 | 15 | 4 | 1500/3600 | 376 | 31.7 | 15 | 1500 | 1500 | 376 | 15 | 31.7 | 4 | 4.48 | 13.69 | 14.47 | 28.63 | 1.290 | 1.269 | 1.00 | 0.50 | 1.00 | 88.7 | 81.7 | 67.2 | 55.2 | 44.0 | 0.133 | 306 | 1.090 | 1.318 | 1.000 | 0.027 | 0.110 | | | | | |
| MVK6167A | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| MVK6184 | 18.5 | 4 | 1500/3600 | 376 | 37 | 18.5 | 1500 | 1500 | 376 | 18.5 | 37 | 4 | 2.66 | 12.45 | 14.02 | 36.06 | 0.882 | 0.882 | 1.00 | 3.00 | 3.00 | 92.5 | 84.3 | 70.3 | 57.1 | 45.1 | 0.295 | 321 | 1.825 | 1.825 | 1.000 | 0.018 | 0.210 | | | | | |
| MVK6184A | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| MVK6185 | 22 | 4 | 1500/3600 | 376 | 45 | 22 | 1500 | 1500 | 376 | 22 | 45 | 4 | 3.61 | 14.06 | 16.81 | 41.72 | 0.903 | 0.891 | 1.50 | 1.50 | 3.00 | 91.1 | 83.2 | 69.1 | 56.5 | 44.6 | 0.387 | 320 | 1.357 | 1.673 | 1.000 | 0.037 | 0.230 | | | | | |
| MVK6185A | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| MVK6206 | 30 | 4 | 1500/3000 | 376 | 58 | 30 | 1500 | 1500 | 376 | 30 | 58 | 4 | 2.55 | 12.16 | 25.74 | 52.52 | 0.666 | 0.648 | 2.50 | 3.50 | 9.50 | 84.4 | 74.0 | 59.5 | 48.9 | 38.0 | 0.173 | 331 | 2.268 | 2.078 | 1.000 | 0.070 | 0.340 | | | | | |
| MVK6206A | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| MVK6187A | 30 | 4 | 1500/3000 | 376 | 58 | 30 | 1500 | 1500 | 376 | 30 | 58 | 4 | 2.43 | 12.32 | 19.97 | 53.0 | 0.915 | 1.015 | 3.00 | 0.00 | 0.00 | 88.2 | 81.9 | 70.1 | 58.4 | 46.7 | 0.385 | 332 | 1.818 | 1.737 | 1.000 | 0.000 | 0.340 | | | | | |
| MVK6187A | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| MVK6207 | 37 | 4 | 1500/3000 | 376 | 71 | 37 | 1500 | 1500 | 376 | 37 | 71 | 4 | 2.49 | 14.11 | 30.07 | 65.54 | 0.497 | 0.498 | 1.79 | 1.80 | 5.00 | 85.4 | 75.7 | 62.3 | 50.5 | 39.9 | 0.184 | 336 | 3.200 | 3.064 | 1.000 | 0.095 | 0.410 | | | | | |
| MVK6207A | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| MVK6208 | 45 | 4 | 1500/3000 | 376 | 85 | 45 | 1500 | 1500 | 376 | 45 | 85 | 4 | 2.73 | 15.30 | 28.36 | 84.85 | 0.947 | 0.937 | 0.50 | 1.50 | 1.85 | 89.2 | 81.6 | 67.6 | 56.2 | 43.4 | 0.295 | 328 | 1.229 | 1.502 | 1.000 | 0.089 | 0.470 | | | | | |
| MVK6208A | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| MVK9250 | 55 | 4 | 1500/2400 | 376 | 108 | 55 | 1500 | 1500 | 376 | 55 | 108 | 4 | 2.05 | 12.20 | 33.11 | 98.98 | 0.621 | 0.595 | 3.00 | 0.83 | 0.21 | 91.5 | 83.8 | 70.6 | 57.8 | 45.6 | 0.413 | 336 | 1.615 | 1.753 | 1.000 | 0.000 | 0.800 | | | | | |
| MVK9250A | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| MVK9252 | 55 | 4 | 1500/2400 | 365 | 111 | 55 | 1500 | 1500 | 365 | 55 | 111 | 4 | 1.99 | 13.96 | 37.76 | 99.0 | 0.721 | 0.721 | 3.00 | 0.00 | 0.00 | 89.3 | 83.3 | 71.4 | 59.5 | 47.6 | 0.531 | 339 | 1.000 | 1.000 | 1.000 | 0.000 | 0.530 | | | | | |
| MVK9252A | 75 | 4 | 1500/2400 | 365 | 138 | 75 | 1500 | 1500 | 365 | 75 | 138 | 4 | 1.71 | 15.39 | 49.67 | 130.8 | 0.638 | 0.665 | 2.00 | 2.00 | 0.00 | 90.4 | 83.0 | 68.4 | 57.4 | 46.4 | 0.409 | 330 | 1.856 | 1.785 | 1.000 | 0.091 | 0.950 | | | | | |
| MVK9254 | 75 | 4 | 1500/2400 | 365 | 149 | 75 | 1500 | 1500 | 365 | 75 | 149 | 4 | 1.77 | 16.39 | 44.04 | 135.0 | 0.714 | 0.714 | 3.00 | 0.00 | 0.00 | 89.3 | 83.3 | 71.4 | 59.5 | 47.6 | 0.627 | 339 | 1.000 | 1.000 | 1.000 | 0.000 | 0.880 | | | | | |
| MVK9254A | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| MVK9280 | 90 | 4 | 1500/2000 | 370 | 173 | 90 | 1500 | 1500 | 370 | 90 | 173 | 4 | 2.23 | 18.47 | 44.37 | 164.1 | 0.685 | 0.647 | 0.00 | 2.00 | 0.00 | 90.7 | 83.7 | 69.0 | 57.1 | 44.9 | 0.590 | 348 | 1.093 | 1.212 | 1.000 | 0.163 | 1.370 | | | | | |
| MVK9280A | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| MVK9256A | 90 | 4 | 1500/2000 | 370 | 179 | 90 | 1500 | 1500 | 370 | 90 | 179 | 4 | 1.51 | 13.93 | 62.28 | 159.2 | 0.600 | 0.600 | 3.00 | 0.00 | 0.00 | 89.3 | 83.3 | 71.4 | 59.5 | 47.6 | 0.621 | 345 | 1.000 | 1.000 | 1.000 | 0.000 | 1.030 | | | | | |
| MVK9282 | 110 | 4 | 1500/3000 | 375 | 206 | 110 | 1500 | 1500 | 375 | 110 | 206 | 4 | 2.14 | 16.83 | 53.03 | 195.8 | 0.557 | 0.606 | 0.44 | 0.00 | 0.00 | 90.1 | 82.6 | 67.7 | 56.3 | 44.2 | 0.577 | 350 | 1.488 | 1.172 | 1.000 | 0.090 | 1.600 | | | | | |
| MVK9284A | 110 | 4 | 1500/2000 | 370 | 212 | 110 | 1500 | 1500 | 370 | 110 | 212 | 4 | 1.66 | 15.39 | 59.73 | 192.9 | 0.579 | 0.579 | 3.00 | 0.00 | 0.00 | 89.3 | 83.3 | 71.4 | 59.5 | 47.6 | 0.824 | 346 | 1.000 | 1.000 | 1.000 | 0.000 | 1.540 | | | | | |
| MVK9310 | 132 | 4 | 1500/3000 | 375 | 248 | 132 | 1500 | 1500 | 375 | 132 | 248 | 4 | 1.56 | 17.21 | 62.05 | 237.3 | 0.481 | 0.531 | 0.00 | 0.39 | 0.00 | 90.1 | 81.2 | 67.7 | 56.2 | 45.9 | 0.689 | 336 | 1.468 | 1.424 | 1.000 | 0.000 | 2.680 | | | | | |
| MVK9286A | 132 | 4 | 1500/2000 | 375 | 247 | 132 | 1500 | 1500 | 375 | 132 | 247 | 4 | 1.57 | 15.65 | 59.05 | 237.4 | 0.592 | 0.592 | 3.00 | 0.00 | 0.00 | 89.3 | 83.3 | 71.4 | 59.5 | 47.6 | 0.876 | 351 | 1.000 | 1.000 | 1.000 | 0.000 | 1.770 | | | | | |

*co-ef: coefficient

Note : The above table shows the setting values of FRENIC-VG.

400 V series (2)

| Motor specification | | VG7S code No. | | Motor parameters | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
|---------------------|-----|--------------------|-----------|----------------------------|-------------|--------------|------|---------------|--------------|-------|-------|-------|------|------|------|------|------|------|------|------|------|------|------|------|------|-------|-------|-------|-------|-------|-------|-------|-------|-------|
| | | FRENIC-VG code No. | | Speed (Rated/Max.) [r/min] | Current [A] | No. of poles | Type | Capacity [kW] | No. of poles | F03 | F04 | F05 | F06 | F07 | F08 | F09 | F10 | F11 | F12 | F13 | F14 | F15 | F16 | F17 | F18 | F19 | P20 | P21 | P22 | P23 | P24 | P25 | H51 | |
| MVK9312 | 160 | 4 | 1500/2400 | 375 | 297 | 4 | 1.15 | 17.47 | 70.71 | 286.3 | 0.518 | 0.518 | 0.00 | 0.00 | 0.00 | 0.00 | 0.00 | 0.00 | 0.00 | 0.00 | 0.00 | 91.0 | 84.3 | 71.8 | 59.1 | 47.7 | 1.127 | 330 | 1.496 | 1.496 | 1.496 | 1.000 | 0.000 | 3.220 |
| MVK931LA | 160 | 4 | 1500/2000 | 375 | 297 | 4 | 1.36 | 16.71 | 76.07 | 287.2 | 0.594 | 0.594 | 3.00 | 0.00 | 0.00 | 0.00 | 0.00 | 0.00 | 0.00 | 0.00 | 89.3 | 83.3 | 71.4 | 59.5 | 47.6 | 0.948 | 351 | 1.000 | 1.000 | 1.000 | 1.000 | 0.000 | 2.970 | |
| MVK528KA | 160 | 4 | 1500/2000 | 370 | 300 | 4 | 1.35 | 18.03 | 71.69 | 284.7 | 0.640 | 0.640 | 2.26 | 0.00 | 0.00 | 0.00 | 0.00 | 0.00 | 0.00 | 0.00 | 93.8 | 87.5 | 75.0 | 62.5 | 50.0 | 0.906 | 340 | 1.000 | 1.000 | 1.000 | 1.000 | 0.000 | 1.720 | |
| MVK9316 | 200 | 4 | 1500/2400 | 375 | 369 | 4 | 1.15 | 14.98 | 107.7 | 341.5 | 0.470 | 0.441 | 0.00 | 2.50 | 0.00 | 0.00 | 0.00 | 0.00 | 0.00 | 0.00 | 93.8 | 87.6 | 74.8 | 60.6 | 48.2 | 1.026 | 342 | 1.175 | 1.358 | 1.000 | 0.104 | 3.900 | | |
| MVK931MA | 200 | 4 | 1500/2000 | 375 | 376 | 4 | 1.17 | 13.73 | 121.00 | 357.0 | 0.492 | 0.492 | 3.00 | 0.00 | 0.00 | 0.00 | 0.00 | 0.00 | 0.00 | 0.00 | 89.3 | 83.3 | 71.4 | 59.5 | 47.6 | 0.894 | 353 | 1.000 | 1.000 | 1.000 | 0.000 | 3.290 | | |
| MVK528LA | 200 | 4 | 1500/2000 | 375 | 375 | 4 | 1.27 | 16.82 | 106.1 | 351.8 | 0.615 | 0.615 | 2.20 | 0.00 | 0.00 | 0.00 | 0.00 | 0.00 | 0.00 | 0.00 | 93.7 | 87.5 | 75.0 | 62.5 | 50.0 | 0.785 | 343 | 1.000 | 1.000 | 1.000 | 0.000 | 1.830 | | |
| MVK9318 | 220 | 4 | 1500/2000 | 370 | 409 | 4 | 1.63 | 14.54 | 98.64 | 385.3 | 0.447 | 0.458 | 1.00 | 1.00 | 0.00 | 0.00 | 0.00 | 0.00 | 0.00 | 0.00 | 95.1 | 88.5 | 75.0 | 63.1 | 51.3 | 1.758 | 361 | 1.535 | 1.513 | 1.000 | 0.078 | 4.260 | | |
| MVK931NA | 220 | 4 | 1500/2000 | 380 | 409 | 4 | 1.05 | 13.27 | 130.40 | 388.2 | 0.473 | 0.473 | 3.00 | 0.00 | 0.00 | 0.00 | 0.00 | 0.00 | 0.00 | 0.00 | 89.3 | 83.3 | 71.4 | 59.5 | 47.6 | 0.935 | 359 | 1.000 | 1.000 | 1.000 | 0.000 | 3.660 | | |
| MVK531FA | 220 | 4 | 1500/2000 | 375 | 415 | 4 | 1.08 | 14.90 | 135.0 | 383.0 | 0.508 | 0.508 | 2.41 | 0.00 | 0.00 | 0.00 | 0.00 | 0.00 | 0.00 | 0.00 | 93.7 | 87.5 | 75.0 | 62.5 | 50.0 | 0.820 | 344 | 1.000 | 1.000 | 1.000 | 0.000 | 2.330 | | |

*co-ef.: coefficient

Note : The above table shows the setting values of FRENIC-VG.

400 V series

| Motor specification | | Motor parameters | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
|---------------------|---------------|------------------|---------------------------|-------------|-------------|--------------------|---------------|---------------------|-------------------|---------------------|-------------------|--------------|-------|-------|--------------------------|--------------------|----------------------|----------------------|-------------------------------------|-------------------------------------|-------------------------------------|---|---|---|---|---|-----------------------------|---|-------------------------------------|-------------------------------------|-------------------------------------|---|
| | | 03 | F03 | F04 | F05 | F07 | F08 | F09 | F10 | F11 | F12 | F13 | F14 | F15 | F16 | F17 | F18 | F19 | F20 | F21 | F22 | F23 | F24 | C14 | | | | | | | | |
| Type | Capacity [kW] | No. of poles | Speed (Rated/Max) [r/min] | Voltage [V] | Current [A] | FRENIC-VG code No. | VG5S code No. | 177 | 175 | 174 | 176 | 178 | 182 | 183 | 184 | 185 | 186 | 187 | 188 | 189 | 190 | 191 | 192 | 193 | 194 | 195 | 196 | 197 | C03 | C04 | - | C14 |
| | | | | | | | | Rated speed [r/min] | Rated voltage [V] | Rated capacity [kW] | Rated current [A] | No. of poles | %R1 | %X | Pre-exciting current [A] | Torque current [A] | Slip on driving [Hz] | Slip on braking [Hz] | Iron loss co-e ^f * 1 [%] | Iron loss co-e ^f * 2 [%] | Iron loss co-e ^f * 3 [%] | Magnetic saturation co-e ^f * 1 [%] | Magnetic saturation co-e ^f * 2 [%] | Magnetic saturation co-e ^f * 3 [%] | Magnetic saturation co-e ^f * 4 [%] | Magnetic saturation co-e ^f * 5 [%] | Secondary time constant [s] | Induced voltage co-e ^f * [V] | R2 correction co-e ^f * 1 | R2 correction co-e ^f * 2 | R2 correction co-e ^f * 3 | Pre-exciting current correction co-e ^f * |
| MV/K6115 | 3.7 | 4 | 1500/3600 | 376 | 9 | 1500 | 1500 | 376 | 3.7 | 9 | 4 | 6.86 | 13.94 | 3.93 | 7.78 | 2.510 | 2.340 | 2.35 | 2.55 | 1.20 | 90.5 | 82.4 | 68.7 | 57.0 | 45.3 | 0.104 | 294 | 0.880 | 1.440 | 1.000 | 0.028 | |
| MV/K6133 | 5.5 | 4 | 1500/3600 | 376 | 15 | 1500 | 1500 | 376 | 5.5 | 15 | 4 | 5.50 | 12.78 | 7.15 | 10.74 | 1.311 | 1.370 | 2.00 | 5.00 | 7.00 | 88.0 | 79.2 | 65.6 | 53.6 | 42.2 | 0.078 | 299 | 2.361 | 1.985 | 1.000 | 0.019 | |
| MV/K6135 | 7.5 | 4 | 1500/3600 | 376 | 18.5 | 1500 | 1500 | 376 | 7.5 | 18.5 | 4 | 4.37 | 13.72 | 7.81 | 15.33 | 1.465 | 1.686 | 7.61 | 2.00 | 1.00 | 85.9 | 76.9 | 63.4 | 51.6 | 40.5 | 0.064 | 310 | 1.607 | 1.427 | 1.000 | 0.000 | |
| MV/K6165 | 11 | 4 | 1500/3600 | 376 | 25.0 | 1500 | 1500 | 376 | 11 | 25 | 4 | 4.27 | 11.67 | 12.39 | 20.15 | 0.988 | 0.824 | 4.53 | 1.88 | 0.22 | 84.9 | 75.0 | 61.6 | 50.0 | 39.4 | 0.087 | 348 | 0.910 | 2.343 | 1.000 | 0.000 | |
| MV/K6167 | 15 | 4 | 1500/3600 | 376 | 31.7 | 1500 | 1500 | 376 | 15 | 31.7 | 4 | 4.48 | 13.69 | 14.47 | 28.63 | 1.290 | 1.269 | 1.00 | 0.50 | 1.00 | 88.7 | 81.7 | 67.2 | 55.2 | 44.0 | 0.133 | 306 | 1.090 | 1.318 | 1.000 | 0.027 | |
| MV/K6184 | 18.5 | 4 | 1500/3600 | 376 | 37 | 1500 | 1500 | 376 | 18.5 | 37 | 4 | 2.66 | 12.45 | 14.02 | 36.06 | 0.882 | 0.882 | 1.00 | 3.00 | 3.00 | 92.5 | 84.3 | 70.3 | 57.1 | 45.1 | 0.295 | 321 | 1.825 | 1.825 | 1.000 | 0.018 | |
| MV/K6185 | 22 | 4 | 1500/3600 | 376 | 45 | 1500 | 1500 | 376 | 22 | 45 | 4 | 3.61 | 14.06 | 16.81 | 41.72 | 0.903 | 0.891 | 1.50 | 1.50 | 3.00 | 91.1 | 83.2 | 69.1 | 56.5 | 44.6 | 0.387 | 320 | 1.357 | 1.673 | 1.000 | 0.037 | |
| MV/K6206 | 30 | 4 | 1500/3000 | 376 | 58 | 1500 | 1500 | 376 | 30 | 58 | 4 | 2.55 | 12.16 | 25.74 | 52.52 | 0.666 | 0.648 | 2.50 | 3.50 | 9.50 | 84.4 | 74.0 | 59.5 | 48.9 | 38.0 | 0.173 | 331 | 2.268 | 2.078 | 1.000 | 0.070 | |
| MV/K6207 | 37 | 4 | 1500/3000 | 376 | 71 | 1500 | 1500 | 376 | 37 | 71 | 4 | 2.49 | 14.11 | 30.07 | 65.54 | 0.497 | 0.498 | 1.79 | 1.80 | 5.00 | 85.4 | 75.7 | 62.3 | 50.5 | 39.9 | 0.184 | 336 | 3.200 | 3.064 | 1.000 | 0.095 | |
| MV/K6208 | 45 | 4 | 1500/3000 | 376 | 85 | 1500 | 1500 | 376 | 45 | 85 | 4 | 2.73 | 15.30 | 28.36 | 84.85 | 0.947 | 0.937 | 0.50 | 1.50 | 1.85 | 89.2 | 81.6 | 67.6 | 56.2 | 43.4 | 0.295 | 328 | 1.229 | 1.502 | 1.000 | 0.089 | |
| MV/K9250 | 55 | 4 | 1500/2400 | 376 | 108 | 1500 | 1500 | 376 | 55 | 108 | 4 | 2.05 | 12.20 | 33.11 | 98.98 | 0.621 | 0.595 | 3.00 | 0.83 | 0.21 | 91.5 | 83.8 | 70.6 | 57.8 | 45.6 | 0.413 | 336 | 1.615 | 1.753 | 1.000 | 0.000 | |
| MV/K9252 | 75 | 4 | 1500/2400 | 365 | 138 | 1500 | 1500 | 365 | 75 | 138 | 4 | 1.71 | 15.39 | 49.67 | 130.8 | 0.638 | 0.665 | 2.00 | 2.00 | 0.00 | 90.4 | 83.0 | 68.4 | 57.4 | 46.4 | 0.409 | 330 | 1.856 | 1.785 | 1.000 | 0.091 | |
| MV/K9280 | 90 | 4 | 1500/2000 | 370 | 173 | 1500 | 1500 | 370 | 90 | 173 | 4 | 2.23 | 18.47 | 44.37 | 164.1 | 0.685 | 0.647 | 0.00 | 2.00 | 0.00 | 90.7 | 83.7 | 69.0 | 57.1 | 44.9 | 0.590 | 348 | 1.093 | 1.212 | 1.000 | 0.163 | |
| MV/K9282 | 110 | 4 | 1500/3000 | 375 | 206 | 1500 | 1500 | 375 | 110 | 206 | 4 | 2.14 | 16.83 | 53.03 | 195.8 | 0.557 | 0.606 | 0.44 | 0.00 | 0.00 | 90.1 | 82.6 | 67.7 | 56.3 | 44.2 | 0.577 | 350 | 1.488 | 1.172 | 1.000 | 0.090 | |
| MV/K9310 | 132 | 4 | 1500/3000 | 375 | 248 | 1500 | 1500 | 375 | 132 | 248 | 4 | 1.56 | 17.21 | 62.05 | 237.3 | 0.481 | 0.531 | 0.00 | 0.39 | 0.00 | 90.1 | 81.2 | 67.7 | 56.2 | 45.9 | 0.689 | 336 | 1.468 | 1.424 | 1.000 | 0.000 | |
| MV/K9312 | 160 | 4 | 1500/2400 | 375 | 297 | 1500 | 1500 | 375 | 160 | 297 | 4 | 1.15 | 17.47 | 70.71 | 286.3 | 0.518 | 0.518 | 0.00 | 0.00 | 0.00 | 91.0 | 84.3 | 71.8 | 59.1 | 47.7 | 1.127 | 330 | 1.496 | 1.496 | 1.000 | 0.000 | |
| MV/K9316 | 200 | 4 | 1500/2400 | 375 | 369 | 1500 | 1500 | 375 | 200 | 369 | 4 | 1.15 | 14.98 | 107.7 | 341.5 | 0.470 | 0.441 | 0.00 | 2.50 | 0.00 | 93.8 | 87.6 | 74.8 | 60.6 | 48.2 | 1.026 | 342 | 1.175 | 1.358 | 1.000 | 0.104 | |
| MV/K9318 | 220 | 4 | 1500/2000 | 370 | 409 | 1500 | 1500 | 370 | 220 | 409 | 4 | 1.63 | 14.54 | 98.64 | 385.3 | 0.447 | 0.458 | 1.00 | 1.00 | 0.00 | 95.1 | 88.5 | 75.0 | 63.1 | 51.3 | 1.758 | 361 | 1.535 | 1.513 | 1.000 | 0.078 | |

*co-e^f: coefficient

Note : The above table shows the setting values of FRENIC-VG.

12.6.3 Replacing VG3

200 V series

| Motor specification | | Motor parameters | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
|---------------------|--------------|--------------------|----------------------------|-------------------|---------------------|-------------------|---------------------|--------------------|---------------------|-------------------|---------------------|-------------------|--------------------------|--------------------|----------------------|----------------------|------------------------------------|------------------------------------|------------------------------------|--|--|--|--|--|-----------------------------|--|------------------------------------|------------------------------------|------------------------------------|--|
| | | FRENIC-VG code No. | Speed (Rated/Max.) [r/min] | Voltage [V] | Current [A] | F03 | F04 | F05 | F03 | F04 | F05 | F06 | F07 | F08 | F09 | F10 | F11 | F12 | F13 | F14 | F15 | F16 | F17 | F18 | F19 | F20 | F21 | F22 | F23 | F24 |
| Type | No. of poles | Capacity [kW] | No. of poles | Rated current [A] | Rated capacity [kW] | Rated voltage [V] | Rated speed [r/min] | Max. speed [r/min] | Rated speed [r/min] | Rated voltage [V] | Rated capacity [kW] | Rated current [A] | Pre-exciting current [A] | Torque current [A] | Slip on driving [Hz] | Slip on braking [Hz] | Iron loss co-ef [*] 1 [%] | Iron loss co-ef [*] 2 [%] | Iron loss co-ef [*] 3 [%] | Magnetic saturation co-ef [*] 1 [%] | Magnetic saturation co-ef [*] 2 [%] | Magnetic saturation co-ef [*] 3 [%] | Magnetic saturation co-ef [*] 4 [%] | Magnetic saturation co-ef [*] 5 [%] | Secondary time constant [s] | Induced voltage co-ef [*] [V] | R2 correction co-ef [*] 1 | R2 correction co-ef [*] 2 | R2 correction co-ef [*] 3 | Pre-exciting current correction co-ef [*] |
| MVK6096 | 4 | 0.75 | 4 | 5.4 | 0.75 | 160 | 1500 | 1500 | 1500 | 160 | 0.75 | 5.4 | 2.65 | 4.55 | 2.360 | 2.560 | 2.30 | 1.90 | 0.10 | 94.1 | 87.8 | 74.9 | 62.7 | 50.2 | 0.152 | 96 | 1.000 | 1.000 | 1.000 | 0.000 |
| MVK6097 | 4 | 1.5 | 4 | 9.8 | 1.5 | 160 | 1500 | 1500 | 1500 | 160 | 1.5 | 9.8 | 2.65 | 9.09 | 4.700 | 5.100 | 2.30 | 1.90 | 0.10 | 94.1 | 87.8 | 74.9 | 62.7 | 50.2 | 0.152 | 96 | 1.000 | 1.000 | 1.000 | 0.000 |
| MVK6107 | 4 | 2.2 | 4 | 12.2 | 2.2 | 160 | 1500 | 1500 | 1500 | 160 | 2.2 | 12.2 | 4.15 | 11.00 | 3.340 | 3.600 | 4.80 | 0.00 | 0.10 | 93.7 | 87.1 | 74.1 | 60.8 | 47.8 | 0.096 | 116 | 1.000 | 1.000 | 1.000 | 0.000 |
| MVK6115 | 4 | 3.7 | 4 | 19.9 | 3.7 | 160 | 1500 | 1500 | 1500 | 160 | 3.7 | 19.9 | 7.25 | 18.60 | 2.540 | 3.440 | 0.00 | 0.00 | 0.10 | 89.4 | 80.4 | 66.7 | 54.5 | 42.7 | 0.172 | 115 | 1.000 | 1.000 | 1.000 | 0.000 |
| MVK6133 | 4 | 5.5 | 4 | 30.2 | 5.5 | 160 | 1500 | 1500 | 1500 | 160 | 5.5 | 30.2 | 14.93 | 26.10 | 1.680 | 2.200 | 0.00 | 0.00 | 0.00 | 87.1 | 77.6 | 63.5 | 51.8 | 40.8 | 0.200 | 122 | 1.000 | 1.000 | 1.000 | 0.000 |
| MVK6135 | 4 | 7.5 | 4 | 41.8 | 7.5 | 160 | 1500 | 1500 | 1500 | 160 | 7.5 | 41.8 | 18.90 | 37.30 | 1.960 | 2.000 | 0.00 | 0.00 | 0.00 | 82.8 | 72.3 | 58.6 | 48.0 | 38.3 | 0.220 | 120 | 1.000 | 1.000 | 1.000 | 0.000 |
| MVK6165 | 4 | 11 | 4 | 54.7 | 11 | 160 | 1500 | 1500 | 1500 | 160 | 11 | 54.7 | 24.00 | 49.10 | 1.320 | 1.500 | 0.00 | 0.00 | 0.00 | 77.6 | 79.6 | 65.9 | 53.7 | 43.1 | 0.320 | 130 | 1.000 | 1.000 | 1.000 | 0.000 |
| MVK6167 | 4 | 15 | 4 | 70.5 | 15 | 160 | 1500 | 1500 | 1500 | 160 | 15 | 70.5 | 28.20 | 64.60 | 1.320 | 1.520 | 0.00 | 0.00 | 0.00 | 91.0 | 83.1 | 69.0 | 56.9 | 45.1 | 0.336 | 135 | 1.000 | 1.000 | 1.000 | 0.000 |
| MVK6185 | 4 | 18.5 | 4 | 89.6 | 18.5 | 160 | 1500 | 1500 | 1500 | 160 | 18.5 | 89.6 | 36.80 | 81.70 | 0.820 | 0.940 | 0.00 | 0.00 | 0.00 | 89.4 | 80.0 | 62.7 | 50.2 | 40.0 | 0.364 | 131 | 1.000 | 1.000 | 1.000 | 0.000 |
| MVK6187 | 4 | 22 | 4 | 104.3 | 22 | 160 | 1500 | 1500 | 1500 | 160 | 22 | 104.3 | 45.70 | 93.80 | 0.780 | 1.000 | 0.00 | 0.00 | 0.00 | 89.4 | 81.2 | 67.5 | 50.2 | 43.9 | 0.384 | 136 | 1.000 | 1.000 | 1.000 | 0.000 |
| MVK6205 | 4 | 30 | 4 | 140.6 | 30 | 160 | 1500 | 1500 | 1500 | 160 | 30 | 140.6 | 51.20 | 130.9 | 0.800 | 0.940 | 0.00 | 0.00 | 0.00 | 89.8 | 80.4 | 65.9 | 53.7 | 42.4 | 0.568 | 133 | 1.000 | 1.000 | 1.000 | 0.000 |
| MVK6206 | 4 | 37 | 4 | 164.5 | 37 | 160 | 1500 | 1500 | 1500 | 160 | 37 | 164.5 | 51.10 | 156.3 | 0.720 | 0.940 | 0.00 | 0.00 | 0.00 | 90.6 | 80.4 | 65.9 | 54.1 | 43.1 | 0.484 | 137 | 1.000 | 1.000 | 1.000 | 0.000 |
| MVK6207 | 4 | 45 | 4 | 195.6 | 45 | 160 | 1500 | 1500 | 1500 | 160 | 45 | 195.6 | 54.40 | 187.9 | 0.960 | 1.100 | 0.00 | 0.00 | 0.00 | 91.4 | 82.7 | 69.0 | 57.3 | 45.5 | 0.732 | 138 | 1.000 | 1.000 | 1.000 | 0.000 |

*co-ef.: coefficient

Note : The above table shows the setting values of FRENIC-VG.

400 V series

| Motor specification | | FRENIC-VG code No. | | Motor parameters | | | | | | | | | | | | | | | | | | | | | | | | | | | |
|---------------------|---------------|----------------------------|--------------------|------------------|-------------|--------------------|---------------------|-------------------|---------------------|-------------------|--------------|-------------------|------------------|--------------------------|--------------------|----------------------|----------------------|------------------------|------------------------|------------------------|----------------------------------|----------------------------------|----------------------------------|----------------------------------|----------------------------------|-----------------------------|----------------------------|------------------------|------------------------|------------------------|--|
| | | Speed (Rated/Max.) [r/min] | Voltage [V] | Current [A] | F03 | F04 | F05 | F03 | F04 | F05 | F06 | F07 | F08 | F09 | F10 | F11 | F12 | F13 | F14 | F15 | F16 | F17 | F18 | F19 | F20 | F21 | F22 | F23 | F24 | F25 | |
| Type | Capacity [kW] | No. of poles | Rated/Max. [r/min] | Voltage [V] | Current [A] | Max. speed [r/min] | Rated speed [r/min] | Rated voltage [V] | Rated capacity [kW] | Rated current [A] | No. of poles | % I _{DR} | % X _σ | Pre-exciting current [A] | Torque current [A] | Slip on driving [Hz] | Slip On braking [Hz] | Iron loss co-ef* 1 [%] | Iron loss co-ef* 2 [%] | Iron loss co-ef* 3 [%] | Magnetic saturation co-ef* 1 [%] | Magnetic saturation co-ef* 2 [%] | Magnetic saturation co-ef* 3 [%] | Magnetic saturation co-ef* 4 [%] | Magnetic saturation co-ef* 5 [%] | Secondary time constant [s] | Induced voltage co-ef* [V] | R2 correction co-ef* 1 | R2 correction co-ef* 2 | R2 correction co-ef* 3 | Pre-exciting current correction co-ef* |
| MVK6115 | 3.7 | 4 | 1500/3600 | 320 | 10 | 1500 | 1500 | 320 | 3.7 | 10 | 4 | 7.07 | 14.40 | 3.62 | 9.30 | 2.540 | 3.280 | 0.00 | 0.00 | 0.00 | 89.4 | 80.4 | 66.7 | 54.5 | 42.7 | 0.172 | 230 | 1.000 | 1.000 | 1.000 | 0.000 |
| MVK6133 | 5.5 | 4 | 1500/3600 | 320 | 15.5 | 1500 | 1500 | 320 | 5.5 | 15.1 | 4 | 4.89 | 13.44 | 7.50 | 13.10 | 1.680 | 1.880 | 0.00 | 0.00 | 0.00 | 87.1 | 77.6 | 63.5 | 51.8 | 40.8 | 0.200 | 242 | 1.000 | 1.000 | 1.000 | 0.000 |
| MVK6135 | 7.5 | 4 | 1500/3600 | 320 | 20.5 | 1500 | 1500 | 320 | 7.5 | 20.3 | 4 | 4.84 | 13.35 | 9.30 | 18.00 | 1.960 | 2.000 | 0.00 | 0.00 | 0.00 | 86.7 | 76.1 | 60.8 | 49.4 | 38.4 | 0.224 | 241 | 1.000 | 1.000 | 1.000 | 0.000 |
| MVK6165 | 11 | 4 | 1500/3600 | 320 | 29 | 1500 | 1500 | 320 | 11 | 27.4 | 4 | 3.79 | 14.03 | 12.00 | 24.60 | 1.320 | 1.420 | 0.00 | 0.00 | 0.00 | 88.6 | 79.6 | 65.9 | 53.7 | 43.1 | 0.320 | 258 | 1.000 | 1.000 | 1.000 | 0.000 |
| MVK6167 | 15 | 4 | 1500/3600 | 320 | 37 | 1500 | 1500 | 320 | 15 | 35.3 | 4 | 3.17 | 13.24 | 14.10 | 32.30 | 1.200 | 1.400 | 0.00 | 0.00 | 0.00 | 91.0 | 83.1 | 69.0 | 56.9 | 45.1 | 0.336 | 268 | 1.000 | 1.000 | 1.000 | 0.000 |
| MVK6185 | 18.5 | 4 | 1500/3600 | 320 | 45 | 1500 | 1500 | 320 | 18.5 | 44.5 | 4 | 2.60 | 13.86 | 18.10 | 39.00 | 0.940 | 0.960 | 1.10 | 3.10 | 1.70 | 91.4 | 83.1 | 68.6 | 56.1 | 45.9 | 0.412 | 274 | 1.000 | 1.000 | 1.000 | 0.000 |
| MVK6187 | 22 | 4 | 1500/3600 | 320 | 53 | 1500 | 1500 | 320 | 22 | 53.2 | 4 | 2.52 | 13.46 | 19.90 | 47.60 | 0.960 | 1.000 | 2.20 | 1.60 | 0.70 | 92.9 | 85.1 | 71.4 | 58.8 | 46.7 | 0.412 | 267 | 1.000 | 1.000 | 1.000 | 0.000 |
| MVK6205 | 30 | 4 | 1500/3000 | 320 | 71 | 1500 | 1500 | 320 | 30 | 70.3 | 4 | 2.57 | 15.08 | 25.60 | 65.50 | 0.800 | 0.940 | 0.00 | 0.00 | 0.00 | 89.8 | 80.4 | 65.9 | 53.7 | 42.4 | 0.568 | 265 | 1.000 | 1.000 | 1.000 | 0.000 |
| MVK6206 | 37 | 4 | 1500/3000 | 320 | 89 | 1500 | 1500 | 320 | 37 | 78.4 | 4 | 2.35 | 13.38 | 25.20 | 74.30 | 0.740 | 0.860 | 0.00 | 0.00 | 0.00 | 90.6 | 80.8 | 67.5 | 52.5 | 40.8 | 0.460 | 288 | 1.000 | 1.000 | 1.000 | 0.000 |
| MVK6207 | 45 | 4 | 1500/3000 | 320 | 102 | 1500 | 1500 | 320 | 45 | 97.8 | 4 | 2.49 | 16.38 | 27.20 | 94.00 | 0.840 | 1.100 | 0.00 | 0.00 | 0.00 | 91.4 | 82.7 | 69.0 | 57.3 | 45.5 | 0.732 | 277 | 1.000 | 1.000 | 1.000 | 0.000 |
| MVK6256 | 75 | 4 | 1500/2400 | 320 | 170 | 1500 | 1500 | 320 | 75 | 170 | 4 | 1.73 | 14.88 | 47.38 | 162.8 | 0.840 | 0.960 | 0.00 | 0.00 | 0.00 | 92.6 | 85.2 | 72.3 | 60.5 | 48.4 | 0.576 | 266 | 1.000 | 1.000 | 1.000 | 0.000 |

*co-ef: coefficient

Note : The above table shows the setting values of FRENIC-VG.

12.7 Protective Functions

12.7.1 Replacing VG7S

| FRENIC5000 VG7S | | FRENIC-VG | |
|-----------------|------------------------------------|-----------|------------------------------------|
| – | | dbA | Braking transistor error |
| dbH | DB resistor overheat | dbH | Braking resistor overheat |
| dCF | DC fuse blown | dCF | DC fuse blown |
| dO | Excessive position deviation | dO | Excessive position deviation |
| EF | Ground fault | EF | Ground fault |
| – | | EC | Encoder communications error |
| Er1 | Memory error | Er1 | Memory error |
| Er2 | KEYPAD panel communication error | Er2 | KEYPAD panel communication error |
| Er3 | CPU error | Er3 | CPU error |
| Er4 | Network error | Er4 | Network error |
| Er5 | RS-485 communication error | Er5 | RS-485 communication error |
| Er6 | Operation procedure error | Er6 | Operation procedure error |
| Er7 | Output wiring error | Er7 | Output wiring error |
| Er8 | A/D converter error | Er8 | A/D converter error |
| Er9 | Speed disagreement | Er9 | Speed disagreement |
| ErA | UPAC error | ErA | UPAC error |
| Erb | Inter-inverter communication error | Erb | Inter-inverter communication error |
| – | | Err | Mock alarm |
| – | | Et1 | Encoder error |
| IPE | IPM error | – | |
| Lin | Input phase loss | Lin | Input phase loss |
| LU | Undervoltage | LU | Undervoltage |
| nrb | NTC thermistor disconnection | nrb | NTC thermistor disconnection |
| OC | Overcurrent | OC | Overcurrent |
| OH1 | Overheating at heat sink | OH1 | Overheating at heat sink |
| OH2 | External alarm | OH2 | External alarm |
| OH3 | Inverter internal overheat | OH3 | Inverter internal overheat |
| OH4 | Motor overheat | OH4 | Motor overheat |
| OL1 | Motor 1 overload | OL1 | Motor 1 overload |
| OL2 | Motor 2 overload | OL2 | Motor 2 overload |
| OL3 | Motor 3 overload | OL3 | Motor 3 overload |
| OLU | Inverter unit overload | OLU | Inverter unit overload |
| – | | OPL | Output phase loss detection |
| OS | Overspeed | OS | Overspeed |
| OU | Overvoltage | OU | Overvoltage |
| PbF | Charging circuit error | PbF | Charging circuit error |
| – | | ECF | Functional safety circuit error |
| P9 | PG disconnection | P9 | PG disconnection |
| – | | dFA | DC fan lock |
| – | | ErH | Hardware error |
| – | | SrF | Functional safety card error |
| – | | SiF | |
| – | | SnF | |

12.7.2 Replacing VG5S

| FRENIC5000 VG5S | | FRENIC-VG | |
|-----------------|----------------------------------|-----------|------------------------------------|
| - | | dbA | Braking transistor error |
| - | | dbH | Braking resistor overheat |
| dCF | DC fuse blown | dCF | DC fuse blown |
| - | | dO | Excessive position deviation |
| EF | Ground fault | EF | Ground fault |
| - | | EC | Encoder communications error |
| Er1 | Memory error | Er1 | Memory error |
| Er2 | KEYPAD panel communication error | Er2 | KEYPAD panel communication error |
| Er3 | CPU error | Er3 | CPU error |
| Er4 | T-Link communication error | Er4 | Network error |
| Er5 | RS485 communication error | Er5 | RS-485 communication error |
| Er6 | Operation procedure error | Er6 | Operation procedure error |
| Er7 | Output wiring error | Er7 | Output wiring error |
| Er8 | A/D converter error | Er8 | A/D converter error |
| - | | Er9 | Speed disagreement |
| - | | ErA | UPAC error |
| - | | Erb | Inter-inverter communication error |
| - | | Err | Mock alarm |
| - | | Et1 | Encoder error |
| - | | - | |
| - | | Lin | Input phase loss |
| LU | Undervoltage | LU | Undervoltage |
| nrb | NTC thermistor disconnection | nrb | NTC thermistor disconnection |
| OC | Overcurrent | OC | Overcurrent |
| OH1 | Overheating at heat sink | OH1 | Overheating at heat sink |
| OH2 | External alarm | OH2 | External alarm |
| OH3 | Inverter internal overheat | OH3 | Inverter internal overheat |
| OH4 | Motor overheat | OH4 | Motor overheat |
| OL | Motor overload | OL1 | Motor 1 overload |
| - | | OL2 | Motor 2 overload |
| - | | OL3 | Motor 3 overload |
| OLU | Inverter unit overload | OLU | Inverter unit overload |
| - | | OPL | Output phase loss detection |
| OS | Overspeed | OS | Overspeed |
| OU | Overvoltage | OU | Overvoltage |
| PbF | Charging circuit error | PbF | Charging circuit error |
| - | | ECF | Functional safety circuit error |
| P9 | PG disconnection | P9 | PG disconnection |
| - | | dFA | DC fan lock |
| - | | ErH | Hardware error |
| - | | SrF | Functional safety card error |
| - | | SiF | |
| - | | SnF | |

12.7.3 Replacing VG3

| FRENIC5000 VG3 | | FRENIC-VG | |
|----------------|---------------------------------|-----------|------------------------------------|
| – | | dbA | Braking transistor error |
| – | | dbH | Braking resistor overheat |
| dCF | DC fuse blown | dCF | DC fuse blown |
| – | | dO | Excessive position deviation |
| EF | Ground fault | EF | Ground fault |
| – | | EC | Encoder communications error |
| Rf | Memory error | Er1 | Memory error |
| – | | Er2 | KEYPAD panel communication error |
| – | | Er3 | CPU error |
| OPF | T-Link communication error | Er4 | Network error |
| – | | Er5 | RS-485 communication error |
| – | | Er6 | Operation procedure error |
| – | | Er7 | Output wiring error |
| CF | Current detection circuit error | – | |
| – | | Er8 | A/D converter error |
| – | | Er9 | Speed disagreement |
| – | | ErA | UPAC error |
| – | | ErB | Inter-inverter communication error |
| – | | Err | Mock alarm |
| – | | Et1 | Encoder error |
| – | | IPE | IPM error |
| – | | Lin | Input phase loss |
| LU | Undervoltage | LU | Undervoltage |
| rb | NTC thermistor disconnection | nrb | NTC thermistor disconnection |
| OC | Overcurrent | OC | Overcurrent |
| OH1 | Overheating at heat sink | OH1 | Overheating at heat sink |
| OH3 | External alarm | OH2 | External alarm |
| – | | OH3 | Inverter internal overheat |
| OH2 | Motor overheat | OH4 | Motor overheat |
| – | | OL1 | Motor 1 overload |
| – | | OL2 | Motor 2 overload |
| – | | OL3 | Motor 3 overload |
| OL | Inverter overload | OLU | Inverter overload |
| – | | OPL | Output phase loss detection |
| OS | Overspeed | OS | Overspeed |
| OU | Overvoltage | OU | Overvoltage |
| – | | PbF | Charging circuit error |
| – | | ECF | Functional safety circuit error |
| – | | P9 | PG disconnection |
| – | | dFA | DC fan lock |
| – | | ErH | Hardware error |
| – | | SrF | Functional safety card error |
| – | | SiF | |
| – | | SnF | |

12.8 Options

12.8.1 Replacing VG7S

| Name | FRENIC5000 VG7S option | Alternative FRENIC-VG option |
|--|--|---|
| Synchro. interface | OPC-VG7-SN | OPC-VG1-SN |
| F/V converter | OPC-VG7-FV | |
| Aio expansion card | OPC-VG7-AIO | OPC-VG1-AIO |
| Di interface card | OPC-VG7-DI | OPC-VG1-DI |
| DIO expansion card | OPC-VG7-DIO | OPC-VG1-DIO |
| RG interface expansion card | OPC-VG7-PG | OPC-VG1-PG |
| | OPC-VG7-PGo | OPC-VG1-PGo |
| T-Link interface card | OPC-VG7-TL | OPC-VG1-TL |
| Highspeed serial card | OPC-VG7-SI | OPC-VG1-TBSI |
| | OPC-VG7-SIU | OPC-VG1-TBSI |
| RS485 expansion card | OPC-VG7-RS | Built-in. |
| CC-Link interface card | OPC-VG7-CCL | OPC-VG1-CCL |
| For synchronous motor driving PG card | OPC-VG7-PMPG | OPC-VG1-PMPG |
| | OPC-VG7-PMPGo | OPC-VG1-PMPGo |
| UPAC | OPC-VG7-UPAC | OPC-VG1-UPAC |
| SX bus interface card | OPC-VG7-SX | OPC-VG1-SX |
| PROFIBUS-DP | OPC-VG7-PDP | OPC-VG1-PDP |
| DeviceNet | OPC-VG7-DEV | OPC-VG1-DEV |
| Synchro. interface | MCA-VG7-SN | |
| F/V converter | MCA-VG7-FV | |
| Dancer controller | MCAII-PU | |
| PG switcher | MCAII-VG7-CPG | |
| Braking unit | Depends on the capacity | Depends on the capacity (Built-in for 55 kW or less of 200 V series, and for 160 kW or less of 400 V series) |
| Braking resistor | Depends on the capacity | Depends on the capacity |
| AC reactor | Depends on the capacity | Depends on the capacity |
| DC REACTOR | Depends on the capacity | Depends on the capacity (Provided as standard for units of more than 75 kW) |
| Ferrite ring for reducing radio noise. Zero-phase reactor | ACL-40B, ACL-74B | |
| KEYPAD panel extension cable | CBIII-10R-2S CBIII-10R-1C CBIII-10R-2C | Extension cable for extension operation CB-YS |

12.8.2 Replacing VG5S

| Name | FRENIC5000 VG5S option | Alternative FRENIC-VG option |
|--|--|---|
| Adder | OPCII-VG3-AD | |
| I/V, V/I converter | OPCII-VG3-IV | |
| Comparator | OPCII-VG3-CP | |
| Isolation converter | OPCII-VG3-IA | |
| F/V converter | OPCII-VG3-FV | |
| Synchro. interface | OPCII-VG3-SN | OPC-VG1-SN |
| Di interface | OPCII-VG5-DIN | OPC-VG1-DI (DIA, DIB) |
| | OPCII-VG5-DIT | OPC-VG1-DI (DIA, DIB) |
| DIO expansion card | OPCII-VG5-DIO | OPC-VG1-DIO (DIOA) |
| T-Link interface card | OPCII-VG5-TL | OPC-VG1-TL |
| PG interface card | OPCII-VG5-PG1 | Built-in. |
| | OPCII-VG5-PG2 | OPC-VG1-PG |
| Pulse train interface card | OPCII-VG5-PTI | OPC-VG1-PG |
| Adder | MCAII-VG3-AD | |
| I/V, V/I converter | MCAII-VG3-IV | |
| Comparator | MCAII-VG3-CP | |
| Isolation converter | MCAII-VG3-IA | |
| F/V converter | MCAII-VG3-FV | |
| Synchro. interface | MCAII-VG5-SN | |
| Dancer controller | MCAII-PU | |
| Relay unit | MCAII-RY | |
| PG switcher | MCAII-VG5-CPG | |
| Braking unit | Depends on the capacity | Depends on the capacity (Built-in for 55 kW or less of 200 V series, and for 160 kW or less of 400 V series) |
| Braking resistor | Depends on the capacity | Depends on the capacity |
| AC reactor | Depends on the capacity | Depends on the capacity |
| DC REACTOR | Depends on the capacity | Depends on the capacity (Provided as standard for units of more than 75 kW) |
| Ferrite ring for reducing radio noise. Zero-phase reactor | ACL-40B, ACL-74B | |
| KEYPAD panel extension cable | CBIII-10R-2S CBIII-10R-1C CBIII-10R-2C | Extension cable for extension operation CB-YS |

12.8.3 Replacing VG3

| Name | FRENIC5000 VG3 option | Alternative FRENIC-VG option |
|--|------------------------------|---|
| Adder | OPCII-VG3-AD | |
| I/V, V/I converter | OPCII-VG3-IV | |
| Comparator | OPCII-VG3-CP | |
| Isolation converter | OPCII-VG3-IA | |
| F/V converter | OPCII-VG3-FV | |
| Synchro. interface | OPCII-VG3-SN | OPC-VG1-SN |
| Di interface | OPCII-VG3-DI | OPC-VG1-DI(DIA, DIB) |
| AO interface | OPCII-VG3-AO | OPC-VG1-AIO |
| T-Link interface card | OPCII-VG3-T2 OPCII-VG3-TL | OPC-VG1-TL |
| Adder | MCAII-VG3-AD | |
| I/V, V/I converter | MCAII-VG3-IV | |
| Comparator | MCAII-VG3-CP | |
| Isolation converter | MCAII-VG3-IA | |
| F/V converter | MCAII-VG3-FV | |
| Synchro. interface | MCAII-VG5-SN | |
| Dancer controller | MCAII-PU | |
| Relay unit | MCAII-RY | |
| Ground fault detection unit | MCAII-GFD-1 MCAII-GFD-2 | For the output circuit, the ground fault detection function is included as standard. |
| Braking unit | Depends on the capacity | Depends on the capacity (Built-in for 55 kW or less of 200 V series, and for 160 kW or less of 400 V series) |
| Braking resistor | Depends on the capacity | Depends on the capacity |
| AC reactor | Depends on the capacity | Depends on the capacity |
| DC REACTOR | Depends on the capacity | Depends on the capacity (Provided as standard for units of more than 75 kW) |
| Ferrite ring for reducing radio noise. Zero-phase reactor | ACL-10A | |

Chapter 13

TROUBLESHOOTING

This chapter describes troubleshooting procedures to be followed when the inverter malfunctions or detects an alarm or a light alarm condition. In this chapter, first check whether any alarm code or the "light alarm" indication ($L_{-}AL$) is displayed or not, and then proceed to the troubleshooting items.

Contents

| | |
|--|-------|
| 13.1 Protective Functions..... | 13-1 |
| 13.2 Before Proceeding with Troubleshooting..... | 13-2 |
| 13.3 If an alarm code appears on the LED monitor | 13-3 |
| 13.3.1 List of alarm codes | 13-3 |
| 13.3.2 Possible causes of alarms, checks and measures..... | 13-5 |
| [1] dBH Braking transistor error | 13-5 |
| [2] dBH Braking resistor overheated..... | 13-5 |
| [3] dCF Fuse blown | 13-5 |
| [4] dFA DC fan locked | 13-6 |
| [5] dD Excessive positioning deviation..... | 13-6 |
| [6] EF Ground fault..... | 13-6 |
| [7] $Er-1$ Memory error | 13-7 |
| [8] $Er-2$ Keypad communications error | 13-7 |
| [9] $Er-3$ CPU error | 13-8 |
| [10] $Er-4$ Network error..... | 13-8 |
| [11] $Er-5$ RS-485 communications error | 13-9 |
| [12] $Er-6$ Operation error | 13-10 |
| [13] $Er-7$ Output wiring fault..... | 13-11 |
| [14] $Er-8$ A/D converter error | 13-12 |
| [15] $Er-9$ Speed mismatch | 13-12 |
| [16] $Er-b$ Inter-inverter communications link error | 13-13 |
| [17] $Er-H$ Hardware error | 13-14 |
| [18] Err Mock alarm | 13-14 |
| [19] L_{in} Power supply phase loss..... | 13-14 |
| [20] LdL Start delay | 13-15 |
| [21] LU Undervoltage..... | 13-16 |
| [22] $nr-b$ NTC thermistor wire break error..... | 13-17 |
| [23] OL Overcurrent | 13-17 |
| [24] $OH-1$ Heat sink overheat..... | 13-18 |
| [25] $OH-2$ External alarm..... | 13-19 |
| [26] $OH-3$ Inverter internal overheat | 13-19 |
| [27] $OH-4$ Motor overheat (PTC/NTC thermistor)..... | 13-20 |

| | | | |
|--------|------------------|---|-------|
| [28] | $\overline{OL1}$ | Overload of motor 1 through 3..... | 13-21 |
| [29] | \overline{OLU} | Inverter overload..... | 13-21 |
| [30] | \overline{OPL} | Output phase loss..... | 13-22 |
| [31] | \overline{OS} | Overspeed..... | 13-23 |
| [32] | \overline{OLV} | Overvoltage..... | 13-24 |
| [33] | \overline{PG} | PG wire break..... | 13-25 |
| [34] | \overline{PCF} | Charger circuit fault..... | 13-26 |
| [35] | \overline{ECF} | ENABLE input circuit failure (Functional safety circuit error)..... | 13-26 |
| 13.4 | | If the "Light Alarm" Indication ($\overline{L-FL}$) Appears on the LED Monitor..... | 13-27 |
| 13.5 | | If Neither an Alarm Code Nor "Light Alarm" Indication ($\overline{L-FL}$) Appears on the LED Monitor..... | 13-28 |
| 13.5.1 | | Abnormal motor operation..... | 13-28 |
| [1] | | The motor does not rotate..... | 13-28 |
| [2] | | The motor rotates, but the speed does not change..... | 13-31 |
| [3] | | The motor runs in the opposite direction to the command..... | 13-32 |
| [4] | | Speed fluctuation or current oscillation (e.g., hunting) occurs during running at constant speed..... | 13-33 |
| [5] | | Grating sound is heard from the motor or the motor sound fluctuates..... | 13-34 |
| [6] | | The motor does not accelerate or decelerate within the specified time..... | 13-34 |
| [7] | | The motor does not restart even after the power recovers from a momentary power failure..... | 13-35 |
| [8] | | The motor abnormally heats up..... | 13-36 |
| [9] | | The motor does not run as expected..... | 13-36 |
| [10] | | When the motor accelerates or decelerates, the speed is not stable..... | 13-36 |
| [11] | | The motor stalls during acceleration..... | 13-37 |
| [12] | | When the T-Link communications option is in use, neither a run command nor a speed command takes effect..... | 13-37 |
| [13] | | When the SX-bus communications option is in use, neither a run command nor a speed command takes effect..... | 13-38 |
| [14] | | When the CC-Link communications option is in use, neither a run command nor a speed command takes effect..... | 13-38 |
| [15] | | ___ (under bar) appears..... | 13-39 |
| 13.5.2 | | Problems with inverter settings..... | 13-40 |
| [1] | | Nothing appears on the monitors..... | 13-40 |
| [2] | | The desired function code does not appear..... | 13-40 |
| [3] | | Data of function codes cannot be changed <u>from the keypad</u> | 13-41 |
| [4] | | Data of function codes cannot be changed <u>via the communications link</u> | 13-41 |

13.1 Protective Functions

The FRENIC-VG series of inverters has various protective functions as listed below to prevent the system from going down and reduce system downtime. The protective functions marked with an asterisk (*) in the table are disabled by default. Enable them according to your needs.

The protective functions include, for example, the "heavy alarm" detection function which, upon detection of an abnormal state, displays the alarm code and causes the inverter to trip, the "light alarm" detection function which displays the alarm code but lets the inverter continue the current operation, and other warning signal output functions.

If any problem arises, understand the protective functions listed below and follow the procedures given in Section 13.2 and onwards for troubleshooting.

| Protective function | Description |
|---|--|
| "Heavy alarm" detection | <p>This function detects an abnormal state, displays the corresponding alarm code, and causes the inverter to trip. The "heavy alarm" codes are check-marked in the "Heavy alarm" object column in Table 13.1. For details of each alarm code, see the corresponding item in the troubleshooting.</p> <p>The inverter retains the latest and the last 10 alarm codes (see Section 3.4.4.9) and the latest and the last three pieces of alarm information (see Section 3.4.4.8). It can also display them.</p> |
| "Light alarm" detection* | <p>This function detects an abnormal state categorized as a "light alarm," displays $L - FL$ and lets the inverter continue the current operation without tripping.</p> <p>It is possible to define which abnormal states should be categorized as a "light alarm" using function codes H81 and H82. The "light alarm" codes are check-marked in the "Light alarm" object column in Table 13.1.</p> <p>For instructions on how to check and release light alarms, see Section 3.4.3.5 "Monitoring light alarms, ■ How to remove the current light alarm."</p> |
| Stall prevention | <p>When the torque command exceeds the torque limiter level (F44, F45) during acceleration/ deceleration or constant speed running, this function limits the motor torque generated in order to avoid an overcurrent trip.</p> |
| Automatic lowering of carrier frequency | <p>Before the inverter trips due to an abnormal surrounding temperature or output current, this function automatically lowers the carrier frequency to avoid a trip.</p> |
| Motor overload early warning* | <p>When the inverter output current has exceeded the specified level, this function issues the "Motor overload early warning" signal OL before the thermal overload protection function causes the inverter to trip for motor protection.</p> |
| Auto-reset* | <p>When the inverter has stopped because of a trip, this function allows the inverter to automatically reset and restart itself. (The number of retries and the latency between stop and reset can be specified.)</p> |
| Surge protection | <p>This function protects the inverter from a surge voltage invaded between main circuit power lines and the ground.</p> |

13.2 Before Proceeding with Troubleshooting

⚠ WARNING ⚠

- If any of the protective functions has been activated, first remove the cause. Then, after checking that the all run commands are set to OFF, release the alarm. If the alarm is released while any run commands are set to ON, the inverter may supply the power to the motor, running the motor.

Injury may occur.

- Even if the inverter has interrupted power to the motor, if the voltage is applied to the main circuit input terminals L1/R, L2/S and L3/T, voltage may be output to inverter output terminals U, V, and W.
- **Turn OFF the power and wait at least five minutes for inverters with a capacity of 22 kW or below, or at least ten minutes for inverters with a capacity of 30 kW or above.** Make sure that the LED monitor and charging lamp are turned OFF. Further, make sure, using a multimeter or a similar instrument, that the DC link bus voltage between the terminals P (+) and N (-) has dropped to the safe level (+25 VDC or below).

Electric shock may occur.

Follow the procedure below to solve problems.

- (1) First, check that the inverter is correctly wired, referring to Chapter 2, Section 2.3.1 "Wiring of main circuit terminals and grounding terminals."
- (2) Check whether an alarm code or the "light alarm" indication ($\angle -\overline{FL}$) is displayed on the LED monitor.
 - If an alarm code appears on the LED monitor → Go to Section 13.3.
 - If the "light alarm" indication ($\angle -\overline{FL}$) appears on the LED monitor → Go to Section 13.4.
 - If neither an alarm code nor "light alarm" indication ($\angle -\overline{FL}$) appears on the LED monitor
 - Abnormal motor operation → Go to Section 13.5.1.
 - [1] The motor does not rotate.
 - [2] The motor rotates, but the speed does not change.
 - [3] The motor runs in the opposite direction to the command.
 - [4] Speed fluctuation or current oscillation (e.g., hunting) occurs during running at constant speed.
 - [5] Grating sound is heard from the motor or the motor sound fluctuates.
 - [6] The motor does not accelerate or decelerate within the specified time.
 - [7] The motor does not restart even after the power recovers from a momentary power failure.
 - [8] The motor abnormally heats up.
 - [9] The motor does not run as expected.
 - [10] When the motor accelerates or decelerates, the speed is not stable.
 - [11] The motor stalls during acceleration.
 - [12] When the T-Link communications option is in use, neither a run command nor a speed command takes effect.
 - [13] When the SX-bus communications option is in use, neither a run command nor a speed command takes effect.
 - [14] When the CC-Link communications option is in use, neither a run command nor a speed command takes effect.
 - [15] _ _ _ _ (under bars) appears.
 - Problems with inverter settings → Go to Section 13.5.2.
 - [1] Nothing appears on the monitors.
 - [2] The desired function code does not appear.
 - [3] Data of function codes cannot be changed from the keypad.
 - [4] Data of function codes cannot be changed via the communications link.

If any problems persist after the above recovery procedure, contact your Fuji Electric representative.

13.3 If an alarm code appears on the LED monitor

13.3.1 List of alarm codes

Table 13.1 Abnormal States Detectable ("Heavy Alarm" and "Light Alarm" Objects)

| Alarm code | Error cause | "Heavy alarm" objects | "Light alarm" objects | Alarm sub code (for manufacturers)* | Remarks | Ref. page |
|-------------|--|-----------------------|-----------------------|-------------------------------------|---|-----------------|
| <i>dbA</i> | Braking transistor broken | √ | -- | -- | 55 kW or below (200 V class series) 160 kW or below (400 V class series) | 13-5 |
| <i>dbH</i> | Braking resistor overheated | √ | -- | -- | Inverters of all capacities | 13-5 |
| <i>dLF</i> | DC fuse blown | √ | -- | -- | 75 kW or above (200 V class series) 90 kW or above (400 V class series) | 13-5 |
| <i>dFA</i> | DC fan locked | √ | √ | -- | 45 kW or above (200 V class series) 75 kW or above (400 V class series) | 13-6 |
| <i>dD</i> | Excessive positioning deviation | √ | -- | -- | | 13-6 |
| <i>EC</i> | PG communication error | √ | -- | 0001 to 2000 | With OPC-VG1-SPGT mounted | Section 6.8.6.2 |
| <i>ECF</i> | Functional safety circuit error | √ | -- | 0001 to 0008 | | 13-26 |
| <i>EF</i> | Ground fault | √ | -- | -- | Inverters of all capacities | 13-6 |
| <i>Er 1</i> | Memory error | √ | -- | 0001 to 0008 | | 13-7 |
| <i>Er 2</i> | Keypad communications error | √ | -- | 0001 to 0002 | | 13-7 |
| <i>Er 3</i> | CPU error | √ | -- | 0001 to 0008 | | 13-8 |
| <i>Er 4</i> | Network error | √ | √ | 0001 to 0004 | | 13-8 |
| <i>Er 5</i> | RS-485 communications error | √ | √ | 0001 to 0002 | | 13-9 |
| <i>Er 6</i> | Operation error | √ | -- | 0001 to 4000 | | 13-10 |
| <i>Er 7</i> | Output wiring fault | √ | -- | 0001 to 0040 | | 13-11 |
| <i>Er 8</i> | A/D converter error | √ | -- | 0001 to 0004 | | 13-12 |
| <i>Er 9</i> | Speed not agreed | √ | √ | 0001 to 0008 | | 13-12 |
| <i>Er A</i> | UPAC error | √ | -- | 0001 to 0004 | | -- |
| <i>Er b</i> | Inter-inverter communications link error | √ | -- | 0001 to 0400 | | 13-13 |
| <i>Er H</i> | Hardware error | √ | -- | 0001 to 1000 | | 13-14 |
| <i>Err</i> | Mock alarm | √ | √ | -- | | 13-14 |
| <i>Et 1</i> | PG failure | √ | -- | -- | With OPC-VG1-SPGT mounted | Section 6.8.6.2 |
| <i>L in</i> | Power supply phase loss | √ | -- | 0001 to 0002 | | 13-14 |
| <i>LoC</i> | Start delay | √ | √ | -- | | 13-15 |
| <i>LU</i> | Undervoltage | √ | -- | -- | | 13-16 |
| <i>nr b</i> | NTC thermistor wire break error | √ | √ | -- | | 13-17 |
| <i>OC</i> | Overcurrent | √ | -- | 0001 to 0100 | | 13-17 |
| <i>OH 1</i> | Heat sink overheat | √ | -- | 0001 to 0200 | | 13-18 |
| <i>OH 2</i> | External alarm | √ | √ | 0001 | | 13-19 |
| <i>OH 3</i> | Inverter internal overheat | √ | -- | 0001 to 0010 | | 13-19 |
| <i>OH 4</i> | Motor overheat | √ | √ | -- | | 13-20 |
| <i>OL 1</i> | Motor 1 overload | √ | √ | -- | | 13-21 |
| <i>OL 2</i> | Motor 2 overload | √ | √ | -- | | 13-21 |
| <i>OL 3</i> | Motor 3 overload | √ | √ | -- | | 13-21 |
| <i>OLU</i> | Inverter overload | √ | -- | 0001 to 0010 | | 13-21 |
| <i>OPL</i> | Output phase loss | √ | -- | 0001 to 0002 | | 13-22 |

Table 13.1 Abnormal States Detectable ("Heavy Alarm" and "Light Alarm" Objects) (Continued)

| Code | Name | "Heavy alarm" objects | "Light alarm" objects | Alarm sub code (for manufacturers)* | Remarks | Ref. page |
|-------------|-------------------------------------|-----------------------|-----------------------|-------------------------------------|---|---|
| <i>OS</i> | Overspeed | √ | -- | -- | | 13-23 |
| <i>OU</i> | Overvoltage | √ | -- | 0001 | | 13-24 |
| <i>PG</i> | PG wire break | √ | -- | 0001 to 0400 | | 13-25 |
| <i>PbF</i> | Charger circuit fault | √ | -- | 0001 to 0002 | 37 kW or above (200 V class series) 75 kW or above (400 V class series) | 13-26 |
| <i>R-E</i> | E-SX bus tact synchronization error | √ | √ | 0001 | With OPC-VG1-ESX mounted | Section 6.15 |
| <i>R-F</i> | Toggle error detection alarm | √ | √ | 0004 | When any of the OPC-VG1-TL, -SX and -ESX is mounted and that option and Fuji PLC (MICREX-SX) are used in combination. | 4-146 MICREX-SX Technical Document |
| <i>S-F</i> | Functional safety card error | √ | -- | 0001 to 000d (8001 to 800d) | With OPC-VG1-SAFE mounted | Functional Safety Card instruction manual |
| <i>S iF</i> | | √ | -- | 000e to 0015 (800e to 8015) | | |
| <i>S-rF</i> | | -- | √ | 0016 to 0018 (8016 to 8018) | | |

* Alarm sub codes (for manufacturers) are provided for facilitating pinpointing of an error cause when a single alarm code contains two or more error factors. For an alarm code containing a single error factor, the alarm sub code is "0000" so that "--" is written in the table above.

For the alarm sub code checking procedure, refer to Chapter 3, Section 3.4.4.8 "Reading alarm information--Menu #7 "ALM INF."

13.3.2 Possible causes of alarms, checks and measures

[1] *dbA* Braking transistor error

Problem A braking transistor error is detected.
(55 kW or below (200 V class series), 160 kW or below (400 V class series) only.)

| Possible Causes | What to Check and Suggested Measures |
|---------------------------------------|---|
| (1) The braking transistor is broken. | Check whether resistance of the braking resistor is correct or there is a misconnection of the resistor. → Ask your Fuji Electric representative to repair the inverter. |

[2] *dbH* Braking resistor overheated

Problem The electronic thermal protection for the braking resistor has been activated.

| Possible Causes | What to Check and Suggested Measures |
|--|---|
| (1) Braking load is too heavy. | Reconsider the relationship between the estimated braking load and the real one. → Lower the real braking load. → Review the selection of the braking resistor and increase the braking capability (Modification of related function code data (E35, E36, E37) is also required.) |
| (2) Specified deceleration time is too short. | Recalculate the deceleration torque and time needed for the load currently applied, based on a moment of inertia for the load and the deceleration time. → Increase the deceleration time (F08, C36, C47, C57, C67). → Review the selection of the braking resistor and increase the braking capability. (Modification of related function code data (E35, E36, E37) is also required.) |
| (3) Incorrect setting of function code data (E35, E36, E37). | Recheck the specifications of the braking resistor. → Review data of function codes E35, E36 and E37, then modify them. |

[3] *dCF* Fuse blown

Problem The fuse inside the inverter blew. (Applicable to the inverters of 75 kW or above (200 V class series) and those of 90 kW or above (400 V class series))

Note If the fuse has blown, the internal elements may be broken. NEVER turn the power ON to prevent the secondary damage. Contact your Fuji Electric representative.

| Possible Causes | What to Check and Suggested Measures |
|---|--|
| (1) The fuse blew due to short-circuiting inside the inverter. | Check whether there has been any excess surge or noise coming from outside. → Take measures against surges and noise. → Ask your Fuji Electric representative to repair the inverter. |
| (2) The fuse blew due to ground faults that have occurred at the inverter output lines. | Disconnect the wiring from the output terminals [U], [V] and [W] and perform a Megger test for the inverter and the motor. → Remove the grounded parts (including replacement of the wires, relay terminals and motor). → Ask your Fuji Electric representative to repair the inverter or the motor. |
| (3) Miswiring of main circuit power lines and output lines. | Check the wiring. → Ask your Fuji Electric representative to repair the inverter. |

[4] *dFA* DC fan locked

Problem The DC fan has stopped. (Applicable to the inverters of 45 kW or above (200 V class series) and those of 75 kW or above (400 V class series))

| Possible Causes | What to Check and Suggested Measures |
|--|---|
| (1) The service life of the DC fan has expired or the DC fan is defective. | <p>The DC fan has stopped although the main power is ON. (Check the DC fan state with the cooling fan ON/OFF control disabled with H06 = 0.)</p> <p>→ Replace the DC fan.</p> <p>→ Disable the DC fan locked signal output (treat it as a light alarm) to keep the inverter running by setting "1" to the hundreds digit of H108 (Light alarm object definition) to "1" (H108 = □1□□).</p> <p>If the DC fan has stopped, replace the fan immediately and revert the data of H108 to the factory default. Leaving the DC fan stopped causes an inverter internal overheat trip or a local temperature rise that shortens the service life of electrolytic capacitors and other electronic devices on the printed circuit boards in the inverter unit, in the worst case, it results in a broken inverter unit.</p> |

[5] *dD* Excessive positioning deviation

Problem An excessive positioning deviation has occurred.

| Possible Causes | What to Check and Suggested Measures |
|---|---|
| (1) Wrong wiring to the motor. | <p>Check the wiring to the motor.</p> <p>→ Connect the inverter output terminals U, V, and W to the motor input terminals U, V, and W, respectively.</p> <p>It is also possible to use H75 (Phase sequence configuration of main circuit output wires).</p> |
| (2) The motor cannot rotate mechanically. | → Check whether the brake is applied. |
| (3) Output torque too small. | → Increase the torque limiter value (F44, F45). |
| (4) Deviation override width too small. | → Review the deviation override width (o18). |
| (5) Insufficient gain in positioning control system. | → Readjust the positioning loop gain (o16). |
| (6) The acceleration/ deceleration by pulse train command is too rapid. | → Increase the acceleration/deceleration time. |

[6] *EF* Ground fault

Problem A ground fault current flew from the output terminal of the inverter.

| Possible Causes | What to Check and Suggested Measures |
|--|--|
| (1) Inverter output terminal(s) grounded (ground fault). | <p>Disconnect the wiring from the output terminals [U], [V] and [W] and perform a Megger test for the inverter and the motor.</p> <p>→ Remove the grounded parts (including replacement of the wires, relay terminals and motor).</p> |
| (2) The setting of the motor rated current (P04, A03, A103) is small relative to the inverter rated current. | <p>Check whether an extremely small motor rated current is set relative to the inverter rated current.</p> <p>→ Check the setting of the motor rated current (P04, A03, A103).</p> <p>→ Disable the ground fault detection by setting "0" to the hundreds digit of H103 (Protection/maintenance function 1).</p> |

[7] E_r / Memory error

Problem Error occurred in writing data to the memory in the inverter.

| Possible Causes | What to Check and Suggested Measures |
|--|--|
| (1) When writing data (especially initializing or copying data), the inverter was shut down so that the voltage to the control PCB has dropped. | Initialize the function code data by setting H03 to "1." After initialization, check if pressing the RESET key releases the alarm. → Revert the initialized function code data to their previous customized settings (See Note below), then restart the operation. |
| (2) Inverter affected by strong electrical noise when writing data (especially initializing or copying data). | Check if appropriate noise control measures have been implemented (e.g., correct grounding and routing of control and main circuit wires). Also, perform the same check as described in (1) above. → Implement noise control measures. Revert the initialized function code data to their previous customized settings (See Note below), then restart the operation. |
| (3) Control circuit failure. [Sub code: 0001 to 0008] | Initialize the function code data by setting H03 to "1," then reset the alarm by pressing the RESET key and check that the alarm goes on. → The control PCB (on which the CPU is mounted) is defective and needs to be replaced. Ask your Fuji Electric representative to repair the inverter. Inform the representative of the alarm sub code displayed. |
| (4) Highly-frequent rewriting to the non-volatile memory has reached the limit of the electronic device (approx. 1,000,000 times). [Sub code: 0001 to 0008] | Function code data has been frequently changed. → The non-volatile memory needs to be replaced. Ask your Fuji Electric representative to repair the inverter. Inform the representative of the alarm sub code displayed. → Decrease the frequency of rewriting. Decrease the frequency of Save all operations. |

Note: Function code data can be easily reverted to the previously customized settings by using the backup data copied in the keypad memory with Menu #10 "DATA COPY" in Programming mode. (Refer to Chapter 3, Section 3.4.4.10 "Copying data")

[8] E_r / Keypad communications error



Problem A communications error occurred between the keypad and the inverter.

| Possible Causes | What to Check and Suggested Measures |
|---|--|
| (1) Broken communications cable or poor contact. [Sub code: 0001] | Check continuity of the cable, contacts and connections. → Re-insert the connector firmly. → Replace the cable. |
| (2) Connecting many control wires hinders the front cover from being mounted, lifting the keypad. [Sub code: 0001] | Check the mounting condition of the front cover. → Use wires of the recommended size (0.75 mm ²) for wiring. → Change the wiring layout inside the unit so that the front cover can be mounted firmly. |
| (3) Inverter affected by strong electrical noise. [Sub code: 0002] | Check if appropriate noise control measures have been implemented (e.g., correct grounding and routing of communication cables and main circuit wires). → Implement noise control measures. |
| (4) A keypad failure occurred. | Replace the keypad with another one and check whether a keypad communications error (E_r / E_r) occurs. → Replace the keypad. |
| (5) A keypad designed for any other series of inverters is connected. | Check whether the connected keypad is a multi-function keypad designed for FRENIC-Mini/-Eco/-Multi/-MEGA/-Lift. → Replace the keypad with the one designed for the FRENIC-VG. |

[9] E-3 CPU error

Problem A CPU error (e.g. erratic CPU operation) occurred.

| Possible Causes | What to Check and Suggested Measures |
|--|---|
| (1) Inverter affected by strong electrical noise. | Check if appropriate noise control measures have been implemented (e.g. correct grounding and routing of signal wires, communications cables, and main circuit wires). ➔ Implement noise control measures. |
| (2) Short circuit on the printed circuit board(s). [Sub code: 0001 to 0008] | Check the printed circuit board(s) for short circuits, accumulation of dust or dirt. ➔ Ask your Fuji Electric representative to repair the inverter. Inform the representative of the alarm sub code displayed. |

 **Note** To remove the E-3 CPU error, turn the power to the inverter OFF and then ON. The error cannot be removed by pressing the  key.

[10] E-4 Network error

Problem The connected option card detected an error.

① For T-Link option

| Possible Causes | What to Check and Suggested Measures |
|---|--|
| (1) The power to the MICREX IO terminal is OFF. | Check the power to the MICREX IO terminal. ➔ Turn ON the power to the MICREX IO terminal and reset the inverter alarm state. |
| (2) T-Link address double assigned. | Check the T-Link address. ➔ Set a new T-Link address. |
| (3) Wrong wiring. | Check that: <ul style="list-style-type: none"> • The T-Link network has a terminating resistor at each end. • The specified cable is used. • There is no wire break. • The wiring length is within the range of the specification. • The shielded wires are properly treated. • The SD terminal of the T-Link is not connected to a frame ground (FG). • A crimp terminal is used for connection. • The signal lines are not wired in parallel with the power lines. ➔ Correct the wiring. |

② For SX-bus option

| Possible Causes | What to Check and Suggested Measures |
|--|---|
| (1) The SX-bus power is shut down or the PLC's CPU module is down. | Check the power to the SX-bus and the status of the PLC's CPU module. ➔ Turn ON the power to the SX-bus, recover the PLC's CPU module, and reset the inverter alarm state. |
| (2) An error has occurred at any other station. | Check the detailed RAS information on the PLC's CPU module to find a faulty station. ➔ Recover the faulty station and reset the inverter alarm state. |

| Possible Causes | What to Check and Suggested Measures |
|-------------------|---|
| (3) Wrong wiring. | Check that: <ul style="list-style-type: none"> • The SX-bus network has a terminating connector at each end. • A dedicated cable is used. • There is no wire break. • Connection to the IN and OUT connector is proper. • The signal lines are not wired in parallel with the power lines. • The total extension length of the SX bus cable does not exceed 25 m. The number of devices connected in succession does not exceed 10. • The SX bus cable is not bent with the bend radius of 50 mm or below. → Correct wiring. |

③ For CC-Link option

| Possible Causes | What to Check and Suggested Measures |
|--|---|
| (1) The power to the PLC is shut down or the PLC's CPU module is down. | Check the power to the PLC and the status of the PLC's CPU module. → Turn ON the power to the PLC, recover the PLC's CPU module, and reset the inverter alarm state. |
| (2) An error has occurred at any other station. | Check the detailed RAS information on the PLC's CPU module to find a faulty station. → Recover the faulty station and reset the inverter alarm state. |
| (3) Wrong wiring. | Check that: <ul style="list-style-type: none"> • The CC-Link network has a terminating resistor at each end. • A dedicated cable is used. • There is no wire break. • Connection to the terminal block is proper. • The signal lines are not wired in parallel with the power lines. • The maximum cable length of the CC-link cable, inter-station cable length, and the number of devices connected are as specified. → Correct wiring. |

[11] E-5 RS-485 communications error



Problem A communications error occurred during RS-485 communication.

| Possible Causes | What to Check and Suggested Measures |
|---|---|
| (1) Communications conditions of the inverter do not match that of the host equipment. [Sub code: 0002] | Compare the settings of function codes H32 to H40 with those of the host equipment. → Correct any settings that differ. |
| (2) Even though no-response error detection time (H38) has been set, communication is not performed within the specified cycle. [Sub code: 0001] | Check the host equipment. → Change the settings of host equipment software or disable the no-response error detection (H38 = 0). |
| (3) The host equipment did not operate due to defective software, settings, or defective hardware. [Sub code: 0002] | Check the host equipment (e.g., PLCs and host computers). → Remove the cause of the equipment error. |

| Possible Causes | What to Check and Suggested Measures |
|--|--|
| (4) The RS-485 converter did not operate due to incorrect connections and settings, or defective hardware. | Check the RS-485 converter (e.g., check for poor contact or incorrect connections). → Change the various RS-485 converter settings, reconnect the wires, or replace hardware with recommended devices as appropriate. |
| (5) Broken communications cable or poor contact. | Check the continuity of the cables, contacts and connections. → Replace the cable. |
| (6) Inverter affected by strong electrical noise. | Check if appropriate noise control measures have been implemented (e.g., correct grounding and routing of communications cables and main circuit wires). Check if decreasing the baud rate (H34) down to 2400 bps causes no alarm. → Implement noise control measures. → Implement noise reduction measures on the host side. → Replace the RS-485 converter with a recommended insulated one. → Keep the inverter running, using any proper communications error processing (H32). |
| (7) Terminating resistor not properly configured. | Check that the inverter serves as a terminating device in the network. → Configure the terminating resistor switch (SW4) for RS-485 communication correctly. (To use the inverter as a terminating device, turn the switch to the ON position.) |
| (8) Response interval does not match the send/receive switching time of the RS-232C–RS-485 converter. | Check whether the specified response interval (H39) matches the specification of the actual converter. → Match the response interval (H39) with the specification of the converter. |

[12] E-6 Operation error

Problem An incorrect operation was attempted.

| Possible Causes | What to Check and Suggested Measures |
|---|--|
| (1) Restrictions on mounting of option(s) not observed. [Sub code: 0001] | Check the model of option(s) mounted. → Check the restrictions on mounting of the option(s). (This error cannot be shown as mounting status of control options on the OPTION pages of the LCD monitor in Menu #4 "I/O CHECK.") Check whether the configurations of the customizing switches (SW) on the two option boards are the same. → Change the SW configuration. |
| (2) Auto-tuning not performed in accordance with correct procedure. [Sub code: 0002] | Check whether tuning started with digital input BX , STOP1 , STOP2 or STOP3 being ON. → With all of BX , STOP1 , STOP2 and STOP3 being OFF, start tuning. Check whether tuning started with digital input EN1 or EN2 being opened. → With each of EN1 and EN2 being short-circuited with PS , start tuning. Check whether 20 seconds or more have elapsed after writing to H01 until the  key is pressed. → Press the  key within 20 seconds after writing to H01. → Before writing to H01, make sure that F02 = 0 and H30 = 0 or 1. Check whether tuning has started with the main power being OFF or with the inverter DC link bus voltage not established. → Check the DC link bus voltage on the maintenance information screen of the keypad. (Refer to Chapter 3, Section 3.4.4.6 "Reading maintenance information – Menu #5 MAINTENANCE.") |

| Possible Causes | What to Check and Suggested Measures |
|--|--|
| (3) The PG detection circuit self-diagnosis function has been performed with the PG (SD)/PGo (SD) card being mounted. [Sub code: 0080] | Check whether the PG (SD)/PGo (SD) card is mounted. ➔ Remove the PG (SD)/PGo (SD) card, then perform the self-diagnosis function of the PG detection circuit (H74). |
| (4) When the multiplex system is selected (o33 ≠ 0), the multiplex system station number (o50) is greater than the number of slave stations (o34). [Sub code: 0100] | ➔ Review the settings of o50 and o34. |
| (5) When the multiplex system is selected (o33 ≠ 0), the motor drive control setting is not proper. [Sub code: 0200] | Some motor drive controls are not available under the multiplex system. ➔ Review the selected drive control (P01, A01, A101). For available drive controls, refer to Chapter 6, Section 6.6 "High-Speed Serial Communication-Capable Terminal Block OPC-VG1-TBSI" in the FRENIC-VG User's Manual (Option Edition). |
| (6) After the multiplex system configuration was established, the setting of o33 has been changed. [Sub code: 0800] | The alarm cannot be released until the inverter is turned off and on. ➔ Review the setting of o33 and turn the inverter off and on. |
| (7) Mismatch between the multiplex system setting (o33) and the number of slave stations setting (o34). [Sub code: 4000] | Multiplex systems may have restrictions on the number of slave stations. ➔ Review the settings of o33 and o34. For available drive controls, refer to Chapter 6, Section 6.6 "High-Speed Serial Communication-Capable Terminal Block OPC-VG1-TBSI" in the FRENIC-VG User's Manual (Option Edition). |

[13] E-7 Output wiring fault

Problem Auto-tuning failed.

| Possible Causes | What to Check and Suggested Measures |
|--|--|
| (1) A phase was missing (There was a phase loss) in the connection between the inverter and the motor. [Sub code: 0001] [Sub code: 0020, 0040] | ➔ Properly connect the motor to the inverter. ➔ Check the state of the contactor connected at the inverter output side. |
| (2) A tuning operation involving motor rotation (H01 = 4) was attempted while the brake was applied to the motor. [Sub code: 0002] | Check that the brake can be released. ➔ Specify the tuning that does not involve the motor rotation (H01 = 2 or 3). ➔ Release the brake before tuning that involves the motor rotation (H01 = 4). |
| (3) Tuning of magnetic pole position offset value has failed. [Sub code: 0010] | ➔ Correct the wiring of the PG. ➔ Adjust the settings of the pull-in current (H161) and pull-in frequency (H162). Refer to Section 3.5.4.2 "Test run procedure for permanent magnet synchronous motor (PMSM), [3] Setting the magnetic pole position offset value, (2) Automatic adjustment of the magnetic pole position offset value." |

[14] *E-r-B* A/D converter error

Problem An error occurred in the A/D converter circuit.

| Possible Causes | What to Check and Suggested Measures |
|--|---|
| (1) Inverter affected by strong electrical noise. | Check if appropriate noise control measures have been implemented (e.g. correct grounding and routing of signal wires, communications cables, and main circuit wires). → Implement noise control measures. |
| (2) Short circuit on the printed circuit board(s). [Sub code: 0001 to 0004] | Check the printed circuit board(s) for short circuits, accumulation of dust or dirt. Check for dew condensation in the inverter unit. Check whether foreign materials have gotten into the inverter unit. → Fix the printed circuit board(s). → Ask your Fuji Electric representative to repair the inverter. Inform the representative of the alarm sub code displayed. |

[15] *E-r-G* Speed mismatch

Problem An excessive deviation has occurred between the speed command and the detected speed.

| Possible Causes | What to Check and Suggested Measures |
|--|--|
| (1) Incorrect setting of function code data. [Sub code: 0001 to 0004] | Check the settings of the following: Number of poles (P05, A07, A107), feedback input pulse resolution (P28, A30, A130), feedback input external PG correction factor (P29, A51, A151), and machine runaway detection speed setting (H149) → Specify motor parameters in accordance with the motor and PG. → Review the data of the following function codes. • E43 (Speed agreement, Detection width) • E44 (Speed agreement, Off-delay timer) • E45 (Speed agreement, Alarm) |
| (2) Overload. [Sub code: 0001 to 0004] | Measure the inverter output current. → Reduce the load. → Increase the inverter capacity. Check whether any mechanical brake is working. → Release the mechanical brake. |
| (3) Mismatch between function code settings and the motor characteristics. [Sub code: 0001 to 0004] | Check the motor parameters. → Perform auto-tuning, using H01. |
| (4) Wrong wiring between the pulse generator (PG) and the inverter. [Sub code: 0001 to 0004] | Check the wiring between the PG and the inverter. → Correct the wiring. (Refer to Chapter 3, Section 3.5.2 "Mounting direction of a pulse generator (PG) and PG signals.") Check that the relationships between the PG feedback signal and the run command are as follows: • For the FWD command: the B phase pulse is in the High level at rising edge of the A phase pulse • For the REV command: the B phase pulse is in the Low level at rising edge of the A phase pulse → If the relationship is wrong, interchange the A and B phase wires. → Note that if the digital input signal <i>IVS</i> ("Switch normal/inverse operation") is active, the above operation is reversed. |

| Possible Causes | What to Check and Suggested Measures |
|--|--|
| (5) Wrong wiring to the motor. [Sub code: 0001 to 0004] | Check the wiring to the motor. ➔ Connect the inverter output terminals U, V, and W to the motor input terminals U, V, and W, respectively. It is also possible to use H75 (Phase sequence configuration of main circuit output wires). |
| <u>Under vector control with/without speed sensor</u> (6) The motor speed does not rise due to the torque limiter operation. [Sub code: 0001 to 0004] | Check the setting of the torque limiter level (F44, F45). ➔ Change the F44 or F45 data to an appropriate value. If no torque limiter is required, disable the torque limiter (F40 = 0). |
| (7) During running of the motor (after the mechanical brake is released), the deviation between the speed command (Reference speed 4, ASR input) and the actual speed exceeds the setting of H149. [Sub code: 0008] | Check the wiring to the motor. ➔ Connect the inverter output terminals U, V, and W to the motor input terminals U, V, and W, respectively. |

[16] *Erb* Inter-inverter communications link error

Problem A communications link error has occurred between high-speed serial communication-capable terminal block options (OPC-VG1-TBSI).

| Possible Causes | What to Check and Suggested Measures |
|---|---|
| (1) The optical cable is disconnected or inserted poorly into the connector. [Sub code: 0001 to 0020] | ➔ Connect the optical cable fully. |
| (2) The optical cable is bundled or bent with the bend radius of 35 mm or less. [Sub code: 0001 to 0020] | ➔ Increase the bend radius to at least 35 mm. |
| (3) The optical cable or connectors on the inverter were exposed to intense light (e.g., direct sunlight or strobe light) [Sub code: 0001 to 0020] | ➔ Do not expose the optical cable or the connectors to intense light. |
| (4) Discrepancy in capacity between master and slave inverters. [Sub code: 0200] | The multiplex system cannot be configured with inverters of different capacities. |
| (5) Discrepancy in current rating between master and slave inverters. [Sub code: 0400] | The multiplex system cannot be configured with inverters of different current rating settings (F80). ➔ Review the current rating settings (F80). |





[17] *E-H* Hardware error

Problem The LSI on the power supply printed circuit board (PCB) malfunctions.

| Possible Causes | What to Check and Suggested Measures |
|---|---|
| (1) The control circuit PCB or power supply PCB is defective. | The control circuit PCB or power supply PCB (including the gate PCB) needs to be replaced. → Ask your Fuji Electric representative to repair the inverter. Inform the representative of the alarm sub code displayed. |

[18] *Err* Mock alarm

Problem The LED displays *err*.

| Possible Causes | What to Check and Suggested Measures |
|--|---|
| (1) The  +  keys were held down for more than 5 seconds. | → To escape from this alarm state, press the  key. |
| (2) The H142 was set to "1" (Cause a mock alarm). | → To escape from this alarm state, press the  key. |
| (3) The FTB ("Cause external mock alarm") assigned to a digital input terminal was turned ON. | → Check the input of the terminal to which an FTB is assigned with function codes E01 to E13 (data = 74). |

[19] *U* Power supply phase loss

Problem Input phase loss occurred, or interphase voltage unbalance rate was large.

| Possible Causes | What to Check and Suggested Measures |
|---|---|
| (1) Breaks in wiring to the main power input terminals. | Measure the input voltage. → Repair or replace the main circuit power input wires or input devices (MCCB, MC, etc.). |
| (2) The screws on the main power input terminals are loosely tightened. | Check if the screws on the main power input terminals have become loose. → Tighten the terminal screws to the recommended torque. |
| (3) Interphase voltage unbalance between three phases was too large. | Measure the input voltage. → Connect an AC reactor (ACR) to lower the voltage unbalance between input phases. → Increase the inverter capacity. |
| (4) Overload cyclically occurred. | Correct the load. → Increase the inverter capacity. |
| (5) Single-phase voltage was input to the three-phase input inverter. | → Connect the inverter to the three-phase voltage power supply. (The FRENIC-VG is a three-phase inverter.) |

[20] \overline{LOL} Start delay

Problem At the startup, an excessive deviation has occurred between the speed command and the detected speed.

| Possible Causes | What to Check and Suggested Measures |
|---|---|
| (1) Incorrect setting of function code data. | <p>Check the data of the following function codes; P05, A07 and A107 (Motor, No. of poles), P28, A30 and A130 (Feedback encoder pulse count/rev), and P29, A51 and A151 (Feedback pulse correction factor 1).</p> <p>→ Specify motor parameters in accordance with the motor and PG.</p> <p>→ Review the data of the following function codes.</p> <ul style="list-style-type: none"> • H140 (Start delay, Detection level) • H141 (Start delay, Detection timer) |
| (2) Overload. | <p>Measure the inverter output current.</p> <p>→ Reduce the load.</p> <p>→ Increase the inverter capacity.</p> <p>Check whether any mechanical brake is working.</p> <p>→ Release the mechanical brake.</p> |
| (3) Mismatch between function code settings and the motor characteristics. | <p>Check the motor parameters.</p> <p>→ Perform auto-tuning, using H01.</p> |
| (4) Wrong wiring between the pulse generator (PG) and the inverter. | <p>Check the wiring between the PG and the inverter.</p> <p>→ Correct the wiring. (Refer to Chapter 3, Section 3.5.2 "Mounting direction of a pulse generator (PG) and PG signals.")</p> <p>Check that the relationships between the PG feedback signal and the run command are as follows:</p> <ul style="list-style-type: none"> • For the FWD command: the B phase pulse is in the High level at rising edge of the A phase pulse • For the REV command: the B phase pulse is in the Low level at rising edge of the A phase pulse <p>→ If the relationship is wrong, interchange the A and B phase wires.</p> <p>→ Note that if the digital input signal <i>IVS</i> ("Switch normal/inverse operation") is active, the above operation is reversed.</p> |
| (5) Wrong wiring to the motor. | <p>Check the wiring to the motor.</p> <p>→ Connect the inverter output terminals U, V, and W to the motor input terminals U, V, and W, respectively.</p> <p>It is also possible to use H75 (Phase sequence configuration of main circuit output wires).</p> |
| <u>Under vector control with/without speed sensor</u> | <p>Check the setting of the torque limiter level (F44, F45).</p> <p>→ Change the F44 or F45 data to an appropriate value. If no torque limiter is required, disable the torque limiter (F40 = 0).</p> |
| (6) The motor speed does not rise due to the torque limiter operation. | |
| (7) During running of the motor (after the mechanical brake is released), the reference torque current (F44, F45) exceeds the specified level (H140) and the actual speed drops below the specified stop speed (F37), and then the state is kept for the specified duration (H141). | <p>Check the wiring to the motor.</p> <p>→ Connect the inverter output terminals U, V, and W to the motor input terminals U, V, and W, respectively.</p> |

[21] Undervoltage

Problem DC link bus voltage has dropped below the undervoltage detection level.

| Possible Causes | What to Check and Suggested Measures |
|--|--|
| (1) A momentary power failure occurred. | <ul style="list-style-type: none"> ➔ Release the alarm. ➔ To restart running the motor without treating this condition as an alarm, set F14 to "3," "4," or "5," depending on the load type. |
| (2) The power to the inverter was switched back to ON too soon (when F14 = 1). | <p>Check if the power to the inverter was switched back to ON while the control power was still alive. (Check whether the LEDs on the keypad light.)</p> <ul style="list-style-type: none"> ➔ Turn the power ON again after all LEDs on the keypad go off. |
| (3) The power supply voltage does not reach the inverter's specification range. | <p>Measure the input voltage.</p> <ul style="list-style-type: none"> ➔ Increase the voltage to within the specified range. |
| (4) Peripheral equipment for the power circuit malfunctioned, or the connection is incorrect. | <p>Measure the input voltage to find which peripheral equipment malfunctioned or which connection is incorrect.</p> <ul style="list-style-type: none"> ➔ Replace any faulty peripheral equipment, or correct any incorrect connections. |
| (5) Any other load(s) connected to the same power supply has required a large starting current, causing a temporary voltage drop. | <p>Measure the input voltage and check the voltage fluctuation.</p> <ul style="list-style-type: none"> ➔ Reconsider the power supply system configuration. |
| (6) Insufficient capacity of the power supply transformer increases load, causing a voltage drop. | <p>Measure the output current.</p> <ul style="list-style-type: none"> ➔ Reduce the load. ➔ Reconsider the capacity of the power supply transformer. |
| (7) No power is supplied to the auxiliary control power input terminals R0 and T0. Fan power supply switching connectors CN W and CN R are set as follows. CN W (white): [FAN] position CN R (red): [NC] position (Refer to Chapter 3, Section 3.3.3.7 "Switching connectors.") | <p>Measure the input voltage of the auxiliary power supply.</p> <ul style="list-style-type: none"> ➔ Insert various circuit breakers or magnetic contactor (MC). ➔ Check for voltage drop, connection failure, poor contact and other problems, then take measures against them. |

[22]  NTC thermistor wire break error

Problem A wire break is found in the NTC thermistor detection circuit.

Note: A negative temperature coefficient (NTC) thermistor is used to protect the motor from overheat, and under vector control, to compensate for the temperature in the motor parameters.

A dedicated motor (VG motor) for Fuji vector control has a built-in NTC thermistor.

| Possible Causes | What to Check and Suggested Measures |
|---|--|
| (1) The NTC thermistor cable is broken. | Check whether the motor cable is broken. → Replace the motor cable. |
| (2) The temperature around the motor is extremely low (lower than -30°C). | Measure the temperature around the motor. → Reconsider the use environment of the motor. |
| (3) The NTC thermistor is broken. | Measure the resistance of the NTC thermistor (including a spare thermistor). → Connect a spare thermistor to the motor. → If the spare thermistor is also broken, replace the motor. |

[23]  Overcurrent

Problem The inverter momentary output current exceeded the overcurrent level.

| Possible Causes | What to Check and Suggested Measures |
|---|---|
| (1) The inverter output lines were short-circuited. | Disconnect the wiring from the inverter output terminals ([U], [V] and [W]) and measure the interphase resistance of the motor wiring. Check if the resistance is too low. → Remove the short-circuited part (including replacement of the wires, relay terminals and motor). |
| (2) Ground faults have occurred at the inverter output lines. | Disconnect the wiring from the output terminals [U], [V] and [W] and perform a Megger test for the inverter and the motor. → Remove the grounded parts (including replacement of the wires, relay terminals and motor). |
| (3) Overload. | Measure the motor current with a measuring device to trace the current trend. Then, use this data to judge if the trend is over the calculated load value for your system design. → If the load is too heavy, reduce it or increase the inverter capacity. Trace the current trend and check if there are any sudden changes in the current. → If there are any sudden changes, make the load fluctuation smaller or increase the inverter capacity. → <u>Under V/f control</u> Enable overcurrent limiting (H58 = 1). |
| <u>Under V/f control</u> (4) Excessive torque boost specified (in the case of manual torque boost) | Check whether decreasing the torque boost (P35, A55, A155) decreases the output current but does not stall the motor. → If no stall occurs, decrease the torque boost (P35, A55, A155). |
| <u>Under V/f control</u> (5) The acceleration/ deceleration time was too short. | Check that the motor generates enough torque required during acceleration/deceleration. That torque is calculated from the moment of inertia for the load and the acceleration/deceleration time. → Increase the acceleration/deceleration time (F07, F08, C46, C47, C56, C57, C66, C67). → Increase the inverter capacity. → Review the braking method. |

| Possible Causes | What to Check and Suggested Measures |
|--|--|
| (6) Malfunction caused by noise. | <p>Check if noise control measures are appropriate (e.g., correct grounding and routing of control and main circuit wires).</p> <ul style="list-style-type: none"> ➔ Implement noise control measures. For details, refer to the FRENIC-VG User's Manual, "Appendix A." ➔ Enable the Auto-reset (H04). ➔ Connect a surge absorber to magnetic contactor's coils or other solenoids (if any) causing noise. |
| <u>Under vector control with/without speed sensor</u> (7) The carrier frequency is low. | <p>Check the motor sound (carrier frequency) specified by F26.</p> <ul style="list-style-type: none"> ➔ Increase the setting of F26. (Note that increasing the carrier frequency excessively may cause other devices to malfunction due to noise generated from the inverter.) |
| <u>Under vector control with/without speed sensor</u> (8) Exciting current was too small during auto-tuning. | <p>Check whether it happens during auto-tuning.</p> <ul style="list-style-type: none"> ➔ Increase the exciting current (P08, A10, A110) and then perform auto-tuning. |
| <u>Under vector control with speed sensor</u> (9) Mismatch between the PG's pulse resolution and the function code setting. | <p>Check the function code setting (P28, A30, A130).</p> <ul style="list-style-type: none"> ➔ Match the function code settings with the PG specifications. |
| <u>Under vector control with speed sensor</u> (10) Wrong wiring of the PG. | <p>Check the wiring between the PG and the inverter for the phase sequence, wire breaks, shielding and twisting.</p> <ul style="list-style-type: none"> ➔ Correct the wiring. |
| <u>Under vector control with speed sensor</u> (11) PG defective. | <p>Check whether the inverter internal control circuit (PG input circuit) is faulty, using the self-diagnosis function of the PG detection circuit (H74).</p> <ul style="list-style-type: none"> ➔ If the result is "Normal," replace the PG; if it is "Abnormal," contact your Fuji Electric representative. <p>Check the PG waveform using an oscilloscope.</p> <ul style="list-style-type: none"> ➔ Replace the PG. |
| <u>PMSM</u> (12) Incorrect setting of function code data (P44, A64, A164). | <p>Recheck the allowable current specifications of the permanent magnet synchronous motor (PMSM).</p> <ul style="list-style-type: none"> ➔ Review the setting of the function code (P44, A64, A164) to modify it. <p>For the GNF2 motor settings, refer to Chapter 3, Section 3.5.3.3 "Vector control for PMSM with speed sensor."</p> |

[24] Heat sink overheat

Problem Temperature around heat sink has risen abnormally.

| Possible Causes | What to Check and Suggested Measures |
|---|---|
| (1) The surrounding temperature exceeded the range of the inverter specification. [Sub code: 0001 to 0008] | <p>Measure the temperature around the inverter.</p> <ul style="list-style-type: none"> ➔ Lower the temperature around the inverter (e.g., ventilate the panel where the inverter is mounted). |
| (2) Ventilation path is blocked. [Sub code: 0001 to 0008] | <p>Check if there is sufficient clearance around the inverter.</p> <ul style="list-style-type: none"> ➔ Change the mounting place to ensure the clearance. <p>Check if the heat sink is not clogged.</p> <ul style="list-style-type: none"> ➔ Clean the heat sink. (For the cleaning procedure, contact your Fuji Electric representative.) |

| Possible Causes | What to Check and Suggested Measures |
|--|---|
| (3) Cooling fan's airflow volume decreased due to the service life expired or failure. [Sub code: 0001 to 0008] [Sub code: 0010 to 0200] | Check the cumulative run time of the cooling fan. Refer to Chapter 3, Section 3.4.4.6 "Reading maintenance information – Menu #5 MAINTENANCE." ➔ Replace the cooling fan. (Contact your Fuji Electric representative.) |
| | Visually check whether the cooling fan rotates normally. ➔ Replace the cooling fan. (Contact your Fuji Electric representative.) |
| (4) Overload. [Sub code: 0001 to 0008] | Measure the output current. ➔ Reduce the load (Use the heat sink overheat early warning <i>INV-OH</i> (E15 through E27) or the inverter overload early warning <i>INV-OL</i> (E15 through E27) to reduce the load before the overload protection is activated.). ➔ Decrease the data of F26 (Motor sound, Carrier frequency). |

[25]  External alarm

Problem External alarm was inputted (*THR*).
(when the "Enable external alarm trip" *THR* has been assigned to any of digital input terminals)

| Possible Causes | What to Check and Suggested Measures |
|---|--|
| (1) An alarm function of external equipment was activated. | Check the operation of external equipment. ➔ Remove the cause of the alarm that occurred. |
| (2) Wrong connection or poor contact in external alarm signal wiring. | Check if the external alarm signal wiring is correctly connected to the terminal to which the "Enable external alarm trip" terminal command <i>THR</i> has been assigned (Any of E01 through E09 should be set to "9"). ➔ Connect the external alarm signal wire correctly. |
| (3) Incorrect setting of function code data. | Check whether the normal/negative logic of the external signal matches that of the <i>THR</i> command specified by E14. ➔ Ensure the matching of the normal/negative logic. |
| (4) The surrounding temperature exceeded the range of the braking resistor specification. | Measure the temperature around the braking resistor. ➔ Lower the temperature (e.g., ventilate the inverter). |
| (5) The capacity of the braking resistor is insufficient. | Reconsider the capacity and %ED of the braking resistor. ➔ Review the braking resistor. |

[26]  Inverter internal overheat

Problem Temperature inside the inverter has exceeded the allowable limit.

| Possible Causes | What to Check and Suggested Measures |
|--|--|
| (1) The surrounding temperature exceeded the inverter's specification limit. [Sub code: 0001 to 0008] | Measure the surrounding temperature. ➔ Lower the temperature around the inverter (e.g., ventilate the panel where the inverter is mounted). |
| (2) Temperature detection circuit failure (Thermistor wire break). [Sub code: 0010] | ➔ Ask your Fuji Electric representative to repair the inverter. Inform the representative of the alarm sub code displayed. |




[27] Motor overheat (PTC/NTC thermistor)

Problem Temperature of the motor has risen abnormally.

| Possible Causes | What to Check and Suggested Measures |
|--|---|
| (1) The temperature around the motor exceeded the range of the motor specification. | Measure the temperature around the motor. → Lower the temperature. |
| (2) Cooling system for the motor defective. | Check if the cooling system of the motor is operating normally. → Repair or replace the cooling system of the motor. |
| (3) Overload. | Measure the output current. → Reduce the load. (e.g. Use the motor overload early warning (E34) to reduce the load before the overload protection is activated.) → Lower the temperature around the motor. |
| (4) The activation level (E32) of the PTC thermistor for motor overheat protection was set inadequately. | Check the PTC thermistor specifications and recalculate the detection voltage. → Modify the data of function code E32. |
| (5) The activation level (E30) of the NTC thermistor for motor overheat protection was set inadequately. | Check the data of function code E30 (Motor overheat protection, Temperature). → When a motor exclusive to vector control is used, set E30 to 150°C (Factory default). → When the motor temperature is entered via any of analog input terminals [Ai1] to [Ai4], set E30 to the protection level matching the motor specification. |
| (6) Settings for the PTC/NTC thermistor are improper. | Check the setting of the thermistor mode selection (function code P30, A31, A131). → Change the data of P30, A31 or A131 in accordance with the thermistor used. |
| (7) NTC thermistor model (characteristics) improper. | Check the NTC thermistor model (characteristics). → Use the NTC thermistor incorporated in a motor exclusive to vector control. |
| <u>Under V/f control</u> (8) Excessive torque boost specified. (P35, A55, A155) | Check whether decreasing the torque boost (function code P35, A55, A155) does not stall the motor. → If no stall occurs, decrease the data of P35, A55 or A155. |
| <u>Under V/f control</u> (9) The V/f pattern did not match the motor. | Check whether the motor rated speed (F04, A05, A105) and the rated voltage (F05, A04, A104) match the values on the motor's nameplate. → Match the function code data with the values on the motor's nameplate. |
| (10) Incorrect setting of function code data. | Although no PTC thermistor is used, the thermistor mode is enabled (function code P30, A31, A131). → Set the data of P30, A31 or A131 to "0" (Disable). |
| (11) The input voltage of the motor cooling fan is out of the range of the specification. | Check the input voltage of the motor cooling fan. → Review the power supply system. |
| (12) The air passage of the motor cooling fan is clogged. | Check the air passage of the motor cooling fan. → Clear the clog. (For the cleaning procedure, contact your Fuji Electric representative.) |
| (13) Mismatch of motor parameters | For exclusive motors for the FRENIC-VG: Check whether the data of function code P02 matches the connected motor. → Correct the data of P02. For other motors: → Perform auto-tuning. |

[28]  Overload of motor 1 through 3

Problem Electronic thermal protection for motor 1, 2, or 3 activated.

-  Motor 1 overload
-  Motor 2 overload
-  Motor 3 overload

| Possible Causes | What to Check and Suggested Measures |
|---|--|
| (1) The electronic thermal characteristics do not match the motor overload characteristics. | Check the motor characteristics. → Reconsider the data of function codes F10, F12, A32, A34, A132 and A134. → Use an external thermal relay. |
| (2) The activation level for the electronic thermal protection was not appropriate. | Check the continuous allowable current of the motor. → Reconsider and change the data of function code F11, A33 or A133. |
| (3) The specified acceleration/ deceleration time was too short. | Recalculate the acceleration/deceleration torque and time needed for the load, based on the moment of inertia for the load and the acceleration/deceleration time. → Increase the acceleration/ deceleration time (F07, F08, C46, C47, C56, C57, C66, C67). |
| (4) Overload. | Measure the output current. → Reduce the load (e.g. Use the motor overload early warning (E34) to reduce the load before the overload protection is activated.). |
| <u>Under V/f control</u> (5) Excessive torque boost specified | Check whether decreasing the torque boost (P35, A55, A155) does not stall the motor. → If no stall occurs, decrease the data of P35, A55 or A155. |
| <u>Under vector control with/without speed sensor</u> (6) The control constants of the automatic speed regulator (ASR) are inadequate. | Check whether the actual speed overshoots or undershoots the commanded one. → Readjust the ASR (ASR gain, constant of integration, etc.). |

[29]  Inverter overload

Problem Electronic thermal overload protection for inverter activated.

| Possible Causes | What to Check and Suggested Measures |
|---|---|
| (1) The surrounding temperature exceeded the range of the inverter specification. | Measure the temperature around the inverter. → Lower the temperature (e.g., ventilate the panel where the inverter is mounted). |
| (2) Excessive torque boost specified. | Check whether decreasing the torque boost (P35, A55, A155) does not stall the motor. → If no stall occurs, decrease the torque boost (P35, A55, A155). |
| (3) The specified acceleration/ deceleration time was too short. | Recalculate the acceleration/deceleration torque and time needed for the load, based on the moment of inertia for the load and the acceleration/deceleration time. → Increase the acceleration/deceleration time (F07, C35, C46, C56, C66). |
| (4) Overload. | Measure the load factor to see that it does not exceed 100%. (Refer to Chapter 3, Section 3.4.4.7 "Measuring load factor -- Menu #6 "LOAD FCTR." → Reduce the load (e.g., Use the overload early warning (E33) and reduce the load before the overload protection is activated.). → Decrease the motor sound (Carrier frequency) (F26). |

| Possible Causes | What to Check and Suggested Measures |
|---|--|
| (5) Ventilation paths are blocked. | Check if there is sufficient clearance around the inverter. ➔ Change the mounting place to ensure the clearance. (For details, refer to Chapter 3, Section 3.3.2 "Installing the Inverter.") |
| | Check if the heat sink is not clogged. ➔ Clean the heat sink. (For the cleaning procedure, contact your Fuji Electric representative.) |
| (6) Cooling fan's airflow volume decreased due to the service life expired or failure. | Check the cumulative run time of the cooling fan. ➔ Replace the cooling fan. (Contact your Fuji Electric representative.) |
| | Visually check that the cooling fan rotates normally. ➔ Replace the cooling fan. (Contact your Fuji Electric representative.) |
| (7) The wires to the motor are too long, causing a large leakage current from them. | Measure the leakage current. ➔ Insert an output circuit filter (OFL). |
| <u>Under vector control with/without speed sensor</u> (8) Reference speed fluctuating | Check whether the reference speed is fluctuating. ➔ Increase the ASR input filter setting (F64, C43, C53, C63). |
| <u>Under vector control with/without speed sensor</u> (9) The control constants of the automatic speed regulator (ASR) are inadequate. | Check whether the actual speed overshoots or undershoots the commanded one. ➔ Readjust the ASR (ASR gain, constant of integration, etc.). |
| (10) Wrong wiring to the PG. | Check the wiring to the PG. ➔ Correct the wiring. (Refer to Chapter 3, Section 3.5.2.2 "Mounting direction of a PG (pulse generator) and PG signals.") |
| (11) Wrong wiring to the motor. | Check the wiring to the motor. ➔ Correct the wiring. It is also possible to use H75 (Phase sequence configuration of main circuit output wires). |
| (12) The magnetic pole position of the permanent magnet synchronous motor (PMSM) is out of place. | Check the magnetic pole position. ➔ Adjust the magnetic pole position (o10, A60, A160). (Refer to Chapter 3, Section 3.5.3.3 "Vector control for PMSM with speed sensor and magnetic pole position sensor," ■ Adjusting the magnetic pole position.) |

[30] Output phase loss

Problem Output phase loss occurred.

| Possible Causes | What to Check and Suggested Measures |
|--|---|
| (1) Inverter output wires are broken. | Measure the output current. ➔ Replace the output wires. |
| (2) The motor winding is broken. | Measure the output current. ➔ Replace the motor. |
| (3) The inverter output terminals or motor input terminals are weakly tightened. | Check if any screws on those terminals have become loose. ➔ Tighten the terminal screws to the recommended torque. |
| (4) A single-phase motor has been connected. | ➔ Single-phase motors cannot be used. (The FRENIC-VG is a drive for three-phase motors.) |

[31] OS Overspeed

Problem The motor rotates in an excessive speed (when Motor speed \geq Maximum speed setting \times H90 \div 100)

| Possible Causes | What to Check and Suggested Measures |
|--|--|
| <u>Under vector control with/without speed sensor</u> (1) Incorrect setting of function code data. | Check the maximum speed setting (function code F03, A06, A106). → Modify the data of F03, A06 or A106 in accordance with the machinery. Check the setting of the speed limiter (F76 to F78). → Enable the speed limiter (F76 to F78). |
| <u>Under vector control with/without speed sensor</u> (2) Insufficient gain of the speed controller (ASR). | Check whether the actual speed overshoots the commanded one in higher speed operation. → Increase the ASR gain (F61). (Depending on the situations, reconsider the setting of the filter constants or the integral time.) |
| <u>Under vector control with/without speed sensor</u> (3) The overspeed alarm detection level is not appropriate. | Check the setting of the overspeed alarm detection level (H90, Factory default 120%). → Set the data of H90, taking into account the maximum allowable speed for the machinery. |
| <u>Under vector control with speed sensor</u> (4) Noises superimposed on the PG wire. | Check whether appropriate noise control measures have been implemented (e.g., correct grounding and routing of signal wires and main circuit wires). → Implement noise control measures. For details, refer to the FRENIC-VG User's Manual, "Appendix A." |
| <u>Under vector control with/without speed sensor</u> (5) Droop gain too large. | Check whether the droop gain is appropriate. → Decrease the droop gain (H28). |
| <u>Under vector control with/without speed sensor</u> (6) The motor parameters do not match the connected motor. | For motors exclusive to the FRENIC-VG: Check whether the setting of function code P02 matches the connected motor. → Correct the data of P02. For other motors: → Perform auto-tuning. |
| <u>Under vector control without speed sensor</u> (7) Breaks in the inverter output circuit. | Check the inverter output circuit. → Correct the wiring. |
| <u>Under vector control with speed sensor</u> (8) PG waveform abnormal. | Measure the PG waveform. → Replace the PG. |
| <u>Under vector control with speed sensor</u> (9) Mismatch between the PG's pulse resolution and the function code setting. | Check the function code setting (P28, A30, A130). → Match the function code settings with the PG specifications. |
| (10) The magnetic pole position of the permanent magnet synchronous motor (PMSM) is out of place. | Check the magnetic pole position. → Adjust the magnetic pole position (o10, A60, A160). (Refer to Chapter 3, Section 3.5.3.3 "Vector control for PMSM with speed sensor and magnetic pole position sensor," ■ Adjusting the magnetic pole position.") |

[32] Overvoltage

Problem The DC link bus voltage exceeded the overvoltage detection level.

| Possible Causes | What to Check and Suggested Measures |
|--|--|
| (1) The power supply voltage exceeded the range of the inverter specification. | Measure the input voltage. → Decrease the voltage to within the specified range. |
| (2) A surge current entered the input power supply. | In the same power line, if a phase-advancing capacitor is turned ON/OFF or a thyristor converter is activated, a surge (momentary large increase in the voltage or current) may be caused in the input power. → Install a DC reactor. |
| (3) The deceleration time was too short for the moment of inertia of the load. | Recalculate the deceleration torque based on the moment of inertia of the load and the deceleration time. → Increase the deceleration time (F08, C36, C47, C57, C67). → Consider the use of a braking resistor or PWM converter (RHC-C). → Decrease the moment of inertia of the load. → Enable the overvoltage trip prevention (H57). → Select the power limit function (F40 = 2). → <u>Under vector control with speed sensor</u> Enable the torque limiter (F40 to F45). |
| (4) The acceleration time was too short. | Check if an overvoltage alarm occurs after rapid acceleration. → Increase the acceleration time (F07, C35, C46, C56, C66). → Select the S-curve acceleration/deceleration (F67 to F70). → Consider the use of a braking resistor or PWM converter (RHC-C). → Decrease the moment of inertia of the load. |
| (5) Braking load was too heavy. | Compare the braking torque of the load with that of the inverter. → Consider the use of a braking resistor or PWM converter (RHC-C). |
| (6) Malfunction caused by noise. | Check if the DC link bus voltage was below the protective level when the overvoltage alarm occurred. → Implement noise control measures. For details, refer to the FRENIC-VG User's Manual, "Appendix A." → Enable the auto-reset (H04). → Connect a surge absorber to magnetic contactor's coils or other solenoids (if any) causing noise. |
| (7) The inverter output lines were short-circuited. | Disconnect the wiring from the inverter output terminals ([U], [V] and [W]) and measure the interphase resistance of the motor wiring. Check if the resistance is too low. → Remove the short-circuited part (including replacement of the wires, relay terminals and motor). |
| (8) Wrong connection of the braking resistor. | Check the connection. → Correct the connection. |
| (9) Large, rapid decrease of the load. | Check whether the inverter runs at the time of rapid decrease of the load. → Consider the use of a braking resistor or PWM converter (RHC-C). |

[33] PG PG wire break

Problem The pulse generator (PG) wire has been broken somewhere in the circuit.

| Possible Causes | What to Check and Suggested Measures |
|--|---|
| (1) Break in the PG wiring. Inverter PA, PB: [Sub code: 0001] Inverter power supply: [Sub code: 0004] Option: [Sub code: 0002] (OPC-VG1-PG, OPC-VG1-PMPG) | Check whether the PG is correctly connected to the option or any wire is broken. → Check whether the PG is connected correctly. Or, tighten up the related terminal screws. → Check whether any joint or connecting part bites the wire sheath. → Replace the wire. |
| <u>PMSM</u> When the option card (OPC-VG1-PMPG) is used: (2) Connection failure of speed/magnetic pole position sensor. (3) Mismatch between the motor rotation direction and sensor output. [Sub code: 0010 to 0400] | Check the output wiring of the speed/magnetic pole position sensor for poor contact or the phase sequence of the AB phases and UVW phases. → Correct the connection between the option card and the speed/magnetic pole position sensor. Check the motor wiring for poor contact or the phase sequence. → Correct the connection between the inverter and the motor. |
| (4) Connection failure of option card (OPC-VG1-PG, OPC-VG1-PMPG). | Check whether the connector of the option card engages with that of the inverter unit. → Mount the option card on the inverter unit correctly. |
| (5) PG related circuit affected by strong electrical noise. | Check if appropriate noise control measures have been implemented (e.g., correct grounding and routing of signal wires, communication cables, and main circuit wires). → Implement noise control measures. → Separate the signal wires from the main power wires as far as possible. |
| (6) Motor drive control wrongly selected. | Check the motor drive control currently selected. → If no PG is mounted, select the vector control without speed sensor. |
| (7) Mismatch between the PG power voltage (rated) and the output voltage setting of terminal [PGP]. | Check the PG power voltage (rated) and the output voltage setting of terminal [PGP] (switchable with SW6). → Set SW6 properly. For details, refer to Chapter 3, Section 3.3.3.9 "Setting up the slide switches." |
| (8) PG wires small in size. | Check whether the PG wires satisfy the recommended wire size. → Replace the wires with the recommended one. |
| (9) PG waveform abnormal. | Check whether the inverter internal control circuit (PG input circuit) is faulty, using the self-diagnosis function of the PG detection circuit (H74). → If the result is "Normal," replace the PG; if it is "Abnormal," contact your Fuji Electric representative. Check the PG waveform using an oscilloscope. → Replace the PG. |

[34] *PbF* Charger circuit fault

Problem The magnetic contactor for short-circuiting the charging resistor failed to work. (For 200 V class series of 37 kW or above and those of 75 kW or above)

| Possible Causes | What to Check and Suggested Measures |
|---|---|
| (1) No control power was supplied to the magnetic contactor (MC) intended for short-circuiting the charging resistor. | Check that, in normal connection of the main circuit (not a connection via the DC link bus), the connector (CN R) on the power printed circuit board (power PCB) is not inserted to [NC]. → Insert the connector (CN R) to [FAN]. For details, refer to Chapter 3, Section 3.3.3.6 "Switching connectors, ■ Fan power supply switching connectors." |
| (2) Breaks in wiring to the main power input terminals. | Measure the input voltage. → Repair or replace the main circuit power input wires or input devices (MCCB, MC, etc.). |

[35] *ECF* ENABLE input circuit failure (Functional safety circuit error)

Problem ENABLE input circuit failure has occurred.

| Possible Causes | What to Check and Suggested Measures |
|---|--|
| (1) Poor contact of the control circuit terminal block. | Check whether the control circuit terminal block is firmly mounted on the inverter unit. |
| (2) ENABLE input circuit logic error. [Sub code: 0010] [Sub code: 0020] | Check the ON/OFF states of terminals [EN1] and [EN2], using Menu #4 "I/O CHECK" on the keypad. → Check that terminals [EN1] and [PS] are wired together and terminals [EN2] and [PS] are wired together. → Operate the relay so that the ON/OFF timings of [EN1] and [EN2] are matched. → Check whether the relay is welded. If it is welded, replace it. → Check the gap of ON/OFF timings between [EN1] and [EN2]. Keep the timing gap within 50 ms. |
| (3) ENABLE input circuit failure. | The failure persists even after the measures given in (2) above are performed. → Ask your Fuji Electric representative to repair the inverter. Inform the representative of the alarm sub code displayed. |

13.4 If the "Light Alarm" Indication ($\mathcal{L} - \mathcal{FL}$) Appears on the LED Monitor

If the inverter detects a minor abnormal state "light alarm," it can continue the current operation without tripping while displaying the "light alarm" indication $\mathcal{L} - \mathcal{FL}$ on the LED monitor. In addition to the indication $\mathcal{L} - \mathcal{FL}$, the inverter blinks the KEYPAD CONTROL LED and outputs the "light alarm" signal **L-ALM** to a general-purpose digital output terminal to alert the peripheral equipment to the occurrence of a light alarm. (To use the **L-ALM**, it is necessary to assign the signal to any of the digital output terminals by setting any of function codes E15 through E19 to "57.")

Function codes H106 through H110 specify which alarms should be categorized as "light alarm." The available "light alarm" codes are check-marked in the "Light alarm" object column in Table 13.1.

For the "light alarm" factors and the alarm removal procedure, refer to Chapter 3, Section 3.4.3.5 "Monitoring light alarms."

Light alarm $\mathcal{S}_{r/f}$ that could occur in the functional safety card OPC-VG1-SAFE cannot be selected with H106 through H110. For details about $\mathcal{S}_{r/f}$, refer to the Functional Safety Card instruction manual.

13.5 If Neither an Alarm Code Nor "Light Alarm" Indication (L -AL) Appears on the LED Monitor

13.5.1 Abnormal motor operation

[1] The motor does not rotate.

| Possible Causes | What to Check and Suggested Measures |
|---|---|
| (1) No power supplied to the inverter. | <p>Check the input voltage and interphase voltage unbalance.</p> <ul style="list-style-type: none"> ➔ Turn ON a molded case circuit breaker (MCCB), a residual-current-operated protective device (RCD)/earth leakage circuit breaker (ELCB) (with overcurrent protection) or a magnetic contactor (MC). ➔ Check for voltage drop, phase loss, poor connections, or poor contacts, and fix them if necessary. ➔ If only the auxiliary control power input is supplied, also supply the main power to the inverter. |
| (2) No run forward/reverse command was inputted, or both the commands were inputted simultaneously (external signal operation). | <p>Check the input status of the forward/reverse command with Menu #4 "I/O CHECK" using the keypad.</p> <ul style="list-style-type: none"> ➔ Input a run command. ➔ Set either the forward or reverse operation command to off if both commands are being inputted. ➔ Correct the run command source. (Set the data of F02 to "1.") ➔ Connect the external circuit wires to control circuit terminals [FWD] and [REV] correctly. ➔ Make sure that the sink/source slide switch (SW1) on the control printed circuit board (control PCB) is properly configured. (Refer to Chapter 3, Section 3.3.3.9 "Setting up the slide switches.") |
| (3) A run command with higher priority than the one attempted was active, and the run command was stopped. Or, a speed command was active. | <p>Referring to the run command block diagram given in the FRENIC-VG User's Manual, Chapter 4, check the higher priority run command using Menu #2 "DATA CHECK" and Menu #4 "I/O CHECK" with the keypad.</p> <ul style="list-style-type: none"> ➔ Correct wrong setting of function code H30 (Communications link function, Mode selection) or cancel the higher priority run command. |
| (4) No analog speed command input. | <p>Check whether the analog speed command is correctly inputted, using Menu #4 "I/O CHECK" on the keypad.</p> <ul style="list-style-type: none"> ➔ Connect the external circuit wires to terminals [13], [12], [11], [Ai1] and [Ai2] correctly. ➔ Inspect the external speed command potentiometers, signal converters, switches and relay contacts. Replace any ones that are faulty. |
| <u>Under V/f control</u> (5) The reference speed was below the starting or stop speed. | <p>Check that a speed command has been entered correctly, using Menu #4 "I/O CHECK" on the keypad.</p> <ul style="list-style-type: none"> ➔ Set the reference speed at the same or higher than the starting speed (F23). ➔ Reconsider the starting speed (F23), and if necessary, change it to the lower value. ➔ Inspect the external speed command potentiometers, signal converters, switches and relay contacts. Replace any ones that are faulty. ➔ Connect the external circuit wires to terminals [13], [12], [11], [Ai1] and [Ai2] correctly. |

13.5 If Neither an Alarm Code Nor "Light Alarm" Indication ($\angle -F_L$) Appears on the LED Monitor

| Possible Causes | What to Check and Suggested Measures |
|---|--|
| (6) A run command with higher priority than the one attempted was active. | Referring to the run command block diagram given in the FRENIC-VG User's Manual, Chapter 4, check the higher priority run command using Menu #2 "DATA CHECK" and Menu #4 "I/O CHECK" with the keypad. → Correct the wrong setting of function codes (e.g., cancel the higher priority run command). → Correct wrong setting of function code H30 (Communications link function, Mode selection) or cancel the higher priority run command. |
| (7) The speed limiter settings were made incorrectly. | Check the data of function codes F76 (Speed limiter mode), F77 and F78 (Speed limiter levels 1 and 2). → Correct the data of F76 through F78. |
| (8) The coast-to-stop command was effective. | Check the data of function codes E01 through E09 and the input signal status of X terminals, using Menu #4 "I/O CHECK" on the keypad. → Release the coast-to-stop command setting. Check the input signal status of terminal [EN], using Menu #4 "I/O CHECK" on the keypad. → Short-circuit the terminal [EN] with terminal [PS]. |
| (9) No input on [EN1] or [EN2]. | Check the input status of the EN terminal, using Menu #4 "I/O CHECK" on the keypad. → Short-circuit each of [EN1] and [EN2] with [PS]. - To make inverters <i>not</i> compliant with the Functional Safety Standard (STO), short-circuit each of [EN1] and [EN2] with [PS]. (Refer to Chapter 3, Section 3.3.3.8 "Detailed functions of control circuit terminals.") - To make inverters compliant with the Functional Safety Standard (STO), refer to the FRENIC-VG Instruction Manual. |
| (10) Broken wires, incorrect connection or poor contact with the motor. Or the motor defective. | Check the wiring and the motor. (Measure the output current). → Repair the wires to the motor, or replace them. → Repair the motor or replace it. |
| (11) Overload | Measure the output current. → Reduce the load (In winter, the load tends to increase.) → Increase the inverter and motor capacities. Check whether any mechanical brake is activated. → Release the mechanical brake, if any. |
| (12) Torque generated by the motor was insufficient. | Check that the motor switching signal (selecting motor 1, 2 or 3) is correct using Menu #4 "I/O CHECK" on the keypad and that the data of function codes matches each motor. → Correct the motor switching signal. → Modify the function code data to match the connected motor. |
| <u>Under V/f control</u> (13) Torque generated by the motor was insufficient. | Check whether the reference speed is below the slip-compensated speed of the motor (Function codes P10 and P11 for M1, A12 and A13 for M2, and A112 and A113 for M3). → Change the reference speed so that it becomes higher than the slip-compensated speed of the motor. Check whether increasing the torque boost (Function code P35, A55, A155) starts rotating the motor. → Increase the data of P35, A55 or A155. Check the data of function code F04, A05 or A105. → Change the V/f pattern setting to match each motor. |

| Possible Causes | What to Check and Suggested Measures |
|---|---|
| (14) Wrong connection or poor contact of DC reactor (DCR) | <p>Check the wiring between the main circuit terminals P1 and P(+). Inverters of 55 kW in LD mode and inverters of 75 kW or above come with a DCR as standard. Without connection of a DCR, these inverters cannot run.</p> <p>➔ Connect a jumper bar or DCR correctly. Repair or replace wires to the DCR.</p> |
| (15) No reference speed setting (keypad operation). | <p>Check the reference speed setting made on the keypad.</p> <p>➔ Modify the reference speed setting by pressing [↑] key.</p> |
| (16) The inverter could not accept any run commands from the keypad since it was in Programming mode. | <p>Check which operation mode the inverter is in, using the keypad.</p> <p>➔ Shift the operation mode to Running mode and enter a run command.</p> |
| <u>Under vector control with speed sensor</u> (17) Incorrect setting of the number of poles of the motor | <p>Check whether the setting of function code P05, A07 or A107 (No. of poles) matches the number of poles of the actual motor.</p> <p>➔ Set the data of P05, A07 or A107 to the correct number of poles.</p> |
| <u>Under vector control with speed sensor</u> (18) Wrong wiring between the motor and pulse generator (PG). | <p>Check the motor wiring (phase sequence) and the polarity of the PG.</p> <p>➔ Correct the wiring. Refer to Chapter 3, Section 3.5.2.2 "Mounting direction of a PG (pulse generator) and PG signals."</p> |
| <u>Under vector control with/without speed sensor</u> (19) Incorrect setting of the torque limiter level. | <p>Check whether the torque limiter level (Function code F44, F45) is set to zero (0).</p> <p>➔ Modify the data of F44 or F45 to the appropriate value.</p> |
| <u>Under vector control with/without speed sensor</u> (20) Incorrect setting of the torque command. | <p>Check whether the torque command of terminal [Ai1]/[Ai2] is zero (0) under torque control mode.</p> <p>➔ Modify the torque command to the appropriate value.</p> |
| <u>Under vector control with speed sensor</u> (21) Mismatch between the PG's pulse resolution and the function code setting. | <p>Check whether the setting of function code P28, A30 or A130 matches the pulse resolution of the actual PG.</p> <p>➔ Modify the data of P28, A30 or A130 to the appropriate value.</p> <p>Check whether the voltage setting of terminal [PGP] (SW6) matches the voltage specification of the actual PG.</p> <p>➔ Set SW6 to the appropriate position.</p> |
| (22) The magnetic pole position of the permanent magnet synchronous motor (PMSM) is out of place. | <p>Check the magnetic pole position.</p> <p>➔ Adjust the magnetic pole position (o10, A60, A160). (Refer to Chapter 3, Section 3.5.3.3 "Vector control for PMSM with speed sensor and magnetic pole position sensor," ■ Adjusting the magnetic pole position.")</p> |

[2] The motor rotates, but the speed does not change.

| Possible Causes | What to Check and Suggested Measures |
|--|--|
| (1) The setting of the maximum speed was too low. | Check the data of function code F03, A06 or A106 (Maximum speed). → Modify the data of F03, A06 or A106 to the appropriate value. |
| (2) The setting of the speed limiter was too low. | Check the setting of the speed limiter (F76 to F78). → Modify the data of F76 to F78 to the appropriate value. |
| (3) The reference speed (analog setting) did not change. | Check whether the reference speed has been entered correctly, using Menu #4 "I/O CHECK" on the keypad. → Increase the reference speed. → Inspect the external speed command potentiometers, signal converters, switches, and relay contacts. Replace any ones that are faulty. → Connect the external circuit wires to terminals [13], [12], [11], [Ai1] and [Ai2] correctly. |
| (4) The external circuit wiring to terminals [X1] to [X9] or signal assignment to those terminals is wrong. | Check whether the reference speed has been entered correctly, using Menu #4 "I/O CHECK" on the keypad. → Connect the external circuit wires to terminals [X1] through [X9]. → Correct the data of E01 to E14. → Correct the data of C05 to C21 (Multistep speed settings). |
| (5) A reference speed (e.g., multistep speed or via communications link) with higher priority than the one attempted was active and the reference speed was too low. | Referring to the speed command block diagram given in the FRENIC-VG User's Manual, Chapter 4, check the data of the relevant function codes and what speed commands are being received, using Menu #2 "DATA CHECK" and Menu #4 "I/O CHECK" with the keypad. → Correct any incorrect data of function codes (e.g. cancel the higher priority reference speed). |
| (6) The acceleration or deceleration time was too long or too short. | Check the settings of the acceleration time and deceleration time (function codes F07, F08, C35, C36, C46, C47, C56, C57, C66 and C67). → Change the acceleration/deceleration time to match the load. |
| (7) Overload. | Measure the output current. → Reduce the load. Check whether any mechanical brake is activated. → Release the mechanical brake. |
| <u>Under V/f control</u> (8) Function code settings do not agree with the motor characteristics. | If auto-torque boost (Function code P35, A55, A155) is enabled, check whether the data of P03, P04, P06, P07 and P08 for M1, A02, A03, A08, A09 and A10 for M2, A102, A103, A108, A109 and A110 for M3 matches the parameters of the motor. → Perform auto-tuning of the inverter for the motor to be used. |
| <u>Under V/f control</u> (9) The output frequency does not increase due to the current limiter operation. | Decrease the value of the torque boost (Function code P35, A55, A155), then run the motor again and check if the speed increases. → Adjust the value of the torque boost (P35, A55, A155). Check the data of function codes F04, A05 and A105 to ensure that the V/f pattern setting is right. → Match the V/f pattern setting with the motor ratings. |
| (10) The motor speed does not increase due to the torque limiter operation. | Check whether the data of torque limiter related function codes F40 through F45 is correctly configured and the <i>TL2/TL1</i> terminal command ("Select torque limiter level") is correct. → Correct the data of F44 or F45 or enter the <i>F40-CCL</i> terminal command ("Cancel F40 (Torque limiter mode 1)"). |

| Possible Causes | What to Check and Suggested Measures |
|---|--|
| (11) Incorrect settings of bias and gain for analog input. | Check the data of function codes F17, F18 and E53 to E60. ➔ Correct the bias and gain settings. |
| (12) The reference speed did not change. (Keypad operation) | Check whether modifying the reference speed setting from the keypad changes the reference speed. ➔ Modify the reference speed setting by pressing the [↑] and [↓] keys. |
| <u>Under vector control with speed sensor</u> (13) Wrong wiring of the PG. | Check the wiring between the PG and the inverter for the phase sequence, wire breaks, shielding and twisting. ➔ Correct the wiring. (Refer to Chapter 3, Section 3.5.2.2 "Mounting direction of a PG (pulse generator) and PG signals.") |
| <u>Under vector control with speed sensor</u> (14) Wrong wiring between the inverter and the motor. | Check the phase sequence (U, V, and W) of the main circuit wires between the inverter and the motor. ➔ Connect the inverter output terminals U, V, and W to the motor input terminals U, V, and W, respectively. |
| <u>Under vector control with/without speed sensor</u> (15) Function code settings do not agree with the motor characteristics. | For exclusive motors for the FRENIC-VG: Check whether the data of function code P02 matches the specification of the connected motor. ➔ Correct the data of P02. For other motors: ➔ Perform auto-tuning. |

[3] The motor runs in the opposite direction to the command.

| Possible Causes | What to Check and Suggested Measures |
|--|--|
| <u>Under V/f control</u> <u>Under vector control without speed sensor</u> (1) Wrong wiring to the motor. | Check the wiring to the motor. ➔ Connect the inverter output terminals U, V, and W to the motor input terminals U, V, and W, respectively. |
| (2) The rotation direction specification of the motor is opposite to that of the inverter. | The rotation direction of IEC-compliant motors is opposite to that of non-compliant motors. ➔ Switch the <i>FWD/REV</i> signal setting. |
| (3) Incorrect setting of speed command related function code data. | Check the data of the speed command related function codes, referring to the speed command block diagram given in the FRENIC-VG User's Manual, Chapter 4. ➔ Correct the data of the related function codes. |
| <u>Under vector control with speed sensor</u> (4) Wrong wiring of the PG. | Check the wiring to the motor. ➔ Correct the wiring. (Refer to the Chapter 3, Section 3.5.2.2 "Mounting direction of a PG (pulse generator) and PG signals.") |

[4] Speed fluctuation or current oscillation (e.g., hunting) occurs during running at constant speed.

| Possible Causes | What to Check and Suggested Measures |
|--|--|
| (1) The analog speed command fluctuates. | <p>Check the signal status for the speed command with Menu #4 "I/O CHECK" using the keypad. (Refer to Chapter 3, Section 3.4.4.4 "Monitoring the running status.")</p> <ul style="list-style-type: none"> ➔ Increase the filter constants (F83, E61 to E64) for the speed command. ➔ Take measures to keep the speed command constant. |
| (2) An external potentiometer is used for speed setting. | <p>Check that there is no noise on the control signal wires connecting to external sources.</p> <ul style="list-style-type: none"> ➔ Isolate the control signal wires from the main circuit wires as far as possible. ➔ Use shielded or twisted wires for control signals. <p>Check whether the external speed command potentiometer is malfunctioning due to noise from the inverter.</p> <ul style="list-style-type: none"> ➔ Connect a capacitor to the output terminal of the potentiometer or set a ferrite core on the signal wire. (Refer to Chapter 2.) |
| (3) Speed switching or multistep speed command was enabled. | <p>Check whether the relay signal for switching the speed command is chattering.</p> <ul style="list-style-type: none"> ➔ If the relay contact is defective, replace the relay. |
| (4) The wiring length between the inverter and the motor is too long. | <p>Check whether auto-torque boost is enabled (P35, A55, A155).</p> <ul style="list-style-type: none"> ➔ Perform auto-tuning. ➔ <u>Under V/f control</u>, disable the automatic control system (select manual torque boost), then check that the motor vibration stops. ➔ Make the output wires as short as possible. |
| (5) The machinery is hunting due to vibration caused by low rigidity of the load. Or the current is irregularly oscillating due to special motor parameters. | <p>Once disable all the automatic control systems (speed control, auto torque boost, current limiter, torque limiter and droop control), then check that the motor vibration comes to a stop.</p> <ul style="list-style-type: none"> ➔ <u>Under vector control with/without speed sensor</u>, readjust the speed control system. (F61 through F66, C40 through C45, C50 through C55) ➔ Disable the automatic control system(s) causing the vibration. |
| (6) Function code settings do not agree with the motor characteristics. | <p>For exclusive motors for the FRENIC-VG: Check whether the setting of function code P02 matches the specification of the connected motor.</p> <ul style="list-style-type: none"> ➔ Correct the data of P02. <p>For other motors:</p> <ul style="list-style-type: none"> ➔ Perform auto-tuning. |
| (7) Load is fluctuating. | <p><u>Under vector control with/without speed sensor</u></p> <p>Check whether automatic speed regulator (ASR) is properly configured. (F61 through F66, C40 through C45, C50 through C55)</p> <ul style="list-style-type: none"> ➔ Readjust the ASR setting. |

[5] Grating sound is heard from the motor or the motor sound fluctuates.

| Possible Causes | What to Check and Suggested Measures |
|---|---|
| (1) The specified carrier frequency is too low. | Check the data of function code F26 (Motor sound (Carrier frequency)). → Increase the data of F26. |
| (2) The surrounding temperature of the inverter was too high. | Measure the temperature inside the panel where the inverter is mounted. → If it is over 40°C, lower it by improving the ventilation. → Lower the temperature of the inverter by reducing the load. |
| (3) Resonance with the load. | Check the machinery mounting accuracy or check whether there is resonance with the mounting base. → Disconnect the motor from the machinery and run it alone to find where the resonance comes from. Upon locating the cause, improve the characteristics of the source of the resonance. → Adjust the jump speed (C01 through C04) to avoid continuous running in the frequency range causing resonance. → Specify the observer (H47 through H52, H125 through H127) to suppress vibration. (Depending on the characteristics of the load, this may take no effect.) → Decrease the P gain of the auto speed regulator (ASR). (F61, C40, C50, C60) |

[6] The motor does not accelerate or decelerate within the specified time.

| Possible Causes | What to Check and Suggested Measures |
|--|--|
| (1) The inverter runs the motor with S-curve acceleration/ deceleration. | Check the data of function codes F67 through F70 (S-curve acceleration/ deceleration pattern). → Select the linear pattern (F67 through F70 = 0). → Decrease the acceleration/deceleration time (F07, F08, C46, C47, C56, C57, C66, C67). |
| <u>Under V/f control</u> (2) The current limiting operation prevented the output frequency from increasing (during acceleration). | Check whether the acceleration time and torque boost are properly specified. → Increase the acceleration time (F07, C35, C46, C56, C66). → Decrease the torque boost (P35, A55, A155) and restart the inverter to check that the speed increases. |
| (3) Overload. | Measure the output current. → Reduce the load. |
| <u>Under V/f control</u> (4) Torque generated by the motor was insufficient. | Check that increasing the torque boost (P35, A55, A155) starts the motor. → Increase the value of the torque boost (P35, A55, A155). |
| (5) An external potentiometer is used for frequency setting. | Check that there is no noise on the control signal wires connecting to external sources. → Isolate the control signal wires from the main circuit wires as far as possible. → Use shielded or twisted wires for control signals. Check whether the external speed command potentiometer is malfunctioning due to noise from the inverter. → Connect a capacitor to the output terminal of the potentiometer or set a ferrite core on the signal wire. (Refer to Chapter 3, Section 3.3.3.8.) |

| Possible Causes | What to Check and Suggested Measures |
|--|---|
| (6) Motor torque generated is limited by the torque limiter. | <p>Check whether data of torque limiter related function codes (F40 through F45) is correctly configured and the TL2/TL1 terminal command ("Select torque limiter level 2/1") is correct.</p> <p>➔ Correct the data of F40 through F45 or reset them to the factory defaults.</p> <p>Check whether the speed command potentiometer is malfunctioning due to noise from the inverter.</p> <p>➔ Set the TL2/TL1 correctly.</p> <p>➔ Increase the acceleration/deceleration time (F07, F08, C35, C36, C46, C47, C56, C57, C66, C67).</p> |
| (7) The specified acceleration or deceleration time was incorrect. | <p>Check the terminal commands RT1 and RT2 for acceleration/deceleration times.</p> <p>➔ Correct the RT1 and RT2 settings.</p> |

[7] The motor does not restart even after the power recovers from a momentary power failure.

| Possible Causes | What to Check and Suggested Measures |
|---|--|
| (1) The data of function code F14 is either "0," "1," or "2." | <p>Check if an undervoltage trip ($\angle L'$) occurs.</p> <p>➔ Change the data of F14 (Restart mode after momentary power failure, Mode selection) to "3," "4," or "5."</p> |
| (2) The run command remains OFF even after the power has been restored. | <p>Check the input signal with Menu #4 "I/O CHECK" using the keypad.</p> <p>➔ Check the power recovery sequence with an external circuit. If necessary, consider the use of a relay that can keep the run command ON.</p> <p>In 3-wire operation, the power to the control printed circuit board (control PCB) has been shut down once because of a long momentary power failure time, or the HOLD signal ("Enable 3-wire operation") has been turned OFF once.</p> <p>➔ Change the design or the setting so that a run command can be issued again within 2 seconds after the power has been restored.</p> |

[8] The motor abnormally heats up.

| Possible Causes | What to Check and Suggested Measures |
|--|--|
| (1) Airflow volume of the motor's cooling fan decreased due to the service life expired or failure | Visually check whether the cooling fan rotates normally. → Ask your Fuji Electric representative to repair the motor's cooling fan. |
| <u>Under V/f control</u> (2) Excessive torque boost specified. | Check whether decreasing the torque boost (P35, A55, A155) decreases the output current but does not stall the motor. → If no stall occurs, decrease the torque boost (P35, A55, A155). |
| <u>Under V/f control</u> (3) Continuous running in extremely slow speed. | Check the running speed of the inverter. → Change the speed setting or replace the motor with an exclusive motor for inverters (motor with separately powered cooling fan). |
| (4) Overload. | Measure the inverter output current. → Reduce the load. → Increase the inverter capacity and motor capacity. |
| <u>Under vector control with/without speed sensor</u> (5) Function code settings do not agree with the motor characteristics. | For exclusive motors for the FRENIC-VG: Check whether the setting of function code P02 matches the connected motor. → Correct the data of P02. For other motors: → Perform auto-tuning. |
| (6) Motor defective. | Check whether the inverter output voltages (U, V and W) are well-balanced. → Repair or replace the motor. |

[9] The motor does not run as expected.

| Possible Causes | What to Check and Suggested Measures |
|--|---|
| (1) Incorrect setting of function code data. | Check that function codes are correctly configured and no unnecessary configuration has been done. → Configure all the function codes correctly. |
| | Make a note of function code data currently configured and then initialize all function code data using H03. → After the above process, reconfigure function codes one by one, checking the running status of the motor. |
| (2) Under torque control, the inverter keeps output although the run command is OFF. | Check the setting of the automatic operation OFF function (H11). → Set the data of H11 to "2" ("Coast to a stop when a run command is turned OFF") or "4" ("Coast to a stop when a run command is turned OFF" under torque control). |

[10] When the motor accelerates or decelerates, the speed is not stable.

| Possible Causes | What to Check and Suggested Measures |
|---|---|
| <u>Under vector control with/without speed sensor</u> (1) The control constants of the automatic speed regulator (ASR) are inadequate. | Check whether the automatic speed regulator (ASR) is properly adjusted under speed control. → Readjust the ASR (F61 to F66, C40 to C45, C50 to C55). |

[11] The motor stalls during acceleration.

| Possible Causes | What to Check and Suggested Measures |
|---|---|
| <p><u>Under vector control with/without speed sensor</u></p> <p>(1) Function code settings do not agree with the motor characteristics.</p> | <p>For exclusive motors for the FRENIC-VG: Check whether the setting of function code P02 matches the connected motor.</p> <p>→ Correct the data of P02.</p> <p>For other motors:</p> <p>→ Perform auto-tuning.</p> |
| <p><u>Under V/f control</u></p> <p>(2) The specified acceleration time is too short.</p> | <p>Check the data of F07, C35, C46, C56 or C66 (acceleration time).</p> <p>→ Increase the acceleration time.</p> |
| <p><u>Under V/f control</u></p> <p>(3) The moment of inertia of the load is large.</p> | <p>Measure the inverter output current.</p> <p>→ Decrease the moment of inertia of the load.</p> <p>→ Increase the inverter capacity.</p> |
| <p><u>Under V/f control</u></p> <p>(4) Large voltage drop on wires.</p> | <p>Check the terminal voltage of the motor.</p> <p>→ Use larger size wires between the inverter and motor or make the wiring distance shorter.</p> |
| <p><u>Under V/f control</u></p> <p>(5) The torque of the load is large.</p> | <p>Measure the output current.</p> <p>→ Decrease the torque of the load.</p> <p>→ Increase the inverter capacity.</p> |
| <p><u>Under V/f control</u></p> <p>(6) Torque generated by the motor was insufficient.</p> | <p>Check that increasing the torque boost (P35, A55, A155) starts the motor.</p> <p>→ Increase the value of the torque boost (P35, A55, A155).</p> |

[12] When the T-Link communications option is in use, neither a run command nor a speed command takes effect.

| Possible Causes | What to Check and Suggested Measures |
|--|--|
| <p>(1) Incorrect setting of the communications link operation (H30).</p> | <p>Check whether the setting of the communications link operation is correct (H30).</p> <p>→ Correct the data of H30.</p> <p>→ Check the status of the X terminal to which the LE command ("Enable communications link") is assigned.</p> |
| <p>(2) Incorrect setting of the transmission format (o32).</p> | <p>Check whether the setting of the transmission format is correct (o32).</p> <p>→ Correct the data of o32 (4W + 4W or 8W + 8W).</p> |
| <p>(3) Incorrect setting of the link number.</p> | <p>Check the current setting of the link number (that should be configured in hexadecimal).</p> <p>→ Review the function code list.</p> |
| <p>(4) Data not written to the I/O relay area as assigned.</p> | <p>Check the data held in the I/O relay area, using the MICREX loader.</p> <p>→ Investigate writing into the I/O relay area.</p> |

[13] When the SX-bus communications option is in use, neither a run command nor a speed command takes effect.

| Possible Causes | What to Check and Suggested Measures |
|---|---|
| (1) Incorrect setting of the communications link operation (H30). | Check whether the setting of the communications link operation is correct (H30). → Correct the data of H30. |
| (2) Terminal command LE is assigned to an X terminal, but the terminal is OFF. | Check the status of the X terminal to which the LE command ("Enable communications link") is assigned. → Turn the corresponding X terminal ON. |
| (3) Incorrect setting of the transmission format (U11). | Check whether the transmission format selected by U11 is identical with the one selected in the system configuration definition. → Correct the setting of the transmission format. |
| (4) Incorrect setting of the link number. | Check the current setting of the link number (that should be configured in hexadecimal). → Review the function code list. |
| (5) Data not written to the I/O relay area as assigned. | Check the data in application programs, using the SX loader. → Investigate writing into the I/O memory area. |

[14] When the CC-Link communications option is in use, neither a run command nor a speed command takes effect.

| Possible Causes | What to Check and Suggested Measures |
|---|---|
| (1) Incorrect setting of the communications link operation (H30). | Check whether the setting of the communications link operation is correct (H30). → Correct the data of H30. |
| (2) Terminal command LE is assigned to an X terminal, but the terminal is OFF. | Check the status of the X terminal to which the LE command ("Enable communications link") is assigned. → Turn the corresponding X terminal ON. |
| (3) Incorrect setting of the transmission format (o32). | Check whether the transmission format selected by o32 is identical with the one selected in the system configuration definition. → Correct the setting of the transmission format. |
| (4) Incorrect setting of the link number. | Check the current setting of the link number (that should be configured in hexadecimal). → Review the function code list. |
| (5) Data not written to the I/O memory area as assigned. | Check the data in application programs, using the PLC loader. → Investigate writing into the I/O memory area. |

[15] _ _ _ _ (under bar) appears.

Problem Although you pressed the \overline{FWD} or \overline{REV} key or entered a run forward command **FWD** or a run reverse command **REV**, the motor did not start and an under bar (_ _ _ _) appeared on the LED monitor.

| Possible Causes | What to Check and Suggested Measures |
|---|---|
| (1) The DC link bus voltage was low. | Select Menu #5 "MAINTENANCE" in Programming mode on the keypad and check the DC link bus voltage which should be 200 VDC or below for three-phase 200 V class series, and 400 VDC or below for three-phase 400 V class series. → Connect the inverter to a power supply that meets its input specifications. |
| (2) The main power is not ON, while the auxiliary input power to the control circuit is supplied. | Check whether the main power is turned ON. → Turn the main power ON. Check whether the short bar is removed from terminals P1 and P(+) or check the short bar for poor contact. → Mount a short bar or DC reactor (DCR) between terminals P1 and P(+). Or tighten the fixing screw further. |
| (3) Although power is supplied not via the commercial power line but via the DC link bus, the main power down detection is enabled (H76 = 1). | Check the connection to the main power and check if the H76 data is set to "1" (factory default). → Correct the data of H76. |
| (4) Breaks in wiring to the main power input terminals. | Measure the input voltage. → Repair or replace the main circuit power input wires or input devices (MCCB, MC, etc.). |

13.5.2 Problems with inverter settings




[1] Nothing appears on the monitors.

| Possible Causes | What to Check and Suggested Measures |
|---|---|
| (1) No power (neither main power nor auxiliary control power) supplied to the inverter. | <p>Check the input voltage and interphase voltage unbalance.</p> <ul style="list-style-type: none"> ➔ Turn ON a molded case circuit breaker (MCCB), a residual-current-operated protective device (RCD)/earth leakage circuit breaker (ELCB) (with overcurrent protection) or a magnetic contactor (MC). ➔ Check for voltage drop, phase loss, poor connections, or poor contacts and fix them if necessary. |
| (2) The power for the control PCB did not reach a sufficiently high level. | <p>Check if the jumper bar has been removed from terminals P1 and P(+) or if there is a poor contact between the jumper bar and those terminals.</p> <ul style="list-style-type: none"> ➔ Mount a jumper bar or a DC reactor between terminals P1 and P(+). For poor contact, tighten up the screws. |
| (3) The keypad was not properly connected to the inverter. | <p>Check whether the keypad is properly connected to the inverter.</p> <ul style="list-style-type: none"> ➔ Remove the keypad, put it back, and see whether the problem recurs. ➔ Replace the keypad with another one and check whether the problem recurs. <hr/> <p>When running the inverter remotely, ensure that the extension cable is securely connected both to the keypad and to the inverter.</p> <ul style="list-style-type: none"> ➔ Disconnect the cable, reconnect it, and see whether the problem recurs. ➔ Replace the keypad with another one and check whether the problem recurs. |

[2] The desired function code does not appear.

| Possible Causes | Check and Measures |
|--|--|
| (1) The function code is not located in the current directory. | <p>Check whether the function code is located in a different directory.</p> <ul style="list-style-type: none"> ➔ Display the function codes in the directory, referring to Chapter 3, Section 3.4.4 "Programming Mode." <p>If no codes do not appear, check whether an option board is mounted.</p> <ul style="list-style-type: none"> ➔ Display the function codes in the directory, referring to Chapter 3, Section 3.4.4 "Programming Mode." <p>Note: No codes appear unless an option board is mounted.</p> |

[3] Data of function codes cannot be changed from the keypad.

| Possible Causes | What to Check and Suggested Measures |
|---|--|
| (1) An attempt was made to change function code data that cannot be changed when the inverter is running. | Check if the inverter is running with Menu #3 "OPR MNTR" using the keypad and then confirm whether the data of the function codes can be changed when the motor is running, referring to the function code tables. → Stop the motor and then change the data of the function codes. |
| (2) The data of the function codes is protected. | Check the data of function code F00 (Data Protection). → Change the data of F00 from "Enable data protection" (F00 = 1) to "Disable data protection" (F00 = 0). |
| (3) The WE-KP terminal command ("Enable data change with keypad") is not entered, though it has been assigned to a digital input terminal. | Check the data of function codes E01 through E09 and the input signal status with Menu #4 "I/O CHECK" using the keypad. → Input a WE-KP command through a digital input terminal. |
| (4) The  key was not pressed. | Check whether you have pressed the  key after changing the function code data. → Press the  key after changing the function code data. → Check that "STORING..." is displayed on the LCD monitor. |
| (5) The data of function code F02 cannot be changed. | Either one of the FWD and REV terminal commands is turned ON. → Turn OFF both FWD and REV . |

[4] Data of function codes cannot be changed via the communications link.

| Possible Causes | What to Check and Suggested Measures |
|---|--|
| (1) An attempt was made to change function code data that cannot be changed when the inverter is running. | Check if the inverter is running with Menu #3 "OPR MNTR" using the keypad and then confirm whether the data of the function codes can be changed when the motor is running, referring to the function code tables. → Stop the motor and then change the data of the function codes. |
| (2) The data of the function codes is protected. | Check the data of function code H29 (Data Protection). → Change the data of H29 from "1" (Enable data protection) to "0" (Disable data protection). |
| (3) The WE-LK terminal command ("Enable data change via communications link") is not entered, though it has been assigned to a digital input terminal. | Check the data of function codes E01 through E09 and the input signal status with Menu #4 "I/O CHECK" using the keypad. → Input a WE-LK command through a digital input terminal. |
| (4) The "Save all function" (H02) was not executed. | Check that the "Save all function" was executed (H02 = 1). → If data of function codes is changed via the communications link, execute the "Save all function"; otherwise, turning the power OFF loses the changed data. |
| (5) The data of function code F02 cannot be changed. | Either one of the FWD and REV terminal commands is turned ON. → Turn OFF both FWD and REV . |

Appendices

Contents

| | | |
|--------|---|------|
| App. A | Advantageous Use of Inverters (Notes on electrical noise) | A-1 |
| A.1 | Effect of inverters on other devices | A-1 |
| A.2 | Noise | A-2 |
| A.3 | Noise prevention | A-4 |
| App. B | Japanese Guideline for Suppressing Harmonics by Customers Receiving High Voltage or Special High Voltage | A-12 |
| B.1 | Application to general-purpose inverters | A-12 |
| B.2 | Compliance to the harmonic suppression for customers receiving high voltage or special high voltage | A-13 |
| App. C | Effect on Insulation of General-purpose Motors Driven with 400 V Class Inverters | A-18 |
| C.1 | Generating mechanism of surge voltages | A-18 |
| C.2 | Effect of surge voltages | A-19 |
| C.3 | Countermeasures against surge voltages | A-19 |
| C.4 | Regarding existing equipment | A-20 |
| App. D | Inverter Generating Loss | A-21 |
| App. E | Conversion from SI Units | A-23 |
| App. F | Allowable Current of Insulated Wires | A-25 |

App. A Advantageous Use of Inverters (Notes on electrical noise)

- *Disclaimer: This document provides you with a summary of the Technical Document of the Japan Electrical Manufacturers' Association (JEMA) (December 2008). It is intended to apply to the domestic market only. It is only for reference for the foreign market. -*

A.1 Effect of inverters on other devices

Inverters have been and are rapidly expanding its application fields. This paper describes the effect that inverters have on electronic devices already installed or on devices installed in the same system as inverters, as well as introducing noise prevention measures. (Refer to Section A.3 [3], "Noise prevention examples" for details.)

[1] Effect on AM radios

Phenomenon If an inverter operates, AM radios may pick up noise radiated from the inverter. (An inverter has almost no effect on FM radios or television sets.)

Probable cause Radios may receive noise radiated from the inverter.

Countermeasures Inserting a noise filter on the power supply side of the inverter is effective.

[2] Effect on telephones

Phenomenon If an inverter operates, nearby telephones may pick up noise radiated from the inverter in conversation so that it may be difficult to hear.

Probable cause A high-frequency leakage current radiated from the inverter and motors enters shielded telephone cables, causing noise.

Countermeasures It is effective to commonly connect the grounding terminals of the motors and return the common grounding line to the grounding terminal of the inverter.

[3] Effect on pressure sensors

Phenomenon If an inverter operates, pressure sensors may malfunction.

Probable cause Noise may penetrate through a grounding wire into the signal line.

Countermeasures It is effective to install a noise filter on the power supply side of the inverter or to separate the control circuit wirings from the I/O wires and grounding wires.

[4] Effect on position detectors (pulse generators, PGs)

Phenomenon If an inverter operates, pulse generators (PGs) may cause a malfunction that shifts the stop position of a machine.

Probable cause Erroneous pulses are liable to occur when the signal lines of the PG and power lines are bundled together.

Countermeasures The influence of induction noise and radiation noise can be reduced by separating the PG signal lines and power lines. Providing noise filters at the input and output terminals is also an effective measure.

[5] Effect on proximity switches

Phenomenon If an inverter operates, proximity switches (capacitance-type) may malfunction.

Probable cause The capacitance-type proximity switches may provide inferior noise immunity.

Countermeasures It is effective to connect a filter to the input terminals of the inverter or implement grounding wiring with a capacitor on the 0 V side of the proximity switches. The proximity switches can be replaced with superior noise immunity types such as magnetic types.

A.2 Noise

This section gives a summary of noises generated in inverters and their effects on devices subject to noise.

[1] Inverter noise

Figure A.1 shows an outline of the inverter configuration. The inverter converts AC to DC (rectification) in a converter unit, and converts DC to AC (inversion) with 3-phase variable voltage and variable frequency. The conversion (inversion) is performed by PWM implemented by switching six transistors (IGBT: Insulated Gate Bipolar Transistor, etc), and is used for variable speed motor control.

Switching noise is generated by high-speed on/off switching of the six transistors. At each high-speed on/off switching, noise current (i) flows to the ground through stray capacitance (C) of the inverter, I/O wire and motor. The amount of the noise current is expressed as follows:

$$i = C \cdot dv/dt$$

It is related to the stray capacitance (C) and dv/dt (switching speed of the transistors). Further, this noise current is related to the carrier frequency since the noise current flows each time the transistors are switched on or off.

In addition to the main circuit of the inverter, the DC-to-DC switching power regulator (DC/DC converter), which is the power source for the control circuit of the inverter, may be a noise source in the same principles as stated above.

The frequency band of this noise over the range of several tens of MHz may affect communications devices such as AM radios, plant radios, and telephones.




Figure A.1 Outline of Inverter Configuration

[2] Types of noise

Noise generated in an inverter is propagated through the main circuit wiring to the power supply and the motor so as to affect a wide range of applications from the power supply transformer to the motor. The various propagation routes are shown in Figure A.2. According to those routes, noises are roughly classified into three types--conduction noise, induction noise, and radiation noise.

Conduction noise propagates through routes 1) to 3), induction noise through route 4), and radiation noise through route 5). Details are described below.




Figure A.2 Noise Propagation Routes

(1) Conduction noise

Noise generated in an inverter may propagate through the conductor and power supply so as to affect peripheral devices of the inverter (Figure A.3). This noise is called "conduction noise." Some conduction noises will propagate through the main circuit ①. If the ground wires are connected to a common ground, conduction noise will propagate through route ②. As shown in route ③, some conduction noises will propagate through signal lines or shielded wires.




Figure A.3 Conduction Noise

(2) Induction noise

When wires or signal lines of peripheral devices are brought close to the wires on the input and output sides of the inverter through which noise current is flowing, noise will be induced into those wires and signal lines of the devices by electromagnetic induction (Figure A.4) or electrostatic induction (Figure A.5). This is called "induction noise" ④.




Figure A.4 Electromagnetic Induced Noise




Figure A.5 Electrostatic Induced Noise

(3) Radiation noise

Noise generated in an inverter may be radiated through the air from main circuit wires or grounding wires (that act as antennas) at the input and output sides of the inverter so as to affect peripheral devices or broadcasting and radio-communications. This noise is called "radiation noise" ⑤ as shown below. Not only wires but motor frames or control system panels containing inverters may also act as antennas.




Figure A.6 Radiation Noise

A.3 Noise prevention

The more noise prevention is strengthened, the more effective. However, with the use of appropriate measures, noise problems may be resolved easily. It is necessary to implement economical noise prevention according to the noise level and the equipment conditions.

[1] Noise prevention prior to installation

Before installing an inverter in your control panel or installing an inverter panel, you need to consider noise prevention. Once noise problems occur, it will cost additional materials and time for solving them.

Noise prevention prior to installation includes:

- 1) Separating the wiring of main circuits and control circuits
- 2) Putting main circuit wiring into a metal conduit pipe
- 3) Using shielded wires or twisted shielded wires for control circuits.
- 4) Implementing appropriate grounding work and grounding wiring.

These noise prevention measures can avoid most noise problems.

[2] Implementation of noise prevention measures

There are two types of noise prevention measures--one for noise propagation routes and the other for noise receiving sides.

The basic measures for lessening the effect of noise at the receiving side include:

- 1) Separating the main circuit wiring from the control circuit wiring, avoiding noise effect.

The basic measures for lessening the effect of noise at the generating side include:

- 2) Inserting a noise filter that reduces the noise level.
- 3) Applying a metal conduit pipe or metal control panel that will confine noise, and
- 4) Applying an insulated transformer for the power supply that cuts off the noise propagation route.

Table A.1 lists the noise prevention measures, their purposes, and targeted propagation routes.

Table A.1 Noise Prevention Measures

| Noise prevention method | | Goal of noise prevention measures | | | | Conduction route | | |
|-----------------------------------|---|---|-------------------------|---------------|--------------------|------------------|-----------------|-----------------|
| | | Make it more difficult to receive noise | Cutoff noise conduction | Confine noise | Reduce noise level | Conduction noise | Induction noise | Radiation noise |
| Wiring and installation | Separate main circuit from control circuit | Y | | | | | Y | |
| | Minimize wiring distance | Y | | | Y | | Y | Y |
| | Avoid parallel and bundled wiring | Y | | | | | Y | |
| | Use appropriate grounding | Y | | | Y | | Y | Y |
| | Use shielded wire and twisted shielded wire | Y | | | | | Y | Y |
| | Use shielded cable in main circuit | | | Y | | | | Y |
| | Use metal conduit pipe | | | Y | | | Y | Y |
| Control panel | Appropriate arrangement of devices in panel | Y | | | | | Y | Y |
| | Metal control panel | | | Y | | | Y | Y |
| Anti-noise device | Line filter | Y | | | Y | Y | | Y |
| | Insulation transformer | | Y | | | Y | | Y |
| Measures at noise receiving sides | Use a passive capacitor for control circuit | Y | | | | | Y | Y |
| | Use ferrite core for control circuit | Y | | | | | Y | Y |
| | Line filter | Y | | | | Y | | |
| Others | Separate power supply systems | Y | Y | | | Y | | |
| | Lower the carrier frequency | | | | Y | Y | Y | Y |

Y: Effective, Blank: Not effective

App.

What follows is noise prevention measures for the inverter drive configuration.

(1) Wiring and grounding

As shown in Figure A.7, separate the main circuit wiring from control circuit wiring as far as possible regardless of being located inside or outside the system control panel containing an inverter. Use shielded wires and twisted shielded wires that will block out extraneous noises, and minimize the wiring distance. Also avoid bundled wiring of the main circuit and control circuit or parallel wiring.




Figure A.7 Separate Wiring

For the main circuit wiring, use a metal conduit pipe and connect its wires to the ground to prevent noise propagation (refer to Figure A.8).

The shield (braided wire) of a shielded wire, in principle, should be connected to the base (common) side of the signal line at only one point to avoid the loop formation resulting from a multi-point connection (refer to Figure A.9).

The grounding is effective not only to reduce the risk of electrical shocks due to leakage current, but also to block noise penetration and radiation. Corresponding to the main circuit voltage, the grounding work should be Class C (300 to 600 VAC, grounding resistance: 10Ω or less) and Class D (300 VAC or less, grounding resistance: 100Ω or less). Each ground wire is to be provided with its own ground or separately wired to a grounding point.




Figure A.8 Grounding of Metal Conduit Pipe




Figure A.9 Treatment of Braided Wire of Shielded Wire

(2) Control panel

The system control panel containing an inverter is generally made of metal, which can shield noise radiated from the inverter itself.

When installing other electronic devices such as a programmable logic controller in the same control panel, be careful with the layout of each device. If necessary, arrange shield plates between the inverter and peripheral devices.

(3) Anti-noise devices

To reduce the noise propagated through the electrical circuits and the noise radiated from the main circuit wiring to the air, a line filter and insulation transformer should be used (refer to Figure A.10).

Line filters are available in these types--the simplified type such as a capacitive filter to be connected in parallel to the power supply line and an inductive filter to be connected in series to the power supply line and the orthodox type such as an LC filter to meet noise regulations. Use them according to the targeted effect for reducing noise.

Insulation transformers include common insulated transformers, and shielded transformers. These transformers have different effectiveness in blocking noise propagation.




Figure A.10 Various Filters and their Connection

(4) Noise prevention measures at the receiving side

It is important to strengthen the noise immunity of those electronic devices installed in the same control panel as the inverter or located near an inverter. Line filters, shielded or twisted shielded wires are used to block the penetration of noise in the control circuit wirings of these devices. The following treatments are also implemented.

- 1) Lower the circuit impedance by connecting capacitors or resistors to the input and output terminals of the signal circuit in parallel.
- 2) Increase the circuit impedance for noise by inserting choke coils in series in the signal circuit or passing signal lines through ferrite core beads. It is also effective to widen the signal base lines (0 V line) or grounding lines.

(5) Other

The level of generating/propagating noise will change with the carrier frequency of the inverter. The higher the carrier frequency, the higher the noise level.

In an inverter whose carrier frequency can be changed, lowering the carrier frequency can reduce the generation of electrical noise and result in a good balance with the audible noise of the motor under driving conditions.

[3] Noise prevention examples

Table A.2 lists examples of the measures to prevent noise generated by a running inverter.

Table A.2 Examples of Noise Prevention Measures











| No. | Target device | Phenomena | Noise prevention measures | |
|-----|---------------|--|---|--|
| | | | | Notes |
| 1 | AM radio | <p>When operating an inverter, noise enters into an AM radio broadcast (500 to 1500 kHz).</p>  <p><Possible cause> The AM radio may receive noise radiated from wires at the power supply and output sides of the inverter.</p> | <p>1) Install an LC filter at the power supply side of the inverter. (In some cases, a capacitive filter may be used as a simple method.)</p> <p>2) Install a metal conduit wiring between the motor and inverter.</p>  <p>Note: Minimize the distance between the input LC filter and inverter as short as possible (within 1 m).</p> | <p>1) The radiation noise of the wiring can be reduced.</p> <p>2) The conduction noise to the power supply side can be reduced.</p> <p>Note: Sufficient improvement may not be expected in narrow regions such as between mountains.</p> |
| 2 | AM radio | <p>When operating an inverter, noise enters into an AM radio broadcast (500 to 1500 kHz).</p>  <p><Possible cause> The AM radio may receive noise radiated from the power line at the power supply side of the inverter.</p> | <p>1) Install inductive filters at the input and output sides of the inverter.</p>  <p>The number of turns of the zero-phase reactor (or ferrite ring) should be as large as possible. In addition, wiring between the inverter and the zero-phase reactor (or ferrite ring) should be as short as possible. (within 1 m)</p> <p>2) When further improvement is necessary, install LC filters.</p>  | <p>1) The radiation noise of the wiring can be reduced.</p> |

Table A.2 Continued

| No. | Target device | Phenomena | Noise prevention measures | Notes |
|-----|---|---|--|--|
| 3 | Telephone (in a common private residence at a distance of 40 m) | <p>When driving a ventilation fan with an inverter, noise enters a telephone in a private residence at a distance of 40m.</p>  <p><Possible cause> A high-frequency leakage current from the inverter and motor flowed to grounded part of the telephone cable shield. During the current's return trip, it flowed through a grounded pole transformer, and noise entered the telephone by electrostatic induction.</p> | <p>1) Connect the ground terminals of the motors in a common connection. Return to the inverter panel, and insert a 1 μF capacitor between the input terminal of the inverter and ground.</p>   | <p>1) The effect of the inductive filter and LC filter may not be expected because of sound frequency component.</p> <p>2) In the case of a V-connection power supply transformer in a 200V system, it is necessary to connect capacitors as shown in the following figure, because of different potentials to ground.</p> |
| 4 | Photoelectric relay | <p>A photoelectric relay malfunctioned when the inverter runs the motor.</p> <p>[The inverter and motor are installed in the same place (for overhead traveling)]</p>  <p><Possible cause> It is considered that induction noise entered the photoelectric relay since the inverter's input power supply line and the photoelectric relay's wiring are in parallel separated by approximately 25 mm over a distance of 30 to 40 m. Due to conditions of the installation, these lines cannot be separated.</p> | <p>1) As a temporary measure, Insert a 0.1 μF capacitor between the 0 V terminal of the power supply circuit in the detection unit of the overhead photoelectric relay and the overhead frame.</p>  <p>2) As a permanent measure, move the 24 V power supply from the ground to the overhead unit so that signals are sent to the ground side with relay contacts in the ceiling part.</p> | <p>1) The wiring is separated by more than 30 cm.</p> <p>2) When separation is impossible, signals can be received and sent with dry contacts etc.</p> <p>3) Do not wire low-current signal lines and power lines in parallel.</p> |

App.

Table A.2 Continued











| No. | Target device | Phenomena | Noise prevention measures | Notes |
|-----|-------------------------------------|--|---|---|
| 5 | Photoelectric relay | <p>A photoelectric relay malfunctioned when the inverter was operated.</p>  <p><Possible cause> Although the inverter and photoelectric relay are separated by a sufficient distance but the power supplies share a common connection, it is considered that conduction noise entered through the power supply line into the photoelectric relay.</p> | <p>1) Insert a 0.1 μF capacitor between the output common terminal of the amplifier of the photoelectric relay and the frame.</p>  | <p>1) If a low-current circuit at the malfunctioning side is observed, the measures may be simple and economical.</p> |
| 6 | Proximity switch (capacitance type) | <p>A proximity switch malfunctioned.</p>  <p><Possible cause> It is considered that the capacitance type proximity switch is susceptible to conduction and radiation noise because of its low noise immunity.</p> | <p>1) Install an LC filter at the output side of the inverter. 2) Install a capacitive filter at the input side of the inverter. 3) Ground the 0 V (common mode) line of the DC power supply of the proximity switch through a capacitor to the box body of the machine.</p>  | <p>1) Noise generated in the inverter can be reduced. 2) The switch is superseded by a proximity switch of superior noise immunity (such as a magnetic type).</p> |

Table A.2 Continued

| No. | Target device | Phenomena | Noise prevention measures | Notes |
|-----|--------------------------------------|--|--|---|
| 7 | Pressure sensor | <p>A pressure sensor malfunctioned.</p>  <p><Possible cause> The pressure sensor may malfunction due to noise that came from the box body through the shielded wire.</p> | <ol style="list-style-type: none"> 1) Install an LC filter on the input side of the inverter. 2) Connect the shield of the shielded wire of the pressure sensor to the 0 V line (common mode) of the pressure sensor, changing the original connection.  | <ol style="list-style-type: none"> 1) The shielded parts of shield wires for sensor signals are connected to a common point in the system. 2) Conduction noise from the inverter can be reduced. |
| 8 | Position detector (pulse generator) | <p>Erroneous-pulse outputs from a pulse converter caused a shift in the stop position of a crane.</p>  <p><Possible cause> Erroneous pulses may be outputted by induction noise since the power line of the motor and the signal line of the PG are bundled together.</p> | <ol style="list-style-type: none"> 1) Install an LC filter and a capacitive filter at the input side of the inverter. 2) Install an LC filter at the output side of the inverter.  | <ol style="list-style-type: none"> 1) This is an example of a measure where the power line and signal line cannot be separated. 2) Induction noise and radiation noise at the output side of the inverter can be reduced. |
| 9 | Program mable logic controller (PLC) | <p>The PLC program malfunctions.</p>  <p><Possible cause> Since the power supply system is the same for the PLC (programmable logic controller) and inverter, it is considered that noise enters the PLC through the power supply.</p> | <ol style="list-style-type: none"> 1) Install a capacitive filter and an LC filter on the input side of the inverter. 2) Install an LC filter on the output side of the inverter. 3) Lower the carrier frequency of the inverter.  | <ol style="list-style-type: none"> 1) Total conduction noise and induction noise in the electric line can be reduced. |

App.

App. B Japanese Guideline for Suppressing Harmonics by Customers Receiving High Voltage or Special High Voltage

- Disclaimer: This document provides you with a translated summary of the Guideline of the Ministry of Economy, Trade and Industry. It is intended to apply to the domestic market only. It is only for reference for the foreign market. -

Agency of Natural Resource and Energy of Japan published the following two guidelines for suppressing harmonic noise in September 1994.

- (1) Guideline for suppressing harmonics in home electric and general-purpose appliances
- (2) Guideline for suppressing harmonics by customers receiving high voltage or special high voltage

Assuming that electronic devices generating high harmonics will be increasing, these guidelines are to establish regulations for preventing high frequency noise interference on devices sharing the power source. These guidelines should be applied to all devices that are used on the commercial power lines and generate harmonic current. This section gives a description limited to general-purpose inverters.

B.1 Application to general-purpose inverters

- [1] Guideline for suppressing harmonics in home electric and general-purpose appliances

Our three-phase, 200 V class series inverters of 3.7 kW or less (FRENIC-MEGA series) were the products of which were restricted by the "Guideline for Suppressing Harmonics in Home Electric and General-purpose Appliances" (established in September 1994 and revised in October 1999) issued by the Ministry of Economy, Trade and Industry.

The above restriction, however, was lifted when the Guideline was revised in January 2004. Since then, the inverter makers have individually imposed voluntary restrictions on the harmonics of their products.

We, as before, recommend that you connect a reactor (for suppressing harmonics) to your inverter.

- [2] Guideline for suppressing harmonics by customers receiving high voltage or special high voltage

Unlike other guidelines, this guideline is not applied to the equipment itself such as a general-purpose inverter, but is applied to each large-scale electric power consumer for total amount of harmonics. The consumer should calculate the harmonics generated from each piece of equipment currently used on the power source transformed and fed from the high or special high voltage source.

(1) Scope of regulation

In principle, the guideline applies to the customers that meet the following two conditions:

- The customer receives high voltage or special high voltage.
- The "equivalent capacity" of the converter load exceeds the standard value for the receiving voltage (50 kVA at a receiving voltage of 6.6 kV).

Appendix B.2 [1] "Calculation of equivalent capacity (Pi)" gives you some supplemental information with regard to estimation for the equivalent capacity of an inverter according to the guideline.

(2) Regulation

The level (calculated value) of the harmonic current that flows from the customer's receiving point out to the system is subjected to the regulation. The regulation value is proportional to the contract demand. The regulation values specified in the guideline are shown in Table B.1.

Appendix B.2 gives you some supplemental information with regard to estimation for the equivalent capacity of the inverter for compliance to "Japanese guideline for suppressing harmonics by customers receiving high voltage or special high voltage."

Table B.1 Upper Limits of Harmonic Outflow Current per kW of Contract Demand (mA/kW)

| Receiving voltage | 5th | 7th | 11th | 13th | 17th | 19th | 23rd | Over 25th |
|-------------------|-----|-----|------|------|------|------|------|-----------|
| 6.6 kV | 3.5 | 2.5 | 1.6 | 1.3 | 1.0 | 0.90 | 0.76 | 0.70 |
| 22 kV | 1.8 | 1.3 | 0.82 | 0.69 | 0.53 | 0.47 | 0.39 | 0.36 |

(3) When the regulation applied

The guideline has been applied. As the application, the estimation for "Voltage distortion factor" required as the indispensable conditions when entering into the consumer's contract of electric power is already expired.

B.2 Compliance to the harmonic suppression for customers receiving high voltage or special high voltage

When calculating the required matters related to inverters according to the guideline, follow the terms listed below. The following descriptions are based on "Technical document for suppressing harmonics" (JEAG 9702-1995) published by the Japan Electrical Manufacturer's Association (JEMA).

[1] Calculation of equivalent capacity (Pi)

The equivalent capacity (Pi) may be calculated using the equation of (input rated capacity) x (conversion factor). However, catalogs of conventional inverters do not contain input rated capacities, so a description of the input rated capacity is shown below:

(1) "Inverter rated capacity" corresponding to "Pi"

- In the guideline, the conversion factor of a 6-pulse converter is used as reference conversion factor 1. It is, therefore, necessary to express the rated input capacity of inverters in a value including harmonic component current equivalent to conversion factor 1.
- Calculate the input fundamental current I_1 from the kW rating and efficiency of the load motor, as well as the efficiency of the inverter. Then, calculate the input rated capacity as shown below:

$$\text{Inputratedcapacity} = \sqrt{3} \times (\text{powersupply voltage}) \times I_1 \times 1.0228/1000 \text{ (kVA)}$$

where 1.0228 is the 6-pulse converter's value of (effective current)/(fundamental current).

- When a general-purpose motor or inverter motor is used, the appropriate value shown in Table B.2 can be used. Select a value based on the kW rating of the motor used, irrespective of the inverter type.



The input rated capacity shown above is for the dedicated use in the equation to calculate capacity of the inverters, following the guideline. Note that the capacity cannot be applied to the reference for selection of the equipment or wires to be used in the inverter input circuits.



For selection of capacity for the peripheral equipment, refer to the catalogs or technical documents issued from their manufacturers.

Table B.2 "Input Rated Capacities" of General-purpose Inverters Determined by the Applicable Motor Ratings

| | | | | | | | | | | | |
|------------------------------|-------|------|------|------|------|------|------|------|------|------|------|
| Applicable motor rating (kW) | | 0.4 | 0.75 | 1.5 | 2.2 | 3.7 | 5.5 | 7.5 | 11 | 15 | 18.5 |
| Pi (kVA) | 200 V | 0.57 | 0.97 | 1.95 | 2.81 | 4.61 | 6.77 | 9.07 | 13.1 | 17.6 | 21.8 |
| | 400 V | 0.57 | 0.97 | 1.95 | 2.81 | 4.61 | 6.77 | 9.07 | 13.1 | 17.6 | 21.8 |
| Applicable motor rating (kW) | | 22 | 30 | 37 | 45 | 55 | 75 | 90 | 110 | 132 | 160 |
| Pi (kVA) | 200 V | 25.9 | 34.7 | 42.8 | 52.1 | 63.7 | 87.2 | 104 | 127 | | |
| | 400 V | 25.9 | 34.7 | 42.8 | 52.1 | 63.7 | 87.2 | 104 | 127 | 153 | 183 |
| Applicable motor rating (kW) | | 200 | 220 | 250 | 280 | 315 | 355 | 400 | 450 | 500 | 630 |
| Pi (kVA) | 200 V | | | | | | | | | | |
| | 400 V | 229 | 252 | 286 | 319 | 359 | 405 | 456 | 512 | 570 | 718 |

(2) Values of "Ki (conversion factor)"

Depending on whether an optional ACR (AC reactor) or DCR (DC reactor) is used, apply the appropriate conversion factor specified in the appendix to the guideline. The values of the conversion factor are listed in Table B.3.

Table B.3 "Conversion Factors Ki" for General-purpose Inverters Determined by Reactors

| Circuit category | Circuit type | | Conversion factor Ki | Main applications |
|------------------|--------------------------------------|----------------------------|----------------------|---|
| 3 | 3-phase bridge (capacitor smoothing) | w/o reactor | K31=3.4 | <ul style="list-style-type: none"> • General-purpose inverters • Elevators • Refrigerators, air conditioning systems • Other general appliances |
| | | w/- reactor (ACR) | K32=1.8 | |
| | | w/- reactor (DCR) | K33=1.8 | |
| | | w/- reactors (ACR and DCR) | K34=1.4 | |

Note Some models are equipped with a reactor as a standard accessory.

[2] Calculation of Harmonic Current

(1) Value of "input fundamental current"

- When you calculate the amount of harmonics according to Table 2 in Appendix of the Guideline, you have to previously know the input fundamental current.
- Apply the appropriate value shown in Table B.4 based on the kW rating of the motor, irrespective of the inverter type or whether a reactor is used.

Note If the input voltage is different, calculate the input fundamental current in inverse proportion to the voltage.

Table B.4 "Input Fundamental Currents" of General-purpose Inverters Determined by the Applicable Motor Ratings

| | | | | | | | | | | | |
|-------------------------------|-------|------|------|------|------|------|------|------|------|------|------|
| Applicable motor rating (kW) | | 0.4 | 0.75 | 1.5 | 2.2 | 3.7 | 5.5 | 7.5 | 11 | 15 | 18.5 |
| Input fundamental current (A) | 200 V | 1.62 | 2.74 | 5.50 | 7.92 | 13.0 | 19.1 | 25.6 | 36.9 | 49.8 | 61.4 |
| | 400 V | 0.81 | 1.37 | 2.75 | 3.96 | 6.50 | 9.55 | 12.8 | 18.5 | 24.9 | 30.7 |
| 6.6 kV converted value (mA) | | 49 | 83 | 167 | 240 | 394 | 579 | 776 | 1121 | 1509 | 1860 |

| | | | | | | | | | | | |
|-------------------------------|-------|------|------|------|------|------|------|------|-------|-------|-------|
| Applicable motor rating (kW) | | 22 | 30 | 37 | 45 | 55 | 75 | 90 | 110 | 132 | 160 |
| Input fundamental current (A) | 200 V | 73.1 | 98.0 | 121 | 147 | 180 | 245 | 293 | 357 | | |
| | 400 V | 36.6 | 49.0 | 60.4 | 73.5 | 89.9 | 123 | 147 | 179 | 216 | 258 |
| 6.6 kV converted value (mA) | | 2220 | 2970 | 73.5 | 4450 | 5450 | 7450 | 8910 | 10850 | 13090 | 15640 |

| | | | | | | | | | | | |
|-------------------------------|-------|-------|-------|-------|-------|-------|-------|-------|-------|-------|-------|
| Applicable motor rating (kW) | | 200 | 220 | 250 | 280 | 315 | 355 | 400 | 450 | 500 | 630 |
| Input fundamental current (A) | 200 V | | | | | | | | | | |
| | 400 V | 323 | 355 | 403 | 450 | 506 | 571 | 643 | 723 | 804 | 1013 |
| 6.6 kV converted value (mA) | | 19580 | 21500 | 24400 | 27300 | 30700 | 34600 | 39000 | 43800 | 48700 | 61400 |

(2) Calculation of harmonic current

Usually, calculate the harmonic current according to the Sub-table 3 "Three-phase bridge rectifier with the smoothing capacitor" in Table 2 of the Guideline's Appendix. Table B.5 lists the contents of the Sub-table 3.

Table B.5 Generated Harmonic Current (%), 3-phase Bridge Rectifier (Capacitor Smoothing)

| Degree | 5th | 7th | 11th | 13th | 17th | 19th | 23rd | 25th |
|----------------------------|-----|------|------|------|------|------|------|------|
| w/o a reactor | 65 | 41 | 8.5 | 7.7 | 4.3 | 3.1 | 2.6 | 1.8 |
| w/- a reactor (ACR) | 38 | 14.5 | 7.4 | 3.4 | 3.2 | 1.9 | 1.7 | 1.3 |
| w/- a reactor (DCR) | 30 | 13 | 8.4 | 5.0 | 4.7 | 3.2 | 3.0 | 2.2 |
| w/- reactors (ACR and DCR) | 28 | 9.1 | 7.2 | 4.1 | 3.2 | 2.4 | 1.6 | 1.4 |

- ACR: 3%
- DCR: Accumulated energy equal to 0.08 to 0.15 ms (100% load conversion)
- Smoothing capacitor: Accumulated energy equal to 15 to 30 ms (100% load conversion)
- Load: 100%

Calculate the harmonic current of each degree using the following equation:

$$\text{nth harmonic current (A)} = \text{Fundamental current (A)} \times \frac{\text{Generated nth harmonic current (\%)}}{100}$$

(3) Maximum availability factor

- For a load for elevators, which provides intermittent operation, or a load with a sufficient designed motor rating, reduce the current by multiplying the equation by the "maximum availability factor" of the load.
- The "maximum availability factor of an appliance" means the ratio of the capacity of the harmonic generator in operation at which the availability reaches the maximum, to its total capacity, and the capacity of the generator in operation is an average for 30 minutes.
- In general, the maximum availability factor is calculated according to this definition, but the standard values shown in Table B.6 are recommended for inverters for building equipment.

Table B.6 Availability Factors of Inverters, etc. for Building Equipment (Standard Values)

| Equipment type | Inverter capacity category | Single inverter availability |
|-------------------------|----------------------------|------------------------------|
| Air conditioning system | 200 kW or less | 0.55 |
| | Over 200 kW | 0.60 |
| Sanitary pump | ———— | 0.30 |
| Elevator | ———— | 0.25 |
| Refrigerator, freezer | 50 kW or less | 0.60 |
| UPS (6-pulse) | 200 kVA | 0.60 |

Correction coefficient according to contract demand level

Since the total availability factor decreases if the scale of a building increases, calculating reduced harmonics with the correction coefficient β defined in Table B.7 is permitted.

Table B.7 Correction Coefficient according to the Building Scale

| Contract demand (kW) | Correction coefficient β |
|----------------------|--------------------------------|
| 300 | 1.00 |
| 500 | 0.90 |
| 1000 | 0.85 |
| 2000 | 0.80 |

Note: If the contract demand is between two specified values listed in Table B.7, calculate the value by interpolation.

Note: The correction coefficient β is to be determined as a matter of consultation between the customer and electric power company for the customers receiving the electric power over 2000 kW or from the special high voltage lines.

(4) Degree of harmonics to be calculated

The higher the degree of harmonics, the lower the current flows. This is the property of harmonics generated by inverters so that the inverters are covered by "The case not causing a special hazard" of the term (3) in the above Appendix for the 9th or higher degrees of the harmonics.

Therefore, "It is sufficient that the 5th and 7th harmonic currents should be calculated."

[3] Examples of calculation

(1) Equivalent capacity

| Example of loads | Input capacity and No. of inverters | Conversion factor | Equivalent capacity |
|---|-------------------------------------|---------------------|-----------------------------|
| [Example 1] 400 V, 3.7 kW, 10 units w/- AC reactor and DC reactor | 4.61 kVA × 10 units | K32 = 1.4 | 4.61 × 10 × 1.4 = 64.54 kVA |
| [Example 2] 400 V, 1.5 kW, 15 units w/- AC reactor | 2.93 kVA × 15 units | K34 = 1.8 | 2.93 × 15 × 1.8 = 79.11 kVA |
| | Refer to Table B.2. | Refer to Table B.3. | |

(2) Harmonic current every degrees

[Example 1] 400 V, 3.7 kW 10 units, w/- AC reactor, and maximum availability: 0.55

| Fundamental current onto 6.6 kV lines (mA) | Harmonic current onto 6.6 kV lines (mA) | | | | | | | |
|--|---|-------------|-------------|-------------|-------------|-------------|-------------|-------------|
| | 5th (38%) | 7th (14.5%) | 11th (7.4%) | 13th (3.4%) | 17th (3.2%) | 19th (1.9%) | 23rd (1.7%) | 25th (1.3%) |
| 394 × 10 = 3940 3940 × 0.55 = 2167 | 823.5 | 314.2 | | | | | | |
| Refer to Tables B.4 and B.6. | Refer to Table B.5. | | | | | | | |

[Example 2] 400 V, 3.7 kW, 15 units, w/- AC reactor and DC reactor, and maximum availability: 0.55

| Fundamental current onto 6.6 kV lines (mA) | Harmonic current onto 6.6 kV lines (mA) | | | | | | | |
|--|---|------------|-------------|-------------|-------------|-------------|-------------|-------------|
| | 5th (28%) | 7th (9.1%) | 11th (7.2%) | 13th (4.1%) | 17th (3.2%) | 19th (2.4%) | 23rd (1.6%) | 25th (1.4%) |
| 394 × 15 = 5910 5910 × 0.55 = 3250.5 | 910.1 | 295.8 | | | | | | |
| Refer to Tables B.4 and B.6. | Refer to Table B.5. | | | | | | | |

App.


App. C Effect on Insulation of General-purpose Motors Driven with 400 V Class Inverters

- Disclaimer: This document provides you with a summary of the Technical Document of the Japan Electrical Manufacturers' Association (JEMA) (March, 1995). It is intended to apply to the domestic market only. It is only for reference for the foreign market. -

Preface

When an inverter drives a motor, surge voltages generated by switching the inverter elements are superimposed on the inverter output voltage and applied to the motor terminals. If the surge voltages are too high they may have an effect on the motor insulation and some cases have resulted in damage.

For preventing such cases this document describes the generating mechanism of the surge voltages and countermeasures against them.

 Refer to A.2 [1] "Inverter noise" for details of the principle of inverter operation.

C.1 Generating mechanism of surge voltages

As the inverter rectifies a commercial power source voltage and smoothes into a DC voltage, the magnitude E of the DC voltage becomes about $\sqrt{2}$ times that of the source voltage (about 620 V in case of an input voltage of 440 VAC). The peak value of the output voltage is usually close to this DC voltage value.

But, as there exists inductance (L) and stray capacitance (C) in wiring between the inverter and the motor, the voltage variation due to switching the inverter elements causes a surge voltage originating in LC resonance and results in the addition of high voltage to the motor terminals. (Refer to Figure C.1)

This voltage sometimes reaches up to about twice that of the inverter DC voltage ($620 \text{ V} \times 2 =$ approximately 1,200 V) depending on a switching speed of the inverter elements and wiring conditions.





Figure C.1 Voltage Waveform of Individual Portions

A measured example in Figure C.2 illustrates the relation of a peak value of the motor terminal voltage with a wiring length between the inverter and the motor.

From this it can be confirmed that the peak value of the motor terminal voltage ascends as the wiring length increases and becomes saturated at about twice the inverter DC voltage.

The shorter a pulse rise time becomes, the higher the motor terminal voltage rises even in the case of a short wiring length.



Excerpt from [J. IEE Japan, Vol. 107, No. 7, 1987]

Figure C.2 Measured Example of Wiring Length and Peak Value of Motor Terminal Voltage

C.2 Effect of surge voltages

The surge voltages originating in LC resonance of wiring may be applied to the motor terminals and depending on their magnitude sometimes cause damage to the motor insulation.

When the motor is driven with a 200 V class inverter, the dielectric strength of the insulation is no problem since the peak value at the motor terminal voltage increases twice due to the surge voltages (the DC voltage is only about 300 V).

But in case of a 400 V class inverter, the DC voltage is approximately 600 V and depending on the wiring length, the surge voltages may greatly increase and sometimes result in damage to the insulation.

C.3 Countermeasures against surge voltages

When driving a motor with a 400 V class inverter, the following are countermeasures against damage to the motor insulation by the surge voltages.

[1] Using a surge suppressor unit, SSU

The surge suppressor unit (SSU) is a newly structured unit using circuits based on the impedance-matching theory of a transmission line. Just connecting the SSU to the surge suppressor cable of the existing equipment can greatly reduce the surge voltage that results in a motor dielectric breakdown.



For 50 m of wiring length: SSU 50TA-NS



For 100 m of wiring length: SSU 100TA-NS

[2] Suppressing surge voltages

There are two ways for suppressing the surge voltages, one is to reduce the voltage rise time and another is to reduce the voltage peak value.

(1) Output reactor

If wiring length is relatively short, the surge voltages can be suppressed by reducing the voltage rise time (dv/dt) with the installation of an AC reactor on the output side of the inverter. (Refer to Figure C.3 (1).)

However, if the wiring length becomes long, suppressing the peak voltage due to surge voltage may be difficult.

(2) Output filter

Installing a filter on the output side of the inverter allows a peak value of the motor terminal voltage to be reduced. (Refer to Figure C.3 (2).)




Figure C.3 Method to Suppress Surge Voltage



If the wiring length between the inverter and the motor is comparatively long, the crest value of the surge voltage can be suppressed by connecting a surge suppressor unit (SSU) to the motor terminal. For details, refer to Chapter 8, Section 8.5.1.4 "Surge suppression unit (SSU)."

[3] Using motors with enhanced insulation

Enhanced insulation of a motor winding allows its surge withstanding to be improved.

C.4 Regarding existing equipment

[1] In case of a motor being driven with 400 V class inverter

A survey over the last five years on motor insulation damage due to the surge voltages originating from switching of inverter elements shows that the damage incidence is 0.013% under the surge voltage condition of over 1,100 V and most of the damage occurs several months after commissioning the inverter. Therefore there seems to be little probability of occurrence of motor insulation damage after a lapse of several months of commissioning.

[2] In case of an existing motor driven using a newly installed 400 V class inverter

We recommend suppressing the surge voltages with the ways shown in Section C.3.

App. D Inverter Generating Loss

The table below lists the inverter generating loss.

●HD specification generating loss

| Power supply voltage | Standard applicable motor capacity [kW] | Inverter type | Low carrier | | Medium carrier (At time of F26 factory default setting) | High carrier | |
|----------------------|---|----------------|-------------|---------------------|--|------------------|---------------------|
| | | | F26 [kHz] | Generating loss [W] | Generating loss [W] | F26 [kHz] | Generating loss [W] |
| Three-phase 200 V | 0.75 | FRN0.75VG1S-2J | 2 | 70 | 95 | 15 | 100 |
| | 1.5 | FRN1.5VG1S-2J | 2 | 100 | 125 | 15 | 130 |
| | 2.2 | FRN2.2VG1S-2J | 2 | 130 | 165 | 15 | 170 |
| | 3.7 | FRN3.7VG1S-2J | 2 | 190 | 245 | 15 | 260 |
| | 5.5 | FRN5.5VG1S-2J | 2 | 240 | 295 | 15 | 310 |
| | 7.5 | FRN7.5VG1S-2J | 2 | 300 | 390 | 15 | 415 |
| | 11 | FRN11VG1S-2J | 2 | 450 | 580 | 15 | 620 |
| | 15 | FRN15VG1S-2J | 2 | 540 | 670 | 15 | 700 |
| | 18.5 | FRN18.5VG1S-2J | 2 | 660 | 825 | 15 | 860 |
| | 22 | FRN22VG1S-2J | 2 | 790 | 995 | 15 | 1040 |
| | 30 | FRN30VG1S-2J | 2 | 1300 | 1400 | 15 | 1450 |
| | 37 | FRN37VG1S-2J | 2 | 1300 | 1500 | 15 | 1550 |
| | 45 | FRN45VG1S-2J | 2 | 1450 | 1600 | 15 | 1600 |
| | 55 | FRN55VG1S-2J | 2 | 1750 | 1900 | 15 | 1900 |
| 75 | FRN75VG1S-2J | 2 | 2300 | 2450 | 10 | 2550 | |
| 90 | FRN90VG1S-2J | 2 | 2750 | 2900 | 10 | 3050 | |
| Three-phase 400 V | 3.7 | FRN3.7VG1S-4J | 2 | 150 | 215 | 15 | 230 |
| | 5.5 | FRN5.5VG1S-4J | 2 | 170 | 280 | 15 | 300 |
| | 7.5 | FRN7.5VG1S-4J | 2 | 230 | 375 | 15 | 400 |
| | 11 | FRN11VG1S-4J | 2 | 300 | 480 | 15 | 520 |
| | 15 | FRN15VG1S-4J | 2 | 360 | 560 | 15 | 610 |
| | 18.5 | FRN18.5VG1S-4J | 2 | 440 | 715 | 15 | 770 |
| | 22 | FRN22VG1S-4J | 2 | 510 | 835 | 15 | 900 |
| | 30 | FRN30VG1S-4J | 2 | 850 | 1100 | 15 | 1150 |
| | 37 | FRN37VG1S-4J | 2 | 1050 | 1400 | 15 | 1450 |
| | 45 | FRN45VG1S-4J | 2 | 1150 | 1500 | 15 | 1600 |
| | 55 | FRN55VG1S-4J | 2 | 1400 | 1850 | 15 | 1950 |
| | 75 | FRN75VG1S-4J | 2 | 1750 | 1950 | 10 ^{*1} | 2150 |
| | 90 | FRN90VG1S-4J | 2 | 2000 | 2350 | 10 ^{*1} | 2600 |
| | 110 | FRN110VG1S-4J | 2 | 2400 | 2750 | 10 ^{*1} | 3050 |
| | 132 | FRN132VG1S-4J | 2 | 2650 | 3000 | 10 ^{*1} | 3300 |
| | 160 | FRN160VG1S-4J | 2 | 3200 | 3650 | 10 ^{*1} | 4000 |
| | 200 | FRN200VG1S-4J | 2 | 4000 | 4550 | 10 ^{*1} | 5000 |
| | 220 | FRN220VG1S-4J | 2 | 4500 | 5100 | 10 ^{*1} | 5600 |
| 280 | FRN280VG1S-4J | 2 | 5500 | 6300 | 10 ^{*1} | 6900 | |
| 315 | FRN315VG1S-4J | 2 | 6250 | 7100 | 10 ^{*1} | 7800 | |
| 355 | FRN355VG1S-4J | 2 | 6750 | 7650 | 10 ^{*1} | 8450 | |
| 400 | FRN400VG1S-4J | 2 | 7650 | 8750 | 10 ^{*1} | 9650 | |
| 500 | FRN500VG1S-4J | 2 | 9950 | 10700 | 5 ^{*1} | 10700 | |
| 630 | FRN630VG1S-4J | 2 | 12350 | 13300 | 5 ^{*1} | 13300 | |

(*1) If the generating loss set in F26 exceeds the value specified in this table, it is set to the same generating loss as that applied with the high carrier set regardless of the value in F26.

●LD specification generating loss

| Power supply voltage | Standard applicable motor capacity [kW] | Inverter type | Low carrier | | Medium carrier (At time of F26 factory default setting) | High carrier | |
|----------------------|---|---------------|-------------|---------------------|--|------------------|---------------------|
| | | | F26 [kHz] | Generating loss [W] | Generating loss [W] | F26 [kHz] | Generating loss [W] |
| Three-phase 200 V | 37 | FRN30VG1S-2J | 2 | 1650 | 1650 | 10 ^{*1} | 1750 |
| | 45 | FRN37VG1S-2J | 2 | 1650 | 1650 | 10 ^{*1} | 1850 |
| | 55 | FRN45VG1S-2J | 2 | 1850 | 1850 | 10 ^{*1} | 1950 |
| | 75 | FRN55VG1S-2J | 2 | 2250 | 2300 | 10 ^{*1} | 2400 |
| | 90 | FRN75VG1S-2J | 2 | 2700 | 2800 | 5 ^{*1} | 2800 |
| | 110 | FRN90VG1S-2J | 2 | 3250 | 3350 | 5 ^{*1} | 3350 |
| Three-phase 400 V | 37 | FRN30VG1S-4J | 2 | 1050 | 1050 | 10 ^{*1} | 1250 |
| | 45 | FRN37VG1S-4J | 2 | 1300 | 1300 | 10 ^{*1} | 1550 |
| | 55 | FRN45VG1S-4J | 2 | 1400 | 1400 | 10 ^{*1} | 1700 |
| | 75 | FRN55VG1S-4J | 2 | 2000 | 2400 | 5 ^{*1} | 2400 |
| | 90 | FRN75VG1S-4J | 2 | 2100 | 2250 | 5 ^{*1} | 2250 |
| | 110 | FRN90VG1S-4J | 2 | 2350 | 2250 | 5 ^{*1} | 2250 |
| | 132 | FRN110VG1S-4J | 2 | 2850 | 3050 | 5 ^{*1} | 3050 |
| | 160 | FRN132VG1S-4J | 2 | 3150 | 3400 | 5 ^{*1} | 3400 |
| | 200 | FRN160VG1S-4J | 2 | 4050 | 4350 | 5 ^{*1} | 4350 |
| | 220 | FRN200VG1S-4J | 2 | 4400 | 4750 | 5 ^{*1} | 4750 |
| | 280 | FRN220VG1S-4J | 2 | 5850 | 6200 | 5 ^{*1} | 6200 |
| | 355 | FRN280VG1S-4J | 2 | 6750 | 7300 | 5 ^{*1} | 7300 |
| | 400 | FRN315VG1S-4J | 2 | 7800 | 8350 | 5 ^{*1} | 8350 |
| | 450 | FRN355VG1S-4J | 2 | 8450 | 9100 | 5 ^{*1} | 9100 |
| | 500 | FRN400VG1S-4J | 2 | 9600 | 10350 | 5 ^{*1} | 10350 |
| 630 | FRN500VG1S-4J | 2 | 12050 | 12950 | 5 ^{*1} | 12950 | |
| 710 | FRN630VG1S-4J | 2 | 13500 | 13500 | - | - | |

(*1) If the generating loss set in F26 exceeds the value specified in this table, it is set to the same generating loss as that applied with the high carrier set regardless of the value in F26.

●MD specification generating loss

| Power supply voltage | Standard applicable motor capacity [kW] | Inverter type | Low carrier (At time of F26 factory default setting) | Medium carrier | |
|----------------------|---|---------------|---|----------------|---------------------|
| | | | Generating loss [W] | F26 [kHz] | Generating loss [W] |
| Three-phase 400 V | 110 | FRN90VG1S-4J | 2250 | - | - |
| | 132 | FRN110VG1S-4J | 2700 | - | - |
| | 160 | FRN132VG1S-4J | 3050 | - | - |
| | 200 | FRN160VG1S-4J | 3900 | - | - |
| | 220 | FRN200VG1S-4J | 4250 | - | - |
| | 250 | FRN220VG1S-4J | 4850 | - | - |
| | 315 | FRN280VG1S-4J | 5850 | - | - |
| | 355 | FRN315VG1S-4J | 6650 | - | - |
| | 400 | FRN355VG1S-4J | 7250 | - | - |
| 450 | FRN400VG1S-4J | 8250 | - | - | |

App. E Conversion from SI Units

All expressions given in Chapter 3, "SELECTING OPTIMAL MOTOR AND INVERTER CAPACITIES" are based on SI units (The International System of Units). This section explains how to convert expressions to other units.

[1] Conversion of units

(1) Force

- $1 \text{ (kgf)} \approx 9.8 \text{ (N)}$
- $1 \text{ (N)} \approx 0.102 \text{ (kgf)}$

(2) Torque

- $1 \text{ (kgf} \cdot \text{m)} \approx 9.8 \text{ (N} \cdot \text{m)}$
- $1 \text{ (N} \cdot \text{m)} \approx 0.102 \text{ (kgf} \cdot \text{m)}$

(3) Work and energy

- $1 \text{ (kgf} \cdot \text{m)} \approx 9.8 \text{ (N} \cdot \text{m)} = 9.8 \text{ (J)}$
 $= 9.8 \text{ (W} \cdot \text{s)}$

(4) Power

- $1 \text{ (kgf} \cdot \text{m/s)} \approx 9.8 \text{ (N} \cdot \text{m/s)} = 9.8 \text{ (J/s)}$
 $= 9.8 \text{ (W)}$
- $1 \text{ (N} \cdot \text{m/s)} \approx 1 \text{ (J/s)} = 1 \text{ (W)}$
 $\approx 0.102 \text{ (kgf} \cdot \text{m/s)}$

(5) Rotation speed

- $1 \text{ (r/min)} = \frac{2\pi}{60} \text{ (rad/s)} \approx 0.1047 \text{ (rad/s)}$
- $1 \text{ (rad/s)} = \frac{60}{2\pi} \text{ (r/min)} \approx 9.549 \text{ (r/min)}$

(6) Inertia constant

- $J \text{ (kg} \cdot \text{m}^2)$: moment of inertia
- $GD^2 \text{ (kg} \cdot \text{m}^2)$: flywheel effect

- $GD^2 = 4 J$

- $J = \frac{GD^2}{4}$

(7) Pressure and stress

- $1 \text{ (mmAq)} \approx 9.8 \text{ (Pa)} \approx 9.8 \text{ (N/m}^2)$
- $1 \text{ (Pa)} \approx 1 \text{ (N/m}^2) \approx 0.102 \text{ (mmAq)}$
- $1 \text{ (bar)} \approx 100000 \text{ (Pa)} \approx 1.02 \text{ (kg} \cdot \text{cm}^2)$
- $1 \text{ (kg} \cdot \text{cm}^2) \approx 98000 \text{ (Pa)} \approx 980 \text{ (mbar)}$
- $1 \text{ atmospheric pressure} = 1013 \text{ (mbar)}$
 $= 760 \text{ (mmHg)} = 101300 \text{ (Pa)}$
 $\approx 1.033 \text{ (kg/cm}^2)$

[2] Calculation formula

(1) Torque, power, and rotation speed

- $P (W) \approx \frac{2\pi}{60} \cdot N (r/min) \cdot \tau (N \cdot m)$
- $P (W) \approx 1.026 \cdot N (r/min) \cdot T (kgf \cdot m)$
- $\tau (N \cdot m) \approx 9.55 \cdot \frac{P (W)}{N (r/min)}$
- $T (kgf \cdot m) \approx 0.974 \cdot \frac{P (W)}{N (r/min)}$

(2) Kinetic energy

- $E (J) \approx \frac{1}{182.4} \cdot J (kg \cdot m^2) \cdot N^2 [(r/min)^2]$
- $E (J) \approx \frac{1}{730} \cdot GD^2 (kg \cdot m^2) \cdot N^2 [(r/min)^2]$

(3) Torque of linear moving load

Driving mode

- $\tau (N \cdot m) \approx 0.159 \cdot \frac{V (m/min)}{N_M (r/min) \cdot \eta_G} \cdot F (N)$
- $T (kgf \cdot m) \approx 0.159 \cdot \frac{V (m/min)}{N_M (r/min) \cdot \eta_G} \cdot F (kgf)$

Braking mode

- $\tau (N \cdot m) \approx 0.159 \cdot \frac{V (m/min)}{N_M (r/min) / \eta_G} \cdot F (N)$
- $T (kgf \cdot m) \approx 0.159 \cdot \frac{V (m/min)}{N_M (r/min) / \eta_G} \cdot F (kgf)$

(4) Acceleration torque

Driving mode

- $\tau (N \cdot m) \approx \frac{J (kg \cdot m^2)}{9.55} \cdot \frac{\Delta N (r/min)}{\Delta t (s) \cdot \eta_G}$
- $T (kgf \cdot m) \approx \frac{GD^2 (kg \cdot m^2)}{375} \cdot \frac{\Delta N (r/min)}{\Delta t (s) \cdot \eta_G}$

Braking mode

- $\tau (N \cdot m) \approx \frac{J (kg \cdot m^2)}{9.55} \cdot \frac{\Delta N (r/min) \cdot \eta_G}{\Delta t (s)}$
- $T (kgf \cdot m) \approx \frac{GD^2 (kg \cdot m^2)}{375} \cdot \frac{\Delta N (r/min) \cdot \eta_G}{\Delta t (s)}$

(5) Acceleration time

- $t_{ACC} (s) \approx \frac{J_1 + J_2 / \eta_G (kg \cdot m^2)}{\tau_M - \tau_L / \eta_G (N \cdot m)} \cdot \frac{\Delta N (r/min)}{9.55}$
- $t_{ACC} (s) \approx \frac{GD_1^2 + GD_2^2 / \eta_G (kg \cdot m^2)}{T_M - T_L / \eta_G (kgf \cdot m)} \cdot \frac{\Delta N (r/min)}{375}$

(6) Deceleration time

- $t_{DEC} (s) \approx \frac{J_1 + J_2 \cdot \eta_G (kg \cdot m^2)}{\tau_M - \tau_L \cdot \eta_G (N \cdot m)} \cdot \frac{\Delta N (r/min)}{9.55}$
- $t_{DEC} (s) \approx \frac{GD_1^2 + GD_2^2 \cdot \eta_G (kg \cdot m^2)}{T_M - T_L \cdot \eta_G (kgf \cdot m)} \cdot \frac{\Delta N (r/min)}{375}$

App. F Allowable Current of Insulated Wires

The tables below list the allowable current of IV wires, HIV wires, and 600 V cross-linked polyethylene insulated wires.

■ IV wires (Maximum allowable temperature: 60°C)

Table F.1 (a) Allowable Current of Insulated Wires

| 電線の径 (mm ²) | 許容電流 reference value (60°C以下) | 屋外の配線 | | | | | 電線の径に配線(同径の管内を以て) | | | |
|----------------------------|-------------------------------------|------------------------|------------------------|------------------------|------------------------|------------------------|------------------------|------------------------|------------------------|------------------------|
| | | 35°C | 40°C | 45°C | 50°C | 55°C | 35°C | 40°C | 45°C | 50°C |
| | | (I ₀ ×0.99) | (I ₀ ×0.88) | (I ₀ ×0.77) | (I ₀ ×0.58) | (I ₀ ×0.44) | (I ₀ ×0.66) | (I ₀ ×0.57) | (I ₀ ×0.49) | (I ₀ ×0.44) |
| I ₀ (A) | (A) | (A) | (A) | (A) | (A) | (A) | (A) | (A) | (A) | |
| 2.0 | 27 | 24 | 22 | 19 | 15 | 11 | 17 | 15 | 13 | 10 |
| 3.5 | 37 | 33 | 30 | 26 | 21 | 15 | 23 | 21 | 18 | 14 |
| 5.5 | 49 | 44 | 40 | 34 | 28 | 20 | 30 | 27 | 24 | 19 |
| 8.0 | 61 | 55 | 50 | 43 | 35 | 25 | 38 | 34 | 29 | 24 |
| 14 | 88 | 80 | 72 | 62 | 51 | 36 | 55 | 50 | 43 | 35 |
| 22 | 115 | 104 | 94 | 81 | 66 | 47 | 72 | 65 | 56 | 46 |
| 38 | 162 | 147 | 132 | 115 | 93 | 66 | 102 | 92 | 79 | 64 |
| 60 | 217 | 197 | 177 | 154 | 125 | 88 | 136 | 123 | 106 | 86 |
| 100 | 298 | 271 | 244 | 211 | 172 | 122 | 187 | 169 | 146 | 119 |
| 150 | 395 | 359 | 323 | 280 | 229 | 161 | 248 | 225 | 193 | 158 |
| 200 | 469 | 426 | 384 | 332 | 272 | 192 | 295 | 267 | 229 | 187 |
| 250 | 556 | 505 | 455 | 394 | 322 | 227 | 350 | 316 | 272 | 222 |
| 325 | 650 | 591 | 533 | 461 | 377 | 266 | 409 | 370 | 318 | 260 |
| 400 | 745 | 677 | 610 | 528 | 432 | 305 | 469 | 424 | 365 | 298 |
| 500 | 842 | 766 | 690 | 597 | 488 | 345 | 530 | 479 | 412 | 336 |
| 22 x 100 | 497 | 452 | 407 | 352 | 288 | 203 | 313 | 283 | 243 | 198 |
| 22 x 150 | 658 | 598 | 539 | 467 | 381 | 269 | 414 | 375 | 322 | 263 |
| 22 x 200 | 782 | 711 | 641 | 555 | 453 | 320 | 492 | 445 | 383 | 312 |
| 22 x 250 | 927 | 843 | 760 | 658 | 537 | 380 | 584 | 528 | 454 | 370 |
| 22 x 325 | 1083 | 985 | 888 | 768 | 628 | 444 | 682 | 617 | 530 | 433 |
| 22 x 400 | 1242 | 1130 | 1018 | 881 | 720 | 509 | 782 | 707 | 608 | 496 |
| 22 x 500 | 1403 | 1276 | 1150 | 996 | 813 | 575 | 883 | 799 | 687 | 561 |

■ HIV wires (Maximum allowable temperature: 75°C)

Table F.1 (b) Allowable Current of Insulated Wires

| 電線の径 (mm ²) | 許容電流 reference value (75°C以下) | 屋外の配線 | | | | | 電線の径に配線(同径の管内を以て) | | | |
|----------------------------|-------------------------------------|------------------------|------------------------|------------------------|------------------------|------------------------|------------------------|------------------------|------------------------|------------------------|
| | | 35°C | 40°C | 45°C | 50°C | 55°C | 35°C | 40°C | 45°C | 50°C |
| | | (I ₀ ×0.99) | (I ₀ ×0.88) | (I ₀ ×0.77) | (I ₀ ×0.58) | (I ₀ ×0.44) | (I ₀ ×0.66) | (I ₀ ×0.57) | (I ₀ ×0.49) | (I ₀ ×0.44) |
| I ₀ (A) | (A) | (A) | (A) | (A) | (A) | (A) | (A) | (A) | (A) | |
| 2.0 | 32 | 31 | 29 | 27 | 24 | 22 | 21 | 20 | 18 | 17 |
| 3.5 | 45 | 42 | 39 | 37 | 33 | 30 | 29 | 27 | 25 | 23 |
| 5.5 | 59 | 56 | 52 | 49 | 44 | 40 | 39 | 36 | 34 | 30 |
| 8.0 | 74 | 70 | 65 | 61 | 55 | 50 | 48 | 45 | 42 | 38 |
| 14 | 107 | 101 | 95 | 88 | 80 | 72 | 70 | 66 | 61 | 55 |
| 22 | 140 | 132 | 124 | 115 | 104 | 94 | 92 | 86 | 80 | 72 |
| 38 | 197 | 186 | 174 | 162 | 147 | 132 | 129 | 121 | 113 | 102 |
| 60 | 264 | 249 | 234 | 217 | 197 | 177 | 173 | 162 | 151 | 136 |
| 100 | 363 | 342 | 321 | 298 | 271 | 244 | 238 | 223 | 208 | 187 |
| 150 | 481 | 454 | 426 | 395 | 359 | 323 | 316 | 296 | 276 | 248 |
| 200 | 572 | 539 | 506 | 469 | 426 | 384 | 375 | 351 | 328 | 295 |
| 250 | 678 | 639 | 600 | 556 | 505 | 455 | 444 | 417 | 389 | 350 |
| 325 | 793 | 747 | 702 | 650 | 591 | 533 | 520 | 487 | 455 | 409 |
| 400 | 908 | 856 | 804 | 745 | 677 | 610 | 596 | 558 | 521 | 469 |
| 500 | 1027 | 968 | 909 | 842 | 766 | 690 | 673 | 631 | 589 | 530 |
| 2 x 100 | 606 | 571 | 536 | 497 | 452 | 407 | 397 | 372 | 347 | 313 |
| 2 x 150 | 802 | 756 | 710 | 658 | 598 | 539 | 526 | 493 | 460 | 414 |
| 2 x 200 | 954 | 899 | 844 | 782 | 711 | 641 | 625 | 586 | 547 | 492 |
| 2 x 250 | 1130 | 1066 | 1001 | 927 | 843 | 760 | 741 | 695 | 648 | 584 |
| 2 x 325 | 1321 | 1245 | 1169 | 1083 | 985 | 888 | 866 | 812 | 758 | 682 |
| 2 x 400 | 1515 | 1428 | 1341 | 1242 | 1130 | 1018 | 993 | 931 | 869 | 782 |
| 2 x 500 | 1711 | 1613 | 1515 | 1403 | 1276 | 1150 | 1122 | 1052 | 982 | 883 |

■ 600 V Cross-linked Polyethylene Insulated wires (Maximum allowable temperature: 90°C)

Table F.1 (c) Allowable Current of Insulated Wires

| 電線の径 (mm ²) | 許容電流 | 単相の配線 | | | | | 電線の径に配線(同サイズのケーブル) | | | |
|----------------------------|--------------------|------------------------|------------------------|------------------------|------------------------|------------------------|------------------------|------------------------|------------------------|------------------------|
| | reference value | 35°C | 40°C | 45°C | 50°C | 55°C | 35°C | 40°C | 45°C | 50°C |
| | (30°C 30°C) | (I ₀ ×0.99) | (I ₀ ×0.88) | (I ₀ ×0.77) | (I ₀ ×0.55) | (I ₀ ×0.44) | (I ₀ ×0.66) | (I ₀ ×0.55) | (I ₀ ×0.44) | (I ₀ ×0.44) |
| | I ₀ (A) | (A) | (A) | (A) | (A) | (A) | (A) | (A) | (A) | (A) |
| 2.0 | 38 | 36 | 34 | 32 | 31 | 29 | 25 | 24 | 22 | 21 |
| 3.5 | 52 | 49 | 47 | 45 | 42 | 39 | 34 | 33 | 31 | 29 |
| 5.5 | 69 | 66 | 63 | 59 | 56 | 52 | 46 | 44 | 41 | 39 |
| 8.0 | 86 | 82 | 78 | 74 | 70 | 65 | 57 | 54 | 51 | 48 |
| 14 | 124 | 118 | 113 | 107 | 101 | 95 | 82 | 79 | 74 | 70 |
| 22 | 162 | 155 | 148 | 140 | 132 | 124 | 108 | 103 | 97 | 92 |
| 38 | 228 | 218 | 208 | 197 | 186 | 174 | 152 | 145 | 137 | 129 |
| 60 | 305 | 292 | 279 | 264 | 249 | 234 | 203 | 195 | 184 | 173 |
| 100 | 420 | 402 | 384 | 363 | 342 | 321 | 280 | 268 | 253 | 238 |
| 150 | 556 | 533 | 509 | 481 | 454 | 426 | 371 | 355 | 335 | 316 |
| 200 | 661 | 633 | 605 | 572 | 539 | 506 | 440 | 422 | 398 | 375 |
| 250 | 783 | 750 | 717 | 678 | 639 | 600 | 522 | 500 | 472 | 444 |
| 325 | 916 | 877 | 838 | 793 | 747 | 702 | 611 | 585 | 552 | 520 |
| 400 | 1050 | 1005 | 961 | 908 | 856 | 804 | 700 | 670 | 633 | 596 |
| 500 | 1187 | 1136 | 1086 | 1027 | 968 | 909 | 791 | 757 | 715 | 673 |
| 22 × 1000 | 700 | 670 | 641 | 606 | 571 | 536 | 467 | 447 | 422 | 397 |
| 22 × 1500 | 927 | 888 | 848 | 802 | 756 | 710 | 618 | 592 | 559 | 526 |
| 22 × 2000 | 1102 | 1055 | 1008 | 954 | 899 | 844 | 735 | 703 | 664 | 625 |
| 22 × 2500 | 1307 | 1251 | 1195 | 1130 | 1066 | 1001 | 871 | 834 | 787 | 741 |
| 22 × 3000 | 1527 | 1462 | 1397 | 1321 | 1245 | 1169 | 1018 | 974 | 920 | 866 |
| 22 × 4000 | 1751 | 1676 | 1602 | 1515 | 1428 | 1341 | 1167 | 1117 | 1055 | 993 |
| 22 × 5000 | 1978 | 1894 | 1809 | 1711 | 1613 | 1515 | 1318 | 1262 | 1192 | 1122 |

High Performance, Vector Control Inverter

FRENIC-VG

User's Manual
(Unit Type / Function Codes Edition)

First Edition, July 2012

Third Edition, July 2019

Fuji Electric Co., Ltd.

The purpose of this manual is to provide accurate information in the handling, setting up and operating of the FRENIC-VG series of inverters. Please feel free to send your comments regarding any errors or omissions you may have found, or any suggestions you may have for generally improving the manual.

In no event will Fuji Electric Co., Ltd. be liable for any direct or indirect damages resulting from the application of the information in this manual.

 **Fuji Electric Co., Ltd.**

Gate City Ohsaki, East Tower, 11-2, Osaki 1-chome, Shinagawa-ku, Tokyo 141-0032, Japan
Phone : (03)5435-7111

Internet address : <http://www.fujielectric.co.jp>

Information in this manual is subject to change without notice.

2019-07